

J-TECH DIGITAL JTD-636 48-Port Switch Matrix User Manual

Home » J-TECH DIGITAL » J-TECH DIGITAL JTD-636 48-Port Switch Matrix User Manual





USER MANUAL



J-Tech Digital 48-Port Switch Matrix JTD-636 | JTECH-48NS

Dear Customer

Thank you for purchasing this product. For optimum performance and safety concerns, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

Contents

- 1 Features
- 2 Package Contents
- 3 Typical Applications
 - 3.1 One to Many Configuration
 - 3.2 Many to Many Configuration
 - 3.3 Login to the switch
- 3.4 After clicking the Login button, the current port routing will be shown as below: PORT TOOLS
- 3.5 System
- 3.6 Port Cable Test
- **4 WARRANTY**
- 5 Documents / Resources
- **6 Related Posts**

Features

- 10Mbps/100Mbps/1000Mbps Network Switch Specially Optimized for J-Tech Digital's HDMI extender matrix.
- Port 1 to Port 46 can be reconfigured as input or output ports & User-friendly Web GUI for Port-to-Port routing.
- Port 47 & 48 are exclusively for management. Supports user management.
- Firmware upgrades and free technical support from J-Tech Digital. Android control app is available on Google Play: search "J-Tech Digital Control" to find more details.

Notice

J-Tech Digital, Inc reserves the right to make changes in the hardware, packaging, and any accompanying documentation without prior written notice.

Package Contents


- User manual X1
- · Warranty Card X1
- JTECH-48NS X1
- Rackmount Ears X2
- Power Cable X1

Typical Applications

One to Many Configuration



One to Many



Many to Many Configuration



Login to the switch


Step 1: Connect your PC (or laptop) to this switch on port 48 (default management port), revise your PC's IP address; PC's IP: 192.168.168.11(0-255), PC's IP address must be different than Switch's IP address (192.168.168.254 default IP).

Step 2: Open a web browser and type in this address 'Http://192.168.168.254' (192.168.168.254 is the default IP address), input **Username: admin, Password: admin**



Username: Password:
Password:
Login

After clicking the Login button, the current port routing will be shown as below:




PORT TOOLS

1. Port Setting

Referencing your desired Transmitter (TX) and Receiver (RX) connections, designate your available ports as an Input ports or Output ports in the web GUI.


Here is an example that demonstrates how to change port 45 and port 46 from Output to Input ports. Follow Steps 1 3 below:



After clicking the 'Edit' button, you will see the input/output setting and be able to add a description for the port.




Click Apply and Port 45 and Port 46 will change from output to input.




2. Port Routing

In PORT TOOLS, you can set each "Output" port to display any "Input" port's content. For example, if you want the output P14 and P15 to display the same Input source (port 1), you can set it as below:




After these steps, the matrix will send P1 source to output ports P14 and P15.

You can use mode 1-4 to save and recall customized port routing configurations. Here is an example setting port routing data for mode2.




After you click `Save and Apply', Mode2 routing configuration will be saved, and the routing data will be applied to the switch.




System

1. User management




Add a user account via steps 1-7 and edit a user account following steps 8-12 shown below:






Also, you can delete a user account as below:




2. System Config

Setting IP address, subnet mask, gateway for matrix.




After clicking "Apply" the device will apply the new IP information. You will need to use these new settings to login to the web GUI.

3. System Status




4. Upgrade Firmware

Follow steps 1-4 to upgrade the firmware. It will take up to 10 minutes to complete. Don't power off during the upgrade process. After you finish the upgrade, you can reboot the unit.



5. Reboot



After steps 1 & 2, a dialogue box will display "Reboot the system, Do you want to continue?", click ok. Please note that if `ok" is not selected promptly, you may be asked to login to the web gui again.

6. Restore Factory Default Settings

`Restore Factory Default` will set the switch to the default settings.



After step 2, a dialogue box will display" Restore to factory defaults, You need to reboot the device to take effect. Do you want to continue?" Click ok to continue. The dialogue box will display "Reboot the device to take effect now, Do you want to continue?" Click ok to reboot the system. Factory Default settings

IP address192.168.168.254

Subnet mask255.255.255.0


Gateway 192.168.1.1

Account admin


Password admin

Management portport 47port 48

Port Cable Test



After steps 1-4, you will receive the cable test results. A status example is shown below:



WARRANTY

With the registration of supported J-Tech Digital products, you extend the current warranty by 6 months. This extension is added to the warranty that starts at the purchase date of the device supported. Total product warranty with the extended period will equate to a total of 18 months of warranty from the date of purchase.

For extended warranties to be accepted, all warranty extensions must be claimed within 30 days of purchasing the eligible J-Tech Digital product. Extensions attempted to be claimed outside of the 30-day window will not be accepted.



Documents / Resources



Manuals+,