




SPARC Fire Core and SPARC Fire Clad Machines

Quick Start Guide


Contents [[hide](#)]


- 1 Key Pad Overview
- 2 Fiber Preparation
- 3 Splicing Operation
- 4 Documents / Resources
 - 4.1 References



Key Pad Overview



Calibration



Calibration should be done daily. With machine on the WorkBench screen (which is initial startup screen), hit the back button  .

Navigate to the Maintenance Menu.  Click the Maintenance option.  Press “OK” to begin the calibration steps.


Hit Set to begin each step

NOTE: Steps 3-6 require that prepared fiber is set in both holders.




Steps 1 and 2 will operate with or without fiber.

Startup

Upon power up, the initial screen will be the WorkBench.



The default settings are Splice Mode: SM_ AUTO and HEATER MODE: 60mm.

If you need to change these settings hit the RETURN key  to return to the main menu and click the Splice Mode icon  (we recommend SM_ AUTO or MM_ AUTO), and adjust settings as needed. To change Heater Mode for different sized protection sleeves, click the Heater Mode icon  and choose the setting that best matches the size of your protection sleeve.

Fiber Preparation



Fiber Stripper Hole Chart

Hole 1		600-900um	Outer Jacket
Hole 2		250um	Buffer
Hole 3		125um	Coating



STEP 1

Carefully slip on protective sleeve and slide down for later use.

STEP 2

Strip outer jacket using Hole 1 on JIC-375.

STEP 3

Cut Aramid Yarn using JIC-186.




STEP 4

Strip buffer using Hole 2 on JIC-375.

STEP 5

Carefully remove coating using Hole 3 on JIC-375.



<p>STEP 6</p> <p>Clean the fiber using included fiber wipes (FW series).</p>	<p>STEP 7</p> <p>Place fiber in the correct channel for your fiber size, exposed fiber end should be in the automatic trash can, close lid to cleave. (Check manual for more information)</p>
---	--



<https://uqr.to/1y0pp>

Splicing Operation

Splicing steps while AUTO SPLICING is enabled

<p>STEP 1</p> <p>Open the Fusion Chamber and fiber holders.</p>	<p>STEP 2</p> <p>Seat fiber in holder, in V-groove, as close to the electrodes without touching.</p>	<p>STEP 3</p> <p>Gently close the fiber holder. Repeat process for second fiber.</p>



STEP 4

Gently close the Fusion Chamber cover. Splicing happens automatically.

STEP 5

Slide the sleeve over the splice and place it in the heater.

STEP 6

Press the heat button. The red light will turn on with a beep, and once complete, it will turn off with a second beep.

Spliced Fiber Result




Once completed remove fiber and set aside to cool.

NOTE: When splicing splice on connectors, make sure to swap the included fiber holders. Check manual for more details.



Heat Chamber Connector Fiber Holder







Fusion Chamber Connector Fiber Holder

Cleaning

For routine maintenance, use the Jonard Tools® CWP-125 Pointed Cleaning Swabs to effectively remove debris. For significant contamination, pair them with the Jonard Tools® FCF-3 Fiber Cleaning Fluid. Avoid using water; always use 99% or higher

isopropyl alcohol to ensure compliance with industry standards and prevent damage. Regular maintenance is recommended before every use to keep SPARC Fusion Splicers operating as designed.

		
<p>STEP 1</p> <p>Use Pointed Cleaning Swabs to gently remove all scrap fiber from the V-grooves.</p>	<p>STEP 2</p> <p>Carefully clean the lens located under the rear electrode positioned between the Fusion Chamber and the Heat Chamber.</p>	<p>STEP 3</p> <p>Wipe the Fiber Stabilizers located under the Fusion Chamber Cover.</p>



STEP 4

Ensure the LED lights under the Fusion Chamber Cover are free from debris.

Warning: Do not touch any of the components (V-grooves, lens, fiber stabilizers or LED lights) with your fingers. Oil and residue from your fingers can damage the machine and affect its performance. Always use appropriate cleaning tools to avoid contamination.




<https://uqr.to/1y627>

Support Notice

Support is available only for registered SPARC Fusion Splicers. Register by scanning the QR code to ensure eligibility for assistance, warranty, and repairs.

Email FusionSupport@jonard.com

Battery Pack and Power Indicators




The SPARC™ Fusion Splicer supports uninterrupted operation.

It can be used while plugged in, allowing the battery to charge during use. With two batteries, you can charge one externally while working with the other, ensuring uninterrupted splicing.



Documents / Resources

	JONARD TOOLS SPARC Fusion Splicer [pdf] User Guide SPARC Fire Core, SPARC Fire Clad, SPARC Fusion Splicer, SPARC, Fusion Splicer, Splicer
---	--

References

- [User Manual](#)

■ JONARD

TOOLS

◆ Fusion Splicer, JONARD TOOLS, SPARC, SPARC Fire Clad, SPARC Fire Core, SPARC Fusion Splicer, Splicer

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.