



KARCHER K5 Premium Power Control K5 Power Control User Guide

[Home](#) » [Karcher](#) » KARCHER K5 Premium Power Control K5 Power Control User Guide 

Contents


- 1 KARCHER K5 Premium Power Control K5 Power Control
- 2 Illustrations
- 3 KÄRCHER Home & Garden app
- 4 Environmental protection
- 5 Intended use
- 6 Accessories and spare parts
- 7 Scope of delivery
- 8 Description of the device
 - 8.1 Supplied screws and dowelsIllustration C
- 9 Safety devices
 - 9.1 Power switch
 - 9.2 High-pressure gun lock
 - 9.3 Auto-stop function
 - 9.4 Motor circuit breaker
- 10 Symbols on the device
 - 10.1 Fitting the wheels
 - 10.2 Mounting the stand
 - 10.3 Installing the spray lance storage
 - 10.4 Mounting the transport handle
 - 10.5 Mounting the accessory net
 - 10.6 Push the high-pressure hose through the hose guide
 - 10.7 Installing the water connection coupling
- 11 Initial startup
 - 11.1 Water supply
 - 11.2 Connection to the water line
 - 11.3 Sucking water from open containers
 - 11.4 Vent the device
- 12 Operation
 - 12.1 Power Control System
 - 12.2 High-pressure operation
 - 12.3 Operation with a washing brush
 - 12.4 Operation with detergent
 - 12.5 Recommended cleaning method
 - 12.6 After operation with detergent
 - 12.7 Interrupting operation
 - 12.8 Ending operation
- 13 Transport
 - 13.1 Carrying the device
 - 13.2 Pulling the device
 - 13.3 Transporting the device in a vehicle
- 14 Storage
 - 14.1 Storing the device
 - 14.2 Frost protection
- 15 Care and service
 - 15.1 Clean the sieve in the water connection
- 16 Troubleshooting guide
- 17 Warranty
- 18 Technical data
- 19 EU Declaration of Conformity
- 20 Documents / Resources
 - 20.1 References
- 21 Related Posts






KÄRCHER







KARCHER K5 Premium Power Control K5 Power Control



Illustrations







General notes

Read these original operating instructions and the enclosed safety instructions before using the device for the first time. Proceed accordingly.

Keep both books for future reference or for future owners.

KÄRCHER Home & Garden app

The KÄRCHER Home & Garden app contains:

- Installation and initial startup information
- Information about the areas of application
- Tips & Tricks
- FAQ with detailed troubleshooting
- Connection to the KÄRCHER Service Centre The app can be downloaded here:



Trademarks

- Google Play™ and Android™ are trademarks or registered trademarks of Google Inc.
- Apple® and App store® are trademarks or registered trademarks of Apple Inc.

Environmental protection

The packing materials can be recycled. Please dispose of packaging in accordance with the environmental regulations. Electrical and electronic appliances contain valuable, recyclable materials and often components such as batteries, rechargeable batteries or oil, which – if handled or disposed of incorrectly – can pose a potential danger to human health and the environment. However, these components are required for the correct operation of the appliance. Appliances marked by this symbol are not allowed to be disposed of together with the household rubbish. Cleaning work producing in oily waste water, e.g. washing engines, washing undercarriages etc., may only be performed at washing stations with an oil separator. Working with detergents may only be performed on watertight surfaces with connection to the waste water sewage system. Do not allow detergent to enter waterways or the soil. Extraction of water from public waterways is not permitted in some countries.

Notes on the content materials (REACH)

Current information on content materials can be found at: www.kaercher.de/REACH

Intended use

Use the high-pressure cleaner in private households only. The high-pressure cleaner is intended for cleaning machines, vehicles, buildings, tools, façades, terraces, garden machines etc. using a high-pressure water jet.

Accessories and spare parts

Only use original accessories and original spare parts. They ensure that the appliance will run fault-free and safely. Information on accessories and spare parts can be found at www.kaercher.com.

Scope of delivery

The scope of delivery for the appliance is shown on the packaging. Check the contents for completeness when unpacking. If any accessories are missing or in the event of any shipping damage, please notify your dealer.

Description of the device

The maximum amount of equipment is described in these operating instructions. Depending on the model used, there are differences in the scope of delivery (see packaging).

For the illustrations, refer to the graphics page

Illustration A

Illustration B

1. Stand with carrying handle
2. Water connection with integrated sieve
3. Transport wheel
4. Visor
5. Hose guide
6. Trigger "0/OFF" / "I/ON"
7. Storage for spray lance
8. High-pressure hose
9. *Plug 'n' Clean detergent bottle
10. Storage / parking position for high-pressure gun
11. Transport handle, telescoping
12. Power Control spray lance dirt grinder for stubborn dirt, pressure level: HARD
13. Vario Power Power Control spray lance for the most common cleaning tasks, pressure levels: HARD / MEDIUM / SOFT / MIX
14. Power Control high-pressure gun
15. Button for separating the high-pressure hose from the high-pressure gun
16. High-pressure gun lever
17. Pressure indicator (0-MIX / 1-SOFT / 2-MEDIUM / 3-HARD)
18. High-pressure gun lock
19. Carrying handle
20. Hose holder
21. High pressure hose reel
22. Crank handle for hose reel
23. Type plate
24. Accessory compartment
25. Hook for net attachment
26. Accessory compartment net
27. Mains connection with mains plug
28. Water connection coupling
29. **Garden hose (fabric reinforced, diameter at least 1/2 inch (13 mm), length at least 7.5 m, with commercially available quick coupling)
30. **KÄRCHER suction hose for water supply from open containers (order no. 2.643-100.0)
31. Supplied screws and dowels
32. *Foam nozzle with detergent container: The detergent is sucked out of the container to produce a strong

detergent foam.

33. *Rotating washing brush (e.g. for washing cars) * optional, ** additionally required

Supplied screws and dowels

Illustration C

1. Stand dowels (2 pieces)
2. Screw M 4×20 (2 pieces)
3. Screw M 4×22 (2 pieces)
4. Screw M 4×16 (8 pieces)

Safety devices

CAUTION

Missing or modified safety devices Safety devices are provided for your own protection. Never modify or bypass safety devices.

Power switch

The power switch prevents unintentional operation of the device.

High-pressure gun lock

The lock locks the lever of the high-pressure gun and prevents the device from starting unintentionally.

Auto-stop function

If the lever of the high-pressure gun is released, the pressure switch turns off the pump and the high-pressure jet stops. The pump switches on again when the lever is pressed.

Motor circuit breaker

The motor circuit breaker shuts off the device if power consumption is too high.

Symbols on the device

Do not aim the high-pressure jet at persons, animals, live electrical equipment or the device itself. Protect the device against frost. The device may not be connected to the public drinking water network.

Fitting the wheels

1. Insert the wheels.

Note Pay attention to the alignment of the hole.

Illustration D

2. Secure the wheels with 1 screw each.

Mounting the stand

1. Insert the stand.

Illustration E

2. Insert the 2 dowels into the holes as far as they will go.
3. Secure the base with 2 screws.

Installing the spray lance storage

1. Hang the spray lance storage in position. Secure the storage with
2. Screws.

Illustration F

3. Secure the cover with 4 screws.

Illustration G

Mounting the transport handle

1. Attach the transport handle.

Illustration H

2. Secure the transport handle with 2 screws.

Mounting the accessory net

1. Hang the accessory net on the hooks.

Illustration I

Push the high-pressure hose through the hose guide

1. Insert the high-pressure hose through the hose guide from the rear.

Illustration J

Installing the water connection coupling

1. Screw the water connection coupling onto the water connection on the device.

Illustration K

Initial startup

1. Place the device on a flat and level surface.
2. For devices with a hose reel: Completely unwind the high-pressure hose from the hose reel.
3. For devices without a hose reel: Unwind the high-pressure hose completely and eliminate any loops and twists.
4. Pull the high-pressure hose all the way forwards through the hose guide.
5. Insert the high-pressure hose into the high-pressure gun until it audibly latches into place.

Note: Take care to ensure the correct alignment of the nipple.

6. Check for a secure connection by pulling on the high-pressure hose.
7. Plug the mains plug into a mains socket.

Water supply

For the connection values, see the type plate or chapter Technical data. Observe the water distribution company regulations

ATTENTION

Damage through contaminated water Contamination in the water can damage the pump and the accessories. KÄRCHER recommends using the KÄRCHER water filter for protection(special accessory, order number 4.730-059).

Connection to the water line

ATTENTION

Hose coupling with Aqua stop on the water connection of the device

Damage to the pump

Never use a hose coupling with Aqua stop on the water connection of the device. You can use an Aqua stop coupling on the tap.

1. Plug the garden hose onto the water connection coupling.
2. Connect the garden hose to the water line.
3. Open the water tap fully.

Illustration M

Sucking water from open containers

When used with the KÄRCHER suction hose with check valve (special accessory, order number 2.643-100) this high-pressure cleaner is suitable for sucking up surface water, e.g. from rain barrels or ponds (for the maximum suction height see chapter Technical data). The water connection coupling is not required for vacuuming operation.

1. Fill the suction hose with water.
2. Screw the suction hose onto the device water connection and hang it in a water source (e.g. water butt).

Vent the device

1. Switch the device on "I/ON".
2. Unlock the lever of the high-pressure gun.
3. Press the lever of the high-pressure gun. The device switches on.
4. Allow the device for run a maximum of 2 minutes until the water escaping from the high-pressure gun is free of air bubbles.
5. Release the lever of the high-pressure gun.
6. Lock the lever of the high-pressure gun.

Operation

ATTENTION





Pump running dry Damage to the device If pressure does not build up in the device after 2 minutes then switch the device off and proceed according to the instructions in chapter Troubleshooting guide.

Power Control System

The pressure indicator on the high-pressure gun shows the currently set pressure level when operating with a Power Control spray lance.

Note: The sensitivity of materials can vary greatly depending on age and condition. The recommendations are therefore not binding.

Note: When operating with surface cleaner and other accessories, the pressure indicator is not accurate.

Display	Pressure level	Recommended for e.g.
	HARD	Stone terraces made of paving stones or washed concrete, asphalt, metal surfaces, garden utensils (wheelbarrow, spade, etc.)
	MEDIUM	Cars / motorcycles, brick surfaces, plastered walls, plastic furniture
	SOFT	Wooden surfaces, bicycle, sandstone surfaces, rattan furniture
	MIX	Operation with detergent

High-pressure operation

ATTENTION

Damage to painted or sensitive surfaces Surfaces can be damaged when the jet is too close to the surface or an unsuitable spray lance is used. Maintain a minimum spray distance of 30 cm when cleaning painted surfaces. Do not clean car tyres, paint or sensitive surfaces such as wood with the dirt grinder.

1. Insert a spray lance into the high-pressure gun and lock it by turning it 90°.

Illustration N

2. Switch the device on ("I/ON").
3. Unlock the lever of the high-pressure gun.
4. Press the lever of the high-pressure gun. The device switches on.
5. Turn the Vario Power Power Control spray lance until the required pressure level is shown on the pressure indicator.

Operation with a washing brush

ATTENTION

Paint damage

Damage to surfaces through a dirty brush Ensure that the washing brush is free from dirt or other particles before

using it.

Note The device operates at low pressure when using washing brushes. This means that detergent can be mixed with the water.

1. Insert the washing brush into the high-pressure gun and turn by 90° to fasten it.

Operation with detergent

DANGER Failure to adhere to the safety data sheet Incorrect handling of the detergent can seriously damage your health Observe the safety data sheet of the detergent manufacturer, in particular the instructions on personal protective equipment.

Note Detergent can only be mixed into the jet at low pressure.

Note A Plug 'n' Clean detergent bottle is required for operating with detergent. KÄRCHER detergent can be purchased ready to use in a Plug 'n' Clean detergent bottle.

1. Remove the cover from the Plug 'n' Clean detergent bottle.
2. Plug the detergent bottle into the Plug 'n' Clean detergent connection with the opening facing down.

Illustration O

3. Use the Vario Power spray lance.
4. Turn the spray lance towards "MIX" until "MIX" is displayed on the high-pressure gun. The detergent solution is mixed with the water jet during operation.
5. You can optionally use the foam nozzle. a Fill the detergent solution into the detergent tank.
 - Adhere to the dosage specifications on the detergent container.
 - Connect the foam nozzle to the detergent container.
 - Insert the foam nozzle into the high-pressure gun and turn by 90° to fasten it.

Illustration P

Recommended cleaning method

1. Spray the detergent sparingly on the dry surface and let it work for a while (do not let it dry).
2. Rinse off the loosened dirt with the high-pressure jet.

After operation with detergent

1. Pull the Plug 'n' Clean detergent bottle out of the mount and close it with the cap before transporting the device lying down.
2. Store the detergent bottle in the holder with the lid facing up.
3. Flush the device with clear water for approx. 30 seconds.

Interrupting operation

1. Release the lever of the high-pressure gun. The device switches off when the lever is released. The high pressure in the system is retained.
2. Lock the lever of the high-pressure gun.

Illustration Q

3. Place the high-pressure gun with the spray lance in the parking position.
4. Switch the device off "0/OFF" during work breaks longer than 5 minutes.

Ending operation

CAUTION

Pressure in the system Injuries from high-pressure water escaping uncontrollably Only disconnect the high-pressure hose from the high-pressure gun or the device when the system is fully depressurized.

1. Release the lever of the high-pressure gun.
2. Close the water tap.
3. Press the lever of the high-pressure gun for 30 seconds. The pressure remaining in the system is discharged.
4. Release the lever of the high-pressure gun.
5. Lock the lever of the high-pressure gun.
6. Disconnect the device from the water supply.
7. Switch off the device "0/OFF".
8. Pull the mains plug out of the socket.

Transport

CAUTION

Failure to observe the weight Risk of injury and damage Be aware of the weight of the device during transportation.

Carrying the device

1. Lift and carry the device by the carrying handles.

Pulling the device

1. Pull the transport handle out until it audibly latches into place.
2. Pull the device via the transport handle.

Transporting the device in a vehicle

1. Before transporting lying down, pull the Plug 'n' Clean detergent bottle out of the mount and close it with the cap.
2. Secure the device against slipping and tipping over.

Storage

CAUTION

Failure to observe the weight Risk of injury and damage Be aware of the weight of the device during storage.

Storing the device

1. Place the device on a level surface.
2. Disconnect the spray lance from the high-pressure gun.
3. Press the separation button on the high-pressure gun and disconnect the high-pressure hose from the high-pressure gun.

ATTENTION

Damage to the high-pressure hose Damage to the high-pressure hose through incorrect direction of rotation
Observe the correct direction of rotation of the hose reel when winding on the hose.

4. For devices with a hose reel: Use the crank handle to turn the hose reel anticlockwise and coil up the high-pressure hose.
5. For devices without a hose reel: Store high-pressure hose completely and eliminate any loops and twists.
6. Store the mains connection cable and accessories on the device.

Observe the additional instructions before storing the device for a longer period of time, see chapter Care and service.

Frost protection

ATTENTION

Danger of frost Incompletely emptied devices can be destroyed by frost. Completely empty the device and accessories. Protect the device from frost.

The following requirements must be satisfied:

- The device is disconnected from the water supply.
- The high-pressure gun is disconnected from the high-pressure hose.

1. Switch the device on "I/ON".
2. Wait for a maximum of 1 minute until no more water escapes from the high-pressure hose.
3. Switch off the device.
4. Store the device in a frost-protected room, together with all accessories.

Care and service

- **DANGER**

Danger of electric shock Injuries due to touching live parts Switch off the device. Remove the mains plug. The device is maintenance-free, i.e. you do not need to perform any maintenance work.

Clean the sieve in the water connection

ATTENTION

Damaged sieve in the water connection Damage to the device through contaminated water Check the sieve for damage before inserting it in the water connection. If necessary, clean the sieve in the water connection.

1. Remove the water connection coupling.
2. Pull the sieve out using flat pliers.
3. Clean the sieve under running water.

Illustration R

4. Insert the sieve into the water connection.

Troubleshooting guide

Malfunctions often have simple causes that you can remedy yourself using the following overview. When in doubt, or in the case of malfunctions not mentioned here, please contact your authorized Customer Service.

DANGER Danger of electric shock Injuries due to touching live parts Switch off the device. Remove the mains plug.
Device not running

1. Press the lever of the high-pressure gun. The device switches on.
2. Check that the voltage specified on the type plate corresponds to the voltage of the power source.
3. Check the mains connection cable for damage.
4. If the motor is overloaded and the motor circuit breaker has triggered:
 - Switch off the device "0/OFF".
 - Allow the device to cool down for 1 hour.
 - c Switch the device on "I/ON" and resume operation. Have the device checked by Customer Service if this fault occurs repeatedly.

The device does not start up, the motor buzzes Voltage drop due to a weak mains grid or when using an extension cable

1. When switching on, first press the lever on the high-pressure gun and then switch on the device "I/ON".

Device does not reach required pressure The water supply is too low

1. Open the water tap fully.
2. Check the water inlet for an adequate flow rate. The sieve in the water connection is dirty.
 - Pull the sieve in the water connection out using flat pliers.
 - Clean the sieve under running water. Air is in the device.
 - Vent the device:
 - Switch on the device without a connected spray lance for a maximum of 2 minutes.
 - Press the high-pressure gun and wait until the water escaping from the high-pressure gun is free of air bubbles.
 - Connect the spray lance.
 - Observe the maximum suction height during suction operation (see chapter Technical data).

Strong pressure fluctuations

1. Clean the high-pressure nozzle:
 - Use a needle to remove dirt from the nozzle drill.
 - Rinse the high-pressure nozzle from the front with water.
2. Check the water supply volume. Device leaking
 1. The device leaks a small amount for technical reasons. If the leak is severe, request authorized Customer Service.

Detergent is not sucked in

1. Use the Vario Power spray lance and turn it to "MIX".
2. Check that the Plug 'n' Clean detergent bottle is sitting correctly with the opening facing down in the detergent connection.

Warranty

The warranty conditions issued by our relevant sales company apply in all countries. We shall remedy possible malfunctions on your appliance within the warranty period free of cost, provided that a material or manufacturing defect is the cause. In a warranty case, please contact your dealer (with the purchase receipt) or the next authorized customer service site.

(See overleaf for the address)

Technical data

Electrical connection			
Voltage	V	230	230
Phase	~	1	1
Frequency	Hz	50	50
Power rating	kW	2,1	2,1
Degree of protection		IPX5	IPX5
Protection class		I	I
Power protection (slow-blowing)	A	10	10
Water connection			
Feed pressure (max.)	MPa	1,2	1,2
Input temperature (max.)	°C	40	40
Input amount (min.)	l/min	10	10
Suction height (max.)	m	0,5	0,5
Device performance data			
Operating pressure	MPa	12,5	12,5
Max. permissible pressure	MPa	14,5	14,5
Water flow rate	l/min	7,5	7,5
Maximum flow rate	l/min	8,3	8,3
Detergent flow rate	l/min	0,3	0,3
High-pressure gun recoil force	N	20	20
Dimensions and weights			
Typical operating weight	kg	15,8	14,8
Length	mm	414	402
Width	mm	306	306
Height	mm	588	588
Determined values in acc. with EN 60335-2-79			
Hand-arm vibration value	m/s ²	<2,5	<2,5
Uncertainty K	m/s ²	0,6	0,6
Sound pressure level L _{pA}	dB(A)	76	76
Uncertainty K _{pA}	dB(A)	3	3
Sound power level L _{WA} + K uncertainty _{WA}	dB(A)	92	92

Subject to technical modifications.

EU Declaration of Conformity

We hereby declare that the machine described below complies with the relevant basic safety and health requirements in the EU Directives, both in its basic design and construction as well as in the version placed in circulation by us. This declaration is invalidated by any changes made to the machine that are not approved by us.

Product: High-pressure cleaner

Type: 1.324-xxx

Currently applicable EU Directives

- 2000/14/EC
- 2014/30/EU

- 2006/42/EC (+2009/127/EC)
- 2011/65/EU

Harmonised standards used

- EN 50581
- EN 55014-1: 2017
- EN 55014-2: 2015
- EN 60335-1
- EN 60335-2-79
- EN 61000-3-2: 2014
- EN 61000-3-3: 2013
- EN 62233: 2008

Conformity evaluation procedure used

- 2000/14/EC: Annex V

Sound power level dB(A)

Measured: 89

Guaranteed: 92

The undersigned act on behalf and under the power of attorney of the company management.



H. Jenner

Chairman of the Board of Management




S. Reiser






Director Regulatory Affairs & Certification

- Documentation supervisor:
- S. Reiser
- Alfred Kärcher SE & Co. KG
- Alfred-Kärcher-Str. 28 – 40
- 71364 Winnenden (Germany)
- Ph.: +49 7195 14-0
- Fax: +49 7195 14-2212
- Winnenden, 2020/08/01

Documents / Resources

	<p>KARCHER K5 Premium Power Control K5 Power Control [pdf] User Guide K5 Premium Power Control K5 Power Control, K5 Premium Power Control, K5 Power Control, Power Control, Premium Power Control, K5</p>
---	--

References

-  [Cher - Official Site](#)
-  [Cleaning equipment and pressure washers | Kärcher International](#)
-  [Home Garden Warranty Registration Karcher North America USA | Kärcher](#)
-  [Reinigungsgeräte und Hochdruckreiniger | Kärcher](#)
-  [Lieferkette und Produkte | Kärcher](#)

Manuals+.