



**KGD-6-AM Ammonia  
Detector Controller  
and Transducer**



# Kele KGD-6-AM Ammonia Detector Controller and Transducer User Manual

[Home](#) » [Kele](#) » Kele KGD-6-AM Ammonia Detector Controller and Transducer User Manual 

## Contents

- [1 Kele KGD-6-AM Ammonia Detector Controller and Transducer](#)
- [2 Specifications](#)
- [3 Product Information](#)
- [4 Features](#)
- [5 GENERAL SAFETY INFORMATION](#)
- [6 USE INSTRUCTIONS AND LIMITATIONS](#)
- [7 Specifications](#)
- [8 Installation](#)
- [9 MAINTENANCE](#)
- [10 WARRANTY](#)
- [11 FAQ](#)
- [12 Documents / Resources](#)
  - [12.1 References](#)
- [13 Related Posts](#)



**Kele KGD-6-AM Ammonia Detector Controller and Transducer**



## Specifications

- **Power:** 3 W (max) from 12 to 24 VAC or 12 to 32 VDC Current @ 24 VDC: 75 mA in alarm (two relays), 50 mA (fan relay only), and 23 mA standby

## Product Information

### General Description:

The Kele KGD-6-AM is a low voltage, dual relay Ammonia (AM) detector and automatic ventilation controller. It utilizes a microcomputer-controlled electronic system to measure the concentration of Ammonia, actuate relays, and provide a 4-20mA output. The device features a field-replaceable electrochemical sensor with an expected life of 2+ years and is capable of displaying Ammonia levels from 0 to 100ppm.

## Features

- Conforms to UL std. 61010-1, Certified to CSA Std. C22.2 No 61010-1
- Low level meter displaying from 0-100 ppm Ammonia
- Meets NIOSH and OSHA standards for gas exposure
- Selectable fan and alarm relay activation
- 5 A SPDT fan relay controls starters of exhaust fans
- 0.5 A N.O. or N.C. alarm relay connects to warning devices or control panels
- 4-20 mA Current Loop
- Mounts on a standard 4x4 electrical box and becomes the cover for the box
- Supervised system: internal detector problems activate the fan & alarm relay
- Calibration kit available with easy access for calibration or gas test

## GENERAL SAFETY INFORMATION

## Intended Use

The Kele KGD-6-AM is a low voltage, dual relay Ammonia (NH<sub>3</sub>) detector, controller and transducer. The KGD-6-AM has selectable 4-20 mA output, buzzer and digital display options. It is an electronic detection system used to measure the concentration of NH<sub>3</sub> and provide feedback and automatic exhaust fan control to help reduce NH<sub>3</sub> concentrations in industrial refrigeration, warehouses, hockey rinks or other commercial applications. The KGD-6-AM is a low level meter capable of displaying from 0-100 ppm of Ammonia. The KGD-6-AM is factory calibrated and 100% tested for proper operation, but can also be calibrated in the field.

List of Warnings and Cautions within these User Instructions

## WARNING

- Each person using this equipment must read and understand the information in these User Instructions before use. Use of this equipment by untrained or unqualified persons, or use that is not in accordance with these User Instructions, may adversely affect product performance and result in sickness or death.
- Use only for monitoring the gas which the sensor and instrument are designed to monitor. Failure to do so may result in exposures to gases not detectable and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).
- This equipment may not function effectively below 0F or above 125 F (-18 C or above 52 C). Using the detector outside of this temperature range may adversely affect product performance and result in sickness or death.
- This detector helps monitor for the presence and concentration level of a certain specified airborne gas. Misuse may produce an inaccurate reading, which means that higher levels of the gas being monitored may be present and could result in overexposure and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).
- High voltage terminals (100-240VAC) are located within this detector, presenting a hazard to service technicians. Only qualified technicians should open the detector case and service the internal circuits. Ensure power is removed from the detector prior to servicing the unit. Failure to do so may result in sickness or death.
- Do not disassemble unit or attempt to repair or modify any component of this instrument. This instrument contains no user serviceable parts, and substitution of components may impair product performance and result in sickness or death.
- Using a certified gas with a concentration other than the one listed for this detector when conducting a calibration or calibration verification test (bump test) will produce inaccurate readings. This means that higher levels of the gas being monitored may be present and could result in overexposure and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).
- The following steps must be performed when conducting a calibration or calibration verification test (bump test) to ensure proper performance of the monitor. Failure to do so may adversely affect product performance and result in sickness or death.
- When performing a calibration or calibration verification test (bump test) only use certified calibration gas at the required concentration level. Do not calibrate with expired calibration gas.
- If the instrument cannot be calibrated, do not use until the reason can be determined and corrected.
- Do not cover or obstruct display or visual alarm
- Ensure sensor inlets are unobstructed and is free of debris

## USE INSTRUCTIONS AND LIMITATIONS

## WARNING

Each person using this equipment must read and understand the information in these User Instructions before use. Use of this equipment by untrained or unqualified persons or use that is not in accordance with these User Instructions, may adversely affect product performance and result in sickness or death.

### **Use For**

The KGD-6-AM provides Ammonia detection and automatic exhaust fan control for industrial refrigeration, warehouses, hockey rinks or other commercial applications. Ammonia or NH<sub>3</sub>, is a colorless gas with a pungent, suffocating odor.

**Note:** Shipped as a liquefied compressed gas – easily liquefied under pressure. The KGD-6-AM is designed to meet the NIOSH and OSHA standards for Ammonia exposure limits. KGD-6-AM can be used stand alone, with the Kele DVP-120 Detection and Ventilation Control Panel, other 12 VAC or 24 VDC fire/security panels or building automation systems.

Use only for monitoring the gas which the sensor and instrument are designed to monitor. Failure to do so may result in exposures to gases not detectable and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).

### **Do Not Use For**

The KGD-6-AM is not intended for use in hazardous locations. Do not mount the KGD-6-AM where the normal ambient temperature is below 0°F or exceeds 125°F (below -18°C or above 52°C). The KGD-6-AM mounts on a 4×4 electrical box supplied by the contractor. Do not install the KGD-6-AM inside another box unless it has good air flow through it.

This equipment may not function effectively below 0°F or above 125°F (-18°C or above 52°C). Using the detector outside of this temperature range may adversely affect product performance and result in sickness or death.

### **General Description**

The KGD-6-AM is a low voltage, dual relay Ammonia (AM) detector and automatic ventilation controller. The KGD-6-AM uses a microcomputer controlled, electronic system to measure the concentration of Ammonia, actuate relays and provide a 4-20mA output. The KGD-6-AM has a field replaceable, electrochemical sensor (expected life of 2+ years) and optional gas test and calibration kits. The KGD-6-AM is a low level meter capable of displaying from 0-100ppm of Ammonia.

### **Features**

- Conforms to UL std. 61010-1, Certified to CSA Std. C22.2 No 61010-1
- Low level meter capable of displaying from 0-100 ppm Ammonia
- The KGD-6-AM meets NIOSH and OSHA standards for gas exposure
- Selectable fan and alarm relay activation
- 5 A SPDT fan relay controls starters of exhaust fans
- 0.5 A N.O. or N.C. alarm relay connects to warning devices or control panels
- 4-20 mA Current Loop
- KGD-6-AM mounts on a standard 4×4 electrical box and becomes cover for the box
- Supervised system: any internal detector problem will cause the fan & alarm relay to activate
- Calibration kit is available. One screw allows access for calibration or gas test

### **Specifications**

- Power: 3 W (max) from 12 to 24 VAC or 12 to 32 VDC
- Current @ 24 VDC: 75 mA in alarm (two relays), 50 mA (fan relay only) and 23 mA stand by

- Shipping Weight: 1 pound (0.45 kg)
- Size: 4 1/2 x 4 x 2 1/8 in. (11.4 X 10.2 X 5.4 cm)
- Color: Dark gray
- Connections: plugs/terminals
- Mounting box: (not included) 4x4 electric
- Fan relay: 5 A, 240 VAC, pilot duty, SPDT, latching or non-latching
- Fan relay actuation: selectable at diS (disable), 15, 20, 25 (default), 30, 35, 40, 45, 50, 55, 60, 65, 70, or 75 ppm NH3
- Fan Delay Settings of 0, 1, 3 (default), 5 and 10 minutes
- Fan Minimum Run Time settings are 0 (default), 3, 5, 10 or 15 minutes
- Fan relay latching or not latching (default) selectable.
- Alarm relay: 0.5A 120 V, 60 VA
- Alarm relay actuation: selectable N.O. (default) or N.C.
- Alarm relay settings: diS, 20, 25, 30, 35, 40, 45, 50, 55, 60, 65, 70, 75 (default), 80, 85, 90, 95 or 100 ppm NH3
- Current Loop: 4-20 mA for 0-100ppm NH3, selectable to off or on (default)
- Buzzer: 85 dBA at 10cm settable to off (default) or on
- Digital display: 3 digit LED selectable to off (default) or on.
- Operating environment 0°F to 125°F (-18°C to 52°C). 10 to 90% RH
- Operating altitude: Up to 5,000m (16,404ft)

## INSTALLATION AND OPERATING INSTRUCTIONS

The following instructions are intended to serve as a guideline for the use of the Kele KGD-6-AM Ammonia Detector. It is not to be considered all-inclusive, nor is it intended to replace the policy and procedures for each facility. If you have any doubts about the applicability of the equipment to your situation, consult an industrial hygienist or call Technical Service at 1-[877-826-9045](tel:877-826-9045).

This detector helps monitor for the presence and concentration level of a certain specified airborne gas. Misuse may produce an inaccurate reading, which means that higher levels of the gas being monitored may be present and could result in overexposure and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).

### Location

A KGD-6-AM is normally mounted high in the room on a wall or column one foot below the ceiling in a central area where air movement is generally good. Use the same spacing as for smoke detectors, 30-foot centers, 900 square feet per detector (465 sq. meters). The coverage depends on air movement within the room or facility. Extra detectors may be needed near any areas where people work or where the air is stagnant. The KGD-6-AM mounts on a 4x4 electrical box supplied by the contractor. Do not install the KGD-6-AM inside another box unless it has good air flow through it. Do NOT mount the KGD-6-AM where the normal ambient temperature is below 0°F or exceeds 125°F (below -18°C or above 52°C).

High voltage terminals (120/240 VAC) are located within this detector, presenting a hazard to service technicians. Only qualified technicians should open the detector case and service the internal circuits. Ensure power is removed from the detector relays prior to servicing the unit. Failure to do so may result in sickness or death.

### Installation

1. The KGD-6-AM mounts on a 4" square (or 4x4) electrical box supplied by the contractor. Do not mount the KGD-6-AM inside another box, unless it has good air flow through it.

2. Connect the KGD-6-AM to Class 2 power supply only. It is suggested to use a separate transformer for powering the unit or units because of possible interferences from other devices on the same power supply.
3. Connect the KGD-6-AM to the control cables with terminal plugs. When making connections, make sure the power is off.
4. There are two terminals for Power: 12 to 24 VAC or 12 to 32 VDC, with no polarity preference.
5. There are two terminals for the dry alarm relay contacts, again with no polarity preference. The alarm relay can switch up to 0.5 A 120 V, or 60 VA. The alarm relay is activated if gas reaches or exceeds the alarm settings. See OPERATION section of these User Instructions for details on relay settings.
6. The alarm relay can be configured to normally open (default) (N.O.) or normally closed (N.C.) and will activate if the gas concentration exceeds alarm set point. It will deactivate once the gas concentration drops below the alarm set point. Note that the “disable” setting will cause the alarm relay not to engage at all.
7. The dry contact, SPDT fan relay has three terminals. The common (COM.), normally open (N.O.) and the normally closed (N.C.) contact. The fan relay can switch up to 5.0 A up to 240 VAC. See OPERATION section of these User Instructions for details on relay settings.
8. The Fan Relay can be configured for latching or non-latching (default) when activated (when the gas concentration exceeds fan relay set point).
9. The Fan Relay will engage if the fan setting Ammonia concentration is exceeded for longer than the Fan Relay Delay time. Unless it is configured for latching, the fan relay will disengage once both conditions have been met:
  - Ammonia concentration has dropped below fan setting.
  - Fan Relay Run time has been exceeded.Note that the “disable” fan setting will cause the fan relay to not engage. The fan relay will engage in trouble fault condition (if the Trouble Fan Setting Option is set to “On”) and will disengage once trouble fault condition is cleared.
10. The Current Loop is 4 mA in clean air and 20 mA for 100 ppm Ammonia.





Figure 3-2 6-Series Rear View





Figure 3-6 6-Series Stand Alone Diagram








Figure 3-3 6-Series Alarm Control Panel diagram




Figure 3-7 6-Series Alternate Alarm Panel

In this application (above) the Fan or primary relay is used as a low level alarm relay. The Alarm or secondary relay is used as a supervisory relay when utilized in the normally closed configuration. The KGD-6-AM monitors all critical functions of the unit through software diagnostics that continually test and verify its operations. If a problem is found, the unit will switch to a fail-safe/error mode or trouble condition. In this error mode the Fan\* and Alarm relays will be activated indicating the trouble condition at panel and the KGD-6-AM display will flash the error. \*See the Trouble Fan Setting Option.

## Power Up

The KGD-6-AM steps through an internal self-test cycle for the first 1 minute that it is powered. The unit will execute the test cycle any time power is dropped and reapplied (i.e. power failure). During the self-test cycle the unit will display the Firmware Version number and the gas type, then count down from 60 to 0 (if the display option is "on") and finally go into normal operation. The alarm relay will be activated for 10 seconds and the fan relay for 60 seconds during the power-up cycle unless the "Power Up Test" (PUT) option is OFF. The indicator light (LED) will flash green during the self-test cycle. At the end of the 1 minute cycle, the unit will take its first sample of the air and the indicator light will turn solid green.

## Operation




1. With the display function turned “On”, the KGD-6-AM will show the current concentration of NH<sub>3</sub> ppm or “0” (zero) in clean air. When the NH<sub>3</sub> concentration reaches the Fan Relay setting (25 ppm, for example) the display will flash back and forth between “FAn” and “25”. With the display function turned “OFF”, the display does not show the gas concentration, but will show “FAn” as long as the fan relay is activated.
2. With the display function turned “On” and the NH<sub>3</sub> concentration reaching the Alarm Relay setting, (75ppm, for example) the display will flash back and forth between “ALr” and “75”. The buzzer will sound indicating “Alarm” if the buzzer is turned “On”. With the display function turned off the display does not show the NH<sub>3</sub> concentration but will show “ALr” when the Alarm relay is activated.
3. With the 4-20 mA function turned “On” and the NH<sub>3</sub> concentration climbing the 4-20 mA signal will ramp up corresponding to the concentration (0-100 ppm).

### Default Configuration – Factory Settings

- The default Power Up Test setting is On
- The default Display setting is OFF
- The default Buzzer setting is OFF
- The default Alarm Relay Setting is activation at 75 ppm
- The default Alarm Relay Configuration is Normally Open
- The default Fan Relay Setting is activation at 25 ppm
- The default Fan Relay Delay setting is 3 minutes
- The default Fan Relay Runtime setting is 0 minutes
- The default Fan Relay Latching condition is OFF
- The default Trouble Fan Setting condition is OFF
- The default 4-20mA Output setting is On

To change settings, remove the Philips screw on the front of the KGD-6-AM. Pull off the front cover of the unit.



### Selecting Default Configuration – “dEF”

To select the Default Configuration, in normal mode, push the Next button to get to “Con” or the Configuration menu. Then push the Enter button to enter the Con menu. The first selection is the “dEF” or Default setting. Push Enter. If it is already in Default configuration, there will be no action. If it is not already in Default configuration, “no” will be displayed. Push Next to change it to “yES” (flashing) then push Enter to confirm the change (solid) and push Enter again to return to “dEF” in the con menu. Push Next until “End” is displayed then push Enter to get back to normal operation.

### Selecting Power Up Test Option – “PUt”

To select the Power Up Test Configuration, in normal mode, push the Next button to get to “Con” or the Configuration menu. Then push the Enter button to enter the Con menu. Then push the Next button to get to the second selection “PUt” or Power Up Test setting. Push Enter. If the test is “On” push Next to turn it “OFF” (flashing)

then push Enter to confirm the change (solid) and push Enter again to return to "PUt" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Display Option – "dSP"**

To select the Display Configuration, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. Then push the Next button to get to the third selection "dSP" or Display setting. Push Enter. If the display is "On" push Next to turn it "OFF" (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "dSP" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Buzzer Option – "bUZ"**

To select the Buzzer Configuration, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The forth selection is the "bUZ" or Buzzer setting. Push Next three times to get to "bUZ" then Enter. If the display is "On" push Next to turn it "OFF" (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "bUZ" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Alarm Relay Setting – "ArS"**

To select the Alarm Relay Setting, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The fifth selection is the "ArS" or Alarm Relay Setting. Push Next four times to get to "ArS" then Enter. If the display is "diS" (disabled) push Next to change it to 20, 25, 30, 35, 40, 45, 50, 55, 60, 65, 70, 75 (default), 80, 85, 90, 95 or 100ppm NH<sub>3</sub> (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "ArS" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Alarm Relay Configuration – "Arc"**

To select the Alarm Relay Configuration, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The sixth selection is the "Arc" or Alarm Relay Configuration. Push Next five times to get to "Arc" then Enter. If the relay is "nO" (normally open) push Next to turn it to "nC" (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "Arc" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Fan Relay Settings – "FrS"**

To select the Fan Relay setting, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The seventh selection is the "FrS" or Fan Relay setting. Push Next six times to get to "FrS" then Enter. If the fan relay is "diS" (disabled) push Next to change it to 15, 20, 25 (default), 30, 35, 40, 45, 50, 55, 60, 65, 70, or 75 ppm NH<sub>3</sub> (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "FrS" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Fan Relay Delay – "Frd"**

To select the Fan Relay Delay setting, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The eighth selection is the "Frd" or Fan Relay Delay. Push Next seven times to get to "Frd" then Enter. If the delay is "0" (disabled) push Next to change it to 1, 3, 5, or 10 minutes (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "Frd" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Fan Relay Run Time – "Frr"**

To select the Fan Minimum Runtime setting, in normal mode, push the Next button to get to "Con" or the Configuration menu. Then push the Enter button to enter the Con menu. The ninth selection is the "Frr" or Fan Minimum Run Time. Push Next eight times to get to "Frr" then Enter. If the runtime is "0" (disabled) push Next to change it to 3, 5, 10 or 15 minutes (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "Frr" in the Con menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

#### **Selecting Fan Relay Latching Option – "FrL"**

To select the Fan Relay Latching Option, in normal mode, push the Next button to get to "Con" or the

Configuration menu. Then push the Enter button to enter the Con menu. The tenth selection is the “FrL” or Fan Relay Latching Option. Push Next nine times to get to “FrL” then Enter. If latching is “OFF” push Next to turn it to “On” (flashing) then push Enter to confirm the change (solid) and push Enter again to return to “FrL” in the Con menu. Push Next until “End” is displayed then push Enter to get back to normal operation.

#### **Selecting Trouble Fan Setting Option – “tFS”**

To select the Trouble Fan Setting Option, in normal mode, push the Next button to get to “Con” or the Configuration menu. Then push the Enter button to enter the Con menu. The eleventh selection is the “tFS” or Trouble Fan Setting Option. Push Next ten times to get to “tFS” then Enter. If Trouble Fan Setting is “OFF” push Next to turn it to “ON” (flashing) then push Enter to confirm the change (solid) and push Enter again to return to “tFS” in the Con menu. Push Next until “End” is displayed then push Enter to get back to normal operation.

#### **Selecting 4-20mA Output Option – “420”**

To select the 4-20mA Output Option, in normal mode, push the Next button to get to “Con” or the Configuration menu. Then push the Enter button to enter the Con menu. The twelfth selection is the “420” or 4-20mA Output Option. Push Next eleven times to get to “420” then Enter. If the 4-20mA is “On” push Next to turn it to “OFF” (flashing) then push Enter to confirm the change (solid) and push Enter again to return to “420” in the Con menu. Push Next until “End” is displayed then push Enter to get back to normal operation.

#### **Onboard Diagnostics**

The KGD-6-AM monitors all critical functions of the unit through software diagnostics that continuously test and verify unit operations. If a problem is found, the unit will switch to a fail-safe/error mode or trouble condition. In this error mode, the Alarm relay will be activated, the 4-20 mA current loop will go to 24 mA, the unit will display the error code, the green status indicator LED light will flash and the buzzer will chirp intermittently. The Fan relay will also engage if the Trouble Fan Setting Option is set to “ON”. This is a safety precaution. To clear this mode, simply turn off power to the unit for a few seconds, or push the ENTER/TEST switch (inside the unit). This will cause the unit to restart the 1 minute self-test cycle.

The 4-20 mA signal can be used for troubleshooting:

- 0 mA is most likely a connection problem
- 4-20 mA is normal gas reading range (0-100 ppm)
- 24 mA indicates a Trouble condition

#### **Error Codes**

- **t01** Sensor missing
- **t02** Temperature compensation failure
- **t04** EEPROM bad checksum
- **t10** Bad EEPROM
- **t20** Bad calibration
- **t40** Factory calibration failure
- **t80** Read ADC failure
- **t100** Under range
- **t200** Sensor warranty expired

**NOTE:** For trouble codes over 080 the display will alternate between t\_1 and t00 for t100 and between t\_2 and t00 for t200.

If the error mode repeats frequently, check for continuous power and proper voltage. If power is not the problem and a unit has repeating error conditions, it may need to be returned to Kele for service, per these User Instructions.

If the error mode indicates “Sensor warranty expired” see the Sensor Replacement section of these User Instructions.

### **Sensor Poisons**

The gas sensor in the detector is designed with extreme sensitivity to the environment. As a result, the sensing function may be deteriorated if it is exposed to a direct spray from aerosols such as paints, silicone vapors, etc., or to a high density of corrosive gases (such as Ammonia, sulfur dioxide) for an extended period of time.

## **MAINTENANCE**

The KGD-6-AM requires periodic maintenance. The unit uses an electrochemical sensor with a 2-3 year life expectancy that can be tested, calibrated and replaced in the field. The KGD-6-AM replacement sensor is available through your local representative or from Kele. The detector’s performance should be tested regularly by using gas as detailed in the Testing and Field Calibration sections. All other maintenance and repair of products manufactured by Kele are to be performed at the appropriate Kele manufacturing facility. Kele does not sanction any third-party repair facilities.

### **End-of-Warranty Signal**

Two years after the KGD-6-AM is installed the sensor end-of-warranty signal will be activated indicating that the KGD-6-AM sensor has reached the end of its warranty period. The end-of-warranty signal will cause an error code t200 “Sensor warranty expired”. See Error Codes section. In addition to the end-of-warranty signal the sensor itself has a tamper proof warranty expiration sticker dated 2 years from the unit manufacture date. See the Kele Fixed Gas Detection Products Limited Warranty section.

The end-of-warranty signal can be silenced for 48 hours by pressing the “ENTER/TEST” button or by temporarily dropping power to the unit. The end-of-warranty signal provides the user an opportunity to test and/or calibrate the sensor assuring that it is still performing within acceptable parameters though the sensor is nearing the end of its 2-3 year expected life. The silence function will continue to be available for 29 days after the KGD-6-AM initiates the initial end-of-warranty signal. After this 29 day period the KGD-6-AM can no longer be silenced and the sensor must be replaced or the sensor life reset.

### **Sensor Replacement**

1. Remove power to the unit
2. Remove the Philips screw on the front of the KGD-6-AM. Pull the front cover of the unit off.
3. Remove the sensor by pulling it gently from the three pronged socket.
4. Remove the Shorting Spring from the new sensor if installed and insert the new sensor into the socket.
5. Power up the unit. The KGD-6-AM steps through an internal self-test cycle for the first 1 minute that it is powered. During the self-test cycle the unit will display the Firmware Version number, then count down from 60 to 0 and finally go into normal operation. The indicator light (LED) will flash green during the self-test cycle. At the end of the 1 minute cycle, the unit will take its first sample of the air and the indicator light will turn solid green.
6. Let the new sensor stabilize for at least 5 minutes then refer to the FIELD CALIBRATION PROCEDURE section to zero and calibrate the unit.
7. After the successful calibration is complete, reset the sensor life.

### **Sensor Life Reset**

1. Remove the Philips screw on the front of the KGD-6-AM. Pull the front cover of the unit off.
2. To reset the sensor life (rSt), from normal or warm-up mode, press the Next button four times to get to SEn or

Sensor Mode.

3. Then press the Enter button to get to "rSt" – Reset Sensor Mode.
4. Press the Enter button again to see the sensor reset status. If the sensor life has already been reset, done "don" will be displayed. If it has not already been reset, "no" will be displayed. Push Next to change it to "yES" (flashing) then push Enter to confirm the change (solid) and push Enter again to return to "rSt" in the SEn menu. Push Next until "End" is displayed then push Enter to get back to normal operation.

**NOTE:** If the sensor is reset and not replaced it is necessary to test and/or calibrate the sensor to assure that it is still performing within acceptable specifications though the sensor is nearing the end of its 2-3 year expected life. There will be no other indication of sensor performance.

Do not disassemble unit or attempt to repair or modify any component of this instrument. This instrument contains no user serviceable parts, and substitution of components may impair intrinsic safety, which may adversely affect product performance and result in sickness or death.

### **CAUTION**

Avoid use caustic, abrasive cleaners and other organic solvents. These materials may scratch surfaces and permanently damage the display window, labels, sensor or instrument case. The high voltage terminals (100-240 VAC) are within this detector, which implies a danger for technicians who give service. Only qualified technicians should open the detector housing and servicing the internal circuits. Be sure to disconnect the detector before cleaning. Not doing so could cause illness or even death.

### **Cleaning**

Cleaning of the external surfaces is best carried out using a damp cloth with a mild detergent or soap. Use a vacuum cleaner with soft brush to remove dust or contamination under the cover. Do not blow out the sensor with compressed air.

Using a certified gas with a concentration other than the one listed for this detector when conducting a calibration or calibration verification test (bump test) will produce inaccurate readings. This means that higher levels of the gas being monitored may be present and could result in overexposure and cause sickness or death. For proper use, see supervisor or User Instructions, or call Technical Service at 1-[877-826-9045](tel:877-826-9045).

### **General**

All KGD-6-AM units are factory calibrated and 100% tested for proper operation. During normal operation the green status indicator LED light will be on steady, the fan & alarm relay will be in standby mode and the 4-20 mA output will be at 4mA (in clean air). The unit also performs a regular automatic self-test during normal operation. If the unit detects an improper voltage or inoperable component, it will default into Error mode. In this error mode, the Alarm relay will be activated, the 4-20 mA current loop will go to 24 mA, the unit will display the error code, the green status indicator LED light will flash and the buzzer will chirp intermittently. The Fan relay will also engage if the Trouble Fan Setting Option is set to "ON".

### **Operation Test**

Check that the green KGD-6-AM status indicator LED light is illuminated continuously. If not, do not proceed with the tests. If the unit is in error mode contact your local representative or Kele technical service representative for information on resolving the problem.

1. Remove the single screw in the middle of the front cover of the KGD-6-AM.
2. Remove the front cover.
3. Observe the LED light on the front of the KGD-6-AM.
4. If the light is solid green proceed to step 6.
5. If the green status indicator LED light is off or flashing, refer to the General section above.
6. Locate the switch labeled ENTER/TEST on the left side of the printed circuit board. Press the Test switch once.

7. The KGD-6-AM will step through a cycle test:

- **a)** The display progresses through the bUZ Buzzer Test) Art (alarm relay test), Frt (fan relay test) then 42t (4-20 mA output test). Make sure that the settings are “on” or not disabled “diS”.
- **b)** During the first 10 seconds of the test cycle, the display will show BUZ and set off the audible buzzer
- **c)** The alarm relay will be closed, so any devices connected to that relay will be tested.
- **d)** The Fan relay will be activated for the next 1 minute of the test, so if the fan circuits are wired in the normal manner, the fan should run.
- **e)** The 4-20mA output will then ramp up from 4 to 16 mA over the next 130 seconds of the test, so if the circuit is wired in the normal manner, the control panel or building automation system should respond.
- **f)** At the end of the test cycle, the light will turn green and be on steady (Normal Operation), the fan & alarm relay will

8. When testing is completed reassemble the unit or units.

### **Manual Operation Test**

This option gives the user the opportunity to manually initiate an individual test for each relay, the analog output and the sensor response to gas. From normal operation mode press the Next button 2 times to get to the Test Mode (tSt). Press the Enter button once to get into the Test Menu. Press the Next button to scroll through the five test options and press Enter to initiate the selected test. Note that if the relay or 4–20 mA output has been disabled, the test selection will not be displayed in the test menu.

1. bUZ – Buzzer Test, 3 seconds
2. Art – Alarm Relay Test, 5 seconds
3. Frt – Fan Relay Test, 60 seconds
4. 42t – 420 loop test, 130 seconds
5. gtS – Gas Test, 3 minutes (no output to the panel during the gas test)

The display will flash during the test, or in the case of the gas test, the gas level will alternate with gtS. Once the test is complete, the display will return to steady display. To exit the test menu, press the Next button until “End” is displayed, then press Enter to return to normal mode.

### **Ammonia Gas Test**

The following steps must be performed when conducting a calibration or calibration verification test (bump test) to ensure proper performance of the monitor. Failure to do so may adversely affect product performance and result in sickness or death.

- When performing a calibration or calibration verification test (bump test) only use certified calibration gas at the required concentration level. Do not calibrate with expired calibration gas.
- If the instrument cannot be calibrated, do not use until the reason can be determined and corrected.
- Do not cover or obstruct display or visual alarm cover.
- Ensure sensor inlets are unobstructed and is free of debris

### **General**

The KGD-6-AM can be bump-tested or calibrated with the AM-FCK with Ammonia gas, regulator and test hood, available through your local representative or from Kele.

- Cal-Kit 5 (30-0052-1120-1)
  - Calibration Case

- Two feet of Tygon tubing
- Cal Hood Pack
- 0.5LPM, Regulator (M)

### Cal-Kit 5 Information

Several detectors can be calibrated with one Cal-Kit. The only limitation is the amount of gas in the cylinder and the flow of the regulator. The 34 liter cylinder for example with a 0.5LPM regulator has approximately 68 minutes of continuous calibration run time. Replacement cylinders are available. The gas cylinder should be replaced when the pressure gauge on the regulator shows 25-psi or less.


**Note:** For optimum test results it is suggested that the unit be in clean air (green light on) and be in a low ambient air flow

### Gas Testing

Testing the Fan Relay –

1. Remove the Philips screw on the front of the KGD-6-AM. Remove the front cover.
2. Open the FCK. Connect the 25 ppm gas cylinder to the regulator.
3. Check the pressure gauge on the regulator. If you have 25-psi or less you will need to replace the gas canister.
4. Assemble regulator, hose and test hood and place the Test Hood over the gas sensor.

**Note:** The time to activate the Fan relay depends on the delay setting.



5. Turn on the regulator to start the gas flow and wait with the gas applied continuously.
6. With the display function turned "On", the KGD-6-AM will show the current concentration of gas or "0" (zero) in clean air. When the gas concentration reaches the Fan Relay setting (20 ppm, for example) the display will flash back and forth between "FAn" and "20". With the display function turned "OFF", the display does not show the gas concentration, but will show "FAn" as long as the fan relay is activated.

**Note:** If the Fan relay does not close within 2 minutes, there are five possibilities:

1. **a.** Gas cylinder is empty, check the pressure gauge. Replace the gas cylinder if 25psi or less.
  2. **b.** Unit needs to be re-calibrated (go through recalibration and re-test).
  3. **c.** Detector is in need of servicing (return unit to factory for servicing).
  4. **d.** Detector has fan relay set to disable (diS) or higher than 20. Set fan relay to 20 ppm and repeat the test.
  5. **e.** Detector has fan relay delay set to 3 minutes. Set fan relay to 0 minutes and repeat the test.
7. Remove the gas from the sensor. Proceed to Test the Alarm relay or replace the top cover. Fan relay test is complete.

### Testing the Alarm Relay

**Note:** The gas concentration to activate the Alarm relay depends on the setting.



1. Connect the 25 ppm cylinder of Ammonia to the regulator.
2. Check the pressure gauge. If there is 25psi or less the cylinder should be replaced.
3. Place the test hood over the gas sensor. Turn on the regulator to start the gas flow.
4. The Fan relay should activate according to the settings.
5. With the display function turned "On" and the gas concentration reaching the Alarm Relay setting, (20 ppm, for example) the display will flash back and forth between "ALr" and "20". The buzzer will sound indicating "Alarm" if the buzzer is turned "On". With the display function turned off the display does not show the gas concentration, but will show "ALr" when the Alarm relay is activated.

**Note:** If the Alarm relay fails to operate within 2 minutes, there are four possibilities:

1. **a.** Gas cylinder is empty, check the pressure gauge. Replace the gas cylinder if 25-psi or less.
  2. **b.** Unit needs to be re-calibrated (go through recalibration and re-test).
  3. **c.** Detector is in need of servicing (return unit to factory for servicing).
  4. **d.** Detector has Alarm relay set to disable (diS) or higher than 20. Set Alarm relay to 20 ppm and repeat the test.
6. Remove the gas from the sensor after Test. Proceed to Test the 4-20mA output or replace the top cover. Alarm relay test is complete.

### Testing the 4-20mA current loop

1. Connect the 25 ppm cylinder of Ammonia to the regulator.
2. Check the pressure gauge. If there is 25-psi or less the cylinder should be replaced.
3. Place the test hood from the regulator over the gas sensor. Turn on the regulator to start the gas flow.
4. The Fan relay should activate according to the settings.
5. The Alarm relay should activate according to the settings.
6. The 4-20 mA output should ramp up from 4mA in clean air to 8 mA at 25 ppm. See 4-20 mA diagram on page 7.

**Note:** If the 4-20mA output does not ramp up within 2 minutes, there are four possibilities:

1. **a.** Gas cylinder is empty, check the pressure gauge. Replace the gas cylinder if 25-psi or less.
  2. **b.** Unit needs to be re-calibrated (go through recalibration and re-test).
  3. **c.** Detector is in need of servicing (return unit to factory for servicing).
  4. **d.** Detector has 4-20 mA option set to "OFF". Set 4-20mA option to "On" and repeat the test.
7. Remove the gas from the sensor. Re-assemble the KGD-6-AM (make sure the LED is aligned with the front case hole). 4-20 current loop test is complete.

### FIELD CALIBRATION PROCEDURE

**Note:** For optimum calibration results the unit should be in clean air and be in a low ambient air flow.

#### Zero the Sensor

1. Ensure that the ambient air has less than 0.1 ppm NH<sub>3</sub> before proceeding with Zeroing the sensor. Remove the Philips screw on the front of the KGD-6-AM. Pull the front cover of the unit off.
2. To select Calibration Zero Mode (000), from normal mode, press the Next button three times to get to CAL or Calibration Mode.
3. Then press the Enter button to get to "000" – Calibration Zero Mode.

4. Press the Enter button and the display will read the current gas level alternating with 000 (blinking) indicating zero calibration in progress (max 165 sec).
5. If the process is successful, the display will read 0 alternating with PAS (blinking) Zero Calibration complete.
6. If the process was not successful, the display will read the current gas level alternating with FFail (fail) (blinking). If this occurs, repeat steps 2 through 4. If the sensor fails to zero twice contact Technical Assistance: [877-826-9045](tel:877-826-9045).

**Note:** The display may just go back to 000 if the process is unsuccessful because the sensor response is too negative or if gas is present.

7. To return to Normal Mode press Enter and then press Next until "End" is displayed. Press Enter to return to Normal Mode.

## Calibration

1. Remove the Philips screw on the front of the KGD-6-AM. Pull the front cover of the unit off. 2.
2. Assemble the 25 ppm gas cylinder and regulator together.
3. Check the pressure gauge on the regulator. If you have 25-psi or less you will need to replace the gas canister.
4. Place the test Hood from the regulator over the gas sensor.
5. Push Next 3 times to get to the CAL menu then push Enter. Press Next once to get to Span mode then press Enter, the display will flash back and forth between gAS and the current gas level.
6. Start applying 25 ppm gas to the gas sensor by turning on the valve on the regulator.

**Note:** The sensor will look for the gas for 90 seconds. If no gas is applied or detected in that time, the display will return to CAL.

7. When the sensor detects the gas, the display will flash back and forth between the gas concentration and SPn, then the calibration will progress and the display will show the gas level for a maximum of 165 seconds.
8. When the calibration is successful, the display will flash back and forth between the gas concentration and PAS, then the display will show the calibration gas level and the calibration is done.
9. If the calibration fails, the display will flash back and forth between the gas concentration and FFail (fail). If this occurs, check the pressure gauge on the regulator. If the pressure is less than 25 psi the flow of gas may not be adequate to properly calibrate the unit. If there is proper pressure in the cylinder repeat steps 4 through 6. If the unit fails to calibrate twice contact Technical Assistance: [877-826-9045](tel:877-826-9045)
10. Once the calibration has passed, remove gas and disassemble the cylinder and regulator.
11. Re-assemble the KGD-6-AM (make sure the LED is aligned with the front case hole). Calibration is complete
12. See Calibration Flowchart on the inside of the housing.

## WARRANTY

### KELE FIXED GAS DETECTION PRODUCTS LIMITED WARRANTY

Kele warrants the KGD-6-AM gas detector will be free from defective materials and workmanship for a period of two (2) years from date of manufacture (indicated on the inside cover of the KGD-6-AM), provided it is maintained and used in accordance with Kele instructions and/or recommendations. If any component becomes defective during the warranty period, it will be replaced or repaired free of charge, if the unit is returned in accordance with the instructions below. This warranty does not apply to units that have been altered or had repair attempted, or that have been subjected to abuse, accidental or otherwise. The above warranty is in lieu of all other express warranties, obligations or liabilities. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE ARE LIMITED TO A PERIOD OF TWO (2) YEARS FROM THE PURCHASE DATE. Kele shall not be liable for any incidental or consequential damages for breach of this or any other warranty, express or implied, arising out of or related to the use of said gas detector. Manufacturer or its agent's liability shall be limited

to replacement or repair as set forth above.

Buyer's sole and exclusive remedies are return of the goods and repayment of the price, or repair and replacement of non-conforming goods or parts.

Kele Inc.  
3300 Brother Boulevard  
Memphis, TN 38133

## Technical Support Contact Information

- **Phone:** 1-[877-826-9045](tel:877-826-9045)
- **Email:** [info@Kele.com](mailto:info@Kele.com)
- **Website:** [www.Kele.com](http://www.Kele.com)

## General Contact Information

- **Phone :** 1-[877-826-9045](tel:877-826-9045)
- **International:** 001-[901-382-6084](tel:901-382-6084)
- **Email :** [info@Kele.com](mailto:info@Kele.com)
- **Website:** [www.Kele.com](http://www.Kele.com)

Rev – 1.2.3


Issue Date: 07.15.2024

© Kele Inc. 2023. All rights reserved.

## FAQ

- **Q: How often should the sensor be replaced?**
  - A: The sensor has an expected life of 2+ years, but it is recommended to regularly test and calibrate the device to ensure accurate readings.

## Documents / Resources

	<a href="#">Kele KGD-6-AM Ammonia Detector Controller and Transducer</a> [pdf] User Manual KGD-6-AM Ammonia Detector Controller and Transducer, KGD-6-AM, Ammonia Detector Controller and Transducer, Detector Controller and Transducer, Controller and Transducer, Transducer
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.