

KENWOOD
DMX40S Receiver
Multimedia
Navigation 2



KENWOOD DMX40S Receiver Multimedia Navigation 2 User Guide

[Home](#) » [KENWOOD](#) » KENWOOD DMX40S Receiver Multimedia Navigation 2 User Guide 

Contents

- 1 KENWOOD DMX40S Receiver Multimedia Navigation 2
- 2 Specifications
- 3 Product Usage Instructions
- 4 Introduction
- 5 Work Flow
- 6 Creating the Update Media
- 7 Updating the Program
- 8 Precautions
- 9 FAQ
- 10 Documents / Resources
 - 10.1 References



KENWOOD DMX40S Receiver Multimedia Navigation 2



Specifications

- Target Models: DMX40S, DMX400S, DMX4710S, DMX5023S, DMX5023DABS, DMX553DABS
- USB Standard: USB 2.0
- Capacity: 8 GB to 32 GB
- File System: FAT 32

Product Usage Instructions

- Download the firmware files and copy them to USB memory.
- Update the firmware (approximately 7 minutes).
- Check that the firmware has been updated.
- Download the updates from the website.
- Decompress the downloaded file.
- Copy the decompressed file to the top hierarchy in USB memory.
- Touch [ARM Update] to start updating (about 4 minutes).
- Remove the USB memory and reconnect it.
- Touch [MCU Update] to start updating (about 3 minutes).
- Check that the firmware version is updated by referring to Checking the Firmware Version..

Introduction

- This document describes the procedure and precautions for upgrading the 2024 NAVIGATION/MULTIMEDIA receiver firmware.
- If an error occurs while you are updating the firmware, the 2024 NAVIGATION/MULTIMEDIA receiver may become unusable. Be sure to read the following procedure and precautions carefully before updating the firmware.

Target Model and Firmware Version

The updater can be used for the firmware versions of the models shown below.

Target models	Target firmware versions	→ Updated versions
DMX40S, DMX400S, DMX4710S	APP: 240513-V1.2.1.0.14863 or earlier MCU: V2.4.1.0425 or earlier	→ APP: 241112-V1.2.2.5.16720 MCU: V2.4.1.1107
DMX5023S	APP: 240513-V1.2.1.0.14870 or earlier MCU: V2.4.1.0425 or earlier	→ APP: 241112-V1.2.2.5.16720 MCU: V2.4.1.1107
DMX5023DABS, DMX553DABS	APP: 240606-V1.2.1.5.15074 or earlier MCU: V2.4.1.0603 or earlier	→ APP: 241112-V1.2.2.5.16720 MCU: V2.4.1.1107

For how to check your firmware version, refer to “Checking the Firmware Version”.


Work Flow

- Step 1. Download the firmware files, and copy them to USB memory.
- Step 2. Update the firmware. (It takes about 7 minutes.)
- Step 3. Check that the firmware has been updated.

Creating the Update Media

Create the update media on your PC.

1. Download the Updates from the Web site.
2. Decompress the downloaded file.
3. Copy the decompressed file to the top of the hierarchy in USB memory.





Caution


- For updating, use a USB memory device with the specifications shown below. Updating is not possible on USB memory devices with other specifications.
 - USB Standard: USB 2.0
 - Capacity: 8 GB to 32 GB
 - File system: FAT 32
- Do not copy the updater to a device containing audio files. Blank USB memory is highly recommended.
- The update cannot be performed if it is copied inside a folder.
- If the updater file name is changed, the update cannot be performed.

Checking the Firmware Version

1. Press the <MENU> button.



2. Touch .
3. Touch [Special].
4. Touch [Software Information].
5. Check the version.




Updating the Program

1. Connect the USB memory. The confirmation message appears.
2. Touch [Yes]




3. Touch [ARM Update] to update starts. (It takes about 4 minutes.)



Caution: The screen may go blank for a few seconds. Do not unplug the USB memory or Power Off the unit during the Update Procedure.

4. System Reboot.
5. Remove the USB memory. Again, connect the USB memory. The confirmation message appears.
6. Touch [Yes]
7. Touch [MCU Update] to update starts. (It takes about 3 minutes.)



8. Once the “MCU Update success!” screen is displayed.
9. System Reboot. Remove the USB memory.
10. Check that the firmware version is updated, by referring to “Checking the Firmware Version”.

Precautions

- Be sure to park the vehicle in a safe place before updating it. Keep the engine running in order to prevent the battery from running out.
- Do not turn off the engine or Navigation/Multimedia receiver power while updating. The update cannot be performed correctly and the Navigation/Multimedia receiver may become unusable.

FAQ

- **Q:** Can I use a USB memory device with specifications other than those mentioned?
- **A:** No, updating is not possible on USB memory devices with other specifications. Stick to USB Standard: USB 2.0, Capacity: 8 GB to 32 GB, File system: FAT 32.
- **Q:** How long does it take to update the firmware?
- **A:** Updating the firmware takes about 7 minutes for the initial update and approximately 4 minutes for ARM Update and 3 minutes for MCU Update during the process

Documents / Resources

	KENWOOD DMX40S Receiver Multimedia Navigation 2 [pdf] User Guide DMX40S, DMX400S, DMX4710S, DMX5023S, DMX5023DABS, DMX553DABS, DMX40S Receiver Multimedia Navigation 2, DMX40S, Receiver Multimedia Navigation 2, Multimedia Navigation 2, Navigation 2
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.