



KOMATSU 830E-5 Variable Speed Pressuriser Instruction Manual

[Home](#) » [Komatsu](#) » KOMATSU 830E-5 Variable Speed Pressuriser Instruction Manual 

KOMATSU

Contents

- 1 KOMATSU 830E-5 Variable Speed Pressuriser
- 2 Installation Overview
- 3 Installation:
 - 3.1 INSTALLATION
 - 3.2 SAFETY
 - 3.3 CRITICAL PARTS & MAINTENANCE SCHEDULE
 - 3.4 OPERATOR GUIDE
 - 3.5 SPECIFICATIONS HIGH-CAPACITY HEPA PRESSURISER
 - 3.6 Wiring Diagram
 - 3.7 TECHNICAL DETAILS
 - 3.8 GENERAL GUIDE
 - 3.9 SMOKE EMITTER CABIN PRESSURE LEAK TEST
 - 3.10 Commissioning Procedures
 - 3.11 TROUBLE SHOOTING
 - 3.12 Express Warranty
- 4 Documents / Resources
 - 4.1 References
- 5 Related Posts

KOMATSU 830E-5 Variable Speed Pressuriser



Specifications

- Kit Part Number: 700063
- Manufacturer: Komatsu
- Model: 830E-5 / 930E-5 Haul Truck
- Features: HEPA H14 Variable Speed Pressuriser, OnGuard Air Quality Monitoring & Control, HEPA Return Air Filter

Installation Overview

This product is designed for use with Komatsu Haul Trucks 830E-5 / 930E-5.

Installation:

Ensure proper installation of the HEPA H14 Variable Speed Pressuriser and INPRESS TS Cabin Display with Data Recorder. Install the HEPA Return Air Filter as instructed.

Warning

Follow all safety precautions mentioned in the manual. Ensure qualified staff wear appropriate personal protective equipment. Never work on the pressuriser system without following safe work procedures and electrical safety measures.

Maintenance Schedule

Inspect and replace components as per the maintenance schedule provided in the manual. Ensure data download for the 3-year warranty on Brushless Blower Motor.

FAQ

Q: Can the HEPA filters be cleaned?

A: HEPA filters cannot be cleaned and must be replaced at the end of their lifecycle or if the filter media is damaged.

INSTALLATION

INSTALLATION OVERVIEW	
Manufacturer	Komatsu
Type	Haul Truck
Model	830E-5 / 930E-5
Cabin Pressure Max	
Set Auto Cabin Pressure	



HEPA H14 Variable Speed Pressuriser



INPRESS TS Cabin Display with Data Recorder



HEPA Return Air Filter

WARNING

THE PRESSURISATION SYSTEM DESCRIBED IN THIS MANUAL HAS THE FOLLOWING AREAS WHICH MAY BE DANGEROUS IF NOT TREATED WITH GREAT CARE.

QUALIFIED STAFF MUST WEAR THE CORRECT PERSONAL PROTECTIVE EQUIPMENT WHEN CLEANING

AND SERVICING THIS UNIT DUE TO DUST AND FIBRES WHICH MAY BE CAUGHT BY THE STAGES OF AIR FILTRATION DURING NORMAL UNIT OPERATION.

THE ELECTRICAL POWER SYSTEM IS SUPPLIED BY 12V DC OR 24V DC AND NO WORK SHOULD BE CARRIED OUT ON THE PRESSURISER SYSTEM WITHOUT THE CORRECT SAFE WORK PROCEDURES AND ELECTRICAL SAFETY MEASURES BEING TAKEN, AND ALL RELEVANT CIRCUIT BREAKER OPENED TO ISOLATE THE CIRCUIT.

THE AIR FILTRATION SYSTEM MAY HAVE SEVERAL TYPES OF HIGH-SPEED ROTATING EQUIPMENT INSTALLED WITH VERY SHARP EDGES. ENSURE ALL SAFETY GUARD ARE IN PLACE WHILE THE SYSTEM IS RUNNING.

Please be aware that HEPA filters cannot be cleaned and must be replaced at the end of their lifecycle or if filter media has been damaged.



Hard Hat



Eye Protection



Dust Mask



Ear Protection



Protective
Clothing

SAFETY

Particulate Behaviour

This is the length of time it takes for a particle to drop from a height of 1.5m in STILL air.



Warehouses and workshops do not have still air, so hazardous airborne particulates may remain in air for longer, increasing chance for workers to breathe in dust. Ensure PPE is worn when installing this system.



Maintenance Schedule

The following tables show our suggested maintenance schedule for all units. Please note that site conditions may alter this. Excludes high corrosion environments.

Data download is required to claim the 3-year warranty on Brushless Blower Motor.

Inspect every 500 Hours and replace when filter is full*

Component / System	Action Required
Turbo Pre-cleaner	Check operation of the Turbo Pre-Cleaner.
Pressuriser Blower	Ensure blower is operational.
HEPA Primary Filter p/n: R9006273D1	Inspect filter capacity indicator. Replace HEPA filter when 80% or greater. Vacuum out housing before replacing the filter elements.
HEPA Return Air Filter P/N: 500026	Vacuum inside cabin floor before replacing filter.
Filter Frame Assembly, Mounts, Seals and Filter Housing	<ul style="list-style-type: none">• Check door seals, all bolts, screws, and all mounts are secure.• Check the filter canister & ensure it is correctly fitted.• Check latches are operational and in good order.• Replace / Re-tension fixtures and fittings required.

15,000 Hours / 36 months*


15,000 Hours / 36 months*	
Component / System	Action Required
500 Hour Inspection	All 500-hour inspection actions.
Pressuriser's Blower R901169D1	Replace BRUSHLESS Pressuriser blower.

CRITICAL PARTS & MAINTENANCE SCHEDULE

Critical Parts				
Item	Part Number	Qty.	Description	Service Interval
1	R9006273D1	1	Fresh Air HEPA H14 Filter (Tested as per EN1822)	1000* Hours (>80% fan capacity)
2	500026	1	HEPA Return Air Filter	500* Hours
3	R901169D1	1	Brushless Blower Motor – 24V	15,000 Hours
4	R9006704D1	1	OnGuard Main Unit Active	10,000 Hours
5	R9006705D1	1	OnGuard UI	AR
6	R9006276D1	1	OnGuard Breathing Zone Sensor Pod	AR

*Filter service hours are subject to cab sealing efficiency, site conditions and correct system use.

Suggested Schedule Servicing*



Fan Capacity Indicator

The filter is serviceable if the motor capacity is between 10% & 80%. We recommend that the filter is changed if the capacity is over 80%.

Site dependent

OPERATOR GUIDE

OPERATORS CHECKLIST

PRE-START

- | | |
|----|--|
| 1. | Visually inspect the BreatheSafe system for any damage. |
| 2. | Visually inspect the cabin for any damage to doors, windows, seals. |
| 3. | Please remove dust & debris from shoes and clothes before entering the cabin. |
| 4. | Ensure door(s) and windows are closed correctly. |
| 5. | Start engine and turn HVAC on to speed 2 (medium speed). |
| 6. | After fixed speed delay, the BreatheSafe display will show 50 Pascals or a preset value. |

The system is working correctly when the pascal value is green.



>> There is no further action required <<

NORMAL OPERATING CONDITION

Cab Air Conditioning

BreatheSafe recommends OEM air conditioning fan is set at mid speed or greater to circulate air around the breathing zone and minimise CO₂.

Acceptable operating range for BreatheSafe fan 10-80%. >80% recommend maintenance.



ALERTS
Fixed Fan Start Delay <ul style="list-style-type: none"> Allows the operator to carry out pre-start checks – limiting at 30% fan speed, press the red text to disable.
CO₂ Level Alert (if equipped) <ul style="list-style-type: none"> Ensure air conditioning fan is set at mid speed or greater to circulate air and minimise CO₂.
Low Pressure Alarm <ul style="list-style-type: none"> Cabin is not maintaining positive pressure – check doors and windows are closed correctly. Refer to maintenance department to check filters and cabin sealing. Ensure filters are serviceable.
Check Filter <ul style="list-style-type: none"> Reminder to inspect or replace filter. Service hour meter requires re-set. Refer to maintenance department.

Specifications High-Capacity HEPA Pressuriser

- Blower : Brushless Blower P/N R901169D1.
- Protection : Locked Rotor Protection (Sub Zero Environments) Under Voltage, Under/Over Current & Over Temperature.
- Voltage : 24VDC.
- Current Draw : 11 amps (peak). *Note: Motor has slow start to stop excessive in-rush current.
- Air Flow : Up to 30-300 m³/h or 50-215 CFM.
- Pre-cleaner : Integrated VLR (Very Low Restriction). Turbo Pre-Cleaner.
- Filter Element : BreatheSafe HEPA Primary Filter (H14=99.99% MPPS) TESTED AS PER EN1822 – P/N R9006273D1.
- Plugs & Fittings : Mining Spec. Deutsch electrical plugs as standard.
- Construction : High strength composite construction.
- Serviceability : Easy access HEPA filter with twist-lock (TL) dust cap single assembly.
- Mounting : Heavy Duty adjustable mounting brackets.
- Design : Fully designed in SolidWorks 3D CAD & Ansys Engineering Simulation Software.
- FEA Testing : Critical components FEA (Finite Element Analyst) tested in Solid Works Simulation.
- CFD Testing : CFD (Computational Fluid Dynamics) simulations in Flow Works to ensure optimum air flow through the system.

SPECIFICATIONS HIGH-CAPACITY HEPA PRESSURISER

List of Abbreviations	
DH	Dual HEPA

DHPR	Dual HEPA Powered Recirculation
DHAC	Dual HEPA Activated Carbon
DHACPR	Dual HEPA Activated Carbon Powered Recirculation
CPM	Cabin Pressure Monitor
CPU	Central Processing Unit
DB	Decibel Sensor
DPM	Diesel Particulate Matter
GAS	Gas Sensor
HEPA	High-Efficiency Particulate Air Filter
HPAFU	High Pressure Air Filtration Unit
HRAF	HEPA Return Air Filter
HVAC	Heating Ventilation and Air Conditioning
MAF	Mass Air Flow
OEM	Original Equipment Manufacturer
PM	Particulate Mass
RH	Relative Humidity
TEMP	Temperature
TS	Touch screen
UI	User Interface
VMS	Vehicle Monitoring System
VS	Vibration Sensor
OGSP	OnGuard Sensor Pod
CO2s	CO2 Sensor INPRESS TS


Item No.	Qty.	Description	Part No.
1	1	Pre-cleaner Hood & Rotor Assy	200004
2	4	Pre-cleaner Injector Ring	200005
3	1	TL Fan Blade (inc. in #7)	200006
4	1	TL Nose Cone / Pre-cleaner	200007
5	1	TL Motor Housing	200008
6	1	TL Filter Housing	200009
7	1	24v DC Brushless VSD Motor & TL Fan Blade	200002
8	1	O Ring Seal Kit 2 Parts	200010
9	1	Included in 8	200011
10	1	Wiring Sleeve	200012
11	1	HEPA H14 Filter	R9006273D1
12	3	M6 Nyloc Nut	300218 (M6NYL)
13	3	M6 x 55mm Hex Bolt	300982 (M655B)
14	4	M8 x 190 Hex Bolt	301136 (M8190B)
15	8	M8 x 22mm O/D HD Washer	300230 (M8222HTW)
16	4	M8 Nyloc Nut	300249 (M8NYL)
17	5	M4 x 75mm Pan Head Phillips Screw	300162 (M475PBH)





PARTS LIST GA

Item No.	Part No.	Rev	Description	Qty	Colour	Category
1	200201	[*]	Controller Assembly	1	—	Stock Item
2	100481A01	0	High Pressure Unit Module	1	Charcoal Grey MX83-682	Module
3	100481M01	0	Monitor Mount Module	1	Charcoal Grey MX83-682	Module
4	100481R01	0	Return Air Module	1	Charcoal Grey MX83-682	Module
5	100481P01	0	Pipework Module	1	(As Req'd)	Pipework


Kit Part Number: 700063




COMPLETE ASSEMBLY No: 700063




Item No.	Part No.	Rev	Description	Qty	Colour	Category
1	R9006704D1	–	Main Unit Active	1	–	–
2	R9006705D1	–	OnGuard UI	1	–	–
3	R9011424D1		OnGuard Return Air sensor Pod	1	–	–
4	R9006276D1	–	OnGuard Breathing Zone Sensor Pod	1	–	–



Item No	Part No.	Rev	Description	Qty	Colour	Category
1	100481A02	0	TL4 Mount Assy	1	Charcoal Grey MX83-682	Weld Assy
2	100481A03	0	TL4 Mount Lid Module	1	Charcoal Grey MX83-682	Module
3	R9006274D1	[*]	TL4 24V DC Unit	1	–	Stock Item
4	200036	[*]	INPRESS TL 3" Outlet Spigot Gasket	1	–	Stock Item




Item No.	Part No.	Rev	Description	Qty	Material	Colour	Category
1	100481P02	0	2" Spigot Plate Assy	1	—	(As Req'd)	Assembly




Item No.	Part No.	Rev	Description	Qty	Material	Thickness	Colour	Category
1	250101	[*]	Monitor Box, Large	1	—	—	(As Req'd)	Stock Item



MONITOR ASSEMBLY No: 100481M01




Item No	Part No.	Rev	Description	Qty	Material	Thickness	Colour	Category
1	100481R02	0	Filter Base & Angles Assy	1	—	—	Charcoal Grey MX83-682	Weld Assy
2	100481R04	0	Filter Cover Assy	1	—	—	Charcoal Grey MX83-682	Weld Assy
3	100481-R257	0	Return Air Drilling & Cutting Template	1	Zan	1.2	Charcoal Grey MX83-682	Part
4	500026	[*]	HEPA Filter 407x177x49	1	—	—	—	HEPA Filter
5	300814	[*]	M6 x 20 Male Scallop Knobs	4	—	—	—	Fastener



Item No.	Part No.	Rev	Description	Qty	Colour	Category
1	400002 (L100002)	N/A	2 Pin 5m Main Power & Earth Supply Loom	1	–	Stock Item
2	400003 (L100003)	N/A	3 Pin 5m Power, Earth & Speed Control Loom	1	–	Stock Item
3	400004 (L100004)	N/A	5m Air Pressure Sense Pipe w/ Sleaving	1	–	Stock Item

WIRING ASSEMBLY No: 400001



GENERAL GUIDE

General Guide to Cabin Sealing, Testing, and Commissioning of BreatheSafe variable speed Pressurisation Units

(Clean Cabin with HEPA vacuum)

1	Inspect the cabin and ensure all cover panels are in place and any cabin pressure leaks are sealed with grommets, sealer, fit new door seals for used equipment, etc
2	Sitting inside the cabin with the door open, turn on the ignition to power up the unit.
3	The pressuriser fan should power up to full speed, and the monitor should indicate 0 Pa pressure (Allow \pm 2 pascals wind gusts).
4	With the ignition on, close all doors and windows. If the cabin is adequately sealed, the monitor should indicate 50 Pa (Pascals), set pressure or whichever pre-set has been chosen. (If not achieved, check for cabin pressure leaks).
5	Once a cabin pressure of 50 Pa is confirmed. Go to the setting menu, select "System Check." The display will indicate "System Test – Max Fan" on the screen while showing the maximum cabin pressure.
6	The MAX cabin pressure should be above 250 Pascals related to the efficiency of cabin seals (Please note the minimum result for warranty compliance is 250 pascals tested with a new R9006273D1 HEPA filter). Therefore, a cabin pressure result of 300 to 500 pascals is the ideal result.
7	If the above pressure is not achieved, leave the unit at full speed and investigate external leaks outside the cabin: e.g., A/C outlets, drains, window & door seals, locks & hinges, etc.
8	If necessary, with the ignition on, controller on 'MAX FAN SPEED,' A/C blower OFF & all doors & windows closed, set off a smoke emitter inside the cabin (SWP attached).
9	Locate any air leaks around the cabin and re-test. If silicone sealant or similar is used, allow it to dry before re-testing, as even slamming the door could push the seal back out.
10	Continue the sealing and testing procedure as above until a satisfactory outcome is achieved. Fill out the record below and attach photo evidence of maximum pressure result and NANOZEN Real-time Dust Monitoring result to register for warranty

* Do not handle until MSDS & all safety precautions have been read and understood. Use personal protective equipment as required.

Before use, carefully read the product label. Safe work practices are advised to avoid eye or skin contact and inhalation. Observe good personal hygiene, including washing hands before eating. Prohibit eating, drinking, and smoking in contaminated areas. Avoid inhalation. Mechanical extraction ventilation is recommended when the removal of atmospheric contaminants is required. Maintain dust / fume levels below the recommended exposure standard. For small amounts, absorb with sand, vermiculite or similar and dispose of at an approved landfill site.

WARNING

For Professional Use Only – keep out of reach of children.

Do not ignite near or around flammable materials.

Use only in well-ventilated areas, outdoors, and/or with proper respiratory protection.

Persons with respiratory sensitivity should avoid exposure to any smoke.

Concentrated smoke may cause severe burns to the skin, eyes, or respiratory system.

Improper use may result in sufficient inhalation of smoke to cause respiratory tract irritation and lung damage.

Harmful if swallowed.

DANGER

Use only as directed. Do not handle until all safety precautions, including Safety Data Sheet, have been read and understood.

The product contains hexachloroethane. Wear protective clothing. If exposed or concerned, get medical advice. Store in a cool, dry, secure location. KEEP OUT OF REACH OF CHILDREN. Dispose of contents/container per location regulations. When used as directed, exposure should be limited and usually poses no hazard because the hexachloroethane is consumed inside the tube as smoke is produced.









Directions: (Smoke Bomb)

- | | |
|----|---|
| 1. | Ensure other workers in close proximity are informed of use. Place on a non-combustible container, away from flammable materials. |
| 2. | Place at Blower intake, or upwind of target area, or near centre of space. |
| 3. | Orient "Smoke Issues Here" toward air stream, away from surfaces. Place candle on a flame / heat resistance plate – if not it will melt into the plastic surface. |
| 4. | Ensure smoke will not create any hazard where it is anticipated to go. |
| 5. | Ignite emitter inside the cabin using site approved device i.e., solder torch or 'lighter' and conduct smoke test. |
| 6. | Do not touch or hold smoke generator after ignition – item becomes very hot & remains hot after use. |

Smoke Emitter Cabin Pressure Leak Test	
1.	The pressuriser system is switched on (TEST MODE).
2.	Hold the smoke emitter angled down.
3.	Ignite emitter using site approved ignitor i.e., solder torch or 'lighter'.
4.	When the product ignites, remove the lighter.
5.	If the product flames up, blow out the flame.
6.	Place the emitter in a non-flammable container and place it inside the cabin at floor level and close the door/windows.
7.	Observe smoke leaks to indicate worn-out or broken seal locations. Check leakage points outside the cabin.
8.	Do not come into contact with or inhale smoke haze.
9.	Wait until the smoke haze completely disperses before re-entering the cabin. Open door to allow sufficient ventilation of smoke prior to entering cabin.

SMOKE EMITTER CABIN PRESSURE LEAK TEST

Link to MSDS: SMOKE GENERATOR TQ7621AT30S.pdf

Personal Protective Equipment (PPE)	
	Safety glasses must be worn at all times.
	Sturdy footwear with rubber soles must be worn.
	Respiratory protection devices may be required.
	Gloves may be worn.
Pre-operational Safety Checks	
✓	Locate and ensure you are familiar with all machine operations and controls.
✓	Check work area and walkways to ensure no slip/trip hazards are present.
✓	Ensure the work area is clean and clear of any flammable material & fire extinguish device is present.
Operational Safety Checks	
✓	Ensure the machine is correctly isolated / immobilized.
✓	Ensure other persons do not inhale smoke haze.
✓	Take care and do not place a lit emitter close to a flammable surface.
Ending Operations and Cleaning Up	
✓	Leave the work area in a safe, clean, and tidy state.
Potential Hazards	
	Falls
	Fumes
	Fire
	May cause cancer
Exposure is highly unlikely when the product is used as directed. Direct contact with the product does not occur.	
Don't	
✗	Do not use if an open flame is forbidden.
✗	Never leave the emitter [cabin test] unattended.

*This SWP does not necessarily cover all possible hazards associated with this equipment and should be used in conjunction with other references. It is designed as a guide to be used to compliment training and as a reminder to users prior to equipment use.

Commissioning Procedures


Follow each step of the installation guide that was supplied with the BreatheSafe kit.

Cabin sealing is an integral part of RS20 & ISO 23875; you must ensure that cabin seals are adequate for maintaining positive pressure. In addition, the site (end- user) must have the correct procedure(s) for servicing OPERATOR enclosure seals in a proactive manner rather than reactive. Items such as door and window seals must be in good working order or new seals FITTED before the BreatheSafe system installation.

How to run Max Speed Commissioning Test

1. Open the 'action menu' by holding down the centre enter (↵) button or by pressing the up (↑) and down (↓) buttons at the same time.
2. If not already displayed, press the down (↓) button to cycle through the menu options until the 'Max Speed Test' option is displayed
3. Ensure the cabin door and windows are completely closed.
4. Press Enter to begin a max speed test.

Submission for commissioning procedure as per the diagram below




BreatheSafe
TRACS QLD Pty Ltd T/A BreatheSafe

Brisbane / Head Office
82 Mica Street, Carole Park QLD 4300
07 3276 7833 / 1300 667 597

Perth Branch
189 Chisholm Crescent, Kewdale WA 6105
08 9253 3314

Commissioning Certificate

Customer Details Company: <input type="text"/> Customer Email: <input type="text"/> Customer PO Reference: <input type="text"/> Job Reference No: <input type="text"/> Location: <input type="text" value="Australia"/> Collinsville Mine: <input type="text"/>		Date of Issue <input type="text"/> Date of Installation/Commissioning <input type="text"/> Installer/Commissioning Technician Name: <input type="text"/> From Company: <input type="text"/> Company / Agent: <input type="text"/> Installation Location: <input type="text"/> Same as customer location: <input type="checkbox"/>	
Machine Details Brand: <input type="text" value="CATERPILLAR"/> Type: <input type="text" value="Haul Truck"/> Model: <input type="text"/> Fleet No: <input type="text"/> VIN / Serial No: <input type="text"/> Machine Age: <input type="text"/> BreatheSafe System Pressuriser Model: <input type="text" value="TL8"/> Pressuriser Serial No: <input type="text"/> Monitor Model: <input type="text" value="INPRESS TS"/> Monitor Serial No: <input type="text"/> Fresh Air Filter P/N: <input type="text"/> Return Air Filter P/N: <input type="text"/> Act. Carbon Filter P/N: <input type="text"/>		Removed Parts/Filters Fresh Air Filter P/N: <input type="text" value="N/A"/> Return Air Filter P/N: <input type="text" value="N/A"/> Commissioning and Calibration Results Date of test: <input type="text"/> Max Pressure (Pa): <input type="text"/> Pressure Setpoint (Pa): <input type="text"/> Actual Pressure (Pa): <input type="text"/> Motor Load (N): <input type="text"/> Narcosis Real Time Cabin Results Tested at A/C vent: <input type="text" value="N/A"/> Tested in Breathing Zone: <input type="text" value="N/A"/> Warranty Variable Speed Motor - 3 years or 15,000 hours extended warranty: <input type="checkbox"/>	
Installation Notes <input type="text"/> <input type="text"/> <input type="text"/>			




The commissioning images required are

ID plate / Machine Serial Number / Asset Number or Call Sign

- INPRESS TL Pressuriser location
HEPA Return Air Filter Location Option: Powered Return Air Filter
- Cabin Pressure Display Location – Including the "System Check" maximum cabin pressure result with motor output capacity %

Fill in the BreatheSafe Service Tag with the following details

- Machine Serial Number and Installers details
- Date installed and System Check result (max cabin pressure)
- The set cabin pressure with actual pressure and motor percentage output
- Verify the 250-pascal threshold was achieved = pass OR not achieved = fail**



BreatheSafe
Part of **AireSafe**

AIR CONDITIONING FAN MUST BE TURNED TO MEDIUM SPEED TO CIRCULATE AIR & MINIMISE CO₂ LEVELS.

MACHINE SN: BREATHESAFE CONTROLLER SN:

DATE INSTALLED: MACHINE HOURS:

AUTO PRE-SET PRESSURE (Pa): MAX CABIN PRESSURE (Pa):

NOTES (FILTER PART NUMBERS):

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31

JAN FEB MAR APR MAY JUN JUL AUG SEP OCT NOV DEC

2023 2024 2025 2026 2027 2028

Technical Support Phone: 1300 667 597 | www.breathe-safe.com

Please upload machine and installation details in conjunction with the required images. A Commissioning Certificate will be sent to the email address you nominate. **Extended warranty for (RS20 & ISO 23875) BreatheSafe Systems is only applicable to operator enclosures meeting this requirement.

HOW TO OPERATE THE UI


Controlling the UI is performed exclusively with the 5-button keypad located on right side of the UI.

- The up (↑) and down (↓) arrows are used to cycle through:
 - Menu Items (Functions or Configurations)
 - Characters/Numbers when editing a parameter
- The Left (←) and Right (→) arrows are used to:
 - Move between character selection when editing a parameter.
 - Navigate to the 'X', which will allow the user to exit the current menu/selection when activated
- The enter (↵) button is used to:
 - Enter a sub-menu (for editing Configurations)
 - Confirm actions (when a parameter is set or to activate a function)

Pressing the enter (↵) button, will either activate the function shown on the screen or, if editing a parameter, will cycle to the next item in the configuration. Pressing enter (↵) at the end of a menu will return the user to the main menu.

HOW TO GAIN ACCESS TO THE OPERATOR AND ADMIN MENUS

1. Press the up (↑) and down (↓) buttons at the same time.
2. Press the down (↓) button until 'Admin Access' appears



3. Locate the appropriate Access Credentials (Operator or Admin), these are provided on the info sheet. Example shown below.





Figure 1: Excerpt from Info sheet showing access credentials

4. Enter the Access Pin. The up and down buttons are used for setting the character at the current cursor position. The right and left buttons are used for moving the cursor along.



5. Press the enter button.

HOW TO ACCESS THE WEB INTERFACE VIA THE WI-FI ACCESS POINT (AP)

1. Open any Web Browser from a 2.4GHz Wi-Fi capable device
2. On the device, connect to the Wi-Fi network being hosted by the OnGuard. The details of the OnGuard's AP are found on the Info sheet (example shown below). These details are also shown in 'Net Config' in the Admin menu on the OnGuard UI.






Figure 2: Excerpt from Info sheet showing OnGuard's AP

Note: This network name and password is an example only. Refer to the provided info sheet for the appropriate network name and password.



- Open a web browser. Enter the IP address of the OnGuard Access Point (AP) into the address bar (Default is 192.168.7.1 for all OnGuard Kits).



- The client will be prompted to enter a username and password. These are the same access credentials as for the OnGuard UI. 'admin' or 'operator' must be entered as the username and the respective pin must be entered as the password.






Figure3: Excerpt from Info sheet showing access credentials



HOW TO CONFIGURE THE ONGUARD TO CONNECT TO AN EXTERNAL WI- FI NETWORK VIA THE WEB INTERFACE

- Connect to the web interface via the Access Point (See Section 2.0)
- Ensure client is logged in as 'admin'

3. Click 'Edit' under 'Current Configuration' heading



4. Scroll down to 'WiFi, Client Mode'

WiFi, Client Mode ▲


Join network at startup? <input type="button" value="yes"/>	Network Name <input type="text" value="Network"/>	Password <input type="password" value="Password"/>
IPv4 Address <input type="text"/>	Netmask Length <input type="text"/>	Gateway Address <input type="text"/>
Nameserver Address <input type="text"/>		

WiFi Client (STA) mode is independent of the Embedded Access Point; the unit's current IP address can be found in the Operator's UI menu.

5. Enter the details of the network the OnGuard will connect to under 'Network Name' and 'Password'
6. Click 'Save Changes'
7. Click 'Restart OnGuard unit to Apply Config'



8. Once the OnGuard has restarted, reconnect to the web interface via the AP
9. Navigate to 'Help' -> 'About'



10. Verify the OnGuard has successfully connected to the Wi-Fi network by checking that 'WiFi Client' is 'Up' and has an IP Address assigned.
If the status of the Wi-Fi Client is 'Down', manually restart the OnGuard Main Unit by turning it off and then powering it back on after 10 seconds.


Network Connections	Connection Type	Status	IP Address
	WiFi Access Point	Up	192.168.7.1
	WiFi Client	Up	10.60.60.228
	Wired Ethernet	Down	

11. The OnGuard web interface can now be accessed on this network by navigating to the IP address displayed next to 'WiFi Client' (as above example) on any normal web browser.


HOW TO CONFIGURE THE ONGUARD TO CONNECT TO A STANDARD WI-FI NETWORK VIA THE USER-

INTERFACE (UI)


1. Enter the Admin menu on the UI using the 'admin' pin (See Section 2.0)
2. Press the down (↓) button until the 'Net Config' option appears




3. Press the Enter button
4. Press the down (↓) button until the 'WiFi STA Config' option appears.




5. Press Enter
6. Enter the name of the Wi-Fi network for the OnGuard to join under 'STA Network:'





7. Enter the password for this network under 'STA Password:'




8. Select the addressing type by cycling through the options with the up (↑) and down (↓) buttons. The default option is dhcp and is standard for most networks. Consult your network admin to confirm the configuration of the network being connected to.




9. Press Enter
10. The UI will return to the Network menu. From here, scroll to the 'Autostart' option using the up (↑) or down (↓) button.
11. Press Enter. Verify the 'WiFi STA' is one of networks listed for automatic start at boot. Change the networks auto-started on boot using the up (↑) or down (↓) buttons.



12. Press Enter.
13. The UI will return to the Network menu. From here, scroll to the 'Start Net' option using the up (↑) or down (↓) button.



14. Press Enter
15. The UI will return to the Network menu. Confirm the OnGuard has connected to the desired network by navigating to 'Net Status'.
16. Press Enter until the status of 'WiFi STA' is shown:



17. The IP address displayed (10.60.60.72 in the example) is the address of the OnGuard web interface on the network. Navigate to this address via a web browser on a device connected to the same network to access the OnGuard's web interface.

TROUBLE SHOOTING

1. If the network status in step 13 shows 'Wi-Fi STA: down', the OnGuard has not successfully connected to the network.
2. Verify all network details were entered correctly in steps 6-8.
3. Restart the OnGuard by powering off the Main Unit for 10 seconds.
4. Once the OnGuard has restarted, return to step 13.
5. Note: Sometimes multiple restarts are required.

HOW TO ADJUST OR DISABLE THE ALARMS ON THE UI

1. Enter the Admin menu on the UI using the 'admin' pin (See Section 2.0)
2. Press the down (↓) button until the 'LowPr. Alerts' / 'HighPr. Alerts' option appears
3. Press Enter to access the 'Buzzer Volume'
4. Use the up (↑) and down (↓) button to adjust the buzzer volume from 1 to 16, 16 being the highest.
5. To disable the buzzer, adjust the volume to 0.
6. Press Enter
7. If the buzzer is enabled (volume 1 or above), the 'Buzzer Type' option will appear.
8. Use the up (↑) and down (↓) button to adjust the buzzer type until a suitable buzzer has been selected.
9. Press enter to confirm selection.

7.0 HOW TO DISABLE/ENABLE DUST ALERTS ON THE WEB INTERFACE

1. Sign in to the Web Interface as 'admin' (see section 3.0)
2. Click 'Edit' under 'Current Configuration' heading



3. Scroll down to '[Sensor Name] Particulate Matter Sensor' (e.g. Breathing ZoneParticulate Matter Sensor)

Breathing zone Particulate Matter Sensor ▲

High Dust Level Alert Enabled?	PM _{2.5} Alert Threshold (µg/m³)	PM ₁₀ Alert Threshold (µg/m³)
yes ▼	25	50

- Click 'High Dust Level Alert Enabled?' and select 'no'

High Dust Level Alert Enabled?

yes ▼


yes

no

- Scroll to the bottom and select 'Save Changes'.

COMMISSIONING: HOW TO RUN A MAX SPEED TEST


- Open the 'action menu' by holding down the centre enter (↵) button or by pressing the up (↑) and down (↓) buttons at the same time.
- If not already displayed, press the down (↓) button to cycle through the menu options until the 'Max Speed Test' option is displayed



- Ensure the cabin door and windows are completely closed.
- Press Enter to begin a max speed test.

COMMISSIONING: HOW TO RUN A PRESSURE TEST

- Access the Admin menu on the UI using the 'admin' pin (See Section 2.0)
- Press the down (↓) button until the 'Pressure Test' function is displayed.




- It is critically important that the cabin door and windows are fully closed during this operation. If the Minimum Pressure percentage is not reached, a Test Failure alert is raised.
- Press Enter to begin a Pressure test.


HOW TO REPLACE A SENSOR POD

- Switch off power to the OnGuard Main Unit, as it powers the Sensor Pod.
- Remove the existing Sensor Pod from where it is mounted by removing the 4 M4 Bolts from the corners of the

case, the mounting holes are shown in the figure below:



3. Find the replacement Sensor Pod, do not mount this in the previous Sensor Pod's place yet.
4. Remove the 4 M3 screws from the top of the sensor pod and remove the lid.



5. Plug the RJ45 cable used to power the previous Sensor Pod into the female port on the sensor board, clip facing upwards.

Note: Replace the RJ45 cable as well if there is any visible damaged to the cable or plug

6. Replace the lid, ensuring that the RJ45 cable is clamped in the hole between the lid and the base. Special care must be taken to ensure the 4 coloured wires inside the case are not clamped by the lid when putting it back on the case.
7. Replace the M3 screws. Do not over tighten the screws as excessive force will strip the threads inside the plastic.
8. Power on the OnGuard Main Unit.
9. Sign in to the Web Interface as 'admin' (see section 3.0)
10. Click 'Edit' under 'Current Configuration' heading



11. Scroll down to the 'Connect Accessories' heading

Connected Accessories ▲			
Hardware Type	Hardware Serial Number	ID Tag	Assigned to Zone
CO ₂ /PM Sensor	30		Return Air zone ▼
Hardware Type	Hardware Serial Number	ID Tag	Assigned to Zone
CO ₂ /PM Sensor	31		Breathing zone ▼
Hardware Type	Hardware Serial Number	ID Tag	
Display Pod	12		

ⓘ This section lists all currently connected accessories with their (fixed) types and serial numbers. A (persistent) name may be set with the ID Tag field.

⚠ All sensors **must be assigned** to sensor zones or they will be ignored!
If an accessory pod is replaced the zone assignment **must be updated** (because assignments are by serial number).

12. Verify the newly replaced Sensor Pod has successfully connected to the OnGuard by checking the number under 'Hardware Serial Number' matches the serial number on the sticker attached to the Sensor Pod.

Hardware Type

CO₂/PM Sensor

Hardware Type

CO₂/PM Sensor

Hardware Serial Number

30

Hardware Serial Number

31

13. Under 'Assigned to Zone', the new sensor will display 'None'. Click this drop-down menu and select a zone the same zone that applied to the replaced sensor pod. This will one of the zones that is not already assigned to another sensor pod.

For example, if the other connected sensor is assigned to 'Breathing Zone', the replacement sensor is most likely the 'Return Air zone' sensor.

Assigned to Zone

Return Air zone ▼

None

Breathing zone

Return Air zone

Express Warranty

All BreatheSafe products carry a warranty against defects in materials or workmanship, provided the defects are not from factors outside of BreatheSafe's control (including neglect, lack of maintenance, improper installation or operation, unauthorized servicing repair, etc.). BreatheSafe will replace goods defected in material or workmanship at our Queensland factory or designated branch*. All parts deemed as failed or faulty must be returned to BreatheSafe for evaluation unless otherwise stated in writing.

Note- Systems must be installed and commissioned as per BreatheSafe installation and commissioning instructions. Once commissioned, the online commissioning sheet must be filled in, extending the components warranty as below. In addition, the system must be serviced and maintained correctly and by trained and qualified personnel. This requisite includes BreatheSafe technicians, qualified automotive air-conditioning technicians, or qualified auto electricians.

Warranty period

- 1 year or 10,000 hours (whichever occurs first).
- Controllers – 1 year no extended warranty option.
- Warranty Period Extension when commissioning documents are registered online within 28 days of installation
- Extended warranty** only offered if commissioning maximum pressure test reaches at least 250Pa.
- Brushless motor fixed speed two years, or 10,000 hours (whichever occurs first).
- Variable speed brushless motor 15,000 hours, or 3 years** (whichever occurs first).

Must be supplied with a variable speed pressure controller, data download required for 3-year warranty option. Link to online Commissioning and Extended Warranty Registration form <https://www.breathe-safe.com.au/commission/>

What is not covered under Express Warranty?

- Failures are due to incorrect application.
- Damage resulting from neglect, misuse, lack of maintenance, improper installation, or operation, inappropriate or abnormal use, accidental or unauthorized servicing repair.

- Failures are due to parts not being sold or approved by BreatheSafe.
- Failures arising from any other cause that is not directly related to a defect in material or workmanship.

This Express Warranty is VOID if the product is altered, modified, or used in the manner it was not designed for, also including unauthorized repairs, or using maintenance and repair parts other than those supplied by BreatheSafe.

BreatheSafe responsibilities

If there is a defect in material or workmanship not caused by the excluded failures during the warranty period, BreatheSafe will either replace the defective goods at our Queensland factory, or designated branch. * Alternatively, BreatheSafe may elect to provide new replacement parts, BreatheSafe approved repair parts or assembled components needed to repair the defect. BreatheSafe reserves the right to provide a refund of the purchase price in lieu of replacement or repair at BreatheSafe's discretion. The replacement or repaired product will be sent to you freight prepaid by the customer or made available for pick-up on site.

Users Responsibilities

The customer should ensure that the system is maintained according to BreatheSafe service requirements and only authorized parts must be used to service and maintain BreatheSafe systems. In the event of a suspected warranty claim, BreatheSafe should be contacted in the first instance to arrange the repair or to assist with diagnosis. Claims should be made within one week of the repair.


After contacting BreatheSafe, you may be required to deliver or send the parts to BreatheSafe's Queensland factory or designated branch. * Link to online Warranty claim form <https://www.breathe-safe.com.au/warranty/>

Exclusion and Limitations on Damages and Remedies

This warranty is provided in lieu of all other warranties, written or oral, whether expressed by affirmation, promise, description, drawing, model, or sample. To the extent allowed by law, all warranties other than this warranty, whether express or implied, including implied warranties of fitness for a particular purpose, are disclaimed. The maximum liability of BreatheSafe under this warranty shall not exceed the original purchase price of the product. Interference with the equipment by or abuse, or by operating the equipment at ambient temperatures or with electrical power characteristics outside the ranges indicated in our specification shall be excluded from this warranty, as shall consequential damages.

Excluded from any express warranty are costs incurred in relation to service outside our factory our designated service branch, including traveling time, waiting time, transport costs, mechanical and overtime payments required. As per Australian Consumer Law: You are entitled to choose a refund or replacement for major failures with goods. If a failure with the goods or service does not amount to a major failure, you are entitled to have the failure rectified in a reasonable time. If this is not done, you are entitled to a refund for the goods and to cancel the contract for the service and obtain a refund of any unused portion. You are also entitled to be compensated for any other reasonably foreseeable loss or damage from a failure in the goods or service.

*This express warranty gives you specific legal rights, and you may also have other rights that vary from country to country.

	<p>KOMATSU 830E-5 Variable Speed Pressuriser [pdf] Instruction Manual 830E-5, 930E-5, 830E-5 Variable Speed Pressuriser, Variable Speed Pressuriser, Speed Pressuriser, Pressuriser</p>
--	---

References

- [SAFE Health + Foods](#)
- [Commissioning - BreatheSafe](#)
- [Commissioning - BreatheSafe](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.