



LANTRONIX EDS1100 Hybrid Ethernet Terminal Multi Port Server User Guide

[Home](#) » [LANTRONIX](#) » LANTRONIX EDS1100 Hybrid Ethernet Terminal Multi Port Server User Guide 

LANTRONIX EDS1100 Hybrid Ethernet Terminal Multi Port Server



Contents

- 1 OTHER MODEL
- 2 Introduction
- 3 What's in the Box
- 4 SDK Installation Overview
- 5 Building Images with the SDK
- 6 SDK Forum Information
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

OTHER MODEL

MatchPort®



XPort Pro™





Copyright and Trademark

© 2010 Lantronix. All rights reserved. No part of the contents of this book may be transmitted or reproduced in any form or by any means without the written permission of Lantronix. MatchPort and XPort are registered trademarks of Lantronix.

Linux is a registered trademark of Linus Torvalds. μ Clinux is a registered trademark of Arcturus Networks Inc.

Ubuntu is a registered trademark of Canonical Ltd. The Fedora trademark is a trademark of Red Hat, Inc.

Contacts

Lantronix Corporate Headquarters

167 Technology
Irvine, CA 92618, USA

Phone: 949-453-3995

Fax: 949-450-7249

Technical Support

Online: www.lantronix.com/support

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix Web site at

www.lantronix.com/about/contact

Disclaimer

The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors that may appear in this guide.

Revision History

Date	Rev.	Comments
	A	Initial document
9/09	B	Updated
6/10	C	Updated to include EDS11/2100

For supporting product documentation, or the most current version of this document, please visit the Lantronix Web site at www.lantronix.com/support/documentation.

Introduction

This Quick Start Guide explains the basics: how to connect and set up your target on the network; how to install the SDK; and how to build the firmware images. For more detailed information, refer to the User Guide supplied with this product or our Lantronix Web site www.lantronix.com/support/downloads.

Overview

The Lantronix Linux Software Developer's Kit (SDK) is an embedded hardware and software suite that enables Linux developers to create applications on Lantronix' embedded networking modules.

The MatchPort AR module can be used to add networking capabilities to your device. The development board includes two RS-232 serial ports and a 10/100Base-TX network connection (RJ45).

The XPort Pro module can be used to add networking capabilities to your device. The development board includes an RS-232 serial port and a 10/100Base-TX network connection (RJ45).

The EDS1100 & EDS2100 are external device servers that can be used to add networking capabilities to your device. The EDS1100 has one RS-232 serial port and a 10/ 100Base-TX network connection (RJ45). The EDS2100 has two RS-232 serial ports and a 10/100 Base-TX network connection (RJ45). Based on the 2.6 Linux kernel, and leveraging existing open source software, the SDK simplifies the process of adding custom applications. Device drivers, GNU toolchain, pre-defined configuration profiles, and sample applications are all included

What's in the Box

Items included depend on which model you have.

MatchPort

The box contains the following items:

- Ethernet cable 10 ft
- MatchPort AR Evaluation Board
- MatchPort AR Module (may have optional BDM connector)
- Antenna – 2.4GHz 2.15 dbi reverse polarity SMA
- 3.3V wall-mount power supply AC/DC, 1A
- RS-232, DB9F/F, 10ft, null modem cable
- SMA to UFL adapter cable

EDS1100

The box contains the following items:

- EDS1100
- Cat5e UTP RJ45M/M Ethernet cable
- DB25M to DB9F serial cable
- Power Cube, 100-240VAC, with international adapters and Power Cord Restrain

EDS2100

The box contains the following items:

- EDS2100
- Cat5e UTP RJ45M/M Ethernet Cable
- DB9F to DB9F serial cable
- Power Cube, 100-240VAC, with international adapters and Power Cord Restraint

Connecting an Evaluation Board – Ethernet

One Step Connect the PC to the evaluation or demo board with a cross-over cable, or a hub/switch and two

regular RJ45 cables.

1. Select the appropriate power plug adaptor for your geographical location. Insert it into the slot on the Universal Power Supply; then plug the power supply into an outlet.
2. Connect the output plug of the power supply to the EDS1100/EDS2100.
3. Connect one end of the supplied DB9F/F (DB25F on EDS1100) serial cable to the serial port on the laptop or desktop.
4. Connect the other end of the supplied serial cable to the serial port on the EDS1100 (CON1 on EDS2100).
5. Connect the PC to the evaluation or demo board with a cross-over cable, or a hub/switch and two regular RJ45 cables.

Booting the Target Device

To boot your target device (MatchPort AR, XPort Pro, or EDS1100 / 2100):

1. From the host computer, open a terminal emulation program for the serial port.
2. Configure the following serial port settings:
 - **baud rate:** 115200
 - **data length:** 8
 - **parity:** None
 - **stop bit:** 1
 - **flow control:** None
3. Turn the power on.

A series of boot messages displays before the Linux shell prompt of '#' appears.

Configuring an IP Address

By default, the target device (MatchPort AR, XPort Pro, or EDS1100 / 2100) will attempt to obtain an IP address via the DHCP protocol. Type the following command at the Linux shell prompt to determine the IP address:

\$ ifconfig eth0

The ifconfig command can also be used to set an address, but it will not persist across a reboot.

To set a temporary static address, issue the following command (replace angle bracketed items with actual values):

\$ ifconfig eth0 <target_ip_address><target_subnet_mask>

To set a static address that persists across reboots:

1. Use the vi text editor to edit /usr/local/etc/netcfg. (Consult a vi manual for details on using this text editor).
2. Add the following lines to the netcfg file (replace angle bracketed items with actual values) IPADDR=
NETMASK= GATEWAY=
3. Write the changes to the file and exit the from the vi editor. 4. Issue the 'reboot' command to reset the target for changes to take effect.

To set a static address that persists across reboots:

1. Use the vi text editor to edit /usr/local/etc/netcfg. (Consult a vi manual for details on using this text editor).
2. Add the following lines to the netcfg file (replace angle bracketed items with actual values)
IPADDR=<target_ip_address>
NETMASK=<target_subnet_mask>
GATEWAY=<target_gateway_address>
3. Write the changes to the file and exit the from the vi editor.
4. Issue the '**reboot**' command to reset the target for changes to take effect.

SDK Installation Overview

Host requirements

Please make sure that at least 2.5 GB of disk space is available before installation.

Some operations may require root privileges. Consult the User Guide for instructions on setting up sudo access.

Linux Distributions

The SDK was validated on the following Linux distributions:

Redhat-based distributions

- Fedora 9, 10, 11, 12, Fedora Core 5 & 6
- CentOS 5.2, 5.3, 5.4
 - groupinstall 'Development Tools' (installs additional development tools not necessary for the SDK) or gcc, make, glibc-devel
 - python
 - sudo
 - libacl-devel
 - tftp-server or tftpd-hpa
 - libtasn1-devel
 - zlib-devel
 - rsync
 - Optional but recommended packages
 - openssh, openssh-clients, openssh-server
 - nfs-utils
 - ncurses-devel (for the ncurses-based configuration utility)
 - libglade2-devel (for the GTK-based graphical configuration utility)
 - qt-devel (for the Qt3-based graphical configuration utility)

Debian-based distributions

- Debian Lenny 5.0.2 & 5.0.4
- Ubuntu 8.04, 8.10, 9.04, 9.10, 10.04
 - build-essential
- python
- sudo
- libacl1-dev
- tftpd or tftpd-hpa
- libtasn1-3-dev
- zlib1g-dev
- rsync
 - Optional but recommended packages
- ssh
- nfs-kernel-server
- libncurses5-dev (for the ncurses-based configuration utility)
- libglade2-dev (for the GTK-based graphical configuration utility)
- libqt3-mt-dev (for the Qt3-based graphical configuration utility)

Other Distributions

- OpenSUSE 11.2
- pattern install devel_C_C++
- pattern install devel_kernel
- python
- sudo
- libacl-devel
- tftp or tftpd-hpa
- libtasn1-devel
- zlib-devel
- rsync
 - Optional but recommended packages
- openssh, openssh-clients, openssh-server
- nfs-utils
- ncurses-devel (for the ncurses-based configuration utility)
- libglade2-devel (for the GTK-based graphical configuration utility)
- qt-devel (for the Qt3-based graphical configuration utility)

NOTE

If you are able to compile the Linux kernel on your host machine, you will also be able to build the SDK images.

Installation Procedure

To install the SDK software on your host machine:

1. Mount the SDK CD image on your host system. The User Guide provides additional information about image mounting procedures.
2. Select and create an installation directory (replace angle bracketed items with actual values). You must have write privileges to this directory.
\$ mkdir -p <install_directory>
3. Switch into the installation directory.
\$ cd <install_directory>
4. Run the installation script. Use the full path to <cdrom directory>
\$ <cdrom directory>/install.sh
5. When prompted, type Y to accept the installation directory.
6. Install the directory.
[<install_directory>] ? (Y/n) : Y
7. Type Y to continue the installation process, if the following message prompts appear.

Figure 4-1. Message Prompts

You are using /bin/sh -> dash.

To use Linux SDK, you cannot use /bin/sh -> dash.

Attempt to automatically relink /bin/sh -> bash?

(y/N): y

Missing needed host development packages.

Note that sudo privileges are required for installation.

Attempt to automatically install missing packages?

(y/N): y

The SDK begins the installation process on your host system.

NOTE

The installation process may take several minutes to complete.

Building Images with the SDK

To build an image with the SDK:

1. From the development host, switch into the installation directory.

```
$ cd <install directory>
```

2. Source the environment file.

```
$ . env_m68k-µClinux
```

3. Issue the make command.

```
$ make
```

4. Select a configuration profile when prompted.

NOTE

If you are unsure of which configuration profile to use, begin with the DEFAULT profile.

Figure 5-1. Configuration Profile Menu

Configuration Profile

- ```
> 1. DEFAULT (LTRX_PROFILE_DEFAULT) (NEW)
2. DEVELOPMENT (LTRX_PROFILE_DEVELOP) (NEW)
3. NO_IPV6 (LTRX_PROFILE_NO_IPV6) (NEW)
4. COMPACT (LTRX_PROFILE_COMPACT) (NEW)
5. AUFS (LTRX_PROFILE_AUFS) (NEW)
6. SHARED (LTRX_PROFILE_SHARED) (NEW)
```

```
choice[1-6?]: 1
```

```
*
```

```
* Kernel/Library/Defaults Selection
```

```
*
```

```
*
```

```
* Kernel is linux-2.6.x
```

```
*
```

```
*
```

```
* Libc is uClibc
```

```
*
```

```
*
```

```
* glibc Library Configuration
```

5. Press Enter to accept the default options for the remaining prompts.

### Figure 5-2. Configuration Prompts

```
Default all settings (lose changes)
```

```
(DEFAULTS_OVERRIDE) [N/y] (NEW)
```

```
Customize Kernel Settings (DEFAULTS_KERNEL) [N/y] (NEW)
```

```
Customize Application/Library Settings
```

```
(DEFAULTS_VENDOR) [N/y] (NEW)
```



Update Default Vendor Settings

(DEFAULTS\_VENDOR\_UPDATE) [N/y] (NEW)

#### NOTE

The build process may take several minutes to complete.

6. Once the build process is complete, verify that the images listed below are under <install directory>/linux/images/.

```
$ ls linux/images/
```

#### Figure 5-3. Installed Images

image.bin imageu.bin imagez.bin linux.bin linuxz.bin image.without\_header linux.without\_header romfs.img rootfs.img romfs-inst.log

7. **Build the root file system for NFS from the installation directory.**

```
$ mkdir linux/nfs
```

```
$ make
```


## SDK Forum Information

The Lantronix Linux SDK forum Web site (<http://forums.lantronix.com>) is the primary resource to obtain updated revisions of the SDK. The SDK and related documentation are also available via the Downloads page ([www.lantronix.com/support/downloads](http://www.lantronix.com/support/downloads)). Please visit the Lantronix Web site or the Forums page to determine if a more current version of the SDK is available.

Individual forum topics are monitored by Lantronix engineers and technical support staff and may be used to ask questions regarding any aspect of the SDK. Complete the registration process to obtain a logon ID and post your question. If enabled in your user profile, you will receive an email message when a response to your post is available. Other options for interacting with the forum are described on the forum site itself.



## Documents / Resources

|                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  The image shows the Lantronix EDS1100 Hybrid Ethernet Terminal Multi Port Server. It is a rack-mountable unit with a front panel featuring a terminal block, a power switch, and a power indicator. The unit is labeled "LANTRONIX" and "EDS1100". | <p><a href="#">LANTRONIX EDS1100 Hybrid Ethernet Terminal Multi Port Server</a> [pdf] User Guide<br/>EDS1100 Hybrid Ethernet Terminal Multi Port Server, EDS1100, Hybrid Ethernet Terminal Multi Port Server, Terminal Multi Port Server, Multi Port Server, Port Server, Server</p> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## References

- [X Contact Us | Lantronix](#)
- [X Lantronix Remote Access Products for Device Networking, Remote Device Access, and IT Support Management](#)
- [X Lantronix Remote Access Products for Device Networking, Remote Device Access, and IT Support](#)

## **Management**

-  **Manual-Hub.com - Free PDF manuals!**
- **User Manual**

### **Manuals+, Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.