



# LEAP SENSORS LGE0-EN Industrial Grade Wireless Sensor Gateway User Guide

[Home](#) » [LEAP SENSORS](#) » LEAP SENSORS LGE0-EN Industrial Grade Wireless Sensor Gateway User Guide 

*LEAP SENSORS LGE0-EN Industrial Grade  
Wireless Sensor Gateway User Guide*



## Quick-Start Guide

PC - USB CONNECTION

LEAP SENSORS® SYSTEM



**WATCH OUR ONLINE QUICK-START VIDEO TUTORIAL**  
Scan the QR code

<https://www.phaseivengr.com/about-us/support/>

### Contents

- [1 HARDWARE](#)
- [2 CONNECTIONS](#)
- [3 SETTING UP YOUR GATEWAY](#)
- [4 HARDWARE](#)
- [5 CONNECTIONS](#)
- [6 SETTING UP YOUR GATEWAY](#)
- [7 HARDWARE](#)
- [8 CONNECTIONS](#)
- [9 SETTING UP YOUR GATEWAY](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)

## HARDWARE


**Power Adapter**



**USB Cable**



**Ethernet Cable**



**Standard Antenna**





**Gateway**



**Leap Wireless Device**




## CONNECTIONS



## SETTING UP YOUR GATEWAY

- Plug the USB-A end of the USB cable to your PC and the USB-Mini-B end to the gateway (see gateway connection diagram above). (B)
- Screw the antenna into the SMA connector on the gateway. (D)
- Plug the Gateway into a wall outlet using the power adapter. (E) (A)
- Wait a few minutes after power-up, then turn on any sensors before logging into the Gateway Web Interface
- Click 'Start' Icon



**!** If the file explore window doesn't pop up, type in the IP address (see login sheet) of your gateway into your web browser.




- Login  
(See provided login sheet for sign-in credentials)




**Make sure to set your inactivity alerts**



## NAVIGATING THE LEAP USER-INTERFACE SOFTWARE



## Power Switch LED Blink Sequence Decoder





# Quick-Start Guide

## ETHERNET CONNECTION

LEAP SENSORS® SYSTEM



[WATCH OUR ONLINE QUICK-START VIDEO TUTORIAL](https://www.phaseivengr.com/about-us/support/)

Scan the QR code

<https://www.phaseivengr.com/about-us/support/>

### HARDWARE

#### Power Adapter



#### USB Cable



#### Ethernet Cable



#### Standard Antenna




#### Gateway



#### Leap Wireless Device



### CONNECTIONS



### SETTING UP YOUR GATEWAY







# Quick-Start Guide

## CELLULAR CLOUD CONNECTION

LEAP SENSORS® SYSTEM



[WATCH OUR ONLINE QUICK-START VIDEO TUTORIAL](https://www.phaseivengr.com/about-us/support/)

Scan the QR code


<https://www.phaseivengr.com/about-us/support/>

### HARDWARE


**Power Adapter**



**USB Cable**



**Ethernet Cable**



**Standard Antenna**



**Cellular Antenna**






**Gateway**



**Leap Wireless Device**




### CONNECTIONS



### SETTING UP YOUR GATEWAY

- Screw the standard antenna into the (left) SMA connector on the gateway. (D)
- Screw the cellular antenna into the (right) SMA connector on the gateway. (G)
- Plug the Gateway into a wall outlet using the power adapter. (E) (A)
- Wait a few minutes after power-up, then turn on any sensors before logging into LeapSensorManager.com
- Login Screen: LeapSensorManager.com  
(See provided login sheet for sign-in credentials)



Leap Sensors  
Phase IV Engineering

Email Address  
Email

Password  
Password

Login

Reset Gateway to Factory Defaults


Leap Sensors is a trademark of Phase IV Engineering Inc.  
© 2022. All Rights Reserved.




**Make sure to immediately set your inactivity alerts**



## NAVIGATING THE LEAP USER-INTERFACE SOFTWARE




## Power Switch LED Blink Sequence Decoder



[www.phaseivengr.com/about-us/support](http://www.phaseivengr.com/about-us/support) | 303-443-6611

Documents / Resources



**LEAP SENSORS LGE0-EN Industrial Grade Wireless Sensor Gateway** [pdf] User Guide  
LGE0-EN Industrial Grade Wireless Sensor Gateway, LGE0-EN, Industrial Grade Wireless  
Sensor Gateway, Grade Wireless Sensor Gateway, Wireless Sensor Gateway, Sensor Gateway

References

- [LEAP Leap Data Server](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.