

Lenco
LS-50
RECORD
PLAYER GRAY



Lenco LS-50 Record Player Gray Instruction Manual

[Home](#) » [Lenco](#) » Lenco LS-50 Record Player Gray Instruction Manual 

Contents

- [1 Lenco LS-50 Record Player Gray](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 PRECAUTIONS BEFORE USE](#)
- [5 TURNTABLE PARTS](#)
- [6 LISTENING TO A RECORD](#)
- [7 FAQ](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

Lenco

Lenco LS-50 Record Player Gray



Specifications

- Manufacturer: SHENZHEN SHI GUANGKAIYUAN TECHNOLOGY., LTD.
- Model: LS-50
- Input voltage: 100-240V
- Input AC frequency: 50-60 Hz
- Output voltage: 12V
- Output current: 1A
- Output Power: 12W
- Average active efficiency: 83.5%
- Efficiency at low load (10%): 78%
- No load Power consumption: 0.068W

Product Usage Instructions

Precautions Before Use

1. Do not cover or block any ventilation openings. Leave 5 cm (2 inches) free space around the device.
2. Install according to the user manual.
3. Keep the device away from heat sources.
4. Only use specified attachments/accessories.
5. Refer servicing to qualified personnel if the device is damaged.

Turntable Parts

- Speaker

- Turntable Platter
- Slip Mat
- Lift Lever
- Turntable Arm Lock
- Auto Stop Control Switch
- Speed Selection Switch
- Turntable Shaft
- Turntable Arm
- Volume Knob
- Phono Stylus Cartridge
- Removable Dust Cover
- Hinge
- RCA Output Jack
- USB Jack
- Power Adaptor Jack
- Power ON/OFF Button

Listening to a Record

1. Raise the dust cover.
2. Press the Power ON/OFF Button.
3. Place a record on the turntable platter and set the player speed to match the record speed.

CAUTION

Usage of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

PRECAUTIONS BEFORE USE

KEEP THESE INSTRUCTIONS IN MIND

1. Do not cover or block any ventilation openings. When placing the device on a shelf, leave 5 cm (2") free space around the whole device.
2. Install in accordance with the supplied user manual.
3. Keep the device away from heat sources such as radiators, heaters, stoves, candles and other heat-generating products or naked flame. The device can only be used in moderate climates. Extremely cold or warm environments should be avoided. Working temperature between 0°and 35°C.
4. Avoid using the device near strong magnetic fields.
5. Electrostatic discharge can disturb normal usage of this device. If so, simply reset and restart the device following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.
6. Warning! Never insert an object into the product through the vents or openings. High voltage flows through the product and inserting an object can cause electric shock and/or short circuit internal parts. For the same reason, do not spill water or liquid on the product.

7. Do not use in wet or moist areas such as bathrooms, steamy kitchens or near swimming pools.
8. The device shall not be exposed to dripping or splashing and make sure that no objects filled with liquids, such as vases, are placed on or near the apparatus.
9. Do not use this device when condensation may occur. When the unit is used in a warm wet room with damp, water droplets or condensation may occur inside the unit and the unit may not function properly; let the unit stand in power OFF for 1 or 2 hours before turning on the power: the unit should be dry before getting any power.
10. Although this device is manufactured with the utmost care and checked several times before leaving the factory, it is still possible that problems may occur, as with all electrical appliances. If you notice smoke, an excessive build-up of heat or any other unexpected phenomena, you should disconnect the plug from the main power socket immediately.
11. This device must operate on a power source as specified on the specification label. If you are not sure of the type of power supply used in your home, consult your dealer or local power company.
12. Keep away from animals. Some animals enjoy biting on power cords.
13. To clean the device, use a soft dry cloth. Do not use solvents or petrol based fluids.
To remove severe stains, you may use a damp cloth with dilute detergent.
14. The supplier is not responsible for damage or lost data caused by malfunction, misuse, modification of the device or battery replacement.
15. Do not interrupt the connection when the device is formatting or transferring files. Otherwise, data may be corrupted or lost.
16. If the unit has USB playback function, the USB memory stick should be plugged into the unit directly. Don't use an USB extension cable because it can cause interference resulting in failing of data.
17. The rating label has been marked on the bottom or back panel of the device.
18. This device is not intended for use by people (including children) with physical, sensory or mental disabilities, or a lack of experience and knowledge, unless they're under supervision or have received instructions about the correct use of the device by the person who is responsible for their safety.
19. This product is intended for non professional use only and not for commercial or industrial use.
20. Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position vibrations or shocks or by failure to follow any other warning or precaution contained within this user manual will not be covered by warranty.
21. Never remove the casing of this device.
22. Never place this device on other electrical equipment.
23. Do not allow children access to plastic bags.
24. Only use attachments/accessories specified by the manufacturer.
25. Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as the power supply cord or the plug, when liquid has been spilled or objects have fallen into the device, when the device has been exposed to rain or moisture, does not operate normally, or has been dropped.
26. Long exposure to loud sounds from personal music players may lead to temporary or permanent hearing loss.
27. If the product is delivered with power cable or AC power adaptor:
 1. If any trouble occur, disconnect the AC power cord and refer servicing to qualified personnel.
 2. Don't step on or pinch the power adaptor. Be very careful, particularly near the plugs and the cable's exit point. Do not place heavy items on the power adaptor, which may damage it. Keep the entire device out


of children's reach! When playing with the power cable, they can seriously injure themselves.

3. Unplug this device during lightning storms or when unused for a long period.
4. The socket outlet must be installed near the equipment and must be easily accessible.
5. Do not overload ac outlets or extension cords. Overloading can cause fire or electric shock.
6. Devices with class 1 construction should be connected to a main socket outlet with a protective earthed connection.
7. Devices with class 2 construction do not require a earthed connection.
8. Always hold the plug when pulling it out of the main supply socket. Do not pull the power cord. This can cause a short circuit.
9. Do not use a damaged power cord or plug or a loose outlet. Doing so may result in fire or electric shock.

INSTALLATION

1. Unpack all parts and remove protective material.
2. Do not connect the unit to the mains before checking the mains voltage and before all other connections have been made.

TURNTABLE PARTS



1. Speaker
2. Turntable Platter
3. Slip Mat

4. Lift Lever
5. Turntable Arm Lock
6. Auto Stop Control Switch
7. Speed Selection Switch
8. Turntable Shaft
9. Turntable Arm
10. Volume Knob
11. Phono Stylus Cartridge
12. Removable Dust Cover
13. Hinge
14. RCA Output Jack
15. USB Jack
16. Power Adaptor Jack
17. Power ON/OFF Button

LISTENING TO A RECORD

1. Raise the dust cover
2. Press the Power ON/OFF Button.
3. Place a record on the turntable platter and set the player speed to match the record speed. NOTE: when playing a single (a 45 rpm record) and/or records with large centre holes, use the 45 rpm adapter.
Remove the needle cartridge protective cover and unlock the tone arm lock from the tone arm rest. Push the lift lever backward, the tone arm will gently rise up. Gently move the tone arm to the desired position over the record and the turntable platter will begin to rotate when the arm is moved towards it if Auto Stop Control Switch is ON. Release the tone arm onto the turntable by pushing the lift lever forward and the vinyl record will begin to play.
If the Auto Stop Control Switch is turned ON, the record will stop automatically when finished. If Auto Stop Control Switch is turned OFF, the record will NOT stop automatically when finished; you must push the lift lever backward to raise the tone arm and place it back in the rest and then turn off the power to stop the turntable from spinning.
Remark: AUTO STOP function applies to most 33RPM vinyl records. However, for very few vinyl records, it will stop when it does not come to the end, or it will not stop when it comes to the end when AUTO STOP is ON.
4. Connect the RCA Output Jack to the external speaker system with the RCA cable (not provided) to enjoy vinyl records music on your speaker system.

Power supply adaptor

Manufacturer: SHENZHEN SHI GUANGKAIYUAN TECHNOLOGY., LTD. Model number: GKYP50100120EU1

Use only original AC adaptor

Use only the power supply listed in the user instructions

Information	Value and and precision
Manufacturers name or trade mark, commercial registration and address	SHENZHEN SHI GUANGKAIYUAN TECHNOLOGY.,LTD. 2 floor, 41 TianSheng Road, TianLiao village, GongMing Stree, Guangming, Shenzhen, GuangDong, P.R.China
Model Identifier	GKYP50100120EU1
Input voltage	100-240V
Input AC frequency	50-60 Hz
Output voltage	12V
Output current	1A
Output Power	12W
Average active efficiency	83.5%
Efficiency at low load (10%)	78%
No load Power consumption	0.068W

Guarantee

Commaxx B.V. offers service and warranty in accordance with European law, which means that in case of repairs (both during and after the warranty period) you should contact your local dealer.

Important note: It is not possible to send products that need repairs to Commaxx B.V. directly.

Important note: If this unit is opened or accessed by a non-official service center in any way, the warranty expires.

This device is not suitable for professional use. In case of professional use, all warranty obligations of the manufacturer will be voided.

Disclaimer

Updates to Firmware and/or hardware components are made regularly. Therefore some of the instructions, specifications and pictures in this documentation may differ slightly from your particular situation. All items described in this guide are for illustration purposes only and may not apply to particular situations. No legal right or entitlements may be obtained from the description made in this manual.

Disposal of the Old Device

This symbol indicates that the relevant electrical product or battery should not be disposed of as general household waste in Europe. To ensure the correct waste treatment of the product and battery, please dispose of them in accordance with any applicable local laws of a requirement for disposal of electrical equipment or batteries. In so doing, you will help to conserve natural resources and improve standards of environmental protection in the treatment and disposal of electrical waste (Waste Electrical and Electronic Equipment Directive).

CE Marking

Hereby, Commaxx B.V., Wiebachstraat 37, 6466 NG Kerkrade, The Netherlands, declares that this product complies with the essential EU directive requirements.

The declaration of conformity may be consulted via techdoc@commaxxgroup.com

Service

For more information and helpdesk support, please visit www.lenco.com Commaxx B.V. Wiebachstraat 37, 6466 NG Kerkrade, The Netherlands.

FAQ


What should I do if the device is damaged?

If the device has been damaged, refer all servicing to qualified service personnel as specified in the user manual. Do not attempt to repair it yourself.

Can I use a different power adaptor with this device?

No, only use the original AC adaptor provided by the manufacturer. Using a different power supply may damage the device and void the warranty.

Documents / Resources

 <small>LS-50 Record Player Gray</small>	Lenco LS-50 Record Player Gray [pdf] Instruction Manual LS-50 Record Player Gray, LS-50, Record Player Gray, Player Gray, Gray
--------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------

References

- [L Lenco.com | Officiële Lenco Webshop](#)
- [L Lenco.com | Officiële Lenco Webshop](#)
- [🌐 Интернет-магазин lenco.ru - удобный способ приобрести электронные музыкальные устройства Lenco](#)
- [🌐 Интернет-магазин lenco.ru - удобный способ приобрести электронные музыкальные устройства Lenco](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.