



LENNOX 56L80 Sensor and After-Hours Switch Kit Instruction Manual

[Home](#) » [Lennox](#) » LENNOX 56L80 Sensor and After-Hours Switch Kit Instruction Manual 



SENSOR AND AFTER-HOURS SWITCH KIT

INSTALLATION INSTRUCTIONS FOR THE SENSOR AND AFTER-HOURS SWITCH KIT USED WITH L
CONNECTION NETWORK

Contents

- [1 Shipping and Packing List](#)
- [2 Application](#)
- [3 Wall-Mount Sensor Location](#)
- [4 Zone Sensors – 56L80, 94L60, 94L61](#)
- [5 Zone Sensor – 76M32](#)
- [6 Return Air Sensor – 56L81](#)
- [7 After-Hours Override Switch S56 – 56L16](#)
- [8 Standard Sensors Used For Averaging](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

Shipping and Packing List

Package 1 of 1 contains:

1. Sensor (A2) or After-Hours Switch (S56)
2. Screws

IMPORTANT – Use 22AWG minimum, 1 twisted pair shielded cable (100% aluminum shield with drain wire, Teflon jacket). Lennox P/N's 94L63, 27M19, 68M25, and Bel den type 88761 is equivalent.

WARNING

Personal injury, loss of life, or damage to property! Installation and service must be performed by a qualified installer or service agency.

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Application

Either a zone or return air sensor is required on each roof top unit in an L Connection™ network. The L Connection network provides direct digital communication to a single or network of rooftop units. A PC or a network control panel (NCP) can then be used to monitor and/or control the system. 56L80 and 94L60 sensors contain a data port that can be wired to interface with the L Connection network. The data port does not have to be wired or in operation for the system to function; it is a monitoring and diagnostic feature. 56L80 zone sensor contains a warmer/cooler adjustment lever which allows a + 1 degree set point shift. A DIP switch on the sensor base can be adjusted to increase the range to + 4 degrees or limit the range to no adjustment. An after-hours switch is provided on 56L80 and 94L60 zone sensors. A separate after-hours switch must be installed when this feature is desired on systems using a 56L81 return air sensor, a 94L61 zone sensor, or a 76M32 zone sensor.

Cat. No.	Features
56L80	Wall-mount; communication port; after-hours override switch; warmer/cooler adjustment with options.
94L60	Wall-mount; communication port, after-hours override switch.
94L61	Wall-mount.
56L81	Duct-mount; installed in return air.
76M32	Wall-mount; flush-mount; stainless steel.
56L16	After Hours Switch

Wall-Mount Sensor Location

Install the sensor on a standard handy box or directly on the wall. Locate the sensor in a conditioned space approximately 5 feet (1-1/2m) above the floor in an area with good air circulation at an average temperature. Avoid locating the room thermo stat where it might be affected by:

- drafts or dead spots behind doors and in corners
- hot or cold air from ducts
- radiant heat from sun or appliances
- concealed pipes and chimneys

Zone Sensors – 56L80, 94L60, 94L61

1. Route cable from the unit controller to an appropriate location in the conditioned space. Make wire connections to the unit as shown in figure 1.




Figure 1. Sensor Wiring

- Loosen screws and remove sensor cover. Turn set screws clockwise on 56L80 and 94L60. See figures 2 and 3.




Figure 2. Zone Sensor - 56L80 and 94L60




Figure 3. Zone Sensor - 94L61

3. Center opening in the baseplate or over the opening in the wall.
4. Mark holes for screws. See figure 3 or 4. Remove baseplate and drill holes.
5. Insert wall anchors (field provided) and align the baseplate over the opening in the wall. Pull wiring through an opening in the base plate. Secure the baseplate to the wall with screws.
6. Connect wiring to the sensor as shown in figure 1. When the use of the data port is desired on 56L80 and 94L60 sensors, make communication wire connections as shown in figure 5.
7. 56L80 Only The sensor contains a warmer/cooler adjustment lever which allows a $\pm 1^{\circ}\text{F}$ set point shift. A DIP switch on the sensor base can be adjusted to increase the range to $\pm 4^{\circ}\text{F}$ or limit the range to no adjustment. See figure 4 for the DIP switch location and figure 6 to change the adjustment range.
8. Replace zone sensor cover and either tighten side screws or turn set screws counterclockwise to secure cover in place.





Figure 4. Zone Sensor - 56L80 and 94L60



**Figure 5. Communication Wiring - L Connection
(Available On 56L80 and 94L60 Sensors Only)**




Figure 6. Warmer/Cooler Adjustment Range

Zone Sensor – 76M32

1. Route cable from unit controller to an appropriate location in the conditioned space. Make wire connections to the unit as shown in figure 1 (see Page 1).
2. Make wire connections to the sensor with wire nuts (sensor has lead instead of a terminal block).
3. Secure sensor to the wall with screws provided.

Return Air Sensor – 56L81

1. Open the unit filter section and remove the knock-out labeled "A2". See figure 7.
2. Insert return air sensor probe through the hole and secure in place with two screws provided.
3. Connect return air sensor leads to wires from J62 terminals 1 and 3.
4. Connect jumper wires between rooftop unit TB1 terminals 5 and 17 and TB1 terminals 14 and 16.




Figure 7. Unit Filter Section

After-Hours Override Switch S56 – 56L16

IMPORTANT – This section refers to 56L16 only. The after-hours override switch is located on the Zone Sensor (A2) and requires no additional installation or wiring.

Connect standard 24V thermostat wires (one pair 20 AWG minimum) from the unit controller (M1, TB1-16 & 17; M2, M3 or M4 P298-6 & 7). Route the wires to the location where the switch will be installed.

1. Center switch over the opening in the wall and mark holes for screws.
2. Connect wires to switch pigtails.
3. Secure the switch to the wall using the two screws provided.
4. Connect jumper wires between rooftop unit TB1 terminals 5 and 17 and TB1 terminals 14 and 16.

Standard Sensors Used For Averaging

Four sensors may be used to get an average temperature reading. Use ONLY the 94L61, 56L81, 76M32 sensors and the 56L16 after-hours override switch. Wire sensors as shown in figure 8.




Figure 8. Wiring Standard Sensors for Averaging



© 2022 Lennox Industries Inc.
 Dallas, Texas, USA
 CONTROLS
 KITS AND ACCESSORIES
 504,762M
 6/2022
 Supersedes 1/2019

Documents / Resources

	<p>LENNOX 56L80 Sensor and After-Hours Switch Kit [pdf] Instruction Manual 56L80, Sensor and After-Hours Switch Kit, 56L80 Sensor and After-Hours Switch Kit, After-Hours Switch Kit, Switch Kit, 94L60, 94L61, 56L81, 76M32</p>
--	--