



Home » LITEON » LITEON SA8990 Wireless Controllers Instruction Manual 🤼

Contents [hide]


- 1 LITEON SA8990 Wireless Controllers
- 2 Product Information
- 3 USA-FCC
- 4 Safety and Battery Disposal
- 5 Frequently Asked Questions
- 6 Documents / Resources
 - 6.1 References

LITEON

LITEON SA8990 Wireless Controllers



Product Information



Numb	Butto	Name	Function	NOTE1
		Y		
1	W B	X	Normal Control Button	1. B + Paring button : BLE mode.2. X + Pari
'	A	A	Normal Control Button	ng button : RF mode.
		В		
2		Menu	This button is located to the lower right of the Logo button. Use this button to access game and application menu options such as Settings and Help, as well as commands in the user interface such as Go to My Channel.	
3		Share	Located in the center of the game pad, just below the Logo button, p ress this button to capture gamepl ay footage and screenshots, then share them with friends.	

4	8	View	This button is located on the lower left side of the Logo button The function of this button varies depending on the application or game. They are usually used to jump between sections of the user interface, but can also perform different actions depending on the game.	
5		Logo	 Press and release the button an d the setting list appears. Press the button for more than 3 seconds to put the handle into d eep sleep. The joystick has no movement a nd will automatically enter sleep mode after 5 minutes. and then press the button for 3 seconds t o wake up the joystick. Light display of mode switching (Note1) 	Note 4. USB/BLE/RF mode lighting: USB m ode: purple breathing I ight effect. BLE mode: blue breathing light eff ect. RF mode: green b reathing light effect. N ote 5. Pairing lighting effects: BLE mode: Blue light flashes. RF m ode: White light flashes. After the pairing is c ompleted, the original BLE or RF mode lighting effect will return to normal display. Pairing failure or disconnection is displayed as red light breathing. Note 6. The green light flashes when chargin
			5. Light display of BLE/ RF Mode pairing (Note1)6. Light display of charging status	g using the Adapter. A fter charging is completed, the original mod

		(Note1) 7. Light display of "Battery power is s less than 20%" (Note1)	e lighting effect will be restored. When using USB Type-C to conne ct to the USB port of NB or PC for charging , the purple breathing I ight is maintained. Note 7. When the batt ery power is less than 20%, the red light will flash until the chargin g mode is turned on.
6	LS/LS B (Left Stick B utton)	These are small joysticks, used to interact with games, apps, and the Xbox console. These move directi onally, and they can also function as clickable buttons when you pre ss them.	Directional control
7	RS/RS B (Rig ht Stic k Butto n)	These are small joysticks, used to interact with games, apps, and the Xbox console. These move directi onally, and they can also function as clickable buttons when you pre ss them.	Viewing Angle Control
8	D-pad	This is a raised plus sign-shaped toggle that resides at the bottom left of the controller's face. It moves the focus up, down, right, and left in game, app, and control interfaces.	

9	MI	M1 But ton	Right Programmable Buttons after setting up with the software, you c an make a macro of buttons.	
10		M2 But ton	Right Programmable Buttons after setting up with the software, you c an make a macro of buttons.	
11		M3 But ton	Left Programmable Buttons after s etting up with the software, you ca n make a macro of buttons.	
12		M4 But ton	Left Programmable Buttons after s etting up with the software, you ca n make a macro of buttons.	
13		R-SW	Toggle the depth of the RT presse s.	 When the switch is t urned to the left, the RT button only needs to be pressed he alfway to trigger the button function. When the switch is term urned to the right, peress the RT button to the end to trigger the button function.

14		L-SW	Toggle the depth of the LT presses.	 When the switch is t urned to the right, t he LT button only n eeds to be pressed halfway to trigger th e button function. When the switch is t urned to the left, press the LT button to the end to trigger th e button function.
15	au)	RB (Ri ght Bu mper)	This button performs different actions depending on the game.	
16		LB (Left B umper)	This button performs different actions depending on the game.	
17		RT (Ri ght Tri gger)	This button performs different actions depending on the game.	
18	7.1	LT (Lef t Trigg er)	This button performs different actions depending on the game.	
19	<u> </u>	Indicat or	 BLE mode : Blue light RF mode : Green light 	

20	((()))	PARIN G	RF(with Dongle)/BLE(Bluetooth) p aring button Press the pairing butt on for more than 3 seconds to ent er pairing mode.	the light display of paring ref. item5 (Note 1)
21		USB T ype-C port	 For Battery Charging Use the USB cable to connect t o a computer or game console t o go to USB mode then can co ntrol the gamepad. 	Charging light effect: green light flashing
22	O	Earpho ne Jac k	Can be connected to a wired head set	

SA8990Equipment name Type designation (
Type)							
	Restricted substances and their chemical symbols						
nit	Lead (Mercury (Hg)	Cadmiu m (Cd)	Hexava I ent chro m i um (Cr+ 6)	lybrom i n ate d b i p heny I s(P BB)	Polybromina ted diphenyl ethers(PBDE	
		0	0	0	0	0	
	0	0	0	0	0	0	
	0	0	0	0	0	0	
	0	0	0	0	0	0	

П

Г

- 1. Note 1 "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage e content of the restricted substance exceeds the reference percentage value of the presence condition.
- 2. Note 2 "O" indicates that the percentage content of the restricted substance does no t exceed the percentage of reference value of presence.
- 3. Note 3 The "-" indicates that the restricted substance corresponds to the exemption

USA-FCC

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Canada IC

Industry Canada statement:

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions:

Radiation Exposure Statement:

The product complies with the Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Safety and Battery Disposal

CAUTION:

- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- To reduce the risk of fire or burns, do not disassemble, crush, or puncture; do not short external contacts; do not dispose of in fire or water.
- Do not expose your portable device or battery pack to a heat source. When heated to excessive temperatures, battery cells could explode, posing risk of fire.

Keep the battery away from children.

Frequently Asked Questions

Q: How do I switch between USB, BLE, and RF modes?

A: Press the Logo button to cycle through the modes. Each mode is indicated by a different lighting effect.

Q: How do I capture gameplay footage?

A: Press the Share button located at the center of the gamepad below the Logo button to capture gameplay footage and screenshots.

• Q: Can I program the M1 and M2 buttons?

A: Yes, after setting up with the software, you can program macros for the M1 and M2 buttons.

Documents / Resources



LITEON SA8990 Wireless Controllers [pdf] Instruction Manual H4ISD8960, SA8990 Wireless Controllers, SA8990, Wireless Controllers, Controllers

References

- User Manual
 - Controllers, H4ISD8960, LITEON, sa8990, SA8990 Wireless Controllers, Wireless
- LITEON Controllers

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	nment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.