



Logicbus PL Gearhead Instruction Manual

[Home](#) » [Logicbus](#) » Logicbus PL Gearhead Instruction Manual 

Contents

- [1 Logicbus PL Gearhead](#)
- [2 CONTENTS](#)
- [3 ASSEMBLY SEQUENCE](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



Logicbus PL Gearhead




CONTENTS

Mounting Instructions – PL Gearhead

1. PL planetary gearhead.
2. Pinion gear with balanced clamp collar.
3. Four (4) allen head cap screws for mounting the motor to the gearhead.
4. Woodruff key.
5. Allen wrench(es).
6. This instruction sheet.

ASSEMBLY SEQUENCE

1. Slide the clamp collar fully onto the pinion gear.




(fig 1)

2. Gently tighten the two (2) screws on the clamp to remove any loose clearance – keep the distance of the gap


at each end approximately equal.

3. Slide the pinion gear with the clamp onto the motor shaft.



(fig 2)


4. Insert the proper thickness feeler gauge (see: Table A, Pinion Gear Positioning, on back) between the pinion gear and motor pilot.



(fig 3)

Note: feeler gauge not supplied.

5. Tighten the two (2) clamp screws evenly and firmly; then remove feeler gauge.
6. **IMPORTANT:** Tighten the two (2) screws on the clamp to the proper torque (see: Table A, Clamp Screw Torques).
7. Position the motor/pinion assembly vertically on a bench with the pinion gear upwards.
NOTE: if the gearhead requires sealing to the motor face, apply a thin film of Loctite 515 “Gasket Eliminator” or equivalent to the entire mounting surface of the motor to achieve a positive seal.
8. Lift and vertically orient the gearhead over the motor. Carefully and slowly lower the gearhead onto the pinion gear. Proper alignment will be necessary.
9. When the gearhead makes contact with the pinion gear, rotate the gearhead to allow the teeth to align themselves. The unit will find its alignment – then lower the gearhead fully into position.
10. Lay the assembly horizontally on a flat surface and install the motor mounting screws – tighten with Allen wrench.



(Fig 4)

Completed Assembly
PL Planetary Gearhead with Motor

Pinion Gear Positioning and Clamp Screw Torques for Standard Nema Gearheads

UNIT SIZE

- SIZE 17
- SIZE 23
- SIZE 34
- SIZE 42
- SIZE 56
- SIZE 75

WRENCH SIZE

- #4-40
- #8-32
- #10-32
- 1/4-28
- 1/4-28
- 1/4-28

SCREW TORQUE (NOM)

- 10 LB. IN.
- 28 LB. IN.
- 45 LB. IN.
- 110 LB. IN.
- 110 LB. IN.
- 110 LB. IN.

DISTANCE

- .047

- .047
- .094
- .094
- .094
- .094

Additional Clamp Screw Torques

SCREW SIZE

- #6-32
- 3/8-24

SCREW TORQUE (NOM.)

- 15 LB. IN.
- 436 LB. I

Customers will need a torque wrench with the proper Allen tip

- Ventas@I091eDus.eom
- 52 (83)-3823-4349
- www.tienda.logiebus.com.mx

Documents / Resources

	Logicbus PL Gearhead [pdf] Instruction Manual PL Gearhead, Gearhead
---	--