Lumens HDL410 CamConnect Pro Setting





# **Lumens HDL410 CamConnect Pro Setting User Guide**

Home » Lumens » Lumens HDL410 CamConnect Pro Setting User Guide 🖺



#### **Contents**

- 1 Lumens HDL410 CamConnect Pro Setting
- **2 Product Usage Instructions**
- 3 Discovering/ Enrolling HDL410
- 4 Access and enroll HDL410
  - 4.1 HDL410 Room Level Settings
- 5 Setting up HDL410 in room (room level settings)
- 6 Connecting CamConnect with HDL410
- 7 Documents / Resources
  - 7.1 References



### **Lumens HDL410 CamConnect Pro Setting**



### **Product Specifications**

- Product Name: Nureva HDL410 & CamConnect Pro
- Supported Room Types: Meeting room, classroom, open space, and others
- Ports: HDL410 Port 1 and Port 2, CamConnect Pro Port 8931
- Default IP Address: Nureva HDL410 Example: 192.168.11.27, CamConnect Pro Example: 192.168.11.11
- Audio Trigger Level: CamConnect Pro 65 (adjustable)

• Room Coverage: HDL410 optimized performance for reduced reverberations, echoes, and background noise

### **Product Usage Instructions**

Nureva HDL410 Setup

### **Enrolling HDL410**

To enroll HDL410, follow these steps:

- 1. Access the Nureva console at <a href="https://www.nureva.com/software-and-services/console">https://www.nureva.com/software-and-services/console</a>
- 2. Enter the enrollment code located at the bottom of the console hardware
- 3. Follow the prompts to enter room level details

#### **HDL410 Room Level Settings**

To set up HDL410 in a room:

- 1. Define the room type (e.g., Meeting room, classroom)
- 2. Access room level settings by clicking on the room name in the rooms section
- 3. Edit and define room dimensions for optimum performance
- 4. Fine-tune room in relation to seating arrangements and HDL410 ports
- 5. Recalibrate HDL410 in the defined room after making any room-level changes

#### **CamConnect Pro Settings**

#### Connecting CamConnect with HDL410

To connect CamConnect with HDL410:

- 1. Allow HDL410 to send data to CamConnect using port 8931 and CamConnect's IP address
- 2. Select HDL410 from the device dropdown list
- 3. Enter HDL410's IP address and set the connect toggle bar to the right
- 4. Fine-tune and map seating positions with azimuth angles in CamConnect

#### Frequently Asked Questions (FAQ)

Q: How can I optimize the performance of HDL410 in different room types?

**A:** You can optimize HDL410 performance by defining room dimensions accurately, fine-tuning port positioning based on the environment, and recalibrating after any room level changes.

Q: What is the default port for connecting CamConnect Pro with HDL410?

A: The default port for connecting CamConnect Pro with HDL410 is port 8931.

# Discovering/ Enrolling HDL410

#### Preface:


- · Accessing Nureva Console
- Enrolling HDL410 (console method)
- · Editing/defining room dimensions

#### Access and enroll HDL410

Access Nureva console: <a href="https://www.nureva.com/software-and-services/console">https://www.nureva.com/software-and-services/console</a>


Note: There are 2 methods to enroll; 1. USB method and 2. Nureva console. (Nureva console is shown here)

• For USB method see here (console client): <a href="https://support.nureva.com/faqs-nureva-console/generate-enrollment-code-with-nurevaconsole-client">https://support.nureva.com/faqs-nureva-console/generate-enrollment-code-with-nurevaconsole-client</a>



# Enrolling HDL410 (console):

- 1. enter your enrollment code (located at the bottom of console- hardware).
- 2. You will be prompted to enter room level details- see next section




#### Preface:

- · Defining room type
- · Accessing room level settings
- Editing/defining room dimensions
- Defining Room Dimensions for optimum performance
- Fine tuning room in relation to seating arrangements and HDL410 ports
- Recalibrating HDL410 in defined room

# Setting up HDL410 in room (room level settings)


# **Defining room type:**

• Shown below is [type =Meeting room]. HDL410 supports up to 8 types (classroom, open space and others).



### Accessing room level settings;

• Your newly created room will appear in rooms section, click on [room name] to access.




Editing/defining room dimensions: (HDL40 works as if were a single unit.)



**Defining Room Dimensions for optimum performance:** (this will take you to room coverage map)


# Important:

- 1. Measure your room space and place HDL410 port 1 and 2 as precise as possible.
- 2. In my demo, the actual room size is bigger than the defined dimensions. For optimized performance ( to reduce reverberations, echos and background noise).



# Fine tuning room in relation to seating arrangements and HDL410 ports:


- An example for depiction purposes only is shown here, adjust your HDL410 port positioning as needed based on environment and usage scenario.
- The blue spots shows noise or voice source detection.



### Recalibrating HDL410 in defined room:

**Note:** After enrolling and defining room level settings, recalibrate HDL410 in finished room. This ensures all settings are kept and HDL410 "is aware" of environmental/room level changes.

General rule = If there are room level changes, recalibrate your HDL410.



CamConnect Pro (AI-BOX1) Settings

#### Connected State\_AiBox and HDL410


#### Preface:

- Allow HDL410 to send data to CamConnect
- Three Basic connection Steps
- Fine tuning and mapping of seating positions (Azimuth angles in CamConnect) with HDL410

# **Connecting CamConnect with HDL410**

#### Allow HDL410 to send data to CamConnect.

• Use port [8931] & enter Camconnect's IP address [Ex. 192.168.11.11].




Nureva default port is 8931. Please confirm the port is allowed to connect with your PC.

#### **Three Basic connection Steps:**

Below items are found under [Supported Device & Settings] HDMI/Web interface.


- From Device drop down list select = HDL410.
- Enter HDL410's IP address = [example : Device IP = 192.168.11.27]. IP of HDL410 can be found as shown in 3.1.
- Connect toggle bar set to connect = [Connect = move toggle to right].



Fine tuning and mapping of seating positions (Azimuth angles in Camconnect) with HDL410.

 In Advanced setting of CamConnect; set the [Audio Trigger level = 65] or stay close to 60 depending on environment.

- Camconnect automatically provides 8 Azimuth Angles (these angles are adjustable for fine tuning per environment).
- In my example; I show only 4 azimuth Angles in operation; voice source is detected at [-35 ~ -18] then VC-TR40N preset 1 is used to capture talker/voice source.
- Map and Adjust your azimuth angle and seating arrangements per environment, use "heat map" in Coverage map.



Thank You!

#### **MyLumens.com**

**Contact Lumens** 



Copyright © Lumens. All rights reserved.

#### **Documents / Resources**



<u>Lumens HDL410 CamConnect Pro Setting</u> [pdf] User Guide HDL410, HDL410 CamConnect Pro Setting, CamConnect Pro Setting, Setting

### References

- <u>Sumens Pro AV Technology | Lumens</u>
- Mureva Console | Software and services

# • User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.