



FORTRESS
POWER
Secure your energy

eForce Battery-Inverter Integration Guide



IMPORTANT NOTICE

This Quick Guide does not exempt the installer or User from reading each product manual. Failure to do so may risk damaging both Fortress Power equipment and other manufacturers and void warranty.

IMPORTANT NOTICE2

ABBREVIATIONS4

CONNECTION DIAGRAMS5

CONNECTION OVERVIEW 5

PARALLEL CONNECTION OVERVIEW 6

CLOSED LOOP AND PINOUT DEFINITIONS..... 7

Envy Inverter-Battery communication port Pinout..... 7

SOL-ARK Inverter-Battery communication port Pinout 8

ecovault Inverter-Battery communication port Pinout..... 9

SCHNEIDER-Battery communication port Pinout10

VICTRON-BATTERY COMMUNICATION PORT PINOUT11

COMMISSIONING.....12

PROGRAMMING THE INVERTER.....13

FORTRESS POWER ENVY13

Battery Set Up.....13

Self-Consumption Mode.....13

Back up14

Off-Grid16

TIME OF USE16

SOL-ARK17

ECOVAULT23

Real-time parameters view25

Settings26


VICTRON.....33

Abbreviations


A = Amperes	m = Meters
AC = Alternating Current	mA = milliamperes
Ah = Amperes hour(s)	mV = millivolts
AWG = American Wire Gauge	N = Neutral
BAT = Battery	NEC = National Electric Code
BMS = Battery Management System	NEMA = The National Electrical Manufacturers Association
CAN = Controller Area Network	NFPA = National Fire Protection Association
CC = Constant Current (Bulk)	NO = Normally Open
CCV = Closed Circuit Voltage	NC = Normally Closed
°C = Degrees Celsius	OCV = Open Loop Voltage
CT = Current Transformer	OSHA = Occupational Safety and Health Administration
CV = Constant Voltage (Absorption)	OT = Over Temperature
DC = Direct Current	OV = Over Voltage
ESS = Energy Storage System	PE = Protective Earth (Ground)
EOL = End of Life	PV = Photovoltaic
°F = Degrees Fahrenheit	R = Electrical Resistance (Ohms)
HV = High Voltage	RS485 = Recommended Standard 485
HVCO = High Voltage Cut-Off	SOC = State of Charge
I/O = Input or Output	SOC = State of Health
ISC = Short Circuit Current	UT = Under Temperature
IP-Ingress Protection	UV = Under Voltage
in = Inches	V = Voltage
lb. = Pounds	VAC = Volts Alternating Current
LED = Light Emitting Diode	VDC = Volts Direct Current
LFCO = Low Voltage Cut-Off	VPP = Virtual Power Plant
LFP = Lithium Ferro Phosphate	W = Watts (Power)
LN1 = AC Line 1	
LN2 = AC Line 2	
LV = Low Voltage	

CONNECTION DIAGRAMS

CONNECTION OVERVIEW










PARALLEL CONNECTION OVERVIEW











CLOSED LOOP AND PINOUT DEFINITIONS





To ensure Closed Loop communication, please follow the process below. If making a communication cable, refer to the pin out diagram for an RJ45 cable below. Type B format ethernet cable may also be used.

eForce Communication Pinout Configuration			Protocol and cable	ENVY INVERTER-BATTERY COMMUNICATION PORT PINOUT		
 <p>Firmware 6016 or above</p>			<p>Dip Switch :1110</p> <p>Using the DIP switch on the eWay</p> <p>Select the following protocol for Closed Loop Communication.</p> <p>You must do this process only the primary eWay when in parallel. The primary eWay shall be the one that connects battery to inverter communication.</p> 	 <p>Lithium Profile: 18 (Fortress) Inverter firmware shall be 1E1E or above LCD Firmware shall be V20</p>		
PIN	COLOR (B FORMAT)	ASSIGNMENT	<p>Included Unmodified Normal Format B RJ45 Cable. Any of the included cables will work.</p>	PIN	COLOR (B FORMAT)	ASSIGNMENT
1	White Orange	CAN1_H		1	White Orange	BAT RS485 B
2	Orange	CAN1_L		2	Orange	BAT RS485 A
3	White Green	CAN2_G		3	White Green	NC
4	Blue	CAN2_H		4	Blue	BAT CAN H
5	White Blue	CAN2_L		5	White Blue	BAT CAN L
6	Green	RS485G1		6	Green	NC
7	White Brown	RS485A1		7	White Brown	NC
8	BROWN	RS485B1		8	Brown	NC

eForce Communication Pinout Configuration	Protocol and Cable	SOL-ARK INVERTER-BATTERY COMMUNICATION PORT PINOUT																																																						
 <p>Firmware 6016 or above</p>	<p>Dip Switch :1000</p> <p>Using the DIP switch on the eWay Select the following protocol for Closed Loop Communication. You must do this process only the primary eWay when in parallel. The primary eWay shall be the one that connects battery to inverter communication.</p> 	 <p>BMS Lithium BAT 00</p>																																																						
<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td>Can1_H</td></tr> <tr><td>2</td><td>Orange</td><td>Can1_L</td></tr> <tr><td>3</td><td>White Green</td><td>Can2_G</td></tr> <tr><td>4</td><td>Blue</td><td>Can2_H</td></tr> <tr><td>5</td><td>White Blue</td><td>Can2_L</td></tr> <tr><td>6</td><td>Green</td><td>RS485G1</td></tr> <tr><td>7</td><td>White Brown</td><td>RS485A1</td></tr> <tr><td>8</td><td>BROWN</td><td>RS485B1</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange	Can1_H	2	Orange	Can1_L	3	White Green	Can2_G	4	Blue	Can2_H	5	White Blue	Can2_L	6	Green	RS485G1	7	White Brown	RS485A1	8	BROWN	RS485B1	<p><i>Modified Cable (not included). Installer may use extra cable included with the eForce or Inverter to crimp RJ45 cable to the following configuration</i></p> 	<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td>BAT RS485 B-</td></tr> <tr><td>2</td><td>Orange</td><td>BAT RS485 A+</td></tr> <tr><td>3</td><td>White Green</td><td>NC</td></tr> <tr><td>4</td><td>Blue</td><td>BAT CAN H</td></tr> <tr><td>5</td><td>White Blue</td><td>BAT CAN L</td></tr> <tr><td>6</td><td>Green</td><td>GND</td></tr> <tr><td>7</td><td>White Brown</td><td>BAT RS485 A+</td></tr> <tr><td>8</td><td>Brown</td><td>BAT RS485 B-</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange	BAT RS485 B-	2	Orange	BAT RS485 A+	3	White Green	NC	4	Blue	BAT CAN H	5	White Blue	BAT CAN L	6	Green	GND	7	White Brown	BAT RS485 A+	8	Brown	BAT RS485 B-
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White Orange	Can1_H																																																						
2	Orange	Can1_L																																																						
3	White Green	Can2_G																																																						
4	Blue	Can2_H																																																						
5	White Blue	Can2_L																																																						
6	Green	RS485G1																																																						
7	White Brown	RS485A1																																																						
8	BROWN	RS485B1																																																						
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White Orange	BAT RS485 B-																																																						
2	Orange	BAT RS485 A+																																																						
3	White Green	NC																																																						
4	Blue	BAT CAN H																																																						
5	White Blue	BAT CAN L																																																						
6	Green	GND																																																						
7	White Brown	BAT RS485 A+																																																						
8	Brown	BAT RS485 B-																																																						

eForce Communication Pinout Configuration	Protocol and Cable	ECOVAULT INVERTER-BATTERY COMMUNICATION PORT PINOUT																																																						
 <p>Firmware 6016 or above</p>	<p>Dip Switch :1110</p> <p>Using the DIP switch on the eWay Select the following protocol for Closed Loop Communication. You must do this process only the primary eWay when in parallel. The primary eWay shall be the one that connects battery to inverter communication.</p> 	 <p>BMS Communication: FOR</p>																																																						
<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td>CAN1_H</td></tr> <tr><td>2</td><td>Orange</td><td>CAN1_L</td></tr> <tr><td>3</td><td>White Green</td><td>CAN2_G</td></tr> <tr><td>4</td><td>Blue</td><td>CAN2_H</td></tr> <tr><td>5</td><td>White Blue</td><td>CAN2_L</td></tr> <tr><td>6</td><td>Green</td><td>RS485G1</td></tr> <tr><td>7</td><td>White Brown</td><td>RS485A1</td></tr> <tr><td>8</td><td>BROWN</td><td>RS485B1</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange	CAN1_H	2	Orange	CAN1_L	3	White Green	CAN2_G	4	Blue	CAN2_H	5	White Blue	CAN2_L	6	Green	RS485G1	7	White Brown	RS485A1	8	BROWN	RS485B1	<p>Included Unmodified Normal Format B RJ45 Cable. Any of the included cables will work.</p>	<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td>RS485 B</td></tr> <tr><td>2</td><td>Orange</td><td>RS485 A</td></tr> <tr><td>3</td><td>White Green</td><td>NC</td></tr> <tr><td>4</td><td>Blue</td><td>BAT CAN H</td></tr> <tr><td>5</td><td>White Blue</td><td>BAT CAN L</td></tr> <tr><td>6</td><td>Green</td><td>NC</td></tr> <tr><td>7</td><td>White Brown</td><td>BAT RS485 A</td></tr> <tr><td>8</td><td>Brown</td><td>BAT RS485 B</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange	RS485 B	2	Orange	RS485 A	3	White Green	NC	4	Blue	BAT CAN H	5	White Blue	BAT CAN L	6	Green	NC	7	White Brown	BAT RS485 A	8	Brown	BAT RS485 B
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White Orange	CAN1_H																																																						
2	Orange	CAN1_L																																																						
3	White Green	CAN2_G																																																						
4	Blue	CAN2_H																																																						
5	White Blue	CAN2_L																																																						
6	Green	RS485G1																																																						
7	White Brown	RS485A1																																																						
8	BROWN	RS485B1																																																						
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White Orange	RS485 B																																																						
2	Orange	RS485 A																																																						
3	White Green	NC																																																						
4	Blue	BAT CAN H																																																						
5	White Blue	BAT CAN L																																																						
6	Green	NC																																																						
7	White Brown	BAT RS485 A																																																						
8	Brown	BAT RS485 B																																																						

eForce Communication Pinout Configuration	Protocol and Cable	SCHNEIDER-BATTERY COMMUNICATION PORT PINOUT																											
 <p>Firmware 6016 or above</p>	<p>Dip Switch :1100</p> <p>Using the DIP switch on the eWay Select the following protocol for Closed Loop Communication. You must repeat this process for all eWay onsite.</p> 	<p>Schneider 6848 XW PRO</p>  <p>Baud Rate 19200</p>																											
<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td>CAN1_H</td></tr> <tr><td>2</td><td>Orange</td><td>CAN1_L</td></tr> <tr><td>3</td><td>White Green</td><td>CAN2_G</td></tr> <tr><td>4</td><td>Blue</td><td>CAN2_H</td></tr> <tr><td>5</td><td>White Blue</td><td>CAN2_L</td></tr> <tr><td>6</td><td>Green</td><td>D0</td></tr> <tr><td>7</td><td>White Brown</td><td>RS485_A1</td></tr> <tr><td>8</td><td>BROWN</td><td>RS485_B1</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange	CAN1_H	2	Orange	CAN1_L	3	White Green	CAN2_G	4	Blue	CAN2_H	5	White Blue	CAN2_L	6	Green	D0	7	White Brown	RS485_A1	8	BROWN	RS485_B1	 <p><i>Modified stripped cable</i></p>	<p>Insight Home</p>  <p>Schneider Gateway: 12 ISO1CAN L, 14 ISO1CAN H</p>
PIN	COLOR (B FORMAT)	ASSIGNMENT																											
1	White Orange	CAN1_H																											
2	Orange	CAN1_L																											
3	White Green	CAN2_G																											
4	Blue	CAN2_H																											
5	White Blue	CAN2_L																											
6	Green	D0																											
7	White Brown	RS485_A1																											
8	BROWN	RS485_B1																											


eForce Communication Pinout Configuration	Protocol and Cable	VICTRON-BATTERY COMMUNICATION PORT PINOUT																																																						
 <p>Firmware 6016 or above</p>	<p>Dip Switch :1010</p> <p>Using the DIP switch on the eWay Select the following protocol for Closed Loop Communication. You must do this process only the primary eWay when in parallel. The primary eWay shall be the one that connects battery to inverter communication.</p> 	<p>Victron Inverter</p> 																																																						
<table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White</td><td>CAN1_H</td></tr> <tr><td>2</td><td>Orange</td><td>CAN1_L</td></tr> <tr><td>3</td><td>White Green</td><td>CAN2_G</td></tr> <tr><td>4</td><td>Blue</td><td>CAN2_H</td></tr> <tr><td>5</td><td>White Blue</td><td>CAN2_L</td></tr> <tr><td>6</td><td>Green</td><td>D0</td></tr> <tr><td>7</td><td>White Brown</td><td>RS485_A1</td></tr> <tr><td>8</td><td>BROWN</td><td>RS485_B1</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White	CAN1_H	2	Orange	CAN1_L	3	White Green	CAN2_G	4	Blue	CAN2_H	5	White Blue	CAN2_L	6	Green	D0	7	White Brown	RS485_A1	8	BROWN	RS485_B1	<div data-bbox="722 1057 1157 1252"> <p><i>Modified Cable (not included). Installer may use extra cable included with the eForce or Inverter to crimp RJ45 cable to the following configuration</i></p> </div> 	<p>Connect Modified Cable to the Victron CERBO GX</p> <table border="1"> <thead> <tr> <th>PIN</th><th>COLOR (B FORMAT)</th><th>ASSIGNMENT</th></tr> </thead> <tbody> <tr><td>1</td><td>White Orange</td><td></td></tr> <tr><td>2</td><td>Orange</td><td></td></tr> <tr><td>3</td><td>White Green</td><td></td></tr> <tr><td>4</td><td>Blue</td><td></td></tr> <tr><td>5</td><td>White Blue</td><td></td></tr> <tr><td>6</td><td>Green</td><td>CAN2_G</td></tr> <tr><td>7</td><td>White Brown</td><td>CAN2_H</td></tr> <tr><td>8</td><td>BROWN</td><td>CAN2_L</td></tr> </tbody> </table>	PIN	COLOR (B FORMAT)	ASSIGNMENT	1	White Orange		2	Orange		3	White Green		4	Blue		5	White Blue		6	Green	CAN2_G	7	White Brown	CAN2_H	8	BROWN	CAN2_L
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White	CAN1_H																																																						
2	Orange	CAN1_L																																																						
3	White Green	CAN2_G																																																						
4	Blue	CAN2_H																																																						
5	White Blue	CAN2_L																																																						
6	Green	D0																																																						
7	White Brown	RS485_A1																																																						
8	BROWN	RS485_B1																																																						
PIN	COLOR (B FORMAT)	ASSIGNMENT																																																						
1	White Orange																																																							
2	Orange																																																							
3	White Green																																																							
4	Blue																																																							
5	White Blue																																																							
6	Green	CAN2_G																																																						
7	White Brown	CAN2_H																																																						
8	BROWN	CAN2_L																																																						

COMMISSIONING

1. Turn on the Inverter Battery Breaker on the Inverter



2. Turn ON the Disconnect on the eWay. For paralleled battery systems, **only** turn on the Primary Battery



PROGRAMMING THE INVERTER


FORTRESS POWER ENVY

Before setting the parameters, make sure the system is in **Standby**. Make sure to press **SET** for each setup. Confirm the battery is doing Closed Loop Communications with the inverter under the **Battery** of the **Data Section**.

BATTERY SET UP



SELF-CONSUMPTION MODE



Basic	Generator	
Charge	DC Current	
Discharge	Charge current limit(A)	100
Advanced	Gen rated power(kW)	8
Debug	Charge start Volt(V)	46.5
Device info	Charge start SOC(%)	25
	Charge end Volt(V)	31
	Charge end SOC(%)	Adj*
	AC couple	
	Start Volt(V)	Default
	Start SOC(%)	Default
	End Volt(V)	Default
	End SOC(%)	Default

Basic	Operating Mode	
Charge	Use SOC %	Use Bat V
Discharge	Discharge current limit(A)	250
Advanced	Discharge start power(W)	30
Debug	On-grid Cut-off(%)	20
Device info	Off-grid Cut-off(%)	15
	On-grid Cut-off(V)	46
	Off-grid Cut-off(V)	45
	Forced discharge	
	Time 1	00 00 00 00
	Discharge power(kW)	0
	Time 2	00 00 00 00
	Stop discharge SOC(%)	0
	Time 3	00 00 00 00
	Stop discharge Volt(V)	0

Basic	PV input	PV1&2&3
Charge	MODBUS addr	1
Discharge	Vpv start (V)	140
Advanced	Offgrid output	CT direction reversed
Debug	Seamless switch	Charge last
Device info	AC couple	EPS output without Battery
	Smart load	Run without grid
	PV Arc	PV Arc fault clear

Basic	Export to Grid	Max Export to Grid(kW)
Charge	Zero Export	
Discharge	Parallel system	
Advanced	Role	1 Phase Primary
Debug	Phase	Default
Device info	Parallel battery	
	Share battery	
	Auto Detect Phase	Reset

BACK UP

Basic	PV input	PV1&2&3
Charge	MODBUS addr	1
Discharge	Vpv start (V)	140
Advanced	Offgrid output	CT direction reversed
Debug	Seamless switch	Charge last
Device info	AC couple	EPS output without Battery
	Smart load	Run without grid
	PV Arc	PV Arc fault clear

Basic	Export to Grid	Max Export to Grid(kW)
Charge	Zero Export	
Discharge	Parallel system	
Advanced	Role	1 Phase Primary
Debug	Phase	Default
Device info	Parallel battery	
	Share battery	
	Auto Detect Phase	Reset

Basic

Operating Mode

Use SOC % ☒

Use Bat V ☒

Set

Charge

Bat charge current limit(A)

250

Discharge

AC charge ☐

According to SOC/Volt ☒

Set

Advanced

AC charge power(KW)

Adj

Start AC charge SOC(%)

85

Debug

Time 1

00

00

00

00

Start AC charge Volt (V)

Device info

Time 2

00

00

00

00

Stop AC charge SOC(%)

100

Time 3

00

00

00

00

Stop AC charge Volt (V)

Basic

Charge first(PV) ☒

Set

Charge

Time 1

00

00

23

59

Charge first power(KW)

Adj

Discharge

Time 2

00

00

00

00

Stop charge first SOC(%)

100

Advanced

Time 3

00

00

00

00

Stop charge first Volt(V)

51

Debug

Lead-acid

Absorb voltage(V)

51.5

Float voltage(V)

51

Set

Device info

Start derate Volt(V)

46

Basic

Generator

DC Current

Charge current limit(A)

100

Gen rated power(KW)

Adj

Set

Charge

Charge start Volt(V)

45.5

Charge start SOC(%)

25

Discharge

Charge end Volt(V)

51

Charge end SOC(%)

Adj*

Advanced

AC couple

Start Volt(V)

Default

Start SOC(%)

Default

Set

Debug

End Volt(V)

Default

End SOC(%)

Default

Device info

Basic

Operating Mode

Use SOC % ☒

Use Bat V ☐

Set

Charge

Discharge current limit(A)

250

Discharge start power(W)

30

Discharge

On-grid Cut-off(%)

90

Off-grid Cut-off(%)

20

Advanced

On-grid Cut-off(V)

51

Off-grid Cut-off(V)

46

Debug

Forced discharge ☐

Set

Device info

Time 1

00

00

00

00

Discharge power(KW)

0

Time 2

00

00

00

00

Stop discharge SOC(%)

0

Time 3

00

00

00

00

Stop discharge Volt(V)

0

OFF-GRID

Basic

Charge

Discharge

Advanced

Debug

Device info

Generator

DC Current

Charge current limit(A)

100

Gen rated power(kW)

6

Set

Charge start Volt(V)

46.5

Charge start SOC(%)

25

Charge end Volt(V)

31

Charge end SOC(%)

Adj*

AC couple

Start Volt(V)

Default

Start SOC(%)

Default

Set

End Volt(V)

Default

End SOC(%)

Default

Device info

Home

Refresh

Alert

Settings

Basic

Charge

Discharge

Advanced

Debug

Device info

Operating Mode

Use SOC %

☒

Use Bat V

☐

Set

Discharge current limit(A)

250

Discharge start power(W)

50

On-grid Cut-off(%)

20

Off-grid Cut-off(%)

15

On-grid Cut-off(V)

46

Off-grid Cut-off(V)

45

Forced discharge

☐

Set

Time 1

00

00

00

00

Discharge power(kW)

0

Time 2

00

00

00

00

Stop discharge SOC(%)

0

Time 3

00

00

00

00

Stop discharge Volt(V)

0

Device info

Home

Refresh

Alert

Settings

Basic

Charge

Discharge

Advanced

Debug

Device info

PV input

PV1&2&3

Meter or CT

CT

Set

MODBUS addr

1

Meter type

0:1 Phase Meter

Vpv start (V)

140

CT ratio

1/3000

Offgrid output

☒

CT direction reversed

☐

Set

Seamless switch

☒

Charge last

☐

RSD disable

☐

AC couple

☐

EPS output without Battery

☐

Micro-grid

☐

Smart load

☐

Run without grid

☒

Set

PV Arc

☒

PV Arc fault clear

☐

Set

Device info

Home

Refresh

Alert

Settings

TIME OF USE


SOL-ARK

SHARE SOL-ARK MONITORING W/FORTRESS

Set up Wi-Fi with Sol-Ark Inverter using Sol-Ark's My Sol-Ark App and have your site name and Wi-Fi dongle serial number handy to register the system online with Sol-Ark. After registering, use a laptop to log into MySolArk via a web browser at <http://mysolark.com>

Note: For certain circumstances, temporarily use the batteries in open-loop communication mode, please follow the following link for open-loop settings:

1. To program the inverter using the Sol-Ark inverter screen, go to battery setup menu:




2. Program the 'Batt' tab first. Enter the settings as shown below and tap on 'OK' in the bottom of the menu afterwards:

Closed Loop Settings

Batt Setup	
Batt	Charge Discharge Smart Load Wind
Batt Capacity	200Ah Per eForce
Max A Charge	120A Per eForce
Max A Discharge	160A Per eForce
Tempco	0mV/C/Cell
<div><input type="checkbox"/> Use Batt V charged</div> <div><input checked="" type="checkbox"/> Use Batt % Charged</div> <div><input type="checkbox"/> No Battery</div> <div><input checked="" type="checkbox"/> BMS Lithium Batt 00</div> <div><input checked="" type="checkbox"/> Activate Battery</div>	

Confirm closed loop communication was established by going to the Home screen and selecting **LI-BATT INFO**



	0.0 V	0.0 A	-100.0 C	0%	0Ah		
	0.0V	0.0V	0A	0A	0x00	0x00	
1	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
2	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
3	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
4	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
5	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
6	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
7	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
8	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
9	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
10	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
11	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
12	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A
13	0.0 V	0.0 A	0.0 C	0.0%	0.0Ah	0.0V	0.0A



Open Loop Settings

Batt Setup	
Batt	Charge Discharge Smart Load Wind
Batt Capacity	<div>200Ah Per eForce</div> <div><input checked="" type="checkbox"/> Use Batt V charged</div>
Max A Charge	<div>120A Per eForce</div> <div><input type="checkbox"/> Use Batt % Charged</div>
Max A Discharge	<div>160A Per eForce</div> <div><input type="checkbox"/> No Battery</div>
Tempco	<div>0mV/C/Cell</div> <div><input type="checkbox"/> BMS Lithium Batt <input type="checkbox"/></div>
	<input checked="" type="checkbox"/> Activate Battery

Note:

a) If closed loop communication is set up correctly, enabling '**BMS Lithium Batt 00**' will adjust some values automatically. In this tab, those would be 'Batt Capacity' and 'Tempco'.

b) If the total charge/discharge current capacity of the batteries exceeds the inverter's capabilities, use the maximum current settings of the inverter.

For example, if you have four eForce batteries and one Sol-Ark 12K inverter, based on the size of the battery bank, 'Max A Charge' and 'Max A discharge' should be 240A each. But Sol-Ark 12K can only carry 185A DC going to or coming from the battery. So, in this case, both 'Max A Charge' and 'Max A Discharge' would be set to 185A.

c) If recovering a deeply discharged battery, adjust the above charge amps to 10A.

3. Next, program the 'Charge' tab in the 'Battery Setup' menu:

Batt Setup

Batt

Charge

Discharge | Smart Load | Wind

Start V

45V

45.8V

Float V

52V

Start %

10%

15%

Absorption V

52V

A

120A

Per eForce

120A

Per eForce

Equalization V

52V

0 Days

0 Hours

☒Gen Charge

☒Grid Charge

51V Open Loop

51.5V Open Loop

51.5V Open Loop

Note:

a) The settings shown in the latter screenshot are the most conventional ones, hence, adjustments may be required (please see the table below).

The approach described in the note "2b" applies while programing this tab as well. Additionally, current set point (A) **must not exceed the generators' capability.**

Grid-tied	Portable Generator	Stationary Generator	Gen Charge	Grid Charge	Time of Use
Y	N	N	uncheck	15%	20%
Y	Y	N	10%	15%	20%
N	Y	N	20%	uncheck	n/a
N	N	Y	uncheck	20%	n/a
N	Y	Y	10%	20%	n/a

b) Larger generators are commonly tied into the grid side of the inverter rather than the dedicated generator input. Make check-marks and current adjustments accordingly. This fact was kept in mind while creating the last two rows of the table above.

c) Fortress batteries may be discharged to its full rated capacity without voiding the warranty, but for best overall experience and battery life, limit the discharge to 80% except for very rare occasions. Here is a list of our suggested triggers:

d) It is acceptable to raise the grid or generator start triggers to increase the reserve capacity of the system.

4. Program the Discharge tab:

Batt Setup				
Batt	Charge	Discharge	Smart Load	Wind
Shutdown	45V	10%	Batt Resistance	5 mOhms
Low Batt	46V	20%	Batt Charge Efficiency	98%
Restart	46.2V	25%	BMS_Err_Stop	
Batt Empty V	44.8V			

Note:

- At 'Shutdown' state of charge (battery bank charge percentage), inverter prevents battery from powering the loads. The battery(s) will renew/continue providing power to the loads when the battery bank is recharged to 'Restart' state of charge. 'Shutdown' and 'Restart' state of charge set-points can be increased to increase the "reserve capacity" of the system, but that will cause less battery charge usage. The correct shutdown level is specific to the project site.
- Low battery is an alarm also specific to the project site, integrated with the Sol-Ark monitoring app. We suggest a 20% state of charge as a low battery alarm level. But it is a good idea to increase it if the 'Shutdown' and 'Restart' set-points are increased.
- The battery empty voltage should not be lower than **44.8V**. The last statement from the previous note applies to the 'Batt Empty V'. Usually this set-point does not exceed **45.5V**.

Grid Setup / Time-of-Use

Time-of-use settings are specific to each end user but also important to having system behavior meeting customer expectations. system to behave as the end user wants it to behave. There are a few important things to know when programming Sol-Ark's time-of-use settings:

- 1) Checking the "charge" column boxes will force a grid charge to that battery.
- 2) Leaving the "charge" column boxes unchecked will act as a low battery cut-off.
- 3) Enabling "grid-sell" will allow the battery to sell back to the grid when it is otherwise 100% full.
- 4) Solar will charge the battery to 100% if there is enough sunlight available and all the loads are otherwise met.
- 5) Additional settings worth exploring in the Grid Setup Menu are the frequency ranges and grid profile settings useful for generator compatibility.

Back-up Only Customers:

Batteries work better and last longer if they are used, rather than staying 100% full. Our recommendation is to allow the battery to drop to 70% during the early morning hours and then have it go to 100% during the day. You do not need to enable a grid-charge for this functionality. You may want to increase the grid start % or voltage in the battery setup menu.

Time-of-use Customers:

- 1) To maintain solar tax credit compliance, you will want to prioritize battery charging in the hours before the time-of-use period so that the battery is 100% going into the time frame.
- 2) You may also want to enable a grid charge the hour before the time-of-use period to ensure the battery reaches 100%
- 3) You may not want to discharge the battery too aggressively. Sticking to no more than 9kW per eVault or 3.3kW per eFlex Max is optimal for maximizing battery life under time-of-use grid sell-back. Likewise, selling back at less than the full rated value of the inverter is healthy for inverter life. So for example, if you can identify that the battery and inverter will be fully utilized over the time of use rate period by discharging at 5kW rate instead of the full rated capacity of the inverter, it will extend battery life.
- 4) That said, the mantra is "use it or lose it" - it is more economically advantageous for the end user to use the battery when it is financially advantageous to do so, rather than to keep the battery at 100% always.

Bad Utility Buyback Rates aka "no net-metering" aka "bad net-metering":

Allow the battery to discharge to a 20% state-of-charge over night, so that it can absorb as much solar power as possible during the day rather than having that energy sold back to the grid. Staggering the step down percentages throughout the night so that the battery hits 20% right in the early morning will mitigate the risk of power outage between sun up and sun down. Maintain the final 20% time-of-use step with a grid charge to make sure the battery does not go below 20% (which would trigger a full grid recharge at 15% per prior steps). During the day, it does not matter if you prioritize the grid or the battery first when recharging with solar power.

Time	Power(W)	Batt	Charge	Sell
3:00AM	3kW	30%		
5:00AM	3kW	20%		
9:00AM	9kW	100%		
3:00PM	3kW	100%	✓	
7:00PM	6kW	60%		
9:00PM	3kW	45%		

Note: Change the programming from Percentage to Voltage in the Battery setup menu. (Use Batt % Charge / Use Batt V charge)

Here are more aggressive settings for minimizing sell-back to the grid (but allowing grid-sellback when the batteries are full).

For minimizing grid sell-back, no TOU

Grid Param


Limiter	Sell Control	Grid Input	FreqVolt	PowFac	Relay	
		Time	Power(W)	Batt	Charge	Sell
<input checked="" type="checkbox"/> Grid Sell	9000	3:00AM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/> Limited Power to Home		5:00AM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/> Limited Power to Load		9:00AM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>
		3:00PM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/> Time of Use	Setup	7:00PM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>
		9:00PM	9kW	20%	<input checked="" type="checkbox"/>	<input type="checkbox"/>





CANCEL OK










































ECOVAULT

OPERATION AND DISPLAY PANEL

The operation and display panel of the inverter includes one LCD screen, three indicators, and four physical buttons.




Physical button		LED Indicator		
Physical button	Description	Indicator	Color	Description
	Enter/Exit the setup menu	AC/INV	Green	Normally ON: Grid
				bypass output
				Flash: inverter output
	Go to the next option	CHARGE	Yellow	Normally ON: charging
				completed
	Go to the previous option	FAULT	Red	Flash: charging
				Normally ON: level-1 fault
	Confirm/Enter the option in setup menu			Flash: level-2 fault
				OFF: level-3 or level-4 fault

ICON	DESCRIPTION	ICON	DESCRIPTION
	PV panel		Grid
	Battery		Generator
	The inverter is working		Load
	The inverter is communicating with the data collector		The buzzer is in mute mode
	Power flow direction		
 STANDBY	The inverter is in standby mode	 NORMAL	The inverter is working normally
 ALARM	There is a fault		Settings
	Load power: 80%–100%		SOC: 80%–100%
	Load power: 60%–79%		SOC: 60%–79%
	Load power: 40%–59%		SOC: 40%–59%
	Load power: 20%–39%		SOC: 20%–39%
	Load power: 5%–19%		SOC: 5%–19%
 UNDER VOLT	Battery under-voltage	 END OF DISCHG	Battery over-discharge
 OVER LOAD	Overload	 BMS FAULT	BMS fault
 COM	System communication error	 UV	System undervoltage
 OV	System overvoltage	 UT	System under temperature
 OT	System overtemperature	 OC	System overcurrent
 FULL	Battery full power	 USER	User-defined battery
 SLD	Sealed lead-acid battery	 FLD	Flooded lead-acid battery
 GEL	Gel lead-acid battery	 NCM	Ternary Li-ion battery
 LFP	LFP Li-ion battery	 ECO	Energy-saving mode
PVLOAD	PV power is loading	PVCHG	PV power is charging the battery

ACCHG	AC input power is charging the battery	GRID FIRST	The output mode of the inverter is Grid first
BYPASS	The output mode of the inverter is Grid bypass	SOLAR FIRST	The output mode of the inverter is PV first
BATT FIRST	The output mode of the inverter is battery first		


REAL-TIME PARAMETERS VIEW

On the screen, press the UP/DOWN button to view real-time data of the inverter in operation



PAGE	PV	BATTERY	AC INPUT	LOAD	GENERAL
1	PV input voltage	Battery voltage	Grid input voltage	Single-phase voltage	Current time
2	PV input current	Battery current	Grid input current	Single-phase current	Current date
3	PV input power	Battery voltage	Grid total input power	Single-phase active power	PV gross generation
4	PV generation for the day	Battery current	Grid charging capacity for the day	Single-phase apparent power	Total load consumption
5	PV heat sink temperature	Heat sink temperature	Grid frequency	Inverter output frequency	RS485 address
6	Rated open circuit voltage	Rated battery voltage	Bus voltage	Rated output frequency	Software version
7	Maximum PV charge current	Maximum battery charges current	Maximum Grid charge current	Total output active power	/
8			/	Total output apparent frequency	/

SETTINGS



NOTICE

If you use lithium battery which has communication with Inverter, please skip all Battery Voltage setting (04~07)

INVERTERT MODE OF OPERATION DESCRIPTION

00	Exit	ESC	Exit the setup menu
01	ESS	UTI (default)	Backup Mode (Load Source Priority: PV → Grid → Battery)
	Operation Mode	Backup Mode	<p>If PV power is insufficient, the system uses both PV and grid power to support the load.</p> <p>When PV power exceeds the demand, the excess energy charges the battery.</p> <p>Grid power is only used for charging when the battery is over-discharged (if setting 06 is PV-only charging, the grid will not charge the battery).</p> <p>The battery discharges only in off-grid mode</p>
	SBU Self-Consumption Mode (Recommend)		<p>Self-Consumption Mode (Load Source Priority: PV → Battery → Grid)</p> <p>PV Power Priority - The system first uses solar (PV) power to supply the load.</p> <p>Battery Backup - If PV power is insufficient, the system draws power from the battery to support the load.</p>

		<p>Grid as Last Resort - The system switches to grid power only when the battery voltage drops below the set threshold (Parameter ④).</p> <p>Return to PV/Battery - Once the battery voltage recovers above the set threshold (Parameter ⑤), the system switches back to PV or battery power for load supply.</p>
SOL		<p>Self-Consumption Mode (Load Source Priority: PV → Battery → Grid)</p> <p>The PV mode is to be applied first and when the PV power is unavailable or the battery voltage is lower than the set value in the item 4, it will switch to the Grid mode</p>
SUB		PV and Grid prioritize Charging the Battery
Battery		
Charging Priority Mode		<p>PV Priority for Charging - The system prioritizes PV power to charge the battery.</p> <p>Grid-Assisted Charging - If PV power is insufficient, the system uses both PV and grid power for charging (except when Parameter 06 is set to PV-only charging, in which case the grid will not charge the battery).</p> <p>Grid Powers the Load - While the battery is charging, the grid supplies power to the load when PV alone is not sufficient.</p> <p>Hybrid Load Supply - If PV power is enough for charging but insufficient for the load, the system will use both PV and grid power to support the load.</p> <p>Battery Discharges Only in Off-Grid Mode - The battery does not discharge when the system is connected to the grid; it is reserved for off-grid operation only.</p>

FN	PARAMETER	EFORCE	EFLEX MAX/EFLEX	EVault MAX
04	Battery Low Cut of Voltage	48V	51.2V	51.2V
WHEN PARAMETER ITEM 01 IS SET TO SBU (SOLAR-BATTERY UTILITY) OR SOL (SOLAR ONLY) MODE, THE SYSTEM PRIORITIZES PV AND BATTERY POWER. HOWEVER, IF THE BATTERY VOLTAGE DROPS BELOW THE SET CUT-OFF POINT, THE POWER SOURCE AUTOMATICALLY SWITCHES FROM THE INVERTER TO THE GRID TO PREVENT BATTERY OVER-DISCHARGE				
06	Grid Charge Setting	SNU (RECOMMENDED)	SNU (RECOMMENDED)	SNU(RECOMMENDED)
SNU (DEFAULT): BOTH PV AND GRID CAN CHARGE THE BATTERY, WITH PV AS THE PRIORITY CHARGING SOURCE OSO: GRID POWER WILL NOT CHARGE BATTERY				
07	Battery Charge Current	120Adc per eForce	60Adc per eFlex MAX/eFlex	140Adc per eVault MAX

08	Battery Type	L14/15/16	L14/15/16	L14/15/16
09	Battery boost charge voltage (Bulk & Absorption)	51.4V	55.2V	55.2V
10	Boost Charge duration	60min	60min	60min
11	Battery floating charge voltage	51V	54V	54V
12	Battery over- discharge Protection voltage (delayed shutdown)	44.8V	48V	48V
13	Battery over- discharge delay time	50s	50s	50s
<p>WHEN THE BATTERY VOLTAGE DROPS BELOW THE THRESHOLD SET IN PARAMETER ITEM 12, THE INVERTER WILL WAIT FOR THE DELAY TIME SET IN THIS PARAMETER BEFORE SHUTTING OFF THE OUTPUT.</p> <p>SETTING RANGE: 5S - 50S</p> <p>ADJUSTMENT STEP: 5S</p> <p>PURPOSE: THIS DELAY PREVENTS UNNECESSARY SHUTDOWNS DUE TO TEMPORARY VOLTAGE DIPS, ENSURING STABLE SYSTEM OPERATION WHILE STILL PROTECTING THE BATTERY FROM OVER-DISCHARGE</p>				
14	Battery under- voltage alarm threshold	46	51.2	51.2
<p>WHEN THE BATTERY VOLTAGE IS LOWER THAN THE THRESHOLD, IT WILL GIVE AN UNDER-VOLTAGE ALARM AND THE OUTPUT WILL NOT SHUT DOWN. SETTING RANGE: 40 V–52 V, WITH A STEP OF 0.4 V</p>				
15	Battery over discharge protection voltage	44.8	48	48
16	Battery equalization charge	DIS (Default)	DIS (Default)	DIS (Default)

DIS: DISABLE EQUALIZATION CHARGE

ENA: ENABLE EQUALIZATION CHARGE, ONLY AVAILABLE FOR FLOODED LEAD-ACID BATTERIES, SEALED LEAD-ACID BATTERIES, AND USER-DEFINED ONES

32	RS485 Communication Function	CAN	CAN	CAN
33	BMS communication	FOR	FOR	FOR
35	Battery under- voltage recovery threshold	46	51.2	51.2
37	Battery Recharge Voltage	48	51.2	51.2
39	Charge current limit (Communicate with BMS)	LCBMS (default)	LCBMS (default)	LCBMS (default)

LCSET: THE MAXIMUM BATTERY CHARGE CURRENT IS NOT GREATER THAN THE SET VALUE OF "07"

LCBMS (DEFAULT): THE MAXIMUM BATTERY CHARGE CURRENT IS NOT GREATER THAN THE MAXIMUM BMS ALLOWED CURRENT

LCINV: THE MAXIMUM BATTERY CHARGE CURRENT IS NOT GREATER THAN INVERTER ALLOWED CURRENT

40-45	Start and End Charge time 1,2,3,	00:00:00	00:00:00	00:00:00
46	Timed battery charge function	DIS	DIS	DIS

DIS (DEFAULT): DISABLE THE FUNCTION

ENA: WHEN THE TIMED GRID CHARGING/LOAD SUPPLY FUNCTION IS ENABLED, THE POWER SUPPLY MODE WILL OPERATE BASED ON THE CONFIGURED TIME PARAMETERS AND BATTERY STATE (RANGE 0:00:00–23:59:00)

1. OPERATING MODES

SBU MODE ACTIVATION:

THE SYSTEM WILL OPERATE IN SBU MODE WHEN TIMED GRID CHARGING IS ENABLED. THE INVERTER WILL PRIORITIZE SOLAR (S) AND BATTERY (B) POWER, SUPPLYING LOADS FROM THESE SOURCES. WHEN THE SYSTEM REACHES THE CONFIGURED CHARGING PERIOD OR THE BATTERY ENTERS AN OVER-DISCHARGE STATE, IT WILL SWITCH TO GRID (U) POWER FOR BATTERY CHARGING.

UTI MODE ACTIVATION (WITH TIMED DISCHARGE ENABLED): IF THE TIMED DISCHARGE FUNCTION IS ALSO ENABLED, THE SYSTEM WILL SWITCH TO UTI MODE. IN THIS MODE, THE INVERTER: USES GRID POWER FOR BATTERY CHARGING ONLY DURING THE SET CHARGING PERIOD. SWITCHES TO BATTERY INVERTER OPERATION DURING THE CONFIGURED DISCHARGE PERIOD OR IF THE GRID POWER IS LOST.

47-52	Start and End discharge time 1,2,3	00:00:00	00:00:00	00:00:00
53	Timed battery discharge function	DIS	DIS	DIS

DIS (DEFAULT): DISABLE THE FUNCTION

ENA: AFTER THE TIMED BATTERY DISCHARGE FUNCTION IS ENABLED, THE POWER SUPPLY MODE WILL BE CHANGED INTO UTI, WHERE THE SYSTEM ONLY SWITCHES TO THE POWER SUPPLY OF BATTERY INVERTER DURING THE SET DISCHARGE PERIOD OR GRID FAILURE

58	SOC setting for discharge alarming	25%	25%	25%
-----------	---	------------	------------	------------

WHEN THE CAPACITY IS LESS THAN THE SET VALUE, THE SOC ALARMS (UNIT: %, ONLY AVAILABLE DURING NORMAL BMS COMMUNICATION)

59	SOC setting for discharge cutoff	20%	20%	20%
-----------	---	------------	------------	------------

WHEN THE CAPACITY IS LESS THAN THE SET VALUE, THE DISCHARGE STOPS (UNIT: %, ONLY AVAILABLE DURING NORMAL BMS COMMUNICATION)

60	SOC setting for charge cutoff	100%	100%	100%
-----------	--------------------------------------	-------------	-------------	-------------

WHEN THE CAPACITY IS GREATER THAN THE SET VALUE, THE CHARGE STOPS (UNIT: %, ONLY VALID DURING NORMAL BMS COMMUNICATION)

61	SOC setting for switching to grid	25%	25%	25%
-----------	--	------------	------------	------------

WHEN THE CAPACITY IS LESS THAN THE SET VALUE, IT SWITCHES TO GRID (UNIT: %, ONLY AVAILABLE DURING NORMAL BMS COMMUNICATION)

62	SOC setting for Switching to inverter Output	100		100
-----------	---	------------	--	------------

WHEN THE CAPACITY IS GREATER THAN THE SET VALUE, IT SWITCHES TO THE INVERTER OUTPUT MODE (UNIT: %, ONLY AVAILABLE DURING NORMAL BMS COMMUNICATION)

73	Max charging current by generator	80Adc	80Adc	80Adc
-----------	--	--------------	--------------	--------------

SCHNEIDER

1. Connect to Schneider's Insight Local
2. Go to SETUP>CONFIGURATION>MODBUS SETTINGS and select **19200 Baud Rate**. Click Apply

The screenshot shows the 'Setup' tab in the Schneider Insight Local interface. The 'Modbus settings' section is expanded, showing 'Serial Port A' configuration. The 'Baud rate' is set to '19200', 'Parity' is 'None', 'Stop bits' is '1', 'Serial unit' is '0', and 'Timeout (ms)' is '1000'. There are 'Apply' and 'Cancel' buttons at the bottom right.


3. Go to SETUP>Device Detection> input range 1-10. Click Detect.

The screenshot shows the 'Device Detection' section in the 'Setup' tab. The 'Port' is 'RS-485-1' and the 'Range' is set from '1' to '10'. A 'Detect' button is located at the bottom right.

4. Make sure that Insight Home is reading the battery internal parameters



5. Associate Battery as House Battery Bank 1



Parameter Settings

Charger Settings

Recharge Voltage	<input type="text" value="46"/>	V	Charge Block Start	<input type="text" value="12"/>	<input type="text" value="00"/>	AM
Recharge SOC	<input type="text" value="20"/>	%				
Recharge SOC Delay	<input type="text" value="60"/>	s	Charge Block Stop	<input type="text" value="12"/>	<input type="text" value="00"/>	AM

Battery Settings

Battery Type	<input type="text" value="Li-Ion"/>
Charge Cycle	<input type="text" value="External BMS"/>
SOC Control Enable	<input checked="" type="checkbox"/> Enabled

PARAMETER

VALUE

CHARGER SETTINGS

RECHARGE VOLTAGE

46V

RECHARGE SOC

20%

RECHARGE DELAY

60s

BATTERY SETTINGS

BATTERY TYPE

LI-ION

CHARGE CYCLE

EXTERNAL BMS

SOC CONTROL ENABLE

ENABLED

BATTERY BANK CAPACITY	200aH per eForce
MAXIMUM CHARGE RATE	100%
MAXIMUM BULK CHARGE CURRENT	120A per eForce
MAXIMUM ABSORPTION CHARGE CURRENT	120A per eForce
MAXIMUM FLOAR CHARGE	120A per eForce
DEFAULT BATTERY TEMPERATURE	WARM
ABSORPTION TIME	3600
BULK/BOOST VOLTAGE	51.5
ABSORPTION VOLTAGE SET POINT	51.5
MAXIMUM DISCHARGE CURRENT	160A per eForce
MAXIMUM DISCHARGE TIME INTERVAL	8
LOW BATTERY CUT OUT	44.8V
LOW BATTERY CUT OUT DELAY	10s
LOW BATTERY CUT OUT HYSTERESIS	2
LOW BATTERY CUTOUT WARNING OFFSET	2
HIGH BATTERY CUT OUT	58V
CHARGE CYCLE TIMEOUT	1440s
HIGH SOC CUT OUT	99%
HIGH SOC CUT OUT DELAY	2s
LOW SOC CUT OUT	15%
LOW SOC CUT OUT DELAY	60s

VICTRON

Setup Steps

