

Installation Manual

Premier 412/816/832

INS159-11



Texecom

Contents


1. System Overview.....	5	Service Faults.....	20
System Architecture.....	5	Communicator.....	20
Control Panels.....	5	Operation.....	20
Remote Keypads.....	5		
Zone Expansion Modules.....	6	4. Programming the Control Panel.....	21
PC-Com Module.....	6	Introduction.....	21
ComIP Module.....	6	Confirm Devices.....	21
Speech Module.....	6	Viewing Numeric Data (LED Keypads).....	21
Radio Receiver Module.....	6	Programming Text (LCD Only).....	22
		Program Menus.....	22
2. Installation.....	7	Programming Zones.....	24
Installation Sequence.....	7	All Zone Options ①①.....	25
Control Panel.....	7	Zone Type ①①.....	25
Mounting.....	7	Zone Wiring ①②.....	26
Wiring the Control Panel.....	7	Zone Attributes 1 ①③.....	26
Control Panel PCB Layout.....	8	Zone Attributes 2 ①④.....	27
Connecting Devices to the Data Bus.....	9	Zone Attributes 3 ①⑤.....	27
Wiring the Data Bus.....	9	Zone Attributes 3 (Key Switch) ①⑤.....	28
Cable Type and Distances.....	9	Zone Partitions & Groups ①⑥.....	28
Overcoming Voltage Drop.....	10	Zone Text (LCD Only) ①⑦.....	28
Installing a Power Supply.....	10	Assign Radio Device ①⑧.....	28
Installing Remote Keypads.....	11	Programming Partitions.....	29
Keypad Layouts.....	11	Partition Exit Delay ②①.....	30
Remote Keypad Connections.....	11	Partition Entry Delay 1 ②①.....	30
Remote Keypad Address.....	11	Partition Entry Delay 2 ②②.....	30
Keypad Zones.....	11	Partition Communication Delay ②③.....	30
Keypad Output.....	11	Partition Bell Delay ②④.....	30
Keypad Speaker Output (LCDL/LCDLP FMK/SMK).....	12	Partition Bell Duration ②⑤.....	30
Adjustable Backlighting.....	12	Partition Options ②⑥.....	30
Keypad Lid Tamper.....	12	Partition Auto Arm/Disarm Options ②⑦.....	31
Remote Zone Expander Module.....	12	Equipment Areas ②⑧.....	31
Remote Expander Layout.....	12	Programming Global Options.....	32
Wiring the Zone Expander.....	12	System Timers ③①.....	34
Remote Expander Address.....	12	System Counter/Levels ③①.....	34
Remote Expander Zones.....	12	System Control Timers ③②.....	35
Zone Expander Outputs.....	13	System Options 1 ③③.....	35
Zone Expander Speaker Driver.....	13	System Options 2 ③④.....	35
Local Zone Expander Module.....	13	System Options 3 ③⑤.....	35
Local Expander Layout.....	13	Hardware Options ③⑥.....	36
Local Expander Zones.....	13	Auxiliary Input Options ③⑦.....	36
Installing the Local Zone Expander.....	13	Miscellaneous Options 1 ③⑧-①.....	37
Zone Connections.....	14	Miscellaneous Options 2 ③⑧-②.....	37
Normally Closed.....	14	EN50131 Options ③⑨.....	38
Normally Open.....	14	Programming Remote Keypads.....	39
Single EOL - N/C & N/O (Burglary).....	15	Keypad Options 1 ④①.....	40
Single EOL - N/O (Fire).....	15	Keypad Options 2 ④①.....	40
Single EOL - N/C.....	15	Keypad Options 3 ④②.....	40
Single EOL - O/C Tamper.....	15	Keypad Options 4 ④③.....	41
Single EOL - S/C Tamper.....	15	Programming Remote Expanders.....	42
Double EOL.....	16	Expander Partitions ⑤①.....	42
Zone Doubling.....	16	Expander Tones ⑤①.....	42
Triple EOL.....	16	Expander Volume Level ⑤②.....	42
Double Pole.....	17	Programming System Outputs.....	43
2-Wire Smoke Detector.....	17	Panel Outputs ⑥①.....	45
Speaker/Bell Connections.....	17	Fast Format/Speech Channels ⑥①.....	45
Speaker Operation.....	17	Expander 1 Outputs ⑥②.....	45
Siren/Bell Operation.....	18	Expander 2 Outputs ⑥③.....	45
Siren/Spk Supervision.....	18	Expander 3 Outputs ⑥④.....	45
Telephone Line Connections.....	18	Keypad Outputs ⑥⑤.....	45
Panel Outputs 1 - 8.....	18	Output Groups and Types.....	45
Output Wiring.....	18	Output Attributes.....	47
Output Supervision.....	18	Programming the Communicator.....	48
3. Commissioning & Troubleshooting.....	19	Communicator Options ⑦①.....	50
Commissioning.....	19	ARC 1 Communicator Menu ⑦①.....	50
Troubleshooting.....	19	Telephone Numbers ⑦①-①.....	50
Power Faults.....	19	Account Numbers ⑦①-①.....	51
Remote Keypads.....	19	Protocol Type ⑦①-②.....	51
Remote Expander.....	20	Dial Attempts ⑦①-③.....	51
Zones.....	20	Partition Options ⑦①-④.....	51
		Reporting Options ⑦①-⑤.....	52
		Pulse Format Options ⑦①-⑥.....	52
		Fast Format Reporting Channels ⑦①-⑦.....	52
		Protocol Options ⑦①-⑧.....	53
		ARC 2 Communicator Options ⑦②.....	53

Fast Format Restore Channels ⑦③	53	6. Specifications.....	75
Fast Format Open/Close Channels ⑦④	54	Control Panel	75
Cancel Call Waiting Sequence ⑦⑤	54	Identifying the Control Panel Type	76
Programming Check List	55	Remote Keypads	76
Programming Download Options	56	Remote Zone Expander	76
Download Menu ⑦⑥	57	Local Zone Expander	76
Download Options ⑦⑥-①	58	Safety Notes	76
Call Back Number ⑦⑥-①	58	Standards	77
UDL Passcode ⑦⑥-②	58	EN 50131-1/3/6 Compliance	77
Download Dial Attempts ⑦⑥-③	58	Warranty	77
Ring Count ⑦⑥-④	58	7. Quick Reference Guide	78
Com1 Device Type ⑦⑥-⑤	58	8. Standard Defaults & Programming	
IP Address & Port ⑦⑥-⑥	58	Records.....	83
ComIP Gateway Address ⑦⑥-⑦	58	Installation Details	83
ComIP Subnet Mask ⑦⑥-⑧	59	Zone Details	83
Com2 Device Type ⑦⑥-⑨	59	Programming Worksheets & Defaults	84
Chiron Iris Data Setup ⑦⑥-⑨ _{Area}	59	Notes	102
Programming Reporting Codes	60		
Zone Alarm/Restore Codes ⑦⑦	61		
Zone Bypass/Unbypass Codes ⑦⑧	61		
Non Zone Alarm/Restore Codes ⑦⑨	61		
Contact ID and SIA Codes	61		
Programming Users	62		
Program User ⑧①	64		
User Options 1 ⑧①	64		
User Options 2 ⑧②	64		
User Options 3 ⑧③	65		
User Text (LCD Only) ⑧④	65		
Program Standard Users ⑧⑤	65		
Default ALL Users ⑧⑥	65		
System Tests & Utilities	66		
Walk Test ⑨①	67		
Test Speakers & Outputs ⑨①	67		
Send Test Call ⑨②	67		
Enable Remote/Engineer Access ⑨③	67		
Start Call Back ⑨④	67		
Program Time ⑨⑤	67		
Program Date ⑨⑥	67		
Program Banner Text (LCD only) ⑨⑦	67		
Print 100 Events ⑨⑧	67		
Log Off Engineer ⑨⑨	67		
5. Operating the Alarm System Introduction	68		
Access Codes	68		
Arming & Disarming the Alarm System	68		
Checking if the System is Ready to Arm	68		
Away Arming	68		
Stay Arming	68		
Cancelling the Arming Process	69		
Disarming During Entry	69		
Disarming when not in Entry	69		
Disarming after an Alarm	69		
Auto Stay Arming	69		
Changing between Delayed and Instant Stay	69		
Arming and Disarming Partitions.....	70		
Away Arming Partitions	70		
Stay Arming Partitions	70		
Disarming Partitions	70		
Changing to another Partition	70		
Bypassing Zones	71		
Manually Bypassing Zones	71		
Unbypassing Zones	71		
Group Bypass	71		
Quick Bypass and Arm	72		
Reset Alarms	72		
Last Alarm Log	72		
Service Faults	73		
Acknowledging a New Service Fault	73		
View Service Faults	73		
Anti-code Reset	74		
Toggle Chime On and Off	74		
Change User Code	74		
View Log (LCD Only)	74		
Abort Communications	74		

System Overview**Installation****Control Panel PCB Layout****Installing Remote Keypads & Expanders****Zone Connections****Siren/Bell, Telephone and Panel Outputs****Commissioning & Troubleshooting****Programming Menus****Programming Zones****Programming Partitions****Programming Global Options****Programming Remote Keypads****Programming Remote Expanders****Programming System Outputs****Programming the Communicator****Programming Download Options****Programming Reporting Codes****Programming Users****System Tests, Utilities and Using *RadioPlus*****Operating the Alarm System****Specifications****Quick Reference Guide & Defaults**

1. System Overview

System Architecture



Control Panels

The *Premier 412*, *816*, *816 Plus* and *Premier 832* are highly sophisticated security control panels with Integrated Multi-protocol Digital Communicator/Modem. The control panels have the following features:

Features	412	816	816 Plus	832
Zones	4	8	8	8
Max. Zones when expanded	12	16	16	32
Partitions	2	4	4	4
User Codes	32	32	32	64
Event Log	750	750	750	1000
Mandatory Log Events (EN50131-3)	250	250	250	250
Touch Tone Remote Control	x	x	✓	✓
Programmable Aux. Input	✓	✓	✓	✓
Supervised Siren/Bell Output	✓	✓	✓	✓
2 x 1A Supervised Outputs	✓	✓	✓	✓
6 x 100mA Outputs	✓	✓	✓	✓
Printer/UDL Port	✓	✓	✓	✓
Integrated Modem/Communicator	✓	✓	✓	✓

Remote Keypads

The control panels will accept up to a maximum of 6 remote keypads. All remote keypads require a 4-wire connection to the data network and have a built in piezoelectric sounder. The following remote keypad models are available:

Premier RKP4/8/16

A cost effective range of remote keypads with either 4, 8 or 16 zone indicator lights.

- 4-wire connection to data network.
- Built in piezoelectric sounder.
- Dual level back-lighting, normally dim, switching to bright for 8 seconds after any key press
- Dedicated status lights for "Alarm", "Service", "Armed" and "Ready".

Premier RKP8/16 Plus

A professional range of LED remote keypads with either 8 or 16 zone indicator lights.

- 2 programmable EOL zones.
- 4-wire connection to data network.
- Built in piezoelectric sounder.

- Fully adjustable back-lighting, normally bright, dim or off, changing to bright whenever a keypad is used and during the entry mode
- Dedicated status lights for “Alarm”, “Service”, “Armed”, “Ready”, “Fire”, “Bypass”, “Instant” and “Stay”

Premier LCD/L

The *Premier LCD* remote keypad has a standard 32 character back-lit LCD display, whereas the *Premier LCDL* has a large 32 character back-lit LCD display.

- 2 programmable EOL zones
- 1 programmable low current (100mA) output
- 4-wire connection to data network.
- Built in piezoelectric sounder.
- Fully adjustable back-lighting, normally bright, dim or off, changing to bright whenever a keypad is used and during the entry mode
- Dedicated status lights for “Power”, “Armed”, “Ready”, “Service” and “Bypass”
- Speaker driver output (*Premier LCDL* Only).

Premier LCDLP

- *Premier LCDL* keypad with built-in proximity tag reader

Premier LCDP

- *Premier LCD* keypad with built-in proximity tag reader

Premier Elite FMK

- *Flush Mount LCDLP with built in proximity tag reader iconic keys.*
- *Available in various finishes*

Premier Elite SMK

- *Flush Mount LCDLP with built in proximity tag reader iconic keys.*
- *Available in various finishes*

Zone Expansion Modules

Either system can be expanded using one of the following zone expansion modules:

Premier 8X Remote Zone Expander

This module comes supplied in its own enclosure and is connected to the control panel data network to provide remote expansion of the system. This module provides the following additional facilities:

- 8 programmable EOL zones
- 2 programmable low current (100mA) outputs
- Speaker driver output with electronic volume control.

Premier 8XE Local Zone Expander

This module comes supplied as a PCB and simply plugs onto the main control panel circuit board. This module provides 8 programmable EOL zones.

PC-Com Module

This module plugs on to the *Premier 412*, *816* and *Premier 832* control panel to provide an RS232 interface, which can be used for:

- Connection of a serial printer to print the event log
- Upload/download the system programming via *Wintex UDL* software and PC.

ComIP Module

This module plugs on to Com1 or Com2 of the control panel to provide the following:

- Alarm event reporting via TCP/IP (WAN/LAN).
- High speed upload/download of system programming via WAN/LAN using *Wintex UDL* software.

Speech Module

This module plugs on to the control panel to provide the following:

- 4 recordable messages (12 seconds each).
- Each message can be assigned to a specific output function, e.g. Alarm or Fire.

This manual does not cover the full installation of this device; please refer to the instructions supplied with the *Speech Module*.

Radio Receiver Module

The control panel will accept either the Texecom *Ricochet™* Premier Elite 8XP-W or Premier Elite 32XP-W. The receiver module should be wired to the control panel network to provide the following:

- 32 wireless devices, such as PIR, Door Contacts, Shock Sensors, Remote FOBs etc.
- *Ricochet™* Mesh Networking Technology
- RF supervision of each device.
- Battery supervision of each device.

This manual does not cover the full installation of these devices; please refer to the instructions supplied with the radio receiver module.

2. Installation

Installation Sequence

Before attempting to install the alarm system, read this section. Once you have an overall understanding of the installation sequence, carefully work through each step.

1: Design the Layout

Make a rough sketch of the premises to get an idea of where all alarm detection devices, keypads and other modules are to be located.

2: Mounting the Panel

The control panel should be mounted in a dry area close to an unswitched AC power source and the incoming telephone line.



NOTE

You must complete all wiring before connecting the battery, or applying AC to the panel.



NOTE

Some versions of the control panel are not supplied with an integral mains transformer. If this is the case a suitable external mains transformer will be required (see page 75)

3: Install the Keypads

Mount and connect the keypads to the control panel.

4: Zone Wiring

Install detection devices and connect to control panel.

5: Other Wiring

Complete all other wiring including bells or sirens and telephone line connections.

6: Apply Power to the Control Panel

Once steps 1 to 5 are completed, apply power to the control panel. First, connect the red battery lead to the positive terminal and the black lead to negative. Then, connect the AC.

7: Complete the Installation Records & Defaults Worksheets

On page 83 you will find "Installation Records and Defaults" worksheets. These worksheets allow you to record all programming data and also lists all program defaults. It is recommended that the worksheets are filled in before attempting to program the system.

8: Program the System

Using the Programming Worksheets program the control panel in accordance with the procedures in Section 3.

9: Testing the System

Test the system thoroughly to ensure that all features and functions are operating as required.

Control Panel

Mounting

Mount the control panel on a flat, plumb wall using at least three appropriate screws. The rear casing has been designed with a central key-hole slot so that mounting is possible without removing the Printed Circuit Board (PCB).

The angled slot in the lower corner has been provided to allow the panel to be levelled easily. If the PCB has to be removed, carefully pull back the two front PCB securing clips, lift the front of the PCB and slide it downward. To replace the PCB simply reverse the above procedure.



NOTE

It is essential to ensure that none of the fixing slots or cable entries are accessible after fixing.

Mains cabling must be secured (e.g. with a cable tie) to one of the anchor points provided.

Wiring the Control Panel

WARNING: ELECTRICITY CAN KILL

**BEFORE connecting the control panel
ALWAYS disconnect the supply at the consumer unit.
If in ANY doubt consult a qualified electrician.**



ONLY connect the mains supply to the mains terminal block, NEVER connect the mains supply directly to the PCB.

The system installation MUST be carried out in accordance with the national safety standards, for example EN 60950: 1992.

ALWAYS refer to National Wiring Regulations when conducting installation.

An appropriate and readily accessible disconnection device (e.g. an unswitched fused spur) MUST be provided as part of the installation.


The disconnection device must NOT be fitted in a flexible cord.

Where identification of the neutral in the mains supply is NOT possible, a two-pole disconnection device MUST be used.

The building mains supply MUST incorporate appropriate short-circuit backup protection (e.g. a fuse or circuit breaker) of High Breaking Capacity (HBC, at least 1500A).

Use mains cable of adequate carrying capacity for the rated current (i.e. at least 0.75mm²).

Control Panel PCB Layout



1: Earth Ground Connection

Earth ground. Connect to earth or an earth rod.



Failure to fit an earth cable may prevent proper operation of the system and will invalidate the Texecom warranty and product approvals.

2: AC Input

Connect to a 16.5V transformer.



Do NOT connect the mains supply to the AC input terminals.

3: Battery Connections

A 12V rechargeable battery must be connected to these two terminals in order to provide continuous system operation in the event of mains failure. The battery output is protected by fuse F1 (1.6 Amp).

4: Data Bus Connections

The data bus terminals provide connections to the remote keypads and *Premier 8X Remote Zone Expander*. The + and - terminals provide power whilst the T and R terminals are transmit and receive data.

5: Siren/Spk output

These terminals are used for driving speakers, sirens or bells. The output can be programmed for speaker driver or for Siren/bell driver (see page 35). This output is supervised, if no warning devices are fitted, either fit a 1K Ω resistor between these two terminals or disable the siren supervision, see page 36.

6: Auxiliary 12V Power

These terminals provide auxiliary power for devices that require 12V power. The auxiliary output is protected by fuse F2 (1 Amp).

7: Zone Inputs 1 to 8

These terminals provide the connections to the zone inputs. The *Premier 816* and *Premier 832* have 8 zone inputs, whereas the *Premier 412* has only 4 zone inputs. There are several ways to wire a zone (see page 13). Each zone is fully programmable, see page 24 for information on programming zones.

8: Two-Wire Smoke Detector Enable

Set this link as shown when connecting 2-wire smoke detectors to Panel Output 1.



Output 1 is enabled for 2-wire smoke detectors



Output 1 is normal

9: Aux Input

This is a programmable input, it can be used for monitoring auxiliary tamper devices etc, see page 36 for programming details.

10: Panel Outputs 1 to 8

These are programmable outputs. Panel outputs 1 and 2 are high current (1 Amp) supervised outputs. If panel outputs 1 or 2 are not used, either fit a 1K Ω resistor between the unused output and Auxiliary 12V + or disable the output supervision, see page 36. Panel outputs 3 to 8 are low current (100mA) outputs.

11: Communication Ports 1 and 2

Serial communication ports 1 and 2, these can be used for third party devices or PC for local downloading.

12: Load Defaults

Short between the centre and either of the outer pins during power up to restore the control panel default program parameters. These pins can also be used to reset the Engineer code back to its default value, see page 67.



NOTE Do not leave these pins shorted, otherwise the control panel event log will be erased.

13: Box Tamper Disable

Fit link as shown:



Box Tamper Disabled



Box Tamper Enabled

14: Local Zone Expander

The *Premier 8XE Local Zone Expander* can be plugged on to the main PCB. The local expander provides an additional 8 programmable zones (see page 13).

15: Speech Module

A two channel *Speech Module* can be plugged on to the main PCB (SK1). This connector is only fitted on the *Premier 816Plus* and *Premier 832* control panels.

16: Box Tamper Switch

Box tamper protection for the main control panel.

17: Power Light

On steady when either AC or standby battery is present. Flashes when the on-board communicator is dialling or sending data.

18: Electronic Fuses

The PCB is protected using electronic PTC fuses:

- F1 (2.5 Amp) Battery fuse
- F2 (900mA) Auxiliary 12V power fuse
- F3 (900mA) Siren/Bell output fuse
- F4 (900mA) Network fuse

To reset a fuse, remove all load from the protected circuit, wait 10 seconds, then reconnect.

19: Telephone Line Connections

Telephone line connections (see page 18).

20: RJ11 Telephone Line Connector

An RJ11 connector is provided so that the panel can be connected to the telephone line via a standard RJ11 patch lead.

21: Engineers Keypad Connection

An engineers keypad (*Premier LCD* keypad and interface lead) can be temporarily plugged onto this connector to allow system programming and testing.

22: Network Data Indicator LEDs

The red transmit (Tx) LED indicates that data is flowing out of the control panel and normally flashes very quickly. The green receive (Rx) LED indicates that data is flowing into the control panel. The green LED flashes faster as more devices are connected to the data network.

23: Electronic Fuse Fault Indicator LEDs

Electronic fuses F2-F4 have red indicator LEDs, which light up when the relevant fuse is open circuit (fault).

24: Battery Kick Start Pins

The control panel has a deep discharge protection circuit that prevents the standby battery from being fully discharged. When powering up the control panel without AC Mains (battery only), the

centre and either outer pins must be shorted together in order to bring the battery into circuit.

25: Battery Charge Current Selector

When using a 7Ah standby battery the charge current selector should be set to 300mA. If a 17Ah battery is connected (metal cabinet only) the selector should be set to the 750mA position.

Connecting Devices to the Data Bus

Before connecting remote keypads and zone expanders, isolate ALL power from the control panel (AC Mains & Battery). Do not continue if there is still power present on the control panel.



NOTE Connecting devices with power still present on the control panel may damage the device or control panel and invalidate any warranty.

Remote keypads and zone expanders are all connected to the same data terminals located at the bottom left hand corner of the control panel and may be connected serially (daisy chain), in parallel (star) or any combination of the two.

Wiring the Data Bus

The data bus is made up of four terminals incorporating power and data. To ensure correct operation, all four terminals on the device must be connected to the corresponding terminals on the control panel, or previous device (see page 10 for wiring details). The table below shows each terminal and its description:

Terminal	Description
+	+12V Supply
-	0V Supply
T	Transmit Data
R	Receive Data

Cable Type and Distances

For improved immunity to electrical noise Texecom recommend the use of screened 4 core cable. The screen should be twisted together and wired into the (-) terminal at the control panel only.

The maximum recommended distance for devices when using standard 7/0.2 alarm cable is:

- 250m for each branch when using the star (parallel) configuration
- When using a daisy chain (series) configuration the maximum distance will depend on the number of devices connected on the chain. The more devices that are connected, the shorter the distance to the last device (this is due to voltage drop in the cable)


Whichever method of wiring configuration is used, ensure that the voltage between the '+' and '-' terminals at each device is no lower than 10.0V when the system is running on the standby battery.

The table below shows maximum cable runs when one keypad or expander is installed using standard 7/0.2 alarm cable with various loads:


Configuration	Max. Cable Run
1. Keypad + 2 PIR's @15mA	250m
2. Expander + 2 PIR's @15mA	250m
3. Expander + 8 PIR's @15mA	100m
4. As No. 3 + 16Ω Speaker	30m

Installing a Power Supply

When a power supply is installed, the 0V connections on the power supply must be connected through to 0V on the control panel and the +12V connection between the control panel and the device must be disconnected (see figure below).



Data Bus Connections (250m without additional power supply).



Data Bus Connections (1Km with additional power supply).


Overcoming Voltage Drop

There are several ways to overcome voltage drop:


- Use thicker lower resistance cable. Standard 7/0.2 alarm cable has a resistance of 8Ω per 100m
- Double up on the power connections – this will require using a 6 or 8-core cable rather than a 4-core cable
- Install a power supply to power the device locally, remember to common the two negative connections

Installing Remote Keypads


Keypad Layouts



RKP4/8/16 Layout



RKP8/16 Plus Layout



LCD/LCDL/LCDP/LCDLP
SMK & FMK Layout

- ① Address DIL Switch
- ② Tamper Switch
- ③ Piezo Sounder
- ④ Data Bus Connections
- ⑤ Programmable Zones 1 and 2
- ⑥ Speaker Output (Premier LCDL/LCDLP Only)
- ⑦ Programmable Output

Remote Keypad Connections

The remote keypad is connected to the data bus terminals located at the bottom left hand side of the PCB. (See pages 8 to 10).

Remote Keypad Address

Each remote keypad must be assigned a different address using the Address DIL switch (①). The table below shows how to set the address:

Address	DIL 1	DIL 2	DIL 3	DIL 4	
1	On/Off	Off	Off	Off	
2	Off	On	Off	Off	
3	Off	Off	On	Off	
4	Off	Off	Off	On	
5	On	Off	Off	On	
6	Off	On	Off	On	

Keypad Zones

The Premier RKP8/16 Plus and all LCD remote keypads have two programmable zone inputs (see page 14 for wiring details). Each zone is also fully programmable (see page 24 for programming details). The table below shows the zone allocation when using the Premier RKP8/16 Plus or Premier LCD remote keypads:

Address	Premier 412		Premier 816/832	
	Zone 1	Zone 2	Zone 1	Zone 2
1	Zone 05	Zone 06	Zone 09	Zone 10
2	Zone 07	Zone 08	Zone 11	Zone 12
3	Zone 09	Zone 10	Zone 13	Zone 14
4	Zone 11	Zone 12	Zone 15	Zone 16
5	N/A	N/A	N/A	N/A
6	N/A	N/A	N/A	N/A

NOTE The onboard remote keypad zones are not seen by the system until they have been enabled. To enable the onboard keypad zones (see page 41 for details).

Keypad Output


All Premier LCD remote keypads have one programmable output, which can be used to drive auxiliary devices such as LED's, sounders or relays etc. Wire as per Panel Outputs shown on page 18 (see page 45 for programming details).

Keypad Speaker Output (LCDL/LCDLP FMK/SMK)

The Premier LCDL and LCDLP keypads has an output that can be used for driving up to one 8Ω or two 16Ω loudspeakers (see page 17 for wiring details).

NOTE The speaker volume is also fully adjustable (see page 34 for details).

Adjustable Backlighting

To adjust the keypad backlighting press the **YES** key, then with the **YES** key still pressed use  to increase or decrease the backlighting until the required brightness is achieved, then release both keys.

NOTE The backlight can only be adjusted when the keypad is not in a menu.


Keypad Lid Tamper

The lid tamper of each keypad can be disabled if required using the relevant keypad option in the Keypad Options 4 menu (see page 41 for details).

Remote Zone Expander Module

The Premier 8X Remote Zone Expander provides 8 additional detection zones, two programmable outputs and a speaker driver output.

Remote Expander Layout






- ① Data Bus Connections
- ② Auxiliary 12V
- ③ Programmable Zone Inputs
- ④ Programmable Outputs 1 and 2
- ⑤ Speaker Driver Output
- ⑥ Power LED
- ⑦ Disable Tamper Jumper
- ⑧ Tamper Switch
- ⑨ Address DIL Switch

Wiring the Zone Expander

The Remote Zone Expansion Module is connected to the data bus terminals located at the bottom left hand side of the PCB. (See pages 8 to 10).

Remote Expander Address

Each remote expander must be assigned a different address using the Address DIL switch (⑨). The table below shows how to set the address:

Address	DIL 1	DIL 2	DIL 3	DIL 4	
1	On/Off	Off	Off	Off	
2	Off	On	Off	Off	
3	Off	Off	On	Off	

NOTE Only one remote expander can be connected to the Premier 412 & 816 control panels (Address = 1).

Remote Expander Zones

The Premier 8X Remote Expander has eight programmable zone inputs (see page 14 for wiring details). Each zone is also fully programmable (see page 24 for programming details).

The table below shows the system zone allocation when one or more modules are installed:

Address	Remote Expander Zone Inputs							
	Z1	Z2	Z3	Z4	Z5	Z6	Z7	Z8
1	09	10	11	12	13	14	15	16
2	17	18	19	20	21	22	23	24
3	25	26	27	28	29	30	31	32

NOTE When the system is expanded above 8 zones, it MUST be fitted with a suitable remote keypad. For systems up to 16 zones a Premier RKP16 or Premier RKP16 Plus should be installed. For systems above 16 zones a LCD remote keypad should be installed.

The system will only support one type of expansion device for zones 09 - 16, i.e., you can fit either a Premier 8X Remote Expander (Address = 1) or a Premier 8XE Local Expander, you cannot fit both.

Zone Expander Outputs

The Zone Expander module has two programmable outputs, which can be used to drive auxiliary devices such as relays, LED's, smoke detectors etc. The table below shows the electrical characteristics for each output:

No	Supervised	Max Current	Type
1	No	100mA	Switched -ve
2	No	100mA	Switched -ve

Wire as per Panel Outputs shown on page 18.


Zone Expander Speaker Driver

The Zone Expander has a Speaker driver output and can be used for driving 8 or 16 Ohm loud speakers as shown on page 17.

Local Zone Expander Module

The *Premier 8XE Local Zone Expander* plugs onto the control panel to provide 8 additional programmable detection zones.

Local Expander Layout



① Zone Inputs 9 to 16

These terminals provide the connections to the zone inputs.

② Auxiliary 12V Power

These terminals provide auxiliary power for devices that require 12V power. The auxiliary output is protected by fuse F2 (1 Amp) on the control panel.

③ Plug-On Connector

The *Premier 8XE Local Zone Expander* plugs onto the control panel via this connector and is held in place by four plastic pillars located in each corner.

Local Expander Zones

The *Premier 8XE Local Zone Expander* has eight programmable zone inputs (see page 14 for wiring details). Each zone is also fully programmable (see page 24 for programming details).

The table below shows the zone allocation when the module is installed:

Panel	Panel Zones	Expander Zones
<i>Premier 412</i>	1 to 4	9 to 16
<i>Premier 816</i>	1 to 8	9 to 16
<i>Premier 832</i>	1 to 8	9 to 16



When the system is expanded above 8 zones, it **MUST** be fitted with a suitable remote keypad. For systems up to 16 zones a *Premier RKP16* or *Premier RKP16 Plus* should be installed. For systems above 16 zones a *Premier LCD/LCDL* should be installed.

The system will only support one type of expansion device for zones 09 - 16, i.e., you can fit either a *Premier 8X Remote Expander* (Address = 1) or a *Premier 8XE Local Expander*, you cannot fit both.


Installing the Local Zone Expander

To install the Local Zone Expander proceed as follows:

Ensure that all power is removed from the control panel (mains and battery) before attempting to fit the expander.

Push the four support pillars (supplied) into the four locating holes on the control panel PCB.

Align the Local Expander Connector with the 8 way plug (JP2) on the control panel. Push expander into place, ensuring that all four pillars clip into the four locating holes on the local expander.



Zone Connections


Each zone on the system is fully programmable to allow for maximum flexibility (see page 24 for Zone Programming details). The program options for a zone will also determine how the zone may be wired. The following wiring options are available:

Type	Zone Status	Response
⑩ Normally Closed	Shorted	Secure
	> 20K	Active
① Normally Open	Shorted	Active
	> 20K	Secure
② Single EOL - N/C & N/O (Burglary)	0 - 1K	Active
	1.1K - 4.7K	Secure
	> 4.8K	Active
③ Single EOL - N/O (Fire)	0 - 1K	Active
	1.1K - 4.7K	Secure
	> 4.8K	Trouble
④ Single EOL - N/C	0 - 1K	Trouble
	1.1K - 4.7K	Secure
	> 4.8K	Active
⑤ Single EOL - O/C Tamper	0 - 1K	Secure
	1.1K - 4.7K	Active
	> 4.8K	Tamper
⑥ Single EOL - S/C Tamper	0 - 1K	Tamper
	1.1K - 4.7K	Secure
	> 4.8K	Active
⑦ Double EOL	0 - 1K*	Tamper
	1.1K - 4.4K	Secure
	4.5K - 20K	Active
	> 20K	Tamper
⑧ Zone Doubled	Shorted	Zones A & B Trouble
	1.0K - 2.2K	Zones A & B Secure
	4.8K - 6.0K	Zone A Violated
	2.3K - 4.7K	Zone B Violated
	Open	Zones A & B Violated
⑨ Triple EOL	0 - 1K	Tamper
	1.1K - 4.0K	Secure
	4.1K - 5.6K	Trouble (Fault)
	5.7K - 8.0K	Active
	8.1K - 20K	Trouble (Masked)
	> 20K	Tamper

* This value may vary depending on the country variant.


Normally Closed

Use this wiring configuration when connecting normally closed detection devices to the zone. Ensure that the zone is programmed for Normally Closed operation (see page 26). The zone must be wired as follows:




Normally Open

Use this wiring configuration when connecting normally open detection devices to the zone. Ensure that the zone is programmed for Normally Open operation (see page 26). The zone must be wired as follows:




Single EOL - N/C & N/O (Burglary)

Use this wiring configuration when connecting a mixture of normally closed and normally open detection devices to the zone. Ensure that the zone is programmed for Single EOL - N/C & N/O operation (see page 26). The zone must be wired as follows:




Single EOL - N/O (Fire)

Use this wiring configuration when connecting a 4-wire smoke detector to the zone. Ensure that the zone is programmed for Single EOL - N/O (Fire) operation (see page 26). The zone must be wired as follows:




Single EOL - N/C

Use this wiring configuration when connecting just normally closed detection devices to the zone. Ensure that the zone is programmed for Single EOL - N/C operation (see page 26). The zone must be wired as follows:



Single EOL - O/C Tamper

Use this wiring configuration when connecting just normally closed detection devices to a zone and when a tamper response is required in the event of an open circuit. Ensure that the zone is programmed for Single EOL - O/C Tamper operation (see page 26). The zone must be wired as follows:




Single EOL - S/C Tamper

Use this wiring configuration when connecting just normally closed detection devices to the zone and when a tamper response is required in the event of a short circuit. Ensure that the zone is programmed for Single EOL - S/C Tamper operation (see page 26). Wire Single EOL - S/C Tamper zones as shown for Single EOL - N/C.

Double EOL

Use this wiring configuration when connecting detection devices to a zone that requires alarm/tamper monitoring. Ensure that the zone is programmed for Double EOL operation (see page 26). The zone must be wired as follows:




Zone Doubling

This wiring option allows you to wire two detection devices into one set of zone connections. However, the system will treat each device, as if it were connected to a separate zone, i.e., each device is fully programmable.

NOTE When using this configuration, the system must be fitted with the appropriate keypad, *Premier RKP16* on the *Premier 816* and the *Premier RKP8* on the *Premier 412*.

When a zone is configured for “Zone Doubled” it must be wired as follows:



The following table shows how each physical zone is mapped when using the “Zone Doubled” configuration:


Premier 412		
Panel Zone	Zone A	Zone B
1	1	5
2	2	6
3	3	7
4	4	8
Premier 816/832		
Panel Zone	Zone A	Zone B
1	1	9
2	2	10
3	3	11
4	4	12
5	5	13
6	6	14
7	7	15
8	8	16


NOTE Zones above 9 on either the *Premier 8X/8XE Expander* MUST not be configured for “Zone Doubled”.

The *Premier 8X/8XE Expander* cannot be used on the *Premier 816/832* control panels if any of zones 1 - 8 are configured as “Zone Doubled”.

Triple EOL

This wiring option is designed to be used with Texecom detectors that support Triple EOL (T-EOL) wiring. Ensure that the zone is programmed for Triple EOL operation (see page 26). The zone must be wired as follows:






NOTE Triple EOL wiring can only be used on remote keypads and remote expanders that are fitted with V7.1 software or above..


Double Pole

This wiring configuration can only be used on the *Premier LCD/LCDL* remote keypads. It provides monitoring for alarm and tamper using normally closed detection devices. Ensure that the zone is programmed for Double EOL operation (see page 26). The zone must be wired as follows:



2-Wire Smoke Detector

Compatible 2-wire smoke detectors such as the ESL429AT or System Sensor 2100TS can be connected as shown:



NOTE Panel Output 1 must be enabled for 2-wire smoke detection (see page 35 for details).

The jumper link fitted across JP1 (Enabled 2-Wire Smoke Det.) MUST be removed.


The maximum number of detectors is 20.

Speaker/Bell Connections

The Siren/Spk output terminals on the main PCB can be configured for Speaker or Siren/Bell operation.

Speaker Operation


When configured as speaker operation the output can be used for driving 8 or 16 Ohm loud speakers as shown:



NOTE The Siren/Spk output must be enabled for speaker driver (see page 35 for details).

Siren/Bell Operation

When configured as bell operation the output terminals provide up to **750mA** of power for driving bells as shown:



NOTE The Siren/Spk output must be enabled for bell driver (see page 35 for details).

Siren/Spk Supervision

The Siren/Spk output is supervised, if no warning devices are fitted, either disable Siren Supervision (see page 36 for details) or connect a 1KΩ resistor between the Siren terminals as shown:



Telephone Line Connections

The control panel has a built in digital communicator and modem, which is used for communicating with an alarm receiving centre and for downloading. If either of these features are used, a telephone line must be connected to the control panel as shown:



! Failure to fit an earth cable may prevent proper operation of the system and will invalidate the Texecom warranty and product approvals.


Panel Outputs 1 - 8

The control panel has eight programmable outputs, which can be used to drive auxiliary devices such as relays, LED's, smoke detectors etc. The table below shows the electrical characteristics for each output:

No	Supervised	Max Current	Type
1	Yes	1 Amp	Switched -ve
2	Yes	1 Amp	Switched -ve
3	No	100mA	Switched -ve
4	No	100mA	Switched -ve
5	No	100mA	Switched -ve
6	No	100mA	Switched -ve
7	No	100mA	Switched -ve
8	No	100mA	Switched -ve


Output Wiring

The figure below shows some typical wiring examples:



Output Supervision

Panel outputs 1 and 2 are supervised, if either output is unused, either disable the relevant output supervision (see page 36 for details) or connect a 1KΩ resistor between the relevant output terminal and Auxiliary 12V+ as shown:





3. Commissioning & Troubleshooting

Commissioning

Once ALL connections have been made to the control panel and power is ready to be applied, you should read this section before continuing.

The control panel leaves the factory with default settings. For a complete list of factory default settings, please refer to the programming worksheets from page 83.

- Connect the black battery lead to the negative (-) terminal of the standby battery and the red battery lead to the positive (+) terminal of the standby battery. The green power light on the main PCB will flash whilst the default values are being loaded.
- If the system has gone into an alarm condition, enter the default Master User code **5678**. The alarm tone will then stop.
- To access the Engineer Programming Menu, **enter the default Engineer code 1234 and press  followed by 9**. All the zone lights will illuminate.
- Confirm Devices see page 21
- Program the system date and time, see page 67.
- Select the Language, see page 34.
- Select the Country Code, see page 34.
- Program the system as described in the next section (Programming the Control Panel).
- Perform a walk test as described on page 67. Remember that some powered detectors (e.g. PIRs and combined technology detectors) take several minutes to warm up and become operational.
- Test the internal sounder, external sounder and strobe as described on page 67.
- Replace the lid and secure with the two lid screws supplied - **do not over-tighten**.
- Replace the screw covers.
- **Press ** to leave the programming menus. All the zone lights will turn off.
- The **Service** light will be flashing to indicate that action is required. Switch on the mains supply to the control panel. The **Service** light will stop flashing and stay on continuously.

Installation is now complete and the system is ready for use.

Troubleshooting

Power Faults

No Power to Unit (mains only)

- Check the mains block fuse and replace if blown.
- Check for any loose wires at the mains block, the transformer and the AC terminals on the PCB.
- Check the mains block is connected correctly; live to live (brown), neutral to neutral (blue).

No Power to Unit (battery only)



- Make sure the "Kick Start" pins have been shorted together.
- Check for any loose wires at the BATT terminals on the PCB.
- Check that the battery wires are connected correctly; red from BATT+ to the battery positive [+], black from BATT- to the battery negative [-].

Remote Keypads

Keypad Does Not Operate at All

- Check that the remote keypad is wired correctly from the control panel.
- Check that the network fault indicator is off. If the indicator is on, the electronic fuse has activated indicating a short circuit across the [+] and [-] of the network terminals.

Keypad Does Not Accept Access Codes

- If the system has more than one remote keypad check that each keypad is addressed differently, see page 11 for details. The address of a keypad can be checked by pressing the  and  keys together, the address is displayed by the relevant zone light.
- Check that the remote keypad is wired correctly.
- If the remote keypad is on a cable run that is longer than 100m, check the voltage between the [+] and [-] terminals at the remote and ensure that it measures no less than 10.0V.
- Check that you are using the correct Access code. The default Engineer code is **1234** and the default Master User code is **5678**.
- Check that the User code you are using is not "Time Locked", if the User code is time locked then the Access code will only be accepted when Control Timer 1 is off, see page 64 for further details.

Keypad Does Not Generate Alarm Tones etc.

- Each keypad can be configured so that the alarm, entry, exit, chime tones etc. can be enabled or disabled. Check that the keypad has been programmed correctly, see page 40 for details.

Keypad Emergency Keys Do Not Operate

- Each keypad can be configured so that the emergency keys **FIRE**, **POLICE** and **MEDICAL** can be enabled or disabled. Check that the keypad has been programmed correctly, see page 40 for details.

Remote Expander

Expander Does Not Operate at All

- Check that the expander is wired correctly from the control panel.
- Check that the network fault indicator is off. If the indicator is on, the electronic fuse has activated indicating a short circuit across the [+] and [-] of the network terminals.

System Does Not Recognise Zones 9 to 16

- If the expander is on a cable run that is longer than 100m, check the voltage between the [+] and [-] terminals at the remote and ensure that it measures no less than 10.0V.

The Speaker Output Does Not Work

- The expander can be configured so that the alarm, entry, exit, chime tones etc. can be enabled or disabled. Check that the expander has been programmed correctly, see page 42 for details.
- The speaker volume on the expander is electronically adjustable. Check the volume is set to the desired level, see page 42 for details.

Zones

One or More Zones Show an Alarm

- Each zone on the system can be configured for different wiring options. Check that the zones are programmed for the correct wiring configuration, see page 26 for further details.
- Check that the zone is wired correctly, see page 14 for further details.

Service Faults

If the Service light is on or flashing then the system has detected one or more fault conditions, for details on how to view and acknowledge Service Faults see page 73.

On Power-Up the Service Light is On

- When the system is powered-up the system date and time are incorrect. This will cause a Date/Time Loss fault, to clear this fault, program the system date and time, see page 67.
- If the battery presence check is enabled the system will check the battery every 30 seconds. If the system does not have a battery connected then a battery fault will be generated. To clear this fault either connect a battery or disable the battery presence check, see page 35.
- Panel outputs 1 and 2 are supervised outputs, if you have not connected a device to either of these outputs the system will generate an output fault. To clear this fault either fit 1K load resistors between the outputs and +12V, see page 18 or disable the monitoring of outputs 1 and 2, see page 36.
- The Siren output is a supervised output, if you have not connected a device to this output the system will generate a siren fault. To clear this fault either fit 1K load resistors between the siren terminals, see page 18 or disable the monitoring of the siren output, see page 36.

Communicator

The Communicator Will Not Dial

- By default the communicator is disabled, check that the communicator is enabled, see page 50.

- Check that the telephone line has been correctly wired to the control panel.
- Check that the primary telephone number is programmed correctly, see page 50.
- Check that the primary account number is programmed correctly, see page 51.
- Check that the primary protocol is programmed correctly, see page 51.
- Check that the primary dial attempts is not programmed as zero, see page 51.
- Check that the primary reporting partitions have been programmed correctly, see page 51.
- Check that the primary reporting options have been programmed correctly, see page 52.

Communicator Dials But Does Not Communicate

- Check that the primary telephone number is programmed correctly, see page 50.
- Check that the primary account number is programmed correctly, see page 51.
- Check that the primary protocol is programmed correctly, see page 51.
- If you are using either Pulse or Express formats check that the protocol is configured correctly, see page 52.

Operation

The System Will Not Allow Arming

- Check that there are no outstanding Service Faults, see page 73.
- Check that there are no outstanding alarms that require resetting, see page 72.
- Check that the User code has been programmed to allow arming, see page 64.
- Check that the User code has been assigned to the correct partition(s), see page 64.
- If the User code is programmed for "Local Partition Access Only" (see page 65) then ensure that the keypad that is being used is assigned to the correct partition, see page 40.

The System Will Not Allow Disarming


- Check that the User code has been programmed to allow disarming, see page 64.
- Check that the User code has been assigned to the correct partition(s), see page 64.
- If the User code is programmed for "Local Partition Access Only" (see page 65) then ensure that the keypad that is being used is assigned to the correct partition, see page 40.

4. Programming the Control Panel

Introduction


All engineers should read this section carefully so as to familiarise themselves with the programming of the control panel.

The programming menus can only be accessed when the control panel is fully disarmed. Enter the default **Engineer code** **①②③④** and press **(Menu)** followed by **⑨** to access the program menus:



A programming menu is selected by entering a two-digit menu code. On completion of each menu option, the system reverts to the main programming menu, allowing other programming menu options to be accessed.

To exit the programming menu enter **⑨⑨** or press the **(Menu)** key, the system will revert to normal operation:



NOTE If the "EN 50131-1 Requirements" option is programmed as enabled (see page 36) the Engineer code will only be accepted after a user has authorised Engineer access. For information on complying with EN 50131-1 please refer to page 77.

Confirm Devices

From Version 14.02 it is necessary to "Confirm Devices" connected to the control panel network

LCD Keypads

LED Keypads

Panel firmware V14.06 and later



NOTE For previous versions (14.02 - 14.04) you can only confirm devices with the LCD

RKP4/8/16

- 1) Allow system to operate for 30 seconds

- 2) Enter installer/engineer code – would display confirm devices
- 3) Press Arm Key – Enter confirm devices menu (Top line of LED's will illuminate)
- 4) Press Arm Key – Accept Detected network devices (All zone LED's will un-illuminate)
- 5) Press Arm Key – Confirm detected devices, exit installer menu and returns to day mode operation

RKP 8 Plus

- 1) Allow system to operate for 30 seconds
- 2) Enter installer/engineer code – would display confirm devices
- 3) Press Yes Key – Enter confirm devices menu (All zone LED's will illuminate)
- 4) Press Yes Key – Accept Detected network devices (All zone LED's will un-illuminate)
- 5) Press Yes Key – Confirm detected devices, exit installer menu and returns to day mode operation

RKP 16 Plus

- 1) Allow system to operate for 30 seconds
- 2) Enter installer/engineer code – would display confirm devices
- 3) Press Yes Key – Enter confirm devices menu (All zone LED's will illuminate)
- 4) Press Yes Key – Accept Detected network devices (All zone LED's will un-illuminate)
- 5) Press Yes Key – Confirm detected devices, exit installer menu and returns to day mode operation




NOTE Any premier International panels containing a software version prior to V14.02 that is flashed with version V14.02 or later, The Confirm Devices strings are not loaded in the panel's memory so any reference to them results in black squares being shown. To reload the English text strings. This can be achieved by entering the Installers code and then pressing the keypad's "Menu" key this provides a short cut to the language setting menu. Once the selected language is transferred from flash to memory the Confirm Devices strings will be displayed.

Viewing Numeric Data (LED Keypads)














When programming numeric data, the value of the data may be viewed by pressing the **(Area)** key. The keypad will flash the value in sequence using the following lights:

Alarm = 0	Zone 5 = 5
Zone 1 = 1	Zone 6 = 6
Zone 2 = 2	Zone 7 = 7
Zone 3 = 3	Zone 8 = 8
Zone 4 = 4	Armed = 9



















Programming Text (LCD Only)



















Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along).

The table below shows the keys to use and the characters that are assigned to them:

Key	Characters																
	.	,	?	!	1	@	"	-	&								
	a	b	c	2	A	B	C										
	d	e	f	3	D	E	F										
	g	h	i	4	G	H	I										
	j	k	l	5	J	K	L										
	m	n	o	6	M	N	O										
	p	q	r	s	7	P	Q	R	S								
	t	u	v	8	T	U	V										
	w	x	y	z	9	W	X	Y	Z								
	_	0	,	#	*	Custom characters											
	Move cursor left and right																
	Backspace (delete)																
	Accept text																


Program Menus


Menu	Function	Page
Programming Zones		
	All Zone Options	25
	Zone Type	25
	Zone Wiring	26
	Zone Attributes 1	26
	Zone Attributes 2	27
	Zone Attributes 3	27
	Zone Partitions & Groups	28
	Zone Text	28
	Assign Radio Device	28
Programming Partitions		
	Partition Exit Time	30
	Partition Entry Delay 1 Time	30
	Partition Entry Delay 2 Time	30
	Partition Communicator Delay	30
	Partition Bell Delay	30
	Part Bell Duration	30
	Partition Options	30
	Partition Auto Arm/Disarm	31
	Equipment Areas	31
Programming Global Options		

Menu	Function	Page
	System Timers	34
	System Counters/Levels	34
	System Control Timers	35
	System Options 1	35
	System Options 2	35
	System Options 3	35
	Hardware Options	36
	Auxiliary Input Options	36
	Miscellaneous Options 1	37
	Miscellaneous Options 2	37
	EN50131 Options	37
Programming Remote Keypads		
	Keypad Options 1	40
	Keypad Options 2	40
	Keypad Options 3	40
	Keypad Options 4	41
Programming Remote Expanders		
	Expander Partitions	42
	Expander Tones	42
	Expander Volume Level	42

Menu	Function	Page
Programming System Outputs		
⑥①①	Panel Outputs	45
⑥①②	Fast Format Channels	45
⑥①③	Expander 1 Outputs	45
⑥①④	Expander 2 Outputs	45
⑥①⑤	Expander 3 Outputs	45
⑥①⑥	Keypad Outputs	45
Programming The Communicator		
⑦①①	Communicator Options	50
⑦①②	ARC 1 Communicator Options	50
⑦①③	ARC 2 Communicator Options	53
⑦①④	Fast Format Restore Channels	53
⑦①⑤	Fast Format Open/Close Channels	54
⑦①⑥	Cancel Call Waiting	54
Programming Download Option		
⑦②①	Download Menu	57
Programming Reporting Codes		
⑦③①	Zone Alarm/Restore Codes	61
⑦③②	Zone Bypass/Unbypass Codes	61
⑦③③	Non Zone Alarm/Restore Codes	61
Programming Users		
⑧①①	Program User	64
⑧①②	User Options 1	64
⑧①③	User Options 2	64
⑧①④	User Options 3	65
⑧①⑤	User Text	65
⑧①⑥	Program Standard Users	65
⑧①⑦	Default All Users	65
System Tests and Utilities		
⑨①①	Walk Test	67
⑨①②	Test Speakers and Outputs	67
⑨①③	Send Test Call	67
⑨①④	Enable Download Access	67
⑨①⑤	Start Call Back	67
⑨①⑥	Program Time	67
⑨①⑦	Program Date	67
⑨①⑧	Program Banner Text	67
⑨①⑨	Print 100 Events	67
⑨②①	Log Off Engineer	67

Programming Zones





All Zone Options

① ①

This menu option allows you to program the Zone Type, Zone Wiring, Zone Attributes 1, Zone Attributes 2, Zone Attributes 3 and Partitions & Bypass Groups all in one sequence.

Zone Type

① ①

How the alarm system responds, when a zone is violated depends on the zone type. The following zone types are available:

① ① Null

A zone that is not monitored by the system, unused zones should be programmed as Null zones.

① ② Delay 1

This zone type is normally used for entry/exit detection. The zone can be violated during the exit delay without causing an alarm. Once the system/partition is armed, activation of the zone will start the Entry Delay 1 timer for the selected partition. The user must disarm the system before the entry timer elapses or the system will generate an alarm.

① ③ Delay 2

Operates as Delay 1, but uses Entry Delay 2 timer for the selected partition.

① ④ Interior Follower

This zone type is normally used for interior detection devices, such as passive infrared sensors. The zone will not cause an alarm if violated during the entry delay. However, if the zone is violated before the entry delay has started, it will generate an instant alarm.

① ⑤ Interior Instant

This zone type is normally used for interior detection where an instant response is required. The zone will cause an instant alarm if it is violated when the system/partition is armed.

① ⑥ Perimeter Instant

This zone type is normally used for perimeter protection, windows, patio doors etc. The zone will cause an instant alarm if it is violated when the system/partition is armed.

① ⑦ Fire

This zone type is normally used for monitoring smoke detectors. The zone will cause a unique alarm with distinctive 'fire' tone if it is violated when the system/partition is armed or disarmed. In

addition, the bell output will be pulsed rather than sounding continuously as with a normal alarm.

If the "Double Knock" attribute is enabled on a Fire zone, the zone will behave as a verified fire zone. On the first activation the panel will start the "Double Knock" timer then remove power to the smoke detector (Sensor Reset on Reset) for a short period, then reapply the power (to reset the detector). If the detector activates again before the timer expires the panel will generate a verified fire alarm condition.

0 7 PA Silent

This zone type is normally used for monitoring Panic or hold-up alarms. The zone will cause a silent alarm if it is violated when the system/partition is armed or disarmed.

0 8 PA Audible

This zone type is normally used for monitoring Panic or hold-up alarms. The zone will cause an instant audible alarm if it is violated when the system/partition is armed or disarmed.

0 9 Medical

This zone type is normally used for monitoring medical alarms. The zone will cause a silent alarm if it is violated when the system/partition is armed or disarmed.

1 0 24-Hour Tamper

This zone type will cause an instant audible alarm if it is violated when the system/partition is armed or disarmed.

1 1 Trouble

This zone type will cause an internal alarm (keypads and speaker) if it is violated when the system/partition is armed or disarmed.

1 2 24-Hour - Gas

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Gas alarm to the monitoring station if communication is enabled.

1 3 24-Hour - Water

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Water alarm to the monitoring station if communication is enabled.

1 4 24-Hour - High Temperature

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour High Temperature alarm to the monitoring station if communication is enabled.

1 5 24-Hour - Low Temperature

This zone type will cause a silent alarm if it is violated when the system/partition is armed or disarmed. The panel will report a 24-Hour Low Temperature alarm to the monitoring station if communication is enabled.

1 6 Momentary Key Switch

This zone type can be used to arm/disarm and reset one or more partitions. When the zone is violated and then secured the system will arm the partition(s) assigned to the zone. When the zone is subsequently violated and then secured, the system will disarm the partition(s) assigned to the zone. Operating this zone following an alarm condition resets the assigned partition(s). The operation of

this zone type can be further changed, see "Zone Attributes 3" on page 28.

1 7 Maintained Key Switch

This zone type can be used to arm/disarm and reset one or more partitions. When the zone is violated the system will arm the partition(s) assigned to the zone. When the zone is subsequently secured, the system will disarm the partition(s) assigned to the zone. Operating this zone following an alarm condition resets the assigned partition(s). The operation of this zone type can be further changed, see "Zone Attributes 3" on page 28.

1 8 Push to Set

This zone type is used to arm the system/partition. When the system is armed, the panel will provide an infinite exit delay. When a user violates and restores the Push to Set zone, the panel will wait 5 seconds, then arm the system/partition.



NOTE To enable the Push to Set feature, the exit delay timer for the selected partition MUST be programmed to 255 seconds.

Zone Wiring

1 2

The zone wiring option determines how the detection device may be electrically wired to the zone input. It also determines what status conditions can be monitored. See page 14 for details on wiring zones.

The following wiring types are available:

0 Normally Closed

1 Normally Open

2 Single EOL - N/C & N/O (Burglary)

3 Single EOL - N/O (Fire)

4 Single EOL - N/C

5 Single EOL - O/C Tamper

6 Single EOL - S/C Tamper

7 Double EOL

8 Zone Doubled

9 Triple EOL

Zone Attributes 1

1 3

Zone Attributes 1 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

1 Enable Instant Internal Alarm Tones

On: The keypad sounder and speaker driver will sound immediately the zone causes an alarm.

Off: The keypad sounder and speaker driver will sound after the bell delay timer. (Zone must also be programmed for Delayed Bell).

2 Enable Bell

On: The bell output will trigger when the zone causes an alarm.

Off: The bell output will not trigger.

3 Delayed Bell

On: The bell output is delayed when the zone causes an alarm.

Off: The bell output is instant.

4 Pulsed Bell

On: The bell output is pulsed on and off when the zone causes an alarm (Fire).

Off: The bell output is constant.

⑤ Enable Instant Strobe

On: The strobe output will trigger immediately the zone causes an alarm.

Off: The strobe output will trigger after the bell delay timer. (Zone must also be programmed for Delayed Bell).

⑥ Enable User Chime

On: The keypad sounder and speaker driver will generate a chime tone when zone is violated in the disarmed state.

Off: The zone will respond as normal.

⑦ Enable Transmission Delay

On: The on-board communicator will delay the alarm transmission to the monitoring station when the zone causes an alarm.

Off: The transmission is instant.

⑧ Enable Transmission

On: The on-board communicator will report the alarm status to the monitoring station when the zone causes an alarm.

Off: The alarm status is not reported.

Zone Attributes 2**① ④**

Zone Attributes 2 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

① Enable Manual Bypass

On: The user can bypass the zone.

Off: The user cannot bypass the zone.

② Enable Stay Bypass

On: The zone is automatically bypassed when the system is stay armed.

Off: The zone is not bypassed when stay armed.

③ Enable Force Arming

On: The user can arm the system/partition with the zone violated.

Off: The zone must be secure before the system/partition can be armed.

④ Quick Response Time

On: The zone response time is governed by the Zone Loop Response Timer (see page 34).

Off: The zone response time is fixed at 250ms.

⑤ Enable Cross Zoning

On: When two or more zones are programmed with this attribute, the system will start the Cross Zone Delay timer after the first zone is violated. If another Cross Zone is violated before the timer expires the system will report a Verified Cross Zone alarm.

Off: The zones report as normal.

⑥ Enable Soak Test

On: The zone is selected for soak test. During the soak test period the zone will not cause an alarm if violated, but the system will record the event in the log and indicate a Service Required Fault. This fault condition can only be cleared, by performing a "Reset" with the Engineer's code.

Off: The zone responds as normal.

⑦ Enable Swinger Shutdown

On: The zone will only rearm at the end of the bell duration providing the Swing Shutdown limit has not been reached.

Off: The zone always rearms at the end of the bell duration and subsequent violations of the zone will cause the system to reactivate the bell and report the alarm to the monitoring station.

⑧ Enable Double Knock

On: When a zone is enabled for Double Knock it will only cause an alarm when:

a) The zone remains violated for the duration of the "Cross Zone Time Window".

b) The zone is violated twice within the "Cross Zone Time Window".

c) If any two zones within the same partition with the "Double Knock" attribute are violated during the "Cross Zone Time Window".

Off: The zone responds as normal.

Zone Attributes 3**① ⑤**

Zone Attributes 3 can be assigned to a zone to alter its default operation. The function of each attribute is described as follows:

① Change to Delay 1 on Stay Arm

On: The zone will change to a Delay 1 zone type when the system is Stay armed.

Off: The zone type will not change.

② Change to Follower on Stay Arm

On: The zone will change to a Follower zone type when the system is Stay armed.

Off: The zone type will not change.

③ Zone Warning

On: The panel will generate an internal alarm when the zone remains active for 2 minutes during the disarmed state.

Off: The panel will respond as normal.

④ Auto Reinstate if Force Armed

On: When a zone is force armed (bypassed), it will automatically be reinstated when the zone is secured.

Off: Force armed zones remain bypassed until the partition is disarmed.

⑤ Disable Keyswitch when Away Armed

On: The keyswitch zone is disabled once the system is Away armed, i.e., it cannot be used to disarm the selected partitions.

Off: The keyswitch zone can be used to arm and disarm the selected partitions.

⑥ Disable Exit Faults

On: The zone will not cause the panel to generate a fault tone or extinguish the "Ready" light, if violated during the exit mode.

Off: The zone behaves as normal.

⑦ Truncate Exit Delay

On: When the zone is activated during exit, the panel will truncate any remaining exit time to zero. This attribute would normally be used with Delay 1/Delay 2 zone types.

Off: The zone behaves as normal.

⑧ Forced Walk Test

On: When arming the system the zone will be indicated as active, if the zone has not been activated during the "Activity Time Window", see page 34. This will force the user to check that the zone is secure, on activating the zone the system will clear the indication from the remote keypad and the user may continue to arm the system. This feature can be used on detectors that are at risk of being masked or obscured in someway.

Off: The zone behaves as normal.

Zone Attributes 3 (Key Switch) ① ⑤

When a zone is programmed as a Key Switch type Zone Attributes 3 options 3, 4 and 6 are used to change the operation of the Key Switch zone. The function of each attribute is described as follows:

③ Key Switch is Instant Arming

On: The key switch zone will arm the selected partitions immediately (no exit delay).

Off: The key switch zone will start exit timer for the selected partitions.

④ Key Switch will Stay Arm/Disarm

On: The key switch zone will Stay arm/disarm the selected partitions.

Off: The key switch zone will Away arm/disarm the selected partitions.

⑥ Disable Auto Arm

On: When a key switch zone with this attribute is active, it will disable the auto-arm feature for the partitions assigned to the zone. When the zone returns to the secure state the auto-arm feature is re-enabled.

Off: Keyswitch zones behave as normal.

Zone Partitions & Groups ① ⑥

Partitions allow the system to be divided into areas of protection so that different partitions can be armed and disarmed independently from each other. By default all zones are assigned to Partition 1, but if required a zone can be assigned to Partitions 1 - 4. If a zone is assigned to more than one partition it will only be armed when all partitions they are assigned to are armed.

The system has four Bypass Groups, these can be configured so that the user can select a predefined group of zones for bypassing.

The function of each attribute is described as follows:

① Partition 1

On: The zone is assigned to Partition 1.

Off: The zone is not assigned to Partition 1.

② Partition 2

On: The zone is assigned to Partition 2.

Off: The zone is not assigned to Partition 2.

③ Partition 3 (Premier 816/832 Only)

On: The zone is assigned to Partition 3.

Off: The zone is not assigned to Partition 3.

④ Partition 4 (Premier 816/832 Only)

On: The zone is assigned to Partition 4.

Off: The zone is not assigned to Partition 4.

⑤ Group 1 Bypass

On: The zone is assigned to Group 1 Bypass.

Off: The zone is not assigned to Group 1 Bypass.

⑥ Group 2 Bypass

On: The zone is assigned to Group 2 Bypass.

Off: The zone is not assigned to Group 2 Bypass.

⑦ Group 3 Bypass

On: The zone is assigned to Group 3 Bypass.

Off: The zone is not assigned to Group 3 Bypass.

⑧ Group 4 Bypass

On: The zone is assigned to Group 4 Bypass.

Off: The zone is not assigned to Group 4 Bypass.



Zones must be assigned to at least one partition, if a zone is not assigned to a partition it will not respond to any alarm activation.


Zone Text (LCD Only) ① ⑦

If the system is fitted with LCD remote keypad you can assign up to 16 characters of text to each zone. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press to move the cursor along). For details on entering text, see page 22.

Assign Radio Device ① ⑧

If the system is fitted with a *Radioplus™* radio module this menu option is enabled. This menu is used to assign radio devices such as PIRs and Door Contacts to a zone on the system. Radio devices can be assigned to any of the available zones on the system.


Programming Partitions



Led Key

- ☐ Off
- ☒ On
- ☒ Slow Flash
- ☒ Fast Flash

Note
If the system only has 1 partition, the option to enter the Partition No will NOT be displayed.



Partition Exit Delay 2 0

This timer controls the delay between the user initiating the exit procedure for the selected partition and the partition actually arming. If a 'Push to Set' zone is used for arming the partition, this timer must be set to 255 seconds.

Partition Entry Delay 1 2 1

If the user enters the premises via a 'Delay 1' zone, the system uses this timer to allow the user time to access the keypad and disarm the selected partition.



NOTE The Entry Delay Timer must be set at 30 seconds or greater to comply with the requirements of EN50131.

Partition Entry Delay 2 2 2

If the user enters the premises via a 'Delay 2' zone, the system uses this timer to allow the user time to access the keypad and disarm the selected partition.



NOTE The Entry Delay Timer must be set at 45 seconds or greater to comply with the requirements of EN50131.

Partition Communication Delay 2 3 3

This timer controls the delay between an alarm occurring in the selected partition and the panel reporting the alarm event to the alarm receiving centre.

Partition Bell Delay 2 4 4

This timer controls the delay between an alarm occurring in the selected partition and the bell output activating.

Partition Bell Duration 2 5 5

This timer controls the duration of the bell output after an alarm has occurred in the selected partition.

Partition Options 2 6 6

The function of the partition options is described as follows:

1 Enable Auto Bypass Mode

On: The system will automatically Stay arm the selected partition if the user arms the system using the ARM button, but does not violate the entry/exit zone.

Off: The system will away arm the selected partition even if the entry/exit zone is not violated.

2 Stay Armed Exit is Silent

On: The selected partition will not generate an exit tone when being Stay armed.

Off: The selected partition will generate exit tone.

3 Enable Remote Arming

On: The selected partition can be armed remotely via download software.

Off: The selected partition cannot be armed remotely.

④ Enable Remote Disarming

On: The selected partition can be disarmed remotely via the downloading computer.

Off: The selected partition cannot be disarmed remotely.

⑤ Enable Local Exit Tones

On: When arming the selected partition only the keypad that is being used will generate an exit tone.

Off: When arming the selected partition all keypads will generate an exit tone.

⑥ Stay Armed Entry is Instant

On: When the selected partition is Stay armed the entry/exit zone changes to instant.

Off: When the selected partition is stay armed the entry/exit zone is delayed.

⑦ Stay Armed Exit is Delayed

On: The selected partition will provide an exit delay when being Stay armed.

Off: The selected partition will arm instantly when being Stay armed.

⑧ Only Start Exit when Partition is Ready

On: When a user attempts to arm their partition, the system will only allow the exit mode to start if the partition is Ready (all zones secure).

Off: The system will allow the exit mode to start even if one or more zones are violated. If one or more zones are violated, the keypad will indicate the active zone(s) and generate a fault tone. The active zones must be secured before the exit time expires or the partition will not arm.

Partition Auto Arm/Disarm Options ②⑦

The system has four independent Control Timers that may be configured to switch on and off at different points of the day and days of the week (see page 35). One or more of these Control Timers can be used to automatically Arm or Disarm a selected partition:

① Auto Arm Partition with Control Timer 1

On: The selected partition is armed automatically when Control Timer 1 is switched ON.

Off: The selected partition is not armed automatically.

② Auto Arm Partition with Control Timer 2

On: The selected partition is armed automatically when Control Timer 2 is switched ON.

Off: The selected partition is not armed automatically.

③ Auto Arm Partition with Control Timer 3

On: The selected partition is armed automatically when Control Timer 3 is switched ON.

Off: The selected partition is not armed automatically.

④ Auto Arm Partition with Control Timer 4

On: The selected partition is armed automatically when Control Timer 4 is switched ON.

Off: The selected partition is not armed automatically.



NOTE

When the control timer switches on, the panel will start a 2 minute exit timer. During the first 90 seconds of the exit timer the panel will generate a warning tone every 10 seconds. After which the panel will revert to a standard exit tone for the remaining 30 seconds.

⑤ Auto Disarm Partition with Control Timer 1

On: The selected partition is disarmed automatically when Control Timer 1 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑥ Auto Disarm Partition with Control Timer 2

On: The selected partition is disarmed automatically when Control Timer 2 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑦ Auto Disarm Partition with Control Timer 3

On: The selected partition is disarmed automatically when Control Timer 3 is switched OFF.

Off: The selected partition is not disarmed automatically.

⑧ Auto Disarm Partition with Control Timer 4

On: The selected partition is disarmed automatically when Control Timer 4 is switched OFF.

Off: The selected partition is not disarmed automatically.

Equipment Areas**②⑧**

This option allows you to assign the following to partitions:

① Auxiliary Input Areas

This option allows the Auxiliary input to be assigned to one or more partitions. This will effect how the Auxiliary input now functions, e.g. if the Auxiliary input is programmed as a "Latched Keyswitch" (see page 36) and is assigned to partition 3 and 4, the system will arm partitions 3 and 4 when the Auxiliary input is activated etc.

① Panel Bell Areas

This option allows the panel Bell output to be assigned to one or more partitions. This will effect how the Bell output operates, e.g. if the Bell output is assigned to partition 1 and 2, the panel Bell will only activate when an alarm occurs in either partition 1 or 2.

② Bell Squawk Areas

This option allows the Bell Squawk feature to be assigned to one or more partitions. This will effect how the Bell Squawk feature operates, e.g. if the Bell Squawk feature is assigned to partition 1 and 2, the panel Bell output and any outputs programmed as Bell will squawk when either partition 1 or 2 is armed/disarmed.




NOTE


The Bell Squawk feature must also be enabled, see page 37.

③ Masked when Armed

When a partition is assigned to this option, the system will generate a full alarm if an Anti-Masking detector in the selected partition reports a "Masking" condition whilst the selected partition is armed. If the partition is unassigned, the system will only generate a "Zone Trouble alarm". The detector must be wired to the system using Triple EOL wiring configuration, as shown on page 16.

Programming Global Options





System Options 1

- ① System Clock = Crystal
- ② Battery Connection Supervision
- ③ Battery Dynamically Load Tested
- ④ Panel NVM is Locked
- ⑤ Power Savings During AC Mains Failure
- ⑥ Line Fault Overrides Bell Delay
- ⑦ Two-Wire Smoke Detection on O/P 1
- ⑧ Convert Siren Output from Voltage to Speaker

System Options 2

- ① Tamper Alarms Cause a Trouble While Disarmed
- ② Tamper Alarms Cause a Trouble While Stay Armed
- ③ Defer Reporting of Non-Zone Restorals
- ④ Use Delay Timer to Defer Non-Zone Restorals
- ⑤ Inhibit Keyswitch Operation Upon EOL Tamper
- ⑥ Away Arm Overrides Alarm Transmission Delay
- ⑦ Defer Reporting of Zone Restorals
- ⑧ Use Delay Timer to Defer Zone Restorals

System Options 3

- ① Away Arm Exit Error Doesn't Sound Bell
- ② Zone Test - Silence on No Violation
- ③ Alarm Status Light Indicates Fire
- ④ Enable Entry/Exit Tones for Panel Speaker
- ⑤ Enable Cross Partitioning
- ⑥ Enable EN 50131-1 Requirements
- ⑦ Reinstate Bypassed Zones on Disarm
- ⑧ Invert Panel Siren Output

Hardware Options

- ① Panel Output 1 Supervised for Faults
- ② Panel Output 2 Supervised for Faults
- ③ Siren/Bell Output Supervised for Faults
- ④ Panel Box Tamper Switch Monitored
- ⑤ Auxiliary Fuse Supervised for Faults
- ⑥ Battery Supervised for Faults
- ⑦ AC Mains Supply is Monitored
- ⑧ Telephone Line Is Monitored

Auxiliary Input Types

- ① Not Used
- ② Auxiliary Tamper
- ③ Remote Reset
- ④ Telephone Line Monitor
- ⑤ Panic Alarm
- ⑥ Silent PA
- ⑦ Latched Keyswitch
- ⑧ Momentary Keyswitch

Miscellaneous 1

- ① Enable Bell Squawk on AWAY Arm/Disarm
- ② Enable Bell Squawk on STAY Arm/Disarm
- ③ Disable AC Fail Acknowledgement
- ④ Disable Open/Close Reporting on STAY Arm
- ⑤ Cross/Double Knock Timer is in Minutes
- ⑥ Disable Zone Bypass when Armed
- ⑦ Activated Zones Cause Alarm during Exit
- ⑧ Control Timer 4 Performs Battery Test

Miscellaneous 2

- ① Disable Service Fault Acknowledgement
- ② Enable User Reset for Alarms
- ③ Disable Online Printing
- ④ Enable Bell Module & UK Options
- ⑤ Enable DD 243:2002 Options
- ⑥ Enable Confirmation after Entry Time-out
- ⑦ Invert Auxiliary Input Operation
- ⑧ Auto BST/GMT Time Change

EN50131

- ① Low FOB Battery Arming
- ② Indicate Zones on Soak Test
- ③ Soak Test Acknowledgement
- ④ Entry Stray Notification
- ⑤ Entry Timeout Notification
- ⑥ Expander Cable Cut or Short Circuit
- ⑦ User Code Entry
- ⑧ Mains & Battery Failures Latch

System Timers ③ ① ①

These timers control the system timing and delay functions. The function of each timer is described as follows:

① ① AC Fail Delay

This timer delays the audible indication following a mains (AC) failure.

① ① Telephone Line Fault Delay

This timer delays the audible indication following a telephone line fault.

① ② Cross Zone Time Window

If one or more zones have been programmed with 'Enabled Cross Zoning', the system will only generate a verified cross zone alarm if the zones are violated within this time window.

① ③ Zone Soak Test Time

This timer controls the number of days a zone is put on soak test. If a zone is violated during the soak test period it will not cause an alarm, however, the event will be logged and the zone that failed test will be indicated when the user disarms the system. The Zone Soak Test is started when one or more zones are programmed with 'Enable Soak Test' attribute, see page 27. All zones that are on test are removed from test at the end of the soak test period, providing no failures have occurred.

① ④ Restore Reporting Delay

This timer controls the delay between a system event restoring and the system reporting the restore condition to the Alarm Receiving Centre.

① ⑤ Output Short Pulse Time

If output is programmed with the 'Use Short Pulse Time' attribute the output will activate for the duration of this timer, 001 to 255 x 100ms.

① ⑥ Zone Loop Response Time

If a zone is programmed with the 'Quick Response Time' attribute the zone loop response will be controlled by the duration of this timer, 001 to 255 x 8mS.

① ⑦ Transmission Abort Delay

This timer controls the duration in which an alarm transmission may be aborted following alarm activation. When an alarm occurs, the 'Alarm Cancel' condition is only reported if the system is disarmed within this period. If the system is disarmed after this period the 'Alarm Cancel' is NOT reported.

① ⑧ Test Transmission Interval

This timer controls the interval of test transmissions to the alarm receiving centre. 000 = Control Timer 3; 024 = daily; 168 = weekly etc.

① ⑨ Courtesy Delay

This timer controls the duration of courtesy output. The courtesy output is activated whenever a keypad is used and when the system is in entry mode.

① ① Service Timer

This timer controls the period in which a Service Required fault condition will occur. If the timer is set to 000 this feature is disabled.

① ① Verified 2-Wire Smoke Delay

When the timer is set to zero 2-wire smoke detectors are unverified, i.e., as soon as a detector activates, the panel will go into a fire

alarm condition. When the timer is set above zero, 2-wire smoke detectors are verified as follows: On the first activation the panel will start this timer then remove power to the 2-wire smoke detector for a short period, then reapply the power (to reset the detector). If the detector activates again before this timer expires, the panel will generate a verified fire alarm condition.

① ② Alarm Confirmation Delay

When an Intruder alarm occurs, this timer starts. If a second (different) zone is activated within this time window, the "Confirmed Alarm" output will activate. If a second (different) zone is activated after this time window, the "Confirmed Alarm" output will not activate.

① ③ Activity Time Window

If a zone has the "Forced Walk Test" attribute and it is not activated during this time window, it will be indicated as an active zone when they try to arm the system. Once the timer expires it is restarted and all "Forced Walk Test" zones are displayed as active on the keypad.

① ④ Poll IP Every

This timer controls how often the *ComIP* module (if fitted) polls the ARC software with a "Polling" message.

System Counter/Levels ③ ①

The function of each Counter/Level is described as follows:

① Swinger Shutdown Count

This counter controls the number of times a zone can re-arm following an alarm activation. Once a zone has reached this limit it will not cause any further alarms. In order to use the Swinger Shutdown Counter the zone must be programmed with the 'Enable Swinger Shutdown' attribute, see page 27. The Swinger Count is also applied to alarms caused by the Auxiliary input.

① Panel Speaker Volume

This counter/level controls the advisory tones (entry/exit, fault etc.) volume level of the speakers connected to the siren output. 0 = minimum volume; 7 = maximum volume.

② Chime Volume

This counter/level controls the chime volume level of the speakers connected to the siren output. 0 = disabled; 1 = minimum volume; 7 = maximum volume.

③ Clock Adjustment

This counter can be used to automatically adjust the real time clock either forward or backwards up to 49 seconds per day. When this counter is set to 50 (default value) no clock adjustment will be made. If the counter is set to value less than 50 the clock will be slowed down, e.g., a value of 48 will slow the clock down by 2 seconds per day. If the counter is set to value greater than 50 the clock will be speeded up, e.g., a value of 52 will speed the clock up by 2 seconds per day.

④ Language Selection

This option selects the operating language of the system. Use the scroll keys to display the available languages, then press Yes to select. After a short delay the keypad display will switch to the selected language.

⑤ Country Operation Code

The country operation code determines the way that the panel works so as to satisfy country specific alarm and telecoms

standards. Enter the code as a 3 digit number by reference to the table below. The panel will re-load the default configuration for the selected country, thereby overwriting all programming already carried out. This command will take around 10 seconds to complete. If a country is not listed then enter the code 000 to load the standard configuration.

Country	Code	Country	Code
USA & Canada	001	Spain	034
Standard	000	UK	044
South Africa	027	Norway	047
New Zealand	064	Russia	007
Sweden	046	Hungary	036
Denmark	045	Belgium	032
Holland	031	Belgium 2	131
Holland 2	131	Portugal	035
Australia	061	Norway	47
Australia 2	161	Poland	048
Australia 3	162		

System Control Timers

③ ②

The system has 4 independent Control Timers that may be configured to switch on and off at different points of the day and days of the week. Once configured these timers can be used to automatically arm/disarm partitions or lock-out users from operating the system. Control Timer 3 can be used to send an automatic test call to the alarm receiving centre, see "Test Transmission Interval" on page 34. Control Timer 4 can be used to perform a dynamic battery test, see "Control Timers 4 Performs Battery Test" on page 37.

System Options 1

③ ③

The function of each option is described as follows:

① Clock = Crystal

On: The system clock is calculated using the onboard crystal.

Off: The system clock is calculated by using the incoming mains supply at a frequency of 50Hz.

② Battery Connection Supervision

On: The system will check that the stand-by battery is connected (every 30 seconds).

Off: The system will not check the standby battery.

③ Battery Dynamically Load Tested

On: The standby battery is tested when any partition is disarmed or every 12 hours from the last battery test.

Off: The system will not perform the dynamic battery test.

④ Panel NVM is Locked

On: The NVM is locked and the "Load Defaults" jumper pins on the main PCB are disabled, thus preventing the factory defaults from being loaded.

Off: The "Load Defaults" jumper pins on the main PCB are enabled, thus allowing the panel to be defaulted.

⑤ Power Savings during AC Mains Failure

On: The back-lighting for all remote keypads is switched off during a mains failure.

Off: The back-lighting is enabled during a mains failure.

⑥ Line Fault Overrides Bell Delay

On: The system will override the bell delay in the event of a telephone line fault.

Off: The system will enforce the bell delay.

⑦ Two-Wire Smoke Detection on O/P 1

On: Panel Output 1 is enabled for 2-wire smoke detectors (JP1 on the main PCB must also be removed, see page 8).

Off: Panel Output is a normal programmable output.

⑧ Convert Siren O/P from Voltage to Speaker Driver

On: The Siren output terminals on the main PCB are configured for a speaker driver.

Off: The Siren output terminals on the main PCB are configured for Voltage output to power a bell or siren.

System Options 2

③ ④

The function of each option is described as follows:

① Tamper Alarms Cause a Trouble While Disarmed

On: Tamper alarms cause a trouble condition while the system is disarmed.

Off: Tamper alarms cause an alarm while the system is disarmed.

② Tamper Alarms Cause a Trouble While Stay Armed

On: Tamper alarms cause a trouble condition while the system is Stay armed.

Off: Tamper alarms cause an alarm while the system is Stay armed.

③ Defer Reporting of Non-Zone Restorals

On: The communicator reporting of non-zone restorals will be deferred until the Restore Reporting Delay timer expires or until the system is disarmed (see 4 below).

Off: Non-zone restorals will report immediately as they occur.

④ Use Delay Timer to Defer Non-Zone Restorals

On: If System Option 2.3 (see above) is enabled, then enabling this option will defer the non-zone restoral reporting until the Restore Reporting Delay Timer has elapsed.

Off: Non-zone restorals are deferred until the system is disarmed.

⑤ Inhibit Keyswitch Operation upon EOL Tamper

On: Tampering of a keyswitch zone will inhibit the keyswitch operation.

Off: Tampering will not inhibit the keyswitch operation.

⑥ Away Arm Overrides Alarm Transmission Delay

On: The 'Alarm Transmission Delay' timer is overridden when the system/partition is away armed.

Off: The 'Alarm Transmission Delay' timer is not overridden.

⑦ Defer Reporting of Zone Restorals

On: The communicator reporting of zone restorals will be deferred until the Restore Reporting Delay Timer expires or until the system is disarmed (see 8 below).

Off: Zone restorals will report immediately as they occur.

⑧ Use Delay Timer to Defer Zone Restorals

On: If System Option 2.7 (see above) is enabled, then enabling this option will defer the zone restoral reporting until the Restore Reporting Delay Timer has elapsed.

Off: Zone restorals are deferred until the system is disarmed.

System Options 3

③ ⑤

The function of each option is described as follows:

① **Away Arm Exit Error Doesn't Sound Bell**

On: The bells will not sound if an exit error occurs when the system is away armed.

Off: The system will sound the bell if an exit error occurs when the system is away armed.

② **Zone Test - Silence on No Violation**

On: The Zone Test sounder is silent when all zones are secure and will pulse sound when one or more zones are violated.

Off: The Zone Test sounder is on continuously when all zones are secure and will pulse sound when one or more zones are violated.

③ **Alarm Status Light Indicates Fire**

On: The alarm status light will only indicate Fire alarms. Fire alarms activated from zones will illuminate the relevant zone light and the alarm light. Fire alarms activated from a 2-wire smoke detector will only illuminate the alarm light. All other zone alarms will illuminate the relevant zone light only.

Off: The alarm status light indicates both alarms and fire alarms.

④ **Enable Entry/Exit Tones for Panel Speaker**

On: The panel speaker will produce entry/exit tones.

Off: The panel speaker only produces alarm and trouble tones.

⑤ **Enable Cross Partitioning**

On: The user may temporarily switch to another partition by pressing the **Area** key, and the relevant partition number. Once the remote keypad has been selected for another partition, the indicator lights will only display information relevant for the selected partition. The remote keypad will revert back to its normal partition 15 seconds after the last key press or 1 minute after the last entry of a User code.

Off: All remote keypads are locked to their programmed partition number and the user cannot switch to another partition.

⑥ **Enable EN 50131-1 Requirements**

On: The Engineer code will only be accepted if the user has authorised Remote/Engineer Access (see page 67). If an alarm occurs during entry (timed-out entry alarm) the system will generate an internal alarm for 30 seconds before activating the bell and communicator. Wireless detectors must have polled in within 20 minutes when attempting to arm the system. Mag 2 input on the *RadioPlus* magnetic contact is a tamper input.

Off: The Engineer code is accepted at all times and the timed-out entry alarms respond as normal. Wireless detectors do not need to poll in within 20 minutes when attempting to arm the system. Mag 2 input on the *RadioPlus* magnetic contact is an alarm input.

⑦ **Reinstate Bypassed Zones on Disarm**

On: Any zones that have been manually bypassed are automatically reinstated when the partition is disarmed.

Off: Any zones that have been manually bypassed will remain bypassed when the partition is disarmed.

⑧ **Invert Panel Siren Output**

On: When the panel siren output is configured for voltage drive (see System Options 1.8 on page 35) the output is inverted, i.e. Bells off = voltage applied, Bells on = voltage removed.

Off: The siren output is normal.

Hardware Options

③ ⑥

The hardware options allow you to control which hardware monitoring features are enabled or disabled. The function of each option is described as follows:

① **Panel Output 1 Supervised for Faults**

On: Panel Output 1 is supervised and if the device or wiring is disconnected, the system will generate an "Output 1 Fault" alarm.

Off: Panel Output 1 is not supervised.

② **Panel Output 2 Supervised for Faults**

On: Panel Output 2 is supervised and if the device or wiring is disconnected, the system will generate an "Output 2 Fault" alarm.

Off: Panel Output 2 is not supervised.

③ **Siren/Bell Output Supervised for Faults**

On: The Siren/Bell Output is supervised and if the device or wiring is disconnected, the system will generate a "Siren/bell Fault" alarm.

Off: The Siren/Bell Output is not supervised.

④ **Panel Box Tamper Switch Monitored**

On: The system will monitor the main panel box tamper switch.

Off: The main panel box tamper switch is not monitored.

⑤ **Auxiliary Fuse Supervised for Faults**

On: The Auxiliary 12V Power fuse is supervised, and if the fuse is blown, the system will generate an "Aux Fuse Fault" alarm.

Off: The Auxiliary 12V Power fuse is not supervised.

⑥ **Battery Supervised for Faults**

On: The Battery is supervised, and if the battery is disconnected or faulted, the system will generate a "Battery Fault" alarm.

Off: The Battery is not supervised.

⑦ **AC Mains Supply is Monitored**

On: The AC mains supply voltage is monitored, and if the supply is removed, the system will generate a "AC Fail" alarm.

Off: The AC mains supply voltage is not monitored.

⑧ **Alarm Call Path Monitored**

The alarm call path monitoring depends on the chosen method of alarm call delivery.

If alarm calls are to be transmitted over the internet ("Connect Via IP" ARC Protocol Option 8 see page 51)

On: The IP connection is monitored and if the connection is lost a "Line Fault" will be generated.

Off: The IP connection is not monitored.

If alarms are to be transmitted over the telephone line

On: The telephone line to the control panel is monitored, and if the telephone line is disconnected, the system will generate a "Line Fault" alarm.

Off: The telephone line is not monitored.

Auxiliary Input Options

③ ⑦

The Auxiliary Input on the main panel PCB can be used for a wide range of functions, the operation of the input can also be inverted to allow various wiring options (see page 38). The following Auxiliary Input functions are available:

① **Not Used**

The Auxiliary Input is not monitored.

① **Auxiliary Tamper**

When activated the panel will generate a tamper alarm for the assigned partitions (see page 31).

② **Remote Reset**

When activated the system will reset any alarms/faults for the assigned partitions (see page 31).

③ Telephone Line Monitor

When activated the system will generate a Telephone Line fault for all partitions.

④ Panic Alarm Input

When activated the system will generate an Audible Panic alarm for the assigned partitions (see page 31).

⑤ PA Silent Input

When activated the system will generate a Silent Panic alarm for the assigned partitions (see page 31).

⑥ Latched Keyswitch Input

When the input is active the system will arm the assigned partitions (see page 31). When the input is inactive the system will disarm the assigned partitions.

⑦ Momentary Keyswitch Input

When the input is activated the system will arm the assigned partitions (see page 31). When the input is activated again the system will disarm the assigned partitions.



NOTE

Both the "Latched" and "Momentary" Keyswitch input types are ideally suited for use with remote RF fobs as they have a special auto re-arm feature. When either input type is used to disarm one or more partitions, the control panel will monitor all zones activity for 2 minutes. If after two minutes no zones were activated within the partition that was disarmed, the panel automatically re-arms the partition. This means even if the user activates the fob unintentionally and disarms the system without realising it; the panel will automatically arm its self after 2 minutes.

Miscellaneous Options 1**③ ⑧ - ①**

The function of each option is described as follows:

① Enable Bell Squawk on AWAY Arm/Disarm

On: When the system is Away armed, the panel bell/siren output is pulsed once. On disarming the output is pulsed twice. The panel bell/siren output must be configured for voltage drive (see System Options 1.8 on page 35).

Off: The panel bell/siren output behaves normally on Away arm.

② Enable Bell Squawk on STAY Arm/Disarm

On: When the system is Stay armed, the panel bell/siren output is pulsed once. On disarming the output is pulsed twice. The panel bell/siren output must be configured for voltage drive (see System Options 1.8 on page 35).

Off: The panel bell/siren output behaves normally on Stay arm.

③ Disable AC Fail Acknowledgement

On: When the mains supply power fails the Service light will flash rapidly indicating an AC failure. The system can now be armed without the need for acknowledging the "AC Fail" fault.

Off: When the mains supply power fails the Service light will flash normally indicating the "AC Fail" Fault. The fault must be acknowledged before the system can be armed.

④ Disable Open/Close Reporting on STAY Arm

On: Open and Close events are not reported to the Alarm Receiving Centre when Stay arming the system/partition.

Off: Open and Close events are reported when Stay arming the system/partition.

⑤ Cross/Double Knock Timer is in Minutes

On: System timer 02 "Cross Zone Time Window" is counted in minutes.

Off: System timer 02 "Cross Zone Time Window" is counted in seconds.

⑥ Disable Zone Bypass when Armed

On: The user cannot bypass zones in an armed partition. Only zones that are unarmed can be selected for bypass.

Off: The user can bypass zones in an armed partition.

⑦ Activated Zones Cause Alarm during Exit

On: If a non "delay" or "follower" zone is activated during exit mode the panel will generate a full alarm condition.

Off: If a non "delay" or "follower" zone is activated during exit mode the panel will generate a fault condition.

⑧ Control Timer 4 Performs Battery Test

On: Control Timer 4 is used to perform the dynamic battery test, i.e. when the timer switches on the panel will allow the stand-by battery to power the system for 1 minute.

Off: Control Timer 4 behaves as normal.

Miscellaneous Options 2**③ ⑧ - ②**

The function of each option is described as follows:

① Disable Service Fault Acknowledgement

On: When a Service Fault occurs the system can be armed without the need to acknowledge the fault condition.

Off: All Service Faults require acknowledgment before the system can be armed.

② Enable User Reset for Alarms

On: Any user can reset alarms and troubles.

Off: Alarms and troubles can only be reset by users with the "Allow Alarm/Fault Acknowledgement" attribute (see User Options 3 on page 65).

③ Disable Online Printing

On: The online printer port (Com1) will not send real time event data.

Off: The online printer port (Com1) will send real time event data.

④ Enable Bell Module and UK Options

On: When the system is fitted with a *Premier Bell Module* this option must be enabled (this module is only used in the UK). Also the following UK options are enabled:

- All alarm zones and tampers are disabled whilst in engineers programming mode
- After entering the engineers passcode, the Strobe output on the *Premier Bell Module* pulses 3 times, this invokes the Engineer Hold Off mode if a *Texecom Odyssey* bell box is connected

Off: The *Premier Bell Module* and UK options are disabled.

⑤ Enable DD 243:2002 Options

On: The Confirmation output is disabled once the Entry Timer is started, i.e. during the Entry Time, activation of a second (different) zone will NOT activate the Confirmation output.

Off: The Confirmation output operates as normal.



NOTE

To comply with DD 243:2002 this option must be enabled if access to the protected premises initiates the entry timer.

Owing to the ability to disable ALL of the confirmation facilities, the customer should be advised in writing by the alarm company that ALL means of alarm confirmation are disabled when the initial entry door is opened. The alarm company

should then obtain written acceptance from the customer of the disabling of the means of alarm confirmation.

⑥ Enable Confirmation After Entry Time-Out

On: If option 5 (above) is enabled the Confirmation output is ONLY disabled for the duration of the Entry Time and re-enabled once the Entry Timer has expired, i.e. after the Entry Timer has expired, further activation of two different zones WILL activate the Confirmation output.

Off: If option 5 (above) is enabled the Confirmation output remains disabled once the Entry Timer is started.



NOTE

To comply with DD 243:2004 this option can only be enabled if the system is unset by a single action device such as a Swipe Card, Radio FOB, Infra-Red FOB, Proximity Card etc.

⑦ Invert Auxiliary Input Operation

On: The operation of the auxiliary input is inverted and operates as shown in the table below:

Inverted	
Function	Operation
Aux Tamper	Normally Open
Remote Reset	Remove 0V to reset
Phone Line Monitor	Remove 0V for Line Fault
Audible PA	Normally Open
Silent PA	Normally Open
Latched Keyswitch	Apply 0V to Arm
Momentary Keyswitch	0V to Removed to change

Off: The operation of the auxiliary input is inverted and operates as shown in the table below:

Normal	
Function	Operation
Aux Tamper	Normally Closed
Remote Reset	Apply 0V to reset
Phone Line Monitor	Apply 0V for Line Fault
Audible PA	Normally Closed
Silent PA	Normally Closed
Latched Keyswitch	Apply 0V to Disarm
Momentary Keyswitch	Removed to 0V to change

⑧ Auto BST/GMT Time Change

On: The clock is automatically put forward by one hour on the last Sunday in March at 2:00AM and put back by one hour on last Sunday in October at 2:00AM.

Off: The clock is not adjusted automatically.

EN50131 Options

③ ⑨

The function of each option is described as follows:

① Low Battery FOB Arming

On: An arming fob with a low battery causes a warning to be indicated. The user must be acknowledged the warning before arming can continue.

Off: An arming fob with a low battery arms the system.

② Indicate zone Soak Test active enabled

On: A zone or zones on Soak Test being armed will cause the "Soak Test Warning" to be displayed. The user can then continue to arm the system or return to Day Mode.

Off: The "Soak Test Warning" message is not displayed.

③ Soak Test Acknowledgement enabled

On: Soak Test warnings must be acknowledged by the user.

Off: Soak Test warnings are displayed for 2 seconds before arming continues.

④ Entry Stray Notification Delay

On: Entry stray notification is delayed after the alarm.

Off: Entry stray notification occurs at the time of the alarm.

⑤ Entry Timeout notifies immediately

On: Entry timeout notification is delayed after the alarm.

Off: Entry timeout notification occurs at the time of the alarm.

⑥ Expander Lost

On: A cable cut or a short circuit on an expander signals tamper.

Off: A cable cut or short circuit on an expander does not signal tamper.



NOTE

When this option is switched on any circuits connected to the expander will go active.

⑦ User Code Entry



NOTE

A user code must be entered in 60 seconds, after every 10 invalid code entry attempts all keypads on the system are locked out for 90 seconds. After 21 invalid code attempts a keypad tamper event will be notified.

On: A user's code must be entered in 60 seconds.


Off: User code validity is by number of characters entered..

⑧ Mains and Battery Failures Latched

On: Mains and Battery Failures are latched and notified and must be acknowledged before the system can be set.

Off: Mains and Battery Failures are only shown when present.

Programming Remote Keypads



Keypad Options 1 ④ ①

The operation of Keypad Options 1 is described as follows:

① Partition 1 Operation

On: The selected keypad is assigned to Partition 1.

Off: The selected keypad is not assigned to Partition 1.

② Partition 2 Operation

On: The selected keypad is assigned to Partition 2.

Off: The selected keypad is not assigned to Partition 2.

③ Partition 3 Operation (Premier 816/832 Only)

On: The selected keypad is assigned to Partition 3.

Off: The selected keypad is not assigned to Partition 3.

④ Partition 4 Operation (Premier 816/832 Only)

On: The selected keypad is assigned to Partition 4.

Off: The selected keypad is not assigned to Partition 4.

⑤ Permanent Keypad Status Display

On: The keypad status will be displayed permanently.

Off: Keypad status (not just zone status) will blank after the courtesy timer has expired.

⑥ Press Any Key for Display

On: If Keypad Option 1.5 (above) is selected as disabled, the selected keypad will re-enable the display after any key press.

Off: The selected keypad display will only re-enable after a valid Access code has been entered.

⑦ Display Zones vs. Partitions

On: The selected keypad will use its zone lights to indicate zone status details.

Off: The selected keypad will use its zone lights to indicate armed status of partitions.

⑧ Wrong Code Attempts Cause Code Tamper

On: The selected keypad will lockout key presses for 5 minutes and will generate a code tamper alarm after 3 incorrect code attempts (12 key presses).

Off: The keypad will accept any amount of incorrect code attempt entries.

Keypad Options 2 ④ ①

The operation of Keypad Options 2 is described as follows:

① Code Tamper Causes a Tamper Alarm

On: If a code tamper is generated by the selected keypad, the system will give a tamper alarm response.

Off: If a code tamper is generated by the selected keypad, the system will lock out the keypad for 5 minutes.



NOTE

Keypad Options 1.8 must also be enabled.

② Keypad Activation of Fire Alarm

On: The selected keypad will generate an emergency Fire alarm if keys ① and ③ are pressed at the same time.

Off: The selected keypad will not generate an emergency Fire alarm.

③ Keypad Activation of Medical Alarm

On: The selected keypad will generate an emergency Medical alarm if keys ⑦ and ⑨ are pressed at the same time.

Off: The selected keypad will not generate an emergency Medical alarm.

④ Keypad Activation of PA Alarm

On: The selected keypad will generate a Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.

Off: The selected keypad will not generate an emergency Panic Alarm.

⑤ Keypad PA Alarm is Silent

On: The selected keypad will generate a silent Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.

Off: The selected keypad will generate an audible Panic Alarm (Police) if keys ④ and ⑥ are pressed at the same time.



NOTE

Keypad Options 2.4 must also be enabled.

⑥ Quick Arm with Keypad ARM Key

On: The selected keypad can be used to quick arm the system (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to arm the system.

⑦ Quick Disarm with Keypad DISARM Key

On: The selected keypad can be used to quick disarm the system (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to disarm the system.

⑧ Quick Bypass with Keypad BYPASS Key

On: The selected keypad can be used to quick bypass zones (Access code not required).

Off: An Access code must be entered before the selected keypad can be used to bypass zones.

Keypad Options 3 ④ ②

The operation of Keypad Options 3 is described as follows:

① Fire Alarm Tones from Keypad

On: The internal sounder for the selected keypad will produce Fire Alarm tones.

Off: Fire Alarm tones will not be produced.

② Burglary Alarm Tones from Keypad

On: The internal sounder for the selected keypad will produce Burglary Alarm tones.

Off: Burglary Alarm tones will not be produced.

③ Service Tones from Keypad

On: The internal sounder for the selected keypad will produce Service tones.

Off: Service tones will not be produced.

④ Acceptance Tones from Keypad

On: The internal sounder for the selected keypad will produce Acceptance tones.

Off: Acceptance tones will not be produced.

⑤ Error Tones from Keypad

On: The internal sounder for the selected keypad will produce Error tones.

Off: Error tones will not be produced.

⑥ Chime Tones from Keypad

On: The internal sounder for the selected keypad will produce Chime tones.

Off: Chime tones will not be produced.

⑦ Exit Tones from Keypad

On: The internal sounder for the selected keypad will produce Exit tones.

Off: Exit tones will not be produced.

⑧ Entry Tones from Keypad

On: The internal sounder for the selected keypad will produce Entry tones.

Off: Entry tones will not be produced.

Keypad Options 4**④ ③**

The operation of Keypad Options 4 is described as follows:

① Enable Keypad Zones

On: The zones onboard the selected remote keypad are enabled and allocated as follows:

Keypad	Premier 412	Premier 816/832
1	Zones 05 & 06	Zones 09 & 10
2	Zones 07 & 08	Zones 11 & 12
3	Zones 09 & 10	Zones 13 & 14
4	Zones 11 & 12	Zones 15 & 16
5	N/A	N/A
6	N/A	N/A

Off: The zones onboard the selected remote keypad are disabled:



NOTE This option is only relevant if the keypad type is a *Premier RKP8/16 Plus* or *Premier LCD*.

If the system is fitted with either a local or remote expander, the relevant zones on the expander will be disabled if the zones on the remote keypad are enabled.

② Disable Keypad Lid Tamper

On: The remote keypad lid tamper is not monitored.

Off: The remote keypad lid tamper is monitored.

③ Zone Shift by 4

On: The remote keypad zone status lights indicate from Zone 5 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 5 and Zone 2 on the remote keypad follows the status of Zone 6 etc.

Off: The remote keypad zone status lights indicate as normal.

④ Zone Shift by 8

On: The remote keypad zone status lights indicate from Zone 9 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 9 and Zone 2 on the remote keypad follows the status of Zone 10 etc.

Off: The remote keypad zone status lights indicate as normal.


⑤ Zone Shift by 16

On: The remote keypad zone status lights indicate from Zone 17 onwards i.e., Zone 1 on the remote keypad follows the status of Zone 17 and Zone 2 on the remote keypad follows the status of Zone 18 etc.

Off: The remote keypad zone status lights indicate as normal.




NOTE Options 3, 4 and 5 allow the *Premier RKP4* remote keypad to be used on a multi-partition system with more than 4 zones and the *Premier RKP8* remote keypad to be used on a multi-partition system with more than 8 zones. The example below shows how a 16 zone system split into 2 partitions could use two *Premier RKP 8* remote keypads:

**Remote Keypad 1 (Partition 1)**

Keypad Options 4:


- ③ Zone Shift by 4 (Disabled)
- ④ Zone Shift by 8 (Disabled)
- ⑤ Zone Shift by 16 (Disabled)

**Remote Keypad 2 (Partition 2)**

Keypad Options 4:

- ③ Zone Shift by 4 (Disabled)
- ④ Zone Shift by 8 (Enabled)
- ⑤ Zone Shift by 16 (Enabled)

Programming Remote Expanders



Expander Partitions

When the expander is assigned to one or more partitions the speaker output on the expander will generate tones only for the partition(s) it's assigned to. E.g. if the expander is assigned to partition 3, the speaker will only be enabled when partition 3 is in alarm, entry, exit etc.

Expander Tones

The Expander Tones are described as follows:

1 Fire Alarm Tones from Expander

On: The siren output on the Expander will produce Fire Alarm tones.

Off: Fire Alarm tones will not be produced.

2 Burglary Alarm Tones from Expander

On: The siren output on the Expander will produce Burglary Alarm tones.

Off: Burglary Alarm tones will not be produced.

3 Service Tones from Expander

On: The siren output on the Expander will produce Service tones.

Off: Service tones will not be produced.

4 Acceptance Tones from Expander

On: The siren output on the Expander will produce Acceptance tones.

Off: Acceptance tones will not be produced.

5 Error Tones from Expander

On: The siren output on the Expander will produce Error tones.

Off: Error tones will not be produced.

6 Chime Tones from Expander

On: The siren output on the Expander will produce Chime tones.

Off: Chime tones will not be produced.

7 Exit Tones from Expander

On: The siren output on the Expander will produce Exit tones.

Off: Exit tones will not be produced.

8 Entry Tones from Expander


On: The siren output on the Expander will produce Entry tones.


Off: Entry tones will not be produced.

Expander Volume Level

This option controls the advisory tones (entry/exit, fault etc.) volume level of the speakers connected to the remote expander speaker output. 0 = minimum volume; 7 = maximum volume.

Programming System Outputs





① System Output Types

- ①① Courtesy
- ①② Successful Transmission
- ①③ Log 80% Full
- ①④ Program Mode Selected
- ①⑤ Download In Progress
- ①⑥ Timed Arming Countdown
- ①⑦ Zone Soak Test Active
- ①⑧ Zone Soak Test Failed
- ①⑨ Latched AC Fail
- ①⑩ Telephone Line Fault
- ①⑪ Smoke Alarm
- ①⑫ Box/Auxiliary Tamper
- ①⑬ Date Time Loss
- ①⑭ Zone Service/Tamper
- ①⑮ Keypad Tamper/Removed
- ①⑯ System Service
- ①⑰ Output 1 Fault
- ①⑱ Output 2 Fault
- ①⑲ Speaker Fault
- ①⑳ Smoke Sensor Fault
- ②① Auxiliary Fuse Fault
- ②② Latched Battery Fault
- ②③ Service Required/Test Fail
- ②④ Fail To Communicate
- ②⑤ Control Timer 1 Active
- ②⑥ Control Timer 2 Active
- ②⑦ Control Timer 3 Active
- ②⑧ Control Timer 4 Active
- ②⑨ PC Output 1
- ②⑩ PC Output 2
- ③① Walk Test
- ③② Confirmed Alarm
- ③③ ARC2 Active
- ③④ Zones Locked-Out
- ③⑤ AC Fail
- ③⑥ Battery Fail

② Partition Output Types

- ②① PA Alarm
- ②② Duress Alarm
- ②③ Burglar Alarm
- ②④ Medical Alarm
- ②⑤ 24Hr - Water Alarm
- ②⑥ 24Hr - Gas Alarm
- ②⑦ 24Hr - Low Temp Alarm
- ②⑧ 24Hr - High Temp Alarm
- ②⑨ Tamper
- ②⑩ Service
- ②⑪ Fire
- ②⑫ Fire Fault
- ②⑬ Bell
- ②⑭ Strobe
- ②⑮ Entry
- ②⑯ Exit
- ②⑰ Armed
- ②⑱ Stay Armed
- ③① Ready
- ③② Bypass
- ③③ Sensor Reset on Exit
- ③④ Sensor Reset on Reset
- ③⑤ Single Pulse on Arming
- ③⑥ Double Pulse on Arming
- ③⑦ Chime
- ③⑧ Door Strike
- ③⑨ Cross Zone Time Active
- ③⑩ Single Pulse on Disarming
- ③⑪ Reset Required
- ③⑫ Acknowledgement Required
- ③⑬ Confirmed Alarm
- ③⑭ Alarm Abort
- ③⑮ Away Armed
- ③⑯ Away Armed/Exit
- ③⑰ Detector Latch
- ③⑱ Armed/Alarm
- ④① Arm Failed

③ Zone Output Types

- ③① Zone 01 Mimic
- ③② Zone 02 Mimic
- ③③ Zone 03 Mimic
- ③④ Zone 04 Mimic
- ③⑤ Zone 05 Mimic
- ③⑥ Zone 06 Mimic
- ③⑦ Zone 07 Mimic
- ③⑧ Zone 08 Mimic
- ③⑨ Zone 09 Mimic
- ③⑩ Zone 10 Mimic
- ③⑪ Zone 11 Mimic
- ③⑫ Zone 12 Mimic
- ③⑬ Zone 13 Mimic
- ③⑭ Zone 14 Mimic
- ③⑮ Zone 15 Mimic
- ③⑯ Zone 16 Mimic
- ③⑰ Zone 17 Mimic
- ③⑱ Zone 18 Mimic
- ④① Zone 19 Mimic
- ④② Zone 20 Mimic
- ④③ Zone 21 Mimic
- ④④ Zone 22 Mimic
- ④⑤ Zone 23 Mimic
- ④⑥ Zone 24 Mimic
- ④⑦ Zone 25 Mimic
- ④⑧ Zone 26 Mimic
- ④⑨ Zone 27 Mimic
- ④⑩ Zone 28 Mimic
- ④⑪ Zone 29 Mimic
- ④⑫ Zone 30 Mimic
- ④⑬ Zone 31 Mimic
- ④⑭ Zone 32 Mimic
- ④⑮ Zone 01 Alarm
- ④⑯ Zone 02 Alarm
- ④⑰ Zone 03 Alarm
- ④⑱ Zone 04 Alarm
- ④⑲ Zone 05 Alarm
- ④⑳ Zone 06 Alarm
- ⑤① Zone 07 Alarm
- ⑤② Zone 08 Alarm
- ⑤③ Zone 09 Alarm
- ⑤④ Zone 10 Alarm
- ⑤⑤ Zone 11 Alarm
- ⑤⑥ Zone 12 Alarm
- ⑤⑦ Zone 13 Alarm
- ⑤⑧ Zone 14 Alarm
- ⑤⑨ Zone 15 Alarm
- ⑤⑩ Zone 16 Alarm
- ⑤⑪ Zone 17 Alarm
- ⑤⑫ Zone 18 Alarm
- ⑤⑬ Zone 19 Alarm
- ⑤⑭ Zone 20 Alarm
- ⑤⑮ Zone 21 Alarm
- ⑤⑯ Zone 22 Alarm
- ⑤⑰ Zone 23 Alarm
- ⑤⑱ Zone 24 Alarm
- ⑥① Zone 25 Alarm
- ⑥② Zone 26 Alarm
- ⑥③ Zone 27 Alarm
- ⑥④ Zone 28 Alarm
- ⑥⑤ Zone 29 Alarm
- ⑥⑥ Zone 30 Alarm
- ⑥⑦ Zone 31 Alarm
- ⑥⑧ Zone 32 Alarm

Panel Outputs (6)(0)

This menu option allows you to program the eight control panel outputs.

Fast Format/Speech Channels (6)(1)

When using the Fast Format communication protocol (see page 51) the channels that are reported to the Alarm Receiving Centre must be programmed for the relevant conditions. This menu option allows you to program the eight channels that are used by the Fast Format protocol.

Expander 1 Outputs (6)(2)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 1.

Expander 2 Outputs (6)(3)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 2 (*Premier 832 Only*).

Expander 3 Outputs (6)(4)

The *Premier 8X* remote expander has two programmable outputs. This menu option allows you to program the outputs of expander 3 (*Premier 832 Only*).

Keypad Outputs (6)(5)

Both the *Premier LCD* and *LCDL* remote keypads have a programmable output. This menu option allows you to program the keypad outputs.

Output Groups and Types

Group (0) - Not Used

This group contains no output types, by assigning an output to this group the output will never activate.

Group (1) - System Output Types

This group contains the system output types as listed below:

(0)(0) Courtesy

This output type activates after any keypad has been used and during entry delay. The output will remain active for the duration of the Courtesy timer (see page 34).

(0)(1) Successful Transmission

This output type activates after the communicator has successfully reported to the alarm receiving centre.

(0)(2) Log 80% Full

This output type activates when the Event Log is 80% full. The output is cleared when the event log is uploaded by the remote downloading computer.

(0)(3) Program Mode Selected

This output type activates when the program mode is selected.

(0)(4) Download in Progress

This output type activates when a Download is in progress.

(0)(5) Timed Arming Countdown

This output type activates when the system initiates a timed arm.

(0)(6) Zone Soak Test Active

This output type activates when any zone is enabled for soak test.

(0)(7) Zone Soak Test Failed

This output type activates if any zone fails during a zone soak test.

(0)(8) Latched AC Fail

This output type activates when the mains supply is disconnected.

(0)(9) Telephone Line Fault

This output type activates when the communicator detects a telephone line fault.

(1)(0) Smoke Alarm

This output type activates when a 2-wire smoke detector connected to Panel Output 1 causes an alarm.

(1)(1) Box/Auxiliary Tamper Alarm

This output type activates when the box tamper or the Auxiliary Input (Tamper) on the main panel causes an alarm.

(1)(2) Date/Time Loss

This output type activates when the control panel real time clock is reset (power up). The output clears when the clock is set.

(1)(3) Zone Trouble/Tamper

This output type activates when any zone is in trouble or tamper.

(1)(4) Keypad Tamper/Removed

This output type activates when a keypad is either disconnected or its box tamper causes an alarm.

(1)(5) Service Fault

This output type activates when there are any Service Faults on the system (mimics the Service light on the remote keypad).

(1)(6) Output 1 Fault

This output type activates when Panel Output 1 detects a fault.

(1)(7) Output 2 Fault

This output type activates when Panel Output 2 detects a fault.

(1)(8) Siren/Bell Fault

This output type activates when Siren Output detects a fault.

(1)(9) Smoke Sensor Fault

This output type activates when a 2-wire smoke detector connected to Panel Output 1 causes a fault.

(2)(0) Auxiliary Fuse Fault

This output type activates when the Auxiliary fuse is ruptured.

(2)(1) Latched Battery Fault

This output type activates when the system detects a fault from the stand-by battery.

(2)(2) Service Required/Test Fail

This output type activates when a Service Required fault exists or the system has failed zone soak test.

(2)(3) Fail to Communicate

This output type activates after the communicator has failed to report to the alarm receiving centre.

(2)(4) Control Timer 1 Active

This output type activates when Control Timer 1 is active.

(2)(5) Control Timer 2 Active

This output type activates when Control Timer 2 is active.

(2)(6) Control Timer 3 Active

This output type activates when Control Timer 3 is active.

(2)(7) Control Timer 4 Active

This output type activates when Control Timer 4 is active.

(2)(8) PC Output 1

The remote Downloading computer controls this output type.

②⑨ PC Output 2

The remote Downloading computer controls this output type.

③① Walk Test

This output type activates when the user selects the Zone Test option (menu 90).

③① Confirmed Alarm

This output type activates when two different zones are violated from any armed partition.

③② ARC 2 Active

This output type activates when the panel is communicating to ARC2.

③③ Zone Locked-Out

This output type activates when the one or more zones are locked out after the confirmation timer has expired.

③④ AC Fail

This output type activates when the mains supply is disconnected.

③⑤ Battery Fault

This output type activates when the system detects a fault from the stand-by battery.

Group ② - Partition Output Types

This group contains the partition output types as listed below:

①① PA Alarm

This output type activates when a PA alarm is generated in the selected Partition. If another PA alarm is generated the output will reset for 3 seconds then reactivate.

①① Duress Alarm

This output type activates when a Duress alarm is generated in the selected Partition. If another Duress alarm is generated the output will reset for 3 seconds then reactivate.

①② Burglar Alarm

This output type activates when a Burglar alarm is generated in the selected Partition. If another Burglar alarm is generated the output will reset for 3 seconds then reactivate.

①③ Medical Alarm

This output type activates when a Medical alarm is generated in the selected Partition. If another Medical alarm is generated the output will reset for 3 seconds then reactivate.

①④ 24Hr - Water Alarm

This output type activates when a 24hr Water alarm is generated in the selected Partition. If another 24hr Water alarm is generated the output will reset for 3 seconds then reactivate.

①⑤ 24Hr - Gas Alarm

This output type activates when a 24hr Gas alarm is generated in the selected Partition. If another 24hr Gas alarm is generated the output will reset for 3 seconds then reactivate.

①⑥ 24Hr - Low Temp Alarm

This output type activates when a 24hr Low Temperature alarm is generated in the selected Partition. If another 24hr Low Temperature alarm is generated the output will reset for 3 seconds then reactivate.

①⑦ 24Hr - High Temp Alarm

This output type activates when a 24hr High Temperature alarm is generated in the selected Partition. If another 24hr High

Temperature alarm is generated the output will reset for 3 seconds then reactivate.

①⑧ Tamper

This output type activates when a Tamper alarm is generated in the selected Partition. If another Tamper alarm is generated the output will reset for 3 seconds then reactivate.

①⑨ Trouble

This output type activates when a Trouble alarm is generated in the selected Partition. If another Trouble alarm is generated the output will reset for 3 seconds then reactivate.

①① Fire

This output type activates when a Fire alarm is generated in the selected Partition. If another Fire alarm is generated the output will reset for 3 seconds then reactivate.

①① Trouble/Tamper

This output type activates when a Trouble or Tamper alarm is generated in the selected Partition.

①② Bell

This output type activates when an alarm is generated in the selected Partition.

①③ Strobe

This output type activates when an alarm is generated in the selected Partition.

①④ Entry

This output type activates when the selected Partition is in entry mode.

①⑤ Exit

This output type activates when the selected Partition is in exit mode.

①⑥ Armed

This output type activates when the selected Partition is stay or away armed.

①⑦ Stay Armed

This output type activates when the selected Partition is stay armed.

①⑧ Ready

This output type activates when the selected Partition is ready for arming.

①⑨ Bypass

This output type activates when the selected Partition has one or more zones bypassed.

②① Sensor Reset on Exit

This output type is normally active and deactivates for 2 seconds when the selected Partition is in exit mode.

②① Sensor Reset on Reset

This output type is normally active and deactivates for 2 seconds when the user resets the selected Partition.

②② Single Pulse on Arming

This output type activates for 2 seconds when the selected Partition is armed.

②③ Double Pulse on Arming

This output type activates twice (2 seconds on) when the selected Partition is armed.

②④ Chime

This output type activates for 2 seconds when a zone programmed as Chime is violated in the selected Partition.

②⑤ Door Strike

This output type activates for 2 seconds when an Access code with the "Activate Door Strike Output" attribute is entered.

②⑥ Cross Zone Time Active

This output type activates when a Cross Zone is violated and remains active for the duration of the Cross Zone Time Window.

②⑦ Single Pulse on Disarming

This output type activates for 2 seconds when the selected Partition is disarmed.

②⑧ Reset Required

This output type activates when an alarm condition requires resetting in the selected Partition.

②⑨ Acknowledgement Required

This output type activates when a Service Fault requires acknowledgement.

③① Confirmed Alarm

This output type activates when two different zones are violated during an armed period.

③① Alarm Abort

This output type activates when the system is disarmed after an alarm condition (providing the system is disarmed before the "Alarm Transmission Abort" delay has expired, see page 34).

③② Away Armed

This output type activates when the partition is "Away Armed".

③③ Away Armed/Exit

This output type activates when the partition is in exit mode (Away arming) and when the partition is "Away Armed".

③④ Detector Latch

This output type is used to latch an alarm condition on detectors that have a latch input.

③⑤ Armed/Alarm

This output type is used to indicate both the armed and alarm status of a partition, it operates as follows: on = armed; off = disarmed; pulsing = alarm.

③⑥ Arm Failed

This output type activates when the selected partition fails to arm.

③⑦ All Armed

This output activates when all selected partitions are armed. It resets when any of the selected partitions is disarmed.

Group ③ Zone Output Types

This group contains the zone output types as listed below:

①① - ③② Zone 01 - 32 Mimic

This output type activates when Zone XX is violated and deactivates when the zone is secure.

③③ - ⑥④ Zone 01 - 32 Alarm

This output type activates when Zone XX causes an alarm and deactivates when the alarm is reset.

Output Attributes

Each output can have the following attributes assigned to alter the function of the selected output:

① Enable for Partition 1

On: The selected output is assigned to Partition 1.

Off: The selected output is not assigned to Partition 1.

② Enable for Partition 2

On: The selected output is assigned to Partition 2.

Off: The selected output is not assigned to Partition 2.

③ Enable for Partition 3 (Premier 816/832 Only)

On: The selected output is assigned to Partition 3.

Off: The selected output is not assigned to Partition 3.

④ Enable for Partition 4 (Premier 816/832 Only)

On: The selected output is assigned to Partition 4.

Off: The selected output is not assigned to Partition 4.

⑤ Enable for User Test

On: The selected output is activated during a user test.

Off: The selected output is not activated during a user test.

⑥ Inverted

On: The selected output is inverted.

Off: The selected output is normal.

⑦ Latching

On: The selected output will latch on until the system is reset.


Off: The selected output will not latch.


⑧ Pulsed


On: The selected output will pulse for the duration of the Output Short Pulse Timer (see page 34).

Off: The selected output will be normal.







Programming the Communicator














Each telephone number can be up to 24 digits. When entering the telephone number the following keys can be used:

- Press**  **1** to insert a “*”.
- Press**  **2** to insert a “#”.
- Press**  **3** to insert a “,” (3 second pause).
- Press**  **4** to insert a “W” (10 second pause).
- Press**  **5** to insert a “D” (Wait for dial tone).
- Press**  **6** to insert a “+” (Force dials next number).

Account Numbers

Alarm Receiving Centre 1 has four account numbers. Account No 1 is for partition 1 and is also the global account number. Account numbers 2 - 4 are for partitions 2 - 4. To send events on separate account numbers, you must ensure the “Disable Separate Events for Each Partition” is turned off (see Protocol Options on page 53). The account number can be up to 6 digits. Separate partition account numbers can be selected by pressing the  key. When entering the account number the following keys can be used to insert hexadecimal characters:

- Press**  **1** to insert a “B”.
- Press**  **2** to insert a “C”.
- Press**  **3** to insert a “D”.
- Press**  **4** to insert a “E”.
- Press**  **5** to insert a “F”.
- Press**  **6** to insert a “A”.

Protocol Type

This is the reporting protocol that is used to communicate with Alarm Receiving Centre 1. The following protocols are supported:

Disabled

Communication disabled.

Pulse Format

The panel will communicate with Alarm Receiving Centre 1 using Pulse Format. See page 60 for details on configuring reporting codes.

Express Format

The panel will communicate with Alarm Receiving Centre 1 using Express Format. See page 60 for details on configuring reporting codes.

Fast Format/Speech Module

The panel will communicate with Alarm Receiving Centre 1 using Fast Format protocol. If the “Enable Speech Module” option is enabled in the Protocol Options (see page 53) the panel will use the plug-on *Speech Module* to communicate the alarm information. The Fast Format/Speech channels must be programmed to the required to type, see Program Outputs on page 45.

Contact ID

The panel will communicate with Alarm Receiving Centre 1 using Contact ID. The defaults Contact ID codes are shown in the standard defaults worksheets from page 83.

SIA Level 2/3

The panel will communicate with Alarm Receiving Centre 1 using SIA Level 2. If the “Send SIA Text” option is enabled, the panel will

communicate using SIA level 3. The defaults SIA codes are shown in defaults worksheets from page 83.

Pager

The panel will communicate to a pager. When using the pager option the panel transmits the data to the pager using the following format:

Pager Format = AAAAAA EE

AAAAAA	4 - 6 digit account number
EE	Event Code
	This code is the same code used for Pulse formats (see page 60)

If for example the account number for the site was programmed as 1234 and zone 8 was violated and caused a burglar alarm, the pager would display 1234 38.



When using the pager option the telephone number will require a pause after it to make it work properly, see Telephone Numbers above.

When using the pager option the pager is normally terminated using either a * or #. This is programmable see Protocol Options on page 53.

The dial attempts when using the pager option should be programmed to 1, see Dial Attempts on page 51.

The panel has no way of confirming if the pager was called successfully which means a “Communication Failure” fault will never be generated.

The panel will only report the event groups that are selected in the Reporting Options, see page 52.

Mobile Phone

This protocol can be used to communicate with standard or mobile phones. When an alarm is activated the panel will dial the programmed telephone number and play a number of “bleeps”, which is repeated 10 times, after which the panel will hang-up.

The number of bleeps corresponds to the pulse format code for the selected event, e.g., if the pulse code for zone 4 alarm is programmed as “4” the panel will play 4 “bleeps”. See page 60 for details on configuring reporting codes.

Dial Attempts

This is the number of times the panel will attempt to communicate with Alarm Receiving Centre 1.



The maximum number of repeat dialling attempts is limited to 9. The system will only allow you to enter values between 0 and 9. Setting the value to 0 will disable the communicator for ARC 1.

Partition Options

The Partition Options are described as follows:

Report for Partition 1

On: The system will report events for Partition 1 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 1.

② Report for Partition 2

On: The system will report events for Partition 2 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 2.

③ Report for Partition 3 (Premier 816/832 Only)

On: The system will report events for Partition 3 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 3.

④ Report for Partition 4 (Premier 816/832 Only)

On: The system will report events for Partition 4 to Alarm Receiving Centre 1.

Off: The system will not report events for Partition 4.

Reporting Options**⑦ ① - ⑤**

The Reporting Options are described as follows:

① Report Priority Alarm and Cancel Events

On: Priority alarm and cancel events are reported to ARC1.

Off: Priority alarms and cancel events are not reported.

② Report Alarm and Cancel Events

On: Alarm and cancel events are reported to ARC1.

Off: Alarm and cancel events are not reported.

③ Report Open and Close Events

On: Open and close events are reported to ARC1.

Off: Open and close events are not reported.

④ Report Bypass and Unbypass Events

On: Bypass and unbypass events are reported to ARC1.

Off: Bypass and unbypass events are not reported.

⑤ Report Maintenance Alarm Events

On: Maintenance alarm events are reported to ARC1.

Off: Maintenance alarm events are not reported.

⑥ Report Tamper Alarm Events

On: Tamper alarm events are reported to ARC1.

Off: Tamper alarm events are not reported.

⑦ Report Test Transmission Events

On: Test transmission events are reported to ARC1.

Off: Test transmission events are not reported.

⑧ Report Restore Events

On: Restore events are reported to ARC1.

Off: Restore events are not reported.

Pulse Format Options**⑦ ① - ⑥**

If ARC 1 protocol is programmed for "Pulse Format", the pulse format protocol can be changed using this menu option. The following options are available:

① Use 1900Hz Carrier

On: Pulse Format carrier frequency is set to 1900Hz.

Off: Pulse Format carrier frequency is set to 1800Hz.

② Use 40 PPS Baud Rate

On: Pulse Format baud rate is set to 40 pulses per second.

Off: Pulse Format baud rate is set to 20 pulses per second.

③ Enable Parity

On: Pulse Format uses parity.

Off: Pulse Format doesn't use parity.

④ Use 2 Digit Events

On: Pulse/Express Format uses 2 digits (3 + 2 or 4 + 2).

Off: Pulse/Express Format uses 1 digit (3 + 1 or 4 + 1).

⑤ Use 2300Hz Handshake

On: Pulse Format uses 2300Hz handshake.

Off: Pulse Format uses 1400Hz handshake.

⑥ Use 2300Hz Kiss-Off Frequency

On: Pulse Format uses 2300Hz kiss-off.

Off: Pulse Format uses 1400Hz kiss-off.

⑦ Use Fast/Slow Format

On: Pulse Format uses 10 PPS.

Off: Pulse Format uses either 20 or 40 PPS as defined by option 2 (Use 40 PPS Baud Rate).

The table below shows how to configure some of the common protocols:

Protocol	Zone Lights						
	1	2	3	4	5	6	7
Ademco Slow 3x1/4x1	-	-	-	-	-	-	
Ademco Slow 3x2/4x2	-	-	-		-	-	
Ademco Fast 3x1/4x1	-	-	-	-	-	-	-
Ademco Fast 3x2/4x2	-	-	-		-	-	-
Silent Knight Fast 3x1/4x1		-	-	-	-	-	-
Silent Knight Fast 3x2/4x2		-	-		-	-	-
FBI (No Parity) 3x1/4x1		-	-	-	-	-	-
FBI (Parity) 3x1/4x1		-		-	-	-	-
Franklin 3x1/4x1	-	-	-	-			-
Franklin 3x2/4x2	-	-	-				-
Radionics 3x1/4x1	-		-	-			-
Radionics (Parity) 3x1/4x1	-			-			-
Radionics 3x2/4x2	-		-				-
Radionics (Parity) 3x2/4x2	-						-
Sescoa		-	-	-	-	-	-
Sescoa Super Fast	-	-		-	-	-	-

= Zone Light On

Fast Format Reporting Channels ⑦ ① - ⑦

This option defines which channels are reported to Alarm Receiving Centre 1 when using the Fast Format communication protocol (see page 51).

① Report Fast Format Channel 1

On: Channel 1 is reported.

Off: Channel 1 is not reported.

② Report Fast Format Channel 2

On: Channel 2 is reported.

Off: Channel 2 is not reported.

③ Report Fast Format Channel 3

On: Channel 3 is reported.

Off: Channel 3 is not reported.

④ Report Fast Format Channel 4

On: Channel 4 is reported.

Off: Channel 4 is not reported.

⑤ Report Fast Format Channel 5

On: Channel 5 is reported.

Off: Channel 5 is not reported.

⑥ Report Fast Format Channel 6

On: Channel 6 is reported.

Off: Channel 6 is not reported.

⑦ Report Fast Format Channel 7

On: Channel 7 is reported.

Off: Channel 7 is not reported.

⑧ Report Fast Format Channel 8

On: Channel 8 is reported.

Off: Channel 8 is not reported.



NOTE The channel must also be programmed to report an event, see "Program Outputs" on page 43.

Protocol Options**⑦①⑧**

This menu option allows you to alter the operation of certain protocol types. The Protocol Options are described as follows:

① Disable SIA Modifier Block/Enable Speech Module

On: When using SIA protocol, the area/partition modifier data block (ri) is not transmitted. When using Fast Format protocol the *Speech Module* is enabled.

Off: When using SIA protocol, the area/partition modifier data block (ri) is transmitted. When using Fast Format protocol the *Speech Module* is disabled.

② Disable Separate Events for Each Partition

On: The panel will communicate as follows:

- If the event occurs in single partition, the panel will report the event using the appropriate account number for the partition.
- If the event occurs in multiple partitions, the panel will report the event using the appropriate account number for the lowest partition, e.g., if the event occurs in partitions 2, 3 and 4, the panel will report the event for partition 2.
- If the account number is not programmed for partitions 2, 3 and 4, the global (partition 1) account number is used.

Off: The panel will communicate as follows:

- If the event occurs in single partition, the panel will report the event using the appropriate account number for the partition.

- If the event occurs in multiple partitions, the panel will report a separate event for each partition using the appropriate account numbers. E.g., if the event occurs in partitions 1 and 3, the panel will report the event for partition 1 using the account number for partition 1, then it will report the event for partition 2 using the account number for partition 2.

- If the account number is not programmed for partitions 2, 3 and 4, the global (partition 1) account number is used.

③ Pager Terminator = * (Star)

On: When using the pager format, the panel transmits a * (star) to terminate the pager call.

Off: When using the pager format, the panel transmits a # (hash) to terminate the pager call.

④ Send Pager Terminator Twice/SIA Text

On: When using the pager format, the panel transmits the pager terminator (* or #) twice to terminate the pager call. If SIA protocol is enabled, the panel will send zone/user text for relevant events (SIA level 3).

Off: When using the pager format, the panel transmits the pager terminator (* or #) once to terminate the pager call. If SIA protocol is enabled, the panel does not send zone/user text for relevant events (SIA level 2).

⑤ Pager DTMF Tones = 500mS

On: When using the pager format, the panel transmits the pager DTMF tones with an on time of 500mS.

Off: When using the pager format, the panel transmits the pager DTMF tones with an on time of 80mS.

⑥ Disable Zone Restorals

On: Zone restore events are not sent to the Alarm Receiving Centre (even if Report Restore Events are enabled, see page 52).

Off: Zone restore events are sent to the Alarm Receiving Centre 1 (providing Report Restore Events are enabled, see page 52).

⑦ Communication Acknowledgment Tone

On: After a successful communication with the alarm receiving centre the keypads and panel speaker will generate an acknowledgment tone.

Off: After a successful communication the system will remain silent.

⑧ Send via IP

On: Alarm events are sent to the ARC via the *ComIP* module (TCP/IP). Only Fast Format, Contact ID and SIA protocols are supported with this option.

Off: Alarm events are not sent via the *ComIP* module.

ARC 2 Communicator Options**⑦②**

This option allows the on-board communicator to be configured for Alarm Receiving Centre 2. The same options are available as for the ARC 1 communicator options (see above).

Fast Format Restore Channels**⑦③**

If either ARC 1 or ARC 2 protocols are programmed as "Fast Format (UK)", the channels that report a restore event to the Alarm Receiving Centre may be selected.

① Report Restore on Channel 1

On: Restore reported on channel 1.

Off: Restore not reported on channel 1.

② Report Restore on Channel 2

On: Restore reported on channel 2.

Off: Restore not reported on channel 2.

③ Report Restore on Channel 3

On: Restore reported on channel 3.

Off: Restore not reported on channel 3.

④ Report Restore on Channel 4

On: Restore reported on channel 4.

Off: Restore not reported on channel 4.

⑤ Report Restore on Channel 5

On: Restore reported on channel 5.

Off: Restore not reported on channel 5.

⑥ Report Restore on Channel 6

On: Restore reported on channel 6.

Off: Restore not reported on channel 6.

⑦ Report Restore on Channel 7

On: Restore reported on channel 7.

Off: Restore not reported on channel 7.

⑧ Report Restore on Channel 8

On: Restore reported on channel 8.

Off: Restore not reported on channel 8.



NOTE The channel must also be programmed to report an event, see "Program Outputs" on page 43.

The channel must also be programmed to report to the ARC, see "Fast Format Reporting Channels" on page 52.

**NOTE**

The channel must also be programmed to report an event, see Program Outputs on page 43.

The channel must also be programmed to report to the ARC, see "Fast Format Reporting Channels" on page 52.

Cancel Call Waiting Sequence**⑦ ⑤**

This is the number that the panel dials to disable Call Waiting. The number can be up to 24 digits. The Cancel Call Waiting option must also be enabled, see Communicator Options on page 50.

Fast Format Open/Close Channels **⑦ ④**

If either ARC 1 or ARC 2 protocols are programmed as "Fast Format (UK)", the channels that report an Open/Close event to the Alarm Receiving Centre may be selected.

① Report Open/Close on Channel 1

On: Open/Close reported on channel 1.

Off: Open/Close not reported on channel 1.

② Report Open/Close on Channel 2

On: Open/Close reported on channel 2.

Off: Open/Close not reported on channel 2.

③ Report Open/Close on Channel 3

On: Open/Close reported on channel 3.

Off: Open/Close not reported on channel 3.

④ Report Open/Close on Channel 4

On: Open/Close reported on channel 4.

Off: Open/Close not reported on channel 4.

⑤ Report Open/Close on Channel 5

On: Open/Close reported on channel 5.

Off: Open/Close not reported on channel 5.

⑥ Report Open/Close on Channel 6

On: Open/Close reported on channel 6.

Off: Open/Close not reported on channel 6.

⑦ Report Open/Close on Channel 7

On: Open/Close reported on channel 7.

Off: Open/Close not reported on channel 7.

⑧ Report Open/Close on Channel 8

On: Open/Close reported on channel 8.

Off: Open/Close not reported on channel 8.

Programming Check List

The table below provides a checklist of what options require programming for each of the protocols supported:

Protocol	0 - Telephone No	1 - Account No	2 - Protocol Type	3 - Dial Attempts	4 - Partition Options	5 - Reporting Options	6 - Pulse Format Options	7 - Fast Format Channels	8 - Protocol Options	73 - Fast Format Restore Channels	74 - Fast Format Open/Close Channels	Notes
Pulse Format			1				2		3			1. Program to type 1. 2. Use table on page 52. 3. Set option 6 as required.
Express Format			1				2		3			1. Program to type 2. 2. Enable option 4 if 2 digit format is required. 3. Set option 6 as required.
Fast Format			1					2		3	4	1. Program to type 3. 2. Select channels that are required to report. Also program the channels for the relevant type, see page 45. 3. Select channels that require a restore to be reported. 4. Select channels that require to report Open/Close.
Speech Module			1					2	3			1. Program to type 3. 2. Select channels 1 and/or 2. Also program the channels for the relevant type, see page 45. 3. Enable option 1.
Contact ID			1						2			1. Program to type 4. 2. Set options 2 and 6 as required.
SIA Level 2			1						2			1. Program to type 5. 2. Set options 1, 2 and 6 as required.
SIA Level 3			1						2			1. Program to type 5. 2. Set options 1, 2 and 6 as required. Enable option 4.
Pager			1						2			1. Program to type 6. 2. Set options 3, 4, 5 and 6 as required.
Mobile Phone			1						2			1. Program to type 7. 2. Set option 6 as required.

Programming Download Options

Enter Engineers code
 () () () ()
 Then press (Menu) then (9)

Programming Menu
 Enter Code > ??



Note

Only Engineer codes that have the Allow NVM Locking/Communicator Programming" option are allowed to access menus 70 - 79.

Led Key

- Off
- On
- ◐ Slow Flash
- ◑ Fast Flash

(7) (6)

Download Menu
 Enter Option 0-9



Enter Option (0) - (9)

Download Menu

Download Options

Download Options
 > ***** <



Use keys (1) - (6) to select/deselect Options.
 Then press (Yes) or (Arm)

(0)

Call-Back Number

Call No>



Enter Telephone Number
 Then press (Yes) or (Arm)

LED: To display Telephone Number press (Clear)

(1)

UDL Passcode

Passcode



Enter Passcode
 Then press (Yes) or (Arm)

LED: To display Telephone Number press (Clear)

(2)

Call-Back Attempts

Call Attempts
 Enter Value: 001



Enter Value (0) - (9) .
 LCD: Use (Left Arrow) to scroll value then press (Yes) .

(3)

Ring Count

Ring Count
 Enter Value: 002



Enter Value (0) - (9) .
 LCD: Use (Left Arrow) to scroll value then press (Yes) .


(4)

Download Options

- (1) Enable Attended Download
- (2) Enable Unattended Call Back
- (3) Enable 2-Call Answer Phone Defeat
- (4) Restrict Download when Armed
- (5) Download when Part Armed
- (6) Disconnect Telephone Line

Continues on
 Next Page

From
Previous Page



Device Types

- ① PC-Com/USB-Com
- ① RadioPlus
- ② Inovonics Radio
- ③ ComIP Module
- ④ WebWayOne/Emizon Module
- ⑤ Chiron Module

Note

The ComIP address and port number MUST be entered as a 17 digit sequence, e.g. If the IP address is 192.168.0.10 and the port number 980, then it should be entered as:
192 168 000 010 00980

Note

The ComIP Gateway address MUST be entered as a 12 digit sequence, e.g. If the Gateway address is 192.168.0.1, then it should be entered as:
192 168 000 001

Device Types

- ① PC-Com/USB-Com
- ① RadioPlus
- ② Inovonics Radio
- ③ ComIP Module
- ④ WebWayOne/Emizon Module
- ⑤ Chiron Module

Chiron Data

- ① Access PT Name
- ① User Name
- ② Password

Download Menu

The Download Menu has the following options:

- ① Download Options
- ① Download Telephone Number
- ② UDL Passcode
- ③ Call Back Attempts
- ④ Ring Count

(7) (6)

- ⑤ Com1 Device Type
- ⑥ ComIP Address & Port
- ⑦ ComIP Gateway address
- ⑧ ComIP Subnet Mask
- ⑨ Com 2 Device Type
- Area Chiron Data Setup

Download Options

(7)(6)-(0)

The system has the following Download options:

① Enable Attended Download

On: The system will only allow download access if a user has authorised downloading.

Off: The system will allow unattended download access.

② Enable Unattended Call Back

On: The system will call back the remote computer before the system can be downloaded.

Off: Call back is not required.

③ Enable 2-Call Answer Phone Defeat

On: The panel will answer incoming calls as follows:

- In order to "prime" the panel one or more rings must be detected, but the panel must not detect more than the ring count. If the panel detects more than the ring count the panel will not "prime" itself.
- The panel will remain in primed state for 60 seconds.
- When the panel is primed the next incoming call is answered immediately.

Off: The panel will answer incoming calls after the specified "Download Ring Count", see below.

④ Restrict Download when Armed

On: Download access is restricted when the system is armed (see option 5 below).

Off: The panel can be downloaded at any time.

⑤ Download when Part Armed

If option 4 above is enabled, then downloading is restricted as follows:

On: The panel will allow download access if system is part armed (one or more partitions disarmed).

Off: The panel will only allow download access when all partitions are disarmed.

⑥ Disconnect Telephone Line

If this option is enabled, the standard T and R connections cannot be used instead the telephone line must be connected to terminals T1 and R1. This configuration provides additional lightning protection as the telephone line is isolated most of the time and is only switched in when the panel is required to transmit an alarm or to test the status of the telephone line. If this option is used then it is NOT possible to use the upload/download feature unless the user enables "Remote Access" see page 67. The operation is as follows:

On: The telephone line is disconnected from panel during normal operation and is only switched in when the panel is required to send an alarm event or test the line (tested every hour).

Off: The telephone line is continuously connected and operates as normal.

⑦ & ⬇️ (down) or ⑨ & ⬆️ (up) Polling IP Address & Port Number

This is the polling IP Address and Port number of the alarm Receiving Centre. The IP address and port number MUST be entered as a 17 digit sequence, e.g. if the IP address is 192.168.0.10 and the port number 980, then it should be entered as: 19216800001000980. Values entered here are not used to set up the Chiron IRIS Module, (The Chiron IRIS module's Polling IP Address is taken from the first 12 digits of the Primary Telephone Number and its Account Number is that of Partition 1).

Call Back Number

(7)(6)-(1)

This is the telephone number that is used to dial the remote downloading computer when the system has been configured to use Unattended Call Back, see Download Options.

UDL Passcode

(7)(6)-(2)

When the remote downloading computer dials into the system, the control panel compares the Security code sent by the computer with Security code stored in the control panel. If the Security codes match, access to the control panel is granted, otherwise access is denied.

The security programmed in this option MUST also be programmed in the customer account on the remote downloading computer. The Security code can be up to 8 characters.

Download Dial Attempts

(7)(6)-(3)

If the "Enable Unattended Call Back" feature is enabled, (see Download Options), this option controls the number of times the panel will attempt to call back the remote downloading computer.



NOTE The maximum number of repeat dialling attempts is limited to 9. The system will only allow you to enter values between 0 and 9. Setting the value to 0 will disable the modem from dialling out.

Ring Count

(7)(6)-(4)

This counter controls the number of rings required in order for the on-board modem to answer the incoming call. If the "Ring Count" is set to 0 the panel will not answer any incoming calls.

Com1 Device Type

(7)(6)-(5)

This option allows you to specify which module is connected to communication port Com1. The control panel will accept the following modules:

- ① PC-Com
- ① RadioPlus
- ② Inovonics Radio
- ③ ComIP
- ④ WebWayOne/Emizon Module
- ⑤ Chiron Module

IP Address & Port

(7)(6)-(6)

This option allows you to assign a local IP address and port number to a module connected to a Com Port (e.g. ComIP or Chiron IRIS). The IP address and port number MUST be entered as a 17 digit sequence, e.g. If the IP address is 192.168.0.10 and the port number 980, then it should be entered as: 19216800001000980. If an IP module (WebWayOne, Chiron IRIS, etc) is fitted its IP address and port must also enter via the Polling IP address and port number.



NOTE Note for the Chiron IRIS module entry of only the 12 digit IP Address results in the port number being set to its default, 10001.

ComIP Gateway Address

(7)(6)-(7)

This option allows you to assign a Gateway IP address to the ComIP module (if fitted). The Gateway IP address MUST be entered as a 12 digit sequence, e.g. If the Gateway IP address is 192.168.0.1, then it should be entered as: 192 168 000 001.

ComIP Subnet Mask

7 6 - 8

This option allows you to assign a Subnet Mask to the *ComIP* module (if fitted). The Subnet Mask is entered as a decimal value of 001 through to 024. Each decimal value generates the following Subnet Masks used by the *ComIP* module:

Value	Subnet Mask	Value	Subnet Mask
001	255.255.255.254	013	255.255.224.0
002	255.255.255.252	014	255.255.192.0
003	255.255.255.248	015	255.255.128.0
004	255.255.255.240	016	255.255.0.0
005	255.255.255.224	017	255.254.0.0
006	255.255.255.192	018	255.252.0.0
007	255.255.255.128	019	255.248.0.0
008	255.255.255.0	020	255.240.0.0
009	255.255.254.0	021	255.224.0.0
010	255.255.252.0	022	255.192.0.0
011	255.255.248.0	023	255.128.0.0
012	255.255.240.0	024	255.0.0.0

Com2 Device Type

7 6 - 9

This option allows you to specify which module is connected to communication port Com2. See Com1 Device Type above for a list of supported devices.

Chiron Iris Data Setup

7 6 - Area

This menu option has three submenus to allow programming of the Chiron Iris module data. The value of each parameter can be viewed by pressing the **Yes** key or its value can be edited by pressing the **No** key. A maximum of 30 characters for the Access Point Name and 32 Characters for User Name and Password can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the **↕** key to move the cursor along). For details on entering text, see page 22.

7 6 - Area - 1

Access Point Name

This is the GPRS Access Point Name. It's value can be viewed by pressing the **Yes** key or its value can be edited by pressing the **No** key. A maximum of 30 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the **↕** key to move the cursor along). For details on entering text, see page 22.

7 6 - Area - 2

User Name


This is the GPRS Access Point Name. It's value can be viewed by pressing the **Yes** key or its value can be edited by pressing the **No** key. A maximum of 32 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the **↕** key to move the cursor along). For details on entering text, see page 22.

7 6 - Area - 3

Password

This is the GPRS Access Point Name. It's value can be viewed by pressing the **Yes** key or its value can be edited by pressing the **No** key. A maximum of 32 characters can be entered. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press the **↕** key to move the cursor along). For details on entering text, see page 22.

Programming Reporting Codes



Zone Alarm/Restore Event Numbers

No	Event Type	No	Event Type
00	Zone 01 Alarm	16	Zone 09 Alarm
01	Zone 01 Restore	17	Zone 09 Restore
02	Zone 02 Alarm	18	Zone 10 Alarm
03	Zone 02 Restore	19	Zone 10 Restore
04	Zone 03 Alarm	20	Zone 11 Alarm
05	Zone 03 Restore	21	Zone 11 Restore
06	Zone 04 Alarm	22	Zone 12 Alarm
07	Zone 04 Restore	23	Zone 12 Restore
08	Zone 05 Alarm	24	Zone 13 Alarm
09	Zone 05 Restore	25	Zone 13 Restore
10	Zone 06 Alarm	26	Zone 14 Alarm
11	Zone 06 Restore	27	Zone 14 Restore
12	Zone 07 Alarm	28	Zone 15 Alarm
13	Zone 07 Restore	29	Zone 15 Restore
14	Zone 08 Alarm	30	Zone 16 Alarm
15	Zone 08 Restore	31	Zone 16 Restore

Zone Bypass/Unbypass Event Numbers

No	Event Type	No	Event Type
00	Zone 01 Bypass	16	Zone 09 Bypass
01	Zone 01 Unbypass	17	Zone 09 Unbypass
02	Zone 02 Bypass	18	Zone 10 Bypass
03	Zone 02 Unbypass	19	Zone 10 Unbypass
04	Zone 03 Bypass	20	Zone 11 Bypass
05	Zone 03 Unbypass	21	Zone 11 Unbypass
06	Zone 04 Bypass	22	Zone 12 Bypass
07	Zone 04 Unbypass	23	Zone 12 Unbypass
08	Zone 05 Bypass	24	Zone 13 Bypass
09	Zone 05 Unbypass	25	Zone 13 Unbypass
10	Zone 06 Bypass	26	Zone 14 Bypass
11	Zone 06 Unbypass	27	Zone 14 Unbypass
12	Zone 07 Bypass	28	Zone 15 Bypass
13	Zone 07 Unbypass	29	Zone 15 Unbypass
14	Zone 08 Bypass	30	Zone 16 Bypass
15	Zone 08 Unbypass	31	Zone 16 Unbypass

Zone Alarm/Restore Codes (7) (7)

This menu option allows you to change the alarm/restore reporting event codes for each zone. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 83.



NOTE To disable the zone from reporting an event, program the first and second digit as 00.

Zone Bypass/Unbypass Codes (7) (8)

This menu option allows you to change the bypass/unbypass reporting event codes for each zone. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 83.



NOTE To disable the zone from reporting an event, program the first and second digit as 00.

Non Zone Alarm/Restore Codes (7) (9)

This menu option allows you to change the reporting event codes for non zone events. These codes are used with Pulse Format, Express Format, Pager and Mobile Phone communication protocols. The default reporting codes are listed in the programming worksheets from page 83.



NOTE To disable the event from reporting, program the first and second digit as 00.

The table below shows the event numbers for both alarm and restore for each event type:


Event Type	Alarm Event No	Restore Event No
AC Fail	00	01
Low Battery	02	03
Telephone Line Fault	04	05
Fail to Communicate	06	07
Open/Close	08	09
Recent Closing	10	11
Auto Open/Close	12	13
Auto Arm Deferred	14	15
Remote Open/Close	16	17
Quick Arm	18	19
Open After Alarm (Cancel)	20	21
Download Start	22	23
Download End	24	25
Group Bypass/Unbypass	26	27
Log Capacity Alert (80%)	28	29
Keypad Lockout	30	31
Code Tamper Alarm	32	33
Manual Test Transmission	34	35
Automatic Test Transmission	36	37


Event Type	Alarm Event No	Restore Event No
User Zone Test Start/End	38	39
Auxiliary Power Fail/Restore	40	41
Bell Output Fault/Restore	42	43
Installer Programming Start	44	45
Installer Programming End	46	47
Exit Error	48	49
Verified Cross Zone Alarm	50	51
Soak Test	52	53
Fire Zone Trouble	54	55
System Power Up	56	57
Swinger Shutdown	58	59
User Code	60	61
Exit Started	62	63
Entry Started	64	65
Bell Active	66	67
Alarm Active	68	69
Keypad Tamper	70	71
Keypad Medical	72	73
Keypad Fire/2-Wire Smoke	74	75
Duress Code Alarm	76	77
Keypad Silent PA	78	79
Keypad Audible PA/Auxiliary PA	80	81
Box Tamper	82	83
Zone Tamper	84	85
Zone Trouble	86	87
Expander/Remote Trouble	88	89
Auxiliary Tamper Input	90	91
Date Changed	92	93
Time Changed	94	95
System Reset	96	97
Remote Control	98	99

Contact ID and SIA Codes

The reporting codes for Contact ID and SIA are fully configurable, however these codes can only be changed using *Wintex* downloading software.

Programming Users





Program User (8) (0)

The Program User option allows the engineer to assign new users for the alarm system. The number of users (including the engineer) that are available is as follows:

- Premier 412 - 32 Users
- Premier 816 - 32 Users
- Premier 832 - 64 Users

User 00 is the Engineer and can only be accessed by the engineer code. User 01 is the Master User which has a default code of 5678. Neither of these two users can be deleted from the system.

Each user is assigned the following attributes:

- **Access Code**
This is a unique 4, 5 or 6 digit code that is assigned to the user. The system will allow a mixture of different length Access codes. The Access code must be entered at a keypad before the user can operate the alarm system.
- **User Options 1**
See User Options 1 on page 64 for details.
- **User Options 2**
See User Options 2 on page 64 for details.
- **User Options 3**
See User Options 3 on page 65 for details.
- **User Text (LCD Only)**
See User Text on page 65 for details.

When using an LED keypad it is possible to view the next available user by pressing the Area key before entering the two digit user number. This will cause the next available user to be indicated using the top row of status lights.

User Options 1 (8) (1)

User Options 1 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

- (1) Enable for Partition 1**
On: The user can access Partition 1.
Off: The user cannot access Partition 1.
- (2) Enable for Partition 2**
On: The user can access Partition 2.
Off: The user cannot access Partition 2.
- (3) Enable for Partition 3 (Premier 816/832 Only)**
On: The user can access Partition 3.
Off: The user cannot access Partition 3.
- (4) Enable for Partition 4 (Premier 816/832 Only)**
On: The user can access Partition 4.
Off: The user cannot access Partition 4.
- (5) Allow Arming**
On: The user can arm the partitions they have been given access to.
Off: The user cannot arm any partitions.
- (6) Allow Bypassing**
On: The user can bypass zones in partitions they have been given access to.

Off: The user cannot bypass zones.

(7) Allow Disarming

On: The user can disarm the partitions they have been given access to.

Off: The user cannot disarm any partitions.



NOTE

The Engineer code (User 0) can only disarm the system, if the system was armed with the Engineer code.

(8) Allow User Functions

On: The user can access the following user functions:

- Reset
- View Alarm Log
- View Service Faults
- Enable Chime
- Change Own Code

Off: The user cannot access the above user functions.

User Options 2 (8) (2)

User Options 2 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

(1) Enable One Time Use Access Code

On: The Access code can only be used once to arm and disarm the system. After the Access code has been used to arm the system it is automatically deleted.

Off: The Access code behaves normally.

(2) Time Lock Code with Control Timer 1

On: When Control Timer 1 is on, the Access code will not be accepted by the system. When Control Timer 1 is off, the Access code will be accepted by the system. For information on programming Control Timers, see page 35.

Off: The Access code will be accepted at all times.

(3) Enable Open Reporting

On: The system will report an 'Open' condition to the alarm receiving centre when the Access code is used to disarm one or more partitions.

Off: The system will not report an 'Open' status.



NOTE

The panel will always send an open signal after an alarm even if this option is disabled.

(4) Enable Close Reporting

On: The system will report a 'Close' condition to the monitoring station when the Access code is used to arm one or more partitions.

Off: The system will not report a 'Close' condition.

(5) Enable User as Duress Code

On: The Access code will report a 'Duress' condition to the monitoring station when the Access code is used.

Off: The Access code behaves normally.

(6) Activate Door Strike Output

On: When a user Access code is entered, the output type "Door Strike" (see page 47) is activated for 2 seconds.

Off: The user Access code will not activate the "Door Strike" output.

(7) Allow Global Bell/Sounder Silence

On: This option allows users to silence the bell and internal sounder for any partition, even if the user is not assigned to

the partition that is in alarm. The user cannot disarm or reset the partition if they are not assigned to it.

Off: The user can only silence alarms for partitions that are assigned to their code.

⑧ Disable Remote Access

On: The touch-tone remote control feature is disabled for the selected user.

Off: The touch-tone remote control feature is enabled for the selected user.

User Options 3

⑧ ③

User Options 3 can be enabled or disabled for a selected user so that the level of access to the system may be altered. The following options are available:

① Allow Engineer Code Programming

On: The Access code can access User 00 (Engineer) in the Program New Users menu (menu 80).

Off: The Access code cannot access user 00 in the Program New Users menu.

② Allow NVM Locking/Communicator Programming

On: The Access code is allowed to lock/unlock the NVM (providing "Allow Engineer Programming" is enabled). Once the NVM is locked the "Load Defaults" jumper pins on the main control panel are disabled, thus preventing the panel from being defaulted. The Access code is also allowed to access the communicator programming menus 70 - 79.

Off: The Access code cannot lock/unlock the NVM or access communicator programming menus 70 - 79.

③ Allow Engineer Programming

On: The Access code can access the Engineer programming menus.

Off: The Access code cannot access the Engineer programming menus.

④ Allow Test Call Transmission

On: The Access code can perform a test transmission to the monitoring station (menu 92, see page 67).

Off: The Access code cannot perform a test transmission.

⑤ Allow Alarm/Fault Acknowledgement

On: The Access code can be used to acknowledge and reset alarms and service faults. A user with this option can disarm the system after an alarm, even if the user does not have the "Allow Disarming" option.

Off: The Access code cannot be used to acknowledge and reset alarms and service faults.

⑥ Allow User Programming

On: The Access code can access the user program menus (menu 90 - 98).

Off: The Access code cannot access the user program menus.

⑦ Allow User Code Programming

On: The Access code can access users 01 to 31 in the User programming menus (menus 80 - 85).

Off: The Access code cannot access user 01 to 31 in the User programming menus.


⑧ Local Partition Access Only

On: The Access code can only be used to arm and disarm the partitions that are assigned to the remote keypad. For example, if the user is assigned to all four partitions and they use a remote keypad that is only assigned to partition 1, they will only be permitted to arm and disarm partition 1 at that particular remote keypad.

Off: The Access code can be used at any remote keypad (Global access).

User Text (LCD Only)

⑧ ④

If the system is fitted with a LCD remote keypad you can assign up to 8 characters of text to each user. This text is used when viewing the system Event Log, see page 74. User text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press  to move the cursor along). For details on entering text, see page 22.

Program Standard Users

⑧ ⑤

This menu option allows you to add "Standard" users to the system. The user will automatically be assigned the following options:

User Options 1: Partition 1 Access

Allow Arming

Allow Bypassing

Allow Disarming

Allow User Functions

User Options 2: Enable Open Reporting

Enable Close Reporting

Allow Global Bell/Sounder Silence


User Options 3: Allow Alarm/Fault Acknowledgement


Default ALL Users

⑧ ⑥

This menu option allows you to default all Users to their factory default settings. Before selecting this menu option you **MUST** link out the "Load Defaults" pins (JP6) on the control panel PCB, see page 8. After selecting this option, User 01(Master) is reverted to 5678 and Users 02 onwards are deleted.

System Tests & Utilities





Walk Test

9 0

The Walk Test feature can only be performed when the partition is disarmed. 24 hour zones (except Fire, Tamper and Trouble) are disabled during Zone Test allowing Audible PA buttons, Silent PA buttons, etc. to be tested.



NOTE Pressing Reset clears all previously tested zones.

Test Speakers & Outputs

9 1

This menu options allows you to perform the following tests:

- ① Test Speakers
- ② Test Bells
- ③ Test Strobes
- ④ Test System Outputs
- ⑤ Test LCD Display



NOTE Only outputs with the 'Enable User Test' option selected (see page 47), will be included in test 4.

Send Test Call

9 2

This menu options allows you to send a test call transmission to your Alarm Receiving Centre. If the engineer code is used to select this option the keypad will display the progress status of the call.



NOTE If the panel is fitted with a *Speech Module*, keys ① and ② can be used to switch between speech message 1 and 2 during the test.

Enable Remote/Engineer Access

9 3

This option will enable both Remote Access to the control panel via downloading and Engineer Access (if EN 50131-1 requirements is enabled, see page 36). Once enabled, the control panel will allow access until 12.00am, after which, both Remote and Engineer Access will be disabled.



NOTE If the "Load Defaults" jumper pins (JP6) are shorted whilst this menu option is selected, the Engineer Access code is restored to its factory default setting of 1234 (providing the NVM is not locked).

Start Call Back

9 4

This option will cause the control panel to initiate a call back sequence. This will allow the remote downloading computer to remotely access the control panel.



NOTE If the Call Back is unsuccessful the keypad will sound the Error Tone.

Program Time

9 5

The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the control panel time.

Program Date

9 6

The control panel has a real time clock that is used to date and time stamp events that are recorded within the system log. The option allows you to set the date on the control panel.

Program Banner Text (LCD only)

9 7

If the system is fitted with a LCD remote keypad you can assign up to 16 characters of text to the Banner Message. The Banner Message is displayed on the top line of the LCD display during the normal disarmed state. Text is programmed in a similar way to mobile phones. Characters are selected by pressing the corresponding key the appropriate number of times (to select a character on the same key, press ↔ to move the cursor along). For details on entering text, see page 22.

Print 100 Events

9 8

This menu option allows the last 100 events in the system Event Log to be sent to the printer port (Com1).

Log Off Engineer

9 9

Selecting this menu option will log you out of engineer's programming mode and return the system to its normal state.

5. Operating the Alarm SystemIntroduction

Before attempting to operate the alarm system ensure you have familiarised yourself with all the arming and disarming methods covered in this section.

Access Codes


- If you make a mistake whilst entering your Access code, simply enter the correct Access code.

Arming & Disarming the Alarm System

Checking if the System is Ready to Arm

To help prevent faults during arming, a **Ready** light has been provided on each keypad. The **Ready** light works as follows:

- If the **Ready** light is on steady then the alarm system is ready to be armed.
- If the **Ready** light is flashing then the alarm system has bypassed zones and/or Force Armable zones that are violated, check these zones before proceeding.
- If the **Ready** light is off then one or more zones are violated, either secure or bypass these zones before proceeding. The keypads will display the zones that are violated:



If any unbypassed zones that are not enabled for "Force Arming" are violated at the end of the exit delay this is termed an exit error and the alarm system will go into fail set state (internal alarm). If programmed by the installer the external bell will also sound. Enter a valid user Access code to silence this alarm.

A zone will only be armed when ALL associated partitions are armed but will be disarmed when ANY associated partition is disarmed.

Away Arming

The Away arming mode is normally used when leaving the premises. When the system is armed in this mode all detection zones assigned to your partition(s) will be armed.

The **Ready** light must be on steady before the alarm system can be Away armed.

To Away arm the alarm system proceed as follows:

- Enter Access code **???**
- Press **Arm**

The **Armed** light will flash and the exit tone will sound.
- Leave the premises, when the system has armed the exit tone will stop. The system is now Away armed.



If the Quick Arm feature is enabled (see page 40) you can omit step 1 from the above procedure.

Stay Arming

The Stay arming mode is normally used when the premises will be occupied. When the system is armed in this mode all Interior detection zones assigned to your partition(s) will be bypassed. Before Stay arming check the following:

- Secure or bypass any perimeter zones that are violated.
- Ensure no perimeter zones are bypassed unintentionally.
- Ensure no perimeter Force Armable zones are violated unintentionally.

To Stay arm the alarm system proceed as follows:

- Enter Access code **???**
- Press **Stay**

The alarm system will arm immediately and the **Armed** light will flash.
- The system is now Stay armed.





If the Quick Arm feature is enabled (see page 40) you can omit step 1 from the above procedure.

If the system is fitted with a *Premier RKP16 Plus* then the **Stay** light will also illuminate when the system is Stay armed.

Cancelling the Arming Process

To cancel the arming process during the exit delay:



- 1 Enter Access code (? ? ? ?)

- 2 Press (Menu) Press (No)

- 3 Arming has been cancelled and the alarm system is now disarmed.



NOTE If the system only has one partition you will not have to perform step 2.

Disarming During Entry

To disarm the alarm system during entry, proceed as follows:



- 1 Enter the premises via the designated entry point, the entry tone will sound. Proceed directly to the remote keypad.

- 2 Enter Access code (? ? ? ?)

- 3 The entry tone will stop and the Armed light will turn off. The alarm system is now disarmed.



NOTE If a valid Access code is not entered before the end of the entry delay, an alarm will occur.

Disarming when not in Entry

To disarm the alarm system when not in entry, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Press (Menu) Press (No)

- 3 The Armed light will turn off. The alarm system is now disarmed.




NOTE If the system only has one partition you will not have to perform step 2.

If the Quick Disarm feature is enabled (see page 40) and the system is Stay armed you can omit step 1 from the above procedure.

Disarming after an Alarm

To disarm the alarm system after an alarm, proceed as follows:



- 1 Enter Access code (? ? ? ?)

- 2 The system is disarmed and the keypads display the source of the alarm.

The system must now be reset before you can arm again, see page 72 for details on resetting alarms.

Auto Stay Arming

If your installer has enabled the Auto Stay feature the system will automatically Stay arm if the entry/exit zone (front door) is not activated whilst attempting to Away arm the system.

To auto Stay arm your alarm system proceed as follows:


- 1 Enter Access code (? ? ? ?)

- 2 Press (Arm) Press (Yes)


The Armed light will flash and the exit tone will sound.
- 3 Do NOT leave the premises during the exit delay. At the end of the exit delay the alarm system will Stay arm.

Changing between Delayed and Instant Stay

When Stay arming the system the delayed zones (front door etc) are normally delayed, i.e., when a delayed zone is violated it will start the entry delay timer. However, it is possible to change the delayed zones to instant when the system is in a Stay armed mode. If a delayed zone is violated when the system is in the "Instant Stay" mode the system will generate an alarm immediately.

To change from Delayed Stay to Instant Stay, proceed as follows:

- 1 Ensure that the system is Stay armed.
- 2 Press and hold the (Stay) key until you hear the confirmation tone.

- 3 The Armed light will flash quickly. The system is Instant Stay armed.



NOTE If the system is fitted with a Premier RKP16 Plus the Instant light will also illuminate.

To change from Instant Stay to Delayed Stay, proceed as follows:

1 Ensure that the system is **Instant Stay** armed.

2 Press and hold the **Stay** key until you hear the confirmation tone.



3 The **Armed** light will flash slowly.
The system is **Delayed Stay** armed.



NOTE If your system is fitted with a *Premier RKP16 Plus* the **Instant** light will go off.

Arming and Disarming Partitions

This section covers arming and disarming partitions. In order to use these procedures the following requirements must be configured:

- The alarm system must be split into one or more partitions.
- Your Access code must be assigned to more than one partition.
- The keypad that you use to operate the alarm system must be assigned to multiple partitions OR your Access code is enabled for Global Access.

Away Arming Partitions

This option allows you to Away arm one or more partitions.

To Away arm selected partitions, proceed as follows:

1 Enter Access code **???**



2 Press **Arm**



3 The **Ready** light will flash quickly.
Press **1** - **4** to select/deselect partitions,
e.g. Press **2** to select Partition 2.



Partition 2 is now selected.

4 Press **Arm**



The **Armed** light will flash and the exit tone will sound.

5 Leave the area being armed, when the partition has armed the exit tone will stop. The selected partition(s) is now **Away** armed.



NOTE If the Quick Arm feature is enabled (see page 40) you can omit step 1 from the above procedure.

Stay Arming Partitions

This option allows you to Stay arm one or more partitions.

To Stay Arm selected partitions, proceed as follows:

1 Enter Access code **???**



2 Press **Stay**



3 The **Ready** light will flash quickly.
Press **1** - **4** to select/deselect partitions,
e.g. Press **1** to select Partition 1.



Partition 1 is now selected.

4 Press **Stay**



The selected partition(s) will arm immediately and the **Armed** light will flash.

5 The selected partition(s) is now **Stay** armed.

Disarming Partitions

This option allows you to disarm one or more partitions.

To disarm selected partitions, proceed as follows:

1 Enter Access code **???**



2 Press **Arm**



3 The **Ready** light will flash quickly.
Press **1** - **4** to select/deselect partitions,
e.g. Press **2** to select Partition 2.



Partition 2 is now selected for disarm.

4 Press **Disarm**



5 The selected partitions are disarmed.

Changing to another Partition


Normally the remote keypad that you use will be assigned to a particular partition and therefore the zone and status lights will indicate information relevant to the assigned partition. However, you can temporarily switch the remote keypad to a different partition so that the zone and status lights indicate the information relevant to the partition that you have selected. Whilst in this mode you can also use your Access code to arm/disarm the partition you have selected (providing you have access to the selected partition).

In order to use the cross partitioning feature, it is recommended that the system is configured as follows:


- Cross partitioning must be enabled (see page 36).
- The user must be assigned to multiple partitions.
- The user should be set for “Local Partition Access Only”, see page 65.
- The remote keypads should only be assigned to a single partition.

To change to another partition, proceed as follows:

1 Press **Arm**



2 Enter partition **① - ④**,
e.g. Press **②** to select Partition 2.



The remote keypad will now indicate information relevant to the selected partition.



NOTE

After changing to the selected partition, the remote keypad will only remain in the selected partition for 10 seconds after the last key press. However if an Access code is entered whilst the remote is in this mode, the remote keypad will remain in the selected partition for 1 minute after the last key press.

Bypassing Zones

Manually Bypassing Zones

Bypassing a zone prevents it from causing an alarm.



NOTE


After manually bypassing a zone, the bypass will remain in place until the zone is manually unbypassed.

The bypass mode will time-out if no key is pressed for 60 seconds.


24 hour zones cannot be unbypassed if they are violated.

To manually bypass zones, proceed as follows:


1 Enter Access code **①①①①**



2 Press **Bypass**



3 The **Ready** light will flash quickly.
Enter the zone number **①②**,
e.g. Enter **①②** to select Zone 2.



4 The selected zone is now bypassed. Repeat step 3 to bypass additional zones.

5 Once the selected zones have been bypassed press:
Yes/Arm to Away arm
Stay to Stay arm
Menu to return to the normal disarmed state



NOTE

If the Quick Bypass feature is enabled (see page 40) you can omit step 1 from the above procedure.

When one or more zones are bypassed the **Ready** light will flash and if the system is fitted with a *Premier RKP8/16 Plus* or LCD remote keypad then the **Bypass** light will also illuminate.

Unbypassing Zones




To manually unbypass zones, perform the manual bypass procedure on a zone that is already bypassed.

- 24 hour zones cannot be unbypassed if they are still violated.
- If the “Reinstate Bypassed Zones on Disarm” option is enabled (see page 36) all zones will automatically be unbypassed each time the system is disarmed.

Group Bypass

The Group Bypass feature allows you to bypass a predefined group of zones. The alarm system has up to four groups, see page 28 on programming bypass groups.

To Bypass a group of zones, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Enter bypass group (1 - 4) followed by (Menu)

- 3 The keypad will display the bypassed zones. If required, zones can be added or removed from the group by entering the required zone number (? ?), e.g. Enter (0 5) to add Zone 5.

- 4 The selected zone is now bypassed. Repeat step 3 to bypass additional zones.
- 5 Once the selected zones have been bypassed press:
 (Yes / Arm) to Away arm
 (Stay) to Stay arm
 (Menu) to return to the normal disarmed state





If the Quick Bypass feature is enabled (see page 40) you can omit step 1 from the above procedure.

When one or more zones are bypassed the **Ready** light will flash and if the system is fitted with a *Premier RKP8/16 Plus* or LCD remote keypad then the **Bypass** light will also illuminate.

Quick Bypass and Arm



The Quick Bypass and Arm feature allows you to Bypass a predefined group of zones and Away or Stay arm the system. The alarm system has up to four groups, see page 28 on programming bypass groups.

To Quick Bypass a group of zones and Away arm, proceed as follows:

- 1 Enter bypass group (1 - 4)

- 2 Press (Arm) Press (Yes)


The **Armed** and **Ready** lights will flash and the exit tone will sound.
- 3 When the exit tone stops, the system is Away armed with the selected group of zones bypassed.

To Quick Bypass a group of zones and Stay arm, proceed as follows:

- 1 Enter bypass group (1 - 4)

- 2 Press (Stay)


The alarm system will arm immediately and the **Armed** and **Ready** lights will flash.
- 3 The system is Stay armed with the selected group of zones bypassed.





The Quick Arm feature must be enabled to use this feature (see page 40).

Reset Alarms

This function is used to reset any standing alarms and service faults. It is also used to reset detectors with a latched alarm indication, e.g., Smoke Detectors.



To Reset Alarms, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Press (Menu) 0 Press (Reset)

- 3 The keypad will bleep and the alarm system will reset all latching detectors and attempt to clear any standing **Alarms** or **Service Faults**.

Last Alarm Log

The control panel has a memory that stores the zones that caused an alarm when the system was last armed.

To view the alarm memory, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Press (Menu) 1


The keypad will display the zones that caused an alarm when the system was last armed.
- 3 Press (Menu) to return to the normal disarmed state.

Service Faults

The response to a Service Fault condition is programmed by the installer but is normally limited to the keypad buzzer. To silence the Service Fault alarm, enter your Access code.

A flashing **Service** light indicates a new fault condition. The alarm system cannot be armed whilst a new fault exists. The **Service** light will remain flashing until the new fault is acknowledged, after which it will revert to a steady yellow and the alarm system can be armed. The **Service** light will remain steady until **all** faults have been cleared.

After a new Service Fault has been acknowledged the **Service** light will revert to steady yellow and the alarm system can be armed. The **Service** light will remain steady yellow until **all** faults have been cleared.

AC Fail and Telephone Line Fault can each have a delay programmed. The **Service** light will turn steady yellow immediately on either of these faults but no Service Fault Alarm (transmission or audible alarm) will occur unless the delay expires.

If your installer has disabled AC fail acknowledgement the **Service** light will flash "rapidly" during an AC fail condition. The system can be armed without requiring acknowledgement of this fault.

Acknowledging a New Service Fault

New service faults can be acknowledged as follows:

- Enter Access code **???**
- Press **Menu** **2**
- Press **Menu** or **Reset** to acknowledge the fault and return to the normal disarmed state.

The keypad will display all Service Faults.

View Service Faults

Standing faults can be viewed as follows:

- Press the **Menu** key followed by the **2** key.

The keypad will display any Service Faults (see tables).

On completion **press** the **Menu** key.

Service Faults Displayed on LED Keypads	
Light	Fault Condition
1	General Warnings Press (Key 1) to view the warning, lights 1-5 will indicate the following:- 1 = AC Fail 2 = Arming Fob has Low Battery 3 = Soak Test Active

2	Telephone Line Fault
3	2-Wire Smoke Alarm
4	Box Tamper & Auxiliary Input: Press 4 to view type, lights 1 - 8 indicate: 1 = Box Tamper 4 = Auxiliary Tamper * 2 = Auxiliary Tamper 5 = Bell Tamper * 3 = Auxiliary PA 6 = Radio Plus Tamper 7 = Low Fob Battery 8 = User Code Tamper * = UK Bell Module
5	Date or Time Lost
6	Zone Tamper/Trouble Press 6 to view zone number
7	Keypad Tamper/Removed Press 7 to view keypad number
8	Equipment Faults Press 8 to view fault type, lights 1 - 8 indicate: 1 = Output 1 Fault 2 = Output 2 Fault 3 = Siren/Bell Fault 4 = 2-Wire Smoke Sensor Fault 5 = Auxiliary Fuse Failed 6 = Battery Fault 7 = Service Timer/Zone Soak Test Failed 8 = Com1 Fault or Fail To Communicate



Service Faults Displayed on LCD Keypads

LCD	Fault Condition
AC Fail	AC Fail
Soak Test Active	One or more zones on soak test
1:Proceed 0:Exit	1 to continue arming 0 to exit arming
Arm Low Fob Bat?	Key fob has a low battery (Message above shown)
User Code Tamper	Shown after invalid user code attempts
Line Fault	Telephone Line Fault
Smoke Alarm (2W)	2-Wire Smoke Alarm
Box/Aux Tamper	Box Tamper
Aux Tamper	Auxiliary Tamper (Aux Input)
Auxiliary Tamper	Auxiliary Tamper (UK Bell Module)
Bell Tamper	Bell Tamper (UK Bell Module)
Aux PA Alarm	Auxiliary PA (Aux Input)
Date/Time Loss	Date or Time Lost
Tamper Zone > 01	Zone Tamper/Trouble
Tamper Keypad > 1	Keypad Tamper/Removed
Output 1 Fault	Output 1 Fault
Output 2 Fault	Output 2 Fault
Siren Fault	Siren/Bell Fault
Smoke Sen. Fault	2-Wire Smoke Sensor Fault
Aux. Fuse Fault	Auxiliary Fuse Failed
Battery Fault	Battery Fault
Service Required	Service Timer/Zone Soak Test Failed
Coms Fault	Com1 Fault or Fail To Communicate

Anti-code Reset

This feature is normally used in the UK where users are not permitted to reset the panel following a communicated alarm. However, the user can reset the panel after entering a unique remote reset number, which is supplied by their installer or ARC.

To perform an Anti-code Reset, proceed as follows:



- 1 Enter Access code (? ? ? ?)

- 2 Press (Menu) (3)

- 3 Contact the ARC to obtain a Anti-code Reset number.
- 4 Enter the Anti-code Reset number given to you by the ARC (? ? ? ?).

If the code is accepted, the keypad will sound an acceptance tone and the system will reset and return to the normal disarmed state.

Toggle Chime On and Off

When a zone is enabled for Chime the keypad will generate a Chime tone every time the zone is violated. This function allows you to turn the Chime feature on and off.



To toggle Chime on and off, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Enter (Menu) (4) Press (Chime)

- 3 If Chime was off, it will turn on and the keypad will sound the Chime tone. If Chime was on, it will turn off and the keypad will sound the acceptance tone.


Change User Code

All users of the alarm system can change their own Access code number.

To change your Access code, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Enter (Menu) (5)

- 3 Enter new code (? ? ? ?)



If the code is 4 or 5 digits press the (Arm/Yes) key to accept.


- 4 Re-enter new code (? ? ? ?)
- 5 The keypad will sound an acceptance tone if the new Access code was accepted. If you hear an error tone (low), please repeat from step 1.

View Log (LCD Only)

The control panel has an Event Log, which stores all system activity i.e., users entering their codes to arm and disarm the system, alarm events, faults etc. Each event is time and date stamped.



To view the Event Log, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Enter (Menu) (6)

- 3
- 4 Press (Left Arrow) to scroll up and down through the log. Press (Menu) to when finished.

Abort Communications

This option aborts any communications to the Alarm Receiving Centre.

To Abort Communications, proceed as follows:

- 1 Enter Access code (? ? ? ?)

- 2 Enter (Menu) (7)

- 3 The keypad will beep and the alarm system will abort all communications to the Alarm Receiving Centre.

6. Specifications

Control Panel

Power Supply

Maximum Current Rating

at -15% (1.95.5Vac)

		Charging @ 300mA
16.5V _{AC} , 25VA transformer:	0.94A _{DC}	0.64A
16.5V _{AC} , 40VA transformer:	1.32A _{DC}	1.02A

Frequency 50/60hz PSU Type A

Ripple: 5%

Standby Battery

Maximum Capacity:	17Ah (See Safety Note 3, 4 & 5)
Recharge Time is dependent on Battery Charge Jumper position:	300mA position 7AH = 24hr 17AH = 56hr 750mA position 7AH = 10hr 17AH = 24hr

Low Voltage Alarm:	10.5V
Deep Discharge Cut-off:	9.5V

EN50131-6

Maximum PSU current for each output = 1amp

Maximum ripple = 0.6V

For input voltages between 90% & 110% the output voltage shall be between 11V & 14V

Electrical

Current Consumption

Quiescent Current:	<50mA
Alarm:	<150mA

Fuses

Mains (Factory Fit 230V _{AC} Transformer):	125mA, 250V, 20mm (See Safety Notes 1 & 2)
Mains (Factory Fit 115V _{AC} Transformer):	250mA, 250V, 20mm (See Safety Notes 1 & 2)
Battery:	2.5A PTC
Auxiliary:	900mA PTC
Siren:	900mA PTC
Data:	900mA PTC

Zones

Number:	8
EOL Resistor Value:	3K3

Panel Outputs

O/P 1 - Supervised:	1A switched to 0V
O/P 2 - Supervised:	1A switched to 0V
O/P 3 - 8:	100mA switched to 0V

Siren Output (Supervised)

Speaker Mode:	Minimum load 4Ω
Bell Mode:	1A switched to 0V

2-Wire Smoke Detectors:

ESL429CT
System Sensor 2100TS

Onboard Communicator

Protocols:

Pulse Format, Express Format, Fast Format, Contact ID, SIA Level 2/3, Pager and Mobile Phone

Dialling Formats:

Pulse or DTMF

REN:

1

Approval:

CTR21, DPT-TE-001

Non Volatile Memory Component

Premier 412, 412 Plus, 816, 816 Plus 24LC128

Premier 832 24LC256

EN50136-1-1 & EN50136-2-3

The inbuilt communicator complies with the requirements of EN50136-2-3, EN50136-1-1 and are suitable for use in systems designed for use with ATS levels 1 or 2 and environmental class 1 or 2 – i.e. systems using notification options up to and including 2B. With the PSTN functioning normally, the ATS will comply with the required performance levels subject to the ARC being suitably equipped.



These units may be used for Downloading, Remote Servicing or SMS text messaging purposes in systems at ALL security grades.

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions: Small Plastic Enclosure 282mm x 225mm x 80mm

Large Plastic Enclosure 305mm x 405mm x 100mm

Large Metal Enclosure 305mm x 405mm x 100mm x 1.2mm steel

Weight

Small Plastic Enclosure 1.78kg

Large Plastic Enclosure 2.6kg

Large Metal Enclosure 5.8kg

Identifying the Control Panel Type

Each PCB has bar code label that includes the product type code and serial number:



Serial Number
Type Code

Type Code	Description
ACA	Premier 412
ACK	Premier 412 with DPT-TE-001 Communicator
ACC	Premier 816
ACL	Premier 816 with DPT-TE-001 Communicator
ACR	Premier 816 with DPT-AS-002 Communicator
ACD	Premier 816 Plus
ACE	Premier 832
ACM	Premier 832 with DPT-TE-001 Communicator
ACQ	Premier 832 with DPT-AS-002 Communicator

Remote Keypads

Type A Non Moveable Device

Electrical

Operating Voltage: 9 - 13.7VDC

Current Consumption

Nominal (model dependant): 10mA
When fully back lit: 200mA

Zone Indicators

Premier RKP4/8/16: LED (4/8/16)
Premier RKP8/16 Plus: LED (8/16)
Premier 32 Character (Standard/Large)
LCD/LCDL/FMK/SMK:

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions:

Premier RKP4/8/16 140mm x 105mm x 35mm
Premier RKP8/16 Plus/LCD/-L/P 145mm x 115mm x 30mm

Packed Weight: 380g

Remote Zone Expander

Electrical

Operating Voltage: 9 - 13.7V_{DC}

Current Consumption

Nominal: 35mA

In Alarm with Speaker: 180mA

Zones

Number: 8
EOL Resistor Value: 3K3

Speaker Output: Minimum load 4Ω

Outputs

O/P 1 & OP 2: 100mA switched to 0V

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions: 145mm x 115mm x 30mm

Packed Weight: 260g approx.

Local Zone Expander

Electrical

Operating Voltage: 9 - 13.7V_{DC}

Current Consumption: 35mA

Connection: Plugs onto control panel

Zones

Number: 8
EOL Resistor Value: 3K3

Environmental

Operating Temperature: -10°C to +55°C
+14°F to +131°F

Maximum Humidity: 95% non-condensing

EMC Environment: Residential/Commercial/Light Industrial or Industrial

Physical

Dimensions: 83mm x 50mm x 12mm

Packed Weight: 50g

Safety Notes

1. Mains voltage is not adjustable when transformer is factory fitted - see label on transformer.
2. Removal of the factory fitted transformer is prohibited and will invalidate the warranty.
3. Only use batteries of the specified type.
4. Dispose of used batteries safely according to the manufacturer's instructions.
5. Locate the battery inside the panel space provided.
6. This equipment is designed for dry indoor use only.

7. When replacing a fuse always observe the specified rating and type - failure to do so is dangerous and will invalidate the warranty. Fuses should comply with IEC 127.
8. The press-seal bag must not be stored inside the panel.

Standards



2004/108/EC (CE directive): Hereby, Texecom declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC.



WEEE Directive: 2002/96/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.

RoHS Directive: 2002/95/EC RoHS Compliant. Hereby, Texecom declares that this device does not contain lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB) or polybrominated diphenyl ethers (PBDE) in more than the percentage specified by EU directive 2002/95/EC, except exemptions stated in EU directive 2002/95/EC annex.

This product is suitable for use in systems designed to comply with EN 50131-1 at grade 2 and environmental class II.

EN 50131-1/3/6 Compliance

In order to comply with the requirements of EN 50131-1, EN 50131-3 and EN 50131-6 the following programming and system configuration must be implemented:

- EN 50131-1 Requirements must be programmed as "Enabled", see page 36.
- The "Permanent Keypad Status Display" option must be programmed to "Disabled" for all remote keypads, see page 40. In addition the "Courtesy Delay" timer must not be set above 180 seconds, see page 34.
- The "Partition Entry Delay" timers must not be programmed above 45 seconds, see page 30.
- The "Partition Bell Delay" timers must not be programmed above 10 minutes, see page 30.
- The "Partition Bell Duration" timers must be programmed between 2 and 15 minutes, see page 30.
- "Quick Arm", "Quick Disarm" and "Quick Bypass" option must be programmed to "Disabled" for all remote keypads, see page 40.
- The "Tamper Alarms Cause a Trouble While Disarmed" option must be "Enabled", see page 35.
- Do not fit more than 10 unpowered detectors per zone.
- Do not fit more than one non-latching powered detector per zone.

- Six digit users codes must be used.
- Do not mix unpowered detectors and non-latching detectors on a zone.
- A Type W warning device must not be used.
- Zones on Type A Keypads MUST not be used in EN50131 systems
- For grade 2 installations a battery standby time of 12 hours is required. In order to comply with this requirement the maximum current that can be drawn from the system is as follows:

Transformer	Standby Battery	Max Current
16.5V _{AC} , 25VA	7.0Ah	600mA
16.5V _{AC} , 40VA	17.0Ah	1.3A

Compliance Label

If the alarm system is programmed to NOT comply with the requirements of EN50131-1 or EN50131-3, or the system is installed to Grade 1 then the compliance label must be removed.

Inhibit functions

For Alarms and Tamper the inhibit function is controlled by the Swinger shutdown counter which is programmable and is defaulted to 3.



NOTE See page 27 & 34 for details.

Minimum Logical Keys

10,000 for 4 digit code
100,000 for 5 digit code
1,000,000 for 6 digit code

The number of disallowed codes

Premier 412 = 0
Premier 816 = 0
Premier 832 = 0



NOTE Dependant on the use of the Black Listed codes function available via Wintex, a maximum of 16 codes may be Black Listed

Warranty

All Texecom products are designed for reliable, trouble free operation. Quality is carefully monitored by extensive computerised testing. As a result the control panel is covered by a two-year warranty against defects in materials or workmanship.

As the control panel is not a complete alarm system but only a part thereof, Texecom cannot accept responsibility or liability for any damages whatsoever based on a claim that the control panel failed to function correctly.

Due to our policy of continuous improvements Texecom reserve the right to change specification without prior notice.

7. Quick Reference Guide

Menu	Function	Page
Programming Zones		
① ①	All Zone Options	25
① ①	Zone Type	25
① ① Null	① ① 24-Hour Tamper	
① ① Delay 1	① ① Trouble	
① ② Delay 2	① ② 24-Hour - Gas	
① ③ Interior Follower	① ③ 24-Hour - Water	
① ④ Interior Instant	① ④ 24-Hour - High Temp	
① ⑤ Perimeter Instant	① ⑤ 24-Hour - Low Temp	
① ⑥ Fire	① ⑥ Momentary Key Switch	
① ⑦ PA Silent	① ⑦ Maintained Key Switch	
① ⑧ PA Audible	① ⑧ Push To Set	
① ⑨ Medical		
① ②	Zone Wiring	26
① Normally Closed	⑤ Single EOL - O/C Tamper	
① Normally Open	⑥ Single EOL - S/C Tamper	
② Single EOL - N/C & N/O	⑦ Double EOL	
③ Single EOL - N/O (Fire)	⑧ Zone Doubled	
④ Single EOL - N/C	⑨ Triple EOL	
① ③	Zone Attributes 1	26
① Enable Instant Internals	⑤ Enable Instant Strobe	
② Enable Bell	⑥ Enable User Chime	
③ Delayed Bell	⑦ Enable Transmission Delay	
④ Pulsed Bell	⑧ Enable Transmission	
① ④	Zone Attributes 2	27
① Enable Manual Bypass	⑤ Enable Cross Zoning	
② Enable Stay Bypass	⑥ Enable Soak Test	
③ Enable Force Arming	⑦ Enable Swinger Shutdown	
④ Quick Response Time	⑧ Enable Double Knock	
① ⑤	Zone Attributes 3	27
① Change to Delay 1 on Stay Arm		
② Change to Follower on Stay Arm		
③ Zone Warning (* Keyswitch is Instant Arming)		
④ Auto Reinstate if Force Armed (* Keyswitch will Stay Arm/Disarm)		
⑤ Disable Keyswitch if Away Armed		
⑥ Disable Exit Faults (* Disabled Auto Arm)		
⑦ Truncate Exit Delay (* Monitor Only)		
⑧ Forced Walk Test		
* Attributes for Key Switch zone types		
① ⑥	Zone Partitions & Groups	27
① Enabled for Partition 1	⑤ Enable for Bypass Group 1	
② Enabled for Partition 2	⑥ Enable for Bypass Group 2	
③ Enabled for Partition 3	⑦ Enable for Bypass Group 3	
④ Enabled for Partition 4	⑧ Enable for Bypass Group 4	
① ⑦	Zone Text	28
① . , ? ! @ " - &	⑦ p q r s 7 P Q R S	
② a b c 2 A B C	⑧ t u v 8 T U V	
③ d e f 3 D E F	⑨ w x y z 9 W X Y Z	
④ g h i 4 G H I	⑩ Space 0 , # *	
⑤ j k l 5 J K L	⬅ Move Left/Right	
⑥ m n o 7 M N O	⌫ Backspace (delete)	

Menu	Function	Page
Programming Partitions		
② ①	Partition Exit Time	30
② ①	Partition Entry Delay 1 Time	30
② ②	Partition Entry Delay 2 Time	30
② ③	Partition Communicator Delay	30
② ④	Partition Bell Delay	30
② ⑤	Part Bell Duration	30
② ⑥	Partition Options	30
① Enable Auto Bypass Mode		
② Stay Armed Exit is Silent		
③ Enable Remote Arming		
④ Enable Remote Disarming		
⑤ Enable Local Exit Tones		
⑥ Stay Armed Entry is Instant		
⑦ Stay Armed Exit is Delayed		
⑧ Only Start Exit when Partition is Ready		
② ⑦	Partition Auto Arm/Disarm	31
① Arm with Control Timer 1	⑤ Disarm with Control Timer 1	
② Arm with Control Timer 2	⑥ Disarm with Control Timer 2	
③ Arm with Control Timer 3	⑦ Disarm with Control Timer 3	
④ Arm with Control Timer 4	⑧ Disarm with Control Timer 4	
② ⑧	Equipment Areas	31
① Auxiliary Input Areas	② Bell Squawk Areas	
① Panel Bell Areas	③ Masked when Armed	
Programming Global Options		
③ ①	System Timers	34
① ① AC Fail Delay	① ⑧ Test Transmission Time	
① ① Line Fault Delay	① ⑨ Courtesy Delay	
① ② Cross Zone Time	① ⑩ Service Timer	
① ③ Zone Soak Test Time	① ① 2-Wire Verified Delay	
① ④ Restore Reporting Delay	① ② Alarm Confirmation Delay	
① ⑤ Output Short Pulse Time	① ③ Activity Time Window	
① ⑥ Zone Response Time	① ④ Poll IP Every	
① ⑦ Transmission Abort		
③ ①	System Counters/Levels	34
① Swinger Shutdown Count	③ Clock Adjustment	
① Panel Speaker Volume	④ Language Selection	
② Chime Volume	⑤ Country Operation Code	
③ ②	System Control Timers	35
③ ③	System Options 1	35
① Clock = Crystal		
② Battery Connection Supervision		
③ Battery Dynamically Load Tested		
④ Panel NVM is Locked		
⑤ Power Savings During AC Mains Failure		
⑥ Line Fault Overrides Bell Delay		
⑦ Two-Wire Smoke Detection on O/P 1		
⑧ Convert Siren Output from Voltage to Speaker Driver		

Menu	Function	Page
③ ④	System Options 2	35
①	Tamper Alarms Cause a Trouble While Disarmed	
②	Tamper Alarms Cause a Trouble While Stay Armed	
③	Defer Reporting of Non-Zone Restorals	
④	Use Delay Timer to Defer Non-Zone Restorals	
⑤	Inhibit Keyswitch Operation Upon EOL Tamper	
⑥	Away Arm Overrides Alarm Transmission Delay	
⑦	Defer Reporting of Zone Restorals	
⑧	Use Delay Timer to Defer Zone Restorals	
③ ⑤	System Options 3	35
①	Away Arm Exit Error Doesn't Sound Bell	
②	Zone Test - Silence on No Violation	
③	Alarm Status Light Indicates Fire	
④	Enable Entry/Exit Tones for Panel Speaker	
⑤	Enable Cross Partitioning	
⑥	Enable EN 50131-1 Requirements	
⑦	Reinstate Bypassed Zones on Disarm	
⑧	Invert Panel Bell/Siren Output	
③ ⑥	Hardware Options	36
①	Panel Output 1 Supervised for Faults	
②	Panel Output 2 Supervised for Faults	
③	Siren/Bell Output Supervised for Faults	
④	Panel Box Tamper Switch Monitored	
⑤	Auxiliary Fuse Supervised for Faults	
⑥	Battery Supervised for Faults	
⑦	AC Mains Supply is Monitored	
⑧	Telephone Line Is Monitored	
③ ⑦	Auxiliary Input Options	36
①	Not Used	
②	Auxiliary Tamper	
③	Remote Reset	
④	Telephone Line Monitor	
⑤	Panic Alarm	
⑥	Silent PA	
⑦	Latched Key switch	
⑧	Momentary Key switch	
③ ⑧ -①	Miscellaneous Options 1	37
①	Enable Bell Squawk on AWAY Arm/Disarm	
②	Enable Bell Squawk on STAY Arm/Disarm	
③	Disable AC Fail Acknowledgement	
④	Disable Open/Close Reporting on STAY Arm	
⑤	Cross/Double Knock Timer is in Minutes	
⑥	Disable Zone Bypass when Armed	
⑦	Activated Zones Cause Alarm during Exit	
⑧	Control Timer 4 Performs Battery Test	
③ ⑧ -②	Miscellaneous Options 2	37
①	Disable Service Fault Acknowledgement	
②	Enable User Reset for Alarms	
③	Disable Online Printing	
④	Enable Bell Module and UK Options	
⑤	Enable DD 243:2002 Options	
⑥	Enable Confirmation after Entry Time-Out	
⑦	Invert Auxiliary Input Operation	
⑧	Auto BST/GMT Time Change	

Menu	Function	Page
③ ⑨	EN50131	38
①	Fob Low Battery Arming	
②	Indicate Zone Soak Test	
③	Soak Test Acknowledgement	
④	Entry Stray Notification	
⑤	Entry Timeout Notification	
⑥	Expander Lost	
⑦	User Code Entry	
⑧	AC & Battery Fail Latch	
Programming Remote Keypads		
④ ①	Keypad Options 1	40
①	Partition 1 Operation	
②	Partition 2 Operation	
③	Partition 3 Operation	
④	Partition 4 Operation	
⑤	Permanent Keypad Status Display	
⑥	Press Any Key for Display	
⑦	Display Zones vs. Partitions	
⑧	Wrong Code Attempts = Code Tamper	
④ ①	Keypad Options 2	40
①	Code Tamper Causes a Tamper Alarm	
②	Keypad Activation of Fire Alarm	
③	Keypad Activation of Medical Alarm	
④	Keypad Activation of PA Alarm	
⑤	Keypad PA Alarm is Silent	
⑥	Quick Arm with Keypad ARM Key	
⑦	Quick Disarm with Keypad DISARM Key	
⑧	Quick Bypass with Keypad BYPASS Key	
④ ②	Keypad Options 3	40
①	Fire Alarm Tones from Keypad	
②	Burglary Alarm Tones from Keypad	
③	Trouble Tones from Keypad	
④	Acceptance Tones from Keypad	
⑤	Error Tones from Keypad	
⑥	Chime Tones from Keypad	
⑦	Entry Tones from Keypad	
⑧	Exit Tones from Keypad	
④ ③	Keypad Options 4	41
①	Enable Keypad Zones (RKP8/16 Plus & Premier LCD/LCDL)	
②	Disable Keypad Lid Tamper	
③	Zone Shift by 4	
④	Zone Shift by 8	
⑤	Zone Shift by 16	
Programming Remote Expanders		
⑤ ①	Expander Partitions	42
①	Partition 1 Operation	
②	Partition 2 Operation	
③	Partition 3 Operation	
④	Partition 4 Operation	
⑤ ①	Expander Tones	42
①	Fire Alarm Tones from Expander	
②	Burglary Alarm Tones from Expander	
③	Trouble Tones from Expander	
④	Acceptance Tones from Expander	

Menu	Function	Page
⑤	Error Tones from Expander	
⑥	Chime Tones from Expander	
⑦	Entry Tones from Expander	
⑧	Exit Tones from Expander	
⑤ ②	Expander Volume Level	42

Menu	Function	Page
Programming System Outputs		
⑥ ①	Panel Outputs	45
⑥ ①	Fast Format Channels	45
⑥ ②	Expander 1 Outputs	45
⑥ ③	Expander 2 Outputs	45
⑥ ④	Expander 3 Outputs	45
⑥ ⑤	Keypad Outputs	45
①	System Output Types	
00	Courtesy	18 Siren/Bell Fault
01	Successful Transmission	19 Smoke Sensor Fault
02	Log 80% Full	20 Auxiliary Fuse Fault
03	Program Mode Selected	21 Latched Battery Fault
04	Download In Progress	22 Service Required/Test Fail
05	Timed Arming Countdown	23 Fail To Communicate
06	Zone Soak Test Active	24 Control Timer 1 Active
07	Zone Soak Test Failed	25 Control Timer 2 Active
08	Latched AC Fail	26 Control Timer 3 Active
09	Telephone Line Fault	27 Control Timer 4 Active
10	Smoke Alarm	28 PC Output 1
11	Box/Auxiliary Tamper	29 PC Output 2
12	Date Time Loss	30 Walk Test
13	Zone Trouble/Tamper	31 Confirmed Alarm
14	Keypad Tamper/Removed	32 ARC 2 Active
15	Service Fault	33 Zones Locked Out
16	Output 1 Fault	34 AC Fail
17	Output 2 Fault	35 Battery Fault
②	Partition Output Types	
00	PA Alarm	19 Bypass
01	Duress Alarm	20 Sensor Reset on Exit
02	Burglar Alarm	21 Sensor Reset on Reset
03	Medical Alarm	22 Single Pulse on Arming
04	24Hr - Water Alarm	23 Double Pulse on Arming
05	24Hr - Gas Alarm	24 Chime
06	24Hr - Low Temp Alarm	25 Door Strike
07	24Hr - High Temp Alarm	26 Cross Zone Time Active
08	Tamper	27 Single Pulse on Disarming
09	Trouble	28 Reset Required
10	Fire	29 Acknowledgement Required
11	Fire Fault	30 Confirmed Alarm
12	Bell	31 Alarm Abort
13	Strobe	32 Away Armed
14	Entry	33 Away Armed/Exit
15	Exit	34 Detector Latch
16	Armed	35 Armed/Alarm
17	Stay Armed	36 Arm Failed
		37 All Armed

Menu	Function	Page
18	Ready	
③	Zone Output Types	33 - 64 Zone Alarm 01 - 32
	01 - 32 Zone Mimic 01 - 32	
	Output Attributes	5 User Test
1	Partition 1	6 Inverted
2	Partition 2	7 Latching
3	Partition 3	8 Pulsed
4	Partition 4	
Programming The Communicator		
⑦ ①	Communicator Options	50
①	Enable On-Board Communicator	
②	Enable DTMF Dialling	
③	Switch to Pulse Dialling after 3 rd Attempt	
④	Enable European Pulse Dialling	
⑤	Enable Auto Test Transmission	
⑥	Enable Cancel Call Waiting	
⑦	Enable Backup to Alarm Receiving Centre	
⑧	Enable Blind Dialling	
⑦ ①	ARC 1 Communicator Menu	50
	Primary and secondary telephone numbers	
①	Account Numbers (partitions 1-4)	
②	Protocol Type:	
①	Disabled	
①	Pulse Format	
②	Express Format	
③	Fast Format/Speech Module	
④	Contact ID	
⑤	SIA Level 2/3	
⑥	Pager	
③	Dial Attempts	
④	Partition Options:	
①	Report for Partition 1	
②	Report for Partition 2	
③	Report for Partition 3	
④	Report for Partition 4	
⑤	Reporting Options:	
①	Priority Alarm and Cancel Events	
②	Alarm and Cancel Events	
③	Open and Close Events	
④	Bypass and Unbypass Events	
⑤	Maintenance Alarm Events	
⑥	Tamper Alarm Events	
⑦	Test Transmission Events	
⑧	Restore Events	
⑥	Pulse Format Options:	
①	Use 1900Hz Carrier	
②	Use 40 PPS Baud Rate	
③	Enable Parity	
④	Use 2 Digit Events	
⑤	Use 2300Hz Handshake	
⑥	Use 2300Hz Kiss-Off	
⑦	Use Fast/Slow Format	
⑦	Fast Format Reporting Channels	
①	Report Channel 1	
②	Report Channel 2	
③	Report Channel 3	
④	Report Channel 4	
⑤	Report Channel 5	

Menu	Function	Page
⑥	Report Channel 6	
⑦	Report Channel 7	
⑧	Report Channel 8	
⑧	Protocol Options:	
①	Disable SIA Modifier Blocks/Enable Speech Module	
②	Disable Events for Each Partition	
③	Pager Terminator = * (Star)	
④	Send Pager Terminator Twice/Send SIA Text	
⑤	Pager DTMF Tones = 500mS	
⑥	Disable Zone Restorals	
⑦	Communication Acknowledgement Tone	
⑧	Connect via IP	
⑦ ②	ARC 2 Communicator Menu	53
⑦ ③	Fast Format Restore Channels	53
①	Report Restore on Channel 1	
②	Report Restore on Channel 2	
③	Report Restore on Channel 3	
④	Report Restore on Channel 4	
⑤	Report Restore on Channel 5	
⑥	Report Restore on Channel 6	
⑦	Report Restore on Channel 7	
⑧	Report Restore on Channel 8	
⑦ ④	Fast Format Open/Close Channels	54
①	Report Open/Close on Channel 1	
②	Report Open/Close on Channel 2	
③	Report Open/Close on Channel 3	
④	Report Open/Close on Channel 4	
⑤	Report Open/Close on Channel 5	
⑥	Report Open/Close on Channel 6	
⑦	Report Open/Close on Channel 7	
⑧	Report Open/Close on Channel 8	
⑦ ⑤	Cancel Call Waiting	54
Programming Download Options		
⑦ ⑥	Download Menu	55
⑩	Download Options:	
①	Enable Attended Download	
②	Enable Unattended Call Back	
③	Enable 2-Call Answer Phone Defeat	
④	Restrict Download when Armed	
⑤	Download when Part Armed	
⑥	Disconnect Telephone Line	
①	Download Telephone No	
②	UDL Password	
③	Call Back Attempts	
④	Ring Count	
⑤	Com1 Device Type	
⑥	ComIP/SMG Address and Port	
⑦	ComIP Gateway	
⑧	ComIP Subnet Mask	
⑨	Com2 Device Type	
⑩	Chiron Iris Data Setup	
①	Access Point Name	
②	User Name	
③	Password	
Programming Reporting Codes		
⑦ ⑦	Zone Alarm/Restore Codes	61

Menu	Function	Page
⑦ ⑧	Zone Bypass/Unbypass Codes	61
⑦ ⑨	Non Zone Alarm/Restore Codes	61
Programming Users		
⑧ ⑩	Program User	64
⑧ ①	User Options 1	64
①	Enable for Partition 1	
②	Enable for Partition 2	
③	Enable for Partition 3	
④	Enable for Partition 4	
⑤	Allow Arming	
⑥	Allow Bypassing	
⑦	Allow Disarming	
⑧	Allow User Functions	
⑧ ②	User Options 2	64
①	Enable One Time Use Access Code	
②	Time Lock Code with Control Timer 1	
③	Enable Open Reporting	
④	Enable Close Reporting	
⑤	Enable User as Duress Code	
⑥	Activate Door Strike Output	
⑦	Allow Global Bell/Sounder Silence	
⑧	Disable Remote Access	
⑧ ③	User Options 3	65
①	Allow Engineer Code Programming	
②	Allow NVM Locking	
③	Allow Engineer Programming	
④	Allow Test Call Transmission	
⑤	Allow Alarm/Fault Acknowledgement	
⑥	Allow User Programming	
⑦	Allow User Code Programming	
⑧	Local Partition Access Only	
⑧ ④	User Text	65
①	. , ? ! 1 @ " ' - &	⑦ p q r s 7 P Q R S
②	a b c 2 A B C	⑧ t u v 8 T U V
③	d e f 3 D E F	⑨ w x y z 9 W X Y Z
④	g h i 4 G H I	⑩ Space 0 , # *
⑤	j k l 5 J K L	⬅ Move Left/Right
⑥	m n o 7 M N O	⌫ Backspace (delete)
⑧ ⑤	Program Standard Users	65
⑧ ⑥	Default ALL Users	65
System Tests and Utilities		
⑨ ⑩	Walk Test	67
⌫	Clears previously tested zones	
⑨ ①	Test Speakers and Outputs	67
①	Test Speakers	④ Test Outputs
②	Test Bells	⑤ Test LCD Display
③	Test Strobes	
⑨ ②	Send Test Call	67
⑨ ③	Enable Remote/Engineer Access	67
⑨ ④	Start Call Back	67
⑨ ⑤	Program Time	67
⑨ ⑥	Program Date	67

Menu	Function	Page
⑨ ⑦	Program Banner Text	67
① .,?!@ "- &	⑦ p q r s 7 P Q R S	
② a b c 2 A B C	⑧ t u v 8 T U V	
③ d e f 3 D E F	⑨ w x y z 9 W X Y Z	
④ g h i 4 G H I	⑩ Space 0 , # *	
⑤ j k l 5 J K L	↔ Move Left/Right	
⑥ m n o 7 M N O	⏮ Backspace (delete)	
⑨ ⑧	Print 100 Events	67
⑨ ⑨	Log Off Engineer	67

Service Faults Displayed on LED Keypads	
Light	Fault Condition
1	General Warnings Press ① to view type, lights 1 - 5 indicate: 1 = AC Fail 2 = Arming Fob has Low Battery 3 = Soak Test Active
2	Telephone Line Fault
3	2-Wire Smoke Alarm
4	Box Tamper & Auxiliary Input: Press ④ to view type, lights 1 - 5 indicate: 1 = Box Tamper 4 = Auxiliary Tamper 2 = Auxiliary Tamper 5 = Bell Tamper 3 = Auxiliary PA 6 = RadioPlus Tamper 7 = Low Fob Battery detected
5	Date or Time Lost
6	Zone Tamper/Trouble Press ⑥ to view zone number
7	Keypad Tamper/Removed Press ⑦ to view keypad number
8	Equipment Faults Press ⑧ to view fault type, lights 1 - 8 indicate: 1 = Output 1 Fault 2 = Output 2 Fault 3 = Siren/Bell Fault 4 = 2-Wire Smoke Sensor Fault 5 = Auxiliary Fuse Failed 6 = Battery Fault 7 = Service Timer/Zone Soak Test Failed 8 = Com1 Fault or Fail To Communicate

Service Faults Displayed on LCD Keypads	
LCD	Fault Condition
AC Fail	AC Fail
Line Fault	Telephone Line Fault
Smoke Alarm (2W)	2-Wire Smoke Alarm
Box/Aux Tamper	Box Tamper
Aux Tamper	Auxiliary Tamper (Aux Input)
Auxiliary Tamper	Auxiliary Tamper (UK Bell Module)
Bell Tamper	Bell Tamper (UK Bell Module)
Aux PA Alarm	Auxiliary PA (Aux Input)
Date/Time Loss	Date or Time Lost
Tamper Zone > 01	Zone Tamper/Trouble
Tamper Keypad > 1	Keypad Tamper/Removed
Output 1 Fault	Output 1 Fault
Output 2 Fault	Output 2 Fault
Siren Fault	Siren/Bell Fault
Smoke Sen. Fault	2-Wire Smoke Sensor Fault
Aux. Fuse Fault	Auxiliary Fuse Failed
Battery Fault	Battery Fault
Service Required	Service Timer/Zone Soak Test Failed
Coms Fault	Com1 Fault or Fail To Communicate
User Functions	
Enter User Code ? ? ? ? followed by	
Menu ①	Reset Alarm/Troubles
Menu ①	View Last Alarm
Menu ②	View/Acknowledge Service Faults
Menu ③	Anti-code Remote Reset
Menu ④	Toggle Chime On and Off
Menu ⑤	Change Own Passcode
Menu ⑥	View Event Log (LCD Only)
Menu ⑦	Abort Communications
Menu ⑨	Select User Programming Mode

8. Standard Defaults & Programming Records

Installation Details

Customer: _____

Address: _____

Telephone: _____ Fax: _____

Email: _____

Alarm Receiving Centre 1:

Alarm Receiving Centre 2:

Installation Date:

Zone Details

Zone	Location	Zone	Location
01		17	
02		18	
03		19	
04		20	
05		21	
06		22	
07		23	
08		24	
09		25	
10		26	
11		27	
12		28	
13		29	
14		30	
15		31	
16		32	

Programming Worksheets & Defaults

These worksheets and defaults apply to the following control panels:

- Premier 412/816 - Software Version 12.x
- Premier 832 - Software Version 12.x

Zone Programming						
Menu: ① ①		Zone Types				Page 24
Zone	Type	Default	Zone	Type	Default	Zone Types
01	[] []	01 (Delay 1)	17	[] []	00 (Null)	00: Null 01: Delay 1 02: Delay 2 03: Interior Follower 04: Interior Instant 05: Perimeter Instant 06: Fire 07: PA Silent 08: PA Audible 09: Medical 10: 24-Hour Tamper 11: Trouble 12: 24-Hour - Gas 13: 24-Hour - Water 14: 24-Hour - High Temp 15: 24-Hour - Low Temp 16: Momentary Keyswitch 17: Maintained Keyswitch 18: Push To Set
02	[] []	03 (Interior Follower)	18	[] []	00 (Null)	
03	[] []	05 (Perimeter Instant)	19	[] []	00 (Null)	
04	[] []	05 (Perimeter Instant)	20	[] []	00 (Null)	
05	[] []	05 (Perimeter Instant)	21	[] []	00 (Null)	
06	[] []	05 (Perimeter Instant)	22	[] []	00 (Null)	
07	[] []	05 (Perimeter Instant)	23	[] []	00 (Null)	
08	[] []	05 (Perimeter Instant)	24	[] []	00 (Null)	
09	[] []	00 (Null)	25	[] []	00 (Null)	
10	[] []	00 (Null)	26	[] []	00 (Null)	
11	[] []	00 (Null)	27	[] []	00 (Null)	
12	[] []	00 (Null)	28	[] []	00 (Null)	
13	[] []	00 (Null)	29	[] []	00 (Null)	
14	[] []	00 (Null)	30	[] []	00 (Null)	
15	[] []	00 (Null)	31	[] []	00 (Null)	
16	[] []	00 (Null)	32	[] []	00 (Null)	
Menu: ① ②		Zone Wiring				Page 26
Zone	Type	Default	Zone	Type	Default	Wiring Types
01	[]	0 (Normally Closed)	17	[]	0 (Normally Closed)	0: Normally Closed 1: Normally Open 2: Single EOL - N/C & N/O (Burglary) 3: Single EOL - N/O (Fire) 4: Single EOL - N/C 5: Single EOL - O/C Tamper 6: Single EOL - S/C Tamper 7: Double EOL 8: Zone Doubled
02	[]	0 (Normally Closed)	18	[]	0 (Normally Closed)	
03	[]	0 (Normally Closed)	19	[]	0 (Normally Closed)	
04	[]	0 (Normally Closed)	20	[]	0 (Normally Closed)	
05	[]	0 (Normally Closed)	21	[]	0 (Normally Closed)	
06	[]	0 (Normally Closed)	22	[]	0 (Normally Closed)	
07	[]	0 (Normally Closed)	23	[]	0 (Normally Closed)	
08	[]	0 (Normally Closed)	24	[]	0 (Normally Closed)	
09	[]	0 (Normally Closed)	25	[]	0 (Normally Closed)	
10	[]	0 (Normally Closed)	26	[]	0 (Normally Closed)	
11	[]	0 (Normally Closed)	27	[]	0 (Normally Closed)	
12	[]	0 (Normally Closed)	28	[]	0 (Normally Closed)	
13	[]	0 (Normally Closed)	29	[]	0 (Normally Closed)	
14	[]	0 (Normally Closed)	30	[]	0 (Normally Closed)	
15	[]	0 (Normally Closed)	31	[]	0 (Normally Closed)	
16	[]	0 (Normally Closed)	32	[]	0 (Normally Closed)	

Menu: ① ③ Zone Attributes 1 Page 26								
Zone	Enable Instant Internals 1	Enable Bell 2	Delayed Bell 3	Pulsed Bell 4	Enable Instant Strobe 5	Enable User Chime 6	Enable Transmission Delay 7	Enable Transmission 8
01	[]	[]	[]	[]	[]	[]	[]	[]
02	[]	[]	[]	[]	[]	[]	[]	[]
03	[]	[]	[]	[]	[]	[]	[]	[]
04	[]	[]	[]	[]	[]	[]	[]	[]
05	[]	[]	[]	[]	[]	[]	[]	[]
06	[]	[]	[]	[]	[]	[]	[]	[]
07	[]	[]	[]	[]	[]	[]	[]	[]
08	[]	[]	[]	[]	[]	[]	[]	[]
09	[]	[]	[]	[]	[]	[]	[]	[]
10	[]	[]	[]	[]	[]	[]	[]	[]
11	[]	[]	[]	[]	[]	[]	[]	[]
12	[]	[]	[]	[]	[]	[]	[]	[]
13	[]	[]	[]	[]	[]	[]	[]	[]
14	[]	[]	[]	[]	[]	[]	[]	[]
15	[]	[]	[]	[]	[]	[]	[]	[]
16	[]	[]	[]	[]	[]	[]	[]	[]
17	[]	[]	[]	[]	[]	[]	[]	[]
18	[]	[]	[]	[]	[]	[]	[]	[]
19	[]	[]	[]	[]	[]	[]	[]	[]
20	[]	[]	[]	[]	[]	[]	[]	[]
21	[]	[]	[]	[]	[]	[]	[]	[]
22	[]	[]	[]	[]	[]	[]	[]	[]
23	[]	[]	[]	[]	[]	[]	[]	[]
24	[]	[]	[]	[]	[]	[]	[]	[]
25	[]	[]	[]	[]	[]	[]	[]	[]
26	[]	[]	[]	[]	[]	[]	[]	[]
27	[]	[]	[]	[]	[]	[]	[]	[]
28	[]	[]	[]	[]	[]	[]	[]	[]
29	[]	[]	[]	[]	[]	[]	[]	[]
30	[]	[]	[]	[]	[]	[]	[]	[]
31	[]	[]	[]	[]	[]	[]	[]	[]
32	[]	[]	[]	[]	[]	[]	[]	[]
= Default setting is ON = Default setting is OFF								

Menu: ① ④		Zone Attributes 2						Page 26
Zone	Enable Manual Bypass 1	Enable Stay Bypass 2	Enable Force Arming 3	Quick Response Time 4	Enable Cross Zoning 5	Enable Soak Test 6	Enable Swinger Shutdown 7	Enable Double Knock 8
01	[]	[]	[]	[]	[]	[]	[]	[]
02	[]	[]	[]	[]	[]	[]	[]	[]
03	[]	[]	[]	[]	[]	[]	[]	[]
04	[]	[]	[]	[]	[]	[]	[]	[]
05	[]	[]	[]	[]	[]	[]	[]	[]
06	[]	[]	[]	[]	[]	[]	[]	[]
07	[]	[]	[]	[]	[]	[]	[]	[]
08	[]	[]	[]	[]	[]	[]	[]	[]
09	[]	[]	[]	[]	[]	[]	[]	[]
10	[]	[]	[]	[]	[]	[]	[]	[]
11	[]	[]	[]	[]	[]	[]	[]	[]
12	[]	[]	[]	[]	[]	[]	[]	[]
13	[]	[]	[]	[]	[]	[]	[]	[]
14	[]	[]	[]	[]	[]	[]	[]	[]
15	[]	[]	[]	[]	[]	[]	[]	[]
16	[]	[]	[]	[]	[]	[]	[]	[]
17	[]	[]	[]	[]	[]	[]	[]	[]
18	[]	[]	[]	[]	[]	[]	[]	[]
19	[]	[]	[]	[]	[]	[]	[]	[]
20	[]	[]	[]	[]	[]	[]	[]	[]
21	[]	[]	[]	[]	[]	[]	[]	[]
22	[]	[]	[]	[]	[]	[]	[]	[]
23	[]	[]	[]	[]	[]	[]	[]	[]
24	[]	[]	[]	[]	[]	[]	[]	[]
25	[]	[]	[]	[]	[]	[]	[]	[]
26	[]	[]	[]	[]	[]	[]	[]	[]
27	[]	[]	[]	[]	[]	[]	[]	[]
28	[]	[]	[]	[]	[]	[]	[]	[]
29	[]	[]	[]	[]	[]	[]	[]	[]
30	[]	[]	[]	[]	[]	[]	[]	[]
31	[]	[]	[]	[]	[]	[]	[]	[]
32	[]	[]	[]	[]	[]	[]	[]	[]
= Default setting is ON								
= Default setting is OFF								

Menu: ① ⑤		Zone Attributes 3						Page 27
Zone	Change to Delay 1 on Stay Arm 1	Change to Follower on Stay Arm 2	* Zone Warning 3	* Auto Reinstate if Force Armed 4	Disable Keyswitch if Away Armed 5	* Disable Exit Faults 6	Truncate Exit Delay 7	Forced Walk Test 8
01	[]	[]	[]	[]	[]	[]	[]	[]
02	[]	[]	[]	[]	[]	[]	[]	[]
03	[]	[]	[]	[]	[]	[]	[]	[]
04	[]	[]	[]	[]	[]	[]	[]	[]
05	[]	[]	[]	[]	[]	[]	[]	[]
06	[]	[]	[]	[]	[]	[]	[]	[]
07	[]	[]	[]	[]	[]	[]	[]	[]
08	[]	[]	[]	[]	[]	[]	[]	[]
09	[]	[]	[]	[]	[]	[]	[]	[]
10	[]	[]	[]	[]	[]	[]	[]	[]
11	[]	[]	[]	[]	[]	[]	[]	[]
12	[]	[]	[]	[]	[]	[]	[]	[]
13	[]	[]	[]	[]	[]	[]	[]	[]
14	[]	[]	[]	[]	[]	[]	[]	[]
15	[]	[]	[]	[]	[]	[]	[]	[]
16	[]	[]	[]	[]	[]	[]	[]	[]
17	[]	[]	[]	[]	[]	[]	[]	[]
18	[]	[]	[]	[]	[]	[]	[]	[]
19	[]	[]	[]	[]	[]	[]	[]	[]
20	[]	[]	[]	[]	[]	[]	[]	[]
21	[]	[]	[]	[]	[]	[]	[]	[]
22	[]	[]	[]	[]	[]	[]	[]	[]
23	[]	[]	[]	[]	[]	[]	[]	[]
24	[]	[]	[]	[]	[]	[]	[]	[]
25	[]	[]	[]	[]	[]	[]	[]	[]
26	[]	[]	[]	[]	[]	[]	[]	[]
27	[]	[]	[]	[]	[]	[]	[]	[]
28	[]	[]	[]	[]	[]	[]	[]	[]
29	[]	[]	[]	[]	[]	[]	[]	[]
30	[]	[]	[]	[]	[]	[]	[]	[]
31	[]	[]	[]	[]	[]	[]	[]	[]
32	[]	[]	[]	[]	[]	[]	[]	[]
= Default setting is ON = Default setting is OFF * = Attributes 3, 4 and 6 change when zone is programmed as a key switch type: 3 = Key Switch is Instant Arming 4 = Key Switch will Stay Arm/Disarm 6 = Disable Auto Arm								

Menu: ①⑥		Zone Partitions & Bypass Groups							Page 28
Zone	Enabled for Partition 1	Enabled for Partition 2	Enabled for Partition 3	Enabled for Partition 4	Enabled for Bypass Group 1	Enabled for Bypass Group 2	Enabled for Bypass Group 3	Enabled for Bypass Group 4	
1	2	3	4	5	6	7	8		
01	[]	[]	[]	[]	[]	[]	[]	[]	
02	[]	[]	[]	[]	[]	[]	[]	[]	
03	[]	[]	[]	[]	[]	[]	[]	[]	
04	[]	[]	[]	[]	[]	[]	[]	[]	
05	[]	[]	[]	[]	[]	[]	[]	[]	
06	[]	[]	[]	[]	[]	[]	[]	[]	
07	[]	[]	[]	[]	[]	[]	[]	[]	
08	[]	[]	[]	[]	[]	[]	[]	[]	
09	[]	[]	[]	[]	[]	[]	[]	[]	
10	[]	[]	[]	[]	[]	[]	[]	[]	
11	[]	[]	[]	[]	[]	[]	[]	[]	
12	[]	[]	[]	[]	[]	[]	[]	[]	
13	[]	[]	[]	[]	[]	[]	[]	[]	
14	[]	[]	[]	[]	[]	[]	[]	[]	
15	[]	[]	[]	[]	[]	[]	[]	[]	
16	[]	[]	[]	[]	[]	[]	[]	[]	
17	[]	[]	[]	[]	[]	[]	[]	[]	
18	[]	[]	[]	[]	[]	[]	[]	[]	
19	[]	[]	[]	[]	[]	[]	[]	[]	
20	[]	[]	[]	[]	[]	[]	[]	[]	
21	[]	[]	[]	[]	[]	[]	[]	[]	
22	[]	[]	[]	[]	[]	[]	[]	[]	
23	[]	[]	[]	[]	[]	[]	[]	[]	
24	[]	[]	[]	[]	[]	[]	[]	[]	
25	[]	[]	[]	[]	[]	[]	[]	[]	
26	[]	[]	[]	[]	[]	[]	[]	[]	
27	[]	[]	[]	[]	[]	[]	[]	[]	
28	[]	[]	[]	[]	[]	[]	[]	[]	
29	[]	[]	[]	[]	[]	[]	[]	[]	
30	[]	[]	[]	[]	[]	[]	[]	[]	
31	[]	[]	[]	[]	[]	[]	[]	[]	
32	[]	[]	[]	[]	[]	[]	[]	[]	
= Default setting is ON									
= Default setting is OFF									

Menu: ① ⑦		Zone Text (LCD Only)		Page 27
Zone	Text	Zone	Text	Editing Keys
01		17		① . , ? ! 1 @ " - &
02		18		② a b c 2 A B C
03		19		③ d e f 3 D E F
04		20		④ g h I 4 G H I
05		21		⑤ j k l 5 J K L
06		22		⑥ m n o 7 M N O
07		23		⑦ p q r s 7 P Q R S
08		24		⑧ t u v 8 T U V
09		25		⑨ w x y z 9 W X Y Z
10		26		⑩ Space 0 , # *
11		27		↔ Move Left/Right
12		28		⏮ Backspace (delete)
13		29		
14		30		
15		31		
16		32		

Partition Programming

Menus: ②① - ②⑤

Partition Timers

Page 29

Partition Timer	1	2	3	4	Default
②① Exit Time	[][][]	[][][]	[][][]	[][][]	020 Seconds
②① Entry Delay 1	[][][]	[][][]	[][][]	[][][]	015 Seconds
②② Entry Delay 2	[][][]	[][][]	[][][]	[][][]	030 Seconds
②③ Comms Delay	[][][]	[][][]	[][][]	[][][]	000 Minutes
②④ Bell Delay	[][][]	[][][]	[][][]	[][][]	000 Minutes
②⑤ Bell Duration	[][][]	[][][]	[][][]	[][][]	015 Minutes

Menu: ②⑥

Partition Options

Page 30

Partition	Enable Auto Bypass Mode	Stay Armed Exit is Silent	Enable Remote Arming	Enable Remote Disarming	Enable Local Exit Tones	Stay Armed Entry is Instant	Stay Armed Exit is Delayed	Only Start Exit when Partition is Ready
	1	2	3	4	5	6	7	8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]

Menu: ②⑦

Partition Auto Arm/Disarm

Page 30

Partition	Auto Arm with Control Timer 1	Auto Arm with Control Timer 2	Auto Arm with Control Timer 3	Auto Arm with Control Timer 4	Auto Disarm with Control Timer 1	Auto Disarm with Control Timer 2	Auto Disarm with Control Timer 3	Auto Disarm with Control Timer 4
	1	2	3	4	5	6	7	8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]

Partition Programming

Menu: ②⑧ Equipment Areas Page 30				
Options	Partitions			
	1	2	3	4
0: Auxiliary Input Areas	[]	[]	[]	[]
1: Panel Bell Areas	[]	[]	[]	[]
2: Bell Squawk Areas	[]	[]	[]	[]

Global Programming

Menu: ③① Global System Timers Page 33					
Timer	Value	Default	Timer	Value	Default
00: AC Fail Delay	[] [] []	001 Minutes	08: Test Transmission Time	[] [] []	024 Hours
01: Line Fault Delay	[] [] []	001 Seconds	09: Courtesy Delay	[] [] []	060 Seconds
02: Cross Zone Time	[] [] []	030 Seconds	10: Service Timer	[] [] []	000 Weeks
03: Zone Soak Test Time	[] [] []	014 Days	11: 2-Wire Verified Delay	[] [] []	000 Seconds
04: Restore Reporting Delay	[] [] []	030 Minutes	12: Alarm Confirmation Delay	[] [] []	045 Minutes
05: Output Short Pulse Time	[] [] []	050 x 100mS	13: Activity Time Window	[] [] []	048 Hours
06: Zone Response Time	[] [] []	010 x 80mS	14: Poll IP Every	[] [] []	000 Minutes
07: Transmission Abort	[] [] []	180 Seconds			

Menu: ③① Global Counter/Levels Page 34					
Counter/Level	Value	Default	Counter/Level	Value	Default
0: Swinger Shutdown Count	[] [] []	003	2: Chime Volume	[]	7
1: Panel Speaker Volume	[]	4	3: Clock Adjustment	[] []	50

Menu: ③② Control Timers Page 34					
Timer	ON/OFF Time		Days of Operation		
1	ON:	[] [] [] [] 00:00	ON Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
	OFF:	[] [] [] [] 00:00	OFF Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
2	ON:	[] [] [] [] 00:00	ON Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
	OFF:	[] [] [] [] 00:00	OFF Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
3	ON:	[] [] [] [] 00:00	ON Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
	OFF:	[] [] [] [] 00:00	OFF Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
4	ON:	[] [] [] [] 00:00	ON Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None
	OFF:	[] [] [] [] 00:00	OFF Time:	Su[] Mo[] Tu[] We[] Th[] Fr[] Sa[]	None

Menu: ③③ System Options 1 Page 35							
Clock = Crystal	Battery Connection Supervision	Battery Dynamically Load Tested	Panel NVM is Locked	Power Savings During AC Mains Failure	Line Fault Overrides Bell Delay	2-Wire Smoke Detection on O/P 1	Convert Siren Output from Voltage to Speaker Driver
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Menu: ③④ System Options 2 Page 35							
Tamper Alarms Cause a Trouble While Disarmed	Tamper Alarms Cause a Trouble While Stay Armed	Defer Reporting of Non-Zone Restorals	Use Delay Timer to Defer Non-Zone Restorals	Inhibit Keyswitch Operation on EOL Tamper	Away Arm Overrides Alarm Tx Delay	Defer Reporting of Zone Restorals	Use Delay Timer to Defer Zone Restorals
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Global Programming

Menu: ③ ⑤

System Options 3

Page 35

Away Arm Exit Error Doesn't Sound Bell	Zone Test - Silence on No Violation	Alarm Status Light Indicates Fire	Enable Entry/Exit Tones for Panel Speaker	Enable Cross Partitioning	Enable EN 50131-1 Requirements	Reinstate Bypassed Zones on Disarm	Invert Panel Siren Output
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Menu: ③ ⑥

Hardware Options

Page 36

Panel Output 1 Supervised for Faults	Panel Output 2 Supervised for Faults	Siren/Bell O/P Supervised for Faults	Panel Box Tamper Switch Monitored	Auxiliary Fuse Supervised for Faults	Battery Supervised for Faults	AC Mains Supply is Monitored	Telephone Line Is Monitored
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Menu: ③ ⑦

Auxiliary Input

Page 36

Value	Default	Types
[]	0	0: Not Used; 1: Auxiliary Tamper; 2: Remote Reset; 3: Line Fault; 4: Panic Alarm; 5: Silent PA; 6: Latched Key Switch; 7: Momentary Key Switch

Menu: ③ ⑧

Miscellaneous Options 1

Page 37

Enable Bell Squawk on AWAY Arm/Disarm	Enable Bell Squawk on STAY Arm/Disarm	Disable AC Fail Ack.	Disable Open/Close Reporting on STAY Arm	Cross/Double Knock Timer is in Minutes	Disable Zone Bypass when Armed	Activated Zones Cause Alarm during Exit	Control Timer 4 Performs Battery Test
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Menu: ③ ⑨

Miscellaneous Options 2

Page 37

Disable Service Fault Ack.	Enable User Reset for Alarms	Disable On-line Printing	Enable UK Bell Module	Enable DD243: 2002 Options	Enable Confirmation after Entry Time-Out	Invert Auxiliary Input Operation	Auto BST/GMT Time Change
1	2	3	4	5	6	7	8
[]	[]	[]	[]	[]	[]	[]	[]

Remote Keypad Programming

Menu: ④ ⑩

Remote Keypad Options 1

Page 40

Keypad	Partition 1 Operation	Partition 2 Operation	Partition 3 Operation	Partition 4 Operation	Permanent Keypad Status Display	Press any Key for Display	Display Zones vs. Partitions	Wrong Code Attempts = Code Tamper
	1	2	3	4	5	6	7	8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]
5	[]	[]	[]	[]	[]	[]	[]	[]
6	[]	[]	[]	[]	[]	[]	[]	[]

Remote Keypad Programming

Menu: ④①

Remote Keypad Options 2

Page 39

Keypad	Code Tamper Causes a Tamper Alarm 1	Keypad Activation of Fire Alarm 2	Keypad Activation of Medical Alarm 3	Keypad Activation of PA Alarm 4	Keypad PA Alarm is Silent 5	Quick Arm with Keypad ARM Key 6	Quick Disarm with Keypad DISARM Key 7	Quick Bypass with Keypad BYPASS Key 8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]
5	[]	[]	[]	[]	[]	[]	[]	[]
6	[]	[]	[]	[]	[]	[]	[]	[]

Menu: ④②

Remote Keypad Options 3

Page 40

Keypad	Fire Alarm Tones from Keypad 1	Burglary Alarm Tones from Keypad 2	Trouble Tones from Keypad 3	Acceptance Tones from Keypad 4	Error Tones from Keypad 5	Chime Tones from Keypad 6	Entry Tones from Keypad 7	Exit Tones from Keypad 8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]
5	[]	[]	[]	[]	[]	[]	[]	[]
6	[]	[]	[]	[]	[]	[]	[]	[]

Menu: ④③

Remote Keypad Options 4

Page 41

Keypad	Enable Keypad Zones 1	Disable Keypad Lid Tamper 2	Zone Shift by 4 3	Zone Shift by 8 4	Zone Shift by 16 5	Reserved 6	Reserved 7	Reserved 8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]
4	[]	[]	[]	[]	[]	[]	[]	[]
5	[]	[]	[]	[]	[]	[]	[]	[]
6	[]	[]	[]	[]	[]	[]	[]	[]

Expander Programming

Menu: ⑤①

Expander Partitions

Page 42

Exp.	Partition 1 1	Partition 2 2	Partition 3 3	Partition 4 4	Reserved 5	Reserved 6	Reserved 7	Reserved 8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]

Expander Programming

Menu: (5)(1)

Expander Tones

Page 42

Exp.	Fire Alarm Tones from Expander 1	Burglary Alarm Tones from Expander 2	Trouble Tones from Expander 3	Acceptance Tones from Expander 4	Error Tones from Expander 5	Chime Tones from Expander 6	Entry Tones from Expander 7	Exit Tones from Expander 8
1	[]	[]	[]	[]	[]	[]	[]	[]
2	[]	[]	[]	[]	[]	[]	[]	[]
3	[]	[]	[]	[]	[]	[]	[]	[]

Menu: (5)(2)

Expander Volume

Page 42

Exp. 1	[]	Default 4	Exp. 2	[]	Default 4	Exp. 3	[]	Default 4
--------	-----	-----------	--------	-----	-----------	--------	-----	-----------

Output Programming

Menu: (6)(0)

Panel Outputs

Page 45

Output	Group & Type	Default	Part. 1 1	Part. 2 2	Part. 3 3	Part. 4 4	Test 5	Invert 6	Latch 7	Pulsed 8
1	[]:[] [] []	2:12	[]	[]	[]	[]	[]	[]	[]	[]
2	[]:[] [] []	2:13	[]	[]	[]	[]	[]	[]	[]	[]
3	[]:[] [] []	2:10	[]	[]	[]	[]	[]	[]	[]	[]
4	[]:[] [] []	2:01	[]	[]	[]	[]	[]	[]	[]	[]
5	[]:[] [] []	2:02	[]	[]	[]	[]	[]	[]	[]	[]
6	[]:[] [] []	2:16	[]	[]	[]	[]	[]	[]	[]	[]
7	[]:[] [] []	2:31	[]	[]	[]	[]	[]	[]	[]	[]
8	[]:[] [] []	2:30	[]	[]	[]	[]	[]	[]	[]	[]

Menu: (6)(1)

Fast Format/Speech Channels

Page 45

Channel	Group & Type	Default	Part. 1 1	Part. 2 2	Part. 3 3	Part. 4 4	Test 5	Invert 6	Latch 7	Pulsed 8
1	[]:[] [] []	2:10	[]	[]	[]	[]	[]	[]	[]	[]
2	[]:[] [] []	2:00	[]	[]	[]	[]	[]	[]	[]	[]
3	[]:[] [] []	2:02	[]	[]	[]	[]	[]	[]	[]	[]
4	[]:[] [] []	2:16	[]	[]	[]	[]	[]	[]	[]	[]
5	[]:[] [] []	2:31	[]	[]	[]	[]	[]	[]	[]	[]
6	[]:[] [] []	2:17	[]	[]	[]	[]	[]	[]	[]	[]
7	[]:[] [] []	2:01	[]	[]	[]	[]	[]	[]	[]	[]

Output Programming

8	[]:[] []	2:30	[]	[]	[]	[]	[]	[]	[]	[]
Menu: ⑥ ② Expander Outputs Page 45										
Exp./OP	Group & Type	Default	Part. 1 1	Part. 2 2	Part. 3 3	Part. 4 4	Test 5	Invert 6	Latch 7	Pulsed 8
1.1	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]
1.2	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]
2.1	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]
2.2	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]
3.1	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]
3.2	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]

Menu: ⑥ ⑤			Keypad Outputs								Page 45
Keypad	Group & Type	Default	Part. 1 1	Part. 2 2	Part. 3 3	Part. 4 4	Test 5	Invert 6	Latch 7	Pulsed 8	
1	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
2	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
3	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
4	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
5	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
6	[]:[] []	0:00	[]	[]	[]	[]	[]	[]	[]	[]	
Output Group 0: Not Used 1: System 2: Partition 3: Zone		System Output Types 00: Courtesy 01: Successful Transmission 02: Log 80% Full 03: Program Mode Selected 04: Download In Progress 05: Timed Arming Countdown 06: Zone Soak Test Active 07: Zone Soak Test Failed 08: Latched AC Fail 09: Telephone Line Fault 10: Smoke Alarm 11: Box/Auxiliary Tamper 12: Date Time Loss 13: Zone Trouble/Tamper 14: Keypad Tamper/Removed 15: Service Fault 16: Output 1 Fault 17: Output 2 Fault 18: Siren/Bell Fault 19: Smoke Sensor Fault 20: Auxiliary Fuse Fault 21: Latched Battery Fault 22: Service Required/Test Fail 23: Fail To Communicate 24: Control Timer 1 Active 25: Control Timer 2 Active 26: Control Timer 3 Active 27: Control Timer 4 Active 28: PC Output 1 29: PC Output 2 30: Walk Test 31: Confirmed Alarm 32: ARC 2 Active 33: Zones Locked Out 34: AC Fail 35: Battery Fault				Partition Output Types 00: PA Alarm 01: Duress Alarm 02: Burglar Alarm 03: Medical Alarm 04: 24Hr - Water Alarm 05: 24Hr - Gas Alarm 06: 24Hr - Low Temp Alarm 07: 24Hr - High Temp Alarm 08: Tamper 09: Trouble 10: Fire 11: Fire Fault 12: Bell 13: Strobe 14: Entry 15: Exit 16: Armed 17: Stay Armed 18: Ready 19: Bypass 20: Sensor Reset on Exit 21: Sensor Reset on Reset 22: Single Pulse on Arming 23: Double Pulse on Arming 24: Chime 25: Door Strike 26: Cross Zone Time Active 27: Single Pulse on Disarming 28: Reset Required 29: Acknowledgement Required 30: Confirmed Alarm 31: Alarm Abort 32: Away Armed 33: Away Armed/Exit 34: Detector Latch 35: Armed/Alarm 36: Arm Failed					

Output Programming

Zone Output Types (Mimic)		Zone Output Types (Alarm)	
01: Zone 01 Mimic	17: Zone 17 Mimic	33: Zone 01 Alarm	49: Zone 17 Alarm
02: Zone 02 Mimic	18: Zone 18 Mimic	34: Zone 02 Alarm	50: Zone 18 Alarm
03: Zone 03 Mimic	19: Zone 19 Mimic	35: Zone 03 Alarm	51: Zone 19 Alarm
04: Zone 04 Mimic	20: Zone 20 Mimic	36: Zone 04 Alarm	52: Zone 20 Alarm
05: Zone 05 Mimic	21: Zone 21 Mimic	37: Zone 05 Alarm	53: Zone 21 Alarm
06: Zone 06 Mimic	22: Zone 22 Mimic	38: Zone 06 Alarm	54: Zone 22 Alarm
07: Zone 07 Mimic	23: Zone 23 Mimic	39: Zone 07 Alarm	55: Zone 23 Alarm
08: Zone 08 Mimic	24: Zone 24 Mimic	40: Zone 08 Alarm	56: Zone 24 Alarm
09: Zone 09 Mimic	25: Zone 25 Mimic	41: Zone 09 Alarm	57: Zone 25 Alarm
10: Zone 10 Mimic	26: Zone 26 Mimic	42: Zone 10 Alarm	58: Zone 26 Alarm
11: Zone 11 Mimic	27: Zone 27 Mimic	43: Zone 11 Alarm	59: Zone 27 Alarm
12: Zone 12 Mimic	28: Zone 28 Mimic	44: Zone 12 Alarm	60: Zone 28 Alarm
13: Zone 13 Mimic	29: Zone 29 Mimic	45: Zone 13 Alarm	61: Zone 29 Alarm
14: Zone 14 Mimic	30: Zone 30 Mimic	46: Zone 14 Alarm	62: Zone 30 Alarm
15: Zone 15 Mimic	31: Zone 31 Mimic	47: Zone 15 Alarm	63: Zone 31 Alarm
16: Zone 16 Mimic	32: Zone 32 Mimic	48: Zone 16 Alarm	64: Zone 32 Alarm

Communicator Programming

Menu: ⑦①①

Communicator Options

Page 50

Enable On-Board Communicator 1	Enable DTMF Dialling 2	Switch to Pulse Dialling after 3 rd Attempt 3	Enable European Pulse Dialling 4	Enable Auto Test Transmission 5	Enable Cancel Call Waiting 6	Enable Backup to Receiving Centre 7	Enable Blind Dialling 8
[]	[]	[]	[]	[]	[]	[]	[]

Menu: ⑦①②

ARC 1 Communicator Options

Page 50

①	Telephone Numbers	Primary: [] None							
		Secondary: [] None							
①	Account Numbers	Partition 1: [] [] [] [] [] [] None				Partition 3: [] [] [] [] [] [] None			
		Partition 2: [] [] [] [] [] [] None				Partition 4: [] [] [] [] [] [] None			
②	Protocol Type	[] 0	Types: 0 = Disabled 2 = Express Format 4 = Contact ID 6 = Pager 1 = Pulse Format 3 = Fast Format 5 = SIA Level 2/3 7 = Mobile Phone						
③	Dial Attempts	[] 3							
④	Partition Options	1: Report for Partition 1		2: Report for Partition 2		3: Report for Partition 3		4: Report for Partition 4	
		[]		[]		[]		[]	
⑤	Reporting Options	Priority Alarm and Cancel Events	Alarm and Cancel Events	Open and Close Events	Bypass and Unbypass Events	Maint. Alarm Events	Tamper Alarm Events	Test Tx Events	Restore Events
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]

Communicator Programming

⑥	Pulse Format Options	Use 1900Hz Carrier	Use 40 PPS Baud Rate	Enable Parity	Use 2 Digit Events	Use 2300Hz Handshake	Use 2300Hz Kiss-Off	Use Fast/Slow Format	Reserved
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
⑦	Fast Format Channels	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7	Channel 8
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
⑧	Protocol Options	Disable SIA Modifier Blocks/ Enable Speech Module	Disable Events for Each Partition	Pager Terminator = * (Star)	Send Pager Terminator Twice/SIA Text	Pager DTMF Tones = 500mS	Disable Zone Restorals	Comms Ack. Tone	Connect via IP
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
Menu: ⑦ ② ARC 2 Communicator Options Page 53									
⑩	Telephone Numbers	Primary: []							None
		Secondary: []							None
①	Account Numbers	Partition 1: [] [] [] [] [] [] [] None				Partition 3: [] [] [] [] [] [] [] None			
		Partition 2: [] [] [] [] [] [] [] None				Partition 4: [] [] [] [] [] [] [] None			
②	Protocol Type	[] 0	Types: 0 = Disabled 2 = Express Format 4 = Contact ID 6 = Pager 1 = Pulse Format 3 = Fast Format 5 = SIA Level 2/3 7 = Mobile Phone						
③	Dial Attempts	[] 3							

④	Partition Options	1: Report for Partition 1		2: Report for Partition 2		3: Report for Partition 3		4: Report for Partition 4	
		[]		[]		[]		[]	
⑤	Reporting Options	Priority Alarm and Cancel Events	Alarm and Cancel Events	Open and Close Events	Bypass and Unbypass Events	Maint. Alarm Events	Tamper Alarm Events	Test Tx Events	Restore Events
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
⑥	Pulse Format Options	Use 1900Hz Carrier	Use 40 PPS Baud Rate	Enable Parity	Use 2 Digit Events	Use 2300Hz Handshake	Use 2300Hz Kiss-Off	Use Fast/Slow Format	Reserved
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
⑦	Fast Format Channels	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7	Channel 8
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]
⑧	Protocol Options	Disable SIA Modifier Blocks/ Enable Speech Module	Disable Events for Each Partition	Pager Terminator = * (Star)	Send Pager Terminator Twice/SIA Text	Pager DTMF Tones = 500mS	Disable Zone Restorals	Comms Ack. Tone	Connect via IP
		1	2	3	4	5	6	7	8
		[]	[]	[]	[]	[]	[]	[]	[]

Communicator Programming

Menu: ⑦③		Fast Format Restore Channels						Page 53
Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7	Channel 8	
1	2	3	4	5	6	7	8	
[]	[]	[]	[]	[]	[]	[]	[]	
Menu: ⑦④		Fast Format Open/Close Channels						Page 54
Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7	Channel 8	
1	2	3	4	5	6	7	8	
[]	[]	[]	[]	[]	[]	[]	[]	
Menu: ⑦⑤		Cancel Call Waiting Sequence						Page 54
Cancel Call Waiting Sequence:		[]	None

Download Programming

[illegible]

Reporting Codes Programming

Menu: ⑦⑦ Zone Alarm/Restore Codes Page 61					Menu: ⑦⑧ Zone Bypass/Unbypass Codes Page 61			
Zone	Event No	Alarm Code	Event No	Restore Code	Event No	Bypass Code	Event No	Unbypass Code
01	00	[][]31	01	[][]00	00	[][]61	01	[][]00
02	02	[][]32	03	[][]00	02	[][]62	03	[][]00
03	04	[][]33	05	[][]00	04	[][]63	05	[][]00
04	06	[][]34	07	[][]00	06	[][]64	07	[][]00
05	08	[][]35	09	[][]00	08	[][]65	09	[][]00
06	10	[][]36	11	[][]00	10	[][]66	11	[][]00
07	12	[][]37	13	[][]00	12	[][]67	13	[][]00
08	14	[][]38	15	[][]00	14	[][]68	15	[][]00
09	16	[][]39	17	[][]00	16	[][]69	17	[][]00
10	18	[][]3A	19	[][]00	18	[][]6A	19	[][]00
11	20	[][]3B	21	[][]00	20	[][]6B	21	[][]00

Reporting Codes Programming

12	22	[] [] 3C	23	[] [] 00	22	[] [] 6C	23	[] [] 00
13	24	[] [] 3D	25	[] [] 00	24	[] [] 6D	25	[] [] 00
14	26	[] [] 3E	27	[] [] 00	26	[] [] 6E	27	[] [] 00
15	28	[] [] 3F	29	[] [] 00	28	[] [] 6F	29	[] [] 00
16	30	[] [] 30	31	[] [] 00	30	[] [] 60	31	[] [] 00
17	32	[] [] 00	33	[] [] 00	32	[] [] 00	33	[] [] 00
18	34	[] [] 00	35	[] [] 00	34	[] [] 00	35	[] [] 00
19	36	[] [] 00	37	[] [] 00	36	[] [] 00	37	[] [] 00
20	38	[] [] 00	39	[] [] 00	38	[] [] 00	39	[] [] 00
21	40	[] [] 00	41	[] [] 00	40	[] [] 00	41	[] [] 00
22	42	[] [] 00	43	[] [] 00	42	[] [] 00	43	[] [] 00
23	44	[] [] 00	45	[] [] 00	44	[] [] 00	45	[] [] 00
24	46	[] [] 00	47	[] [] 00	46	[] [] 00	47	[] [] 00
25	48	[] [] 00	49	[] [] 00	48	[] [] 00	49	[] [] 00
26	50	[] [] 00	51	[] [] 00	50	[] [] 00	51	[] [] 00
27	52	[] [] 00	53	[] [] 00	52	[] [] 00	53	[] [] 00
28	54	[] [] 00	55	[] [] 00	54	[] [] 00	55	[] [] 00
29	56	[] [] 00	57	[] [] 00	56	[] [] 00	57	[] [] 00
30	58	[] [] 00	59	[] [] 00	58	[] [] 00	59	[] [] 00
31	60	[] [] 00	61	[] [] 00	60	[] [] 00	61	[] [] 00
32	62	[] [] 00	63	[] [] 00	62	[] [] 00	63	[] [] 00

Menu: 7 9 Non Zone Alarm/Restore Codes Page 61						
Event No	Event Type	Event	Reporting Group	Pulse/Express	Contact ID	SIA
00	AC Fail	Alarm	Maintenance	[] [] FF	301	AT
01		Restore	Restore	[] [] AF	301	AR
02	Low Battery	Alarm	Maintenance	[] [] FE	302	YT
03		Restore	Restore	[] [] AE	302	YR
04	Telephone Line Fault	Alarm	Maintenance	[] [] FD	351	LT
05		Restore	Restore	[] [] AD	351	LR
06	Fail to Communicate	Alarm	Maintenance	[] [] 00	354	YC
07		Restore	-	-	-	-
08	Open/Close	Alarm	Open	[] [] B*	401	OP
09		Restore	Close	[] [] C*	401	CL
10	Recent Closing	Alarm	Close	[] [] DA	459	CR
11		Restore	-	-	-	-
12	Auto Open/Close	Alarm	Open	[] [] CC	403	OA
13		Restore	Close	[] [] CC	403	CA
14	Auto Arm Deferred	Alarm	Close	[] [] D*	405	CE
15		Restore	-	-	-	-
16	Remote Open/Close	Alarm	Open	[] [] B9	407	OP
17		Restore	Close	[] [] C9	407	CL

Menu: ⑦ ⑨		Non Zone Alarm/Restore Codes				Page 61
Event No	Event Type	Event	Reporting Group	Pulse/Express	Contact ID	SIA
18	Quick Arm	Alarm	-	-	-	
19		Restore	Close	[] [] C	408	CL
20	Open After Alarm (Cancel)	Alarm	Open	[] [] D*	406	OR
21		Restore	-	-	-	-
22	Download Start	Alarm	Maintenance	[] [] 00		
23		Restore	-	-	-	-
24	Download End	Alarm	Maintenance	[] [] 00		
25		Restore	-	-	-	-
26	Group Bypass/Unbypass	Alarm	Bypass	[] [] 00	574	
27		Restore	Unbypass	[] [] 00	574	
28	Log Capacity Alert (80%)	Alarm	Maintenance	[] [] 00	623	JL
29		Restore	-	-	-	-
30	Keypad Lockout (Device No)	Alarm	Tamper	[] [] EA	421	JA
31		Restore	-	-	-	-
32	Code Tamper Alarm (Device No)	Alarm	Tamper	[] [] EA	421	JA
33		Restore	-	-	-	-
34	Manual Test Transmission	Alarm	Test	[] [] 9A	601	RX
35		Restore	-	-	-	-
36	Automatic Test Transmission	Alarm	Test	[] [] 9C	602	RP
37		Restore	-	-	-	-
38	User Zone Test Start/End	Alarm	Test	[] [] 00		
39		Restore	Restore	[] [] 00		
40	Auxiliary Power Fail/Restore	Alarm	Maintenance	[] [] FB	300	YP
41		Restore	Restore	[] [] AB	300	YQ

42	Bell Output Fault/Restore	Alarm	Maintenance	[] [] 00	321	YA
43		Restore	Restore	[] [] 00	321	YH
44	Installer Programming Start	Alarm	Maintenance	[] [] 00		
45		Restore	-	-	-	-
46	Installer Programming End	Alarm	Maintenance	[] [] 00		
47		Restore	-	-	-	-
48	Exit Error	Alarm	Close	[] [] 00		
49		Restore	-	-	-	-
50	Verified Cross Zone Alarm	Alarm	Alarm	[] [] 00	140	BV
51		Restore	-	-	-	-
52	Soak Test	Alarm	Test	[] [] 00		
53		Restore	-	-	-	-
54	Fire Zone Trouble	Alarm	Tamper	[] [] 00	373	FT
55		Restore	Restore	[] [] 00	373	FJ
56	System Power Up	Alarm	Maintenance	[] [] 00		
57		Restore	-	-	-	-
58	Swinger Shutdown (Zone No)	Alarm	Alarm	[] [] 00		
59		Restore	-	-	-	-

Menu: ⑦ ⑨		Non Zone Alarm/Restore Codes				Page 61
Event No	Event Type	Event	Reporting Group	Pulse/Express	Contact ID	SIA
60	User Code Entered	Alarm	-	-	-	-
61		Restore	-	-	-	-
62	Exit Started	Alarm	-	-	-	-
63		Restore	-	-	-	-
64	Entry Started	Alarm	-	-	-	-
65		Restore	-	-	-	-
66	Bell Active	Alarm	-	-	-	-
67		Restore	-	-	-	-
68	Alarm Active	Alarm	-	-	-	-
69		Restore	-	-	-	-
70	Keypad Tamper	Alarm	Tamper	[] [] 3*	137	TA
71		Restore	-	-	-	-
72	Keypad Medical	Alarm	Priority Alarm	[] [] 00	100	MA
73		Restore	-	-	-	-
74	Keypad Fire/2-Wire Smoke	Alarm	Priority Alarm	[] [] 00	115	FA
75		Restore	Restore	[] [] 00	115	FH
76	Duress Code Alarm	Alarm	Priority Alarm	[] [] 00	121	HA
77		Restore	-	-	-	-
78	Keypad Silent PA	Alarm	Priority Alarm	[] [] 2*	122	PA
79		Restore	-	-	-	-
80	Keypad Audible PA/Auxiliary PA	Alarm	Priority Alarm	[] [] 2*	120	PA
81		Restore	Restore	[] [] 00	120	PH
82	Box Tamper	Alarm	Tamper	[] [] 30	137	TA
83		Restore	Restore	[] [] 00	137	TR

84	Zone Tamper	Alarm	Tamper	[] [] 3*	144	TA
85		Restore	Restore	[] [] 00	144	TR
86	Zone Trouble	Alarm	Tamper	[] [] 00	380	UT
87		Restore	Restore	[] [] 00	380	UJ
88	Expander/Remote Trouble	Alarm	Tamper	[] [] 00	333	ET
89		Restore	-	-	-	-
90	Auxiliary Tamper Input	Alarm	Tamper	[] [] 30	137	TA
91		Restore	Restore	[] [] 00	137	TR
92	Date Changed	Alarm	Maintenance	[] [] 00	625	JD
93		Restore	-	-	-	-
94	Time Changed	Alarm	Maintenance	[] [] 00	625	JT
95		Restore	-	-	-	-
96	System Reset	Alarm	Maintenance	[] [] 00		
97		Restore	-	-	-	-
98	Remote Control	Alarm	Test	[] [] 00	-	-
99		Restore	Restore	[] [] 00	-	-
100	Confirmed Alarm	Alarm	Alarm	[] [] 00	139	BV
101		Restore	-	-	-	-

Menu: ⑦⑨		Non Zone Alarm/Restore Codes				Page 61
Event No	Event Type	Event	Reporting Group	Pulse/Express	Contact ID	SIA
102	Monitored Alarm	Alarm	Alarm	[] [] 00	220	BA
103		Restore	Restore	[] [] 00	220	BH
104	FOB Low Battery	Alarm	Maintenance	[] [] 00	384	XT
105		Restore	-	[] [] 00	-	-
106	Radio Supervision	Alarm	Maintenance	[] [] 00	355	YS
107		Restore	-	[] [] 00	-	-
108	Communication Port	Alarm	Maintenance	[] [] 00	356	ET
109		Restore	-	[] [] 00	-	-

* If the second digit for Pulse/Express is programmed as "0", the panel will replace this digit with the Zone/User/Keypad number.

A dash (-) indicates an event that is not generated by the control panel and therefore cannot be reported.

Notes

System Overview

Installation

Control Panel PCB Layout

Installing Remote Keypads & Expanders

Zone Connections

Siren/Bell, Telephone and Panel Outputs

Commissioning & Troubleshooting

Programming Menus

Programming Zones

Programming Partitions

Programming Global Options

Programming Remote Keypads

Programming Remote Expanders

Programming System Outputs

Programming the Communicator

Programming Download Options

Programming Reporting Codes

Programming Users

System Tests, Utilities and Using *RadioPlus*

Operating the Alarm System

Specifications

Quick Reference Guide & Defaults

Texecom
Designed to Perform

Texecom Limited, Bradwood Court, St. Crispin Way, Haslingden,
Lancashire BB4 4PW, England.

Technical Support:

UK Customers Tel: 08456 300 600

(Calls charged at 3.36 pence per minute from a BT landline. Calls from other networks may vary.)

International Customers Tel: +44 1706 233875

Email: techsupport@texe.com

© Texecom Limited 2011

INS159-11



Certificate Number : FM 35285