

SIEMENS

WT43H00LDN

Tumble dryer



EN User manual and installation instructions



Siemens Home Appliances

Register your appliance on My Siemens and
discover exclusive services and offers.



**You can find additional information and explanations online.
Scan the QR code on the title page.**



Table of contents

1 Safety	3	11 Basic operation	20
1.1 General information	3	11.1 Switching on the appliance ..	20
1.2 Intended use	3	11.2 Setting a programme	20
1.3 Restriction on user group	3	11.3 Opening the door	20
1.4 Safe installation	4	11.4 Loading laundry	20
1.5 Safe use	6	11.5 Starting the programme	21
1.6 Safe cleaning and maintenance	8	11.6 Adding laundry	21
2 Preventing material damage	9	11.7 Cancelling the programme ...	21
3 Environmental protection and saving energy	9	11.8 Unloading the laundry	21
3.1 Disposing of packaging	9	11.9 Switching off the appliance ...	21
3.2 Saving energy	10	11.10 Fluff filter	21
3.3 Energy saving mode	10	11.11 Filter system on the base unit	22
4 Installation and connection	10	11.12 Condensation container	24
4.1 Unpacking the appliance	10	12 Dryness level	24
4.2 Contents of package	10	12.1 Changing the dryness level ..	25
4.3 Requirements for the installation location	10	12.2 Adjusting the dryness level ...	25
4.4 Aligning the appliance	11	13 Childproof lock	25
4.5 Connecting the appliance to the electricity supply	11	13.1 Activating the childproof lock	25
5 Familiarising yourself with your appliance	12	13.2 Deactivating the childproof lock	25
5.1 Appliance	12	14 Basic settings	25
5.2 Control panel	13	14.1 Overview of the basic settings	25
6 Display	13	14.2 Changing the basic settings	26
7 Buttons	15	15 Cleaning and servicing	26
8 Programmes	16	15.1 Base unit	26
8.1 Automatic programmes	16	15.2 Moisture sensor	28
8.2 Timed programmes	18	16 Troubleshooting	28
9 Accessories	18	17 Transportation, storage and disposal	31
10 Laundry	19	17.1 Disposing of old appliance ...	31
10.1 Preparing the laundry	19	18 Customer Service	32
10.2 Care symbols on the care labels	20		

18.1 Product number (E-Nr.) and
production number (FD) 32

19 Consumption values 32

20 Technical data 35



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- ▶ Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ▶ Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ▶ The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the  mark.
- ▶ Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
- ▶ Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

- ▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ▶ Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer . No other installation method is permitted.

→ *"Accessories", Page 18*

- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ▶ Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

- ▶ Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

- ▶ Do not move the appliance by holding onto protruding parts.

⚠ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- ▶ Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ▶ Call customer service. → *Page 32*

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ▶ Keep small parts away from children.
- ▶ Do not let children play with small parts.

WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

- ▶ Keep the area around the appliance clean during operation.

WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

- ▶ Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ▶ Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

- ▶ Keep naked flames and ignition sources away from the appli-



ance.

⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

- ▶ Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

- ▶ Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- ▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- ▶ Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

⚠ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ▶ If drying is interrupted early, remove the laundry immediately and spread it out.

⚠ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

- ▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

- ▶ Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

⚠ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

- ▶ Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

- ▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

- ▶ Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- ▶ Observe the maximum load capacity for each programme and do not exceed it.

→ "Programmes", Page 16

The function of the appliance may be impaired if the appliance overheats.

- ▶ Keep the ventilation opening on the appliance clear during operation.
- ▶ Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- ▶ Keep the area around the appliance clean during operation.
- ▶ Keep light objects away from the appliance.

If you operate the appliance without a fluff guard (e.g. fluff filter, fluff collector, filter mat, etc., depending on appliance specifications), or if the

fluff guard is incomplete or defective, this may result in damage to the appliance.

- ▶ Do not operate the appliance without a fluff guard, or with a fluff guard that is incomplete or defective.

Foam and foam rubber may deform or melt during the drying process.

- ▶ Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.
- ▶ Do not use hard scouring pads or cleaning sponges.
- ▶ Clean the appliance with nothing but water and a soft, damp cloth.
- ▶ Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

- ▶ Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

- Operate the appliance in a well-ventilated room and keep the ventilation opening on the appliance clear.
- Spin the laundry in the washing machine before drying.
- For each drying process, use the maximum load for the programs. Programmes → *Page 16*
- Do not exceed the programme's maximum load capacity. Programmes → *Page 16*
- After drying, clean the fluff filter.
→ *"Cleaning the fluff filter", Page 21*
- Dry the filters in the filter system of the base unit thoroughly after cleaning.
→ *"Filter system on the base unit", Page 22*

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and ► flashes.

Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION

Objects remaining in the drum that are not designed for operation with the appliance may cause material

damage and damage to the appliance.

- ▶ Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
1. Remove any packaging and protective covers completely from the appliance.
→ *"Disposing of packaging", Page 9*
 2. Check the appliance for visible damage.
 3. Open the door. → *Page 20*
 4. Remove any accessories from the drum.
 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- ▶ Do not operate the appliance with incomplete or defective accessories.
- ▶ Replace the accessories in question before operating the appliance.
→ *"Accessories", Page 18*

The delivery consists of the following:

- Tumble dryer
- Accompanying documents

4.3 Requirements for the installation location

Observe the instructions for the installation location.

ATTENTION

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ▶ Tilt the appliance carefully.
- ▶ Transport the appliance in an up-right position.

If residual water in the appliance freezes, this may cause damage to the appliance.

- ▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

- ▶ Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

On the floor

Place the appliance on a clean, level and firm surface.

Align the appliance. → *Page 11*


In a washer-dryer stack

Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

- Connection kit → *Page 18*
- Connection kit with pull-out work-top → *Page 19*

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine.

Do not place the washer-dryer stack on a platform.


Against a wall

Do not trap the hoses and power cord between the wall and the appliance.

4.4 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

- ▶ To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

4.5 Connecting the appliance to the electricity supply

1. Insert the mains plug of the appliance's power cable in a socket nearby.

The connection details of the appliance can be found under Technical data → *Page 35*.


en Familiarising yourself with your appliance

2. Check the mains plug is inserted properly.
- ✓ The appliance is now ready for use.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening	4	Door → <i>Page 20</i>
2	Maintenance flap on the base unit → <i>Page 26</i>	5	Condensation container → <i>Page 24</i>
3	Fluff filter → <i>Page 21</i>	6	Control panel → <i>Page 13</i>

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



1 Programmes → *Page 16*


2 Programme selector
→ *Page 20*

3 Display → *Page 13*

4 Buttons → *Page 15*

6 Display

The display shows the current settings, options or relevant information. Depending on the programme status, the display shows some information in the 8:88 area, e.g. End.



Example: Display

Indicator	Description
0:40 ¹	Expected programme duration or programme time remaining in hours and minutes.
1:25	The timed programme is set. → <i>Page 18</i>
10h ¹	Program end time → <i>"Buttons", Page 15</i>
	■ Lights up: The childproof lock is activated. ■ Flashes: The childproof lock is activated and the appliance has been operated. → <i>"Deactivating the childproof lock", Page 25</i>
	Start, cancel or pause ■ Lights up: The programme is running and can be cancelled or paused. ■ Flashes: The programme can be started or continued.
  	The adjusted dryness level is activated. → <i>Page 24</i>
	The crease-reduction function is activated. → <i>"Buttons", Page 15</i>
	Gentle drying is activated for delicate fabrics. → <i>Page 15</i>
	Empty and insert the condensation container. → <i>Page 24</i>
	Clean the fluff filter → <i>Page 21</i> . Clean the filter system on the base unit. → <i>Page 22</i>
Hot	The cooling process cools the laundry independently of the programme status for a few minutes while the drum is rotating, in order to avoid damage to the laundry. The cooling process can be cancelled by opening the door. Note: Do not change the set programme.
	Programme status: Drying
	Programme status: Iron dry dryness level
	Programme status: Cupboard Dry dryness level
	Programme status: Crease-reduction function
-P-	Programme status: Pause
End	Programme status: Programme end

¹ Example

7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
	■ Start ■ Cancel ■ Pause	Start, cancel or pause the programme.
 3 sek.	■ Activate ■ Deactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 25
	■ ¹ ■ ² ■ ³	Adjust the dryness level. If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level. → "Adjusting the dryness level", Page 25
	■ Activate ■ Deactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.
	■ Activate ■ Deactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.
	Up to 24 hours	Set the programme end time.

Button	Selection	Description
		The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
	Multiple selection	Set the programme duration for timed programmes. → <i>"Timed programmes", Page 18</i>

8 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

Note: The laundry's care labels provide you with additional information about programme selection.
→ *"Care symbols on the care labels", Page 20*

8.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached.

Each automatic programme has a dryness level → *Page 24*. The dryness level defines how dry or damp the laundry is after the programme ends.

Tip: Select the dryness level according to the type of fabric or the desired drying result.

Programme	Description	Max. load (kg)
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is defined in this programme. → <i>Page 24</i>	8.0
Eco (Skabstørt) (Cup-board Dry)	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is defined in this programme. → <i>Page 24</i>	8.0
Bomuld Strygetørt (Cotton Iron Dry)	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is defined in this programme. → <i>Page 24</i>	8.0

Programme	Description	Max. load (kg)
Strygelet Ekstra skabstørt (Easy Care Cupboard Dry Extra)	Dry items made of synthetic materials or blended fabrics. The dryness level is defined in this programme. → <i>Page 24</i>	3.5
Strygelet Skabstørt (Easy Care Cupboard Dry)	Dry items made of synthetic materials or blended fabrics. The dryness level is defined in this programme. → <i>Page 24</i>	3.5
Strygelet Strygetørt (Easy Care Iron Dry)	Dry items made of synthetic materials or blended fabrics. The dryness level is defined in this programme. → <i>Page 24</i>	3.5
Mix	Dry items made of cotton and synthetics.	3.0
Dunprogram (Down)	Dry clothing, bedspreads or eiderdowns stuffed with down. Notes ▪ Dry large items of laundry, such as blankets or sleeping bags, separately. ▪ Once the programme has ended, shake the items of laundry to distribute the stuffing and eliminate any pockets of moisture. ▪ If you dry the pillows and the pillows are not completely dry at the end of the programme, dry the pillows with a timed programme. → <i>Page 18</i>	1.5
Outdoor	Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1.5
Skjorter (Shirts)	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time. Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	1.5
Super 40'	Dry items made of synthetics and light cotton.	1.0

Programme	Description	Max. load (kg)
Håndklæder (Towels)	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0

8.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Programme	Description	Max. load (kg)
Uldfinish (Wool Finish)	Dry machine-washable items made of wool or containing wool. Note: The laundry becomes fluffier but not dry. Remove laundry once the programme has ended and allow it to dry.	0.5
Tidsprogram koldt (Time Program Cold)	Fluff/loosen all fabric types except for wool and silk. This programme is suitable for fluffing dry laundry only. Also suitable for freshening up or airing dry clothing that has hardly been worn.	3.0
Tidsprogram varmt (Time Program Warm)	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.	3.0

9 Accessories

Use original accessories. These have been made especially for your appliance.

Tip: Some accessories are available in other colours. Contact customer service. → *Page 32*

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth	WZ11410

	Use	Order number
	and that is from the same manufacturer.	
Connection kit with pull-out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ20400
Wool basket	Dry or air individual wool-len items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water outlet hose of an additional appliance to the same siphon outlet.	15000490
Water outlet hose	Drain away excess condensation directly into the waste water system, without having to regularly empty the condensation container.	WZ20160
Filter mat	Spare part to protect against fluff for the base unit's filter system.	12007650
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D

10 Laundry

10.1 Preparing the laundry

ATTENTION

Objects remaining in the laundry may damage the laundry and the drum.

- ▶ Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes

en Basic operation

- Remove curtain fittings and lead strips
 - Load the laundry unfolded into the drum
 - Spin the laundry before drying
 - Dry woollen items, sports shoes and soft toys in the wool basket
- Wool basket

10.2 Care symbols on the care labels

Drying care symbols

Symbol	Fabrics
	Items made from cotton and linen, e.g. towels, bed linen, underwear
	Items made from synthetic, blended or delicate fabrics, e.g. functional garments, shirts
	Do not tumble dry items made from silk, nylon, air-impermeable and rubber-coated fabrics, synthetic curtains

11 Basic operation

11.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. → *Page 10*

- Turn the programme selector to a programme.


11.2 Setting a programme

1. Turn the programme selector and set the required programme.
→ *"Programmes", Page 16*


2. If required, adjust the programme settings.
→ *"Buttons", Page 15*
The programme settings are not saved permanently for the programme.

11.3 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



11.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes.
→ *"Programmes", Page 16*

Requirements

- The laundry is prepared and sorted.
→ *"Laundry", Page 19*
 - The drum is empty.
1. Open the door. → *Page 20*
 2. Place the laundry in the drum.

3. Close the door.
Ensure that there is no laundry trapped in the door.

11.5 Starting the programme

Requirements

- A programme is set. → *Page 20*
- The door is closed.
- ▶ Press ▷|||.
- ✓ The display shows the programme duration or the programme end time.
- ✓ After the programme has ended, the display shows: "End".

Note: When "Hot" is shown on the display, the appliance cools the laundry.
When "Hot" goes out, the laundry has cooled down.

11.6 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press ▷|||.
The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door.
→ *Page 14*
2. Open the door. → *Page 20*
3. Add or remove laundry.
4. Close the door.
5. Start the programme. → *Page 21*

11.7 Cancelling the programme

1. Press ▷|||.
2. Open the door. → *Page 20*
3. Remove the laundry. → *Page 21*

11.8 Unloading the laundry

1. Open the door. → *Page 20*

2. Remove the laundry from the drum.

11.9 Switching off the appliance

- ▶ Turn the programme selector to **Fra** ○ (**Off**).

11.10 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.


Cleaning the fluff filter

If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter after the programme end.


Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirements

- The display shows the following after drying: "End"
 - or the display shows the following during operation: .
1. Open the door. → *Page 20*
 2. Remove the fluff from the inside of the door.
 3. Remove the two-part fluff filter one part at a time.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.

5. Open the two fluff filters ① and remove the fluff ②.



Dispose of the fluff with the household waste in order to prevent the water from being contaminated with microplastics.

6. Clean the two fluff filters thoroughly under warm, running water and then dry them off.




Note: Collect the cleaning water in a container, e.g. a bucket. After


cleaning, pour the contents of the container through a filter, e.g. a coffee filter.

Dispose of the coffee filter with the household waste in order to prevent the water from being contaminated with microplastics.

7. Close the two fluff filters and put them together.



8. Insert the two-part fluff filter.



9. Close the door.

11.11 Filter system on the base unit

During drying, fluff from the laundry is collected in the base unit's filter system. The filter system protects the appliance from fluff.

Cleaning the filter system on the base unit


If the display shows a notification while the appliance is in operation, clean the base unit's filter system after the programme end.

Notes

- You can clean the filter system regularly even without the notification being shown on the display. It is not necessary to clean after each drying cycle.
- If you do not clean the appliance as described, the appliance's functionality may be impaired.


Requirement: The display shows the following during operation: .

1. Clean the fluff filter → *Page 21*.
2. Open the base unit. → *Page 26*
3. Carefully remove the filter mat from the retainers.




Ensure that you do not deform or damage the filter mat.

4. Use a soft brush to clean the heat exchanger cover.



Make sure that you remove all dirt from the seal.

5. Clean the filter mat thoroughly under warm, running water and squeeze it out by hand.




You can remove heavy soiling carefully using a vacuum cleaner. Do not clean the filter mat using cleaning agents.

Note: Collect the cleaning water in a container, e.g. a bucket. After cleaning, pour the contents of the container through a filter, e.g. a coffee filter.

Dispose of the coffee filter with the household waste in order to prevent the water from being contaminated with microplastics.

6. Push the filter mat onto the retainers.



Ensure that the cleaned filter mat is not deformed, damaged or inverted when you push it onto the retainers.

Note: You can order the filter mat → *Page 19* as a spare part from customer service.

7. Close the base unit. → *Page 27*

11.12 Condensation container


Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container.

Emptying the condensation container


If the drying programme has finished or the display shows a notification that the drying programme is paused, empty the condensation container.

Requirements

- The display shows the following after drying: "End"
 - or the display shows the following while operation is paused: .
1. Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Make sure that you insert the condensation container before operating the appliance. → *Page 24*

3. If the drying programme is paused, start the programme. → *Page 21*

Inserting the condensation container

- Push the condensation container in as far as it will go.



12 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Programme	Description
Bomuld Ekstra skabstørt (Cotton Cupboard Dry Extra) Strygelet Ekstra skabstørt (Easy Care Cupboard Dry Extra)	For multi-layered, thick laundry that does not dry readily.
Eco (Skabstørt) (Cupboard Dry) Strygelet Skabstørt (Easy Care Cupboard Dry)	For normal, single-layered laundry.

Programme	Description
Bomuld Strygetørt (Cotton Iron Dry)	For normal, single-layered laundry.
Strygelet Strygetørt (Easy Care Iron Dry)	The laundry is still slightly damp after the programme ends. To prevent creasing after drying, iron the laundry or hang it up.

12.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- Set an automatic programme with the desired dryness level.
→ *Page 16*

12.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

1. Set an automatic programme with the desired dryness level.
→ *Page 16*
2. Repeatedly press $\star^{\pm}$ to adjust the dryness level from $\star^1$ (dry) to $\star^3$ (driest).

13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- Press on both $\hookrightarrow$ **3 sek.** buttons for approx. 3 seconds.
- ✓ The display shows $\hookrightarrow$.
- ✓ The control elements are locked.
- ✓ The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

13.2 Deactivating the childproof lock


Requirement: To deactivate the childproof lock, the appliance must be switched on.

- Press on both $\hookrightarrow$ **3 sek.** buttons for approx. three seconds. So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ $\hookrightarrow$ goes out on the display.

14 Basic settings

You can configure the basic settings for your appliance to meet your needs.

14.1 Overview of the basic settings



Programme selector with programme positions

1 No basic setting.

Set the spin speed of the washing machine:

2 600 (low) to 1800 (high)¹
The set value increases or decreases the duration of the automatic programmes.

3 Set the volume of the signal at the end of the programme:
0 (off) to 4 (very loud)

4 Set the volume of the signal tone emitted when the buttons are pressed:
0 (off) to 4 (very loud)

14.2 Changing the basic settings

1. Set the programme selector to position 1. → *Page 25*
2. Press ▷ and, at the same time, turn the programme selector to position 2.
- ✓ The display shows the current value.
3. Use the programme selector to select the required basic setting.
→ *Page 25*
4. To change the value, press ⌚ / ⌚.
5. To save the changes, switch off the appliance.

15 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.


15.1 Base unit

The base unit is the accessible area at the bottom of the appliance in which you will find the heat exchanger.

Opening the base unit


Requirements

- The appliance has cooled down for 30 minutes.
 - The appliance door is closed.
1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.



¹ Example

3. Pull out the heat exchanger cover by the handle.



Cleaning the base unit

You can remove any visible dirt in the base unit.


⚠ CAUTION

Risk of cutting!

Touching sharp edges on the heat exchanger may lead to cuts.


- ▶ Do not touch the fins on the heat exchanger.

1. Open the base unit. → *Page 26*
2. Use a soft brush to clean the heat exchanger cover.



Make sure that you remove all dirt from the seal.

3. Clean the opening with a soft, damp cloth.




4. Close the base unit. → *Page 27*

Closing the base unit


Requirement: The base unit is open.

→ *"Opening the base unit", Page 26*


1. Insert the heat exchanger cover by the handle.



2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



15.2 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.


ATTENTION

Hard or rough objects may damage the moisture sensor.

- Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

1. Open the door.
2. Clean the moisture sensor with a sponge.



16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The display goes out and ▷❖ flashes.	Energy-saving mode is active ► Press ▷❖.

Fault	Cause and troubleshooting
"Hot" and the drum rotates.	Not a fault. The cooling process is active. No action required. Note: Do not change the programme during the cooling process. The cooling process takes up to 10 minutes.
 and programme terminated.	The condensation container is full. ► Empty the condensation container. → <i>Page 24</i> The water outlet hose is not connected correctly, or is kinked or trapped. ► Check the installation of the water outlet hose. Water outlet hose is blocked. ► Rinse the water outlet hose with tap water. A foreign object is in the base unit. 1. Open the base unit. → <i>Page 26</i> 2. Remove any foreign objects. 3. Close the base unit. → <i>Page 27</i>
 / E:69	Fluff filter is soiled. ► Clean the fluff filter. → <i>Page 21</i> Filter system on the base unit is dirty. ► Clean the filter system on the base unit. → <i>Page 22</i>
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → <i>Page 25</i> ⏻ is activated. ► Check whether ⏻ is activated. → <i>Page 15</i>
The length of the programme changes during the drying cycle.	Not a fault. The programme sequence is optimised electronically. No action required.
The drying time is too long.	Filter system on the base unit is dirty. ► Clean the filter system on the base unit. → <i>Page 22</i> Fluff filter is soiled. ► Clean the fluff filter. → <i>Page 21</i> The ambient temperature is lower than 15 °C or higher than 30 °C. ► Ensure that the ambient temperature is between 15 °C and 30 °C. The air circulation at the appliance's installation location is insufficient. ► Ventilate the appliance's installation location.

Fault	Cause and troubleshooting
The drying time is too long.	The appliance's ventilation opening is blocked. ► Ensure that the ventilation opening of the appliance is kept clear. Heat exchanger is soiled. 1. Open the base unit. → <i>Page 26</i> 2. Clean the heat exchanger. → <i>Page 27</i> 3. Close the base unit. → <i>Page 27</i>
Humming, whirring or pumping noises.	Not a fault. The compressor, compressor ventilation or condensation pump is active. No action required.
The laundry is too damp.	The selected programme is unsuitable for the type of fabric. ► Set a time programme for subsequent drying. → <i>Page 18</i> The load is too large. ► Observe the programme's maximum load capacity. → <i>Page 16</i> After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling. The selected dryness level is unsuitable. ► Change the dryness level. → <i>Page 25</i> The dryness level is not adjusted. ► Adjust the dryness level. → <i>Page 25</i> The load is too small. ► Set a time programme for subsequent drying. → <i>Page 18</i> The moisture sensor is dirty. ► Clean the moisture sensor. → <i>Page 28</i> The appliance has interrupted the drying process due to the condensation container being full. ► Empty the condensation container. → <i>Page 24</i>
Creasing.	The selected programme is unsuitable for the type of fabric. ► Set a suitable programme. → <i>Page 16</i> The load is unsuitable. ► Observe the programme's maximum load capacity. → <i>Page 16</i> ► Prepare the laundry. → <i>Page 19</i>

Fault	Cause and troubleshooting
Creasing.	The laundry lies in the drum for too long after drying. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling. Easy Care fabrics have been dried for too long. ► Change or adjust the dryness level. → <i>Page 24</i> The crease-reduction function is not activated. ► Activate the crease-reduction function. → <i>Page 15</i>
Water is leaking from the appliance.	Appliance is not correctly aligned. ► Align the appliance. → <i>Page 11</i> The seal for the heat exchanger cover is dirty. ► Clean the seal for the heat exchanger cover. → <i>Page 22</i> Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose. The lever for the heat exchanger cover is not closed correctly. ► Ensure that the lever for the heat exchanger cover is closed correctly. → <i>Page 27</i>
Condensation collects in the condensation container despite the water outlet hose being connected.	Not a fault. The remaining volume of condensation may remain in the condensation container. No action required. Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose.

17 Transportation, storage and disposal

17.1 Disposing of old appliance

Valuable raw materials can be re-used by recycling.

WARNING

Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the ap-

pliance door or prevent it from opening.

- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

WARNING

Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.

- Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

18 Customer Service

Function-relevant genuine spare parts according to the corresponding Eco-design Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

18.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

19 Consumption values

The **Eco (Skabstørt) (Cupboard Dry)** programme is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption. This programme serves to assess compliance with Regulations (EU) 2023/2533 and (EU) 2023/2534. It corresponds to the "standard cotton programme" within the meaning of Regulation (EU) No 392/2012 and within the meaning of

Annex I, point 1.1 of Regulation (EU) No 932/2012. The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values specified for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions.

The expected programme duration/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final moisture level (%)	Load (kg)	Spin speed (rpm)	Initial moisture level (%)	Programme duration (h:min)	Energy consumption (kWh/cycle)
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	8.0	1400	50	3:42	1.98
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	4.0	1400	50	2:32	1.39
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	8.0	1000	60	4:07	2.24
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	4.0	1000	60	2:47	1.54
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	8.0	800	70	4:32	2.51
Bomuld Ekstra skabstørt (Cotton Cup-board Dry Extra)	-3.0	4.0	800	70	3:02	1.69
Eco (Skabstørt) (Cup-board Dry)	0.0	8.0	1400	50	3:01	1.73
Eco (Skabstørt) (Cup-board Dry)	0.0	4.0	1400	50	1:56	1.05

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Eco (Skabstørt) (Cup- board Dry) ¹	0.0	8.0	1000	60	3:25	1.97
Eco (Skabstørt) (Cup- board Dry)	0.0	4.0	1000	60	2:10	1.19
Eco (Skabstørt) (Cup- board Dry)	0.0	8.0	800	70	3:50	2.21
Eco (Skabstørt) (Cup- board Dry)	0.0	4.0	800	70	2:25	1.33
Bomuld Strygetørt (Cotton Iron Dry)	12.0	8.0	1400	50	2:14	1.27
Bomuld Strygetørt (Cotton Iron Dry)	12.0	4.0	1400	50	1:22	0.73
Bomuld Strygetørt (Cotton Iron Dry)	12.0	8.0	1000	60	2:40	1.53
Bomuld Strygetørt (Cotton Iron Dry)	12.0	4.0	1000	60	1:37	0.88
Bomuld Strygetørt (Cotton Iron Dry)	12.0	8.0	800	70	3:05	1.79
Bomuld Strygetørt (Cotton Iron Dry)	12.0	4.0	800	70	1:52	1.03
Strygelet Ekstra skab- størt (Easy Care Cup- board Dry Extra)	0.0	3.5	800	40	1:11	0.60
Strygelet Ekstra skab- størt (Easy Care Cup- board Dry Extra)	0.0	3.5	600	50	1:24	0.72
Strygelet Skabstørt (Easy Care Cupboard Dry)	2.0	3.5	800	40	1:12	0.62
Strygelet Skabstørt (Easy Care Cupboard Dry)	2.0	3.5	600	50	1:25	0.74

¹ The acoustical noise emissions during the drying cycle are 63 dB.

Programme	Final moisture level (%)	Load (kg)	Spin speed (rpm)	Initial moisture level (%)	Programme duration (h:min)	Energy consumption (kWh/cycle)
Strygelet Strygetørt (Easy Care Iron Dry)	12.0	3.5	800	40	0:50	0.41
Strygelet Strygetørt (Easy Care Iron Dry)	12.0	3.5	600	50	1:02	0.52

20 Technical data

Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm
Appliance depth with door closed	64.8 cm
Appliance depth with door open	109.6 cm
Weight	46.0 kg
Maximum load	8.0 kg
Mains voltage	220-240 V, 50 Hz
⇒ Minimum installation protection	10 A

Nominal power	600 W
Power consumption	■ Off mode: 0.10 W ■ Left-on mode: 0.50 W
Ambient temperature	■ Minimum: 5 °C ■ Maximum: 35 °C
Length of the power cord	145 cm

More information about your model can be found online at <https://eprel.ec.europa.eu/qr/21147581>. This web address is linked to the official EU EPREL product database.

¹ Only applies to countries in the European Economic Area. This website address is available from 1st July 2025.

EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain:
Imported to Great Britain by
BSH Home Appliances Ltd.
Grand Union House
Old Wolverton Road
Wolverton, Milton Keynes
MK12 5PT
United Kingdom

BSH Hausgeräte GmbH
Carl-Wery-Straße 34
81739 München, GERMANY
siemens-home.bsh-group.com



9001978466 (050611)
en