




Mark Door Reference Lines



Preparing Door (if necessary)










Changing Handing (if necessary)

4" Latt Band to 4" Right Band Shower








Lockset Handing Configurations




Almost done. Turnisheet over milinish installation.






















Installing Exterior Deadbolt








4 Installing Fire Cups








Programming Instructions

Touchscreen

Installing Interior Lock continued






Creating Master PIN Code


is not possible until this step has been successfully completed.

Creating a Master PIN Code must be performed upon installation or


after resetting the lock to factory default. Programming and use of lock


Installing Interior Lever












Testing Final Latchbolt Operation Testing Final Deadbolt Operation (16) Installing Batteries & Cover











Unlocking Door with PIN Code





Unlocking Door with RFID

Menu", to configure RFID communicatio11



Il Code Lockout Mode: This feature is enabled liv the Master code. When enabled, it restriGts all user (except Master) PINcode access. When attemptingto enter a code whileunit is in Lockout, the RED locked padlock will appear on the screen.

selected in Advanced Lock Se11ings (Main Menuselection #3 Handing the Lock: Lock handing refers to which direction thebolt comes out of the door (right or

left). 11 lock was programmed off the door, the lockmay need adjusting. Review Handingthe Lock instructions and for Re-Handing instructions listed in Hardware Troubleshooting

enabl8d or disabledin Mvanced Lock Settings (Main Menu selBGtion #3)

Low Battery: When llatt@rv power is low, the Low Battery Warning indicator flash8sRED. If battery

Master PIN Code: TheMaster PIN code is used for programming and for feature settings II must be created prior to programming the lock. TheMaster cmle will also opernt♦ (unlock/lock) th♦lock

thruthe Main Menu (7) and allows the locktoconnect with a network controller One Touch Locking: When thelatchis retracted, activating the keypad will extend the latch {during Automatic Re-lock durationor when Automatic Re-lockis disalJI8dJ. When On Touch Re-lock is not in use (disabled), any valid PIN code will re-lock thelock

Previous: WhileinMenu Mode, pressingthis iconcancels the current operation and returns the

Privacy Mode: Privacymode is disabled by deiault EnablePrivacy Mod8 by pressinll the 1nivacy button for 4 secondsto out the lockin do-not-disturb mode (all pin codes are disabled)

Shutdown Time: Theunit will shutdown (flashing RED) for sixty (60) seconds and not allow operationafter the wrong code entry limit (5 attempts) has been met

Plus or Zigliee network moduleis 250: without network moduleor withiM1 network module. maximum is 25: with Bluetooth: maximum is 12 Note: When deleting user pin code(s), screen will display user pin code beingdt:lel8d.

otherwise it canbe set to High(1) or Silent (3) for quiet areas

Wrong Code Entry Limit: After five (5) unsuccessful attempts all entering a valid PIN code, theunit will shut clown and not allow operation for siX1y (60) seconds.

Feature Programming Thru


Touch screen with back of hand or palm to activate. [2 2. Enter 4-8 digit master PIN code' followed by [& key.

The Master PIN code must be registered prior to any other programming of the lock, 0 = +0' = +




User PIN Code Aegistrfli





Handing the Lock



Congratulations, y o u nexTouch™ Electronic nnected chscreen Continue with the Programming Instructions to customize your product.

Hardware Troubleshooting

Cycle lock in both the locked and unlocked positions If problems are found:

Bolt will not extend and motor is grinding

a. Enter your Master PIN code.

b. With the bolt retracted, press menu Option 3 for Advanced Lock Settings.

Press Option 5 to rehand the lock. d. Test the operation; locking the door via the keypad

oor is binding

 a. Chock that door and frame are properly align&d and door is free swinging. b. Check hinges: They should not be loose or have excessive wear on knuckle

Bolt will not deadlock a. Check for sufficient clearance of the bolt within the strike-side jamb.

Correct this by increasing the depth of the pocket for the bolt.

b. Check for misalignment of bolt and/or strike which may be preventing bolt from properly entering the strike. With the door open, extend and retract the bolt; if it is smooth, check the strike alignment.

Bolt does not extend or retract smoothly

- a. Bolt and strike are misaligned, see above.
- o. Check the backset of door relative to adjustments already made to bolt Verify proper door preparation and re-bore holes that are too small or
- d. Verify touchscreen wire harness is routed properly (see Step 10).

e. Verify bolt is installed with correct side up (see Step 6).

eypad numerics are scrolling emove interior escutcheon:

a. Check that wire terminals are securely connected.

Check that wire harness lies flat against mounting plate and is routed

through wire hook on mounting plate so cable is not pinched at any point.

Master PIN code", are deleted. All programming featur are reset to original default settings (see below).

\tv removed from door

To Remove cylinder:

- Remove the battery cover and batteries Remove the interior lock to access the reset button hole. (See image at right.)
- Re-insert 3 batteries and insert a small screwdrive into the hole; holding the reset button for 3 seconds. While still holding the reset button, insert the 4th
- battery and hold the reset button for an additional 3 seconds.

Resetting Lock to Factory Default

When resetting the lock, all user codes, including the (4" Shown)

Changing Lock: Replacing Cylinder

C. Remove cylinder by letting it drop out of assembly

A. Remove touchscreen from door.

B. Remove pan head screw.

5. Release the reset button. 6 Re-install the interior lock onto the door.

Upon reset, Master PIN Code creation is the only option

available and must be performed prior to any other programming of the lock.

For best results, the lock should be installed on the door when resetting the lock to factory default. If the process was done and the lock was not installed on the door,

review the Re-Handing instructions listed in Hardware Troubleshooting

Class B Equipment

This equipment hat since rate aster land found to romply with the limits for all Claiks Bidinita r. I8vice pursuant to E'art IS of th8 ECCRuIBs H18selimits am clesie 1ed to provid'I reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and canradiate radio irequency energy and, if not installed a11d used ir1accordance witl'1 thei1-1strudions, may cause harmful interterence to radio ommunications. Hm"lever, there is no guarantee that interfere 11ce Nill not ocr ourin a particular installation. If this equipmer, t do8s cause harmful Ir.t8ri8r8nc8 to radio or telr, visionreception...which ccJn bedetl':rmir1ed by tufllir1g the, cquip111, cnt off and on, th, c

Remient or relocated 1e r1c ceiVir g anter1na Increase thBseparation bet, veer1 tr1e equipm81-1t a1-1d receiv8r.

Connect the equipment ir1to an outlet on a circuit different iromtl1at to which th8 r8c8iV8r is conn8ct8d

Consult thl':rJeal,cror an ,cxperil':nu,rJradio/TVtc:chr,ician for help Warning: Cr1 anges or modificatior1s to this, Jevice, not expressly approved by ASSA ABLOY

coulclvoid tr1e user's authority to operate the equipment.

Causing Equipment Regulatio11s

C8t appareillagenum8riqu8 d8 la classe A r8pond a toutgs lesexigenc8s d8 l'i11terfP,rence ca11adi,cnn,ccausar,t d,cs rP,g(emc:nts d'P,ctuipement.

(11L'appareil ne doit pa, pmduire de bioullisJe
(2) L'appareil doit accc, pter truit hmuil, c,crMio<1ectrique suhl. m∳mc si le bmuillage est susceptible d'enimiprori, ettre le food</p>

should be init, lied and o,e,..t∈d ,...th a no...th a n

Copyright © 2020, 2023, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.







Max U C with Z-Wave Plus or ZigBee netwo Max User 5 without network module or with iM1 Max User Codes= 12 with Bluetooth

























Creating User PIN Codes

Police March:

FIR code

Press III

Maxuser codes = 25

Press Mil

Telor L.E. AGR PRIVATES

. . .

. . .


. . .

Provide City

Personal District

let in d. S. Start 1995 or








press No year kg

. .


. .











Definitions

Automatic Re-lock Time: Alter a successful unlock unit will re-lock automatically after duration

Inside Indicator Light: Located on interior lock. Shows activestatus (Locked) of lock and can be

Language Selling Mode: Choosing English (1), Spanish (2) or FrenGh (3) becomes the (default)

userto th8pr@vious.step

Tamper Alert: Audible alarm sounds if attempting to forcibly removeoutsidelock from door User PIN Code: Theuser code operates thelock. The maximum number of user codes with 7-Wave


Volume Setting Mode: The volume setting for PINcodeverification is set ta Low (2) lly ,Jt:1.Jult

Menu Mode Using Master PIN code*

Lock Response: "Menu mode, enter number, press O:key to continue." 3. Enter digit corresponding to the function to be performed followed by the ro-1key. Follow the voice commands.

(unlocked)

pendilen before tractic Street



Programming Troubleshooting

Touchsmen becomes active when pressed w/whole hand Use a larger area of the hand or fingers and verify contac with at least 3 areas f touchscreen numbers are visible, check to see if they Lock does not respond door is openand

espond when pressed theck batteriesare installed and oriented correctly (polarity)

heck batteriesare in good condition; replace batteries I discharged. Checkto see if touchscreen harness is fully connected

and not ninched

45 mars \$4

Lockout Mode

Set up SEOS Card

r Escape Return Mode is enabled ASSA ABLOY Accentra Configuration app. Automatic Re-lock cannot bt: enabled.

Lockout Mode

Language Setting

Manufacturer: ASSA ABLOY

Model: NTC623-ACC / NTC643-ACC

Shutdown Time The Master PIN code must be registered prior to any other progn1mming of the lock

Automatic Re-lock Inside Indicator Light

Factory Settings

Master PIN Code

Disabled Disabled (Off) ::sH is cn ouragerJto try to a:;orrer the intr::rler orir , by one ormor,::of the following Disabled Privacy Sutton Setting Volume Setting Enabled (Low) English

;m expose you to lead which is know to the state of Cilliforni♦to cause cancer ♦nd birth

defects or other reproductive harm. For more information go to www.p65wamings.ca

Registration required"

Disabled Wrong Code Entry Limit 5 Times

This Class B ,jigital apparatusmeetsall requirements of tr1e C:anaclian Ir1terference

This de,ce conlam, licency,c,,mpl eas,n;f.cr(s)rece; "ISI that compt, __;11, Innovat;c__ Science and Economic Oc.dopment Cacada's banco...,en;d RSS(s). Oc.pratu, ;__ subject 10 the rollo-_;*U1,...; cumUjens

L'(amelleur.'.;cepteur e-emr,l de lice," m.jenu-usr-ste p.eserol aow.e.lest conforme au-> c.nm ..J'innu,-a1 xia. StJences et De,etupue, ecunumique Cane-da applic,bles aux appc, reils cadiu esempts de lirence. L'e,gluit,tim est autuosee au., deux c-onditiuns suNcantes

tne tadiato, aM = >My. rn; transm;ti@t must not be co-locat-d or operating in amjunct;u; w;u, --Yulher orileaaae,

Prnduc:t Support:1-800-810-9473

