


## Operating Instructions - Dishwasher Homark DW009H

### Control Panel



1. The Programme Indicator Light: when you select the washing programme, the corresponding light will be displayed.
2. Programme Key: Press the programme key to select the required wash programme
3. Salt and Rinse Aid Warning Light: this will come on when the softener or dispenser need to be refilled (Your Apartment Manager will do this).
4. Delay Timer: Press the button to set the delay start time
5. Delayed Start Button: Press this button to set the delayed hours for washing. You can delay the start of washing up to 24 hours. One press on this button delays the start of washing by one hour.
6. Power on Light: To come on when Power On/Off button is pressed down
7. On/Off button: For power supply








### Dishwasher Features



1. Upper Basket

2. Spray Arms
3. Lower Basket
4. Water Softener
5. Main Filter
6. Detergent Dispenser
7. Cup Shelf
8. Cutlery Basket
9. Water Filter
10. Rinse Aid Dispenser

### Wash cycle table

Programme	Cycle	Cycle Selection Information	Description of Cycle
Intensive		For the heaviest soiled loads, such as pots, pans, casserole dishes and dishes that have been sitting with dried food on them for a while	Pre-rinse Pre-rinse (50°C) Wash (60°C) Rinse Rinse (70°C) Drying
Normal		For normally soiled loads, such as pots, plates, glasses and lightly soiled pans. Standard daily cycle	Pre-rinse Pre-rinse Wash (50°C) Rinse Rinse (65°C) Drying
Economy		For lightly soiled loads, such as plates, glasses, bowls and lightly soiled pans	Pre-rinse Wash (50°C) Rinse Rinse (65°C) Drying
Rinse		For dishes that need to be rinsed and dried only	Rinse Rinse (65°C) Drying
Delicate		For lightly soiled loads, such as glasses, crystal and fine china	Pre-rinse Wash (40°C) Rinse Rinse (65°C)
Rapid		A shorter wash for lightly soiled loads that do not need drying	Wash (40°C) Rinse Rinse (55°C)
Soak		To rinse dishes that you plan to wash later that day	Pre-rinse

### Starting a wash programme

1. Load the dishwasher
2. Put the detergent tablet or powder into the detergent compartment
3. Press the On/Off button to turn the machine on

4. Press the 'Programme Key' to select the 'Wash Cycle'. The LED display will always show the residual internal temperature of the dishwasher cavity. This is shown by a number and is not an error.
5. Close the door and washing will start after ten seconds.

### Approximate timing of wash cycle

Intensive	Normal	Economy	Rinse	Delicate	Rapid	Soak
127 min	117 min	102 min	50 min	70 min	45 min	7 min

### Forgotten to add a dish?

1. Open the door a little to stop the washing
2. After the spray arms stop working, you can open the door completely
3. Add forgotten dishes
4. Close the door, the dishwasher will work after 10 seconds.

### How to cancel or change a wash cycle

A cycle that is underway can only be changed if it has only been running for a short time, otherwise the detergent may have already been released and the appliance may have already drained the wash water. If this is the case, the detergent dispenser must be refilled. Open the door, press the 'Programme Key' for more than 3 seconds, then you can change the programme to the desired cycle setting. Then close the door.

- To cancel a programme and/or change the programme: Open the door, press the 'Programme Key' for more than 3 seconds, then you can change the programme to the desired cycle setting. Then close the door.
- To cancel a 'Delayed Start' press and hold down the Delayed Start button whilst switching off using the On/Off button.

### At the end of the wash cycle

When the washing cycle has finished, the dishwasher will emit an acoustic signal for 8 seconds, then stop. Wait approximately 20-30 seconds before opening the door. This will allow the dishes and utensils to cool and dry better. Open the door and turn the appliance off using the On/Off button before removing the dishes and utensils.

### Loading cutlery and dishes


The following items are not suitable for use in the dishwasher: cutlery with wooden handles, plastic items that are not heat resistant, older cutlery with glued parts that are not temperature resistant, pewter or copper items, steel items prone to rusting, wooden platters and items made from synthetic fibres.

### What do you need to do before loading the dishwasher?

- Remove all left over food and debris
- Soften remnants of burnt food in pans
- Load hollow items such as cups, glasses, pans etc. with the opening downwards so that water cannot collect in the container or a deep base.
- Dishes and items of cutlery must not lie inside one another, or cover each other
- To avoid damage to glasses they must not touch.
- Lay small items in the cutlery basket

Before closing the door, ensure that the spray arms can rotate freely.

### How to load cutlery




For best results we recommend you use the cutlery grid provided (if the size and dimensions permit)




Place knives and other items of cutlery with sharp points or edges with their handles facing upwards.




Load the basket. Arrange serving dishes and large lids around the edge of the basket.



Load upper basket. Light items (plastic bowls etc.) must not be loaded in the upper basket and arranged so they do not move.



For taller items the cup racks can be folded upwards



If plates are to be loaded in the upper basket: Load them starting from the rear positions; tilting them slightly forwards and avoiding the front positions near the door.