

Rosemount™ 5408 and 5408:SIS Level Transmitters

Non-Contacting Radar with HART® Protocol



HART 
COMMUNICATION PROTOCOL

Safety messages

NOTICE

Read this manual before working with the product. For personal and system safety, and for optimum product performance, ensure you thoroughly understand the contents before installing, using, or maintaining this product.

For technical assistance, contacts are listed below:

Customer Central

Technical support, quoting, and order-related questions.

- United States - 1-800-999-9307 (7:00 am to 7:00 pm CST)
- Asia Pacific- 65 777 8211

North American Response Center

Equipment service needs.

- 1-800-654-7768 (24 hours a day — includes Canada)
- Outside of these areas, contact your local Emerson representative.

⚠ WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure the transmitter is installed by qualified personnel and in accordance with applicable code of practice.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- For installations in hazardous locations, the transmitter must be installed according to the Rosemount 5408 and 5408:SIS [Product Certifications](#) document and System Control Drawing (D7000002-885).

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.
- Both transmitter covers must be fully engaged to meet Explosion-proof/Flameproof requirements.

Electrical shock could cause death or serious injury.

- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.
- Ensure the mains power to the transmitter is off and the lines to any other external power source are disconnected or not powered while wiring the transmitter.

Process leaks could result in death or serious injury.

- Ensure that the transmitter is handled carefully. If the process seal is damaged, gas might escape from the tank.

Any substitution of non-recognized parts may jeopardize safety. Repair (e.g. substitution of components) may also jeopardize safety and is not allowed under any circumstances.

- Unauthorized changes to the product are strictly prohibited as they may unintentionally and unpredictably alter performance and jeopardize safety. Unauthorized changes that interfere with the integrity of the welds or flanges, such as making additional perforations, compromise product integrity and safety. Equipment ratings and certifications are no longer valid on any products that have been damaged or modified without the prior written permission of Emerson. Any continued use of product that has been damaged or modified without the written authorization is at the customer's sole risk and expense.

⚠ WARNING

Physical access

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access by unauthorized personnel to protect end users' assets. This is true for all systems used within the facility.

⚠ CAUTION

Hot surfaces

The flange and process seal may be hot at high process temperatures. Allow to cool before servicing.



⚠ CAUTION

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings. For information on Rosemount nuclear-qualified products, contact your local Emerson Sales Representative.

Contents

Chapter 1	Introduction.....	9
	1.1 Using this manual.....	9
	1.2 Product recycling/disposal.....	9
Chapter 2	Transmitter overview.....	11
	2.1 Measurement principle.....	11
	2.2 Process characteristics.....	12
	2.3 Vessel characteristics.....	14
	2.4 Application examples.....	14
	2.5 Components of the transmitter.....	17
	2.6 System integration.....	19
Chapter 3	Mechanical installation.....	21
	3.1 Safety messages.....	21
	3.2 Confirm approval type.....	22
	3.3 Installation considerations.....	22
	3.4 Mounting preparations.....	32
	3.5 Mount the cone antenna.....	36
	3.6 Mount the process seal antenna.....	51
	3.7 Mount the parabolic antenna.....	55
	3.8 Adjust display orientation (optional).....	73
Chapter 4	Electrical installation.....	75
	4.1 Safety messages.....	75
	4.2 Hazardous areas.....	76
	4.3 Prepare the electrical connections.....	76
	4.4 Connect wiring and power up.....	79
	4.5 Optional devices.....	82
Chapter 5	Configuration.....	85
	5.1 Safety messages.....	85
	5.2 Overview.....	85
	5.3 System readiness.....	86
	5.4 Get started with your preferred configuration tool.....	87
	5.5 Confirm HART [®] revision capability.....	89
	5.6 Configure transmitter using guided setup.....	90
	5.7 Verify level.....	91
	5.8 Establish multidrop communication.....	92
	5.9 Use with the Rosemount 333 HART [®] Tri-Loop [™]	93
	5.10 Write protect a transmitter.....	95

Chapter 6	Operation.....	97
	6.1 LCD display screen messages.....	97
	6.2 Set up the LCD display.....	99
	6.3 Smart echo level test.....	100
	6.4 View measurement data.....	101
	6.5 Device status.....	103
Chapter 7	Service and troubleshooting.....	107
	7.1 Safety messages.....	107
	7.2 Diagnostic messages per NAMUR NE 107.....	108
	7.3 Troubleshooting guides.....	122
	7.4 Service and troubleshooting tools.....	137
	7.5 Application challenges.....	156
	7.6 Replace the transmitter head.....	163
	7.7 Cleaning or replacing the PTFE sealing.....	166
	7.8 Service support.....	171
Appendix A	Specifications and reference data.....	173
	A.1 Performance specifications.....	173
	A.2 Functional specifications.....	176
	A.3 Physical specifications.....	186
	A.4 Spare parts and accessories.....	188
	A.5 Dimensional drawings.....	202
Appendix B	Product certifications.....	213
	B.1 European directive information.....	213
	B.2 Safety Instrumented Systems (SIS).....	213
	B.3 Ordinary location certification.....	213
	B.4 Telecommunication compliance.....	213
	B.5 FCC.....	214
	B.6 IC.....	214
	B.7 Radio Equipment Directive (RED) 2014/53/EU.....	215
	B.8 Installing equipment in North America.....	215
	B.9 USA.....	216
	B.10 Canada.....	219
	B.11 Europe.....	223
	B.12 International.....	227
	B.13 Brazil.....	230
	B.14 China.....	231
	B.15 Technical Regulations Customs Union (EAC).....	232
	B.16 Japan.....	235
	B.17 India.....	235
	B.18 Republic of Korea.....	236

	B.19 United Arab Emirates.....	237
	B.20 Additional certifications.....	237
	B.21 Hygienic certificates and approvals.....	239
	B.22 Pattern approval.....	240
	B.23 Installation drawings.....	241
Appendix C	Configuration parameters.....	251
	C.1 Menu tree.....	251
	C.2 Device setup.....	253
	C.3 Level setup.....	257
	C.4 Alert setup.....	274

1 Introduction

1.1 Using this manual

The sections in this manual provide information on installing, operating, and maintaining the Rosemount™ 5408 and 5408:SIS Level Transmitters – Non-Contacting Radar.

The sections are organized as follows:

[Transmitter overview](#) provides an introduction to theory of operation, a description of the transmitter, information on typical applications, and process characteristics.

[Mechanical installation](#) contains mechanical installation instructions.

[Electrical installation](#) contains electrical installation instructions.

[Configuration](#) provides instructions on configuration of the transmitter.

[Operation](#) contains operation and maintenance techniques.

[Service and troubleshooting](#) provides troubleshooting techniques for the most common operating problems.

[Specifications and reference data](#) supplies reference and specification data, as well as ordering information for spare parts and accessories.

[Product certifications](#) contains safety approval information and approval drawings.

[Configuration parameters](#) provides extended information about the configuration parameters.

1.2 Product recycling/disposal

Recycling of equipment and packaging should be taken into consideration and disposed of in accordance with local and national legislation or regulations.

2 Transmitter overview


2.1 Measurement principle

The Rosemount 5408 is a two-wire transmitter for continuous level measurements using fast-sweep Frequency Modulated Continuous Wave (FMCW) technology.

The transmitter continuously emits signal sweeps with a constantly varying frequency towards the product surface. Since the transmitter continuously changes the frequency of the transmitted signal, there will be a difference in frequency between the transmitted and the reflected signals (see Figure 2-1).

The frequency of the reflected signal is subtracted from the frequency of the signal transmitted at that moment, resulting in a low frequency signal which is proportional to the distance to the product surface. This signal is further processed to obtain fast, reliable, and highly accurate level measurements.

Figure 2-1: FMCW-method




$$\Delta f \sim d = \text{distance}$$

- A. Frequency (GHz)
- B. Time (s)
- C. Transmitted signal
- D. Reflected signal

2.1.1 Signal processing

See [Figure 2-2](#) for a schematic overview of the signal processing.

Figure 2-2: Flowchart of the Signal Processing



2.2 Process characteristics

2.2.1 Dielectric constant

A key parameter for measurement performance is reflectivity. A high dielectric constant of the media provides better reflection and enables a longer measuring range.

2.2.2 Foam and turbulence

Foaming liquids or turbulence may cause weak and varying surface echo amplitudes. The effects of turbulence are usually minor, but in the most challenging conditions, the

transmitter may be mounted in a still pipe. In addition, measurement performance can be optimized by configuring the appropriate process conditions settings.

Measurement in foamy applications depends largely on the foam properties. When the foam is light and airy, the actual product level is measured. For heavy and dense foam, the transmitter may measure the level of the foam's upper surface.

The Double Surface Handling function allows the user to select if the foam layer or product surface should be used as output.

Related information

[Process conditions](#)

[Double surface handling](#)

2.2.3 Dust

Dust is often present in solids applications, and even if the non-contacting radar is not affected by the dust in the vapor space, dust can be sticky and create a layer on the antenna. If this layer becomes too thick, it may affect the measurement. This is best managed by using air purging.

2.2.4 Solid surface

Solids have some common characteristics which may cause weak and varying surface reflections. The surface is rarely flat or horizontal, the angle of the sloping surface differs during filling and emptying, and the dielectric constant of many solids is fairly low. [Table 2-1](#) presents common characteristics of some solids applications.

The parabolic antenna is ideal for applications with weak surface reflections. A larger diameter concentrates the radar beam and ensures maximum antenna gain. The parabolic antenna comes with a swivel connection that adjusts for angled tank roofs.

Table 2-1: Common Characteristics of Solids Applications

Applications	Common characteristics				
	Particle size			Vapor space	
	Dust or powder	Small (<1 in.)	Larger (>1 in.)	Dust	Steam or condensation
Wood chip bins	Yes	Yes	Yes	Yes	Possible
Grain silo - small kernel grains	Yes	Yes	No	Yes	No
Grain silo - large kernel grains	No	Yes	No	No	No
Lime stone silo	No	Yes	Yes	Possible	No
Cement - raw mill silo	Yes	Yes	No	Yes	No
Cement - finished product silo	Yes	Yes	No	Yes	No
Coal bin	Yes	Yes	Yes	Yes	Yes
Saw dust	Yes	Yes	No	Yes	No
High consistency - pulp stock	No	No	No	No	Yes
Alumina	Yes	Yes	No	Yes	No
Salt	No	Yes	Yes	No	No

2.3 Vessel characteristics

2.3.1 In-tank obstructions

The transmitter should be mounted so that objects such as heating coils, ladders, and agitators are not in the radar signal path. These objects may cause false echoes resulting in reduced measurement performance. However, the transmitter has built-in functions designed to reduce the influence from disturbing objects where such objects cannot be totally avoided.

Vertical and inclined structures cause minimal effect since the radar signal is scattered rather than directed back to the antenna.

2.3.2 Tank shape

The shape of the tank bottom affects the measurement signal when the product surface is close to the tank bottom. The transmitter has built-in functions which optimize measurement performance for various bottom shapes.


2.4 Application examples

The Rosemount 5408 and 5408:SIS are ideal for level measurements over a broad range of liquid and solids applications. The transmitters are virtually unaffected by changing density, temperature, pressure, media dielectric, pH, and viscosity. Non-contacting radar

level is ideal for harsh conditions such as corrosive and sticky media, or when internal tank obstructions are a limiting factor.


Storage and buffer tanks

The Rosemount 5408 provides accurate and reliable level measurement for both metallic or non-metallic vessels containing almost any liquid (e.g. oil, gas condensate, water, chemicals).




Reactors

The Rosemount 5408 is ideal for the most challenging applications, including reactors where there can be agitation, foaming, and condensation, as well as high temperatures and pressures.




Blenders and mixers

The Rosemount 5408 can help you withstand the rigors of blenders and mixing tanks. Easy to install and commission, it is also unaffected by virtually any fluid property change.




Open atmospheric applications

The Rosemount 5408 measures reliably in open applications, from short range sumps or ponds to long range dams.



Still pipe and chamber installations

The Rosemount 5408 is a great choice for level measurement in tanks with small diameter still pipes. It may also be used in chambers, but guided wave radar is generally the best fit for these applications. For more information on using the Rosemount 5408 in still pipes and chambers refer to the Best Practices for Using Radar in Still Pipes and Chambers [Technical Note](#).




Bulk solids

The Rosemount 5408 is the ideal solution for small- to medium-sized silos with rapid level changes. The narrow beam avoids internal obstructions while still keeping good level measurement.



Safety applications


The Rosemount 5408:SIS is the ideal choice for safety functions such as overfill prevention, level deviation monitoring or dry-run prevention.



2.5 Components of the transmitter

Figure 2-3 shows the different components of the transmitter. There are different antenna types and sizes available for various applications.

Figure 2-3: Components



- A. Terminal compartment
- B. Transmitter housing (aluminum or stainless steel)
- C. Sensor module with signal processing electronics
- D. External ground screw
- E. Flanged process connection
- F. Cone antenna
- G. Two cable/conduit entries ($\frac{1}{2}$ -14 NPT, M20 x 1.5, or G $\frac{1}{2}$); Optional adapters: eurofast™ and minifast™
- H. LCD display (optional)
- I. Alignment marker (one per side)
- J. Threaded process connection (NPT or BSPP (G))
- K. Air purge ring (option code PC1 for cone antenna)
- L. Integrated air purge connection
- M. Parabolic antenna
- N. Parabolic antenna with swivel mount
- O. Process seal antenna
- P. Tri Clamp process connection


2.6 System integration

The transmitter is loop-powered, and uses the same two wires for power supply and output signal. The output is a 4-20 mA analog signal superimposed with a digital HART® signal. The transmitter can be configured for either HART Revision 6 (default) or 7 (option code HR7). The HART Revision can be switched in field.

By using the optional Rosemount 333 HART Tri-Loop™, the digital HART signal can be converted into three additional 4-20 mA analog signals. With the HART protocol, multidrop configuration is possible. In this case, communication is restricted to digital, since current is fixed to the 4 mA minimum value.

The transmitter can be combined with the Emerson Wireless 775 THUM™ Adapter to wirelessly communicate HART data with IEC 62591 (*WirelessHART*®) technology. In addition, the transmitter can be connected to a Rosemount 751 Field Signal Indicator, or it can be equipped with an integral display.

Figure 2-4: System Architecture



- A. Emerson Wireless 775 THUM Adapter
- B. Rosemount 5408
- C. Rosemount 751
- D. Handheld communicator
- E. Approved IS barrier (for Intrinsically Safe installations only)
- F. Rosemount 333
- G. Host/DCS system
- H. HART modem
- I. Rosemount Radar Master Plus or AMS Device Manager


The transmitter can easily be configured by using a PC with the Rosemount Radar Master Plus software (running in the Instrument Inspector™ Application), a handheld

communicator, the AMS Device Manager, or any other Device Descriptor (DD), Device Type Manager (DTM™), or Field Device Integration (FDI) compatible host system.

The Rosemount 5408 is compliant with NAMUR NE 107 Field Diagnostics for standardized device diagnostic information.

3 Mechanical installation

3.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol () . Refer to the following safety messages before performing an operation preceded by this symbol.

WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure the transmitter is installed by qualified personnel and in accordance with applicable code of practice.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- For installations in hazardous locations, the transmitter must be installed according to the Rosemount 5408 and 5408:SIS [Product Certifications](#) document and System Control Drawing (D7000002-885).

Process leaks could result in death or serious injury.

- Ensure that the transmitter is handled carefully. If the process seal is damaged, gas might escape from the tank.

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.


3.2 Confirm approval type

For hazardous locations transmitters labeled with multiple approval types:

Procedure

Permanently mark the checkbox of the selected approval type(s).

Figure 3-1: Label with Multiple Approval Types



3.3 Installation considerations

Before installing the transmitter, follow recommendations for mounting position, sufficient free space, nozzle requirements, etc.


3.3.1 Mounting position

When finding an appropriate location on the tank for the transmitter, the conditions of the tank must be carefully considered.

Consider the following guidelines when mounting the transmitter:

- For optimal performance, the transmitter should be installed in locations with a clear and unobstructed view of the product surface.
- The transmitter should be mounted with as few internal structures as possible within the signal beam.
- Do not install the transmitter in the center of the tank.
- Do not mount close to or above the inlet stream.
- Multiple Rosemount 5408 transmitters can be used in the same tank without interfering with each other.

Figure 3-2: Recommended Mounting Position



3.3.2 Free space requirements

If the transmitter is mounted close to a wall or other tank obstruction such as heating coils and ladders, noise might appear in the measurement signal. Therefore the following minimum clearance, according to [Table 3-1](#), must be maintained.

For easy access to the transmitter, mount it with sufficient service space (see [Table 3-2](#)).

Figure 3-3: Free Space Requirements




Table 3-1: Distance to Tank Wall (L)

Application	Minimum	Recommended
Liquids	8 in. (200 mm)	½ of tank radius
Solids	8 in. (200 mm)	⅔ of tank radius

Table 3-2: Free Space Requirements

Description	Distance
Service space width (A)	20 in. (500 mm)
Service space height (B)	24 in. (600 mm)

3.3.3 Antenna size

Choose as large antenna diameter as possible. A larger antenna diameter concentrates the radar beam and ensures maximum antenna gain. Increased antenna gain permits greater margin for weak surface echoes.


In addition, a larger antenna diameter results in a smaller beam angle and thereby, less interference from any internal structures in the tank.

3.3.4 Antenna inclination

Ensure the antenna is aligned perpendicular to the product surface (see [Figure 3-4](#)). The parabolic antenna comes with a swivel connection that adjusts for angled tank roofs.

Note that if the surface echo is weak in solids applications, then a small inclination of the parabolic antenna toward the surface slope may improve the performance.

Figure 3-4: Inclination



3.3.5 Non-metallic tanks

Nearby objects outside the tank may cause disturbing radar echoes. Wherever possible, the transmitter should be positioned so that objects close to the tank are kept outside the signal beam.

3.3.6 Beam width and beam angle

The transmitter should be mounted with as few internal structures as possible within the signal beam. Refer to [Table 3-3](#) for beam angle and [Table 3-4](#) for beam width at different distances.

Figure 3-5: Beam Angle and Beam Width




Table 3-3: Beam Angle

Antenna size	Beam angle (α)
1½-in. (DN 40) cone	22°
2-in. (DN50) cone/process seal	18°
3-in. (DN80) cone/process seal	14°
4-in. (DN100) cone/process seal	10°
8-in. (DN200) parabolic	4.5°

Table 3-4: Beam Width, ft. (m)

Distance (D)	Beam width (W)				
	1½-in. cone	2-in. cone/ process seal	3-in. cone/ process seal	4-in. cone/ process seal	Parabolic
16 (5)	6.2 (1.9)	5.2 (1.6)	4.0 (1.2)	2.9 (0.9)	1.3 (0.4)
33 (10)	12.8 (3.9)	10.4 (3.2)	8.1 (2.5)	5.7 (1.8)	2.6 (0.8)
49 (15)	19.0 (5.8)	15.6 (4.8)	12.1 (3.7)	8.6 (2.6)	3.9 (1.2)
66 (20)	25.6 (7.8)	20.8 (6.3)	16.1 (4.9)	11.5 (3.5)	5.2 (1.6)
82 (25)	31.8 (9.7)	26.0 (7.9)	20.1 (6.1)	14.3 (4.4)	6.4 (2.0)
98 (30)	38.4 (11.7)	31.2 (9.5)	24.2 (7.4)	17.2 (5.3)	7.7 (2.4)
131 (40)	51.2 (15.6)	41.6 (12.7)	32.2 (9.8)	23.0 (7.0)	10.3 (3.1)

3.3.7 Nozzle requirements

To allow the microwaves to propagate undisturbed, the nozzle dimensions should be kept within the specified limits as given in [Table 3-5](#), [Table 3-6](#), and [Table 3-7](#).

Nozzle requirements for cone antenna

For best performance, the cone antenna should extend at least 0.4 in. (10 mm) below the nozzle. If required, use the extended cone antenna versions (option code S1 or S2).

However, the antenna can be recessed in smooth nozzles up to 4 ft. (1.2 m). Note that if the inside of the nozzle has irregularities (e.g. due to bad welding, rust, or deposit), then use the extend cone antenna.

Figure 3-6: Mounting of the Cone Antenna




Table 3-5: Nozzle Requirements for Cone Antenna, in Inches (Millimeters)

Antenna size	Minimum nozzle diameter (D) ⁽¹⁾	Recommended maximum nozzle height (H) ⁽²⁾⁽³⁾	
		Antenna	Antenna with air purge ring (code PC1)
1½-in. (DN 40)	1.50 (38.1)	5.59 (142)	N/A
2-in. (DN50)	1.94 (49.3)	5.71 (145)	4.69 (119)
3-in. (DN80)	2.80 (71.0)	5.63 (143)	4.61 (117)
4-in. (DN100)	3.78 (96.0)	6.54 (166)	5.51 (140)

(1) The antennas are sized to fit within schedule 80 or lower schedules.

(2) The values are valid for cone antennas without antenna extension.

(3) For liquid applications, the cone antenna can be recessed in smooth nozzles up to 4 ft. (1.2 m), but note that the accuracy may be reduced in the region close to the nozzle.

Nozzle requirements for process seal antenna

The antenna can be used on nozzles up to 4 ft. (1.2 m). Disturbing objects inside the nozzle may impact the measurement, and should therefore be avoided.

Figure 3-7: Mounting of the Process Seal Antenna




Table 3-6: Nozzle Requirements for Process Seal Antenna

Antenna size	Minimum nozzle diameter (D) ⁽¹⁾	Recommended maximum nozzle height (H) ⁽²⁾
2-in. (DN50)	1.77 in. (45 mm)	4 ft. (1.2 m)
3-in. (DN80)	2.76 in. (70 mm)	4 ft. (1.2 m)
4-in. (DN100)	2.76 in. (70 mm)	4 ft. (1.2 m)


⁽¹⁾ The antennas are sized to fit within schedule 120 or lower schedules.

⁽²⁾ For hygienic applications, the nozzle height (H) must not exceed two times the nozzle diameter (D) to ensure cleanability. Maximum nozzle height is 5 in. (127 mm).

Nozzle requirements for parabolic antenna

See [Table 3-7](#) for nozzle height recommendations at different inclination angle.

Figure 3-8: Mounting of the Parabolic Antenna



A. Nozzle mounting

B. Flange mounting in manhole cover

Table 3-7: Nozzle Requirements for Parabolic Antenna, in Inches (Millimeters)

Nozzle size (D)	Inclination angle (α)	Maximum nozzle height (H) ⁽¹⁾
Pipe schedule std, Ø 8 in. (200 mm)	0°	6.1 (155)
	3°	3.4 (85)
	6°	1.6 (40)
	9°	1.2 (30)
	12°	1.0 (25)
	15°	0.6 (15)
Pipe schedule std, Ø10 in. (250 mm)	0°	17.2 (440)
	3°	10.2 (260)
	6°	7.1 (180)
	9°	5.1 (130)
	12°	3.9 (100)
	15°	3.0 (75)

(1) Note that the inside of the nozzle must be smooth (i.e. avoid bad welding, rust, or deposit).

3.3.8 Still pipe/chamber installations

Installation in still pipe/chamber is recommended for tanks where there are excessive foaming or turbulence. Still pipe/chamber may also be used to avoid disturbing objects in the tank.

For more information and installation requirements, refer to the Best Practices for Using Radar in Still Pipes and Chambers [Technical Note](#).


Still pipe

Consider the following still pipe requirements:

- Pipe**
 - Pipes should be an all-metal material.
 - Pipe should have a constant inside diameter.
 - The inner surface must be smooth and clear of any rough edges. (Smooth pipe joints are acceptable, but may reduce accuracy.)
 - The end of the pipe must extend beyond the zero level.
- Holes**
 - Maximum hole diameter is 1 in. (25 mm).
 - Minimum distance between holes is 6 in. (150 mm).
 - Holes should be drilled on one side only and deburred.
 - Drill one hole above maximum product surface.

- Antenna**
- All cone/process seal antenna sizes can be used for still pipe/chamber installations.
 - The gap between the cone antenna and the still pipe should be maximum 0.2 in. (5 mm)⁽¹⁾. Larger gaps may result in inaccuracies. If required, order a larger antenna and cut on location. See [Table A-15](#) for antenna dimensions.

Figure 3-9: Still Pipe Requirements



- A. Maximum 0.2 in. (5 mm)
B. Maximum 1 in. (25 mm)
C. Minimum 6 in. (150 mm)
D. Maximum 1°
E. Level = 100%
F. Level = 0%

Chamber


Consider the following chamber requirements:

- Pipes should be an all-metal material.
- Pipe should have a constant inside diameter.
- Inlet pipes should not protrude into the inside of the stand pipe.

⁽¹⁾ A larger gap is inevitable for the 4-in. cone antenna in pipes with a diameter larger than 4 in.

- The inner surface must be smooth and clear of any rough edges. (Smooth pipe joints are acceptable, but may reduce accuracy.)
- The gap between the cone antenna and the stand pipe should be maximum 0.2 in. (5 mm)⁽¹⁾. Larger gaps may result in inaccuracies. If required, order a larger antenna and cut on location. See [Table A-15](#) for antenna dimensions.

Figure 3-10: Chamber Requirements



- A. Minimum 0.4 in. (10 mm)
- B. Minimum 6 in. (150 mm)
- C. Maximum 1°
- D. Maximum 0.2 in. (5 mm)

3.3.9 Ball valve installation

The transmitter can be isolated from the process by using a valve:

- Use a full-port ball valve.
- Ensure there is no edge between the ball valve and the nozzle or still pipe, the inside should be smooth.
- Valves can be combined with still pipes.
- The ball valve should have the same inner diameter as the still pipe.

3.3.10 Shipboard installations

Transmitters with aluminum housing are not approved for open deck installations; for use only in engine room, pump room, etc.

For application conditions and limitations refer to the applicable shipboard approval.

3.4 Mounting preparations

3.4.1 Assemble the segmented cone antenna


Prerequisites

This section applies to the segmented cone antenna (option code S2). Use only one segment; the total antenna length should not exceed 47.2 in. (1200 mm).

Procedure


1. Determine the antenna length.

Figure 3-11: Installation Recommendation




A. Min. 0.4 in. (10 mm)


2. Insert the segment into the cone antenna until it bottoms.




3. Mark where to cut the segment.



4. Remove and cut the segment at the marking.




5. Remove any burrs.
6. Insert the segment into the cone antenna until it bottoms.




7. Secure the segment to the antenna.

Note

Be careful of sharp edges. Wear protective gloves!



8. Measure the Antenna Extension Length (L).



9. Update the transmitter configuration to the new Antenna Extension Length (L).
 - Rosemount Radar Master Plus:
 - Under **Configure**, select **Level Setup** → **Antenna**.
 - AMS Device Manager and handheld communicator:
 - Select **Configure** → **Manual Setup** → **Level Setup** → **Antenna**.

3.4.2 Shorten the extended cone antenna


Prerequisites

This section only applies to the extended cone antenna (option code S1).


Procedure

1. Determine the antenna length.


Figure 3-12: Installation Recommendation



2. Mark where to cut the antenna.




3. Cut the antenna at the marking.



4. Remove any burrs.

5. Measure the Antenna Extension Length (L).



6. Update the transmitter configuration to the new Antenna Extension Length (L).

- Rosemount Radar Master Plus:
 - Under **Configure**, select **Level Setup** → **Antenna**.
- AMS Device Manager and handheld communicator:
 - Select **Configure** → **Manual Setup** → **Level Setup** → **Antenna**.

3.4.3 Replace the transmitter head nut

When mounting on a legacy Rosemount 5402 antenna, the transmitter head nut must be changed from size M50 to M52.

Prerequisites


Applies only to transmitters ordered with the option code A1.

Procedure


1. Remove the stop ring using a flat head screwdriver.

Tip

Wear gloves to increase grip when using the tool!




2. Replace the transmitter head nut.



3. Mount the stop ring.

Use the new stop ring supplied with the kit.



Prerequisites

Ensure to set the Antenna Type to Legacy (Rosemount 5402), and then set the User Defined Antenna Options parameters.


Related information

[User defined antenna options](#)

3.5 Mount the cone antenna

3.5.1 Overview

Figure 3-13: Overview




- A. Flanged version (see [page 37](#))
- B. Flanged version with air purge ring (see [page 38](#))
- C. Threaded version, $D < d$ (see [page 41](#))
- D. Threaded version, $D > d$ (see [page 44](#))
- E. Bracket mounting (see [page 47](#))

3.5.2 Protective cap

For spare antennas, keep the protective cap in place until installing the transmitter head. The cap protects the process seal from dust and water.

Figure 3-14: Protective Cap




3.5.3 Flanged version

Prerequisites


If applicable, assemble the segmented cone antenna.

Procedure


1. Place a suitable gasket on the tank flange.



2. Lower transmitter with antenna and flange into the nozzle.



3. Tighten bolts and nuts with sufficient torque for the flange and gasket choice.



Postrequisites

Align the transmitter head.

Related information

[Assemble the segmented cone antenna](#)

[Align transmitter head](#)


3.5.4 Flanged version with air purge ring (option code PC1)

Prerequisites


If applicable, assemble the segmented cone antenna.

Procedure

1. Place a suitable gasket on the tank flange.




2. Place the purge ring over the gasket.




3. Place a suitable gasket over the purge ring.

Note

A minimum gasket thickness of 0.125 in. (3.2 mm) is required for flanges with protective plate design.




4. Lower transmitter with antenna and flange into the nozzle.




A. Antenna with air purge holes

5. Tighten bolts and nuts with sufficient torque for the flange and gasket choice.



A. 1.0 in. (25.5 mm)

6. Connect the air purging system. Use thread sealant or suitable gasket according to your site procedures.



- A. $G\frac{3}{8}$ -in.
B. 0.4 in. (10 mm)

Table 3-8: Incoming Air Supply Specification

Maximum pressure	Recommended pressure
190 psi (13 bar)	100 to 115 psi (7 to 8 bar)

Postrequisites

Align the transmitter head.

Related information

[Assemble the segmented cone antenna](#)
[Align transmitter head](#)

3.5.5 Threaded version, antenna diameter smaller than thread diameter


Threaded tank connection

Prerequisites


If applicable, assemble the segmented cone antenna.

Procedure

1. Apply anti-seize paste or PTFE tape on threads according to your site procedures.
⚠ Gasket may be used as a sealant for adapters with 1½- or 2-in. BSPP (G) threads.



2. Mount the transmitter on the tank.



A. Gasket (for 1½-in. and 2-in. BSPP (G) threads only)

Postrequisites

Align the transmitter head.

Related information

[Assemble the segmented cone antenna](#)

[Align transmitter head](#)


Flanged tank connection

Prerequisites


If applicable, assemble the segmented cone antenna.

Procedure


1. Place a suitable gasket on the tank flange.



2. Place the customer supplied flange over the gasket.




3. Tighten the bolts and nuts with sufficient torque for the flange and gasket choice.




4. Apply anti-seize paste or PTFE tape on threads according to your site procedures.

⚠ Gasket may be used as a sealant for adapters with 1½- or 2-in. BSPP (G) threads.



5. Lower transmitter with antenna into the nozzle.



A. Gasket (for 1½-in. and 2-in. BSPP (G) threads only)

Postrequisites

Align the transmitter head.

Related information

[Assemble the segmented cone antenna](#)

[Align transmitter head](#)


3.5.6 Threaded version, antenna diameter larger than thread diameter

Prerequisites

If applicable, assemble the segmented cone antenna.


Procedure

1. Unscrew and remove the antenna.




Note

Be careful not to scratch the microwave launcher. The microwave launcher is sensitive to mechanical impacts.




2. Apply anti-seize paste or PTFE tape on threads according to your site procedures.

⚠ Gasket may be used as a sealant for adapters with 1½- or 2-in. BSPP (G) threads.



3. Mount the adapter on the customer supplied flange.




A. Gasket (for 1½-in. and 2-in. BSPP (G) threads only)


4. Mount the antenna.

Note


Visually inspect the microwave launcher for damage and dirt.




5. Place a suitable gasket on the tank flange.




6. Lower transmitter with antenna and flange into the nozzle.



7. Tighten the bolts and nuts with sufficient torque for the flange and gasket choice.



8. Screw the adapter until it is properly tightened.



Postrequisites

Align the transmitter head.

Related information

[Assemble the segmented cone antenna](#)


[Align transmitter head](#)

3.5.7 Bracket mounting

Procedure


1. Mount the bracket to the pipe/wall.

On pipe:




A. Horizontal pipe
B. Vertical pipe


On wall:



2. Mount the holder to the bracket.




3. Unscrew and remove the antenna.




Note


Be careful not to scratch the microwave launcher. The microwave launcher is sensitive to mechanical impacts.



4. Screw the transmitter into the holder.




5. Mount the antenna.



3.5.8 Align transmitter head

Procedure

1. Loosen the nut slightly and turn the transmitter.



2. Verify the transmitter head is properly aligned.

Option	Description
Open tank	Align the marking on the sensor module toward the tank wall (see Figure 3-15).
Still pipe	Align the external ground screw toward the holes of the still pipe (see Figure 3-16).
Chamber	Align the external ground screw toward the process connections (see Figure 3-17).

3. Tighten the nut.




Figure 3-15: Open Tank




Figure 3-16: Still pipe






Figure 3-17: Chamber



3.6 Mount the process seal antenna

3.6.1 Overview

Figure 3-18: Overview




- A. Flanged version (see [page 51](#))
- B. Tri Clamp version (see [page 53](#))
- C. Bracket mounting (see [page 54](#))

3.6.2 Mount the flanged version


Procedure

1. Lower the transmitter into the nozzle.



Note

Be careful not to scratch or otherwise damage the PTFE sealing.



2. Tighten the bolts and nuts (see [Table 3-9](#)).

Note

- Re-tighten after 24 hours and again after the first temperature cycle.
- Check at regular intervals and re-tighten if necessary.




Table 3-9: Torque Value, lb-ft (N-m)

Process connection size ⁽¹⁾⁽²⁾	Process connection rating ⁽¹⁾⁽²⁾					
	ASME B16.5		EN1092-1			JIS B2220
	Class 150	Class 300	PN6	PN10/ PN16	PN25/PN40	10K
2-in./DN50/50A	29 (40)	52 (70)	15 (20)	26 (35)	29 (40)	18 (25)
3-in./DN80/80A	33 (45)	48 (65)	37 (50)	37 (50)	41 (55)	22 (30)
4-in./DN100/100A	59 (80)	52 (70)	37 (50)	37 (50)	74 (100)	26 (35)

(1) The conditions used for the calculation are: Standard mating metal flange, A193 B8M Cl.2 / A4-70 bolt material, and a friction coefficient of $\mu=0.16$.

(2) Low strength bolt and non-metallic mating flange may require lower tightening torque.

Postrequisites

Align the transmitter head.


Related information

[Align transmitter head](#)

3.6.3 Mount the Tri Clamp version


Procedure

1. Lower the transmitter into the nozzle.




Note

Be careful not to scratch or otherwise damage the PTFE sealing.



2. Tighten the clamp to the recommended torque (see the manufacturer's instruction manual).



Postrequisites

Align the transmitter head.

Related information


[Align transmitter head](#)

3.6.4 Bracket mounting

Procedure


1. Mount the bracket to the pipe/wall.

On pipe:




- A. Horizontal pipe
B. Vertical pipe

On wall:




2. Mount the transmitter to the bracket.



3.7 Mount the parabolic antenna

3.7.1 Overview

Figure 3-19: Overview




- A. Flanged version (see [page 58](#))
- B. Threaded version (see [page 59](#))
- C. Welded version (see [page 62](#))
- D. Bracket mounting (see [page 66](#))

3.7.2 Components of the parabolic antenna

Components of the threaded version


Figure 3-20: Components



- A. Antenna
- B. Purge plug kit
- C. Threaded sleeve
- D. M20 adapter
- E. Lock nut BSPP (G) 3½-in.
- F. Antenna adapter with ball joint
- G. O-ring

Components of the welded version

Figure 3-21: Components




- A. Antenna
- B. Purge plug kit
- C. Threaded sleeve
- D. M20 adapter
- E. Weld protection plate
- F. Flange ball
- G. O-ring
- H. Clamp flange
- I. Washer
- J. M8 screw
- K. Weld protection bar
- L. Ball joint


3.7.3 Mount the flanged version

Procedure


1. Place a suitable gasket on the tank flange.



2. Lower the flange and antenna assembly into the nozzle.



3. Tighten the bolts and nuts with sufficient torque for the flange and gasket choice.



Postrequisites

1. Adjust the inclination of the antenna.
2. Connect the air purging system.

Related information


[Adjust the inclination of the antenna](#)

[Connect the air purging](#)


3.7.4 Mount the threaded version

Procedure


1. Remove the lock nut.



2. Mount the O-ring.




3. Mount the antenna adapter on flange/manhole cover. Ensure the antenna adapter fits tightly to the flange/manhole cover.




A. $\varnothing 3.98 \pm 0.02$ in. ($\varnothing 101 \pm 0.6$ mm) or G 3½-in.
B. Max. 0.59 in. (15 mm)


4. Remove the M20 adapter and visually inspect the O-rings for damage and dirt.




5. Carefully insert the antenna.




6. Secure the antenna.




7. Tighten the set screw.




8. Place a suitable gasket on the tank flange.



9. Lower the antenna assembly into the tank.



10. Tighten the bolts and nuts with sufficient torque for the flange and gasket choice.



Postrequisites

1. Adjust the inclination of the antenna.
2. Connect the air purging system.

Related information


[Adjust the inclination of the antenna](#)

[Connect the air purging](#)

3.7.5 Mount the welded version

Procedure


1. Mount the protection plates to flange/manhole cover. These plates protect the internal surfaces of the flange ball from dust and sparks during welding.




A. $\varnothing 3.94 \pm 0.02$ in. ($\varnothing 100 \pm 0.5$ mm)

B. Max. 1.18 in. (30 mm)


2. Weld the flange ball.



3. Remove the protection plates and visually inspect the internal surfaces of the flange ball for damage and dirt.





4. Mount the O-ring.




5. Mount the ball joint.


- a) Insert the ball joint and place the clamp flange with the “7 Nm” marking side up.
- b) Gradually tighten the M8 screws.




6. Remove the M20 adapter and visually inspect the O-rings for damage and dirt.




7. Carefully insert the antenna.




8. Secure the antenna.




9. Tighten the set screw.




10. Place a suitable gasket on the tank flange.



11. Lower the antenna assembly into the tank.



12. Tighten the bolts and nuts with sufficient torque for the flange and gasket choice.



Postrequisites

1. Adjust the inclination of the antenna.
2. Connect the air purging system.

Related information


Adjust the inclination of the antenna
Connect the air purging

3.7.6 Bracket mounting


Procedure

1. Mount the bracket to the pipe/wall.


On pipe:




On wall:




2. Mount the antenna assembly to the bracket.




3. Place the supplied circular level on top of the antenna assembly.




4. Adjust the inclination of the antenna.




5. Gradually tighten the two M8 screws.



6. Remove the circular level.



7. Mount the transmitter head.



Postrequisites

1. Connect the air purging system.

Related information

[Connect the air purging](#)

3.7.7 Adjust the inclination of the antenna

Prerequisites


⚠ WARNING

Contents may be under pressure.


- Do not loosen the M8 screws while in operation. Attempting to do so may release pressurized gases, resulting in serious injury or death.

Procedure


1. Loosen the M8 screws until the antenna can rotate smoothly.




2. Rotate the antenna so the air purge connection is directed toward the tank wall.




3. Place the supplied circular level on top of the antenna assembly.




4. Adjust the inclination of the antenna.




5. Gradually tighten the M8 screws.



6. Remove the circular level.



7. Mount the transmitter head.
Align the marking on the sensor module with the air purge connection.




3.7.8 Connect the air purging

Procedure

- If air purging is not used, plug and seal the entry with the purge plug kit.

Figure 3-22: Air Purging



- A. Air purging?
- B. No
- C. Yes
- D. Use thread sealant or gasket according to your site procedures.
- E. $G\frac{3}{8}$ -in.
- F. 0.3-0.4 in. (8-10 mm) (gasket excluded)

Table 3-10: Incoming Air Supply Specification

Maximum pressure	Recommended pressure
190 psi (13 bar)	100 to 115 psi (7 to 8 bar)

3.8 Adjust display orientation (optional)

To improve field access to wiring or to better view the optional LCD display:

Prerequisites


Note

In high vibration applications, the transmitter housing must be fully engaged into the sensor module to meet the vibration test specifications. This is achieved by rotating the transmitter housing clockwise to thread limit.

Procedure


1. Loosen the set screw until the transmitter housing can rotate smoothly.
2. First, rotate the housing clockwise to the desired location. If the desired location cannot be achieved due to thread limit, rotate the housing counterclockwise to the desired location (up to 360° from thread limit).
3. Re-tighten the set screw.

Figure 3-23: Rotate the Transmitter Housing



4 Electrical installation

4.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol () . Refer to the following safety messages before performing an operation preceded by this symbol.

WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure the transmitter is installed by qualified personnel and in accordance with applicable code of practice.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- For installations in hazardous locations, the transmitter must be installed according to the Rosemount 5408 and 5408:SIS [Product Certifications](#) document and System Control Drawing (D7000002-885).

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.
- Both transmitter covers must be fully engaged to meet Explosion-proof/Flameproof requirements.

Electrical shock could cause death or serious injury.

- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.
- Ensure the mains power to the transmitter is off and the lines to any other external power source are disconnected or not powered while wiring the transmitter.

4.2 Hazardous areas

When the transmitter is installed in hazardous areas, local regulations, and specifications in applicable certificates must be observed.

Related information

[Product certifications](#)

4.3 Prepare the electrical connections

4.3.1 Cable selection

Use 24-14 AWG wire. Twisted pairs and shielded wiring are recommended for environments with high EMI (electromagnetic interference).

Use wire rated at least 5 °C above maximum ambient temperature.

Two wires can be safely connected to each terminal screw.

4.3.2 Cable gland/conduit

For explosion-proof/flameproof installations, only use cable glands or conduit entry devices certified explosion-proof or flameproof.

4.3.3 Power consumption

Max. 1 W, current max. 23 mA


4.3.4 Grounding

Make sure grounding is done according to national and local electrical codes. Failure to do so may impair the protection provided by the equipment.

Transmitter housing

The most effective grounding method is direct connection to earth ground with minimal impedance. There are two grounding screw connections provided (see [Figure 4-1](#)).

Figure 4-1: Ground Screws




Cable shield grounding

Make sure the instrument cable shield is:

- Trimmed close and insulated from touching the transmitter housing.
- Continuously connected throughout the segment.
- Connected to a good earth ground at the power supply end.

Figure 4-2: Cable Shield



- A. Insulate shield and drain wire
- B. Minimize distance
- C. Trim shield and insulate exposed drain wire
- D. Connect drain wire to the power supply ground

Note

Do not ground the shield and its drain wire at the transmitter. If the cable shield touches the transmitter housing, it can create ground loops and interfere with communications.

4.3.5


Power supply

The transmitter operates on 12-42.4 Vdc (12-30 Vdc in Intrinsically Safe installations) at the transmitter terminals.

4.3.6 Load limitations

For HART® communication, a minimum loop resistance of 250 Ω is required. Maximum loop resistance is determined by the voltage level of the external power supply.

Figure 4-3: Load Limits




Maximum Loop Resistance = $43.5 \times (\text{External Power Supply Voltage} - 12)$

- A. Loop Resistance (Ohms)
- B. External Power Supply Voltage (Vdc)


4.3.7 Wiring diagram

Figure 4-4: 4-20 mA/HART® Communication



- A. Handheld communicator
- B. Approved IS barrier (for Intrinsically Safe installations only)
- C. HART modem
- D. Load resistance ($\geq 250 \Omega$)
- E. Current meter
- F. Power supply

Figure 4-5: 4-20 mA/HART Communication - Terminal Block with TEST Terminal



- A. Handheld communicator
- B. Approved IS barrier (for Intrinsically Safe installations only)
- C. HART modem
- D. Load resistance ($\geq 250 \Omega$)
- E. Current meter
- F. Power supply
- G. Blue plug
- H. TEST terminal


Note

Disconnect the blue plug only during the loop current measurement procedure.


4.4 Connect wiring and power up

Procedure

1. ⚠ Verify the power supply is disconnected.
2. Remove the cover.





3. Remove the plastic plugs.




4. Pull the cable through the cable gland/conduit. ⁽²⁾

Identification of thread size and type:




5. Connect the cable wires.



6. Ensure proper grounding.

⁽²⁾ Unless marked, the conduit/cable entries in the transmitter housing use a 1/2-14 NPT thread form.

7. Tighten the cable gland.
Apply PTFE tape or other sealant to the threads.




Note


Make sure to arrange the wiring with a drip loop.



8. Seal any unused ports with the enclosed metal plug.
Apply PTFE tape or other sealant to the threads.




9. Attach and tighten the cover.
 - a) Verify the cover jam screw is completely threaded into the housing.




- b) Attach and tighten the cover.

⚠ Make sure the cover is fully engaged. There should be no gap between the cover and the housing.



- c) Turn the jam screw counterclockwise until it contacts the cover.

⚠ Required for explosion-proof/flameproof installations only.



- d) Turn the jam screw an additional ½ turn counterclockwise to secure the cover.

10. Connect the power supply.

Note

It may take up to 15 seconds before the LCD display lights up.

4.5 Optional devices


4.5.1 Rosemount™ 333 HART® Tri-Loop™

The Rosemount 5408 outputs a HART signal with four process variables. By using the Rosemount 333 HART Tri-Loop, up to three additional analog 4-20 mA outputs are provided.

Each Tri-Loop channel receives power from control room. Channel 1 must be powered for the Tri-Loop to operate.

The transmitter receives power from control room.

Figure 4-6: Example Installation of Rosemount 333 with Rosemount 5408




- A. Approved IS barrier
- B. DIN rail mounted Rosemount 333
- C. Load resistance ($\geq 250 \Omega$)
- D. Control room

Refer to the Rosemount 333 HART Tri-Loop [Reference Manual](#) for further information on how to install and configure the Rosemount 333.

5 Configuration

5.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol () . Refer to the following safety messages before performing an operation preceded by this symbol.

WARNING

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.
- Both transmitter covers must be fully engaged to meet Explosion-proof/Flameproof requirements.

Electrical shock could cause death or serious injury.

- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.

5.2 Overview

This chapter provides information about configuration and configuration tools. Appendix [Configuration parameters](#) provides extended information about the configuration parameters.

5.3 System readiness

5.3.1 Confirm correct device driver

The transmitter meets the NAMUR recommendation NE 53. Verify the latest FDI Package, Device Descriptor (DD), or Device Type Manager (DTM™) is loaded on your systems to ensure proper communication.

Procedure

1. Within [Table 5-1](#), use the HART® Universal Revision and Device Revision numbers to find the correct FDI Package, DD, or DTM.
2. Download the latest FDI Package, DD, or DTM.

Table 5-1: Identification and Compatibility According to NAMUR NE 53

Release date	Device identification			FDI, DD, and DTM identification		Review instructions	Review functionality
	NAMUR hardware revision ⁽¹⁾	NAMUR software revision ⁽¹⁾	Device software revision ⁽²⁾	HART® universal revision ⁽³⁾	Device revision ⁽⁴⁾	Manual document number	Change description
March-17	1.0.xx	1.0.xx	1.Axx	6	1	00809-0100-4408	Initial release
				7	1		
May-19	1.1.xx	1.1.xx	1.Axx	6	1	00809-0100-4408	Updated design of the cone antenna (PEEK seal) and new device software to support the change
				7	1		
September-21	1.1.xx	1.1.xx	1.Cxx	6	1	00809-0100-4408	Added Smart Echo Level Test functionality
				7	1		

- (1) NAMUR Revision is located on the transmitter label. Differences in level 3 changes, signified above by xx, represent minor product changes as defined per NE53. Compatibility and functionality are preserved and product can be used interchangeably.
- (2) Device software revision is located on the transmitter label, e.g. 1.A3. It can also be found in Rosemount Radar Master Plus (under **Overview**, select **Device Information** → **Revisions**).
- (3) HART Revision 6 and 7 can be switched in field. Default HART universal revision from factory is located on the transmitter head label, e.g. PROTOCOL 6.
- (4) Device revision is located on the transmitter label, e.g. DEVICE REV 1.

Related information

[Download the latest FDI Package](#)

[Download the latest Device Descriptor \(DD\)](#)

[Download the latest Device Type Manager \(DTM\)](#)

5.4 Get started with your preferred configuration tool

5.4.1 Configuration tools

- Rosemount Radar Master Plus for Rosemount 5408 Series (accessible through any Field Device Integration (FDI) based tool, e.g. AMS Instrument Inspector Application⁽³⁾)
- Device Descriptor (DD) based systems, e.g. AMS Device Manager, handheld communicator, and DeltaV™, or any other EDDL or enhanced-EDDL host
- Device Type Manager (DTM™) based systems, e.g. AMS Device Manager, Yokogawa Fieldmate/PRM, E+H FieldCare®, and PACTware™
- Field Device Integration (FDI) based systems, e.g. AMS Instrument Inspector Application

5.4.2 FDI compliant hosts

Rosemount Radar Master Plus

The Rosemount Radar Master Plus is a user-friendly software package that includes basic configuration options, as well as advanced configuration and service functions.

Rosemount Radar Master Plus is the recommended tool for configuration. The AMS Instrument Inspector Application or any FDI compliant host is needed to run Rosemount Radar Master Plus.

Download AMS Instrument Inspector

Procedure

Download the AMS Instrument Inspector Application at [Emerson.com/InstrumentInspector](https://emerson.com/instrumentinspector).

See the installation guide for a list of supported HART modems and system requirements.

Download the latest FDI Package

To manually add/update the FDI Package:


Prerequisites

The installation typically includes the Rosemount 5408 FDI Package.

Note

If the `Can't initialize Radar Master` error message occurs, then the software revision on your device requires an update of the Rosemount Radar Master Plus FDI Package.

⁽³⁾ For additional information, visit [Emerson.com/RosemountRadarMasterPlus](https://emerson.com/RosemountRadarMasterPlus).




Procedure

1. Download the latest FDI Package at [Emerson.com/DeviceInstallKits](https://emerson.com/DeviceInstallKits).
2. Unzip/extract the FDI Package.
3. Add the FDI Package to the host system.

Add the FDI Package to AMS Instrument Inspector

Procedure

1. Start **Instrument Inspector**.
2. From the menu bar, select , and then select **Add Device Package**.
3. Browse to the downloaded FDI Package and select **Open**.
4. Select **Add**.
5. Select **Back**.



5.4.3 Device Descriptor hosts

Download the latest Device Descriptor (DD)

The Device Descriptor (DD) is a configuration tool that is developed to assist the user through the configuration.

Procedure

- If using AMS Device Manager and the DeltaV™ system, download the latest DD at [Emerson.com/DeviceInstallKits](https://emerson.com/DeviceInstallKits).
- If using a third-party host, download the latest DD at [FieldCommGroup.org/Registered-Products](https://fieldcommgroup.org/Registered-Products).

Add the DD to AMS Device Manager

Prerequisites

The Rosemount 5408 DD is typically installed together with AMS Device Manager.

Procedure

1. Close AMS Device Manager.

2. Click the **Start** button, and then select **All Programs → AMS Device Manager → Add Device Type**.
3. Browse to the downloaded DD files and select **OK**.

Need help?

In the **Add Device Type** application, select the **Help** button for more information on how to complete this operation.

Configure the HART® modem interface

Before connecting to the device using a HART modem, the HART modem interface must be configured in AMS Device Manager:

Procedure

1. Close AMS Device Manager.
2. Click the **Start** button, and then select **All Programs → AMS Device Manager → Network Configuration**.
3. Select **Add**.
4. In the drop down list, select **HART modem** and select **Install**.
5. Follow the on-screen instructions.

Need help?

In the **Network Configuration** application, select the **Help** button for more information on how to complete this operation.

5.4.4 Device Type Manager hosts

Download the latest Device Type Manager (DTM™)

To configure device using a DTM operating tool:

Procedure

Download the latest DTM at [Emerson.com/DeviceInstallKits](https://emerson.com/DeviceInstallKits).

5.4.5 Handheld communicator

Get the latest Device Descriptor (DD)

If the DD is not installed in your handheld communicator, see the appropriate handheld communicator User's Manual available at [Emerson.com/FieldCommunicator](https://emerson.com/FieldCommunicator) for instructions on how to update the handheld communicator with the latest DD.

5.5 Confirm HART® revision capability

If using HART based control or asset management systems, confirm the HART capability of those systems prior to transmitter installation. Not all systems are capable of

communicating with HART Revision 7 protocol. This transmitter can be configured for either HART Revision 6 or Revision 7.

5.5.1 Switch HART® revision mode

If the HART configuration tool is not capable of communicating with HART Revision 7, the device will load a generic menu with limited capability. To switch the HART revision mode from the generic menu:

Procedure

1. Locate the “Message” field.
2. In the Message field, enter **HART6** or **HART7** and then 27 trailing spaces.

5.6 Configure transmitter using guided setup

5.6.1 Configure using Rosemount Radar Master Plus


The options available in the Guided Setup wizard include all items required for basic operation.

Procedure

1. Start Instrument Inspector Application.



2. Under **HART**, double-click the device icon.
3. From the **Overview** screen, select **Rosemount Radar Master Plus**.



4. Under **Configure**, select **Guided Setup** and follow the on-screen instructions.

5.6.2 Configure using AMS Device Manager

The options available in the Guided Setup wizard include all items required for basic operation.

Procedure

1. Start AMS Device Manager and connect to the device.
2. Select **Configure** → **Guided Setup**.
3. Select **Basic Setup** and follow the on-screen instructions.

5.6.3 Configure using handheld communicator

The options available in the Guided Setup wizard include all items required for basic operation.

Procedure


1. Turn on the handheld communicator and connect to the device.
2. Select **Configure** → **Guided Setup**.
3. Select **Basic Setup** and follow the on-screen instructions.

5.7 Verify level

The Verify Level tool matches the product level reported by the device to a reference measurement (measured by using for example handgauging).

If any difference, the Calibration Offset parameter will be adjusted. A minor adjustment using Calibration Offset is normal. There may, for example be a deviation between the actual tank height and the configured value.

Figure 5-1: Calibration Offset



- A. Positive Calibration Offset value
- B. Negative Calibration Offset value
- C. Reported level
- D. Actual level

5.7.1 Run verify level using Rosemount Radar Master Plus

Verify and adjust level measurement by comparing it to a hand-gauged measurement.

Prerequisites

Note

Before running Verify Level, make sure that: the product surface is calm, the tank is not being filled or emptied, and the actual level is well above the tank bottom.

Procedure

1. Under **Configure**, select **Verify Level** to check your level measurement.
Verify Level is also available via the Guided Setup wizard.
2. Follow the on-screen instructions.

5.7.2 Run verify level using AMS Device Manager and handheld communicator

Verify and adjust level measurement by comparing it to a hand-gauged measurement.

Prerequisites

Note

Before running Verify Level, make sure that: the product surface is calm, the tank is not being filled or emptied, and the actual level is well above the tank bottom.

Procedure

1. Select **Configure** → **Guided Setup**.
2. Select **Verify Level** to check your level measurement, and follow the on-screen instructions.

5.8 Establish multidrop communication

5.8.1 Establish multidrop communication using Rosemount Radar Master Plus

Multidropping transmitters refers to the connection of several transmitters to a single communications transmission line. Communication between the host and the transmitters takes place digitally with the analog output of the transmitters deactivated.

Prerequisites

In multidrop communication, each transmitter in the loop must have a unique HART address.

Procedure

1. Under **Configure**, select **Device Setup** → **HART**.

2. Under **Communication Interface**, select **HART Multidrop**.
3. In the **HART Address** box, type or select the HART address you want to use.
4. Select **Save**.

5.8.2 Establish multidrop communication using AMS Device Manager

Multidropping transmitters refers to the connection of several transmitters to a single communications transmission line. Communication between the host and the transmitters takes place digitally with the analog output of the transmitters deactivated.

Prerequisites

In multidrop communication, each transmitter in the loop must have a unique HART address.

Procedure

1. Select **Configure** → **Manual Setup** → **Device Setup** → **HART**.
2. Select **Change Address**, and then type the HART address you want to use.
3. Select **Next**.
4. Select **Finish** when the **Method Complete** message appears.
5. Ensure the **Multidrop** check box is selected.

5.8.3 Establish multidrop communication using handheld communicator

Multidropping transmitters refers to the connection of several transmitters to a single communications transmission line. Communication between the host and the transmitters takes place digitally with the analog output of the transmitters deactivated.

Prerequisites

In multidrop communication, each transmitter in the loop must have a unique HART address.

Procedure

1. Select **Configure** → **Manual Setup** → **Device Setup** → **HART**.
2. Select **Change Address**.
3. Type the HART address you want to use, and then select **ENTER**.
4. Ensure **Multidrop** is set to **ON**.

5.9 Use with the Rosemount 333 HART® Tri-Loop™

To prepare the transmitter for use with a Rosemount 333 HART Tri-Loop, the transmitter must be configured to Burst Mode and the process variable output order must be set. This can be done using the AMS Device Manager or a handheld communicator.

Prerequisites

The operational mode on the Rosemount 5408:SIS must be set to Control/Monitoring when used with the Rosemount 333 HART Tri-Loop.

Procedure

1. Make sure the transmitter is properly configured.
2. If desired, change the measurement units.
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **Units**.
3. Set the desired transmitter variable to use for Primary Variable (PV), Secondary Variable (SV), Third Variable (TV), and Fourth Variable (QV).
 - a) Select **Configure** → **Manual Setup** → **Device Setup** → **HART**.
 - b) Under **Variable Mapping**, select variables for PV, SV, TV, and QV.
4. Set the Rosemount 5408 to Burst Mode.
 - HART Revision 6:
 - a. Select **Configure Burst Mode**.
 - b. Under **Burst Mode**, select **On**.
 - c. Under **Burst Command**, select **PV, SV, TV, QV**.
 - d. Select **Send**.
 - HART Revision 7:
 - a. Select **Configure Burst Mode**.
 - b. Select **View/Configure Message 1**.
 - c. Under **Message 1 Broadcast**, select **Wired HART Enabled**.
 - d. Under **Burst Command**, select **PV, SV, TV, QV**, and then select **Next**.
 - e. Under **Burst Msg Trigger Mode**, select **Continuous**, and then select **Next**.
 - f. Set the Update Period, and then select **Finish**.
5. Prior to exiting the configuration, note the selected variables for SV, TV, and QV, and the units set for each of the variables. The same configuration must be used for the Rosemount 333.

Need help?

Refer to the Rosemount 333 HART Tri-Loop [Reference Manual](#) for full information about installing and configuring the Rosemount 333.

5.10 Write protect a transmitter

5.10.1 Write protect a transmitter using Rosemount Radar Master Plus

The transmitter can be write protected (with or without a password) to prevent unauthorized changes.

Prerequisites

If the Rosemount 5408:SIS is configured for use in Safety (SIS) operational mode, then the Safety Mode must be enabled for the transmitter to become operational. When Safety Mode is enabled, the transmitter is write protected to prevent unauthorized changes.

Procedure

1. Under **Overview**, select **Device Information** → **Alarm and Security**.
2. Under **Write Protection**, select **Change** and follow the on-screen instructions.

5.10.2 Write protect a transmitter using AMS Device Manager and handheld communicator

The transmitter can be write protected (with or without a password) to prevent unauthorized changes.

Prerequisites

If the Rosemount 5408:SIS is configured for use in Safety (SIS) operational mode, then the Safety Mode must be enabled for the transmitter to become operational. When Safety Mode is enabled, the transmitter is write protected to prevent unauthorized changes.

Procedure


1. Select **Configure** → **Manual Setup** → **Device Setup** → **Security**.
2. Under **Security**, select **Change Write Protection** and follow the on-screen instructions.

6 Operation

6.1 LCD display screen messages

The optional LCD display shows output variables and abbreviated diagnostic messages.


Figure 6-1: LCD Display




Startup screen sequence

The following screens are shown on the LCD display when the transmitter is switched on:


Figure 6-2: Startup Screen Sequence



1. All segments on




2. Device type and communication protocol



3. Software revision



4. Serial number



5. Device HART address

6.1.1 Variable screens

The transmitter can display the following variables:

Table 6-1: LCD Display Variables

Parameter	Presentation on display	Description
Level	LEVEL	The current level measurement value.
Distance	DIST	Distance from the upper reference point to the product surface.
Level Rate	LR	The current velocity at which the level is moving. A positive value indicates the surface is moving up.
Signal Strength	AMP	The signal amplitude of the surface echo.
Volume	VOLUM	Volume of the product at the current level.
Electronics Temperature	ITEMP	The current temperature at the electronics.
Signal Quality ⁽¹⁾	SIG QUALITY	The quality of product surface echo signal compared to surface threshold and noise.
Scaled Variable ⁽¹⁾	SCALE ⁽²⁾	A variable calculated from a scaling table (as defined by pairs of input/scaled values).
Percent of Range Primary Variable	PV %RANGE	A variable value expressed in percent within a range defined by a Lower Range Value (LRV) and an Upper Range Value (URV).
Auxiliary Percent of Range	AUX %RANGE	A variable value expressed in percent within a range defined by a Lower Range Value (LRV) and an Upper Range Value (URV).
User Defined Variable ⁽¹⁾	USER ⁽²⁾	A variable associated with a selected register in the device.

⁽¹⁾ Only for transmitters ordered with Smart Diagnostics Suite.

⁽²⁾ Default, user selectable display text (up to five characters).

Related information

[User defined variable setup](#)

6.2 Set up the LCD display

6.2.1 Set up the LCD display using Rosemount Radar Master Plus

It is possible to specify the variables to be presented on the optional LCD display.

Procedure

1. Under **Configure**, select **Device Setup**, and then select the **Display** tab.
2. Select the desired variables to be displayed on the LCD display.
3. Select **Save**.

6.2.2 Set up the LCD display using AMS Device Manager and handheld communicator

It is possible to specify the variables to be presented on the optional LCD display.

Procedure

1. Select **Configure** → **Manual Setup** → **Device Setup** → **Display**.
2. Select the desired variables to be displayed on the LCD display.
3. Select **Send**.

6.3 Smart echo level test

The function allows you to test the behavior of the transmitter in a real tank environment without raising the level. During the test, a virtual surface echo is superimposed onto the radar signal, and the transmitter will output a level corresponding to the echo position.

The test verifies the integrity of the signal processing, and can be used to test the alarm limits in the host system, output of the transmitter, and transmitter configuration (for example the upper/lower range values).

Related information

[Rosemount 5408:SIS Safety Manual](#)

6.3.1 Configure the smart echo level using Rosemount Radar Master Plus

Procedure

1. Under **Service Tools**, select **Proof Test**.
2. Select **Configure Smart Echo**.
3. In the **Smart Echo Level** box, enter the desired value.
4. Select **Save**.

6.3.2 Perform a smart echo level test using Rosemount Radar Master Plus

During the test, a virtual surface echo is superimposed onto the radar signal, and the transmitter will output a level corresponding to the echo position.

Prerequisites

This test is available for transmitters with:

- Device software revision 1.C0 or later
- Option code ET

Prior to and during the test, ensure that:

- The product surface is calm.
- The smart echo level is not closer than 1 ft. (0.3 m) to the liquid surface (5 ft. [1.5 m] when measuring solids).
- The tank is not being filled or emptied.

⚠ WARNING

During the proof test, the transmitter will not output measurement values corresponding to the product surface level. Ensure systems and people relying on measurement values from the transmitter are made aware of the changed conditions. Failure to do so could result in death, serious injury and/or property damage.

Procedure

1. Under **Service Tools**, select **Proof Test**.
2. Select **Smart Echo Level Test**.
3. Select **Start** and follow the on-screen instructions.

Postrequisites

When you have finished testing, select **Stop** to return to normal operation.

Related information

[Simulation/test active](#)

6.4 View measurement data

Measurement values can be viewed using Rosemount Radar Master Plus, AMS Device Manager, handheld communicator, or other communicator.


6.4.1 View measurement data in Rosemount Radar Master Plus

Current measurement data of the primary variables are presented on the **Overview** screen together with a graphical representation of the tank.

Procedure

Select **All Variables** to view a complete list of all variables within the transmitter.

Figure 6-3: Rosemount Radar Master Plus - Overview Screen



6.4.2 View measurement data in AMS Device Manager and handheld communicator

Current measurement data of the primary variables are presented on the **Overview** screen. To view all current measurement values, do the following:


Procedure

1. Select **Service Tools** → **Variables**.
2. Select **Mapped Variable**, **Process**, **Device**, or **Signal Quality**.

6.4.3 Interpret measurement status

A “Good” or “Bad” status next to a value is an indication of the reliability or integrity of the data being received, not an indication of whether or not the value is within the configured upper or lower ranges. A value that triggers an alert, such as a high or low temperature indication, will change the overall status of the device, but the measurement might still be indicated as “Good” if the reliability of the data is good.

Figure 6-4: AMS Device Manager - Status Indicators



6.5 Device status

The overall device status is presented under the **Overview** screen in Rosemount Radar Master Plus, AMS Device Manager, and handheld communicator. The transmitter reports diagnostic alerts when there is a device malfunction.

The device can also be configured to report user defined alerts based on the measured variables.

Related information

[Diagnostic messages per NAMUR NE 107](#)
[High/low user defined alert](#)

6.5.1 Check device status

Follow this procedure to check device status and see whether there are any active alerts reported.

Procedure

1. Go to the **Overview** screen to view the overall device status.

2. If status is anything than Good, click the button in the device status image to open a window with active alerts. The different device status images are shown in [Table 6-2](#) and [Table 6-3](#).

Active Alerts can also be obtained via **Service Tools** → **Alerts**.

Table 6-2: Presentation of Device Status Images as per NAMUR NE 107 - AMS Device Manager












Device status image	Category	Description	Action
Device:  Good	Good	No active alert.	N/A
Device:  Failure Troubleshoot	Failure	At least one Failure alert is active.	Click the Troubleshoot button to open a window with active alerts together with recommended actions.
Device:  Function Check Investigate	Function Check	At least one Function Check alert is active (and no Failure alerts).	Click the Investigate button to open a window with active alerts together with recommended actions.
Device:  Out of Specification Investigate	Out of Specification	At least one Out of Specification alert is active (and no Failure or Function Check alerts).	
Device:  Maintenance Required Investigate	Maintenance Required	At least one Maintenance Required alert is active (and no Failure, Function Check, or Out of Specification alerts).	

Table 6-3: Presentation of Device Status Images as per NAMUR NE 107 - Rosemount Radar Master Plus

Device status image	Category	Description	Action
	Good	No active alert.	N/A
	Failure	At least one Failure alert is active.	Click the device status image to open a window with active alerts together with recommended actions.
	Function Check	At least one Function Check alert is active (and no Failure alerts).	
	Out of Specification	At least one Out of Specification alert is active (and no Failure or Function Check alerts).	
	Maintenance Required	At least one Maintenance Required alert is active (and no Failure, Function Check, or Out of Specification alerts).	

7 Service and troubleshooting

7.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol () . Refer to the following safety messages before performing an operation preceded by this symbol.

WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure the transmitter is installed by qualified personnel and in accordance with applicable code of practice.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.

Explosions could result in death or serious injury.

- Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure the instruments are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.
- Both transmitter covers must be fully engaged to meet Explosion-proof/Flameproof requirements.

Process leaks could result in death or serious injury.

- Ensure that the transmitter is handled carefully. If the process seal is damaged, gas might escape from the tank.

Electrical shock could cause death or serious injury.

- In Explosion-proof/Flameproof and Non-Incendive/Type n installations, avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.
- Ensure the mains power to the transmitter is off and the lines to any other external power source are disconnected or not powered while wiring the transmitter.

7.2 Diagnostic messages per NAMUR NE 107

7.2.1 Electronics failure, transmitter

Category	Failure
LCD display message	ELEC FAILUR

Cause

An electronics error has occurred.

The device measurement reading is invalid.

Recommended actions

1. Restart the device.
2. If the condition persists, replace the device.

Related information

[Restart the device](#)

7.2.2 Electronics failure, sensor module

Category	Failure
LCD display message	ELEC FAILUR

Cause

An electronics error has occurred.

The device measurement reading is invalid.

Recommended actions

1. Restart the device.
2. If the condition persists, replace the device.

Related information

[Restart the device](#)

7.2.3 Device memory failure

Category	Failure
LCD display message	MEMRY FAILUR

Cause

A device memory error has occurred.

The device measurement reading is invalid.

Recommended actions

1. Restore default settings, restart device, and reconfigure the device.
2. If the condition persists, replace the device.

Related information

[Restore to default settings](#)

[Restart the device](#)

[Configure transmitter using guided setup](#)

7.2.4 Radar signal failure

Category	Failure
LCD display message	SIGNL FAILUR

Cause

The received radar signal is invalid resulting in an invalid device measurement reading.

Recommended actions

1. Clean the antenna.
2. If the condition persists, replace the device.

7.2.5 Startup failure

Category	Failure
LCD display message	START FAILUR

Cause

Device repeatedly failed to start up with user configuration settings.
The device measurement reading is invalid.

Recommended actions

1. Check supply voltage is within range and restart device.
2. Restore default settings, restart device, and reconfigure the device.
3. If the condition persists, replace the device.

Related information

[Power supply](#)
[Restore to default settings](#)
[Restart the device](#)
[Configure transmitter using guided setup](#)

7.2.6 Software error

Category	Failure
LCD display message	SW FAILUR

Cause

The software in the device encountered a problem and stopped running which may cause an invalid measurement reading.

In some cases, problems may be caused by temporary environmental conditions (e.g. electromagnetic interferences) and not observed again.

Recommended actions

1. Restart the device.
2. Restore default settings and reconfigure the device.
3. If the condition persists, replace the device.

Related information

[Restart the device](#)
[Restore to default settings](#)
[Configure transmitter using guided setup](#)

7.2.7 Level measurement lost

Category	Failure
LCD display message	MEAS FAILUR

Cause

No valid level reading. Reasons may be multiple:

- No valid surface echo peak in the measuring range.
- Incorrect device configuration.

Recommended actions

1. Analyze the Echo Curve at time of loss for reason and check device configuration, especially thresholds.
2. Check device physical installation (for instance antenna contamination).
3. Consider increasing Measurement Recovery Time parameter for intermittent conditions.
4. Restart the device.
5. Restore default settings and reconfigure the device.
6. If the condition persists, replace the device.

Related information

[Read the echo curve](#)

[Amplitude thresholds](#)

[Measurement recovery time](#)

[Restart the device](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

7.2.8 Configuration error

Category	Failure
LCD display message	CONFG ERROR

Cause

The device has detected a configuration error. Reasons may be multiple.

Recommended actions

1. Click the **Details** button for more information.
2. Correct the parameter causing the error.

Volume configuration error

Cause

The volume cannot be calculated correctly with the current configuration.

Recommended actions

1. If strapping table is used, check that level-volume values are entered in increasing order.
2. If strapping table is used, check that number of strapping points to use is correct.
3. If tank dimensions are used for volume, check that geometry shape and size measures are correct.
4. If condition persists, restore default settings and reconfigure the device.

Related information

[Volume](#)

[Geometry](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

Scaled variable configuration error

Cause

The Scaled Variable configuration is incorrect.

Recommended actions

1. Check that the value pairs in the scaled variable table are entered in increasing order.
2. Check the number of table points to use is correct.
3. If condition persists, restore default settings, and reconfigure the device.

Related information

[Scaled variable](#)
[Restore to default settings](#)
[Configure transmitter using guided setup](#)

Geometry configuration error

Cause

The configured tank geometry results in a too large level measuring range for this device.

Recommended actions

1. Check tank geometry configuration and reduce Reference Height.
2. If condition persists, restore default settings and reconfigure the device.

Related information

[Reference height](#)
[Restore to default settings](#)
[Configure transmitter using guided setup](#)

Primary variable configuration error

Cause

The Primary Variable selection is not supported.

Note

Rosemount 5408:SIS only supports level or distance as Primary Variable.

Recommended actions

1. Change Primary Variable to variable supported by device.
2. Consider purchasing an upgrade of the device to access additional variables.

Related information

[Primary variable](#)

Measurement correction configuration error

Cause

The factory measurement correction data is invalid.

Recommended actions

1. Restore default settings and reconfigure the device.
2. If the condition persists, replace the device.

Related information

[Restore to default settings](#)
[Configure transmitter using guided setup](#)

Threshold configuration error

Cause

The surface threshold configuration is incorrect.

Recommended actions (Rosemount Radar Master Plus)

1. Adjust the threshold as necessary.
2. If condition persists, restore default settings and reconfigure device.

Recommended actions (AMS Device Manager and handheld communicator)

1. In the threshold table, check that distance-threshold values are entered in increasing order.
2. Check that the number of threshold points to use is correct.
3. If condition persists, restore default settings and reconfigure the device.

Related information

[Amplitude thresholds](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

Factory approval error

Cause

- The Sensor Module factory approval is missing.
- The Transmitter factory approval is missing.

Recommended actions

1. Restart the device.
2. Restore default settings and reconfigure device.
3. If the condition persists, replace the device.

Related information

[Restart the device](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

SIS configuration error

Cause

It is currently not possible to enable Safety Mode due to other active alerts.

Note

Rosemount 5408:SIS only supports liquids level measurement when operating in Safety (SIS) mode.

Recommended actions

1. Clear other active alerts by priority order until this alert is cleared.
2. Change Operational Mode to Control/Monitoring if device is not intended to be used as safety device.
3. If the condition persists, restore default settings and reconfigure device.

Related information

[Rosemount 5408:SIS Safety Manual](#)
[Operational mode](#)
[Restore to default settings](#)
[Configure transmitter using guided setup](#)

Function not supported

Cause

Functionality in the device is enabled, but not supported by this device.
Additional features may be enabled by purchasing an upgrade of the device.

Recommended actions

1. Check that selections for variables (e.g. Primary Variable) are supported by this device.
2. Turn off functionality not supported by this device.
3. Consider purchasing an upgrade of the device to access additional variables and functionality.
4. If condition persists, restore default settings and reconfigure device.

Related information

[Primary variable](#)
[Restore to default settings](#)
[Configure transmitter using guided setup](#)

Antenna type configuration error

Cause

The configured Antenna Type is not supported by the device.

Recommended actions

1. Check configuration of Antenna Type.
2. Make sure the configured antenna type matches the physical antenna for the device.

Related information

[Antenna type](#)

Factory calibration error

Cause

The factory calibration in the device is missing.

Recommended actions

Replace the device.

Analog out span configuration error

Cause

The span for the configured analog out range is too small.

Recommended actions

Increase analog out span by adjusting Upper or Lower Range Value.

Related information

[Upper/lower range value](#)

Analog out calibration error

Cause

Analog output calibration failed.

Recommended actions

1. Try calibrating the analog output again.
2. If the condition persists, replace the device.

Related information

[Calibrate analog out](#)

SIS multidrop error

Cause

HART multidrop mode is not supported for safety (SIS) devices. Only 4-20 mA output is supported for safety devices.

Recommended actions

1. Disable multidrop mode.
2. Change Operational Mode to Control/Monitoring if device is not intended to be used as safety device.
3. If the condition persists, restore default settings and reconfigure device.

Related information

[Rosemount 5408:SIS Safety Manual](#)

[Operational mode](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

Engineering unit configuration error

Cause

One of the configured engineering units is not supported by the device.

Recommended actions

1. Check unit configuration.
2. If condition persists, restore default settings and reconfigure device.

Related information

[Units](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

Burst mode configuration error

Cause

The burst mode configuration is incorrect.

Recommended actions

1. Check configuration of burst mode.
2. If condition persists, restore default settings and reconfigure device.

Related information

[Burst mode](#)

[Restore to default settings](#)

[Configure transmitter using guided setup](#)

Start code configuration error

Cause

The start code to enable options in the device is invalid.

Note

Start codes are unique for individual devices and cannot be copied from one device to another.

Recommended actions

1. Enter a valid start code for this device using the Upgrade function.
2. If condition persists, contact your local Emerson representative to get a valid start code.

7.2.9 Safety mode not activated

Category	Function Check
LCD display message	SAFE DISBLD

Cause

Safety Mode is disabled and device is in alarm mode.

This device is configured for use in Safety Instrumented Systems (SIS) which requires Safety Mode to be enabled.

Recommended actions

1. Change Safety Mode to Enabled for use in SIS application.
2. Change Operational Mode to Control/Monitoring if device is not intended to be used as safety device.

Related information

[Rosemount 5408:SIS Safety Manual](#)

7.2.10 Simulation/test active

Category	Function Check
LCD display message	SIMUL ACTIVE

Cause

The device is in simulation or test mode and is not reporting actual information.

Recommended actions

1. If this behavior is not desired, stop simulation or test mode.
2. If the condition persists, restart the device.

Related information

[Use the simulation mode](#)
[Restart the device](#)

7.2.11 Electronics temperature out of limits

Category	Out of Specification
LCD display message	TEMP LIMITS

Cause

The temperature of the electronics board has exceeded the transmitter's operating range.

Recommended actions

1. Verify ambient temperature is within the operating range.
2. Remote mount the transmitter away from the process and environmental conditions.

Related information

[Ambient temperature limits](#)

7.2.12 Supply voltage low

Category	Maintenance Required
LCD display message	SUPPLY LOW

Cause

The supply voltage is low and may affect device operation.

Recommended actions

Check supply voltage is within range.

Related information

[Power supply](#)

7.2.13 Low signal quality

Category	Maintenance Required
LCD display message	LOW SIG Q

Cause

The Signal Quality is below the defined alert limit.

Recommended actions

1. Take action based on your intended use of this alert.
2. Clean the antenna.
3. If no actions were necessary, consider to change the limit.

Related information

[Signal quality alert](#)

7.2.14 High user defined alert

Category	Maintenance Required
LCD display message	HIGH ALERT

Cause

The user defined variable is above the defined limit.

Recommended actions

1. Bring the system to a safe state.
2. Verify that the process variable is within specified limits.
3. Reconfirm the user defined alarm limit.
4. If not needed, disable this alert.

Related information

[High/low user defined alert](#)

7.2.15 Low user defined alert

Category	Maintenance Required
LCD display message	LOW ALERT

Cause

The user defined variable is below the defined limit.

Recommended actions

1. Bring the system to a safe state.
2. Verify that the process variable is within specified limits.
3. Reconfirm the user defined alarm limit.
4. If not needed, disable this alert.

Related information

[High/low user defined alert](#)

7.2.16 Linearized variable out of range

Category	Maintenance Required
LCD display message	VAR OUTRNG

Cause

The level measurement is outside the configured range for volume or scaled variable, or both.

Accuracy of volume/scaled variable measurement may be degraded.

Recommended actions

1. If volume strapping table is used, make sure level values within operating range are included.
2. If scaled variable table is used, make sure input variable values within operating range are included.

Related information

[Volume](#)

[Scaled variable](#)

7.2.17 Dielectric constant estimation degraded

Category	Maintenance Required
LCD display message	DC DEGRAD

Cause

The dielectric constant estimation is degraded.

Accuracy of level measurement may be degraded.

Recommended actions

1. Check configuration of Bottom Product Dielectric Constant.
2. Check configuration of Reference Height and Bottom Offset.
3. If not needed, disable Tank Bottom Projection.

Related information

[Tank bottom projection](#)

[Reference height](#)

[Bottom offset](#)

7.3 Troubleshooting guides

If there is a malfunction despite the absence of alerts, follow the procedures described in the appropriate troubleshooting guide. Under each of the symptoms, specific suggestions for solving problems are offered.

Related information


[Troubleshooting incorrect level readings](#)

[Troubleshooting the 4-20 mA/HART Output](#)

7.3.1 Troubleshooting incorrect level readings

Reported level is too high or low

Figure 7-1: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Incorrect tank geometry configuration.

Recommended actions

- Verify the tank geometry parameters are configured correctly (especially the Reference Height).
- Run Verify Level to adjust level measurement.
- Analyze the echo curve and check amplitude thresholds.
- Restore default settings and reconfigure the device.

Related information

[Reference height](#)

[Verify level](#)


[Read the echo curve](#)

[Amplitude thresholds](#)

[Restore to default settings](#)

Level is stuck in measuring range

Figure 7-2: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Incorrect alignment of the transmitter.

Recommended actions

- Verify the transmitter head is correctly aligned.

Possible cause

Disturbing object in the tank.

Recommended actions

- Use the suppress false echoes function to manage strong disturbance echoes.
- Analyze the echo curve and check amplitude thresholds.
- Remove the disturbing object.
- Change alignment of transmitter head in steps of about 15 degrees. After each step, check if impact of disturbing echoes is decreased using the echo curve.
- Put an inclined metal plate on top of the disturbing object.
- Move the transmitter to another position.

Related information

[Align transmitter head](#)

[Suppressing false echoes](#)


[Read the echo curve](#)

[Amplitude thresholds](#)

[Installation considerations](#)

Level is stuck in full tank

Figure 7-3: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Disturbing object near the antenna.

Recommended actions

- Use the suppress false echoes function to manage strong disturbance echoes.
- Analyze the echo curve and check amplitude thresholds.
- For process seal antenna installed in a nozzle taller than 10-in. (25 cm), adjust the pre-configured amplitude threshold.
- Increase the Upper Null Zone.
- Remove the disturbing object.
- Move the transmitter to another position.

Possible cause

Product build-up on the antenna.

Recommended actions

- Clean the antenna.
- Use transmitter with air purging connection.

Possible cause

Cone antenna does not extend below the nozzle.

Recommended actions

- Use the extended cone antenna.

Related information

[Suppressing false echoes](#)

[Read the echo curve](#)

[Amplitude thresholds](#)

[Handling disturbances at top of tank](#)


[Installation considerations](#)

Level value drops when close to antenna

Symptom

Level value drops to a lower value when product surface is close to antenna.

Figure 7-4: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Product surface is within the Upper Null Zone and a disturbance echo is interpreted as the product surface.

Recommended actions


- Check the setting of the Upper Null Zone.

Related information

[Upper null zone](#)

Measured value jumps to a lower value

Figure 7-5: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Multiple products in the tank, e.g. thin oil layer on top of water that is sometimes detected, sometimes not.

Recommended actions


- Set Double Surface Handling to Track Upper Surface or Track Lower Surface.

Related information

[Double surface handling](#)

Measured level fluctuates

Figure 7-6: Symptom



- A. Level
- B. Time
- C. Reported level

Possible cause

Excessive foaming or turbulence.

Recommended actions

- Under turbulent conditions with low level rates, consider increasing the Damping value.
- Enable the Foam parameter or Turbulent Surface parameter, or both.


Related information

[Damping value](#)

[Process conditions](#)

Measured level is occasionally unstable

Figure 7-7: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

The product surface is close to a suppressed false echo.

Recommended actions

- If possible, remove the disturbing object.

Related information


[Read the echo curve](#)

Lagging of measured level

Symptom

Measured level lags during rapid level changes.

Figure 7-8: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Damping value is set too high.

Recommended actions

- If there is a problem with lag during rapid level changes, consider decreasing the Damping value.

Possible cause

Maximum Level Rate value too low.

Recommended actions

- Verify Maximum Level Rate configuration.


Related information

[Damping value](#)

[Maximum level rate](#)

Incorrect level when using still pipe

Figure 7-9: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Device is not configured for still pipe measurement.

Recommended actions

- Enable pipe measurement.

Possible cause

Incorrect Pipe Inner Diameter configuration.

Recommended actions

- Verify the configured Pipe Inner Diameter matches the physical inner diameter.

Possible cause

Ghost echo problems below the product surface.

Recommended actions

- Enable the Track First Echo function.

Related information

[Mounting type](#)

[Inner diameter, pipe/chamber](#)


[Handling ghost echoes in still pipes](#)

Incorrect level at 100% (20 mA)

Symptom

Measured level is correct at 0% (4 mA) but incorrect at 100% (20 mA).

Figure 7-10: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Upper Range Value is not set correctly.

Recommended actions

- Check that the Upper Range Value matches the 100% (20 mA) level in the tank.

Related information


[Upper/lower range value](#)

Incorrect level when product surface is above 50%

Symptom

The reported level is incorrect when the product surface is above the 50% level.

Figure 7-11: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

A strong double bounce echo is interpreted as the product surface.

Recommended actions

- Enable the Double Bounce Handling function.

Related information


[Handling strong double bounce echoes](#)

Dropping of level close to tank bottom

Symptom

Measured value drops to zero level in the tank bottom region.

Figure 7-12: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Transmitter has locked on a strong tank bottom echo.

Recommended actions

- Verify the Reference Height is configured correctly.
- Enable the Tank Bottom Projection function
- Enable the Bottom echo visible when tank is empty parameter.

Related information

[Reference height](#)

[Use tank bottom projection](#)


[Enable bottom echo visible when tank is empty](#)

Alarm mode close to tank bottom

Symptom

When the product surface is near the sloped tank bottom, the transmitter enters alarm mode.

Figure 7-13: Symptom



- A. Level
- B. Time
- C. Actual level
- D. Reported level

Possible cause

Reduction of projected surface area close to sloping tank bottom.

Recommended actions

- Verify the tank geometry parameters are configured correctly (especially the Reference Height and Bottom Offset).
- If measurement in this region is not crucial, increase the Empty Tank Detection Area.
- Verify the Bottom echo visible when tank is empty parameter is disabled.

Related information

[Reference height](#)

[Bottom offset](#)

[Empty tank handling](#)

[Enable bottom echo visible when tank is empty](#)

7.3.2 Troubleshooting the 4-20 mA/HART Output

Device milliamp reading is zero

Recommended actions

1. Verify power is applied to signal terminals.
2. Verify power supply voltage is adequate at signal terminals.
3. Verify device and power supply are properly grounded.

Related information

[Power supply](#)

[Grounding](#)

Device milliamp reading is too low or high

Recommended actions

1. Verify level.
2. Check the settings of the 4-20 mA range values.
3. Verify output is not in alarm condition.
4. Check that power wires are connected to the correct signal terminals.
5. Perform Calibrate Analog Out.

Related information

[Upper/lower range value](#)

[Alarm mode](#)

[Calibrate analog out](#)

Milliamp reading is erratic

Recommended actions

1. Verify power supply voltage is adequate at signal terminals.
2. Check for external electrical interference.
3. Verify device is properly grounded.
4. Verify shield for twisted pair is only grounded at the power supply end.
5. Under turbulent conditions with low level rates, consider increasing the Damping value.

Related information

[Power supply](#)

[Grounding](#)

[Damping value](#)

Device will not respond to changes in level

Recommended actions

- Verify level is between the 4 and 20 mA set points.
- Verify output is not in alarm condition.
- Verify device is not in loop test or simulation mode.

Related information

[Upper/lower range value](#)

[Alarm mode](#)

[Check device status](#)

There is no HART communication (lost device communication)

Recommended actions

1. Verify power supply voltage is adequate at signal terminals.
2. Check load resistance (250 ohms minimum).
3. Check if device is at an alternate HART address.
4. Check current analog output value to verify that device hardware works.
5. Verify the blue plug is attached to the TEST terminal (if applicable). When unplugged, HART communication to configuration tool may be compromised.

Related information

[Power supply](#)

[HART/polling address](#)

[Use the TEST terminal](#)

7.4 Service and troubleshooting tools


This section briefly describes tools and functions in the Rosemount Radar Master Plus, AMS Device Manager, and handheld communicator, which may be useful for service and troubleshooting of the Rosemount 5408 and 5408:SIS Level Transmitters.

7.4.1 Using the echo curve

The Rosemount Radar Master Plus software includes functions for viewing and recording single instances or movies of the echo curve. The echo curve represents the tank, as seen by the radar transmitter. Each peak corresponds to a strong reflection of the radar signal.

When connected to Rosemount Radar Master Plus, past measurement records and echo curves including the 10 highest peaks, as well as the 50 last alert events are automatically transferred from the transmitter's internal memory to the hard drive on your local computer. Past measurement records are then available the next time you connect to the transmitter using the level trend timeline.

Figure 7-14: Echo Curve



Measurement problems can be understood by studying the position and amplitude of the different peaks. Additionally, the recorded echo curves give insight into unexpected and intermittent measurement behaviors, for instance, at the time of the triggered alert.

Read the echo curve

To read the echo curve in Rosemount Radar Master Plus:

Procedure

1. Under **Service Tools**, select **Echo Curve**. Rosemount Radar Master Plus reads one echo curve and then stops.
2. To continuously update the echo curve, select the **Play** icon.

Analyzing the echo curve

The following echo peaks may appear in the echo curve:


Table 7-1: Echo Peak Types

Type	Description
Surface	Echo tracked as the current surface echo
Unknown	Echo not recognized by the device, which might interfere with measurement
Suppressed	Echoes that are identified but suppressed by the device
Suppressed (double bounce)	Echo managed as a double bounce echo by the Double Bounce function

Table 7-1: Echo Peak Types (continued)

Type	Description
Secondary surface	Echo tracked as the current secondary surface (if Double Surface Handling function is enabled)
Tank bottom echo	Echo considered as an echo from the tank bottom

Figure 7-15: Echo Curve with Typical Echo Peaks



- A. Suppressed (dashed line indicates use of false echo suppression)
- B. False echo suppression
- C. Unknown
- D. Amplitude threshold
- E. Surface

Zoom in and out the echo curve

You can zoom in to a specific area of the echo curve.

Procedure

- To zoom in, drag a rectangle around the area you want to magnify.
- To zoom out, in the upper right corner of the echo curve, select **Reset Zoom**.

View level trends and historical echo curves

Procedure

- To go to a desired point in the displayed part of the timeline, drag the slider, or click anywhere in the timeline.
- To move the timeline forward or backward, click the left or right arrow, or drag anywhere in the timeline.

Tip


To speed up the upload time of historical data in a specific area, click or drag the slider to the desired start point on the timeline. Rosemount Radar Master Plus continues to load data from that point forward.

View active/historical alerts

Procedure

In the timeline, click the left or right arrow to scroll to the alert, and then select the alert icon for details.

Figure 7-16: Level Trend Timeline



- A. Play or pause
- B. Left arrow
- C. Timeline slider
- D. History alert icon
- E. Drag anywhere in the timeline to move the timeline forward or backward.
- F. Right arrow
- G. Export echo curves
- H. Options


Play echo curve movies

Procedure

1. Set the start point.
 - a) Click the left or right arrow, or drag anywhere in the timeline.
 - b) Click the start point in the timeline.
2. Select **Play**, or drag the timeline slider to move one frame at a time.

Export echo curve movies


Procedure

1. Under **Service Tools**, select **Echo Curve**.
 2. Select **Export**.
- 
3. Type your desired file name.
 4. Browse to the desired directory, and then select **Save**.
 5. Under **Time range**, select **Last 1 hour**, **Last 3 hours**, **Last 24 hours**, or **User defined range**.
 6. If **User defined range** is selected, specify the start and end times.
 7. Select **Export**.
 8. Select **Back**.



Set echo curve range

Procedure


1. Under **Service Tools**, select **Echo Curve**.
 2. Select **Options**.
- 
3. Under **Echo Curve Range**, select **User Defined**.
 4. Enter the desired values.
 5. Select **Save**.
 6. Select **Back**.



Set timeline resolution

To set the resolution of the level trend timeline:

Procedure

1. Under **Service Tools**, select **Echo Curve**.
 2. Select **Options**.
- 
3. In the **Timeline Resolution** list, select the desired length (in hours) of the timeline.
 4. Select **Save**.
 5. Select **Back**.



7.4.2 Managing disturbance echoes

There are two general methods for managing disturbance echoes:

- Set amplitude thresholds to filter out weak disturbance echoes and noise.
- Use the suppress false echoes function to manage strong disturbance echoes.

Amplitude thresholds

The amplitude thresholds are used to filter out noise and disturbing echoes from the product surface echo. The transmitter uses certain criteria to decide which type of echo peak that is detected. Only echoes above the amplitude threshold might be considered the product surface. The amplitude threshold can either be set to a constant value, or split into sections as defined by up to 10 anchor points.

If necessary, a customized amplitude threshold section can for instance be used to remove the influence from the tank nozzle, or disturbances close to the tank bottom. Additionally, it might be needed in areas where there are occasionally strong echoes present, for instance due to wide mixer blades. Suppressing false echoes may not be sufficient in those areas.

Note

Do not create a customized amplitude threshold section around echoes which are already registered as false echoes.

General recommendations

Use the following best practices to apply custom threshold adjustments:

- Generally, set amplitude threshold to about 10 percent of surface echo amplitude.
- Do not set the amplitude threshold to less than 150 mV (50 mV for solids measurements)⁽⁴⁾.

Adjust the threshold value

Prerequisites


It is recommended to adjust thresholds using Rosemount Radar Master Plus.

Procedure

1. In Rosemount Radar Master Plus, under **Service Tools**, select **Echo Curve**.
2. In the echo curve, drag the amplitude threshold point left or right, or type the desired value (Figure 7-17).
3. Select **Save**.

⁽⁴⁾ If required in solids applications with weak surface echoes, the amplitude threshold can be set down to 50 mV, as long as it is greater than the disturbance echoes.

Figure 7-17: Amplitude Threshold Point




A. Amplitude threshold point

Set the endpoint of a threshold segment

Procedure

1. In the echo curve, drag the endpoint up or down, or type the desired value (Figure 7-18).
2. Select **Save**.

Figure 7-18: Endpoint



A. Endpoint

Add or delete an amplitude threshold point

Procedure


1. In the echo curve, select the desired amplitude threshold point, and select **Split threshold** or **Merge with threshold below**.
2. Click again on one of the amplitude threshold points and select **Save**.

Suppressing false echoes

Stationary objects with horizontal surfaces may generate strong false echoes. When the surface is close to an obstruction in the tank (e.g. beams and agitators), the surface and false echoes might interfere and cause a decrease in performance.

However, false echoes can be suppressed to reduce the influence of such objects, in case they cannot be totally avoided. When the surface is passing by a disturbing object, the transmitter will then measure with higher reliability, even if the surface echo is weaker than the false echo, see [Figure 7-19](#).

Figure 7-19: Suppression of False Echoes



- A. Amplitude threshold
- B. Disturbing object
- C. False echo suppression
- D. Suppressed echo
- E. Surface

Add a new false echo suppression

Prerequisites

Follow these recommendations before suppressing new false echoes:

- Make sure a correct amplitude threshold is set.
- Make sure the level is stable. A fluctuating level may indicate a temporary disturbance which is not due to an interfering object.
- Only suppress echoes which can be clearly identified as objects in the tank. Compare the list of interfering echoes with the tank drawing or visual inspection of the tank.
- Do not suppress false echoes located below the product surface.
- Keep the number of suppressed false echoes to a minimum.

It may be necessary to suppress new false echoes at a later stage when objects have become visible due to surface movement.

Procedure



1. In Rosemount Radar Master Plus, under **Service Tools**, select **Echo Curve**.
2. In the echo curve, click  at the unknown echo peak, and then select **Suppress**.

Figure 7-20: Add False Echo Suppression



Related information

[Amplitude thresholds](#)

Delete a false echo suppression

Procedure



1. In Rosemount Radar Master Plus, under **Service Tools**, select **Echo Curve**.
2. In the echo curve, click  at the left end of the false echo suppression, and then select **Delete**.


Figure 7-21: Delete False Echo Suppression



Suppress a false echo manually

The false echo may also be suppressed manually if the position of the false echo is known.

Procedure

1. In Rosemount Radar Master Plus, under **Service Tools**, select **Echo Curve**.
2. Select **Options**.

3. Select **Suppress False Echo Manually**. Suppressed echoes are shown in the table.
 - To add a new suppression, select **Add**, and then type the distance to the false echo and the width of the false echo area.
 - To change a suppression, select the cell you want change and type the new value.
 - To delete a suppression, select the row you want to delete, and then select **Delete**.
4. Select **Save**.

5. Select **Back**.



Suppress false echoes using AMS Device Manager

Procedure

1. Select **Service Tools** → **Echo Tuning** → **Suppress**. Suppressed echoes are shown in the table.
2. Select **Suppress** or **Remove Suppression**.
3. Type the distance to the echo that should be added to or removed from the list, and then select **Next**.
4. Select **Finish** when the `Method Complete` message appears.

Suppress false echoes using handheld communicator

Procedure

1. Select **Service Tools** → **Echo Tuning** → **Suppress**.
2. To view the current suppressed echoes, select **Suppressed Echoes**.
3. Select **Suppress** or **Remove Suppression**.
4. Type the distance to the echo that should be added to or removed from the list, and then select **Enter**.

7.4.3 Perform an analog loop test

Perform an analog loop test using Rosemount Radar Master Plus

During a loop test, the transmitter outputs a fixed value (4 mA, 20 mA, or user-selected value). The loop test command verifies the output of the transmitter, the integrity of the loop, and the operations of any recorders or similar devices installed in the loop. A loop test can also be used to determine the need for an analog output calibration.

Prerequisites

If the transmitter is equipped with a TEST terminal, current can be measured directly at the terminal block without disconnecting any signal wires.

Procedure

1. Under **Service Tools**, select **Simulate**.
2. Select **Loop Test**.
3. Select **4 mA**, **20 mA**, or **Other**.
4. If **Other** is selected, enter the desired value.
5. Select **Start**.
6. Measure the loop current.
7. Select **Stop** to end loop test.

Related information

[Calibrate analog out using Rosemount Radar Master Plus](#)
[Use the TEST terminal](#)
[Simulation/test active](#)

Perform an analog loop test using AMS Device Manager and handheld communicator

During a loop test, the transmitter outputs a fixed value (4 mA, 20 mA, or user-selected value). The loop test command verifies the output of the transmitter, the integrity of the loop, and the operations of any recorders or similar devices installed in the loop. A loop test can also be used to determine the need for an analog output calibration.

Prerequisites

If the transmitter is equipped with a TEST terminal, current can be measured directly at the terminal block without disconnecting any signal wires.

Procedure

1. Select **Service Tools** → **Simulate**.
2. Under **Analog Out**, select **Loop test**.
3. Select **4mA**, **20mA**, or **Other**, and then select **Next** (**Enter** on handheld communicator).
4. If **Other** is selected, enter the desired value, and then select **Next** (**Enter** on Field Communicator).
5. Measure the loop current.
6. To end loop test, select **Cancel** (**ABORT** on handheld communicator).

Related information

[Calibrate analog out using AMS Device Manager and handheld communicator](#)
[Use the TEST terminal](#)
[Simulation/test active](#)

7.4.4 Use the TEST terminal

Prerequisites

WARNING

Verify that the installation is consistent with the appropriate hazardous locations certifications when the instrument used for loop current measurement is connected.


For Explosion-proof/Flameproof and Non-Incendive/Type n installations, the cover must not be opened in an explosive atmosphere.

Note


Disconnect the blue plug only during the loop current measurement procedure. To meet the stated EMC specification during normal operation, the blue plug must be plugged in.

Procedure


1. Turn the jam screw clockwise until it is completely threaded into the housing.




2. Remove the cover.



3. Remove the blue plug from the TEST terminal.




4. Connect the ampere meter leads to the terminals labeled “+” and “TEST”.




5. Measure the loop current.

6. Attach the blue plug to the TEST terminal.




7. Attach and tighten the cover.

- a) Verify the cover jam screw is completely threaded into the housing.




- b) Attach and tighten the cover.

⚠ Make sure the cover is fully engaged. There should be no gap between the cover and the housing.



- c) Turn the jam screw counterclockwise until it contacts the cover.

⚠ Required for explosion-proof/flameproof installations only.



- d) Turn the jam screw an additional $\frac{1}{2}$ turn counterclockwise to secure the cover.

7.4.5 Calibrate analog out

Calibrate analog out using Rosemount Radar Master Plus

Use this function to calibrate the analog output by comparing the actual output current with the nominal 4 mA and 20 mA currents. Calibration is done at factory and the analog output does not normally need to be recalibrated.

Procedure

1. Under **Service Tools**, select **Maintenance** → **Routine Maintenance**.
2. Select **Calibrate Analog Out** and follow the on-screen instructions.

Calibrate analog out using AMS Device Manager and handheld communicator

Use this function to calibrate the analog output by comparing the actual output current with the nominal 4 mA and 20 mA currents. Calibration is done at factory and the analog output does not normally need to be recalibrated.

Procedure

1. Select **Service Tools** → **Maintenance** → **Routine Maintenance**.
2. Select **D/A trim** and follow the on-screen instructions.

7.4.6 Save a backup file of the device configuration

When configuration is finished, it is recommended to store the device configuration in a backup file for future reference using Rosemount Radar Master Plus. A backup of the device configuration will be saved to file as well as a configuration report (optional).

The backup file may be useful to:

- Restore the configuration of the transmitter.
- Install another transmitter in a similar tank.
- Troubleshoot the transmitter.

Procedure

1. In Rosemount Radar Master Plus, under **Service Tools**, select **Maintenance** → **Backup**.
2. Select **Save Configuration**.
3. Type your desired file name.
4. Browse to the desired directory, and then select **Save**.
5. Optional: Select the **Create and save report (.pdf)** check box.
6. Select **Save**.

7.4.7 Download configuration from file to device

Procedure

1. In Rosemount Radar Master Plus, under **Service Tools**, select **Maintenance** → **Backup**.
2. Select **Restore Configuration**.
3. Browse to the backup file and select **Open**.

7.4.8 Restart the device

Restart the device using Rosemount Radar Master Plus

To restart the device electronics:

Procedure

1. Under **Service Tools**, select **Maintenance** → **Reset/Restore**.
2. Select **Restart Device** and follow the on-screen instructions.

Restart the device using AMS Device Manager and handheld communicator

To restart the device electronics:

Procedure

1. Select **Service Tools** → **Maintenance** → **Reset/Restore**.
2. Select **Restart Device** and follow the on-screen instructions.

7.4.9 Restore to default settings

Restore to default settings using Rosemount Radar Master Plus

This function restores the transmitter to default settings (user configuration is overwritten).

Prerequisites

Before restoring the transmitter to default settings, it is recommended to backup the device configuration. The backup file can be used to restore configuration at a later stage.

Procedure

1. Under **Service Tools**, select **Maintenance** → **Reset/Restore**.
2. Select **Restore Default Settings**.

Related information

[Save a backup file of the device configuration](#)

Restore to default settings using AMS Device Manager and handheld communicator

This function restores the transmitter to default settings (user configuration is overwritten).

Prerequisites

Before restoring the transmitter to default settings, it is recommended to backup the device configuration. The backup file can be used to restore configuration at a later stage.

Procedure

1. Select **Service Tools** → **Maintenance** → **Reset/Restore**.
2. Select **Restore Default Settings** and follow the on-screen instructions.

Related information

[Save a backup file of the device configuration](#)

7.4.10 Use the simulation mode

Use the simulation mode with Rosemount Radar Master Plus

This function can be used to simulate measurements.

Procedure

1. Under **Service Tools**, select **Simulate**.
2. Select **Simulate** next to desired transmitter variable and follow the on-screen instructions.

Related information

[Simulation/test active](#)

Use the simulation mode with AMS Device Manager and handheld communicator

This function can be used to simulate measurements.

Procedure

1. Select **Service Tools** → **Simulate**.
2. Under **Simulate Measurement Values**, select desired transmitter variable and follow the on-screen instructions.

Related information

[Simulation/test active](#)

7.4.11 View input registers

View input registers using Rosemount Radar Master Plus

Measured data is continuously stored in the input registers. By viewing the contents of the input registers, expert users can check that the transmitter works properly.

Procedure

1. Under **Configure**, select **Level Setup** → **Advanced**.
2. Under **More Advanced Options**, select **Expert Options**.
3. Select the **Input Registers** tab.
4. Under **Show registers by**, do one of the following:
 - Select **Block**, and then in the list, select the desired register group.
 - Select **Number**, and then type the desired register number and the number of registers.
5. Select **Refresh**.

View input registers using AMS Device Manager and handheld communicator

Measured data is continuously stored in the input registers. By viewing the contents of the input registers, expert users can check that the transmitter works properly.

Procedure

1. Select **Configure** → **Manual Setup** → **Level Setup** → **Advanced** → **Expert Options** → **Input Registers**.
2. Type the desired register number to start reading from.
3. Select **Read Input Registers**. 10 registers will be read, starting from the selected number.
4. (Handheld communicator) Select **Input Registers**.

7.4.12 View/edit holding registers

View/edit holding registers using Rosemount Radar Master Plus

The holding registers store various transmitter parameters, such as configuration data, used to control the measurement performance.

Prerequisites

Note

Do not use holding registers to configure the transmitter unless you are qualified. This dialog is mainly used for service purposes and for advanced configuration.

Procedure

1. Under **Configure**, select **Level Setup** → **Advanced**.
2. Under **More Advanced Options**, select **Expert Options**.
3. Select the **Holding Registers** tab.
4. Under **Show registers** by, do one of the following:
 - Select **Block**, and then in the list, select the desired register group.
 - Select **Number**, and then type the desired register number and the number of registers.
5. Select **Refresh**.
6. To change a holding register value, type a new value in the corresponding value field, or select a new value from the corresponding list.
7. Select **Save** to store the new value.

View/edit holding registers using AMS Device Manager and handheld communicator

The holding registers store various transmitter parameters, such as configuration data, used to control the measurement performance.

Prerequisites

Note

Do not use holding registers to configure the transmitter unless you are qualified. This dialog is mainly used for service purposes and for advanced configuration.

Procedure

1. To view a holding register value:
 - a) Select **Configure** → **Manual Setup** → **Level Setup** → **Advanced** → **Expert Options** → **Holding Registers**.
 - b) Type the desired register number to start reading from.
 - c) Select **Read Holding Registers**. 10 registers will be read, starting from the selected number.
 - d) (Handheld communicator) Select **Holding Registers**.
2. To edit a holding register value:
 - a) Select **Configure** → **Manual Setup** → **Level Setup** → **Advanced** → **Expert Options** → **Holding Registers**.
 - b) Select **Write Holding Register** and follow the on-screen instructions.

7.5 Application challenges

7.5.1 Handling disturbances at top of tank

There are two general methods for managing disturbance echoes at the top of the tank:

- Set amplitude threshold section
- Extend the Upper Null Zone

Set amplitude threshold section

If necessary, a customized amplitude threshold section can be used to block out disturbing echoes (e.g. from the tank nozzle or bypass well inlet).

Prerequisites

Amplitude threshold sections are pre-configured at the factory for transmitters with process seal antenna. For nozzles taller than 10 in. (25 cm), it may be necessary to manually increase the distance value for the first endpoint ([Figure 7-22](#)).


Procedure

1. In Rosemount Radar Master Plus, start the echo curve reading.
2. View the echo curve plot to find out if there are disturbing echoes close to the transmitter.
3. Calculate the required distance to the first endpoint.

$$\text{Distance} = \text{Nozzle height} + 2 \text{ in. (50 mm)} =$$

4. In the echo curve, click the first endpoint and type the calculated value ([Figure 7-22](#)).
5. Select **Save**.

Figure 7-22: First Endpoint



A. First endpoint

Related information

[Amplitude thresholds](#)
[Read the echo curve](#)

Change the upper null zone

The Upper Null Zone defines a zone close to the transmitter where echoes are ignored. This zone can be extended to block out disturbing echoes at the top of the tank.

Prerequisites

Note


Make sure the Upper Range Value (100%/20 mA) value is below the Upper Null Zone. Measurements are not performed within the Upper Null Zone.

Procedure

1. Identify desired Upper Null Zone using the echo curve plot.
 - a) In Rosemount Radar Master Plus, start the echo curve reading.

- b) View the echo curve plot to find out if there are disturbing echoes close to the transmitter.
2. Set the desired Upper Null Zone value.
 - a) Under **Configure**, select **Level Setup** → **Antenna**.
 - b) Under **Advanced**, type desired Upper Null Zone, and then select **Save**.

Figure 7-23: Upper Null Zone



- A. Upper Null Zone
- B. Disturbance echo
- C. Amplitude threshold
- D. Product surface echo

Related information

[Read the echo curve](#)


7.5.2 Tracking of weak surface echoes close to tank bottom

Use tank bottom projection

The Tank Bottom Projection function can be used to enhance measurement performance in the tank bottom region.

If the product surface echo is weak in the tank bottom region and the bottom echo is strong (typical for flat tank bottoms), the transmitter may lock on the bottom echo and report a false level measurement (empty tank). If the application requires, the Tank Bottom Projection settings can be user-defined. [Figure 7-24](#) illustrates an example of the Tank Bottom Projection when the tank is being emptied.

Figure 7-24: Tank Bottom Projection



Procedure

1. In Rosemount Radar Master Plus, under **Configure**, select **Level Setup** → **Advanced**.
2. Under **More Advanced Options**, select **Empty Tank Handling**.
3. In the **Tank Bottom Projection** list, select **Enabled** or **Disabled**.
4. If you enabled Tank Bottom Projection, then:
 - a) Set the Bottom Product Dielectric Constant.
 - b) Enter Maximum Projection Distance.
 - c) Enter Minimum Tank Bottom Echo Amplitude.
5. Select **Save**.

Bottom product dielectric constant

Enter the product dielectric constant for the product in the bottom of the tank.

Maximum projection distance


This defines the range in which the function operates. Enter the maximum distance from the zero level (tank bottom). It is recommended to use the default setting.

Minimum tank bottom echo amplitude

Enter the minimum allowed amplitude for the echo from the tank bottom before this function is activated. It is recommended to use the default setting.

Enable bottom echo visible when tank is empty

Enable the Bottom echo visible when tank is empty parameter if a bottom echo is visible when tank is empty (i.e. for flat tank bottoms). The bottom echo will then be treated as a disturbance echo to facilitate tracking of weak surface echoes close to the tank bottom. This function may be useful for products which are relatively transparent for microwaves, such as oil.

Figure 7-25: Bottom Echo Visible

- A. Product surface near bottom of tank
- B. Empty tank
- C. Signal amplitude
- D. Distance
- E. Surface echo
- F. Echo peak from tank bottom (at the electrical distance when product in the tank)

Prerequisites

Note

Only enable this parameter if a bottom echo is visible when tank is empty. To verify this, use the echo curve function.

Procedure


1. In Rosemount Radar Master Plus, under **Configure**, select **Level Setup** → **Advanced**.
2. Under **More Advanced Options**, select **Empty Tank Handling**.
3. In the **Empty Tank Handling** list, select **User Defined**.
4. Select the **Bottom echo visible when tank is empty** check box.
5. Select **Save**.

7.5.3 Handling ghost echoes in still pipes

The Track First Echo function can eliminate ghost echo problems below the product surface. When enabled, the first echo above threshold will always be considered as the surface echo.

Ghost echoes may occur in still pipes because of multiple reflections between the pipe wall, flange, and antenna. In the echo curve, these echoes appear as amplitude peaks at various distances below the product surface, see [Figure 7-26](#).

Figure 7-26: Ghost Echoes in Still Pipes



- A. Signal amplitude
- B. Actual level
- C. Virtual level
- D. Distance

Procedure

1. In Rosemount Radar Master Plus, read the echo curve. Make sure there are no disturbing echoes above the product surface.
2. Under **Configure**, select **Level Setup** → **Advanced**.
3. Under **More Advanced Options**, select **Echo Tracking**.
4. In the **Surface Echo Tracking** list, select **User defined**, and then select the **Track First Echo** check box.

5. Select **Save**.

Related information


[Read the echo curve](#)

7.5.4 Handling strong double bounce echoes

Double bounces are most commonly present in spherical or horizontal cylinder tanks, and usually appear when the tank is about 60-70 percent filled. In these cases, the amplitude may be strong enough for the transmitter to interpret the double bounce as the surface echo. The Double Bounce Handling function is used for managing such problems.

A double bounce echo occurs when a radar signal bounces back and forth between the product surface and tank roof (or other object within the tank) before it is detected by the transmitter. Normally, these signals have a low amplitude and are ignored by the transmitter.

Figure 7-27: Double Bounce Echoes



- A. Distance to surface
- B. Distance to first double bounce
- C. Actual level
- D. Virtual level (first double bounce)
- E. Signal amplitude
- F. Distance

Prerequisites

Note

The Double Bounce Handling function should only be used if the problem of double bounces cannot be solved by changing the mounting position.

Note

The surface echo is required to suppress the double bounce. If the surface echo enters the Upper Null Zone, there is no product surface reference and the double bounce might be interpreted as the surface echo.

Procedure

1. In Rosemount Radar Master Plus, read the echo curve plot to determine if double bounce echoes are present.
2. Under **Configure**, select **Level Setup** → **Advanced**.
3. Under **More Advanced Options**, select **Echo Tracking**.
4. In the **Double Bounce Handling** list, select **Enabled** or **Disabled**.
5. If you enabled Double Bounce Handling, then enter desired Double Bounce Offset.
6. Select **Save**.

Related information

[Read the echo curve](#)

Double bounce offset

The distance between each double bounce echo is constant. The Double Bounce Offset is used to define the distance between detected double bounces, as given by the following formula (see [Figure 7-27](#)):

$$\text{Double Bounce Offset} = B - 2A$$

The Double Bounce Offset is negative if the reflection point (normally the tank roof) is below the Tank Reference Point.

7.6 Replace the transmitter head


Prerequisites

⚠ In Explosion Proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.


Procedure

1. Disconnect the power supply.
2. If applicable, remove the external ground cable from the transmitter head.


3. Turn the jam screw clockwise until it is completely threaded into the housing.




4. Remove the cover.



5. Remove all electrical leads and disconnect conduit.




6. Loosen the nut that connects the transmitter head to the process seal.




7. Carefully lift the transmitter head.

⚠ Do not attempt to loosen it by rotating the transmitter head. If it is stuck, then it may need to be replaced with a new process connection and transmitter head, by following all plant safety rules and procedures.



8. Attach a protection plug to the process seal to protect it from dust and water.



A. Process seal

7.7 Cleaning or replacing the PTFE sealing

This section applies only to transmitters with a process seal antenna.

Replace the PTFE sealing if it shows any signs of damage. If it is not damaged, clean and reuse it.

Remove from service

⚠ Be aware of the following:

- Follow all plant safety rules and procedures.
- In Explosion Proof/Flameproof and Non-Incendive/Type n installations, do not remove the transmitter covers when power is applied to the unit.
- Do not remove the process connection while in operation. Removing while in operation may cause process gas leaks.

Cleaning

To avoid electrostatic charges, use only a damp cloth to clean the PTFE surfaces. Clean the PTFE sealing with care.

The transmitter is suitable for:

- Cleaning-Out-of-Place (COP)
- Cleaning-In-Place (CIP)
- Steaming-In-Place (SIP)

Related information

[Clean-In-Place \(CIP\)](#)


[Steam-In-Place \(SIP\)](#)

7.7.1 Flanged version


Disassembly procedures

Procedure


1. Insert two flathead screwdrivers between the PTFE sealing and flange.



2. Gently push the screwdriver handles forward until the PTFE sealing pops out.




3. Carefully pull the PTFE sealing straight out.




Reassembly procedures

Procedure



1. Clean the cavity with a lint-free cloth.



2. Verify the O-ring on the PTFE sealing is in place.



3. Gently insert the PTFE sealing until it stops, and then firmly push it all the way in.



7.7.2 Tri Clamp version

Disassembly procedures


Procedure

1. Insert a wide flathead screwdriver into the groove at the base of the PTFE sealing.


2. Gently wiggle the screwdriver back and forth.

Note

Be careful not to scratch or depress the PTFE surfaces (facing the process).




3. Repeat [Step 1-Step 2](#) at different positions until the PTFE sealing is loose.
4. Carefully lift the PTFE sealing.




Reassembly procedures

Procedure


1. Clean the cavity with a lint-free cloth.



2. Verify the O-ring on the PTFE sealing is in place.



3. Gently insert the PTFE sealing until it stops, and then firmly push it all the way in.



7.8 Service support

To expedite the return process outside of the United States, contact the nearest Emerson representative.

Within the United States, call the Emerson Instrument and Valve Response Center using the 1-800-654-RSMT (7768) toll-free number. This center, available 24 hours a day, will assist you with any needed information or materials.

The center will ask for product model and serial numbers, and will provide a Return Material Authorization (RMA) number. The center will also ask for the process material to which the product was last exposed.

CAUTION

Individuals who handle products exposed to a hazardous substance can avoid injury if they are informed of and understand the hazard. Returned products must include a copy of the required Safety Data Sheet (SDS) for each substance.

Emerson Instrument and Valve Response Center representatives will explain the additional information and procedures necessary to return goods exposed to hazardous substances.

A Specifications and reference data

A.1 Performance specifications

A.1.1 General

Conformance to specification ($\pm 3\sigma$ [Sigma])

Technology leadership, advanced manufacturing techniques, and statistical process control ensure specification conformance to at least $\pm 3\sigma$.

Reference conditions

- Measurement target: Stationary metal plate, no disturbing objects
- Temperature: 59 to 77 °F (15 to 25 °C)
- Ambient pressure: 14 to 15 psi (960 to 1060 mbar)
- Relative humidity: 25-75%
- Damping: Default value, 2 s

Instrument accuracy (under reference conditions)

- Ultra accuracy: ± 0.04 in. (± 1 mm)⁽⁵⁾
- Standard: ± 0.08 in. (± 2 mm)⁽⁵⁾

Repeatability

± 0.04 in. (± 1 mm)

Ambient temperature effect

± 0.04 in. (± 1 mm)/10 K⁽⁶⁾

Sensor update rate

Minimum 1 update per second

Maximum level rate

40 mm/s as default, adjustable up to 200 mm/s

(5) Refers to inaccuracy according to IEC 60770-1 when excluding installation dependent offset. See the IEC 60770-1 standard for a definition of radar specific performance parameters and if applicable corresponding test procedures.

(6) Ambient temperature effect specification valid over temperature range -40 °F to 176 °F (-40 °C to 80 °C).

A.1.2 Measuring range

Table A-1: Maximum Measuring Range, ft. (m)

Model	Performance class	
	Standard	Ultra accuracy
Rosemount 5408	130 (40)	50 (15)
Rosemount 5408:SIS ⁽¹⁾	130 (40) in Control/Monitoring mode 82 (25) in Safety (SIS) mode	50 (15)

(1) The Rosemount 5408:SIS has two operational modes: Safety (SIS) and Control/Monitoring. Safety (SIS) mode must be set when used in Safety Instrumented Systems. Control/Monitoring mode is intended for use in a Basic Process Control System (BPCS).

Note that a combination of adverse process conditions, such as heavy turbulence, foam, and condensation, together with products with poor reflection may affect the measuring range.

Measuring range for solids

The figures given in Table A-2 should be considered as guidelines; the total measuring range may differ depending on other contributing application conditions such as product filling, how the product piles up, silo diameter vs. angle of repose, internal obstacles within the silo, dust, condensation, antenna build up, etc.

Table A-2: Recommended Measuring Range for Solids, ft. (m)

Antenna	Light powder ⁽¹⁾	Light granulates and pellets ⁽²⁾	Heavy powder ⁽³⁾	Grains ⁽⁴⁾	Larger particles ⁽⁵⁾
1½-in. (DN40) cone	16 (5)	33 (10)	66 (20)	66 (20)	82 (25)
2-in. (DN50) cone/process seal ⁽⁶⁾	16 (5)	33 (10)	82 (25)	82 (25)	98 (30)
3-in. (DN80) cone/process seal ⁽⁶⁾	49 (15)	66 (20)	98 (30)	98 (30)	130 (40)
4-in. (DN100) process seal ⁽⁶⁾					
4-in. (DN100) cone ⁽⁶⁾	66 (20)	98 (30)	130 (40)	130 (40)	130 (40)
8-in. (DN200) parabolic ⁽⁷⁾	115 (35)	130 (40)	130 (40)	130 (40)	130 (40)

(1) Plastic powder, etc. (Dielectric constant: 1.2)

(2) Plastic pellets, etc. (Dielectric constant: 1.35)

(3) Lime powder, cement, sand, etc. (Dielectric constant: 1.5)

(4) Kernels, brans, etc. (Dielectric constant: 1.5)

(5) Wood chips/pellets, etc. (Dielectric constant: 1.7)

(6) Cone and process seal antennas are the preferred choice for most solid applications. For specific recommendations in dusty applications, see section "Dust management" in the Measuring Level and Volume of Solid Materials [Technical Note](#).

(7) Recommended for longer measuring ranges, typically > 66 ft (20 m).


Accuracy over measuring range

The measuring range is limited by the blind zone at the very top of the tank. In the blind zone, the accuracy exceeds ± 0.20 in. (± 5 mm) and measurements may not be possible. Measurements close to the blind zone will have reduced accuracy (see [Figure A-1](#)).

For the extended cone antennas, the reduced accuracy zone ends 11.8 in. (30 cm) below the antenna end.

The accuracy in still pipe/chamber installations depends on how well the antenna size matches the pipe size. For more details, refer to the Best Practices for Using Radar in Still Pipes and Chambers [Technical Note](#).

Figure A-1: Accuracy Over Measuring Range



A.1.3

Environment

Vibration resistance

- 2 g at 10-180 Hz according to IEC 61298-3, level “field with general application”
- IACS UR E10 test 7

For compliance with these standards, the transmitter housing must be fully engaged into the sensor module. This is achieved by rotating the transmitter housing clockwise to thread limit.

Related information

[Adjust display orientation \(optional\)](#)

Electromagnetic compatibility (EMC)

- EMC Directive (2014/30/EU): EN 61326-1
- EN 61326-2-3
- NAMUR recommendations NE21⁽⁷⁾

For Rosemount 5408:SiS, the blue plug on the terminal block must be connected.

Pressure Equipment Directive (PED)

Complies with 2014/68/EU article 4.3

Built-in lightning protection

EN 61326, IEC 61000-4-5, level 6kV

Radio approvals

- Radio Equipment Directive (2014/53/EU): ETSI EN 302 372, ETSI EN 302 729 and EN 62479
- Part 15 of the FCC Rules
- Industry Canada RSS 211

A.2 Functional specifications

A.2.1 General

Field of application

Continuous level measurements for tank monitoring, process control, and overflow prevention on a broad range of liquids, slurries, and solids.

Ideal for applications with varying and harsh process conditions, such as heavy turbulence, foaming, product build-up, condensing vapors, sticky, viscous, corrosive, and crystallizing products.

Measurement principle

Frequency Modulated Continuous Wave (FMCW)

Frequency range

24.05 to 27.0 (26.5⁽⁸⁾) GHz

⁽⁷⁾ In challenging applications where the dynamic of the transmitter sensitivity is utilized by multiple factors such as small aperture antenna, very low product dielectric constant and/or turbulent surface, the margin for additional influence due to extreme EMC may be limited.

Maximum output power

-5 dBm (0.32 mW)

Internal power consumption

< 1 W in normal operation

Humidity

0 - 100% relative humidity, non-condensing

Turn-on time

< 40 s⁽⁹⁾

A.2.2 Functional safety

The Rosemount 5408:SIS Level Transmitter is IEC 61508 certified to:

- Low and high demand: Type B element
- SIL 2 for random integrity @ HFT=0
- SIL 3 for random integrity @ HFT=1
- SIL 3 for systematic capability

Related information

[Functional Safety Certificate](#)

[Rosemount 5408:SIS Safety Manual](#)

A.2.3 Display and configuration


LCD display

- Toggles between selected output variables
- Shows diagnostic information (alerts)

(8) 26.5 GHz in Australia, New Zealand, and Russia, and for LPR (Level Probing Radar), option code OA.

(9) Time from when power is applied to the transmitter until performance is within specifications.

Figure A-2: LCD Display



Remote display

Data can be read remotely by using the Rosemount 751 Field Signal Indicator, see the corresponding [Product Data Sheet](#) for more information.

Damping

User selectable (default is 2 s, minimum is 0 s)⁽¹⁰⁾

Output units

- Level and distance: ft., in., m, cm, mm
- Level rate: ft/s, in./min, in./s, m/h, m/s
- Volume: ft³, in.³, yd³, US gal, imperial gal, barrel (bbl), m³, l
- Temperature: °F, °C
- Signal strength: mV

⁽¹⁰⁾ The Damping parameter defines how fast the device responds to level changes (step response). A high value makes the level steady but the device reacts slowly to level changes in the tank.

Output variables

Variable	4-20 mA	Digital output	LCD display
Level	✓	✓	✓
Distance (ullage)	✓	✓	✓
Volume	✓	✓	✓
Scaled variable ⁽¹⁾	✓	✓	✓
Electronics temperature	N/A	✓	✓
Signal quality ⁽¹⁾	N/A	✓	✓
Level rate	N/A	✓	✓
Signal strength	N/A	✓	✓
Percent of range	N/A	✓	✓
Percent of range auxiliary	N/A	✓	✓
User-defined ⁽¹⁾	✓	✓	✓

⁽¹⁾ Only for transmitters ordered with Smart Diagnostics Suite.

A.2.4 4-20 mA HART

Output

Two-wire, 4-20 mA. Digital process variable is superimposed on 4-20 mA signal, and available to any host that conforms to the HART protocol. The digital HART[®] signal can be used in multidrop mode.

HART Revision

- Revision 6 (default)
- Revision 7 (option code HR7)

The HART revision can be switched in field.

Analog signal on alarm

The transmitter automatically and continuously performs self-diagnostic routines. If a failure or a measurement error is detected, the analog signal will be driven offscale to alert the user. High or low failure mode is user-configurable.

Table A-3: Signal on Alarm

Standard	High	Low
Rosemount standard	≥ 21.75 mA (default)	≤ 3.75 mA (option code C8)
NAMUR NE43	≥ 22.50 mA (option code C4)	≤ 3.6 mA (option code C5)

Analog saturation levels

The transmitter will drive the output to high or low saturation values if measurement goes outside the 4-20 mA range values.

Table A-4: Saturation Levels

Standard	High	Low
Rosemount standard (default and option code C8)	20.8 mA	3.9 mA
NAMUR NE43 (option code C4 and C5)	20.5 mA	3.8 mA

A.2.5

Process temperature and pressure rating

The following figures give the process temperature limits (measured at the lower part of the flange, Tri Clamp, or threaded connection) and pressure rating for different antenna types.


Final rating may be lower depending on flange selection.

For antenna type code CAB, at 100 °F (38 °C), the rating decreases with increasing temperature per ASME B16.5 Table 2-2.2, Class 300.

Note


For applications where saturated steam may occur, consult factory.

Figure A-3: Cone Antenna (PTFE Seal)



- A. Pressure psig (bar)
- B. Temperature °F (°C)
- C. Code CAC
- D. Code CAB
- E. Code CAA
- F. Code CAD

Figure A-4: Cone Antenna (PEEK Seal)



- A. Pressure psig (bar)
- B. Temperature °F (°C)
- C. Code CBF (FVMQ)
- D. Code CBV (Viton®)
- E. Code CBM (FKM)
- F. Code CBK (Kalrez® 6375)

Figure A-5: Process Seal Antenna with Tri Clamp



- A. Pressure psig (bar)
- B. Temperature °F (°C)

Figure A-6: 2-in. Process Seal Antenna with Flange



- A. Pressure psig (bar)
- B. Temperature °F (°C)

Figure A-7: 3-in. Process Seal Antenna with Flange



- A. Pressure psig (bar)
B. Temperature °F (°C)

Figure A-8: 4-in. Process Seal Antenna with Flange



- A. Pressure psig (bar)
B. Temperature °F (°C)

Figure A-9: Parabolic Antenna



- A. Pressure psig (bar)
B. Temperature °F (°C)

A.2.6 Cryogenic applications

Operating temperature at flange

See [Figure A-3](#) to [Figure A-9](#) for antenna type specific operating limits.

Operating temperature in tank

-320.8 to 482 °F (-196 to 250 °C)

A.2.7 Ambient temperature limits

Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications, see [Product certifications](#).


Table A-5: Ambient Temperature Limits

Description	Operating limit	Storage limit ⁽¹⁾
Without LCD display	-40 °F to 176 °F (-40 °C to 80 °C)	-58 °F to 176 °F (-50 °C to 80 °C)
With LCD display ⁽²⁾		-40 °F to 176 °F (-40 °C to 80 °C)

- (1) The minimum storage temperature is -22 °F (-30 °C) for the cone antenna with Kalrez® 6375 O-ring (antenna type code CBK).
- (2) LCD display may not be readable and LCD display updates will be slower at temperatures below -4 °F (-20 °C).

The ambient temperature limits may be further restricted by the process temperature as described by [Figure A-10](#).

Figure A-10: Ambient Temperature vs. Process Temperature



Aside from ambient temperature variations, heat from the process may be transferred to the transmitter housing. Being exposed to a high process temperature without extra cooling for an extended period of time may cause the electronics temperature to exceed the allowed limit and thereby affect the transmitter's performance and reliability. The latter are potential risks whenever a transmitter has shut down due to high electronics temperature. The transmitter will warn about the electronics temperature being out of limits.

Related information

[Electronics temperature out of limits](#)

A.2.8 Flange rating

ASME

- 316 SST according to ASME B16.5 Table 2-2.2
- 316L SST according to ASME B16.5 Table 2-2.3 (for protective plate design)⁽¹¹⁾
- Alloy C-276 (UNS N10276) according to ASME B16.5 Table 2-3.8
- Alloy 400 (UNS N04400) according to ASME B16.5 Table 2-3.4

EN

- 1.4404 according to EN 1092-1 material group 13E0

JIS

- 316 SST according to JIS B2220 material group No. 2.2
- 316L SST according to JIS B2220 material group No. 2.3 (for protective plate design)⁽¹¹⁾

A.2.9 Conditions used for flange strength calculations

Table A-6: 316/316L SST (EN 1.4404) Flanges

Item	ASME	EN, JIS
Bolting material	SA193 B8M CL.2, SA193 B7 ⁽¹⁾ , or SA320 L7 ⁽¹⁾	EN 1515-1/2, ISO 3506 A4-70, or Bumax [®] 88 ⁽¹⁾
Gasket ⁽²⁾	Soft (1a) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (1b)	Soft (EN 1514-1) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (EN 1514-2)
Flange material	Stainless steel A182 Gr. F316 and EN 10222-5-1.4404	
Hub material ⁽³⁾	Stainless steel SA479 316 and EN 10272-1.4404	

(1) Only applicable to forged one-piece flanges.

(2) Not applicable to process seal antenna (features an integrated gasket). Use of extra gasket may result in faulty installation.

(3) Only applicable to flanges with welded construction.

(11) Flange rating according to backing flange.

Table A-7: Flanges with Protective Plate Design

Item	ASME	EN, JIS
Bolting material	SA193 B8M Cl.2	EN 1515-1/2, ISO 3506 A4-70
Gasket ⁽¹⁾	Soft (1a) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (1b)	Soft (EN 1514-1) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (EN 1514-2)
Flange material	Stainless steel A182 Gr. F316L/F316 and EN 10222-5-1.4404	
Hub material	SB574 Gr. N10276 (solution annealed condition) or SB164 Gr. N04400 (solution annealed condition)	

(1) Note that a minimum gasket thickness of 0.125 in. (3.2 mm) is required when using an air purge ring (option code PC1).

Table A-8: Alloy C-276 (UNS N10276) Flanges

Item	ASME	EN, JIS
Bolting material	UNS N10276	UNS N10276
Gasket	Soft (1a) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (1b)	Soft (EN 1514-1) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (EN 1514-2)
Flange material	SB462 Gr. N10276 (solution annealed condition) or SB575 Gr. N10276 (solution annealed condition)	
Hub material	SB574 Gr. N10276 (solution annealed condition)	

Table A-9: Alloy 400 (UNS N04400) Flanges

Item	ASME	EN, JIS
Bolting material	UNS N04400	UNS N04400
Gasket	Soft (1a) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (1b)	Soft (EN 1514-1) with min. thickness 1.6 mm or Spiral wound gasket with nonmetallic filler (EN 1514-2)
Flange material	SB/B564 Gr. N04400 (solution annealed condition) or SB/B127 Gr. N04400 (solution annealed condition)	
Hub material	SB164 Gr. N04400 (solution annealed condition)	

A.3 Physical specifications

A.3.1 Material selection

Emerson provides a variety of Rosemount products with various product options and configurations including materials of construction that can be expected to perform well in a wide range of applications. The Rosemount product information presented is intended as a guide for the purchaser to make an appropriate selection for the application. It is the purchaser's sole responsibility to make a careful analysis of all process parameters (such as all chemical components, temperature, pressure, flow rate, abrasives, contaminants, etc.), when specifying product, materials, options, and components for the particular application. Emerson is not in a position to evaluate or guarantee the compatibility of the process fluid or other process parameters with the product, options, configuration or materials of construction selected.

A.3.2 Transmissible Spongiform Encephalopathy (TSE) declaration

This declaration is applicable to Tri Clamp connections.

Emerson certifies no process wetted components used in this product contain substances of animal origin. Materials used in the production or processing of wetted components for this product meet the requirements stated in EMA/410/01 Rev. 3 and ISO 22442-1:2015. Wetted components in this product are considered free of TSE.

A.3.3 Engineered solutions

When standard model codes are not sufficient to fulfill requirements, please consult the factory to explore possible Engineered Solutions. This is typically, but not exclusively, related to the choice of wetted materials or the design of a process connection. These Engineered Solutions are part of the expanded offerings and may be subject to additional delivery lead time. For ordering, factory will supply a special P-labeled numeric option code that should be added at the end of the standard model string.

A.3.4 Housing and enclosure

Electrical connections

Two cable/conduit entries ($\frac{1}{2}$ -14 NPT, M20 x 1.5, or G $\frac{1}{2}$)

Optional adapters: M12 4-pin male eurofast connector or A size Mini 4-pin male minifast connector

Materials

- Electronics housing: Polyurethane-covered Aluminum or Stainless Steel Grade CF-8M (ASTM A743)
- Sensor module: 316L SST

Weight

- Aluminum housing: 6.2 lb (2.8 kg)⁽¹²⁾
- Stainless steel housing: 10.0 lb (4.5 kg)⁽¹²⁾

Ingress protection

IP 66/67/68⁽¹³⁾ and NEMA® 4X

A.3.5 Tank connection

The tank connection consists of a tank seal, a flange, NPT or BSPP (G) threads, Tri Clamp, or a specific welded connection with swivel feature for parabolic antenna.

Flange dimensions

Follows ASME B16.5, JIS B2220, and EN 1092-1 standards. For more information, see [Standard flanges](#).

Tri Clamp connection

Follows ISO 2852 standard.

A.3.6 Material exposed to tank atmosphere

Cone antenna, PTFE seal

- 316/316L SST (EN 1.4404), Alloy C-276 (UNS N10276), or Alloy 400 (UNS N04400)
- PTFE fluoropolymer

Cone antenna, PEEK seal

- 316/316L SST (EN 1.4404), Alloy C-276 (UNS N10276), or Alloy 400 (UNS N04400)
- PEEK polyetheretherketone
- FVMQ fluorosilicone, Kalrez® 6375 perfluoroelastomer, FKM fluoroelastomer, or Viton® fluoroelastomer (O-ring)

Process seal antenna

- PTFE fluoropolymer

Parabolic antenna

- 316/316L SST (EN 1.4404)
- PTFE fluoropolymer
- FVMQ fluorosilicone (O-ring)

⁽¹²⁾ Fully functional transmitter with sensor module, housing, terminal block, LCD display, and covers.

⁽¹³⁾ The transmitter meets IP 68 at 9.8 ft. (3 m) for 30 minutes.

A.4 Spare parts and accessories

A.4.1 Spare parts list - transmitter head

Required model components Model

Code	Description	
5408	Radar Level Transmitter	★

Profile

Code	Description	
A	Standard monitoring & control applications	★
F ⁽¹⁾	Functional safety / SIS applications	★

(1) The Rosemount 5408:SIS has two operational modes: Safety (SIS) and Control/Monitoring. Safety (SIS) mode must be set when used in Safety Instrumented Systems. Control/Monitoring mode is intended for use in a Basic Process Control System (BPCS).

Measurement type

Code	Description	
1	Liquid level measurement	★
3	Solids level measurement	★
4 ⁽¹⁾	Liquid & solids level measurement	★

(1) Note that for the Rosemount 5408:SIS (profile code F), solids level measurement is only available when operating in Control/Monitoring mode.

Performance class

Code	Description	Reference accuracy	
A	Ultra accuracy	±0.04 in. (±1 mm)	★
S	Standard	±0.08 in. (±2 mm)	★

Signal output

Code	Description	
H	4–20 mA with digital signal based on HART® revision 6 protocol (HART revision 7 available as option)	★

Housing material

Code	Description	
A	Aluminum	★
S	Stainless steel (SST)	★

Conduit/cable threads

Code	Description	
1	½-14 NPT	★
2	M20 x 1.5	★
3 ⁽¹⁾	G½	

(1) G½ thread form is not available with hazardous locations approvals.

Hazardous locations certifications

Code	Description	
NA	None	★
E1	ATEX Flameproof	★
I1	ATEX Intrinsic Safety	★
N1	ATEX Type n	★
E5	USA Explosion-proof, Dust Ignition-proof	★
I5	USA Intrinsically Safe; Nonincendive	★
E6	Canadian Explosion-proof, Dust Ignition-proof	★
I6	Canadian Intrinsically Safe; Nonincendive	★
E7	IECEx Flameproof, Dust Ignition-proof	★
I7	IECEx Intrinsic Safety	★
N7	IECEx Type n	★
E2	INMETRO Flameproof	★
I2	INMETRO Intrinsic Safety	★
N2	INMETRO Type n	★
E3	China Flameproof	★
I3	China Intrinsic Safety	★
N3	China Type n	★
E4	Japan Flameproof	★
EP	Republic of Korea Flameproof	★
IP	Republic of Korea Intrinsic Safety	★
EM ⁽¹⁾	Technical Regulations Customs Union (EAC) Flameproof	★

Code	Description	
IM ⁽¹⁾	Technical Regulations Customs Union (EAC) Intrinsic Safety	★
NM ⁽¹⁾	Technical Regulations Customs Union (EAC) Type n	★

(1) Not available with performance class code A (ultra accuracy).

Materials of construction

Code	Description	
Z	None (spare transmitter head)	★

Process connection type

Code	Description	
Z	None (spare transmitter head)	★

Process connection size

Code	Description	
Z	None (spare transmitter head)	★

Process connection rating

Code	Description	
ZZ	None (spare transmitter head)	★

Antenna type

Code	Description	
ZZZ	None (spare transmitter head)	★

Antenna size

Code	Description	
Z	None (spare transmitter head)	★

Additional options

Display

Code	Description	
M5	LCD display	★

Functional safety options

Code	Description	
EF2	Extended SIS package	★

Diagnostic functionality

Code	Description	
DA1	HART Smart Diagnostics Suite	★

Smart level test

Code	Description	
ET	Smart Echo Level Test	★

HART revision configuration

Code	Description	
HR7	4-20 mA with digital signal based on HART revision 7 protocol	★

Open air applications configuration

This option is only available with parabolic antenna, 3-in. (DN80) and 4-in. (DN100) process seal antennas, and 4-in. (DN100) cone antenna.

Code	Description	
OA	Open air applications configuration; LPR (Level Probing Radar)	★

Factory configuration

Code	Description	
C1	Factory configuration per Configuration Data Sheet	★

Alarm limits

Code	Description	
C4	NAMUR alarm and saturation levels, high alarm	★
C5	NAMUR alarm and saturation levels, low alarm	★
C8 ⁽¹⁾	Standard Rosemount alarm and saturation levels, low alarm	★

(1) The standard alarm setting is high.

Special quality assurance

Code	Description	
Q4	Calibration data certificate	★
QG	Calibration certificate and GOST verification certificate (only for end-destination country Russia)	

Hygienic certification

Only available for process seal antennas with Tri Clamp connection.

Code	Description	
QA	Certificate of compliance to 3-A®	★

Quality certification for safety

Code	Description	
QS	Certificate of FMEDA Data	★
QT	Safety-certified to IEC 61508 with certificate of FMEDA data	★

Overfill prevention

Code	Description	
U1	Overfill prevention according to WHG/TUV	★

Shipboard approvals

Transmitters with aluminum housing are not approved for open deck installations; for use only in engine room, pump room, etc.

Code	Description	
SBS	American Bureau of Shipping Type Approval	★
SDN	Det Norske Veritas Germanischer Lloyd (DNV GL) Type Approval	★
SLL	Lloyd's Register Type Approval	★
SBV	Bureau Veritas Type Approval	★
SRS	Russian Maritime Register of Shipping	★

Extended product warranty

Rosemount extended warranties have a limited warranty of three or five years from date of shipment.

Code	Description	
WR3	3-year limited warranty	★
WR5	5-year limited warranty	★

Paint option for aluminum housing

Code	Description	
PY1	Housing and covers in yellow per RAL 1003	★
PY2	Covers in yellow per RAL 1003	★
PR1	Housing and covers in red per RAL 3002	★
PR2	Covers in red per RAL 3002	★
PO1	Housing and covers in orange per Munsell 2.5 YR 6/14	★
PO2	Covers in orange per Munsell 2.5 YR 6/14	★

Conduit electrical connector (shipped uninstalled)

Requires ½-14 NPT conduit/cable threads (code 1). Available with Intrinsically Safe approvals only.

Code	Description	
EC	M 12, 4-pin, male connector (eurofast®)	★
MC	A size Mini, 4-pin, male connector (minifast®)	★

Adapter wetted parts

Rosemount 5408 is backward compatible with the full range of Rosemount 5402 antennas, manufactured after September 2013, when ordered with the appropriate adapter (option code A1).

The Rosemount 5408 transmitter head can also pre-configured to an existing Rosemount 5402 antenna. Contact your Emerson sales representative for more information.

Code	Description	
A1	Adapter for Rosemount 5402 Antennas	★

Specials

Code	Description	
PXXXX	Custom engineered solutions beyond standard model codes. Consult factory for details.	

A.4.2 Spare parts list - antenna

Required model components Model

Code	Description	
5408	Radar Level Transmitter	★

Profile

Code	Description	
Z	None (Spare Antenna)	★

Measurement type

Code	Description	
9	None (Spare Antenna)	★

Performance class

Code	Description	
Z	None (Spare Antenna)	★

Signal output

Code	Description	
Z	None (Spare Antenna)	★

Housing material

Code	Description	
Z	None (Spare Antenna)	★

Conduit/cable threads

Code	Description	
Z	None (Spare Antenna)	★

Hazardous locations certifications

Code	Description	
NA	None	★

Materials of construction

Code	Description	Available antenna types	
1	316/316L/EN 1.4404	Cone, parabolic	★
7	All PTFE wetted parts	Process seal	★
2	Alloy C-276 (UNS N10276) with protective plate	Cone	
3	Alloy 400 (UNS N04400) with protective plate	Cone	
H	Alloy C-276 (UNS N10276) process connection, flange, and antenna	Cone	
M	Alloy 400 (UNS N04400) process connection, flange, and antenna	Cone	

Process connection type

Code	Description	Available antenna types	
F ⁽¹⁾	Flat Face flange	Cone, parabolic	★
R ⁽²⁾	Raised Face flange	All	★
N	NPT thread	Cone	★
G	BSPP (G) thread	Cone, parabolic	★
B	Bracket mounting	All	★
C	Tri Clamp	Process seal	★
W	Welded connection	Parabolic	★
T	Ring Type Joint (RTJ) flange	Cone	

(1) Type A flat face for EN 1092-1 flanges.

(2) Type B1 raised face for EN 1092-1 flanges.

Process connection size

Code	Description	Available antenna types	
A	1½-in.	Cone	★
2	2-in./DN50/50A	Cone, process seal	★
3	3-in./DN80/80A	Cone, process seal	★
B	3½-in.	Parabolic	★
4	4-in./DN100/100A	Cone, process seal	★
6	6-in./DN150/150A	Cone	★
8	8-in./DN200/200A	Cone, parabolic	★
T	10-in./DN250/250A	Parabolic	★
Z	None (use when ordering bracket mounting)	All	★

Process connection rating

Code	Description		
ZZ	For use with non-flange process connection type		★
ASME flanges			
AA	ASME B16.5 Class 150		★
AB	ASME B16.5 Class 300		★
AC	ASME B16.5 Class 600		★
AD	ASME B16.5 Class 900		★
EN flanges		Note	
DK	EN1092-1 PN6		★
DA	EN1092-1 PN16	PN10 and PN16 dimensions are identical for DN50 to DN150	★
DB	EN1092-1 PN40	PN25 and PN40 dimensions are identical for DN50 to DN150	★
DC	EN1092-1 PN63		★
DD	EN1092-1 PN100		★
JIS flanges			
JK	JIS 5K		★
JA	JIS 10K		★
JB	JIS 20K		★

Antenna type

For applications where saturated steam may occur, consult factory.

Code	Description	Operating pressure	Operating temperature	
CAA	Cone antenna (PTFE seal)	-15 to 363 psig (-1 to 25 bar)	-76 to 392 °F (-60 to 200 °C)	★
CAB	Cone antenna (PTFE seal)	-15 to 725 psig (-1 to 50 bar) ⁽¹⁾	-40 to 302 °F (-40 to 150 °C)	★
CAC	Cone antenna (PTFE seal)	-15 to 1450 psig (-1 to 100 bar)	-40 to 212 °F (-40 to 100 °C)	★
CAD	Cone antenna (PTFE seal)	-15 to 44 psig (-1 to 3 bar)	-76 to 482 °F (-60 to 250 °C)	★
CBF	Cone antenna (PEEK seal, FVMQ)	-15 to 754 psig (-1 to 52 bar)	-76 to 338 °F (-60 to 170 °C)	★
CBK	Cone antenna (PEEK seal, Kalrez® 6375)	-15 to 754 psig (-1 to 52 bar)	5 to 482 °F (-15 to 250 °C)	★
CBM	Cone antenna (PEEK seal, FKM)	-15 to 754 psig (-1 to 52 bar)	-13 to 428 °F (-25 to 220 °C)	★
CBV	Cone antenna (PEEK seal, Viton®)	-15 to 754 psig (-1 to 52 bar)	-22 to 392 °F (-30 to 200 °C)	★
SAA	Process seal antenna	-15 to 363 psig (-1 to 25 bar) ⁽²⁾	-76 to 392 °F (-60 to 200 °C) ⁽²⁾	★
PAS	Parabolic antenna, swivel mount	-7 to 43 psig (-0.5 to 3 bar)	-67 to 392 °F (-55 to 200 °C)	★

(1) Pressure limit is derated for process temperatures above 100 °F (38 °C).

(2) The final rating depends on the selected process connection.

Antenna size

Code	Description	Available antenna types	
A ⁽¹⁾	1½-in. (DN40)	Cone (PTFE seal)	★
2	2-in. (DN50)	Cone, process seal	★
3	3-in. (DN80)	Cone, process seal	★
4	4-in. (DN100)	Cone, process seal	★
8	8-in. (DN200)	Parabolic	★

(1) 1½-in. (DN40) cone antenna is available for 1½-in. NPT threaded connection and materials of construction code 1 (316/316L/EN 1.4404).

Additional options Antenna extensions

Code	Description	Total length	Available antenna sizes	
S1	Extended cone antenna	23.6-in. (600 mm)	All except 1½-in. (DN40)	★
S2	Extended cone antenna, segmented	47.2-in. (1200 mm)		★

Purging connection

Option code PC1 is for cone antennas only, and requires matching flange and antenna sizes. Note that all parabolic antennas come with an integrated air purge connection.

A minimum gasket thickness of 0.125 in. (3.2 mm) is required for flanges with protective plate design.

Code	Description	
PC1	Purging connector (purge ring)	★

Welding standard for flanges

Only applies to flanged process connections with welded construction or protective plate design; only applicable to cone antennas.

Flanged process connections with protective plate design are only available with ASME IX (option code AW).

Code	Description	
AW	According to ASME IX	★
EW	According to EN-ISO	★

Country certification

CRN is not available with EN1092-1 or JIS B2220 flanges, neither for ASME B16.5 flanges in materials of construction code M.

Code	Description	
J1	Canadian Registration (CRN)	★

Hydrostatic testing

Hydrostatic testing is only available for cone antennas and process seal antennas with flanged process connections.

Code	Description	
Q5	Hydrostatic testing, including certificate	★

Material traceability certification

Certificate includes all pressure retaining and wetted parts.

Code	Description	
Q8	Material traceability certification per EN 10204 3.1 (2.1 for non-metallic)	★

Hygienic certification

Only available for process seal antennas with Tri Clamp connection.

Code	Description	
QA	Certificate of compliance to 3-A®	★

Food and Drug Administration (FDA) statement

Only available for process seal antennas with Tri Clamp connection.

Code	Description	
QH ⁽¹⁾	Certificate of compliance to FDA 21CFR110, Subpart C: Food and Drug Administration - Current Good Manufacturing Practice in Manufacturing, Packing, or Holding Human Food	★

(1) Applicable only to wetted parts.

Materials certification

The materials certification is not available with parabolic antenna.

Code	Description	
Q15	NACE® material recommendation per NACE MR0175/ISO 15156	★
Q25	NACE material recommendation per NACE MR0103/ISO 17945	★
Q35	NACE material recommendation per NACE MR0175/ISO 15156 and NACE MR0103/ISO 17945	★

Welding procedure qualification record documentation

Only applies to flanged process connections with welded construction or protective plate design; only applicable to cone antennas.

Code	Description	
Q66	Welding Procedure Qualification Record (WPQR)	★
Q67	Welder Performance Qualification (WPQ)	★
Q68	Welding Procedure Specification (WPS)	★
Q79	WPQR/WPQ/WPS	★

Dye penetration test certificate

Only applies to flanged process connections with welded construction or protective plate design; only applicable to cone antennas.

Code	Description	
Q73	Certificate of liquid penetrant inspection	★

Positive material identification certificate

Code	Description	
Q76	Positive material identification certificate of conformance	★

Shipboard approvals

Transmitters with aluminum housing are not approved for open deck installations; for use only in engine room, pump room, etc.

Code	Description	
SBS	American Bureau of Shipping Type Approval	★
SDN	Det Norske Veritas Germanischer Lloyd (DNV GL) Type Approval	★
SLL	Lloyd's Register Type Approval	★
SBV	Bureau Veritas Type Approval	★
SRS	Russian Maritime Register of Shipping	★

Extended product warranty

Rosemount extended warranties have a limited warranty of three or five years from date of shipment.

Code	Description	
WR3	3-year limited warranty	★
WR5	5-year limited warranty	★

Specials

Code	Description
PXXXX	Custom engineered solutions beyond standard model codes. Consult factory for details.

A.4.3 Availability of process connections

Table A-10: Cone Antenna - 316/316L SST/EN 1.4404 (Type vs. Size and Rating)

Process connection size	Process connection rating								
	Thread ⁽¹⁾	ASME B16.5 flanges ⁽²⁾		EN1092-1 flanges ⁽²⁾				JIS B2220 flanges ⁽²⁾	
		Class 150/300 ⁽³⁾	Class 600/900 ⁽³⁾	PN16 ⁽⁴⁾	PN40 ⁽⁴⁾	PN63 ⁽⁵⁾	PN100 ⁽⁵⁾	10K ⁽³⁾	20K ⁽⁵⁾
1½-in.	G, N	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2-in./DN50/50A	G, N	R	R, T	F	F, R	F, R	F	R	R
3-in./DN80/80A	G, N	R	R, T	F, R	F, R	F, R	F, R	R	R
4-in./DN100/100A	G, N	R	R, T	F, R	F, R	F	F	R	R
6-in./DN150/150A	N/A	R	N/A	F, R	F, R	F	N/A	R	R
8-in./DN200/200A	N/A	R	N/A	F, R	F, R	N/A	N/A	R	R

(1) BSPP (G) thread (process connection type code G); N = NPT thread (process connection type code N)

(2) F = Flat Face (process connection type code F); R = Raised Face (process connection type code R);

T = Ring Type Joint (process connection type code T)

(3) Forged one-piece flange or welded construction according to EN-ISO 1092-1.

(4) Welded construction for type A flat face; forged one-piece flange or welded construction for type B1 raised face.

(5) Welded construction.

Table A-11: Cone Antenna - Alloy C-276 and Alloy 400 (Type vs. Size and Rating)

Process connection size	Process connection rating								
	Thread ⁽¹⁾	ASME B16.5 flanges ⁽²⁾⁽³⁾			EN1092-1 flanges ⁽²⁾⁽⁴⁾⁽⁶⁾			JIS B2220 flanges ⁽²⁾⁽⁶⁾	
		Class 150	Class 300	Class 600	PN16	PN40	PN63	10K	20K
1½-in.	N	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2-in./DN50/50A	N	R ⁽⁵⁾	R ⁽⁵⁾	R ⁽⁵⁾	R	R	R	R	R
3-in./DN80/80A	N/A	R ⁽⁵⁾	R ⁽⁵⁾	R ⁽⁶⁾	R	R	R	R	R
4-in./DN100/100A	N/A	R ⁽⁵⁾	R ⁽⁵⁾	N/A	R	R	R	R	R
6-in./DN150/150A	N/A	R ⁽⁵⁾	R ⁽⁶⁾	N/A	R	R	R	R	R
8-in./DN200/200A	N/A	R ⁽⁶⁾	N/A	N/A	R	R	N/A	R	R

(1) N = NPT thread (process connection type code N)

(2) R = Raised Face (process connection type code R)

- (3) Welded construction for materials of construction codes H and M.
(4) Backing flange in flat face.
(5) Available with materials of construction codes 2, 3, H, and M.
(6) Only available with protective plate design (materials of construction codes 2 and 3).

Table A-12: Process Seal Antenna (Type vs. Size and Rating)

Process connection size	Process connection rating						
	Tri Clamp ⁽¹⁾	ASME B16.5 flanges ⁽²⁾⁽³⁾		EN1092-1 flanges ⁽²⁾⁽³⁾			JIS B2220 flanges ⁽²⁾⁽³⁾
		Class 150	Class 300	PN6	PN16	PN40	10K
2-in./DN50/50A	C	R	R	R	R	R	R
3-in./DN80/80A	C	R	R	R	R	R	R
4-in./DN100/100A	C	R	R	R	R	R	R

- (1) C = Tri Clamp (process connection type code C)
(2) Forged one-piece flange.
(3) R = Raised Face (process connection type code R)

Table A-13: Parabolic Antenna (Type vs. Size and Rating)

Process connection size	Process connection rating				
	Thread ⁽¹⁾	Welded ⁽²⁾	ASME B16.5 Class 150 flange ⁽³⁾	EN1092-1 PN6 flange ⁽⁴⁾	JIS B2220 5K flange ⁽³⁾
3½-in.	G	W	N/A	N/A	N/A
8-in./DN200/200A	N/A	N/A	R	F	R
10-in./DN250/250A	N/A	N/A	R	F	R

- (1) G = BSPP (G) thread (process connection type code G)
(2) W = Welded connection (process connection type code W)
(3) R = Raised Face face (process connection type code R)
(4) F = Flat Face face (process connection type code F)

A.4.4 Accessories

Table A-14: Accessories

HART modem and cable	
03300-7004-0002	MACTek® VIATOR® HART modem and cables (USB connection)


Table A-14: Accessories (continued)

Flushing connection rings for process seal antenna ⁽¹⁾	
DP0002-2111-S6	2-in. ANSI, ¼-in. NPT connection
DP0002-3111-S6	3-in. ANSI, ¼-in. NPT connection
DP0002-4111-S6	4-in. ANSI/DN100, ¼-in. NPT connection
DP0002-5111-S6	DN50, ¼-in. NPT connection
DP0002-8111-S6	DN80, ¼-in. NPT connection

(1) Not available with Canadian Registration Number (CRN).

A.5 Dimensional drawings

Figure A-11: Cone Antenna with Flanged Process Connection




- A. See [Table A-15](#) for dimensions.
- B. See [Table A-15](#) for dimensions.
- C. See [Table A-15](#) for dimensions.
- D. 2-in. (DN50) cone style
- E. s60
- F. 3-in. (DN80) and 4-in. (DN100) cone style
- G. ½-14 NPT, M20 x 1.5, or G½; optional adapters: eurofast® and minifast®
- H. Protective plate design
- I. Protective plate
- J. Purging connector (option code PC1)
- K. G¾-in.

Dimensions are in inches (millimeters).

Table A-15: Cone Antenna Dimensions

Cone size	A	B	C
1½-in. (DN40)	5.98 in. (152 mm)	1.38 in. (35 mm)	N/A
2-in. (DN50)	6.10 in. (155 mm)	1.85 in. (47 mm)	5.39 in. (137 mm)
3-in. (DN80)	6.02 in. (153 mm)	2.64 in. (67 mm)	6.77 in. (172 mm)
4-in. (DN100)	6.93 in. (176 mm)	3.62 in. (92 mm)	7.80 in. (198 mm)


Figure A-12: Cone Antenna with Threaded Process Connection



- A. See [Table A-15](#) for dimensions.
- B. See [Table A-15](#) for dimensions.
- C. s60
- D. NPT 1½-, 2-, 3-, 4-in.
- E. ½-14 NPT, M20 x 1.5, or G½; optional adapters: eurofast and minifast
- F. BSPP (G) 1½-, 2-in.
- G. 2-in. (DN50) cone style
- H. BSPP (G) 3-, 4-in.
- I. 3-in. (DN80) and 4-in. (DN100) cone style
- J. 1½-in. (DN40) cone style

Dimensions are in inches (millimeters).

Figure A-13: Extended Cone Antenna




A. Option code S1

B. Option code S2

Dimensions are in inches (millimeters).


Figure A-14: Cone Antenna with Bracket Mounting



- A. Pipe mounting (vertical pipe)
- B. Pipe diameter, max 2.52 in. (64 mm)
- C. Wall mounting (see [Figure A-19](#) for hole pattern)
- D. Pipe mounting (horizontal pipe)
- E. NPT 1½-in.

Dimensions are in inches (millimeters).


Figure A-15: Process Seal Antenna



- A. 2-in. (DN50) process seal style
- B. 1/2-14 NPT, M20 x 1.5, or G1/2; optional adapters: eurofast and minifast
- C. s60
- D. 3-in. (DN80) and 4-in. (DN100) process seal style
- E. 2-in. Tri Clamp
- F. 3-in. Tri Clamp
- G. 4-in. Tri Clamp

Dimensions are in inches (millimeters).


Figure A-16: Process Seal Antenna with Bracket Mounting



- A. Pipe mounting (vertical pipe)
- B. Pipe diameter, max 2.52 in. (64 mm)
- C. Wall mounting (see [Figure A-19](#) for hole pattern)
- D. Pipe mounting (horizontal pipe)

Dimensions are in inches (millimeters).

Figure A-17: Parabolic Antenna




- A. *Purging connector*
- B. $\frac{1}{2}$ -14 NPT, M20 x 1.5, or G $\frac{1}{2}$; optional adapters: eurofast and minifast
- C. 0.3-0.4 (8-10) (gasket excluded)
- D. G $\frac{3}{8}$ -in.
- E. s60
- F. *Threaded connection*
- G. *Purge plug kit (supplied)*
- H. *Welded connection*
- I. BSPP (G) 3 $\frac{1}{2}$ -in.
- J. *Lock nut (supplied)*⁽¹⁾

1. Maximum flange thickness (with lock nut): 0.59 in. (15 mm)

Dimensions are in inches (millimeters).


Figure A-18: Parabolic Antenna with Bracket Mounting



- A. Pipe mounting (vertical pipe)
- B. Pipe diameter, max 2.52 in. (64 mm)
- C. Wall mounting (see [Figure A-19](#) for hole pattern)

Dimensions are in inches (millimeters).


Figure A-19: Hole Pattern for Wall Mounting



Dimensions are in inches (millimeters).

A.5.1 Standard flanges

Figure A-20: Cone Antenna Flange Connection



- A. Forged one-piece
- B. Welded construction
- C. Protective plate design
- D. Weld
- E. Backing flange
- F. Protective plate

Table A-16: Standard Flanges for Cone Antenna

Standard	Face type ⁽¹⁾	Face surface finish, R_a
ASME B16.5	Raised face	125-250 μin
	Ring type joint	< 63 μin
EN 1092-1	Type B1 raised face	3.2-12.5 μm
	Type A flat face	3.2-12.5 μm
JIS B2220	Raised face	3.2-6.3 μm

(1) Face gasket surface is serrated per mating standard.

Table A-17: Cone Antennas with Protective Plate

Standard	Face type including protective plate	Plate surface finish, R_a
ASME B16.5	Raised face	3.2-6.3 μm
EN 1092-1	Raised face	3.2-6.3 μm
JIS B2220	Raised face	3.2-6.3 μm

Figure A-21: Parabolic Antenna Flange Connection





Table A-18: Standard Flanges for Parabolic Antenna

Standard	Face type ⁽¹⁾	Face surface finish
ASME B16.5	Raised face	125-250 μ in
EN 1092-1	Type A flat face	3.2-12.5 μ m
JIS B2220	Raised face	3.2-12.5 μ m

(1) Face gasket surface is serrated per mating standard.

A.5.2 Flushing connection rings

Figure A-22: Flushing Connection Rings



A. Height: 0.97 in. (24.6 mm)

Table A-19: Dimensions of Flushing Connection Rings

Flushing connection rings	D _i	D _o	D _H
2-in. ANSI	2.12 (53.8)	3.62 (91.9)	¼-in. NPT
3-in. ANSI	3.60 (91.4)	5.00 (127.0)	¼-in. NPT
4-in. ANSI/DN100	3.60 (91.4)	6.20 (157.5)	¼-in. NPT
DN50	2.40 (61.0)	4.00 (102.0)	¼-in. NPT
DN80	3.60 (91.4)	5.43 (138.0)	¼-in. NPT

B Product certifications

Rev 4.34

B.1 European directive information

A copy of the EU Declaration of Conformity can be found at the end of the Rosemount 5408 [Product Certifications](#) document. The most recent revision of the EU Declaration of Conformity can be found at [Emerson.com/Rosemount](https://emerson.com/Rosemount).

B.2 Safety Instrumented Systems (SIS)

SIL 3 Capable: IEC 61508 certified for use in safety instrumented systems up to SIL 3 (Minimum requirement of single use (1oo1) for SIL 2 and redundant use (1oo2) for SIL 3).

B.3 Ordinary location certification

As standard, the transmitter has been examined and tested to determine that the design meets the basic electrical, mechanical, and fire protection requirements by a nationally recognized test laboratory (NRTL) as accredited by the Federal Occupational Safety and Health Administration (OSHA).

B.4 Telecommunication compliance

Measurement principle

Frequency Modulated Continuous Wave (FMCW), 26 GHz

Maximum output power

-5 dBm (0.32 mW)

Frequency range

24.05 to 27.0⁽¹⁴⁾ GHz (TLPR)

24.05 to 26.5 GHz (LPR)

LPR (Level Probing Radar) equipment are devices for measurement of level in the open air or in a closed space. Model option “OA”. Hardware Version Identification Number (HVIN) is 5408L.

TLPR (Tank Level Probing Radar) equipment are devices for measurement of level in a closed space only (i.e metallic, concrete or reinforced fiberglass tanks, or similar enclosure structures made of comparable attenuating material). Hardware Version Identification Number (HVIN) is 5408T.

(14) 26.5 GHz in Australia, New Zealand, and Russia.

B.5 FCC

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID K8C5408L (for LPR)
K8C5408T (for TLPR)

B.6 IC

This device complies with Industry Canada's licence-exempt RSS standard. Operation is subject to the following conditions:

1. This device may not cause interference.
2. This device must accept any interference received, including interference that may cause undesired operation.
3. The installation of the LPR/TLPR device shall be done by trained installers in strict compliance with the manufacturer's instructions.
4. The use of this device is on a "no-interference, no-protection" basis. That is, the user shall accept operations of high-powered radar in the same frequency band which may interfere with or damage this device. However, devices found to interfere with primary licensing operations will be required to be removed at the user's expense.
5. Devices operating under TLPR conditions (i.e. not operating in "Open Air" Mode) shall be installed and operated in a completely enclosed container to prevent RF emissions, which can otherwise interfere with aeronautical navigation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage.
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

3. L'installation d'un dispositif LPR ou TLPR doit être effectuée par des installateurs qualifiés, en pleine conformité avec les instructions du fabricant.
4. Ce dispositif ne peut être exploité qu'en régime de non-brouillage et de non-protection, c'est-à-dire que l'utilisateur doit accepter que des radars de haute puissance de la même bande de fréquences puissent brouiller ce dispositif ou même l'endommager. D'autre part, les capteurs de niveau qui perturbent une exploitation autorisée par licence de fonctionnement principal doivent être enlevés aux frais de leur utilisateur.
5. Un dispositif visé comme TLPR doit être installé et exploité dans un réservoir entièrement fermé afin de prévenir les rayonnements RF qui pourraient autrement perturber la navigation aéronautique.

Certificate 2827A-5408L (for LPR)
 2827A-5408T (for TLPR)

B.7 **Radio Equipment Directive (RED) 2014/53/EU**

This device complies with ETSI EN 302 372 (TLPR), ETSI EN 302 729 (LPR) and EN 62479.

For the receiver test that covers the influence of an interferer signal to the device, the performance criterion has at least the following level of performance according to ETSI TS 103 361 [6].

- Performance criterion: measurement value variation Δd over time during a distance measurement
- Level of performance: $\Delta d \leq \pm 2 \text{ mm}$

LPR (Level Probing Radar), model code “OA”

Install at a separation distance of >4 km from Radio Astronomy sites, unless a special authorization has been provided by the responsible National regulatory authority (a list of Radio Astronomy sites may be found at www.craf.eu).

Between 4 km to 40 km around any Radio Astronomy site the LPR antenna height shall not exceed 15 m height above ground.

TLPR (Tank Level Probing Radar)

The device must be installed in closed tanks. Install according to requirements in ETSI EN 302 372 (Annex E).

B.8 **Installing equipment in North America**

The US National Electrical Code® (NEC) and the Canadian Electrical Code (CEC) permit the use of Division marked equipment in Zones and Zone marked equipment in Divisions. The markings must be suitable for the area classification, gas, and temperature class. This information is clearly defined in the respective codes.

B.9 USA

B.9.1 E5 Explosionproof (XP), Dust-Ignitionproof (DIP)

Certificate	FM-US FM16US0010X
Standards	FM Class 3600 – 2018; FM Class 3615 – 2018; FM Class 3810 – 2005; ANSI/ISA 60079-0 – 2013; ANSI/UL 60079-1 – 2015; ANSI/UL 60079-26 – 2017; ANSI/ISA 60079-31 – 2015; ANSI/NEMA® 250 – 1991; ANSI/IEC 60529 – 2014, ANSI/ISA 12.27.01:2011
Markings	XP CL I, DIV 1, GRPS A, B, C, D T6...T2 DIP CLII/III, DIV 1, GRPS E, F, G; T6...T3 CL I Zone 0/1 AEx db IIC T6...T2 Ga/Gb Zone 21 AEx tb IIIC T85 °C...T250 °C Db (-40 °C ≤ Ta ≤ +70 °C) ⁽¹⁵⁾ ; Type 4X/IP6X SINGLE SEAL

Specific Conditions of Use (X):

1. Flamepath joints are not for repair. Contact the manufacturer.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between a Zone 0 and Zone 1 area. In this configuration, the process connection is installed in Zone 0, while the transmitter housing is installed in Zone 1. Refer to Control Drawing D7000002-885.
5. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP6X and/or Type 4X rating. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
6. Install per Control drawing D7000002-885.
7. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
8. Display glass shall be positioned in such a way as to minimize the risk of mechanical impact.
9. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

⁽¹⁵⁾ Other temperature ranges may apply, see Specific Conditions of Use (X).

Table B-1: For Divisions:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Division Gas groups:		
T2	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 250 °C
T3	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 195 °C
T4	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 130 °C
T5	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 95 °C
T6	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 80 °C
Division Dust groups:		
T3	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 160 °C
T4	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 130 °C
T5	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 95 °C
T6	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 80 °C

Table B-2: For Zones:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Zone Gas groups:		
T2	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 250 °C
T3	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 195 °C
T4	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 130 °C
T5	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 95 °C
T6	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 80 °C
Zone Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

B.9.2 I5 Intrinsic Safety (IS), Non-Incendive (NI)

Certificate FM-US FM16US0010X

Standards FM Class 3600 – 2018; FM Class 3610 – 2018; FM Class 3611 – 2018; FM Class 3810 – 2005; ANSI/ISA 60079-0 – 2013; ANSI/UL 60079-11 –

Markings

2014; ANSI/UL 60079-26 – 2017; ANSI/NEMA® 250 – 1991; ANSI/IEC 60529 – 2014; ANSI/ISA 12.27.01:2011

IS CL I, II, III DIV 1, GRPS A-G T4...T2

NI CL I, DIV 2, GRPS A-D T4...T2

S CL II, III DIV 2, GRPS E-G T4...T3

CL I Zone 0 AEx ia IIC T4...T2 Ga

CL I Zone 0/1 AEx ib IIC T4...T2 Ga/Gb

Zone 20 AEx ia IIIC T85°C...T250°C Da

-60 °C ≤ Ta ≤ +70 °C

When installed per Control Drawing D7000002-885

SINGLE SEAL

Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between a Zone 0 and Zone 1 area. In this configuration, the process connection is installed in Zone 0, while the transmitter housing is installed in Zone 1. Refer to Control Drawing D7000002-885.
5. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
6. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Table B-3: For Divisions:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Division Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
Division Dust groups:		
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 160 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T5	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T6	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

Table B-4: For Zones:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Zone Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
Zone Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

B.10 Canada

B.10.1 E6 Explosionproof, Dust-Ignitionproof

Certificate	FM-C FM16CA0011X
Standards	C22.2 NO. 0.4-17:2017, C22.2 NO. 0.5-16:2016, C22.2 No. 25-17:2017, C22.2 No.30-M1986:1986 (R:2016), C22.2 No.94-M91:1991 (R:2011), C22.2 No. 61010-1:2004, CAN/CSA C22.2 No. 60079-0:2015 Ed. 3, C22.2 No. 60079-1:2016 Ed. 3, C22.2 No. 60079-26:2016; CAN/CSA-

	C22.2 No. 60079-31:2015, C22.2. 60529:2016, ANSI/ISA 12.27.01:2011
Markings	XP CL I, DIV 1, GRPS A-D T6...T2 DIP CLII/III, DIV 1, GRPS E-G; T6...T3 Ex db IIC T6...T3 Gb Ex tb IIIC T85°C...T250°C Db (-40 °C ≤ Ta ≤ +70 °C) ⁽¹⁶⁾ ; Type 4X/IP6X SINGLE SEAL

Specific Conditions of Use (X):

1. Flamepath joints are not for repair. Contact the manufacturer.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. Metric Field Wiring Entries are not allowed for Divisions.
5. The Transmitter can be installed in the boundary wall between a Zone 0 and Zone 1 area. In this configuration, the process connection is installed in Zone 0, while the transmitter housing is installed in Zone 1. Refer to Control Drawing D7000002-885.
6. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP6X and/or Type 4X rating. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
7. Install per Control Drawing D7000002-885.
8. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
9. Display glass shall be positioned in such a way as to minimize the risk of mechanical impact.
10. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

⁽¹⁶⁾ Other temperature ranges may apply, see Specific Conditions of Use (X).

Table B-5: For Divisions:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Division Gas groups:		
T2	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 250 °C
T3	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 195 °C
T4	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 130 °C
T5	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 95 °C
T6	$-40^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-40 °C to 80 °C
Division Dust groups:		
T3	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 160 °C
T4	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 130 °C
T5	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 95 °C
T6	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 80 °C

Table B-6: For Zones:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Zone Gas groups:		
T2	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 250 °C
T3	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 195 °C
T4	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 130 °C
T5	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 95 °C
T6	$-50^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-50 °C to 80 °C
Zone Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

B.10.2 I6 Intrinsically Safe and Non-Incendive Systems

Certificate FM-C FM16CA0011X

Standards C22.2 NO. 0.4-17:2017, C22.2 NO. 0.5-16:2016, C22.2 No. 25-17:2017, C22.2 No.94-M91:1991 (R:2011), C22.2 No. 213-16:2016, C22.2 No.

61010-1:2004, CAN/CSA C22.2 No. 60079-0:2015 Ed. 3, CAN/CSAC22.2 No. 60079-11:2014 Ed. 2, CAN/CSAC22.2 No. 60079-15:2016 Ed.2, C22.2 No. 60079-26:2016, C22.2. 60529:2016, ANSI/ISA 12.27.01:2011

Markings

IS CL I, II, III DIV 1, GRPS A-G T4...T2

NI CL I, DIV 2, GRPS A-D T4...T2

S CL II, III DIV 2, GRPS E-G T4...T3

Ex ia IIC T4...T2 Ga

Ex ib IIC T4...T2 Ga/Gb

Ex ia IIIC T85°C...T250°C Da

-60 °C ≤ Ta ≤ +70 °C

When installed per Control Drawing D7000002-885

SINGLE SEAL

Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between a Zone 0 and Zone 1 area. In this configuration, the process connection is installed in Zone 0, while the transmitter housing is installed in Zone 1. Refer to Control Drawing D7000002-885.
5. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
6. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Table B-7: For Divisions:


Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Division Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
Division Dust groups:		
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 160 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T5	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T6	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

Table B-8: For Zones:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Zone Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
Zone Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 250 °C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 195 °C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 130 °C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 95 °C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60 °C to 80 °C

B.11 Europe

B.11.1 E1 ATEX Flameproof

Certificate	FM15ATEX0055X
Standards	EN IEC 60079-0:2018, EN 60079-1:2014, EN 60079-26:2015, EN 60079-31:2014, EN 60529+A1+A2:2013
Markings	 II 1/2G Ex db IIC T6...T2 Ga/Gb II 2D Ex tb IIC T85°C... T250°C Db, IP6X

$$-60\text{ °C} \leq T_a \leq +70\text{ °C}$$

Specific Conditions of Use (X):

1. Flamepath joints are not for repair. Contact the manufacturer.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between EPL Ga and EPL Gb location. In this configuration, the process connection is EPL Ga, while the transmitter housing is EPL Gb. Refer to Control Drawing D7000002-885.
5. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP6X. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
6. Install per Control Drawing D7000002-885.
7. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
8. Display glass shall be positioned in such a way as to minimize the risk of mechanical impact.
9. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:


Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Gas & Dust groups:		
T2 / T250°C	$-60\text{ °C} \leq T_a \leq 70\text{ °C}$	-60 °C to 250 °C
T3 / T200°C	$-60\text{ °C} \leq T_a \leq 70\text{ °C}$	-60 °C to 195 °C
T4 / T135°C	$-60\text{ °C} \leq T_a \leq 70\text{ °C}$	-60 °C to 130 °C
T5 / T100°C	$-60\text{ °C} \leq T_a \leq 70\text{ °C}$	-60 °C to 95 °C
T6 / T85°C	$-60\text{ °C} \leq T_a \leq 70\text{ °C}$	-60 °C to 80 °C

B.11.2 I1 ATEX Intrinsic Safety

Certificate FM15ATEX0055X

Standards EN IEC 60079-0:2018, EN 60079-11:2012, EN 60079-26:2015, EN 60529:1991+A1:2000 +A2:2013

Markings

 II 1G Ex ia IIC T4...T2 Ga
 II 1/2G Ex ib IIC T4...T2 Ga/Gb
 II 1D Ex ia IIIC T85°C...T250°C Da
 $-60\text{ }^{\circ}\text{C} \leq T_a \leq +70\text{ }^{\circ}\text{C}$


Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between EPL Ga and EPL Gb location. In this configuration, the process connection is EPL Ga, while the transmitter housing is EPL Gb. Refer to Control Drawing D7000002-885.
5. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
6. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 250°C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 195°C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 130°C
Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 250°C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 195°C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 130°C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 95°C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 80°C

B.11.3 N1 ATEX Type N: Non-Sparking

Certificate	FM15ATEX0056X
Standards	EN IEC 60079-0:2018, EN 60079-15:2010, EN 60529:1991+A1:2000 +A2:2013
Markings	 II 3G Ex nA IIC T4...T2 Gc, IP65 $(-34^{\circ}\text{C} \leq T_a \leq +70^{\circ}\text{C})$ $V \leq 42.4\text{V}, I \leq 23\text{mA}$

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP65. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
4. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Temperature class	Ambient temperature range	Process temperature range
T2	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 250°C
T3	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 195°C
T4	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 130°C

B.12 International

B.12.1 E7 IECEx Flameproof

Certificate	IECEx FMG15.0033X
Standards	IEC 60079-0:2017, IEC 60079-1:2014; IEC 60079-26:2014, IEC 60079-31:2013
Markings	Ex db IIC T6...T2 Ga/Gb Ex tb IIIC T85°C...T250°C Db IP6X $-60^{\circ}\text{C} \leq T_a \leq +70^{\circ}\text{C}$

Specific Conditions of Use (X):

1. Flamepath joints are not for repair. Contact the manufacturer.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5°C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between EPL Ga and EPL Gb. In this configuration, the process connection is EPL Ga, while the transmitter housing is EPL Gb. Refer to Control Drawing D7000002-885.
5. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP6X. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
6. Install per Control Drawing D7000002-885.
7. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
8. Display glass shall be positioned in such a way as to minimize the risk of mechanical impact.
9. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Gas & Dust groups:		
T2 / T250°C	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 250 °C
T3 / T200°C	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 195 °C
T4 / T135°C	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 130 °C
T5 / T100°C	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 95 °C
T6 / T85°C	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 80 °C

B.12.2 I7 IECEx Intrinsic Safety

Certificate	IECEX FMG15.0033X
Standards	IEC 60079-0:2017, IEC 60079-11:2011, IEC 60079-26:2014, IEC 60529:2013
Markings	Ex ia IIC T4...T2 Ga Ex ib IIC T4...T2 Ga/Gb Ex ia IIIC T85°C...T250°C Da -60 °C ≤ Ta ≤ +70 °C

Safety parameter	HART®
Voltage U _i	30 V
Current I _i	133 mA
Power P _i	1.0 W
Capacitance C _i	7.3 nF
Inductance L _i	0

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. The Transmitter can be installed in the boundary wall between EPL Ga and EPL Gb. In this configuration, the process connection is EPL Ga, while the transmitter housing is EPL Gb. Refer to Control Drawing D7000002-885.

5. Using the box provided on the nameplate, the User shall permanently mark the type of protection chosen for the specific installation. Once the type of protection has been marked it shall not be changed.
6. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
Gas groups:		
T2	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 250°C
T3	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 195°C
T4	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 130°C
Dust groups:		
T250°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 250°C
T200°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 195°C
T135°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 130°C
T100°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 95°C
T85°C	$-60^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-60°C to 80°C

B.12.3 N7 IECEx Type N: Non-Sparking

Certificate	IECEx FMG15.0033X
Standards	IEC 60079-0:2017, IEC 60079-15:2010, IEC 60529:2013
Markings	Ex nA IIC T4...T2 Gc ($-34^{\circ}\text{C} \leq T_a \leq +70^{\circ}\text{C}$), IP65 $V \leq 42.4\text{V}$, $I \leq 23\text{mA}$

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test between the circuits and the earth ground. This must be taken into account during installation.
2. Plastic wire-on tag, Plastic part of Process Seal Antenna and Non-standard paint options (paint options other than Rosemount Blue) may cause risk from Electrostatic discharge. Avoid installation that could cause electrostatic build-up, and only clean with a damp cloth.
3. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP65. To maintain the ingress protection ratings, Covers and Sensor Module to be fully tightened and PTFE tape or pipe dope is required for cable entries and blanking plugs. See Instruction Manual on application requirements.
4. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows:

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
T2	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 250°C
T3	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 195°C
T4	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 130°C

B.13 Brazil

B.13.1 E2 INMETRO Flameproof

Certificate	UL-BR 17.0344X
Standards	ABNT NBR IEC 60079-0:2013, ABNT NBR IEC 60079-1:2016, ABNT NBR IEC 60079-26:2016, ABNT NBR IEC 60079-31:2014
Markings	Ex db IIC T6...T2 Ga/Gb Ex tb III C T85°C...T250°C Db Tamb = -60°C to $+70^{\circ}\text{C}$; IP6X

Specific Conditions of Use (X):

1. See certificate.

B.13.2 I2 INMETRO Intrinsic Safety

Certificate	UL-BR 17.0344X
Standards	ABNT NBR IEC 60079-0:2013, ABNT NBR IEC 60079-11:2013, ABNT NBR IEC 60079-26:2016, ABNT NBR IEC 60079-31:2014
Markings	Ex ia IIC T4...T2 Ga Ex ib IIC T4...T2 Ga/Gb Ex ia IIIC T85°C...T250°C Da Tamb = -60°C to $+70^{\circ}\text{C}$

Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. See certificate.

B.13.3 N2 INMETRO Type N: Non-Sparking

Certificate	UL-BR 17.0344X
Standards	ABNT NBR IEC 60079-0:2013, ABNT NBR IEC 60079-15:2012
Markings	Ex nA IIC T4...T2 Gc Tamb = -34 °C to +70 °C; IP65 V ≤ 42.4 V, I ≤ 23 mA

Specific Conditions of Use (X):

1. See certificate.

B.14 China

B.14.1 E3 Flameproof

Certificate	NEPSI GYJ17.1226X
Standards	GB3836.1/2/20-2010, GB12476.1/5-2013
Markings	Ex d IIC T6..T2 Ga/Gb Ex tD A21 IP6X T85°C..250°C Tamb = -60 °C to +70 °C; IP6X

Specific Conditions of Use (X):

1. See certificate.

B.14.2 I3 Intrinsic Safety

Certificate	NEPSI GYJ17.1226X
Standards	GB3836.1/4/20-2010, GB12476.4-2010
Markings	Ex ia IIC T4..T2 Ga Ex ib IIC T4..T2 Ga/Gb Ex iaD 20 T85..250 Da Tamb = -60 °C to +70 °C

Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. See certificate.

B.14.3 N3 Type N: Non-Sparking

Certificate	NEPSI GYJ17.1226X
Standards	GB3836.1-2010, GB3836.8-2014
Markings	Ex nA IIC T4~T2 Gc Tamb = -34 °C to +70 °C; IP65 V ≤ 42.4 V, I ≤ 23 mA

Specific Conditions of Use (X):

1. See certificate.

B.15 Technical Regulations Customs Union (EAC)



TR CU 020/2011 "Electromagnetic Compatibility of Technical Products"

TR CU 032/2013 "On safety of equipment and vessels under pressure"

Certificate	EAЭC RU C-US.AД07.B.00770-19
--------------------	------------------------------



TR CU 012/2011 "On safety of equipment intended for use in explosive atmospheres"

B.15.1 EM Technical Regulations Customs Union (EAC) Flameproof

Certificate	EAЭC RU C-SE.AД07.B.01297/20
Standards	GOST 31610.0-2014 (IEC 60079-0:2011), GOST IEC 60079-1-2011, GOST 31610.26-2012 (IEC 60079-26:2006), GOST R IEC 60079-31-2010
Markings	Ga/Gb Ex d IIC T6....T2 X Ex tb IIIC T85°C...T250°C Db X Tamb = -60 °C to +70 °C

Specific Conditions of Use (X):

1. Flamepath joints are not for repair. Contact the manufacturer.
2. The Model 5408 Level Transmitter can accumulate electrostatic charge on the surface of the casing. It is necessary to clean the painted surfaces with a damp cloth.

3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP65.
5. It is necessary for display to avoid physical impact.
6. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows;

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
IIC/ IIIC		
T2/T250	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 250 °C
T3/T200	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 195 °C
T4/T135	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 130 °C
T5/T100	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 100 °C
T6/T85	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 85 °C

B.15.2 IM Technical Regulations Customs Union (EAC) Intrinsic Safety

Certificate	EAЭC RU C-SE.AД07.B.01297/20
Standards	GOST 31610.0-2014 (IEC 60079-0:2011), GOST 31610.11-2014 (IEC 60079-11:2011), GOST 31610.26-2012 (IEC 60079-26:2006)
Markings	0Ex ia IIC T4...T2 Ga X Ga/Gb Ex ib IIC T4...T2 X Ex ia IIIC T85°C ...T250°C Da X Tamb = -60 °C to +70 °C

Safety parameter	HART®
Voltage U _i	30 V
Current I _i	133 mA
Power P _i	1.0 W
Capacitance C _i	7.3 nF
Inductance L _i	0

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test. This must be taken into account during installation.

2. The Model 5408 Level Transmitter can accumulate electrostatic charge on the surface of the casing. It is necessary to clean the painted surfaces with a damp cloth.
3. Appropriate cable, glands, and plugs need to be suitable for a temperature of 5 °C greater than the maximum specified ambient temperature for location where installed.
4. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP6X.
5. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows;

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
IIC/ IIIC		
T2/T250	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 250 °C
T3/T200	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 195 °C
T4/T135	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 130 °C
T100	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 100 °C
T85	-60 °C ≤ Ta ≤ 70 °C	-60 °C to 85 °C

B.15.3 NM Technical Regulations Customs Union (EAC) Non-Sparking

Certificate	EAЭC RU C-SE.AД07.B.01297/20
Standards	GOST 31610.0-2014 (IEC 60079-0:2011), GOST 31610.15-2014/IEC 60079-15:2010
Markings	2Ex nA IIC T4...T2 Gc X Tamb = -34 °C to +70 °C V ≤ 42.4V, I ≤ 23 mA

Specific Conditions of Use (X):

1. The Model 5408 Level Transmitter will not pass the 500Vrms dielectric strength test. This must be taken into account during installation.
2. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP65.
3. The applicable temperature class, ambient temperature range and process temperature range of the equipment is as follows;

Temperature class / Maximum surface temperature	Ambient temperature range	Process temperature range
T2	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 250°C
T3	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 195°C
T4	$-34^{\circ}\text{C} \leq T_a \leq 70^{\circ}\text{C}$	-34°C to 130°C

B.16 Japan

B.16.1 E4 Flameproof

Certificate CML 17JPN1206X
Markings Ex d IIC T6...T2 Ga/Gb
 $T_{amb} = -40^{\circ}\text{C}$ to $+70^{\circ}\text{C}$

Specific Conditions of Use (X):

1. See certificate.

B.17 India

B.17.1 Intrinsic Safety

Certificate PESO P403812
Markings Ex ia IIC T4...T2 Ga

B.17.2 Flameproof Safety

Certificate PESO P403810
Markings Ex db IIC T6...T2 Ga/Gb

B.17.3 Intrinsic Safety and Flameproof

Certificate PESO P402545, PESO P452909/2, PESO P452909/3
Markings Ex ia IIC T4...T2 Ga
Ex ib IIC T4...T2 Ga/Gb
Ex db IIC T6...T2 Ga/Gb

B.17.4 Intrinsic Safety

Certificate PESO P428401

Markings Ex ia IIC T4...T2 Ga
Ex ib IIC T4...T2 Ga/Gb

B.17.5 Non-Sparking

Certificate PESO P452909/1
Markings Ex nA IIC T4...T2 Gc

B.18 Republic of Korea

B.18.1 EP Flameproof

Certificate KTL 17- KAB4O-0652X, 18-KA4BO-0346X, 19-KA4BO-0169X, 19-KA4BO-0170X, 19-KA4BO-0726, 19-KA4BO-0727, 19-KA4BO-0728, 19-KA4BO-0732, 19-KA4BO-0733, 19-KA4BO-0734
Markings Ex d IIC T6...T2 Ga/Gb
Ex tb IIIC T85°C...T250°C
Tamb = -60 °C to +70 °C

B.18.2 IP Intrinsic Safety

Certificate KTL 17-KA4BO-0448X, 17-KA4BO-0654X, 18-KA4BO-0347X, 18-KA4BO-0345X, 19-KA4BO-0729, 19-KA4BO-0730, 19-KA4BO-0731, 19-KA4BO-0752, 19-KA4BO-0736, 19-KA4BO-0737
Markings Ex ia IIC T4...T2 Ga
Ex ib IIC T4...T2 Ga/Gb
Tamb = -60 °C to +70 °C

Safety parameter	HART®
Voltage U_i	30 V
Current I_i	133 mA
Power P_i	1.0 W
Capacitance C_i	7.3 nF
Inductance L_i	0

Specific Conditions of Use (X):

1. See certificate.

B.19 United Arab Emirates

B.19.1 Flame-proof

Certificate 20-11-28736/Q20-11-001012

Markings Same as IECEx (E7)

B.19.2 Intrinsic Safety

Certificate 20-11-28736/Q20-11-001012

Markings Same as IECEx (I7)

B.19.3 Type-N Non Sparking

Certificate 20-11-28736/Q20-11-001012

Markings Same as IECEx (N7)

B.20 Additional certifications

B.20.1 SBS American Bureau of Shipping (ABS) Type Approval

Certificate 20-1981069-PDA

Intended Use For use on ABS Classed Vessels and Offshore installations in accordance with ABS rules and International Standards.

Note

Housing material A, Aluminum, is not to be used on open decks.

B.20.2 SBV Bureau Veritas (BV) Type Approval

Certificate 52129/A1 BV

Requirements Bureau Veritas Rules for the Classification of Steel Ships/Offshore Units. EC Code: 31/41SB for 5408 SST housing 31/41B for 5408 Aluminum housing

Application Class Notations: AUT-UMS, AUT-CCS, AUT-PORT and AUT-IMS.

B.20.3 SDN Det Norske Veritas Germanischer Lloyd (DNV GL) Type Approval

Certificate TAA0000230

Intended Use DNV GL rules for classification – Ships, offshore units, and high speed and light craft.

Table B-9: Application

Location classes	
Temperature	D
Humidity	B
Vibration	A
EMC	B
Enclosure	C ⁽¹⁾

(1) Enclosure Class B for aluminum housing

B.20.4 SLL Lloyd's Register (LR) Type Approval

Certificate LR2002529TA

Application Marine applications for use in environmental categories ENV1, ENV 2, ENV 3 and ENV 5⁽¹⁷⁾ as defined in Lloyd's Register's Type Approval System, Test Specification Number 1, May 2018

B.20.5 SRS Russian Maritime Register of Shipping (RS) Type Approval

Certificate 21.10003.262

Rules Part XV of the Rules for the Classification and Construction of Sea-going Ships, 2020
Part XIV of the Rules for the Classification, Construction and Equipment of Mobile Offshore Drilling Units (MODU) and Fixed Offshore Platforms of (FOP), 2018
Part IV, section 12 of the Rules for Technical Supervision During Construction of ships and Manufacture of Materials and Products for Ships, 2020

Note

Housing material A, Aluminum, is not to be used on open decks.

B.20.6 QT Safety-certified to IEC 61508:2010 with certificate of FMEDA data

Certificate exida ROS 15-01-149 C001

(17) Only housing material "S" (stainless steel) is to be used on open decks.

B.20.7 Suitable for intended use

Compliant with NAMUR NE 95:2013, “Basic Principles of Homologation”.

B.20.8 U1 Overfill prevention

Certificate Z-65.16-575

Application TÜV tested and approved by DIBt for overfill prevention according to the German WHG regulations.

B.21 Hygienic certificates and approvals

B.21.1 QA 3-A®

Certificate Authorization Number 3626

The following options are conforming to the 3-A Sanitary Standards, Number 74-07 (Sensors and Sensor Fittings and Connections):

Process connection type C (Tri Clamp)

Process connection size 2, 3, 4

Antenna type SAA (Process Seal antenna)

Antenna size 2, 3, 4

B.21.2 Other hygienic approvals

The process wetted components of the Process Seal Antenna (antenna type SAA) comply with:

- FDA 21 CFR 110, subpart C and FDA 21 CFR 177.1550
- EC 1935/2004 and EC 10/2011
- TSE/BSE Free
- USP<87>
- USP<88> Class VI

B.21.3 Instructions for hygienic installations

It is the responsibility of the user to ensure that:

1. The materials listed in [Table B-10](#) and [Table B-11](#) are suitable for the media and cleaning/sanitizing processes.
2. The installation of the transmitter is drainable and cleanable.

3. The joint/clamping between the transmitter and the nozzle is compatible with the tank pressure and media.
4. For the application suitable cable entry devices are used and with appropriate ingress protection.
5. Any unused cable entries are sealed with suitable plugs to maintain the ingress protection ratings.
6. The product contact surfaces are not scratched.
7. The 3-A specific nozzle height limits are kept to ensure cleanability.

Related information

[Nozzle requirements](#)

B.21.4 Materials of construction

The hygienic approvals and certificates of the transmitter rely upon the following materials used in its construction:

Table B-10: Product Contact Surfaces

Item	Material
Microwave launcher	PTFE fluoropolymer

Table B-11: Nonproduct Contact Surfaces

Item	Material
Metal housing	Stainless steel 300 series or aluminium 360, painted with epoxy-polyester or polyurethane
Fasteners and plugs	Stainless steel 300 series
Seals	Nitrile rubber NBR, Ethylene propylene peroxide and FKM fluoroelastomer
Labels	Stainless steel 300 series, metallized polyester, polyester/polycarbonate

B.21.5 Clean-In-Place (CIP)

Withstands cleaning routines up to 194 °F (90 °C)

B.21.6 Steam-In-Place (SIP)

Withstands cleaning routines up to 284 °F (140 °C)

B.22 Pattern approval

Belarus Pattern Approval

Certificate No. 12954

Kazakhstan Pattern Approval

Certificate KazInMetr No. 15466

Russia Pattern Approval

Certificate VNIIMS No. SE.C.29.004.A No 70968

Uzbekistan Pattern Approval

Certificate No. 02.7102

B.23 Installation drawings

The installation guidelines presented by the System Control Drawing must be followed in order to maintain certified ratings for installed transmitters.

Figure B-1: D7000002-885 - System Control Drawing

ISSUE		CHANGE ORDER NO.	WEEK
5		506-0408	2945

EMERSON

DESIGNED BY

ESa-LN

DATE

1524

PRODUCT CODE

5408

APPROVED BY

EAP

DATE

1525

DOC. TYPE

6

SIZE

A3

REVISIONS

1 OF 9

SHEET

1 OF 5

SYSTEM CONTROL DRAWING
Rosemount 5408 Series
(Table of Contents)

D7000002-885

THE COPYRIGHT/OWNERSHIP OF THIS DOCUMENT IS AND WILL REMAIN WITH ROSEMOUNT TANK RIGGING AB

FM APPROVED PRODUCT
No revisions to this drawing
without prior Factory Mutual
Approval.

SYSTEM CONTROL DRAWING – ROSEMOUNT 5408 SERIES

(Table of Contents)

Page 2

-

General Information

Page 3

-

Intrinsically safe, EPL Ga installation (including description of ENTITY concept)

Page 4

-

Intrinsically safe, EPL Gb installation

Page 5

-

FISCO, EPL Ga installation (including description of FISCO concept)

Page 6

-

FISCO, EPL Gb installation

Page 7

-

Flameproof/XP installation

Page 8

-

Non-incendive installation

Page 9

-

Transmitter with test terminal option (SIS, 4-20 mA)

243

ENTITY CONCEPT APPROVALS

The Entity concept allows interconnection of intrinsically safe apparatus to associated apparatus not specifically examined in combination as a system. The approved values of max. open circuit voltage (U_o, Voc or Vi) and max. short circuit current (I_o, Isc or It) and max. power (Po or Voc x Isc / 4 or Vi x It / 4), for the associated apparatus must be less than or equal to the maximum safe input voltage (Ui), maximum safe input current (Ii), and maximum safe input power (Pi) of the intrinsically safe apparatus. In addition, the approved max. allowable connected capacitance (Ca or Co) of the associated apparatus must be greater than the sum of the interconnecting cable capacitance and the unprotected internal capacitance (Ci) of the intrinsically safe apparatus, and the approved max. Allowable connected inductance (La or Lo) of the associated apparatus must be greater than the sum of the interconnecting cable inductance and the unprotected internal inductance (Li) of the intrinsically safe apparatus.

Notes

- No revision to drawing without prior FM Approval.
- The Associated Apparatus must be FM Approved for installations in the U.S.
- The Associated Apparatus must be Canadian Approved for Installations in Canada.
- The Associated Apparatus must be ATEX Certified for Installations in Europe.
- The Associated Apparatus must be IECEx Certified for IECEx Installations.
- Associated apparatus manufacturer's installation drawing must be followed when installing this equipment.
- Installations in the U.S. should be in accordance with ANSI/ISA RP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous (Classified) Locations" and the latest edition of the National Electrical Code (ANSI/NFPA 70).
- Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm.
- Installation in Canada should be in accordance with the latest edition of the C22.1 Canadian Electrical Code, Part I.
- Installations in Europe shall comply with the relevant requirements of EN 60079-14 and applicable National regulations.
- Installations for IECEx certification shall be in accordance with latest editions of the Mining Practices for the country of origin.
- The Entity Concept allows interconnection of associated apparatus and intrinsically safe apparatus when the following conditions are met:
 $U_o \leq U_i$ (Vmax), $I_o \leq I_i$ (Imax), $P_o \leq P_i$ (Imax), $C_o \leq C_i$ (nF), $L_o \leq L_i$ (mH)
4408 (00825-0300-4408/00825-0500-4408) and the Product Certification Document (doc no 00825-0200-4408) for additional installation details.

WARNING – Substitution of components may impair Intrinsic Safety.
WARNING – Potential electrostatic charging hazard. wipe with a damp cloth.
WARNING – To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

AVERTISSEMENT – La substitution de composants peut compromettre la sécurité intrinsèque.
AVERTISSEMENT – Risque potentiel de charge électrostatique, essuyer avec un chiffon humide.
AVERTISSEMENT – Ne pas ouvrir en cas de présence d'atmosphère explosive.

UNCLASSIFIED LOCATION

ASSOCIATED APPARATUS

Intrinsically safe, EPL Ga Installation

	Safe Apparatus for use in:	Ambient Temperature Limits
FMus	IS Class I, II, III, DIV 1, GP A-G T4...T2 CL I, Zone 0 AEX Ia IIC T4...T2 Ga Zone 20 AEX Ia IIIC T85C...T250°C Da	-60°C to +70°C (4-20mA/HART) -55°C to +70°C (Fieldbus)
FMc	IS Class I, II, III, DIV 1, GP A-G T4...T2 Ex Ia IIC T4...T2 Ga Ex Ia IIIC T85°C...T250°C Da	-60°C to +70°C (4-20mA/HART) -55°C to +70°C (Fieldbus)
ATEX	II 1G Ex Ia IIC T4, T2 Ga II 1D Ex Ia IIIC T85°C...T250°C Da	-60°C to +70°C (4-20mA/HART) -55°C to +70°C (Fieldbus)
IECEx	Ex Ia IIC T4...T2 Ga Ex Ia IIIC T85°C...T250°C Da	-60°C to +70°C (4-20mA/HART) -55°C to +70°C (Fieldbus)

Model	Intrinsic Entity Parameters	Note
4-20mA / HART IS	Ui (Vmax) ≤ 30V, li (Imax) ≤ 133 mA Pi (pmax) ≤ 1W, Ci = 7.3 nF, Li = 0 uH	
Fieldbus IS	Ui (Vmax) ≤ 30V, li (Imax) ≤ 300 mA Pi (pmax) ≤ 1.5W, Ci = 1.1 nF, Li = 0 uH	Non-linear barrier assumed

EMERSON

SYSTEM CONTROL DRAWING
FOR INTRINSICALLY SAFE EPL GA INSTALLATION

PROJECT NO. 1524
EPL Ga

DATE 1525
EAP

ISSUE 6

REVISION 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

BY 0

CHK 0

APP 0

DATE 0

UNCLASSIFIED LOCATION

POWER SUPPLY

(b) BARRIER

HAZARDOUS LOCATION / EXPLOSIVE ATMOSPHERE
(ZONE 1/21)

Ground Terminal, Internal

Ground Terminal, External

See note 14

HAZARDOUS AREA
(ZONE 0/21)

EPL Gb

EPL Gb

ISSUE

CHANGE ORDER NO.

WEEK

6

500-1000

2045

Notes

1. No revision to drawing without prior FM Approval.

2. The Associated Apparatus must be FM Approved for installations in the U.S.

3. The Associated Apparatus must be Canadian Approved for installations in Canada.

4. The Associated Apparatus must be ATEX Certified for installations in Europe.

5. The Associated Apparatus must be IECEx Certified for IECEx installations.

6. Associated apparatus manufacturer's installation drawing must be followed when installing this equipment.

7. "Installations in the U.S. should be in accordance with ANSI/ISA RP12.06.01 the latest edition of the National Electrical Code (ANSI/NFPA 70).

8. Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm.

9. Installation in Canada should be in accordance with the latest edition of the C22.1 Canadian Electrical Code, Part I.

10. Installations in Europe shall comply with the relevant requirements of EN 60079-14 and applicable National regulations.

11. Installations for IECEx certification shall be in accordance with latest editions of the wiring practices for the country of origin.

12. The Entity Concept allows interconnection of associated apparatus and intrinsically safe apparatus with when the following is true:
 $U_o \leq U(V_{max})$, $I_o \leq I(I_{max})$, $P_o \leq P(P_{max})$, $C_o \leq C_o + C_{cable}$, $L_o \leq L_o + L_{cable}$.

13. Listed intrinsic safety parameters apply only to associated apparatus with linear output.

14. Different terminal blocks are applicable. See Quick Start Guide (doc no 00825-0100-4408/ 00825-0300-4408/00825-0500-4408) and the Product Certification Document (doc no 00825-0200-4408) for additional installation details.

Intrinsically safe, EPL Gb installation

	Safe Apparatus for use in:	Ambient Temperature Limits
FMus	CL I, Zone 0/1 AEx Ib IIC T4...T2 Ga/Gb	-60°C/5Tas+70°C (4-20mA/HART) -55°C/5Tas+70°C (Fieldbus)
FMc	Ex Ib IIC T4...T2 Ga/Gb	-60°C/5Tas+70°C (4-20mA/HART) -55°C/5Tas+70°C (Fieldbus)
ATEX	II 1/2S Ex Ib IIC T4...T2 Ga/Gb	-60°C/5Tas+70°C (4-20mA/HART) -55°C/5Tas+70°C (Fieldbus)
IECEX	Ex Ib IIC T4...T2 Ga/Gb	-60°C/5Tas+70°C (4-20mA/HART) -55°C/5Tas+70°C (Fieldbus)

Model	Intrinsic Entity Parameters	Note
4-20mA / HART IS	Ui (Vmax) ≤ 30V, Ii (Imax) ≤ 133 mA Pi (Pmax) ≤ 1W, Ci = 7.3 nF, Li = 0 uH	
Fieldbus IS	Ui (Vmax) ≤ 30V, Ii (Imax) ≤ 300 mA Pi (Pmax) ≤ 1.5W, Ci = 1.1 nF, Li = 0 uH	Non-linear barrier assumed

FM APPROVED PRODUCT

No revisions to this drawing

without prior Factory Mutual

Approval.

WARNING – Substitution of components may impair Intrinsic Safety.

WARNING – Potential electrostatic charging hazard, wipe with a damp cloth.

WARNING – To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

AVERTISSEMENT – La substitution de composants peut compromettre la sécurité intrinsèque.

AVERTISSEMENT – Risque potentiel de charge électrostatique, essuyer avec un chiffon humide.

AVERTISSEMENT – Ne pas ouvrir en cas de présence d'atmosphère explosive.

EMERSON

UNIVERSITY OF SASKATCHEWAN

SYSTEM CONTROL DRAWING

ROSEMOUNT 5408 SERIES

(INTRINSICALLY SAFE, EPL Gb INSTALLATION)

DATE: 1524

ISSUE: 6

REVISED BY: Eap

APPROVED BY: D7000002-885


SHEET 4 OF 9

THE CONTENTS OF THIS DOCUMENT IS NOT VALID WITH ROSEMOUNT TANK PUMP 48

Rosemount 5408 and 5408:SIS Level Transmitters

245





UNCLASSIFIED LOCATION

POWER SUPPLY

HAZARDOUS LOCATION / EXPLOSIVE ATMOSPHERE
(ZONE 2 DIVISION 2)

Ground Terminal,
Internal

Ground Terminal,
External

See note 6

ISSUE
6

CHANGE ORDER NO.
SISE-10408

WEEK
2045

FMus

Safe Apparatus for use in:

Ambient Temperature Limits

NI CL I, DIV 2, GP A-D T4...T2
S CL II, III DIV 2, GP E-G T4...T3

-60°CStas+70°C

FMc

NI CL I, DIV 2, GP A-D T4...T2
S CL II, III DIV 2, GP E-G T4...T3

-60°CStas+70°C

ATEX

II 3G Ex Na IIC T4...T2 Gc

-34°CStas+70°C

IECEX

Ex Na IIC T4...T2 Gc

-34°CStas+70°C

Model

Maximum operating parameters

4-20mA / HART

U ≤ 42.4V, I ≤ 23 mA

Fieldbus

U ≤ 32V, I ≤ 60 mA

Notes

1. No revision to drawing without prior FM Approval.

2. Installations in the U.S. should be in accordance with the latest edition of the National Electrical Code (ANSI/NFPA 70).

3. Installation in Canada should be in accordance with the latest edition of the C22.1 Canadian Electrical Code, Part I.

4. Installations in Europe shall comply with the relevant requirements of EN 60079-14 and applicable National regulations.

5. Installations for IECEX certification shall be in accordance with latest editions of the wiring practices for the country of origin.

6. Different terminal blocks are applicable. See Quick Start Guide (doc no 00825-0100-4408/ 00825-0300-4408/00825-0500-4408) and the Product Certification Document (doc no 00825-0200-4408) for additional installation details.

FM APPROVED PRODUCT

No revisions to this drawing without prior Factory Mutual Approval.

WARNING – Do not separate when energized.

WARNING – Substitution of components may impair Intrinsic Safety.

WARNING – Potential electrostatic charging hazard, wipe with a damp cloth.

WARNING – To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

AVERTISSEMENT – Ne pas séparer lorsqu'il est activé.

AVERTISSEMENT – La substitution de composants peut compromettre la sécurité intrinsèque.

AVERTISSEMENT – Risque potentiel de charge électrostatique, essuyer avec un chiffon humide.

EMERSON

UNIVERSITY AVENUE, 1, 5405 39th AVENUE, SW, EDINBURGH, SCOTLAND, UK

REVISIONS

DATE

DESCRIPTION

1524

5408

ESa-LN

System Control Drawing

1525

6

EAp

Rosemount 5408 Series

A3

D7000002-885

Non-Incendive Installation

5

8

9

OF

THE COPYRIGHTED CONTENT OF THIS DOCUMENT IS AND WILL REMAIN THE PROPERTY OF EMERSON

ISSUE
6

CHANGE ORDER NO.
516-10408

WEEK
2045

SYSTEM CONTROL DRAWING – ROSEMOUNT 5408 SERIES
TRANSMITTERS WITH TEST TERMINAL OPTION

UNCLASSIFIED LOCATION

POWER
SUPPLY

ASSOCIATED APPARATUS

IS
BARRIER

HAZARDOUS LOCATION / EXPLOSIVE ATMOSPHERE
(ZONE 0/20, DIVISION 1)
(ZONE 1/21, DIVISION 1)

TEST
INSTRUMENT

In addition to instructions per Type of Protection, the following applies for the Test Terminal option:

1. In hazardous locations/explosive atmospheres, this test can only be done for intrinsically safe installations.
2. The instrument used for loop current measurement must have correct intrinsically safe type of protection.
3. The combined entity parameters of the transmitter and the test instrument must be compatible with the output parameters of the associated apparatus.
4. The cable/plug must be re-attached to the TEST terminal after completed test.

EMERSON

UNIVERSITY OF APPLIED SCIENCES
LUNDUNIVERSITÄT S-223 62 LUND, SWEDEN

REVISION
ESa-LN
1524

PRODUCT CODE
5408

DATE
2020-09-01

DOC TYPE
6

SIZE
A3

REVISION NO.
D7000002-885

SHEET
9 OF 9

D7000002-885

FM APPROVED PRODUCT
No revisions to this drawing
without prior Factory Mutual
Approval.

250

Reference Manual

C Configuration parameters

C.1 Menu tree

The menu tree structure in [Figure C-1](#) is applicable for Rosemount™ Radar Master Plus. For AMS Device Manager and the handheld communicator, see [Figure C-2](#).

Figure C-1: Menu Tree for Rosemount Radar Master Plus

Overview	Primary Variables	
	All Variables	
	Device Information	Identification
		Revisions
Configure		Alarm and Security
		Upgrade
	Guided Setup	
	Verify Level	
	Device Setup	HART
		Units
		Analog Output
		Display
		Security
		Device Information
	Level Setup	Geometry
		Environment
		Volume
		Scaled Variable
		Antenna
		Advanced
	Alert Setup	Measurement Recovery
Service Tools		Signal Quality Alert
		High User Defined Alert
		Low User Defined Alert
	Alerts	
	Echo Curve	
	Proof Test	Level Verification
		Loop Test
		Smart Echo Level Test
	Maintenance	Routine Maintenance
		Backup
		Reset/Restore
		Upgrade
	Simulate	Simulate Measurement Values
		Loop Test

Figure C-2: Menu Tree for AMS Device Manager and Handheld Communicator

Overview	Device Status	
	Communication Status	
	PV	
	PV Status	
	SV	
	SV Status	
	TV	
	TV Status	
	QV	
	QV Status	
	Device Information	Identification
		Revisions
		Alarm and Security
Configure	Guided Setup	Basic Setup
		Verify Level
	Manual Setup > Device Setup	HART
		Units
		Analog Output
		Display
		Security
		Device Information
	Manual Setup > Level Setup	Geometry
		Environment
		Volume
		Scaled Variable
		Antenna
		Advanced
	Alert Setup	Measurement Recovery
		Signal Quality Alert
		High User Defined Alert
		Low User Defined Alert
Service Tools	Alerts	
	Variables	Mapped Variables
		Process
		Device
		Signal Quality
	Maintenance	Routine Maintenance
		Reset/Restore
	Echo Tuning	Thresholds
		Echo Peaks
		Suppress
	Simulate	Simulate Measurement Values
		Analog Out > Loop test

C.2 Device setup

C.2.1 HART protocol

HART/polling address

The address range is 0 to 63. The transmitter operates in either standard mode with a 4–20 mA output signal or in multidrop. When the transmitter is in multi-drop mode, the current output is fixed to 4 mA.

Burst mode

When set to burst mode, the transmitter regularly sends out messages instead of waiting for the host to request it.

Both the transmitter and host must be configured to operate in burst mode. Almost all HART host systems today are designed to communicate in poll/response mode, not burst mode. However, the Rosemount 333 HART Tri-Loop™ requires burst mode communication.

Related information

[Use with the Rosemount 333 HART Tri-Loop](#)

Variable mapping

Up to four transmitter variables can be assigned for the HART protocol. The transmitter outputs a 4–20 mA signal proportional to the primary variable. Additional variables are available through the HART digital signal.

Related information

[Output variables](#)

Damping value

This parameter defines how fast the transmitter reacts to a change of the level value (step response). The default value is 2 seconds.

A high value makes the level reading steady, while a low value allows the transmitter to respond to rapid level changes (but the presented level value may be less steady).

Percent of range auxiliary

Set this parameter to output the percent of range for another transmitter variable (in addition to the primary variable).

Table C-1: Percent of range auxiliary

Parameter	Description
Percent of range auxiliary	The variable selected for percent of range auxiliary.
100% auxiliary	Value corresponding to 100 percent range of variable selected for percent of range auxiliary.
0% auxiliary	Value corresponding to 0 percent range of variable selected for percent of range auxiliary.

C.2.2 Units

The units for length, volume, temperature, and level rates are selectable. All configuration parameters and transmitter variables will be expressed in these units.

Related information

[Output units](#)

C.2.3 Analog output

The output source (primary variable), range values, and alarm mode are specified for the analog output.

Primary variable

Select the desired transmitter variable to use for the analog output.


Upper/lower range value

Enter the range values that correspond to the analog output values 4 and 20 mA. The transmitter will drive the output to saturation mode if a measured value goes outside the 4-20 mA range values.

Note

Measurements may not be possible in the blind zone, and measurements close to the blind zone will have reduced accuracy. Therefore, the 20 mA point should be configured outside these zones.

Figure C-3: Example of Range Value Settings



- A. Upper blind zone
- B. Upper reduced accuracy zone
- C. Level measurement range 0-100%
- D. Zero Level

Related information

[Accuracy over measuring range](#)

Alarm mode

The transmitter automatically and continuously performs self-diagnostic routines. If a failure or a measurement error is detected, the transmitter drives the output to selected alarm limit (high or low).

High/low alarm value

The high/low alarm current for the analog output when the device enters the alarm mode.

Related information

[Analog signal on alarm](#)

High/low saturation value

The device will continue to set a current that corresponds with the measurement until reaching the upper/lower limit (and then freeze).

Related information

[Analog saturation levels](#)

C.2.4 Display

Select variables to show on the optional LCD display. If more than one variable is selected, then the LCD display toggles between the output variables.

Related information

[Variable screens](#)

[Set up the LCD display](#)

C.2.5 Security

Write protection

The transmitter can be write protected (with or without a password) to prevent unauthorized changes.

Operational mode

There are two Operational Modes to choose from for the Rosemount 5408: SIS: Control/Monitoring and Safety (SIS).

If the transmitter is used as safety device in a Safety Instrumented System, the Operational Mode must be set to Safety (SIS).

Safety mode

When the operational mode is set to Safety (SIS), then the Safety Mode must be enabled for the transmitter to become operational. When Safety Mode is enabled, the transmitter is write protected (with or without a password) to prevent unauthorized changes.

Change counter

A counter that increments each time the device enters active Safety Mode.

C.2.6 Device information

Tag

Identifier of up to 8 characters for the device used by host system. The tag is typically a reference number, location, or duty description.

Long tag

Identifier of up to 32 characters for the device used by host system. It is recommended to enter both a short and a long tag (they may be the same).

Date

The date field can be used for any purpose, for example to save the date of the last configuration change.

Descriptor

The 16-character descriptor field can be used for any purpose.

Message


The 32-character message field can be used for any purpose, such as providing details of the last configuration change.

C.3 Level setup

C.3.1 Geometry


The transmitter configuration includes setting the tank geometry parameters, see [Figure C-4](#) and [Figure C-5](#).

Figure C-4: Tank Geometry, Basic Dimensions



- A. Device Reference Point
- B. Reference Height
- C. Zero Level
- D. Vertical cylinder
- E. Cubical Tank
- F. Horizontal cylinder
- G. Spherical tank

Figure C-5: Tank Geometry, All Dimensions



- | | | | |
|----|--------------------------------|----|--|
| A. | Tank Reference Point | I. | Bottom Shape Height*/
Bottom Height** |
| B. | Reference Height | J. | Height of Tank*/Height (of tank)** |
| C. | Zero Level | K. | End Shape Length*/End Length** |
| D. | Bottom Offset | L. | Length of Tank*/Length** |
| E. | Device Reference Point | M. | Vertical cylinder |
| F. | Reference Offset | N. | Cubical cylinder |
| G. | Top Shape Height*/Top Height** | O. | Horizontal cylinder |
| H. | Width of Tank*/Width** | P. | Spherical cylinder |

* AMS Device Manager and handheld communicator


** Rosemount Radar Master Plus

Mounting type

Select option best describing how transmitter is mounted on the tank. There are four options to choose from: Nozzle, Still pipe, Chamber, and Bracket.

The Bracket option should be used for measurements in open air installations such as sumps or ponds, or when measuring through a plastic tank roof.

Figure C-6: Mounting Type



- A. Nozzle
- B. Still pipe
- C. Chamber
- D. Bracket (open air)

Inner diameter, pipe/chamber

Enter the inner diameter for the pipe or chamber in which the antenna is mounted. The inner diameter value is used to compensate for the lower microwave propagation speed inside the pipe/chamber. An incorrect value will give a scale factor error.


Tank shape

Select a tank shape that corresponds to the actual tank. If the actual tank does not match one of the pre-defined tank shapes, then select Other (e.g. level measurements of sumps, basins, or ponds).

Tank top shape

Form of the upper tank closure.

Figure C-7: Tank Top Shape




- A. *Dome*
- B. *Flat*
- C. *Conical*

Tank bottom shape

Form of the lower tank closure.

Figure C-8: Tank Bottom Shape




- A. *Dome*
- B. *Flat*
- C. *Conical/pyramid*
- D. *Flat, inclined (for vertical cylinder)*
- E. *Flat, inclined (for cubical tank)*

Tank end shape

For a horizontal tank, form of the tank ends. Same shape is assumed at both ends.

Figure C-9: Tank End Shape



Reference height

Distance between the Tank Reference Point (typically same as Device Reference Point) and Zero Level.

Ensure the Reference Height is set as accurate as possible. The transmitter measures the distance to the product surface and subtracts this value from the Reference Height to determine the level.

Device reference point

Figure C-10, Figure C-11, and Figure C-12 show the Device Reference Point for various antennas and tank connections.

Figure C-10: Device Reference Point for Cone Antennas






Figure C-11: Device Reference Point for Process Seal Antennas



A. Device Reference Point

Figure C-12: Device Reference Point for Parabolic Antennas




A. Device Reference Point

Reference offset

Distance between the Device Reference Point and the Tank Reference Point (typically the upper side of a customer plug where levels can be manually measured).

The Reference Offset parameter can be used to specify your own reference point, for example when the measured level by the transmitter should correspond with the level value obtained by hand-dipping.

Figure C-13: Reference Offset




- A. Tank Reference Point
- B. Device Reference Point
- C. Reference Offset > 0
- D. Reference Offset < 0

Bottom offset

The Bottom Offset is defined as the distance between Zero Level and the tank bottom. The default value is zero.

If the Zero Level is not located at the tank bottom, then enter a Bottom Offset. It is needed for the transmitter to know the position of the tank bottom echo and for correct volume calculations.

Figure C-14: Bottom Offset



- A. Tank Reference Point
- B. Reference Offset
- C. Device Reference Point
- D. Reference Height
- E. Zero Level
- F. Bottom Offset

Height of tank

The vertical distance between tank bottom and tank roof. For a horizontal cylinder or spherical tank, this is the diameter of the tank.

Width of tank

The horizontal distance between tank ends. For a vertical cylinder, this is the diameter of the tank. The width of tank is also the shortest horizontal side of a box-shaped (cubical) tank.

Length of tank

The longest horizontal side of a cubical tank.

Top shape height

The height of the shape on tank top (typically from shape floor to cap top, measured at cylinder center line).

Bottom shape height

The height of the shape at tank bottom (typically from shape floor to shape bottom, measured at cylinder center line).

End shape length

The width of the spherical cap at tank end (measured at cylinder center line).

Show negative level as zero

When this setting is selected and the product surface is at or below Zero Level, the level measurement output will be zero.

C.3.2 Environment

Product type

The media (liquid/solid) used in the monitored process.

- Liquid (requires measurement type code 1 or 4)
- Solid (requires measurement type code 3 or 4)

The solids measurement mode should never be used for measuring liquid products due to the solids specific signal processing method, and vice versa.

Note

Solid is not supported for a Rosemount 5408:SIS operating in Safety (SIS) mode.

Process conditions

Foam

This parameter should be used if there is, or may be, surface foam. When setting this parameter, the transmitter is optimized for conditions with weak and varying surface echo amplitudes, which is typical for presence of surface foam.

Turbulent surface

Set this parameter to improve the performance of the transmitter when there are small and local rapid level changes caused by surface turbulence. The reason for the turbulence might be splash loading, agitators, mixers, or boiling product.

Maximum level rate

Fastest rate that may occur in the monitored process to (partially) fill or empty this tank. Note that product level rate may be higher during upset conditions.

Product dielectric range

Select the range of the dielectric constant for the product in the tank. If the range is not known, or if the product in the tank is changed on a regular basis, then select Default.

C.3.3 Volume

Select if the volume measurement should be calculated from the configured tank dimensions or a strapping table.

Strapping tables can be used for irregularly shaped tanks, to eliminate errors due to bulging when product is added to a tank, or if a pre-defined tank type does not provide sufficient accuracy.

Strapping table

Strapping table requires entering level-volume pairs in a table (maximum 50 points). Use most of the strapping points in regions where the tank shape is non-linear. Starting at the bottom of the tank, for each new point, enter the total volume up to the specified level value.

Volume offset


Use this parameter to add a volume to each calculated volume value, for example a sump volume below the Zero Level in the tank.

C.3.4 Scaled variable

The scaled variable can be used to convert a transmitter variable into an alternative measurement, such as open channel flow, mass, or calibrated level (e.g. 5 point verification). This variable is available only for transmitters ordered with Smart Diagnostics Suite.

The scaled variable is defined by creating a table of transmitter variables and corresponding output variables. A maximum of 50 points can be specified. Between the points linearly interpolated values are calculated.

Figure C-15: Scaled Variable Examples



As an example, consider a product with a density of 900 kg/m³. In this case, the volume to mass conversion is given by the following table:

Table C-2: Example of Scaled Variable Table

Number	Input value (volume)	Output value (mass)
1	0 m ³	0 ton
2	100 m ³	90 ton

Scaled variable name

Name of the scaled variable. It is recommended to enter a short name to fit into the LCD display area.

Scaled variable unit

Units of measurement of the scaled variable.

Number of scaled values

Number of values in the scaled variable table.

Input variable

Select the input variable to use for scaled variable calculation.

C.3.5

Antenna


Antenna type

The transmitter is designed to optimize measurement performance for each available antenna type. This parameter is pre-configured at factory; it only needs to be set if the antenna is changed to another type, or if you have installed a spare transmitter.

Antenna extension length

This parameter is pre-configured at factory. The Antenna Extension Length (see [Figure C-16](#)) must be changed if the extension is shortened, or if you have ordered a spare transmitter head. Enter zero (0) for antennas without extensions.

Figure C-16: Antenna Extension Length (L)



User defined antenna options

These antenna parameters are applicable to customized antennas only. The settings are typically provided by factory.

Legacy (Rosemount 5402) antenna parameters

When a Rosemount 5408 transmitter head is mounted on a Rosemount 5402 antenna, then select the Legacy (Rosemount 5402) antenna type and specify the antenna parameters according to the settings in [Table C-3](#) and [Table C-4](#).

Table C-3: Legacy (Rosemount 5402) Antenna Parameters, Free Propagation

Antenna type	Model code	Tank connection length		Antenna gain	Nearzone threshold (mV)	Nearzone range		Upper null zone ⁽¹⁾	
		ft	m			ft	m	ft	m
2-in. SST cone	2S	0.509	0.155	2.45	4500	5.09	1.55	0.541	0.165
2-in. cone with protective plate	2H, 2M, 2N	0.509	0.155	2.45	5000	5.25	1.60	0.492	0.150
2-in. process seal	2P	0.929	0.283	3.4	3400	4.13	1.26	0.492	0.150
3-in. SST cone	3S	0.509	0.155	1.4	1170	3.38	1.03	0.492	0.150
3-in. cone with protective plate	3H, 3M, 3N	0.509	0.155	1.4	4400	5.41	1.65	0.591	0.180
3-in. process seal	3P	1.191	0.363	1.7	3400	4.13	1.26	0.492	0.150
4-in. SST cone	4S	0.509	0.155	0.9	1170	3.38	1.03	0.738	0.225
4-in. cone with protective plate	4H, 4M, 4N	0.509	0.155	0.9	2400	4.27	1.30	0.820	0.250
4-in. process seal	4P	1.316	0.401	0.8	1000	3.48	1.06	0.492	0.150

(1) Default setting. The Upper Null Zone may need to be increased if there are disturbance echoes in the region close to the antenna.

Table C-4: Legacy (Rosemount 5402) Antenna Parameters, Still Pipe/Chamber Installation

Antenna type	Model code	Tank connection length		Antenna gain	Nearzone threshold (mV)	Nearzone range		Upper null zone ⁽¹⁾	
		ft	m			ft	m	ft	m
2-in. SST cone	2S	0.509	0.155	0.035	800	2.03	0.62	0.541	0.165
2-in. cone with protective plate	2H, 2M, 2N	0.509	0.155	0.035	900	3.28	1.00	0.492	0.150
2-in. process seal	2P	0.929	0.283	0.035	930	2.56	0.78	0.492	0.150
3-in. SST cone	3S	0.509	0.155	0.035	800	2.03	0.62	0.492	0.150
3-in. cone with protective plate	3H, 3M, 3N	0.509	0.155	0.035	1100	4.27	1.30	0.591	0.180
3-in. process seal	3P	1.191	0.363	0.035	1000	2.53	0.77	0.492	0.150
4-in. SST cone	4S	0.509	0.155	0.035	800	2.03	0.62	0.738	0.225
4-in. cone with protective plate	4H, 4M, 4N	0.509	0.155	0.035	1000	3.61	1.10	0.820	0.250
4-in. process seal	4P	1.316	0.401	0.035	900	4.59	1.40	0.492	0.150

(1) Default setting. The Upper Null Zone may need to be increased if there are disturbance echoes in the region close to the antenna.

Upper null zone

The Upper Null Zone defines how close to the device's reference point a level value is accepted. You can extend this value to block out disturbing echoes close to the antenna, for example from the tank nozzle or bypass well inlet.

Note

Make sure the 20 mA value is below the Upper Null Zone. Measurements are not performed within the Upper Null Zone (UNZ).

Related information

[Change the upper null zone](#)

C.3.6 Advanced

Calibration offset

Difference between surface distance measured by transmitter and the same distance measured by, for example, hand-dipping with a measurement tape. A positive Calibration Offset value will increase the presented level value.

It is recommended to run the Verify Level tool to match the product level reported by the transmitter to a reference measurement.

Related information

[Verify level](#)

User defined variable setup

This section applies only to transmitters ordered with Smart Diagnostics Suite.

Name

Name of the user defined variable. It is recommended to enter a short name to fit into the LCD display area.

Input register

Enter the number of the input register that contains value of the user defined variable. See [Table C-5](#) for a list of suitable input registers.

The default value is 20210 (Distance).

Table C-5: List of Input Registers to the User Defined Variable

Variable	Register	Description
Min Electronics Temperature	20146	Minimum electronics temperature measured by the device (°C)
Max Electronics Temperature	20148	Maximum electronics temperature measured by the device (°C)
Min Signal Quality	21034	Minimum signal quality measured by the device since last signal quality reset. Signal quality calculation must be enabled to use this variable.
Max Signal Quality	21036	Maximum signal quality measured by the device since last signal quality reset. Signal quality calculation must be enabled to use this variable.
Distance to Upper Surface	21042	Distance to the upper product surface (m) when measuring on multiple products in the tanks. Double Surface function must be enabled to use this variable.
Distance to Lower Surface	21044	Distance to the lower product surface (m) when measuring on multiple products in the tanks. Double Surface function must be enabled to use this variable.
Surface Signal/Noise Ratio	21054	Ratio between surface echo signal strength and signal noise (dB). A high value (>20 dB) indicates very good margin to noise.
Product Dielectric Constant	22800	Square root of the product dielectric constant estimated by the transmitter when the Bottom Projection function is enabled. The product dielectric constant is calculated when both the bottom and surface echoes are found by device, and when surface echo is within the Max Projection Distance. Product dielectric constant estimation is frozen if any of these conditions are not fulfilled.

Unit

Units of measurement of the user defined variable.

More advanced options

More advanced options are only available in Rosemount Radar Master Plus.

By default, these parameters are automatically set based on current configuration. It is recommended that these parameters should remain at the default settings, unless there is a good understanding of the function and capability of the parameters.

Empty tank handling

The Empty Tank Handling functions handle situations when the surface echo is close to the tank bottom.

Table C-6: Empty Tank Handling

Parameter	Description
Empty tank detection area	<p>The Empty Tank Detection Area defines a range where it is accepted to lose the echo from the product. If the echo is lost in this range, the tank is considered empty and the level is presented as 0.</p> <p>When the tank is empty, the transmitter looks in this range for the product surface. When a new echo is found in this range, it is considered to be the product surface. Therefore, if there are disturbance echoes in this area, they may need to be filtered out.</p> <p>This function requires the Bottom echo visible when tank is empty parameter to be disabled.</p>
Bottom echo visible when tank is empty	<p>Only enable this parameter if the bottom echo is visible when tank is empty. By setting this parameter, the bottom echo will be treated as a disturbance echo to facilitate tracking of weak surface echoes close to the tank bottom.</p>

Related information

[Enable bottom echo visible when tank is empty](#)

Tank bottom projection

The Tank Bottom Projection is used to enhance measurement performance near the bottom of the tank. When the tank bottom echo is strong (typical for flat tank bottoms) and the dielectric constant of the product is low (e.g. oil), the transmitter may lock on the bottom echo and report a false level measurement (empty tank). This problem can be solved by using the Tank Bottom Projection function.

Table C-7: Tank Bottom Projection

Parameter	Description
Bottom product dielectric constant	Enter the product dielectric constant for the product in the bottom of the tank.
Maximum projection distance	This defines the range where the function is active. Enter the maximum distance from the zero level (tank bottom).
Minimum tank bottom amplitude	Enter the minimum allowed amplitude for the echo from the tank bottom before this function is activated.

Related information[Use tank bottom projection](#)

Echo tracking

Surface echo tracking

Use these settings to configure how the transmitter should keep track of the surface. These are advanced settings. Normally, they should not be changed.

Table C-8: Surface Echo Tracking

Parameter	Description
Search window size	<p>This parameter defines a window centered at the current surface position where new surface echo candidates can be selected. The size of the window is \pmSearch Window Size. Echoes outside this window will not be considered as surface echoes.</p> <p>If there are rapid level changes in the tank, the value of the Search Window Size can be increased to prevent the transmitter from missing level changes. On the other hand, a large value may cause the transmitter to select an invalid echo as the surface echo.</p>
Track first echo	Select the Track First Echo check box if the first echo above threshold always should be considered as the surface echo.

Related information[Handling ghost echoes in still pipes](#)

Double surface handling

If there are multiple products in the tank, the Double Surface Handling function can be manually set to allow user to select if the upper or lower product should be used as output.

The upper and lower surface echoes must be stronger than any disturbance echoes in the search region for Double Surface Handling to function properly.

Table C-9: Double Surface Handling

Parameter	Description
Track upper surface	Track upper surface when there are multiple products in the tank (for example thin oil layer on top of water).
Track lower surface	Track the lower product surface, such as the interface when there are multiple products in the tank, or the product surface instead of a foam layer.
Upper product dielectric constant	Enter the dielectric constant for the upper product. A more precise value results in better accuracy for the lower surface level.

Double bounce handling

Use this function to prevent transmitter from locking on strong double bounce echoes (may occur in spherical and horizontal cylinder tanks).

Related information

[Handling strong double bounce echoes](#)


Overfill prevention

The Overfill Prevention function adds an extra layer of protection to prevent tank overfills. The function uses an independent echo logic algorithm to identify the surface echo close to the top of the tank.

In the unlikely event there is a conflict between the normal and the overfill prevention echo logic, the Overfill Prevention function will have a precedence in determining the position of the surface. The transmitter will then output this new value, or generate an alarm if the normal echo logic is not able to find the surface echo at the new position.

The Overfill Prevention Range defines the lower end of the range in which the function operates. The range is configurable. See [Figure C-17](#) for default factory settings.

Figure C-17: Overfill Prevention Range



- A. Device Reference Point
- B. Overfill Prevention Range
- C. Rosemount 5408:SYS
- D. Rosemount 5408

Expert options

Use the expert options to view input registers, and to view and edit holding registers.

Note

Instructions for how to use Expert options are typically provided by factory and should only be modified if required.

Related information

[View input registers](#)

[View/edit holding registers](#)

C.4 Alert setup

C.4.1 Measurement recovery

Measurement recovery time

The Measurement Recovery Time (Echo Timeout) parameter controls the maximum time from when measurement is lost (e.g. due to process conditions such as foam or

turbulence) until it is annunciated. If measurement is recovered within the time specified by this parameter, then it will not be annunciated.

Measurement recovery handling

By default, the Measurement Recovery Time is set up automatically by the device based on the transmitter configuration.

It is recommended to leave the Measurement Recovery Handling at default unless required by your application. A higher value may be entered to increase robustness and avoid nuisance alarms. Only enter a lower value if lost measurement is required to be annunciated within a certain time for your application.

Used measurement recovery time

This is the value used by the transmitter.

C.4.2 Signal quality alert

This section applies only to transmitters ordered with Smart Diagnostics Suite.

Signal Quality is a measure of the product surface echo amplitude compared to the surface threshold and noise.

The Signal Quality spans from 0 to 10. A low value means that there is a risk for the noise peak to be mistaken for the product surface peak.


Note

The Signal Quality may not be 10 even if the antenna is clean. The value depends on antenna type, application conditions, configured surface threshold, as well as the condition of the antenna.

Build up on the antenna and different surface conditions are factors that can result in a low Signal Quality value. By setting an alert⁽¹⁸⁾, the Signal Quality value can be used to schedule maintenance to clean the antenna, fine-tune the surface threshold, or detect and monitor adverse surface conditions such as turbulence or foam.

Suitable alert limits vary from application to application. Appropriate value can be determined by logging Signal Quality over time and viewing maximum/minimum values. The Signal Quality Alert limit should be at least 1, but a better guideline is 2-3.

(18) Signal strength fluctuations are common when measuring solids, so Signal Quality alerts may not be appropriate in this case.

Figure C-18: Signal Quality Alert

A. Signal quality

B. Time

C. Alert ON

D. Deadband

E. Limit

F. The Signal Quality drops below the alert limit and an alert message is triggered.

G. The alert message is reset once the Signal Quality value rises above the Deadband range.

Limit

The Signal Quality value that will trigger the alert.

Deadband

The Deadband is a buffer zone so the alerts do not toggle on and off when the Signal Quality fluctuates around the alert limit. The alert is set when value falls below the alert limit. The alert is then cleared when value rises above the Deadband range.

C.4.3 High/low user defined alert

A high and low alert may be established to output an alert message when the measurement readings exceed the specified limits.

Variable

Select the transmitter variable to use for the alert.


Limit

The value that will trigger the alert.

Deadband


The Deadband is a buffer zone so the alerts do not toggle on and off when the measurement value fluctuates around the alert limit. The alert is set when the value exceeds the alert limit. The alert is then cleared when the value falls outside the Deadband range.

Figure C-19: High User Defined Alert



- A. User Defined Alert
- B. Time
- C. High Alert ON
- D. Limit
- E. Deadband
- F. The alert is active when the level value rises above the alert limit.
- G. The alert turns off when the value falls below the deadband.

Figure C-20: Low User Defined Alert



- A. User Defined Alert
- B. Time
- C. Low Alert ON
- D. Deadband
- E. Limit
- F. The alert is active when the level value falls below the alert limit.
- G. The alert turns off when the value rises above the deadband.

For more information: www.emerson.com

©2021 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.

ROSEMOUNT™

