



Industrial LoRaWAN[®] Gateway UG56

Quick Guide



Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- The device must not be modeled in any way.
- Do not place the device close to objects with naked flames.
- Do not place the device where the temperature is below/above the operating range.
- Do not power on the device or connect it to another electrical device when installing.
- Check lightning and water protection when used outdoors.
- Do not connect or power the equipment using cables that have been damaged.

Related Documents


This Quick Start Guide only explains the installation of Milesight UG56 LoRaWAN® Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
UG56 Datasheet	Datasheet for UG56 LoRaWAN® Gateway.
UG56 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Milesight website: <https://www.milesight-iot.com>

Declaration of Conformity

UG56 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
Milesight technical support:
Email: iot.support@milesight.com
Tel: 86-592-5085280
Fax: 86-592-5023065

Revision History

Date	Doc Version	Description
Aug.8, 2022	V1.0	Initial version

Contents

1. Packing List	4
2. Hardware Introduction	4
2.1 Overview	4
2.3 LED Indicators	5
2.4 Reset Button	5
3. Hardware Installation	6
3.1 SIM & Micro SD Installation	6
3.2 Antenna Installation	6
3.3 Power Supply	7
3.4 Gateway Installation	7
4. Web GUI Access	9
4.1 Wireless Access	9
4.2 Wired Access	10
5. Network Connection	13
5.1 Configure the Ethernet Connection	13
5.2 Configure the Wi-Fi Connection	13
5.3 Configure the Cellular Connection	14
6. Packet Forwarder Configuration	16
7. Network Server Configuration	18
7.1 Connect UG56 to Milesight IoT Cloud	18
7.2 Connect UG56 to MQTT/HTTP Server	20

1. Packing List


Before you begin to install the UG56 LoRaWAN® Gateway, please check the package contents to verify that you have received the items below.



1 × UG56 Device




1 × LoRaWAN®
Magnetic Antenna



1 × Wall Mounting
Bracket



2 × M3 Bracket Fixing
Screws



4 × Wall Mounting
Kits



1 × Quick Start Guide



1 × Warranty Card



1 × Type-C Cable & Power
Adapter (Optional)




1 × LoRaWAN®
Fiber-Glass Antenna
Kit(Optional)




If any of the above items is missing or damaged, please contact your sales representative.

2. Hardware Introduction

2.1 Overview




- ① LoRaWAN® Antenna Connector
- ② SIM Slot
- ③ Micro SD Slot
- ④ Reset Button



- ⑤ Type-C Power & Console Port
- ⑥ LED Indicators
- ⑦ Ethernet Port (PoE)

2.2 Dimensions (mm)



2.3 LED Indicators

LED	Indication	Status	Description
SYS	System Status	Off	The system is starting up
		Red Light	The system goes wrong
		Green Light	The system is running properly
LoRa	LoRa Status	Off	Packet Forwarder mode is running off
		On	Packet Forwarder mode is running well
Ethernet Port	Link Indicator (Yellow)	Off	Disconnected or connect failure
		On	Connected
		Blinking	Transmitting data
	Rate Indicator (Green)	Off	Other modes
		On	100 Mbps mode

2.4 Reset Button


Function	Description	
	SYS LED	Action
Reset	Static Green	Press and hold the reset button for more than 5 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Static Green	The gateway resets to factory default.

3. Hardware Installation

3.1 SIM & Micro SD Installation


Remove the front panel of the device, insert the SIM card or micro SD card into the corresponding slot.

Note: UG56 does not support hot plugging (also called hot swapping). please turn off the power before you insert or take off cards.




3.2 Antenna Installation

Rotate the LoRa antenna into the antenna connector. The antenna should be installed vertically and kept away from batteries.




If you need to fix the LoRa fiber-glass antenna to a pole, please pass the LoRa antenna through the antenna clamp and fix it with 4 screws, then wrap the U-bolt around a pole and fix the clamp with nuts and other accessories.




3.3 Power Supply

UG56 can be powered by 802.3af standard PoE or Type-C port (5 VDC). If both are connected, the device will be powered by the former method (PoE).


- **Power by a PoE Switch**



- **Power by a PoE injector**



- **Power by a Type-C Port**




Note: When connecting, Ethernet cable of UG56 device side should be installed first, otherwise, PoE devices or gateway may be damaged.


3.4 Gateway Installation

Before you get started, make sure all fittings are installed and the power supply is disconnected.

A. Fix the wall mounting bracket to the device with 2 x M3 bracket fixing screws.



- B. Drill 4 holes on the wall according to the wall mounting bracket, then fix the wall plugs into the wall.
- C. Fix the device to the wall plugs with M3 wall mounting screws. When installation, it's suggested to fix the upper two screws first.



4. Web GUI Access

UG56 provides web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:

ETH IP Address: **192.168.23.150**

Wi-Fi IP Address: **192.168.1.1**

Wi-Fi SSID: **Gateway_*******

Username: **admin**

Password: **password**

Browser: **Chrome(recommended)**

4.1 Wireless Access

A. Enable wireless network connection on your computer and search for access point "**Gateway_*******" to connect it.

B. Open a web browser on your PC (Chrome is recommended) and type in the IP address **192.168.1.1** to access the web GUI, enter the username and password, click "Login".



If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

D. After logging the web GUI, follow the guide to complete the basic configurations. It's suggested that you change the password for the sake of security.

Change Your Default Password

For your device security, please change the default password in time.

Old Password

New Password

Confirm New Password

Close

Save

E. You can view system information and perform configuration of the gateway.

Milesight

For your device security, please change the default password in time.

Status

Packet Forwarder

Network Server

Network

System

Maintenance

APP

Overview

Cellular

Network

WLAN

VPN

Routing

Host List

System Information

Model

UG56-17FE-RTM

Region

USDT1

Serial Number

8841C002749

Firmware Version

30.0.0.1-42

Hardware Version

V1.0

Local Time

2022-06-10 16:31:29 Wednesday

Uptime

103:16:23

CPU Load

3%

RAM (Available/Capacity)

194MB/128M (17.28%)

sdBMC (Available/Capacity)

4.2GB/5T (92.48%)

Manual Refresh

Refresh

Help

Model

Show the model name of gateway.

Region

Show the Region of gateway.

Serial Number

Show the serial number of gateway.

Firmware Version

Show the current firmware version of gateway.

Hardware Version

Show the current hardware version of gateway.

Local Time

Show the current local time of system.

Uptime

Show the information on how long the gateway has been running.


4.2 Wired Access

Connect PC to UG56 ETH port directly or through PoE injector to access the web GUI of gateway. The following steps are based on Windows 10 system for your reference.

A. Go to "Control Panel" → "Network and Internet" → "Network and Sharing Center", then click "Ethernet" (It may have different names).



B. Go to “Properties” → “Internet Protocol Version 4 (TCP/IPv4)” and select “Use the following IP address”, then assign a static IP manually within the same subnet of UG56.



C. Open a Web browser on your PC (Chrome is recommended) and type in the IP address 192.168.23.150 to access the web GUI.

D. Enter the username and password, click “Login”.



If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

E. After logging the web GUI, follow the guide to complete the basic configurations. It's suggested that you change the password for the sake of security.

Change Your Default Password

For your device security, please change the default password in time.

Old Password

New Password

Confirm New Password

Close

Save

F. You can view system information and perform configuration of the gateway.

Milesight

For your device security, please change the default password in time.

Status

Packet Forwarder

Network Server

Network

System

Maintenance

APP

Overview

Cellular

Network

Wi-Fi

VPN

Routing

Host List

System Information

Model	V000-LTE-R10M
Region	US010
Serial Number	0001C000740
Firmware Version	30.00.1-42
Hardware Version	V1.2
Local Time	2023-06-12 16:31:28 Wednesday
Uptime	02:10:23
CPU Load	0%
RAM (Available/Capacity)	194MB/128M (17.80%)
sdBEC (Available/Capacity)	6.20GB/7.0GB (88.60%)

Manual Refresh

Refresh

Model

Show the model name of gateway.

Region

Show the Region of gateway.

Serial Number

Show the serial number of gateway.

Firmware Version

Show the current firmware version of gateway.

Hardware Version

Show the current hardware version of gateway.

Local Time

Show the current local time of system.

Uptime

Show the information on how long the gateway has been running.

5. Network Connection

This section explains how to connect the gateway to network via WAN connection, Wi-Fi or cellular.

5.1 Configure the Ethernet Connection

- Go to “Network”→ “Interface” → “Port” page to select the connection type and configure Ethernet port information.
- Click “Save & Apply” for changes to take effect.

Port	eth 0
Connection Type	Static IP
IP Address	192.168.22.112
Netmask	255.255.255.0
Gateway	192.168.22.1
MTU	1500
Primary DNS Server	8.8.8.8
Secondary DNS Server	114.114.114.114
Enable NAT	☒

- Connect Ethernet port of gateway to the devices like router or modem.
- Log in the web GUI via the newly assigned IP address and go to “Status”→ “Network” to check Ethernet port status.

Port	Status	Type	IP Address	Netmask	Gateway	DNS	Duration
eth 0	up	Static	192.168.22.112	255.255.255.0	192.168.22.1	8.8.8.8	14:00:02h 34m 22s

5.2 Configure the Wi-Fi Connection

- Go to “Network” → “Interface” → “WLAN” and select “Client” mode.
- Click “Scan” to search for Wi-Fi access points. Select the available one and click “Join Network”.

Port
WLAN
Cellular
Loopback

< Go Back

SSID	Channel	Signal	Cipher	BSSID	Security	Frequency
AAA	Auto	-61dBm	AES	24:e1:24:f0:c4:13	WPA-PSK/WPA2-PSK	2412MHz

Join Network

C. Type the key of Wi-Fi.

Port
WLAN
Cellular
Loopback

WLAN

Enable

☒

Work Mode

Client

Scan

SSID

AAA

BSSID

24:e1:24:f0:c4:13

Encryption Mode

WPA-PSK/WPA2-PSK

Cipher

AES

Key

IP Setting

Protocol

DHCP Client

D. Go to “Status”→“WLAN” to check Wi-Fi status. If it shows “Connected”, it means gateway connects to Wi-Fi successfully.

Overview
Packet Forward
Cellular
Network
WLAN

WLAN Status

Wireless Status	Enabled
MAC Address	24:e1:24:f0:de:14
Interface Type	Client
SSID	AAA
Channel	Auto
Encryption Type	WPA-PSK/WPA2-PSK
Cipher	AES
Status	Connected
IP Address	192.168.1.145
Netmask	255.255.255.0
Connection Duration	0 days, 02:44:45

5.3 Configure the Cellular Connection

A. Go to “Network” → “Interface” → “Cellular” → “Cellular Setting” page to enable cellular settings.

- B. Choose relevant network type and fill in SIM card information like APN or PIN code.
- C. Click “Save” and “Apply” for changes to take effect.

Port	WLAN	Cellular	Loopback
Cellular Setting			
Enable		☒	
Network Type		Auto	
APN			
Username			
Password			
Access Number			
PIN Code			
Authentication Type		Auto	
Roaming		☒	
SMS Center			
Connection Setting		☐	
Enable NAT		☒	

- D. Go to “Status” → “Cellular” page to view the status of the cellular connection. If it shows “Connected”, it means the SIM has dialed up successfully. On the other hand, you can check the status of LTE indicator. If it keeps on light statically, it means SIM has dialed up successfully.

Overview	Packet Forward	Cellular	Network	WLAN
Modem				
Status	Ready			
Model	EC21			
Version	EC21EGAR06A07M10			
Signal Level	25dB (-67dBm)			
Register Status	Registered (Home network)			
IMEI	89042194T348936			
IMSI	460019425101642			
ICCID	89000117130008834129			
ISP	CHN-CHN-OM			
Network Type	LTE			
PLMN (B)				
LAC	5522			
CAR ID	34368E5			
Network				
Status	Connected			
IP Address	10.132.132.58			
Netmask	255.255.255.248			
Gateway	10.132.132.60			

6. Packet Forwarder Configuration

UG has installed multiple packet forwarders including Semtech, Chirpstack-Generic MQTT broker, etc. This section explains how to connect the gateway to network servers.



Make sure the gateway connects to the network as shown in [Section 5](#).

A. Go to “Packet Forwarder” → “General” page and click  to add a network server.



ID	Enable	Type	Server Address	Operation
0	Enabled	Embedded NS	localhost	

B. Fill in the server information and enable this server.



Enable ☒

Type: Semtech

Server Address: eu1.cloud.thethings.network

Port Up: 1700

Port Down: 1700

Save

C. Go to “Packet Forwarder” → “Radio” page, center frequency and channels. The channels of the gateway and network server need to be the same.

Region

US913

Name	Center Frequency(MHz)
Radio 0	904.3
Radio 1	905.0

Multi Channels Setting

Enable	Index	Radio	Frequency(MHz)
☒	0	Radio 0	903.9
☒	1	Radio 0	904.1
☒	2	Radio 0	904.3
☒	3	Radio 0	904.5
☒	4	Radio 1	904.7
☒	5	Radio 1	904.9
☒	6	Radio 1	905.1
☒	7	Radio 1	905.3

D. Add the gateway on network server page. For more details about the network server connection please refer to [Milesight IoT Support portal](#).

E. Go to “Traffic” page to view the data communication of UG56.

General
Radio
Advanced
Custom
Traffic

Traffic Setting

Stop

Clear

Block	Direction	Time	Index	Frequency	Datarate	Coderate	RSSI	SNR
1	up	11:52:38	317882157 1	885.385	SF7BW125	45	-91	0.0
1	up	11:52:32	316326389 2	886.585	SF7BW125	47	-108	-11.0
0	down	-	317088813 1	885.825	SF7BW125	45	-	-
0	up	11:51:37	317788813 1	885.825	SF7BW125	45	-95	-0.0

7. Network Server Configuration

UG56 can work as network server and transmit data to Milesight IoT Cloud or another platform via MQTT/HTTP/HTTPS.

Make sure the gateway connects to the network as shown in [Section 5](#).

7.1 Connect UG56 to Milesight IoT Cloud


A. Go to “Packet Forwarder” → “General” page to enable the embedded network server.

ID	Enable	Type	Server Address	Operation
0	Enabled	Embedded NS	localhost	

B. Go to “Packet Forwarder” → “Radio” page to select the antenna type, center frequency and channels. The channels of the gateway and nodes need to be the same.

Enable	Index	Radio	Frequency/MHz
☒	0	Radio 0	903.9
☒	1	Radio 0	904.1
☒	2	Radio 0	904.3
☒	3	Radio 0	904.5
☒	4	Radio 1	904.7
☒	5	Radio 1	904.9
☒	6	Radio 1	905.1
☒	7	Radio 1	905.3

C. Go to “Network Server” → “General” page to enable the network server and “Milesight IoT Cloud” mode.



D. Log in the Milesight IoT Cloud. Then go to “My Devices” page and click “+New Devices” to add gateway to Milesight IoT Cloud via SN. Gateway will be added under “Gateways” menu.




E. The gateway is online on Milesight IoT Cloud.




7.2 Connect UG56 to MQTT/HTTP Server

A. Go to “Packet Forwarder” → “General” page to enable the embedded network server.



B. Go to “Packet Forwarder” → “Radio” page to select the antenna type, center frequency and channels. The channels of the gateway and nodes need to be the same.




C. Go to “Network Server” → “General” page to enable the network server mode.




D. Go to “Network Server”→“Application” to add a new application.



After saving the application, you can select HTTP, HTTPS or MQTT protocol and fill in corresponding server information to send data to another server.



E. Go to “Profiles” page to add a new profile for the device.



General Applications **Profiles** Device

Device Profiles

Name

Max TXPower

Join Type

Class Type ☒ Class A ☐ Class B ☐ Class C

Advanced ☐

F. Go to “Device” page and click “Add” to add LoRaWAN® node devices.



General Applications Profiles **Device** Gateways Packets

Device

Device Name	Device EUI	Device Profile	Application	Last Seen	Activated	Operation
No matching records found						



Device Name

Description

Device EUI

Device Profile

Application

Frame counter Validation ☐

Application Key

Device Address

Network Session Key

Application Session Key

Uplink Frame counter

Downlink Frame counter

You can also click “Bulk Import” if you want to add many nodes all at once.



Import File

Click “Template Download” to download template file and add device information to this file. Application

and device profile should be the same as you created on web page.

A	B	C	D	E	F	G	H	I
name	description	deviceid	region	deviceprofile	apikey	deviceid	apikey	apikey
24e3242156323266		24e3242156323266	cloud	ClassC-OTAA	112233445566778899aa112233445566			

Import this file to add bulks of devices.

F. Go to “Packets” page to check the packets from LoRaWAN® node devices. The type starts from “Up” means uplinks and “Dn” means downlinks.

Network Server										
Clear		Search								
Device EUI	Frequency	Datarate	SNR	RSSI	Size	Font	Type	Time	Details	
24e124125a146579	868300000	SF7BW125	8.5	-85	4	14	UpUnc	2020-04-20T16:09:25+08:00	!	
24e124125a146579	868300000	SF7BW125	10.2	-75	4	13	UpUnc	2020-04-20T16:04:25+08:00	!	

Click “Details” to check the properties and payload contents of packets.

Packets Details	
Font	14
Port	85
Modulation	LORA
Bandwidth	125
SpreadFactor	7
Bitrate	0
CodeRate	4/5
SNR	8.5
RSSI	-85
Power	-
Payload(b64)	AJcYAA==
Payload(hex)	03771800
MIC	f5ecdeb2

[END]