

DLN

Е

# **CONTENTS**

TRANSFER: ATX90A	CONSULT-III Function21 F
PRECAUTION6	ECU DIAGNOSIS INFORMATION24
PRECAUTIONS	TRANSFER CONTROL UNIT       24         Reference Value       24         Fail-Safe       28         DTC Inspection Priority Chart       29         DTC Index       29
tion after Battery Disconnect6 Service Notice or Precautions for Transfer7	WIRING DIAGRAM31
PREPARATION8	<b>4WD SYSTEM31</b> Wiring Diagram31
PREPARATION	BASIC INSPECTION38
Commercial Service Tools8	DIAGNOSIS AND REPAIR WORK FLOW38
SYSTEM DESCRIPTION10	Work Flow
COMPONENT PARTS         10           Component Parts Location         10           Component Description         11           Transfer Control Unit         11           Transfer Control Actuator         11           Transfer Hi-Lo Position Sensor         12           Transfer Rotary Position Sensor         12           Transfer Lock Position Sensor         12           Transfer Fluid Temperature Sensor         12	ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT
STRUCTURE AND OPERATION         13           Sectional View         13           Torque Split Mechanism         13	TRANSFER LOCK POSITION SENSOR LEARNING
SYSTEM18	Work Procedure44
4WD SYSTEM       18         4WD SYSTEM : System Description       18         4WD SYSTEM : Fail-Safe       20	TRANSFER ROTARY POSITION SENSOR LEARNING46 Description46
DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)21	Work Procedure46  TRANSFER FLUID VISCOSITY LEARNING47  Description47

Work Procedure	47	Component Inspection	71
CONFIGURATION (TRANSFER CONTROL		P181A TRANSFER MOTOR TEMPERATURE	
UNIT)	48	SENSOR	72
Description		DTC Logic	
Work Procedure		Diagnosis Procedure	
		Component Inspection	
DTC/CIRCUIT DIAGNOSIS	51	·	
		P181B INCOMPLETE SELFSHUT	74
P1802, P1803, P1804, P1809 TRANSFER		DTC Logic	74
CONTROL UNIT	51	Diagnosis Procedure	74
DTC Logic	51	•	
Diagnosis Procedure	51	P181C TRANSFER MOTOR POWER SUP-	
		PLY	76
P1807 OUT PUT SHAFT SPEED SENSOR		Description	76
DTC Logic		DTC Logic	76
Diagnosis Procedure	52	Diagnosis Procedure	76
DAGGO WILEEL OREED OFNOOD		•	
P1808 WHEEL SPEED SENSOR		P181E STEERING ANGLE SENSOR	
DTC Logic		DTC Logic	
Diagnosis Procedure	53	Diagnosis Procedure	77
D100C SENSOD DOWED SLIDDLY (EV)	E 4	DAGAE INICOMPLETE CALIDDATION	
P180C SENSOR POWER SUPPLY (5V)		P181F INCOMPLETE CALIBRATION	
Description		DTC Logic	
DTC Logic	54	Diagnosis Procedure	78
Diagnosis Procedure	54	D4000 ENGINE CREED CIGNAL	70
P180D TRANSFER ROTARY POSITION		P1820 ENGINE SPEED SIGNAL	
SENSOR	<b>5</b> 7	DTC Logic	
		Diagnosis Procedure	79
DTC Logic		P1826 TRANSFER FLUID TEMPERATURE	90
Diagnosis Procedure	57	DTC Logic	
P180E SENSOR POWER SUPPLY (8V)	50	Diagnosis Procedure	
Description			
DTC Logic		Component Inspection	81
		P1829 ACCELERATOR PEDAL POSITION	
Diagnosis Procedure	59	SENSOR	82
P180F TRANSFER INTERNAL SPEED SEN-		DTC Logic	
SOR		Diagnosis Procedure	
DTC Logic		Diagnosis Frocedure	02
Diagnosis Procedure		P182A TRANSFER HI-LO POSITION SEN-	
Diagnosis Flocedure	01	SOR	83
P1811 POWER SUPPLY CIRCUIT FOR		DTC Logic	
TRANSFER CONTROL UNIT	64	Diagnosis Procedure	
Description	-	Diagnosis Frocedure	63
DTC Logic		P182B TRANSFER LOCK POSITION SEN-	
Diagnosis Procedure		SOR	85
Diagnosis Procedure	04	DTC Logic	
P1813 4WD MODE SWITCH	67	Diagnosis Procedure	
DTC Logic		Diagnosis Flocedure	65
Diagnosis Procedure		P1830 ABS OPERATION SIGNAL	88
Component Inspection		DTC Logic	
Component inspection	00	Diagnosis Procedure	
P1816 PARKING/NEUTRAL POSITION		2.03.100.01.10000010	55
SWITCH	69	P1831 VDC OPERATION SIGNAL	89
DTC Logic		DTC Logic	89
Diagnosis Procedure		Diagnosis Procedure	
Diagnosis i locedule	ບອ		. 55
P1817 TRANSFER MOTOR	70	P1832 TCS OPERATION SIGNAL	90
DTC Logic		DTC Logic	90
Diagnosis Procedure		Diagnosis Procedure	
g.:50:0 : 1000dd:0 :::::::::::::::::::::::::	0	<del>-</del>	

U1000 CAN COMM CIRCUIT91	TRANSFER CONTROL UNIT	107
Description91	Removal and Installation	107
DTC Logic91	AND MODE CHITCH	400
Diagnosis Procedure91	4WD MODE SWITCH	
HIANA CONTROL HAIT (CAN)	Removal and Installation	108
U1010 CONTROL UNIT (CAN)92	FRONT OIL SEAL	109
Description	Exploded View	
DTC Logic	Removal and Installation	
Diagnosis Procedure92		
POWER SUPPLY AND GROUND CIRCUIT93	REAR OIL SEAL	
Description93	Exploded View	
Diagnosis Procedure93	Removal and Installation	
AND WARNING LAND	Adjustment	112
4WD WARNING LAMP97	TRANSFER CONTROL ACTUATOR	114
Component Function Check97	Exploded View	
Diagnosis Procedure97	Removal and Installation	
4WD INDICATOR LAMP98	Inspection	
Component Function Check98	mapcodon	1
Diagnosis Procedure98	TRANSFER HI-LO POSITION SENSOR	116
	Exploded View	116
SYMPTOM DIAGNOSIS99	Removal and Installation	116 (
	Inspection	116
HEAVY TIGHT-CORNER BRAKING SYMP-	TRANSFER ROTARY ROOFFION OFNIOR	
TOM OCCURS99	TRANSFER ROTARY POSITION SENSOR.	
Description99	Exploded View	
Diagnosis Procedure99	Removal and Installation	
4WD MODE DOES NOT CHANGE100	Inspection	118
	TRANSFER LOCK POSITION SENSOR	119
Description	Exploded View	
Diagnosis Procedure100	Removal and Installation	
4WD MODE INDICATOR LAMP CONTINUES	Inspection	
BLINKING101		
Description	TRANSFER FLUID TEMPERATURE SEN-	
Diagnosis Procedure101	SOR	120
-	Exploded View	
4WD WARNING LAMP BLINKS QUICKLY 102	Removal and Installation	120
Description102	Inspection	120
4WD WARNING LAMP BLINKS SLOWLY 103	LINUT DEMOVAL AND INCTALLATION	
	UNIT REMOVAL AND INSTALLATION .	121
Description	TRANSFER ASSEMBLY	121
Diagnosis Flocedule103	Exploded View	
INFORMATION DISPLAY IS NOT DIS-	Removal and Installation	
PLAYED104		
Description	INPUT OIL SEAL	123
Diagnosis Procedure104	Exploded View	123
	Removal and Installation	123
NOISE, VIBRATION AND HARSHNESS		(
(NVH) TROUBLESHOOTING105	SERVICE DATA AND SPECIFICATIONS	
NVH Troubleshooting Chart105	(SDS)	124
DEDIODIC MAINTENANCE	CEDVICE DATA AND ODEOUGOATIONS	
PERIODIC MAINTENANCE106	SERVICE DATA AND SPECIFICATIONS	
TRANSFER FLUID106	(SDS)	
	General Specifications	
Inspection	FRONT PROPELLER SHAFT: 2F P1	5
Draining		46-
Refilling106	PREPARATION	125
REMOVAL AND INSTALLATION107	PREPARATION	125
	I INEFANATION	123

Commercial Service Tools125	NOISE, VIBRATION, AND HARSHNESS	
SYMPTOM DIAGNOSIS126	(NVH) TROUBLESHOOTING14  NVH Troubleshooting Chart14	
NOISE, VIBRATION, AND HARSHNESS	· ·	
(NVH) TROUBLESHOOTING126	PERIODIC MAINTENANCE14	42
NVH Troubleshooting Chart126	REAR PROPELLER SHAFT14	42
•	Inspection14	
PERIODIC MAINTENANCE127	·	
FRONT PROPELLER SHAFT 127	REMOVAL AND INSTALLATION14	43
Inspection127	REAR PROPELLER SHAFT14	42
•	Exploded View12	
REMOVAL AND INSTALLATION128	Removal and Installation12	
EDONT PROPELLED CHAFT	Disassembly and Assembly14	
FRONT PROPELLER SHAFT 128	Inspection14	
Exploded View		
Removal and Installation129 Disassembly and Assembly129	SERVICE DATA AND SPECIFICATIONS	
Inspection131	(SDS)14	47
	SERVICE DATA AND SPECIFICATIONS	
SERVICE DATA AND SPECIFICATIONS	(SDS)14	47
(SDS)133	General Specification14	
SERVICE DATA AND SPECIFICATIONS	Propeller Shaft Runout14	
(SDS) 133	Journal Axial Play14	
General Specification	FRONT FINAL DRIVE: R180A	
Propeller Shaft Runout133	DDECALITION	
Journal Axial Play133	PRECAUTION14	48
REAR PROPELLER SHAFT: 2F P26	PRECAUTIONS14	48
	Precaution Necessary for Steering Wheel Rota-	
SYMPTOM DIAGNOSIS134	tion after Battery Disconnect14	48
NOISE, VIBRATION, AND HARSHNESS	Precaution for Servicing Front Final Drive 14	48
(NVH) TROUBLESHOOTING134	PREPARATION14	
NVH Troubleshooting Chart134	PREPARATION14	49
-	PREPARATION14	49
PERIODIC MAINTENANCE135	Special Service Tool14	49
REAR PROPELLER SHAFT135	Commercial Service Tool15	51
Inspection	SYSTEM DESCRIPTION15	
mopodion100	3131EW DESCRIPTION1	33
REMOVAL AND INSTALLATION136	STRUCTURE AND OPERATION15	53
REAR PROPELLER SHAFT136	Sectional View15	53
Exploded View	CVMDTOM DIA CNOCIC	
Removal and Installation137	SYMPTOM DIAGNOSIS15	54
Disassembly and Assembly137	NOISE, VIBRATION AND HARSHNESS	
Inspection139	(NVH) TROUBLESHOOTING15	54
	NVH Troubleshooting Chart15	
SERVICE DATA AND SPECIFICATIONS	DEDICOIO MAINTENANCE	
(SDS)140	PERIODIC MAINTENANCE15	55
SERVICE DATA AND SPECIFICATIONS	FRONT DIFFERENTIAL GEAR OIL15	55
(SDS)140	Inspection	
General Specification140	Draining15	
Propeller Shaft Runout140	Refilling15	
Journal Axial Play140	REMOVAL AND INSTALLATION15	Er
REAR PROPELLER SHAFT: 2S1410	INCINIOVAL AIND INSTALLATION1	20
SAMDLOW DIV CNOSIS	FRONT OIL SEAL15	56
SYMPTOM DIAGNOSIS141	Exploded View15	56

Removal and Installation156	STRUCTURE AND OPERATION191
SIDE OIL SEAL160	Sectional View191
Exploded View	SYMPTOM DIAGNOSIS192
Removal and Installation	31 WF 10W DIAGNOSIS192
Nomoval and installation100	NOISE, VIBRATION AND HARSHNESS
UNIT REMOVAL AND INSTALLATION 162	(NVH) TROUBLESHOOTING192
	NVH Troubleshooting Chart192
FRONT FINAL DRIVE ASSEMBLY162	
Exploded View162	PERIODIC MAINTENANCE193
Removal and Installation162	
UNIT DISASSEMBLY AND ASSEMBLY . 164	REAR DIFFERENTIAL GEAR OIL193 Inspection193
SIDE SHAFT164	Draining193
Exploded View	Refilling193
Disassembly	REMOVAL AND INSTALLATION194
Assembly	NEMOVAE AND INSTALLATION
Inspection	FRONT OIL SEAL194
	Exploded View194
DIFFERENTIAL ASSEMBLY167	Removal and Installation194
Exploded View167	
Disassembly168	SIDE OIL SEAL199
Assembly	Exploded View199
Adjustment171	Removal and Installation199
Inspection174	LINIT DEMOVAL AND INCTALL ATION
DRIVE PINION176	UNIT REMOVAL AND INSTALLATION 201
Exploded View	REAR FINAL DRIVE201
Disassembly	Exploded View201
	Removal and Installation201
Assembly	removal and installation201
Inspection	UNIT DISASSEMBLY AND ASSEMBLY . 203
·	DIFFERENTIAL ACCEMBLY
SERVICE DATA AND SPECIFICATIONS	DIFFERENTIAL ASSEMBLY203
(SDS)185	Exploded View
`	Disassembly
SERVICE DATA AND SPECIFICATIONS	Assembly
(SDS)185	Adjustment
General Specifications185	Inspection215
Drive Gear Runout185	DRIVE PINION216
Preload Torque185	Exploded View216
Backlash185	
Companion Flange Runout185	Disassembly217
Companion Flange Runout	Disassembly217 Assembly218
Companion Flange Runout	Disassembly
Companion Flange Runout185	Disassembly
Companion Flange Runout	Disassembly
Companion Flange Runout	Disassembly
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS         (SDS)       222
Companion Flange Runout	Disassembly         217           Assembly         218           Adjustment         220           Inspection         220           SERVICE DATA AND SPECIFICATIONS
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS       (SDS)         SERVICE DATA AND SPECIFICATIONS       222         SERVICE DATA AND SPECIFICATIONS       (SDS)
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS       (SDS)         SERVICE DATA AND SPECIFICATIONS       (SDS)         (SDS)       222         General Specification       222
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS         (SDS)       222         SERVICE DATA AND SPECIFICATIONS         (SDS)       222         General Specification       222         Drive Gear Runout       222
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS       (SDS)         (SDS)       222         SERVICE DATA AND SPECIFICATIONS       (SDS)         (SDS)       222         General Specification       222         Drive Gear Runout       222         Side Gear Clearance       222
Companion Flange Runout	Disassembly       217         Assembly       218         Adjustment       220         Inspection       220         SERVICE DATA AND SPECIFICATIONS         (SDS)       222         SERVICE DATA AND SPECIFICATIONS         (SDS)       222         General Specification       222         Drive Gear Runout       222

#### **PRECAUTIONS**

< PRECAUTION > [TRANSFER: ATX90A]

# **PRECAUTION**

## **PRECAUTIONS**

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal
  injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag
  Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:0000000006222210

#### NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### **OPERATION PROCEDURE**

Connect both battery cables.

#### NOTE:

Supply power using jumper cables if battery is discharged.

- 2. Turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
- Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
- Perform the necessary repair operation.

#### **PRECAUTIONS**

< PRECAUTION > [TRANSFER: ATX90A]

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)

6. Perform self-diagnosis check of all control units using CONSULT-III.

# Service Notice or Precautions for Transfer

#### INFOID:0000000006222211

#### **CAUTION:**

- Use Genuine NISSAN Transfer Fluid. Refer to MA-10, "Fluids and Lubricants".
- Never reuse transfer fluid, once it has been drained.
- Check the fluid level or replace the fluid only with the vehicle parked on level ground.
- During removal or installation, keep inside of transfer clear of dust or dirt.
- Replace all tires at the same time. Always use tires of the proper size and the same brand and pattern. Fitting improper size and unusually worn tires applies excessive force to vehicle mechanism and can cause longitudinal vibration.
- Disassembly should be done in a clean work area, it is preferable to work in dustproof area.
- Before proceeding with disassembly, thoroughly clean the transfer. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the transfer is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Observe the specified torque when assembling.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- Clean inner parts with lint-free cloth or towels. Do not use cotton work gloves and rags to prevent adhering fibers.

DLN

В

Е

F

G

Κ

.

VI

Ν

0

Р

# **PREPARATION**

< PREPARATION > [TRANSFER: ATX90A]

# **PREPARATION**

# **PREPARATION**

# **Special Service Tools**

INFOID:0000000006222212

Tool number (Kent-Moore No.) Tool name		Description
ST30701000 (J-25742-2) Drift a: 61.5 mm (2.421 in) dia. b: 41 mm (1.61 in) dia.	-b- -a-	Removing dust shield from companion flange
KV40104710 ( — ) Drift a: 76.3 mm (3.004 in) dia. b: 67.9 mm (2.673 in) dia.	ZZA1000D	Installing rear oil seal     Installing input oil seal
KV10119400 ( — ) Spline socket	ZZA1205D	Installing transfer control actuator     Installing transfer rotary position sensor

# **Commercial Service Tools**

INFOID:0000000006222213

Tool name		Description
Puller	ZZA0119D	Removing dust shield from shaft flange     Removing dust shield from companion flange
Replacer	ZZAO700D	Removing dust shield from shaft flange     Removing dust shield from companion flange

# **PREPARATION**

< PREPARATION > [TRANSFER: ATX90A]

Tool name		Description
Drift a: 63 mm (2.48 in) dia. b: 59 mm (2.32 in) dia.		Installing front oil seal
	ab	
	ZZA1003D	
Power tool		Loosening bolts and nuts
	PBIC0190E	

Revision: 2010 May **DLN-9** 2011 QX56

С

Α

В

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

Р

# SYSTEM DESCRIPTION

# **COMPONENT PARTS**

# **Component Parts Location**

O.E 3 © Œ

- Refer to EC-16, "Component Parts Location".
- Control valve & TCM Refer to TM-10, "A/T CONTROL SYSTEM: Component Parts Location".
- Transfer lock position sensor
- 10. Transfer control actuator
- Back of glove box assembly
- D. Transfer assembly upper side

- ABS actuator and electric unit (control unit)
  - Refer to BRC-10, "Component Parts Location".
- Transfer control unit

- 8. Transfer Hi-Lo position sensor
- Transfer fluid temperature sensor 11.
- 4WD indicator lamp, 4WD warning lamp, ATP warning lamp (in combination meter)
- Transfer assembly under side

Steering angle sensor Refer to BRC-10, "Component Parts Location".

JPDIE0270GB

[TRANSFER: ATX90A]

INFOID:0000000006222214

- 4WD switch assembly
- Transfer rotary position sensor
- C. Console assembly

# Component Description

[TRANSFER: ATX90A]

Α

Compor	nent parts	Reference/Function	
Transfer control unit		DLN-11, "Transfer Control Unit"	В
	Transfer motor	DLN-11, "Transfer Control Actuator"	
Transfer control actua-	Transfer internal speed sensor	DLN-11, "Transfer Control Actuator"	С
	Transfer motor temper- ature sensor	DLN-11, "Transfer Control Actuator"	5.
Transfer Hi-Lo position	sensor	DLN-12, "Transfer Hi-Lo Position Sensor"	DL
Transfer rotary position	sensor	DLN-12, "Transfer Rotary Position Sensor"	
Transfer lock position se	ensor	DLN-12, "Transfer Lock Position Sensor"	Е
Transfer fluid temperatu	ire sensor	DLN-12, "Transfer Fluid Temperature Sensor"	
4WD mode switch		DLN-18, "4WD SYSTEM : System Description"	
4WD indicator lamp		DLN-18, "4WD SYSTEM : System Description"	F
4WD warning lamp		DLN-18, "4WD SYSTEM : System Description"	
ATP warning lamp		DLN-18, "4WD SYSTEM : System Description"	G
ABS actuator and elect	ric unit (control unit)	Transmits the following signals via CAN communication line to transfer control unit.  Vehicle speed signal (ABS) Stop lamp switch signal (brake signal) ABS operation signal VDC operation signal TCS operation signal	F
Steering angle sensor		Transmits the following signals via CAN communication line to transfer control unit.  • Steering angle sensor signal	I
ECM		Transmits the following signals via CAN communication line to transfer control unit.  • Accelerator pedal position signal  • Engine speed signal  • Engine torque signal	J
TCM		Transmits the following signals via CAN communication line to transfer control unit.  Shift position signal Gear position signal Output shaft revolution signal	K

#### **Transfer Control Unit**

INFOID:0000000006222216

M

Ν

Р

- Transfer control unit operates transfer control actuator, 4WD warning lamp and 4WD mode indicator lamp according to input signal from 4WD shift switch and each sensor and control unit.
- When 4WD system is malfunctioning, 4WD warning lamp turns ON and fail-safe status activates.
- When protection is necessary, 4WD warning lamp blinks and protection status activates.

#### Transfer Control Actuator

INFOID:0000000006222217

Transfer control actuator integrates transfer motor, transfer internal position sensor, and transfer motor temperature sensor, and switches 4WD mode (AUTO⇔4H⇔4L).

#### TRANSFER MOTOR

Transfer motor operates according to signal from transfer control unit and switches 4WD mode (AUTO⇔4H⇔4L). It also performs front and rear distribution of traction force during AUTO mode.

#### TRANSFER INTERNAL SPEED SENSOR

Transfer internal speed sensor detects rotation status of transfer motor and transmits signal to transfer control unit.

#### TRANSFER MOTOR TEMPERATURE SENSOR

Transfer motor temperature sensor measures temperature of transfer motor.

#### **COMPONENT PARTS**

#### < SYSTEM DESCRIPTION >

• This sensor uses a thermistor and its electrical resistance varies as the temperature varies. The electrical resistance decreases as the temperature increases.

#### Transfer Hi-Lo Position Sensor

INFOID:0000000006222218

[TRANSFER: ATX90A]

Transfer Hi-Lo position sensor detects engagement status of Hi-Lo sleeve and transmits signal to transfer control unit.

# Transfer Rotary Position Sensor

INFOID:0000000006222219

Transfer rotary position sensor detects rotation status of actuator shaft and transmits signal to transfer control unit.

#### Transfer Lock Position Sensor

INFOID:0000000006222220

Transfer lock position sensor detects engagement status of lock sleeve and transmits signal to transfer control unit.


## Transfer Fluid Temperature Sensor

INFOID:00000000006222221

- Transfer fluid temperature sensor measures temperature of transfer fluid.
- This sensor uses a thermistor and its electrical resistance varies as the temperature varies. The electrical resistance decreases as the temperature increases.

# [TRANSFER: ATX90A] STRUCTURE AND OPERATION

Sectional View INFOID:0000000006222222



- Rear companion flange
- Ball ramp lever
- 7. Clutch
- 10. Hi-Lo sleeve
- 13. Planetary carrier assembly
- 16. Transfer rotary position sensor
- 19. Actuator shaft

- 2. Main shaft
- 5. Ball lamp lever
- 8. Sprocket
- 11. Sun gear
- 14. Internal gear
- Front shaft flange 17.
- 20. Cam

- 3. Rear case
- 6. Piston
- 9. Lock sleeve
- 12. Front case
- 15. Shift fork
- 18. Drive chain
- 21. Transfer control actuator

Torque Split Mechanism

**CONTROL DIAGRAM** 

INFOID:0000000006222223

Α

В

C

DLN

Е

Н

K


M

Ν

0

Р

**DLN-13** Revision: 2010 May 2011 QX56



#### DESCRIPTION

- Ball ramp lever operates in the direction of main shaft axis according to rotation of actuator shaft and presses piston. Pressure is applied to each clutch and torque is transmitted.
- Shift fork operates in the direction of main shaft axis according to rotation of actuator shaft and performs engagement and disengagement to Hi-Lo sleeve and lock sleeve of main shaft. Mode is switched between 4H⇔4L.

#### **AUTO MODE**

- The optimum torque distribution is electronically performed for front and rear wheels according to road conditions.
- Stable start without wheel spin is possible on slippery road conditions, such as on a snowy road.
- When road condition does not require 4WD driving, the status becomes close to rear wheel drive, which
  results in better fuel efficiency and provides FR-like steering characteristics.
- The vehicle cornering status is judged according to information from each sensor, and the optimum torque is distributed to front wheels for preventing tight-corner braking symptom.

#### NOTE:

When there is a difference of revolution speed between the front and rear wheel the shift occasionally changes to direct 4-wheel driving conditions automatically. This is not a malfunction.

#### 4H MODE

• Torque distribution for front and rear wheels is fixed and stable start is achieved while driving on an rough, sandy or snowy road.

#### **4L MODE**

- Large traction force is obtained due to low gear. High running ability and escaping ability are achieved.
- Switching from 4H mode to 4L mode is not possible when the vehicle is not stopped and A/T shift selector is not in the neutral position.

#### TORQUE DISTRIBUTION DIAGRAM

Α

В

C

DLN

Е

F


Н

M

Ν


0

Р




- 1. Main shaft
- 4. Lock sleeve
- 7. Planetary carrier assembly
- 2. Clutch
- 5. Hi-Lo sleeve
- Front shaft flange
- 3. Sprocket
- 6. Sun gear
- 9. Drive chain

#### TORQUE DISTRIBUTION FLOW



#### **OPERATION PRINCIPLE**

AUTO, 4H MODE




- 1. Main shaft
- 4. Clutch
- 7. Shift fork

- 2. Ball lamp lever
- 5. Hi-Lo sleeve
- 8. Actuator shaft

- 3. Piston
- 6. Sun gear
- 9. Transfer control actuator
- 1. Transfer control unit supplies command current to transfer motor.
- 2. Transfer motor operates and actuator shaft rotates clockwise.
- 3. Shift fork operates according to rotation of actuator shaft. Sun gear and Hi-Lo sleeve are engaged.
- 4. Ball ramp lever operates in axial direction via cam fixed on actuator shaft according to traction torque of transfer motor, presses piston, and thrusts multiple plate clutch.
- 5. Torque is transmitted to front wheels according to thrusting pressure of multiple plate clutch. **NOTE:**

Torque transmitted to the front wheel is determined according to the command current.

**4L MODE** 



- 1. Main shaft
- 4. Hi-Lo sleeve
- 7. Internal gear
- 10. Transfer control actuator
- 2. Sprocket
- 5. Sun gear
- 8. Shift fork

- 3. Lock sleeve
- 6. Planetary carrier assembly
- 9. Actuator shaft
- 1. Transfer control unit supplies command current to transfer motor.
- 2. Transfer motor operates and actuator shaft rotates counterclockwise.
- 3. Shift fork operates according to rotation of actuator shaft. Planetary carrier assembly and Hi-Lo sleeve are engaged.

Α

В

C

DLN

Е

F

G

Н

1

J

L

Κ

M

Ν

0

Р

# SYSTEM 4WD SYSTEM

## 4WD SYSTEM: System Description


INFOID:0000000006222224

[TRANSFER: ATX90A]

- In AUTO mode, distribution of traction force is controlled from 2WD status (0:100) to 4WD status (50:50) according to signal from each sensor and switch.
- In accordance with fail-safe function, when system is malfunctioning, 4WD warning lamp on combination meter turns ON and 4WD control stops. For fail-safe function, refer to <a href="DLN-20">DLN-20</a>, "4WD SYSTEM: Fail-Safe".
- When a high load status continues for transfer assembly (transfer control actuator or transfer fluid), 4WD control temporarily becomes 4H or 2WD status, according to protection function.
   NOTE:

4WD system is not malfunctioning.

#### SYSTEM DIAGRAM



#### INPUT/OUTPUT SIGNAL

It transmits/receives each signal from the following transfer control unit via CAN communication line.

Component parts	Control signal
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication line to transfer control unit.  • Vehicle speed signal (ABS)  • Stop lamp switch signal (brake signal)  • ABS operation signal  • VDC operation signal  • TCS operation signal
ECM	Transmits the following signals via CAN communication line to transfer control unit.  • Accelerator pedal position signal  • Engine speed signal  • Engine torque signal

Component parts	Control signal
ТСМ	Transmits the following signals via CAN communication line to transfer control unit.  • Shift position signal  • Gear position signal  • Output shaft revolution signal
Steering angle sensor	Transmits the following signals via CAN communication line to transfer control unit.  • Steering angle sensor signal
Combination meter	Receives the following signals via CAN communication line from transfer control unit.  • 4WD warning lamp signal  • ATP warning lamp signal  • 4WD mode indicator signal

#### 4WD SHIFT SWITCH AND 4WD SHIFT INDICATOR LAMP

4WD shift switch	4WD shift indicator lamp (in Information display)	4WD shift procedure	
AUTO			
RUTO 4H PUSH PY	AUTO	Start the engine.     Turn the 4WD shift switch.	
JPDIE0230ZZ	JPDIE0234ZZ	NOTE:	
4H		Mode can be switched between AU- TO⇔4H while driving straight.	
NUTO 4H PUSH X	<b>▲4HI</b>		
JPDIE0231ZZ	JPDIE0235ZZ		
JPDIE0231ZZ  JPDIE0233ZZ	✓4HI ↓ ↑  ✓4L0  JPDIE0236ZZ  (Blinking)*1*2	<ol> <li>Start the engine.</li> <li>Never drive the vehicle.</li> <li>Shift A/T shift selector to N position.</li> <li>Press and rotate 4WD shift switch while depressing brake pedal.</li> <li>CAUTION:</li> <li>4WD mode does not switch when 4WD shift switch is operated while the vehicle is running or A/T shift selector is</li> </ol>	
4WD status: 4H⇔4L 4L		shifted to any position other than neutral.	
AUTO 4H PUSH FY	<b>▼4L0</b>		
JPDIE0233ZZ	JPDIE0237ZZ		

<sup>\*1:</sup> Blinking 2 times/1 second

<sup>\*2: &</sup>quot;4HI" and "4LO" blink alternately.

#### **SYSTEM**

#### < SYSTEM DESCRIPTION >

4WD Warning Lamp

- Turns ON when there is a malfunction in 4WD system. 4WD warning lamp indicates the vehicle is in fail-safe mode.
- Also turns ON when ignition switch is turned ON, for the purpose of lamp check. Turns OFF approximately
  for 1 second after the engine starts if system is normal.

Condition	4WD warning lamp	
Lamp check	Turns ON when ignition switch is turned ON. Turns OFF approx. 1 second after the engine start.	
4WD system malfunction	ON	
Protection function is activated due to heavy load to transfer assembly. (4WD system is not malfunctioning.)	Quick blinking: 2 times/second (Blinking in approx. 1 minute and then turning OFF)	
Large difference in diameter of front/rear tires	Slow blinking: 1 time/2 seconds (Continuing to blink until turning ignition switch OFF)	
Other than above (system normal)	OFF	

#### ATP Warning Lamp

When the A/T shift selector is in P position, the vehicle may move if the transfer case in neutral. ATP warning lamp is turned on to indicate this condition to the driver.

#### CONDITION FOR OPERATE WARNING BUZZER

For preventing an incorrect operation during 4H⇔4L switching, warning buzzer sounds from inside of transfer control unit and warns the driver, when certain conditions are satisfied.

	Condition					
4WD shift status	4WD shift status A/T shift selector Engine speed					
	N range	350 – 1.600 rpm	OFF			
4H⇔4L	in range	Under 350 rpm or over 1.600 rpm	ON			
	Except N range	Always	ON			

## 4WD SYSTEM: Fail-Safe

INFOID:0000000006303692

[TRANSFER: ATX90A]

- If any malfunction occurs in 4WD electrical system, and control unit detects the malfunction, 4WD warning lamp on combination meter turns ON to indicate system malfunction.
- When 4WD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque).

# **DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)**

< SYSTEM DESCRIPTION >

# DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

#### **CONSULT-III Function**

INFOID:0000000006222226

Α

В

DLN

Е

Н

Ν

Р

[TRANSFER: ATX90A]

#### **FUNCTION**

CONSULT-III can display each diagnostic item using the diagnostic test modes as follows.

Diagnostic test mode	Function	
ECU Identification	Transfer control unit part number can be read.	
Self Diagnostic Result	Self-diagnostic results can be read and erased quickly.*	
Data Monitor	Input/Output data in the transfer control unit can be read.	
Work Support	This mode enables a technican to adjust some devices faster and more accurately by following the indications on the CONSULT-III	

<sup>\*:</sup> The following diagnosis information is erased by erasing.

• DTC

#### **ECU IDENTIFICATION**

Transfer control unit part number can be read.

#### SELF DIAGNOSTIC RESULT

Refer to DLN-29, "DTC Index".

When "0" is displayed on self-diagnosis result.

The system is presently malfunctioning.

When except "0" is displayed on self-diagnosis result.

System malfunction in the past is detected, but the system is presently normal.

#### NOTE:

Each time when ignition switch is turned OFF to ON, numerical number increases in  $1\rightarrow2\rightarrow3...110\rightarrow111$ . When the operation number of times exceeds 111, the number do not increase and "111" is displayed until self-diagnosis is erased<sup>\*</sup>.

\*: For "U1000" and "U1010", the maximum value is "39".

#### DATA MONITOR

X:Applicable

	SELECT MC	ONITOR ITEM		
Monitor item (Unit)	ECU INPUT SIGNALS	MAIN SIG- NALS	Remarks	
4WD MODE [BOTNG/SWTNG/4L/4H/AUTO]		Х	Control status of 4WD mode is displayed.	
2WD SW [On/Off]	Х		4WD shift switch (2WD) is not equipped, but it is displayed.	
AUTO SW [On/Off]	X		4WD shift switch signal (AUTO) is displayed.	
4H SW [On/Off]	X		4WD shift switch signal (4H) is displayed.	
4L SW [On/Off]	X		4WD shift switch signal (4L) is displayed.	
T/M RANGE [D/N/R/P]	Х		A/T shift selector position via CAN communication line is displayed.	
N RANGESW [On/Off]	х		A/T shift selector position (N) via CAN communication line is displayed.	
R RANGE SW [On/Off]	х		A/T shift selector position (R) via CAN communication line is displayed.	
ING SW [On/Off]	X		Ignition switch status is displayed.	
TCS OPER [On/Off]	Х		TCS operation status via CAN communication line is displayed.	
VDC OPER [On/Off]	Х		VDC operation status via CAN communication line is displayed.	

# DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT) RIPTION > [TRANSFER: ATX90A]

# < SYSTEM DESCRIPTION >

	SELECT MC	NITOR ITEM		
Monitor item (Unit)	ECU INPUT SIGNALS	MAIN SIG- NALS	Remarks	
ABS OPER [On/Off]	Х		ABS operation status via CAN communication line is displayed.	
SAND MODE IND [On/Off]			This indicator is not equipped, but it is displayed.	
ROCK MODE IND [On/Off]			This indicator is not equipped, but it is displayed.	
SNOW MODE IND [On/Off]			This indicator is not equipped, but it is displayed.	
ONROAD MODE IND [On/Off]			This indicator is not equipped, but it is displayed.	
SAND MODE SW [On/Off]	Х		This switch is not equipped, but it is displayed	
ROCK MODE SW [On/Off]	Х		This switch is not equipped, but it is displayed	
SNOW MODE SW [On/Off]	Х		This switch is not equipped, but it is displayed	
ONROAD MODE SW [On/Off]	X		This switch is not equipped, but it is displayed	
HI/LO POSI SEN 3 [On/Off]	Х		Transfer Hi-Lo position sensor (3) status is dis played.	
HI/LO POSI SEN 1 [On/Off]	Х		Transfer Hi-Lo position sensor (1) status is dis played.	
LOCK POSI SEN [OPEN/LOCK/BAT/UNLEAN/HI TEMP/ERROR/GND]	Х		Transfer lock position sensor signal is displayed.	
ATP IND [On/Off]			Control status of ATP warning lamp is displayed.	
4WD FAILLAMP [On/Off]		Х	Control status of ATP warning lamp is displayed.	
4WD MODE IND [4L/LOCK/AUTO]		Х	Control status of 4WD mode indicator lamp is displayed. (LOCK means 4H of 4WD mode)	
MOTOR DRIVE B [HI/LO/PWM]		Х	Driving status of transfer motor is displayed. (Reverse side)	
MOTOR DRIVE A [HI/LO/PWM]		Х	Driving status of transfer motor is displayed. (Drive side)	
FLUID TEMP SEN [V]	Х		Temperature of transfer fluid is displayed.	
MOTOR TEMP [V]	Х		Temperature of transfer motor is displayed.	
C/U POWER SUP [V]	Х		Power supply voltage value of transfer control unit is displayed.	
MOTOR POWER SUP [V]	Х		Power supply voltage value of transfer motor unit is displayed.	
ROTARY POSI SEN [%]	Х		Transfer rotary position sensor signal is displayed.	
THRTL POSI SEN [%]	Х	Х	Throttle opening status via CAN communication line is displayed.	
AT R SPEED [km/h]	Х		Output shaft revolution speed via CAN communication line is displayed.	
T/M GEAR [0 - 7]	х		Current transmission gear via CAN communication line is displayed.	
COMPR VHCL SPEED [km/h]		Х	Vehicle speed calculated by transfer control unit is displayed.	
VHCL/S SEN-FR [km/h]	Х		Wheel speed (front) average calculated by transfer control.	

# DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT) RIPTION > [TRANSFER: ATX90A]

# < SYSTEM DESCRIPTION >

	SELECT MO	NITOR ITEM		
Monitor item (Unit)	ECU INPUT SIGNALS	MAIN SIG- NALS	Remarks	
VHCL/S SEN-RR [km/h]	Х		Wheel speed (rear) average calculated by transfer control.	
ENG SPEED [rpm]	Х		Engine status via CAN communication line is displayed.	
INTERNL SPEED SEN [count]	Х		Transfer internal speed sensor status is displayed.	
TRANSFER TORQUE [Nm]		Х	Commanded transfer communication torque is displayed.	
UNIT PARAMETER [A1 - A9, B1 - B9, C1 - C9, D1 - D9, E1 - E9, F1 - F9, G1 - G9, H1 - H9, J1 - J9]			Unit parameter of transfer recognized by transfer control unit is displayed.	

#### **WORK SUPPORT**

Function	Description
UNIT CHARACTERISTIC WRITE	Writes the unit parameter of transfer to transfer control unit.
START CALIBRATION	Perform initial calibration of transfer control unit.
LOCK SLEEVE SENSOR* INITIALIZE	Format learning the transfer lock position sensor written to transfer control unit.
LOCK SLEEVE SENSOR* LEARNING	Perform learning the transfer lock position sensor.
OIL DETERIORATION INFO RESET	Format the transfer fluid viscosity written to transfer control unit.

<sup>\*: &</sup>quot;LOCK SLEEVE SENSOR" means transfer lock position sensor.

Revision: 2010 May **DLN-23** 2011 QX56

С

Α

В

DLN

Е

\_

Н

Κ

L

M

Ν

0

P

[TRANSFER: ATX90A]

< ECU DIAGNOSIS INFORMATION >

# **ECU DIAGNOSIS INFORMATION**

# TRANSFER CONTROL UNIT

Reference Value

#### VALUES ON THE DIAGNOSIS TOOL

Monitor item		Condition	Value/Status		
	4WD is booting		BOTNG		
		4WD mode is switching	SWTNG		
4WD MODE	IGN ON	4WD mode: 4L	4L		
		4WD mode: 4H	4H		
		4WD mode: AUTO	AUTO		
2WD SWITCH *1	Always		OFF		
ALITO OMITOLI	4WD shift switch: A	ито	ON		
AUTO SWITCH	4WD shift switch: 4l	H or 4L	OFF		
411.014/17011	4WD shift switch: 4l	Н	ON		
4H SWITCH	4WD shift switch: A	UTO or 4L	OFF		
AL CIMITOU	4WD shift switch: 4I	L	ON		
4L SWITCH	4WD shift switch: A	UTO or 4H	OFF		
	A/T shift selector: D		D		
T/M RANGE	A/T shift selector: N		N		
I/W RANGE	A/T shift selector: R	R			
	A/T shift selector: P	A/T shift selector: P			
N RANGE SW	A/T shift selector: N	ON			
N RANGE SW	A/T shift selector: E	xcept N	OFF		
R RANGE SW	A/T shift selector: R		ON		
K KANGE SW	A/T shift selector: E	xcept R	OFF		
IGN SW	IGN SW: ON		ON		
1014 377	IGN SW: OFF	OFF			
TCS OPER SW	TCS is operating	ON			
100 OF LICOW	TCS is not operating	OFF			
VDC OPER SW	VDC is operating	VDC is operating			
VDO OF ER OW	VDC is not operatin	VDC is not operating			
ABS OPER SW	ABS is operating	ON			
7.50 0. 2. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.	ABS is not operating	ABS is not operating			
SAND MODE IND*2	Always		OFF		
ROCK MODE IND*2	Always		OFF		
SNOW MODE IND*2	Always		OFF		
ONROAD MODE IND*2	Always		ON		
SAND MODE SW*3	Always		OFF		
ROCK MODE SW*3	Always		OFF		
SNOW MODE SW*3	Always		OFF		
ONROAD MODE SW*3	Always		ON		

[TRANSFER: ATX90A]

# < ECU DIAGNOSIS INFORMATION >

Monitor item	Condition	Value/Status
	4WD mode: AUTO or 4H	ON
II-LO POSI SEN 3	4WD mode: Shifting	OFF
	4WD mode: 4L	OFF
	4WD mode: AUTO or 4H	ON
HI-LO POSI SEN 1	4WD mode: Shifting	ON
	4WD mode: 4L	OFF
	When lock sleeve is opening	OPEN
	When lock sleeve locking	LOCK
	When transfer lock position sensor signal circuit is short. (Battery short)	ВАТ
LOCK POSI SEN	When transfer lock position sensor is unlearned.	UNLEAN
	When the temperature of transfer lock position sensor is high.	HI TMP
	When transfer lock position sensor is malfunctioning.	ERROR
	When transfer lock position sensor signal circuit is short. (Ground short)	GND
ATP IND	ATP lamp: ON	ON
	ATP lamp: OFF	OFF
4WD FAIL LAMP	4WD warning lamp: ON	ON
TVID I AIL LAWIF	4WD warning lamp: OFF	OFF
	4WD shift switch: AUTO	AUTO
4WD MODE IND	4WD shift switch: 4H	LOCK
	4WD shift switch: 4L	4L
	When transfer motor is driving in reversal. (100% duty controlled)	HI
MOTOR DRIVE B	When transfer motor is driving or stopping.	LO
	When transfer motor is driving in reversal. (PWM output)	PWM
	When transfer motor is driving. (100% duty controlled)	HI
MOTOR DRIVE A	When transfer motor is driving in reversal or stopping.	LO
	When transfer motor is driving. (PWM output)	PWM
FLUID TEMP SE	The temperature of transfer fluid is 20 – 80 °C.	Approx. 1.1 – 0.3 V
MOTOR TEMP	The temperature of transfer motor is 20 – 80 °C.	Approx. 1.1 – 0.3 V
C/U POWER SUP	Always	Battery voltage
MOTOR POWER SUP	Always	Battery voltage
ROTARY POSI SEN	4WD mode: AUTO  A/T shift selector: D  Depress the accelerator pedal several times.	Value is changing
THRTL POS SEN	When depressing accelerator pedal (Value rises gradually in response to throttle position)	0 – 100 %
	Vehicle stopped	0.00 km/h (0.00 mph)
AT R SPEED	Vehicle driving (4WD mode: AUTO)  CAUTION: Check air pressure of tire under standard condition.	Approx. equal to the indication on speedometer (inside of $\pm 10$ %)
Г/M GEAR	A/T shift selector: D Vehicle driving	1 2 3 4 5
		6 7


[TRANSFER: ATX90A]

#### < ECU DIAGNOSIS INFORMATION >

Monitor item		Condition	Value/Status
	Vehicle stopped		0.00 km/h (0.00 mph)
COMPR VHCL SPEED	Vehicle driving CAUTION: Check air pressure of ti	Approx. equal to the indication on speedometer (inside of ±10 %)	
	Vehicle stopped		0.00 km/h (0.00 mph)
VHCL/S SEN-FR	Vehicle driving CAUTION: Check air pressure of ti	ire under standard condition.	Approx. equal to the indication on speedometer (inside of ±10 %)
	Vehicle stopped		0.00 km/h
VHCL/S SEN-RR	Vehicle driving CAUTION: Check air pressure of ti	Approx. equal to the indication on speedometer (inside of ±10 %)	
ENGINE SPEED	Engine running		Approx. equal to the indication on tachometer (inside of ±10 %)
INTRNL SPEED SEN	4WD mode: AUTO A/T shift selector: D	Depress the accelerator pedal several times.	Value is changing
	4WD shift switch: AUTO	0 - 2250 N⋅m	
TRANSFER TORQUE	4WD shift switch: 4H	0 - 2250 N⋅m	
	4WD shift switch: 4L	0 Nm	
UNIT PARAMETER	Always		A1 - A9 B1 - B9 C1 - C9 D1 - D9 E1 - E9 F1 - F9 G1 - G9 H1 - H9 J1 - J9

<sup>\*1: 4</sup>WD shift swich (2WD) is not equipped, but it is displayed.

#### **TERMINAL LAYOUT**



#### PHYSICAL VALUES

	nal No. color)	L)escription		Condition		Value (Approx.)
+	-	Signal name	Input/ Output	Condition		Value (Approx.)
			Engine ru	Engine run-	4WD mode: AUTO or 4H	0 V
6	Ground	Hi-Lo position sensor 1	Input/	/ Never	4WD mode: Shifting	0 V
(BR)			Output	drive the vehicle.)	4WD mode: 4L	5 V

<sup>\*2:</sup> This indicator is not equipped, but it is displayed.

<sup>\*3:</sup> This switch is not equipped, but it is displayed.

[TRANSFER: ATX90A]

# < ECU DIAGNOSIS INFORMATION >

		OIO II OI				
	nal No. color)	Description			Condition	Value (Approx.)
+	-	Signal name	Input/ Output			value (Approx.)
7 (Y)	Ground	Transfer fluid tempera- ture sensor power supply	Input	Engine running		0 – 5V
9 (G)	Ground	Transfer internal speed sensor (GND)	_		Always	0 V
10 (Y/G)	Ground	Transfer internal speed sensor (IMP)	Input	IGN ON	Transfer motor driving	400 μ Sec/div 2V/div JPDIE0267GB
11					4WD shift switch: 4L	Battery voltage
(V)	Ground	4WD shift SW (4Lo)	Input	IGN ON	4WD shift switch: Except 4L	0 V
12 (L)	_	CAN-H	Input/ Output		_	_
13 (P)	_	CAN-L	Input/ Output		_	_
14					4WD shift switch: AUTO	Battery voltage
(W/R)	Ground	4WD shift SW (AUTO)	Input	IGN ON	4WD shift switch: Except AUTO	0 V
15 (P/B)	Ground	Transfer rotary position sensor (PWM)	Input	IGN ON		400 μ Sec/div 2V/div JPDIE0268GB
16 (LG)	Ground	Transfer rotary position sensor (GND)	_		Always	0 V
17		Transfer lock position			IGN ON	5V
(W/L)	Ground	sensor power supply	Input	10 seconds or more later after ignition switch turned OFF		0V
18		Transfer rotary position			IGN ON	5V
(BR/Y)	Ground	sensor power supply	Input	10 seconds or more later after ignition switch turned OFF		0V
20 (GR)	Ground	Transfer control unit pow- er supply	Input	Always		Battery voltage
			Engine	Engine running	4WD mode: AUTO or 4H	0 V
25 (P/L)	Ground	Hi-Lo position sensor 3	Input/ Output	(Never drive the	4WD mode: Shifting 4WD mode: 4L	5 V 5 V
		_ ,		venicie.)		0 – 5V
28 (W)	Ground	Transfer motor tempera- ture sensor power supply	Input		IGN OFF	
(**)		12.0 CO.IGOI POWOI Supply		IGN OFF		0V

[TRANSFER: ATX90A]

#### < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description			Condition	Value (Access)							
+	-	Signal name	Input/ Output		Condition	Value (Approx.)							
29 (LG/R)	Ground	Hi-Lo position sensor 2	Input/ Output	Engine running (Never drive the vehicle.)	Always	0 V							
30 (R/B)	Ground	Transfer lock position sensor (GND)	_		Always	0 V							
31 (L/O)	Ground	Transfer internal speed sensor (DIR)	Input	IGN ON	When changing the transfer motor rotation direction.	400 μ Sec/div 2V/div JPDIE0269GB							
32	Ground	IGN SW	Input		IGN ON	Battery voltage							
(BR/R)	Giodila	IGN SW	IIIput	0V									
25					4WD shift switch: 4H	Battery voltage							
35 (R)	Ground	4WD shift SW (4H)	Input	IGN ON	4WD shift switch: Except 4H	0 V							
36 (L/R)	Ground	Transfer fluid tempera- ture sensor (GND)	_		Always	0 V							
38 (G/O)	Ground	Transfer lock position sensor signal	Input		IGN ON	400 μ Sec/div 2V/div JPDIE0268GB							
39	Ground	Transfer internal speed	Input		IGN ON	8 V							
(R/W)	Ground	sensor power supply	IIIput		IGN OFF	0V							
41 (W/R)	Ground	Transfer control actuator power supply	Input		Always	Battery voltage							
43 (G/R)	Ground	Motor drive B	Input/ Output	Tra	nsfer motor driving	0V - Battery voltage							
44 (B)	Ground	GND	_		Always 0 V								
45 (G/Y)	Ground	Motor drive A	Input/ Output	Tra	Transfer motor driving 0V - Battery voltage								
46 (B)	Ground	Transfer control actuator (GND)	_	Always 0 V									

#### **CAUTION:**

When using circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.

Fail-Safe

• If any malfunction occurs in 4WD electrical system, and control unit detects the malfunction, 4WD warning lamp on combination meter turns ON to indicate system malfunction.

• When 4WD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque).

< ECU DIAGNOSIS INFORMATION >

# **DTC Inspection Priority Chart**

INFOID:0000000006222229

[TRANSFER: ATX90A]

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)	В
1	U1000 CAN COMM CIRCUIT     U1010 CONTROL UNIT (CAN)	
2	<ul> <li>P1802 CONTROL UNIT 1</li> <li>P1803 CONTROL UNIT 2</li> <li>P1804 CONTROL UNIT 3</li> <li>P1809 CONTROL UNIT 4</li> <li>P180C SEN POWER SUPPLY (5V)</li> <li>P180E SEN POWER SUPPLY (8V)</li> <li>P1811 BATTERY VOLTAGE</li> <li>P181B INCOMP SELFSHUT</li> <li>P181C MOTOR POWER SUPPLY</li> <li>P181F INCOMP CALIBRATION</li> </ul>	DL
3	<ul> <li>P1807 VECL SPEED SEN-AT</li> <li>P1808 VECL SPEED SEN-ABS</li> <li>P1816 PNP SW/CIRC</li> <li>P181E ST ANGLE SEN SIG</li> <li>P1820 ENGINE SPEED SIG</li> <li>P1829 THROTTLE POSI SEN</li> <li>P1830 ABS OP SIG</li> <li>P1831 VDC OP SIG</li> <li>P1832 TCS OP SIG</li> </ul>	G H
4	<ul> <li>P180D ROTARY POSITION SEN</li> <li>P1813 4WD MODE SW</li> <li>P181A MOTOR TEMP SEN</li> <li>P1826 OIL TEMP SEN</li> <li>P182A HI-LO POSITION SEN</li> <li>P182B LOCK POSITION SEN</li> </ul>	
5	P180F MOTOR SYSTEM P1817 SHIFT ACTUATOR	

**DTC Index** INFOID:0000000006222230

DTC	Display Items	Reference
P1802	CONTROL UNIT 1	DLN-51, "DTC Logic"
P1803	CONTROL UNIT 2	DLN-51, "DTC Logic"
P1804	CONTROL UNIT 3	DLN-51, "DTC Logic"
P1807	VHCL SPEED SEN-AT	DLN-52, "DTC Logic"
P1808	VHCL SPEED SEN-ABS	DLN-53, "DTC Logic"
P1809	CONTROL UNIT 4	DLN-51, "DTC Logic"
P180C	SEN POWER SUPPLY (5V)	DLN-54, "DTC Logic"
P180D	ROTARY POSITION SEN	DLN-57, "DTC Logic"
P180E	SEN POWER SUPPLY (8V)	DLN-59, "DTC Logic"
P180F	MOTOR SYSTEM	DLN-61, "DTC Logic"
P1811	BATTERY VOLTAGE	DLN-64, "DTC Logic"
P1813	4WD MODE SW	DLN-67, "DTC Logic"
P1816	PNP SW/CIRC	DLN-69, "DTC Logic"
P1817	SHIFT ACTUATOR	DLN-70, "DTC Logic"
P181A	MOTOR TEMP SEN	DLN-72, "DTC Logic"
P181B	IMCOMP SELFSHUT	DLN-74, "DTC Logic"

**DLN-29** Revision: 2010 May 2011 QX56

L

Ν

0

Р

[TRANSFER: ATX90A]

# < ECU DIAGNOSIS INFORMATION >


DTC	Display Items	Reference
P181C	MOTOR POWER SUPPLY	DLN-76, "DTC Logic"
P181E	ST ANGLE SEN SIG	DLN-77, "DTC Logic"
P181F	INCOMP CALIBRATION	DLN-78, "DTC Logic"
P1826	OIL TEMP SEN	DLN-80, "DTC Logic"
P1820	ENGINE SPEED SIG	DLN-79, "DTC Logic"
P1829	THROTTLE POSI SEN	DLN-82, "DTC Logic"
P182A	HI-LO POSITION SEN	DLN-83, "DTC Logic"
P182B	LOCK POSITION SEN	DLN-85, "DTC Logic"
P1830	ABS OP SIG	DLN-88, "DTC Logic"
P1831	VDC OP SIG	DLN-89, "DTC Logic"
P1832	TCS OP SIG	DLN-90, "DTC Logic"
U1000	CAN COMM CIRCUIT	DLN-91, "DTC Logic"
U1010	CONTROL UNIT (CAN)	DLN-92, "DTC Logic"


# **WIRING DIAGRAM**

# **4WD SYSTEM**

Wiring Diagram

Α





# **4WD SYSTEM**

< WIRING DIAGRAM > [TRANSFER: ATX90A]

	А
E59 TRANSFER CONTROL UNIT TH40FW-NH TH40FW-NH Signal Name [Specification] Signal Name [Specification] NTERNAL SPEED SEN MIP ALTO SWINDERLY NOTALY POSITION SEN SUPPLY NOTALY POSITION SEN SUPPLY NOTALY POSITION SEN SUPPLY TRANSFER FLUID TEMP SEN SUPPLY NOTALY POSITION SEN SUPPLY H-LO POSITION SEN SUPPLY LOCK POSITION SEN SUPPLY LOCK POSITION SEN SUPPLY TRANSFER FLUID TEMP SEN SUPPLY LOCK POSITION SEN SUPPLY	В
1   6/V   2   5   5   5   5   5   5   5   5   5	DL
Signal Name   Specification    Specification    Signal Name   Specification    Specification	E
Connector No.   E36   Connector No.   E36   Connector Name   Ass ACTUATION AND RECIPRIC UNIT CONNECTOR OF THE PARTY   Connector Type   SAZ42FB-SAZ4   Connector No.   Connec	G
	ı
FIST	J K
Commetter   Comm	L
ETW WIRE TO WIRE  TH32MW-NH  14 6 6 7 8 9 10 1112 13 14 15 16  20 21 22 23 24 25 20 27 20 29 30 31 32  Signal Name (Specification)  E13  E13  E13  E13  Signal Name (Specification)  Signal Name (Specification)  Signal Name (Specification)  Signal Name (Specification)	M
Connector Name   Color	0
JCDWM1071GB	Р

Revision: 2010 May **DLN-33** 2011 QX56

43 \		52 BR/W –	53 BR/Y -	54 GR/L -	- M 09	61 B -	62 R -	H	64 SHIELD –	91 BR –	F	H	95 G/R -	97 R –	- e e e e e e e e e e e e e e e e e e e	100 W/R -																																			
E109	AMDE TO MADE		TH80MW-CS16-TM4			9	S S S S S S S S S S S S S S S S S S S		10 10 10 10 10 10 10 10 10 10 10 10 10 1	88 82 88 82 86 86 86 86 86 86 86 86 86 86 86 86 86			oignal Name [opecification]	1	_		-	1				-	1	1	1	1	1	1	1	-	1	-	1		,	,	-	_	_	-	-	1	- ~				1		1	-	-
Connector No.	N	nnector Name	Connector Type		修	Į.	į					Terminal Color	No. of Wire	1 L	2 L/W	3 R/B	4 L	γ λ	7 W/G	8 P/B	9 M/B	T 01	11	12 P	13 P/B	┝	┝	16 SB	┝	18 BR	H	20 BR/Y	H	22 L	23 Y	24 L/W	26 L	27 L/W	Н	29 R/W	H	H	32 GR/R	t	35	ľ	t	t	ľ	F	H
SENSOR POWER SUPPLY (APP SENSOR 1)	BATTERY CURRENT SENSOR	BATTERY TEMPERATURE SENSOR	SENSOR GROUND	IGNITION SWITCH	FUEL PUMP CONTROL MODULE (FPCM) CHECK	EVAP CONTROL SYSTEM PRESSURE SENSOR	REFRIGERANT PRESSURE SENSOR	CAN COMMUNICATION LINE	ICC BRAKE SWITCH	SENSOR GROUND	CAN COMMUNICATION LINE	POWER SUPPLY FOR ECM (BACK-UP)	STOP LAMP SWITCH	ECM COMMUNICATION LINE	ECM RELAY (SELF SHUT-OFF)	-	ECM COMMUNICATION LINE	ENGINE SPEED SIGNAL OUTPUT	POWER SUPPLY FOR ECM	POWER SUPPLY FOR ECM	THROTTLE CONTROL MOTOR POWER SUPPLY	ECM GROUND	ECM GROUND			E94	Law CT Law	WIRE TO WIRE	M06MW-LC					1 2 3	4 5 6			Simal Name Specification	orginal marrie Lopecinication	1	1	1	-		1						
9/M	>	9	R/Y	SB	R/W	L/Y	0/B	٦	λ/9	œ	Ь	_	M/B	R/W	5/7	GR/R	W	G/B	W	W	0	В	В			Γ		Connector Name	Sonnector Type	  -			7					-	of Wire	J/5	۵	>	~	G/R	B/8						
137	138	139	140	141	142	143	144	146	147	120	151	126	158	161	163	165	166	169	171	172	173	174	175			Connector No.		Connec	Connect		修	ŧ	2					Terminal	No.	-	2	က	4	LC:							
JEM JEGO	TIMIT TOUTING GERALD	I KAINSPER CONTROL UNIT	M06FW-LC				L	41 43 45	44 46			3	Signal Name [Specification]	MOTOR SUPPLY	MOTOR DRIVE B	GND	MOTOR DRIVE A	MOTOR GND			E80	Mod	ECIM	MAB55FB-MEB10-LH				102 (3) (3) (4) (4)	110 III 12 II 12 III 12 II 12	201 201 101 101 101 101 101 101 101 101				olgnar Name Lopecincarion	FUEL INJECTOR DRIVER POWER SUPPLY	FUEL INJECTOR DRIVER POWER SUPPLY	FUEL RETURN VALVE	ECM GROUND	ECM GROUND	EVAP CANISTER VENT CONTROL VALVE	VVEL ACTUATOR MOTOR RELAY ABORT SIGNAL (VVEL CONTROL MODULE)	THROTTLE CONTROL MOTOR RELAY	FUEL PUMP CONTROL MODULE (FPCM)	ACCEL FRATOR PEDAL POSITION SENSOR 2	ICC STEFRING SWITCH	SENSOR GROUND (APP SENSOR 2)	SENSOB GROUND	SENSOR POWER SUPPLY	SENSOR POWER SUPPLY	ŢF	ACCELERATOR PEDAL POSITION SENSOR 1
4WD SYSTEM	N	cor Name	Connector Type				7					al Color	of Wire	W/R	G/R	В	G/Y	В			tor No.	No.	cor Name	Connector Type				_					al Color	of Wire	œ	SB	9	В	В	٨	BR/W	ν/κ	S.	c	)  -	/d	-	. M	SB	M/A	Н
4WD SY		Connec	Connect	(	医	Ę	4					Terminal	No.	41	43	44	42	46			Connector No.		Connec	Connect	ا	13	ť	Ć					Terminal	No	Ξ	112	113	114	115	120	122	123	125	126	128	129	130	131	133	134	136

JCDWM1072GB

# **4WD SYSTEM**

	Α
V   C   C   C   C   C   C   C   C   C	В
1   V     2   2   1   1   1   1   1   1   1	DLN
ation]	Е
FEL RHOSFCY RHOSFCY Signal Name [Specification] Signal Name [Specification] Signal Name [Specification]  FEL  TRANSFER H-LO POSITION SENSOR PEZOSFB  AT ASSEMBLY RK10FG  Signal Name [Specification]  Signal Name [Specification]	F
	G
Connector None  Connector Type  Terminal Color  No. of Wire  1 BR/W  2 LG  2 LG  3 P./B  Connector Name Connect	Н
SENSOR Cation]	I
F57  Transfer FLUD Teaherarture Sensor  E02FGV-RS  F40  Transfer LOCK POSITION SENSOR RH03FB  Signal Name [Specification]  Signal Name [Specification]	J
	K
1   8   1   2   2   2   2   2   2   2   2   2	L
1   1   2   2   1	M
STEM   Name	N
AWD & Connector	0
JCDWM1073GB	Р

Revision: 2010 May **DLN-35** 2011 QX56

24	MAA	1   L/W
Connector No. M30 Connector Name STEERING ANGLE SENSOR Connector Type THOSPW-NH  1 2 4	Terminal   Color   Signal Name [Specification]   Color   Connector Name   Commercial   Connector Name   Con	Terminal   Color   Signal Mane [Specification]     1
Connector No.   M3	Terminal   Color   No. of Wire   Signal Name [Specification]   Color   No. of Wire   Color	gnal Name [Specific
4WD SYSTEM Connector No. F103 Connector Name WIRE TO WIRE Connector Type MOGFW-LC  A.S. 3 2 1 6 5 4		Terminal Color No. of Wire Signal Name (Specification)  1 - NO. of Wire No. of Wire Signal Name (Specification)  2 - RATH  4 - RATH  5 - GAN-H  5 - GAN-H  7 - REV LAMP RLY  10 - START RLY  10 - GAND

JCDWM1074GB

[TRANSFER: ATX90A]

[TRANSFER: ATX90A]

Α

В

С

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

Р

-	-	-	-	-	-								-	1	-		1
Я	۸	0/7	BR/W	BR/Y	GR/L	W	В	g	В	SHIELD	BR	L/W	Y/B	L/R	ч	0/L	M/B
42	43	51	52	53	54	09	61	62	63	64	91	92	94	92	6	98	100

'EM	ı	WIRE TO WIRE	TH80FW-CS16-TM4		Signal Name [Specification]	1	1	1	1	1	1 1	1	1	-	- [With ICC]	- [Without ICC]	ı	1	1	1	10 1	1 1		1	1	-	-	_	1	1	1	1	1	1	1	1	1	1	1	1
TSYS ™	Ī	Name	Type		Color of Wire	>	M/	R/B	-	× ,	5 a	M/B	-	7	Ь	œ	P/B	æ	0/ر	27 (	1 8	<u>د</u> د	2 2	>	_	Υ	L/W	٦	L/W	0	R/W	٥/٦	>	GR/R	-	إ ٢	0/8	<u>ک</u>	5 5	2
4WD	200	Connector	Connector	是 H.S.	Terminal	-	2	3	4	2	- α	6	10	11	71	12	13	14	12	9 5	2 0	0 0	20	21	22	23	24	56	27	28	29	30	31	32	34	32	36	37	8 8	₽:

JCDWM1075GB

### DIAGNOSIS AND REPAIR WORK FLOW

[TRANSFER: ATX90A]

< BASIC INSPECTION >

# **BASIC INSPECTION**

## DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

### **DETAILED FLOW**

## ${f 1}$ . INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing <u>DLN-39</u>, "<u>Diagnostic Work Sheet</u>" and reproduce symptoms as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

#### **CAUTION:**

Customers are not professional. Never guess easily like "maybe the customer means that...," or "maybe the customer mentions this symptom".

>> GO TO 2.

## 2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by interview. Also check that the symptom is not caused by fail-safe function. Refer to <a href="DLN-28">DLN-28</a>. "Fail-Safe".

### **CAUTION:**

When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.

>> GO TO 3.

# 3. PERFORM SELF-DIAGNOSIS

### (P) With CONSULT-III

Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is any DTC detected?

YES >> Record or print self-diagnosis results. GO TO 4.

NO >> GO TO 6.

## 4. RECHECK SYMPTOM

#### (P)With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Perform DTC confirmation procedures for the error detected system.

#### NOTE:

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on <u>DLN-29</u>, "DTC Inspection Priority Chart".

### Is any DTC detected?

YES >> GO TO 5.

NO >> Check harness and connectors based on the information obtained by interview. Refer to <u>GI-40</u>, "Intermittent Incident".

# 5.REPAIR OR REPLACE ERROR-DETECTED PARTS

- · Repair or replace error-detected parts.
- Reconnect part or connector after repairing or replacing.
- When DTC is detected, erase self-diagnostic results for "ALL MODE AWD/4WD".

>> GO TO 7.

# 6. IDENTIFY ERROR-DETECTED SYSTEM BY SYMPTOM DIAGNOSIS

Estimate error-detected system based on symptom diagnosis and perform inspection.

Can the error-detected system be identified?

### DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION > [TRANSFER: ATX90A]

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained by interview. Refer to <u>GI-40</u>, <u>"Intermittent Incident"</u>.

# 7. FINAL CHECK

## **With CONSULT-III**

- Check the reference value for "ALL MODE AWD/4WD".
- 2. Recheck the symptom and check that symptom is not reproduced on the same conditions.

### Is the symptom reproduced?

YES >> GO TO 3.

NO >> INSPECTION END

## Diagnostic Work Sheet

INFOID:0000000006222233

### Description

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

### Interview sheet sample

			Interview s	heet				
Customer	MR/MS	Registration number			Initial year registration			
name		Vehicle type			VIN			_
Storage date		Engine			Mileage		km (	Mile)
		□Vehicle does	not enter 4WD	mode.	,			
		□4WD warning	lamp turns on.					
Symptom		□Heavy tight-c	rner braking sy	mptom occu	ırs			
Cympioni		□Noise □V	bration					
		□Others (					)	
First occurre	ence	□Recently	⊒Others (				)	
Frequency of	of occurrence	□Always □	Under a certain	conditions	of □Sometimes	(time(s)/day)		
		□Irrelevant						
Climate	Weather	□Fine □Clo	oud □Rain	□Snow	□Others (		)	
conditions	Temperature	□Hot □Wa	m □Cool	□Cold	☐Temperature [App	prox. °(	C (	°F)]
	Relative humidity	□High □Mo	derate □Lo	OW				
Road condit	ions	□Urban area □Mounting roa	□Suburb are I (uphill or dow	3	n way Rough road			
Operation c	onditions, etc.	□Irrelevant □When engine □During driving □During decele	□During a	ring idling cceleration ring cornerir	□At constant spe	•		

Revision: 2010 May **DLN-39** 2011 QX56

DLN

В

Е

F

G

Н

I

M

Ν

# **DIAGNOSIS AND REPAIR WORK FLOW**

[TRANSFER: ATX90A] < BASIC INSPECTION >

		Interview	sheet		
Customer	MR/MS	Registration number	Initial year registration		
name		Vehicle type	VIN		
Storage date		Engine	Mileage	km (	Mile)
Other conditions					
Memo					

### ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT [TRANSFER: ATX90A] < BASIC INSPECTION > ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT Α Description INFOID:0000000006222234 Perform writing unit parameter and initial calibration after replacing transfer control unit. Refer to DLN-41, "Work Procedure". Work Procedure INFOID:0000000006222235 NOTE: In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.) 1. WRITE UNIT PARAMETER DLN Perform writing unit parameter to control unit. Refer to <u>DLN-48</u>, "Work <u>Procedure"</u>. Е >> GO TO 2. 2 . INITIAL CALIBRATION (1) F With CONSULT-III Start the engine. **CAUTION:** Never drive the vehicle. 2. Check "4WD MODE", "T/M RANGE", "COMER VHCL SPEED", "MOTOR POWER SUP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD". 3. Continue the following condition more than 10 seconds. Н **4WD MODE** : AUTO T/M RANGE : N COMPER VHCL SPEED : 0 km/h (Never drive the vehicle) MOTOR POWER SUP : More than 11 V Does the transfer motor operate automatically? YES >> After the transfer motor operation stop (After approximately 10 seconds) GO TO 4. NO >> GO TO 3. 3.INITIAL CALIBRATION (2) K (P)With CONSULT-III Select "START CALIBRATION" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD". Wait until the motor operation stop. (After approximately 10 seconds) >> GO TO 4. M 4.PERFORM SELF-DIAGNOSIS (P)With CONSULT-III Erase self-diagnosis result for "ALL MODE AWD/4WD". N Turn the ignition switch ON to OFF. CAUTION: Wait for 10 seconds after turning ignition switch OFF.

# Revision: 2010 May **DLN-41** 2011 QX56

Р

3. Start the engine. CAUTION:

YES

NO

Is "DTC P181F" detected?

>> GO TO 1.

>> WORK END

Never drive the vehicle.

Perform self-diagnosis for "ALL MODE AWD/4WD".

## ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

[TRANSFER: ATX90A]

< BASIC INSPECTION >

## ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

Description INFOID:000000006222236

Perform writing unit parameter, transfer fluid viscosity learning and initial calibration after replacing transfer assembly. Refer to <a href="https://doi.org/li>
<a href="https://doi.org/li

Work Procedure

### NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1.WRITE UNIT PARAMETER

Perform writing unit parameter to control unit. Refer to <a href="DLN-48">DLN-48</a>, "Work Procedure".

>> GO TO 2.

# 2.PREPARATION BEFORE WORK

### (P)With CONSULT-III

1. Start the engine.

### **CAUTION:**

Never drive the vehicle.

- Check "4WD MODE", "T/M RANGE", "COMER VHCL SPEED", "MOTOR POWER SUP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".
- 3. Continue the following condition more than 10 seconds.

4WD MODE : AUTO T/M RANGE : N

COMPER VHCL SPEED : 0 km/h (Never drive the vehicle)

MOTOR POWER SUP : More than 11 V

>> GO TO 3.

# 3. PERFORM TRANSFER FLUID VISCOSITY LEARNING

### (P)With CONSULT-III

- Select "OIL DETERIORATION INFO RESET" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/ 4WD".
- 2. Select "Start".

>> GO TO 4.

# 4. INITIAL CALIBRATION

### (P)With CONSULT-III

- Select "START CALIBRATION" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD".
- 2. Wait until the motor operation stop. (After approximately 10 seconds)

>> GO TO 5.

# 5. PERFORM SELF-DIAGNOSIS

### (P)With CONSULT-III

- 1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
- 2. Turn the ignition switch ON to OFF.

### **CAUTION:**

Wait for 10 seconds after turning ignition switch OFF.

Start the engine.

### **CAUTION:**

### Never drive the vehicle.

4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Revision: 2010 May **DLN-42** 2011 QX56

# ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

< BASIC INSPECTION > [TRANSFER: ATX90A]

Is "DTC P181F" detected?

YES >> GO TO 1.

NO >> WORK END

Α

В

С

DLN

F

Е

G

Н

J

Κ

L

M

Ν

0

### TRANSFER LOCK POSITION SENSOR LEARNING

[TRANSFER: ATX90A]

< BASIC INSPECTION >

## TRANSFER LOCK POSITION SENSOR LEARNING

Description INFOID:0000000000222238

- Detect a stroke of transfer lock sleeve and learn operating area of transfer lock sleeve (Lock/Unlock)
- Perform the learning of transfer lock position sensor by "CONFIGURATION" of CONSULT-III function. Refer to <u>DLN-44</u>, "Work <u>Procedure"</u>.

### **CAUTION:**

Before performing the learning of lock position sensor, must erase learning of transfer lock position sensor.

Function	Description
LOCK SLEEVE SENSOR* INITIALIZE	Format learning the transfer lock position sensor written to transfer control unit.
LOCK SLEEVE SENSOR* LEARNING	Perform learning the transfer lock position sensor.

<sup>\*: &</sup>quot;LOCK SLEEVE SENSOR" means transfer lock position sensor.

Work Procedure

### NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F or P182B is detected.)

## 1. PREPARATION BEFORE WORK

### (P)With CONSULT-III

Start the engine.

#### **CAUTION:**

Never drive the vehicle.

- Check "4WD MODE", "T/M RANGE", "COMER VHCL SPEED", "MOTOR POWER SUP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".
- 3. Continue the following condition.

 $\begin{array}{lll} \text{4WD MODE} & : \text{4L} \\ \text{T/M RANGE} & : \text{N} \end{array}$ 

COMPER VHCL SPEED : 0 km/h (Never drive the vehicle)

MOTOR POWER SUP : More than 11 V

>> GO TO 2.

# 2.PERFORM ERASE LOCK POSITION SENOR LEARNING

### (P)With CONSULT-III

- Select "LOCK SLEEVE SENSOR INITIALIZE" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/ 4WD".
- Select "Start".
- Wait until the motor operation stop.

>> GO TO 3.

# 3.PERFORM LOCK POSITION SENOR LEARNING

### (II) With CONSULT-III

- Select "LOCK SLEEVE SENSOR LEARNING" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD".
- Select "Start".
- Wait until the motor operation stop.

>> GO TO 4.

# 4. PERFORM SELF-DIAGNOSIS

With CONSULT-III

## TRANSFER LOCK POSITION SENSOR LEARNING

< BASIC INSPECTION > [TRANSFER: ATX90A]

Erase self-diagnosis result for "ALL MODE AWD/4WD".

2. Turn the ignition switch ON to OFF.

**CAUTION:** 

Wait for 10 seconds after turning ignition switch OFF.

3. Start the engine.

**CAUTION:** 

Never drive the vehicle.

4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is "DTC P182B" detected?

YES >> GO TO 1.

NO >> WORK END

C

Α

В

DLN

Е

F

G

Н

J

K

L

M

Ν

0

### TRANSFER ROTARY POSITION SENSOR LEARNING

< BASIC INSPECTION > [TRANSFER: ATX90A]

# TRANSFER ROTARY POSITION SENSOR LEARNING

Description INFOID:0000000000222240

Perform initial calibration after replacing transfer rotary position sensor. Refer to <u>DLN-46, "Work Procedure"</u>.

Work Procedure

### NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

# 1. INITIAL CALIBRATION

## (R)With CONSULT-III

1. Start the engine.

### **CAUTION:**

### Never drive the vehicle.

- 2. Check "4WD MODE", "T/M RANGE", "COMER VHCL SPEED", "MOTOR POWER SUP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".
- 3. Continue the following condition.

4WD MODE : AUTO T/M RANGE : N

COMPER VHCL SPEED : 0 km/h (Never drive the vehicle)

MOTOR POWER SUP : More than 11 V

- Select "START CALIBRATION" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD".
- 5. Wait till the motor operates. (Aprrox. 10 seconds)

>> GO TO 2.

# 2. PERFORM SELF-DIAGNOSIS

### (P)With CONSULT-III

- 1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
- Turn the ignition switch ON to OFF.

## **CAUTION:**

### Wait for 10 seconds after turning ignition switch OFF.

3. Start the engine.

### **CAUTION:**

#### Never drive the vehicle.

Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is "DTC P180D" detected?

YES >> GO TO 1.

NO >> WORK END

### TRANSFER FLUID VISCOSITY LEARNING

[TRANSFER: ATX90A] < BASIC INSPECTION > TRANSFER FLUID VISCOSITY LEARNING Α Description INFOID:0000000006222242 Perform transfer fluid viscosity learning and initial calibration after draining and refilling transfer fluid. Refer to DLN-47, "Work Procedure". Work Procedure INFOID:0000000006222243 NOTE: In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.) 1. PREPARATION BEFORE WORK DLN (P)With CONSULT-III Start the engine. Е **CAUTION:** Never drive the vehicle. Check "4WD MODE", "T/M RANGE", "COMER VHCL SPEED", "MOTOR POWER SUP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD". F Continue the following condition more than 10 seconds. **4WD MODE** : AUTO T/M RANGE : N COMPER VHCL SPEED : 0 km/h (Never drive the vehicle) MOTOR POWER SUP : More than 11 V Н >> GO TO 2. 2.transfer fluid viscosity learning With CONSULT-III Select "OIL DETERIORATION INFO RESET" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/ 4WD". Select "Start". K >> GO TO 3. 3 . INITIAL CALIBRATION (P)With CONSULT-III Select "START CALIBRATION" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD". Wait until the motor operation stop. (After approximately 10 seconds) >> GO TO 4. 4.PERFORM SELF-DIAGNOSIS N (P)With CONSULT-III Erase self-diagnosis result for "ALL MODE AWD/4WD". Turn the ignition switch ON to OFF. **CAUTION:** Wait for 10 seconds after turning ignition switch OFF. 3. Start the engine. **CAUTION:** Р Never drive the vehicle. 4. Perform self-diagnosis for "ALL MODE AWD/4WD". Is "DTC P181F" detected? YES >> GO TO 1.

>> WORK END

NO

< BASIC INSPECTION > [TRANSFER: ATX90A]

# **CONFIGURATION (TRANSFER CONTROL UNIT)**

Description INFOID:0000000006388779

Perform writing unit parameter after replacing transfer control unit, transfer assembly and transfer control actuator. Refer to <a href="DLN-48">DLN-48</a>, "Work Procedure".

Work Procedure

### NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1.CONFIRM REPLACING PARTS

Confirm the replacing parts.

What is the replacing parts?

Transfer control unit>>GO TO 2.

Transfer control actuator>>GO TO 3.

Transfer assembly>>GO TO 4.


2.write unit parameter (1)

### (P)With CONSULT-III


- 1. Make the new unit parameter with the following procedure.
- Confirm the alphabet of unit parameter (A).

#### NOTE:

- This illustration is sample.
- For this illustration, the unit parameter is "G3" and the alphabet of unit parameter is "G".



- Confirm the alphabet of transfer control actuator parameter (B).
   NOTE:
  - Original transfer control actuator does not have marking of alphabet.
  - Just in case that transfer control actuator has been replaced, it has marking of alphabet.
  - This illustration is sample of replaced transfer control actuator.
  - For this illustration, the alphabet of transfer control actuator parameter is "H".



- Make new alphabet of unit palameter as to the alphabets of unit palameter and the transfer control actuator parameter, using following chart.

When the alphabet of transfer control actuator parameter is no marking.

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<b></b>	$\downarrow$	$\downarrow$	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	$\downarrow$
The new alphabet of unit parameter	Α	В	С	D	E	F	G	Н	J

# **CONFIGURATION (TRANSFER CONTROL UNIT)**

### < BASIC INSPECTION >

When the alphabet of transfer control actuator parameter is "C".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<b></b>	<b>\</b>	$\downarrow$							
The new alphabet of unit parameter	Α	В	С	С	D	Е	Е	F	G

When the alphabet of transfer control actuator parameter is "H".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<u> </u>	<b>\</b>	<b>\</b>	$\downarrow$	<b>\</b>	<b>\</b>	$\downarrow$	$\downarrow$	<b>\</b>	$\downarrow$
The new alphabet of unit parameter	В	С	D	D	Е	F	F	G	Н

When the alphabet of transfer control actuator parameter is "N".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<b>\</b>	$\downarrow$	<b>\</b>	<b>1</b>						
The new alphabet of unit parameter	С	D	E	Е	F	G	G	Н	J

#### NOTE:

For the sample illustrations, the new alphabet of unit parameter is "F".

Add the same number of unit parameter behind the new alphabet of unit parameter.

#### NOTE:

For the sample illustration, the number of unit parameter is "3" and new unit parameter is "F3".

- 2. Turn the ignition switch OFF to ON.
- Select "UNIT CHARACTERISTICS WRITE" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/ 4WD".
- 4. Input new unit parameter.
- Select "Start".
- 6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.

#### >> WORK END.


# 3.WRITE UNIT PARAMETER (2)

### (P)With CONSULT-III


- 1. Make the new unit parameter with the following procedure.
- Confirm the alphabet of unit parameter (A).

### NOTE:

- This illustration is sample.
- For this illustration, the unit parameter is "G3" and the alphabet of unit parameter is "G".



- Confirm the alphabet of transfer control actuator parameter (B). **NOTE:** 
  - Original transfer control actuator does not have marking of alphabet.
  - Just in case that transfer control actuator has been replaced, it has marking of alphabet.
  - This illustration is sample of replaced transfer control actuator.
- For this illustration, the alphabet of transfer control actuator parameter is "H".



Α

[TRANSFER: ATX90A]

В

DLN

Е

Г

G

Н

|

J

K

L

M

Ν

0

Р

Ρ

2011 QX56

Revision: 2010 May

## CONFIGURATION (TRANSFER CONTROL UNIT)

### < BASIC INSPECTION >

Make new alphabet of unit palameter as to the alphabets of unit palameter and the transfer control actuator parameter, using following chart.

When the alphabet of transfer control actuator parameter is "C".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<u> </u>	<b>\</b>	$\downarrow$	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	<b>\</b>	$\downarrow$
The new alphabet of unit parameter	Α	В	С	С	D	Е	Е	F	G

When the alphabet of transfer control actuator parameter is "H".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<b></b>	<b>\</b>	$\downarrow$	<b>\</b>						
The new alphabet of unit parameter	В	С	D	D	Е	F	F	G	Н

When the alphabet of transfer control actuator parameter is "N".

The alphabet of original unit parameter	Α	В	С	D	Е	F	G	Н	J
<b></b>	<b>\</b>	$\downarrow$	<b>\</b>						
The new alphabet of unit parameter	С	D	Е	Е	F	G	G	Н	J

### NOTE:

For the sample illustrations, the new alphabet of unit parameter is "F".

- Add the same number of unit parameter behind the new alphabet of unit parameter.

#### NOTE:

For the sample illustration, the number of unit parameter is "3" and new unit parameter is "F3".

- 2. Turn the ignition switch OFF to ON.
- Select "UNIT CHARACTERISTICS WRITE" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/ 4WD".
- 4. Input new unit parameter.
- 5. Select "Start".
- Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.

### >> WORK END.


# 4. WRITE UNIT PARAMETER (3)

### (P)With CONSULT-III

1. Confirm the unit parameter (A).

### NOTE:

- This illustration is sample.
- For this illustration, the unit parameter is "G3".
- Turn the ignition switch OFF to ON.
- 3. Select "UNIT CHARACTERISTICS WRITE" of CONSULT-III "WORK SUPPORT" for "ALL MODE AWD/4WD".
- 4. Input unit parameter.
- Select "Start".
- 6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.



[TRANSFER: ATX90A]

>> WORK END.

## P1802, P1803, P1804, P1809 TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

# DTC/CIRCUIT DIAGNOSIS

# P1802, P1803, P1804, P1809 TRANSFER CONTROL UNIT

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause	- '
P1802	CONTROL UNIT 1	Malfunction is detected in the memory (RAM) system of transfer control unit.		- D
P1803	CONTROL UNIT 2	Malfunction is detected in the memory (ROM) system of transfer control unit.	late and modification of transfer control	
P1804	CONTROL UNIT 3	Malfunction is detected in the memory (EEOROM) system of transfer control unit.	Internal malfunction of transfer control unit.	
P1809	CONTROL UNIT 4	AD converter system of transfer control unit is malfunctioning.		

### DTC CONFIRMATION PROCEDURE

# 1.DTC REPRODUCTION PROCEDURE

## (I) With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

### Are DTC's "P1802, P1803, P1804 or P1809" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-51</u>. "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

# Diagnosis Procedure

## 1.PERFORM SELF-DIAGNOSIS

### (P)With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Turn the ignition switch OFF, and then wait 10 seconds and more.
- 3. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Are DTC's "P1802, P1803, P1804 or 1809" detected?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

DLN

Α

[TRANSFER: ATX90A]

\_

Н

K

INFOID:00000000006222245

F

Ν

M

## P1807 OUT PUT SHAFT SPEED SENSOR

[TRANSFER: ATX90A]

< DTC/CIRCUIT DIAGNOSIS >

## P1807 OUT PUT SHAFT SPEED SENSOR

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1807	VHCL SPEED SEN-AT	<ul> <li>Malfunction is detected in output speed signal that is output from TCM through CAN communication.</li> <li>Improper signal is input while driving.</li> </ul>	Harness or connector (CAN communication line)     TCM     Internal malfunction of TCM     Output speed signal error

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P1807" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-52">DLN-52</a>, "Diagnosis Procedure".

NO >> INSPECTION END

# Diagnosis Procedure

DEGUITE INFOID:000000006222247

## 1.PERFORM TCM SELF-DIAGNOSIS

### (P)With CONSULT-III

Perform self-diagnosis for "TRANSMISSION".

### Is any DTCs detected?

YES >> Check the DTC.

NO >> GO TO 2.

# 2. ERASE SELF-DIAGNOSTIC RESULT

## (E)With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Start the engine and drive vehicle at 30 km/h (19 MPH) or more.
- 3. Check that A/T CHECK indictor lamp turns OFF.

### Does A/T CHECK indicator lamp turn OFF?

YES >> GO TO 3.

NO >> Refer to TM-165, "Symptom Table".

# 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1807" is detected, Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

### P1808 WHEEL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## P1808 WHEEL SPEED SENSOR

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1808	VHCL SPEED SEN-ABS	<ul> <li>Malfunction is detected in vehicle speed signal that is output from ABS actuator and electric unit (control unit) through CAN communication.</li> <li>Improper signal is input while driving.</li> </ul>	Harness or connector (CAN communication line)     Malfunction of ABS actuator and electric unit (control unit)     Malfunction of ABS actuator and electric unit (control unit) circuit error     Vehicle speed signal error

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P1808" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-53, "DTC Logic"</u>.

NO >> INSPECTION END

## Diagnosis Procedure

1.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

## (P)With CONSULT-III

Perform self-diagnosis for "ABS".

### Is any DTCs detected?

YES >> Check the DTCs.

NO >> GO TO 2.

# 2.erase self-diagnostic result

## (E) With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Start the engine and drive vehicle at 30 km/h (19 MPH) or more.
- Check that ABS warning lamp turns OFF.

### Does ABS warning lamp turn OFF?

YES >> GO TO 3.

NO >> Refer to <u>BRC-122</u>, "<u>Diagnosis Procedure</u>".

# 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1808" is detected, Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

DLN

Α

В

[TRANSFER: ATX90A]

Е

F

Н

П

INFOID:0000000006222249

K

M

Ν

# P180C SENSOR POWER SUPPLY (5V)

< DTC/CIRCUIT DIAGNOSIS >

# P180C SENSOR POWER SUPPLY (5V)

Description

Supplies power (5V) to transfer lock position sensor and transfer rotary position sensor.

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180C	SEN POWER SUPPLY (5V)	When the sensor power supply (5V) voltage is lower or higher than normal.	<ul> <li>Malfunction of transfer lock position sensor power supply circuit (open or short)</li> <li>Malfunction of transfer rotary position sensor power supply circuit (open or short)</li> </ul>

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P180C" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-54">DLN-54</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:00000000006222252

[TRANSFER: ATX90A]

# 1.CHECK TRANSFER LOCK POSITION SENSOR POWER SUPPLY (1)

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer lock position sensor harness connector and transfer rotary position sensor harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer lock position sensor harness connector terminals.

	+	_	
Tran	Voltage		
Connector	Terr		
F40	1	2	Approx. 5 V

### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

# 2.CHECK TRANSFER LOCK POSITION SENSOR CIRCUIT

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

# P180C SENSOR POWER SUPPLY (5V)

### < DTC/CIRCUIT DIAGNOSIS >

Transfer	control unit	Transfer lock position sensor		Continuity
Connector	Terminal	Connector Terminal		Continuity
E59	17	F40	1	Existed
£39	30	1 40	2	LAISIEU

4. Check the continuity between transfer lock position sensor harness connector and ground.

Transfer lock	position sensor		Continuity
Connector	Terminal		Continuity
F40	1	Ground	Not existed

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

# 3.check transfer lock position sensor power supply (2)

- 1. Turn the ignition switch OFF.
- 2. Connect transfer lock position sensor harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer lock position sensor harness connector terminals.

	+	_	
Tran	Voltage		
Connector	Terr		
F40	1	2	Approx. 5 V

### Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace transfer lock position sensor. Refer to <u>DLN-119</u>, "<u>Removal and Installation</u>".

# 4. CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY (1)

- 1. Turn the ignition switch OFF.
- 2. Connect transfer control unit harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

## Never start the engine.

Check the voltage between transfer rotary position sensor harness connector terminals.

	+	_	
Trans	Voltage		
Connector	Terr		
F41	1	2	Approx. 5 V

### Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

# 5. CHECK TRANSFER ROTARY POSITION SENSOR CIRCUIT

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

[TRANSFER: ATX90A]

Α

В

DLN

/1

K

N

0

P

# P180C SENSOR POWER SUPPLY (5V)

[TRANSFER: ATX90A]

### < DTC/CIRCUIT DIAGNOSIS >

Transfer	control unit	Transfer rotary position sensor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E50	18	F41	1	Existed
E59	16	141	2	LAISIEU

4. Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary	position sensor	_	Continuity
Connector	Connector Terminal		Continuity
F41	1	Ground	Not existed

### Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts.

# **6.**CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY (2)

- 1. Turn the ignition switch OFF.
- 2. Connect transfer lock position sensor harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer rotary position sensor harness connector terminals.

	+	_	
Trans	Voltage		
Connector	Terr		
F41	1	2	Approx. 5 V

### Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace transfer rotary position sensor. Refer to <u>DLN-117</u>, "Removal and Installation".

# 7.check terminals and harness connectors

Check the pin terminals for damage or loose connection with each harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

## P180D TRANSFER ROTARY POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

# P180D TRANSFER ROTARY POSITION SENSOR

DTC Logic

[TRANSFER: ATX90A]

Α

В

DLN

F

Н

Ν

Р

INFOID:0000000006222254

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180D	ROTARY POSITION SEN	Malfunction is detected in transfer rotary position sensor.	Transfer rotary position sensor Transfer rotary position sensor error Transfer rotary position sensor circuit error

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

## With CONSULT-III

- Turn the ignition switch OFF to ON.
- 2. Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- 3. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P180D" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-57">DLN-57</a>, "Diagnosis Procedure".

NO >> INSPECTION END

# Diagnosis Procedure

# 1. CHECK TRANSFER ROTARY POSITION SENSOR SIGNAL

1. Turn the ignition switch ON.

2. Check the voltage between transfer control unit harness connector and ground.

+ Transfer control unit		_	Voltage
Connector	Terminal		
E59	15	Ground	400 μ Sec/div 2V/div JPDIE0268GB

### Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 2.

# 2.CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY

- Turn the ignition switch OFF.
- 2. Disconnect transfer rotary position sensor harness connector.
- Turn the ignition switch ON.

#### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer rotary position sensor harness connector terminals.

	+	_	
Trans	Voltage		
Connector	Terr		
F41	1	2	Approx. 5 V

### P180D TRANSFER ROTARY POSITION SENSOR

[TRANSFER: ATX90A]

### < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 3.

# 3.check transfer rotary position sensor circuit

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- 3. Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

Transfer control unit		Transfer rotary position sensor		Continuity
Connector	Terminal	Connector Terminal		Continuity
E59	18	F41	1	Existed
L39	16	141	2	LAISIEU

4. Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary	position sensor	_	Continuity
Connector Terminal			Continuity
F41	1	Ground	Not existed

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

# 4. CHECK TRANSFER ROTARY POSITION SENSOR SIGNAL CIRCUIT

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

Transfer	control unit	Transfer rotary position sensor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E59	15	F41	3	Existed

Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary	position sensor		Continuity	
Connector	Connector Terminal		Continuity	
F41	3	Ground	Not existed	

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

## ${f 5}$ . REPLACE TRANSFER ROTARY POSITION SENSOR

- 1. Replace transfer rotary position sensor. Refer to <u>DLN-117, "Removal and Installation"</u>.
- 2. Perform confirmation procedure again. Refer to <u>DLN-57</u>, "DTC Logic".

### Is DTC "P180D" detected?

YES >> GO TO 6.

NO >> INSPECTION END

## 6. CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

# P180E SENSOR POWER SUPPLY (8V)

< DTC/CIRCUIT DIAGNOSIS >

# P180E SENSOR POWER SUPPLY (8V)

Description INFOID:0000000006222255

Supplies power (8V) to transfer internal speed sensor.

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180E	SEN POWER SUPPLY (8V)	When the sensor power supply (8V) voltage is lower or higher than normal.	Malfunction of transfer internal speed sensor power supply circuit (open or short)

# DLN

Ν

Р

Α

В

[TRANSFER: ATX90A]

## DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

## With CONSULT-III

- 1. Turn the ignition switch ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P180E" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-59</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

## Diagnosis Procedure

# Cedure INFOID:0000000006222257

# 1. CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer control actuator harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

Check the voltage between transfer control actuator harness connector terminals.

	+	_	
Tra	Voltage		
Connector	Terr		
F52	3	7	Approx. 8 V

### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

# 2.check transfer internal speed sensor circuit

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E59	39	F52	3	Existed
⊏39	9	1 32	7	LXISIEU

4. Check the continuity between transfer control actuator harness connector and ground.

# P180E SENSOR POWER SUPPLY (8V)

[TRANSFER: ATX90A]

### < DTC/CIRCUIT DIAGNOSIS >

Transfer cor	ntrol actuator		Continuity	
Connector	Terminal	_	Continuity	
F52	7	Ground	Not existed	

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

# 3.check transfer internal speed sensor power supply (2)

- 1. Turn the ignition switch OFF.
- 2. Connect transfer control actuator harness connector.
- Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer control actuator harness connector terminals.

	_				
Tra	Transfer control actuator				
Connector	Terr				
F52	3	7	Approx. 8 V		

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Transfer internal speed sensor is malfunctioning. Replace transfer control actuator. Refer to <u>DLN-114</u>, "Removal and Installation".

# 4. CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

## P180F TRANSFER INTERNAL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

# P180F TRANSFER INTERNAL SPEED SENSOR

**DTC** Logic INFOID:0000000006222258

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180F	MOTOR SYSTEM	<ul> <li>Malfunction is detected in transfer motor.</li> <li>Malfunction is detected in transfer internal speed sensor.</li> </ul>	Transfer control actuator Transfer motor error Transfer internal speed sensor circuit error Transfer assembly internal malfunction.

## DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

## (II) With CONSULT-III

- Turn the ignition switch OFF to ON.
- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

## Is DTC "P180F" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-61">DLN-61</a>, "Diagnosis Procedure".

>> INSPECTION END NO

# Diagnosis Procedure

1. CHECK TRANSFER INTERNAL SPEED SENSOR SIGNAL

- Turn the ignition switch ON.
- Check the voltage between transfer control unit harness connector and ground.

+ Transfer control unit		_	Condition	Voltage	
Connector	Terminal				
	10	Ground		400 μ Sec/div 2V/div JPDIE0267GB	
E59	31	Ground	4WD mode: AUTO A/T shift selector: N Depress accelerator pedal several time	400 $\mu$ Sec/div  2V/div  JPDIE0269GB  NOTE:  When changing the transfer motor rotation direction.	

### Is the inspection result normal?

YES >> GO TO 6. NO >> GO TO 2.

# 2.CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY

**DLN-61** Revision: 2010 May 2011 QX56

DLN

Α

В

[TRANSFER: ATX90A]

Е

F

Н

INFOID:0000000006222259

Ν

## P180F TRANSFER INTERNAL SPEED SENSOR

[TRANSFER: ATX90A]

### < DTC/CIRCUIT DIAGNOSIS >

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control actuator harness connector.
- 3. Turn the ignition switch ON.
- 4. Check the voltage between transfer control actuator harness connector terminals.

Tra	Voltage			
Connector	Connector Terminal			
F52	3	7	8V	

### Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

# ${f 3.}$ CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY CIRCUIT

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector Terminal		Continuity
E59	39	F52	3	Existed
<b>⊑</b> 39	9	F52	7	Existed

4. Check the continuity between transfer control actuator harness connector and ground.

Transfer cor	ntrol actuator		Continuity
Connector Terminal			Continuity
F52	3	Ground	Not existed

### Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

# 4. CHECK TRANSFER INTERNAL SPEED SENSOR SIGNAL CIRCUIT

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- 3. Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector Terminal		Continuity
E59	10	F52	2	Existed
	31	6	6	LXISIEU

4. Check the continuity between transfer control actuator harness connector and ground.

Transfer co	ntrol actuator		Continuity
Connector	Connector Terminal		Continuity
F52	2	Ground	Not existed
F32	6	Glound	Not existed

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

## P180F TRANSFER INTERNAL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS > [TRANSFER: ATX90A]

# 5. REPLACE TRANSFER CONTROL ACTUATOR

1. Replace transfer control actuator. Refer to <a href="DLN-114">DLN-114</a>, "Removal and Installation".

2. Perform confirmation procedure again. Refer to DLN-57, "DTC Logic".

### Is DTC "P180F" detected?

YES >> GO TO 6.

NO >> INSPECTION END

## 6. CHECK TRANSFER INTERNAL FUNCTION

### ®With CONSULT-III

Remove transfer control actuator. Refer to <u>DLN-114</u>, "Removal and Installation".

Turn the actuator shaft. Refer to <u>DLN-114, "Inspection"</u>.

3. Check "ROTARY POSI SEN" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing

### Is the inspection result normal?

YES >> GO TO 7.

NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to <u>DLN-121</u>, <u>"Removal and Installation"</u>.

# 7. CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

DLN

Α

В

C

Е

F

G

Н

M

Ν

O

## P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

# P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

Description

Supplies power to transfer control unit.

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1811	BATTERY VOLTAGE	When transfer control unit power supply is lower or higher than normal	Malfunction of transfer control unit pow- er supply circuit (open or short)

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P1811" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-64</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222262

[TRANSFER: ATX90A]

# 1. CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- 3. Check the voltage between transfer control unit harness connector and ground.

Transfer	control unit		Voltage
Connector	Terminal	_	voltage
E59	20	Ground	Battery voltage

4. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

5. Check the voltage between transfer control unit harness connector and ground.

Transfer of	control unit		Voltage
Connector Terminal			voltage
E59	20	Ground	Battery voltage

### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

# 2.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

- 1. Turn the ignition switch OFF.
- Check the 10A fuse (#34).
- 3. Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

### Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to <u>PG-11, "Wiring Diagram - BAT-TERY POWER SUPPLY -"</u>.

NO >> Repair or replace error-detected parts.

## P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

# ${f 3.}$ CHECK TRANSFER CONTROL UNIT POWER SUPPLY (3)

1. Turn the ignition switch OFF.

Check the voltage between transfer control unit harness connector and ground.

Transfer	control unit	_	Voltage
Connector Terminal			voltage
E59	32	Ground	0 V

Turn the ignition switch ON.

#### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		_	Voltage
Connector	Terminal		voltage
E59	32	Ground	Battery voltage

### Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

# 4.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (4)

- Turn the ignition switch OFF.
- 2. Check the 10A fuse (#56).
- 3. Disconnect IPDM E/R harness connector.
- Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

IPDI	M E/R	Transfer control unit		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E15	58	E59	32	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

Transfer control unit			Continuity
Connector	Terminal	_	Continuity
E59	32	Ground	Not existed

## Is the inspection result normal?

>> Perform the trouble diagnosis for ignition power supply circuit. Refer to PG-89, "Wiring Diagram -YES **IGNITION POWER SUPPLY -".** 

NO >> Repair or replace error-detected parts.

# 5. CHECK TRANSFER CONTROL UNIT GROUND

Turn the ignition switch OFF.

Check the continuity between transfer control unit harness connector and ground.

Transfer control unit			Continuity	
Connector	Terminal	<del></del>	Continuity	
E60	46	Ground	Existed	
<b>⊑</b> 00	44	Ground	Existed	

#### Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

## $\mathsf{6}.$ CHECK TERMINALS AND HARNESS CONNECTORS

DLN

Α

В

[TRANSFER: ATX90A]

Е

Н

Ν

# P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

[TRANSFER: ATX90A]

< DTC/CIRCUIT DIAGNOSIS >

Check the transfer control unit pin terminals for damage or loose connection with harness connector. Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

### P1813 4WD MODE SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

## P1813 4WD MODE SWITCH

**DTC** Logic INFOID:0000000006222263

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1813	4WD MODE SW	Multiple signals received from 4WD shift switch are detected.	4WD switch assembly     Internal malfunction of 4WD switch assembly     Malfunction of 4WD switch assembly circuit     Transfer control unit

DTC CONFIRMATION PROCEDURE

# 1.DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

## Is DTC "P1813" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-67">DLN-67</a>, "Diagnosis Procedure".

>> INSPECTION END NO

# Diagnosis Procedure

1.CHECK TRANSFER SHIFT SWITCH

Check 4WD switch assembly. Refer to DLN-68, "Component Inspection".

### Is the inspection result normal?

YES >> GO TO 2.

NO >> 4WD shift switch is malfunctioning. Replace 4WD switch assembly. Refer to DLN-108, "Removal and Installation".

# 2.CHECK 4WD SHIFT SWITCH CIRCUIT (1)

- Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and 4WD switch assembly harness connector.

Transfer of	control unit	4WD switch assembly		Continuity	
Connector	Terminal	Connector Termin		Continuity	
			11	Existed	
	11		10	Not existed	
	E59 35		9	Not existed	
		M54	11	Not existed	
E59			10	Existed	
			9	Not existed	
			11	Not existed	
1	14		10	Not existed	
			9	Existed	

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

**DLN-67** Revision: 2010 May 2011 QX56

Α

В

[TRANSFER: ATX90A]

DLN

F

Н

INFOID:0000000006222264

K

M

Ν

### P1813 4WD MODE SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

# 3.CHECK 4WD SHIFT SWITCH CIRCUIT (2)

Check the continuity between 4WD switch assembly harness connector and ground.

4WD switch assembly			Continuity	
Connector Terminal			Continuity	
	11		Not existed	
M54	10	Ground		
	9			

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

### 4. CHECK TERMINALS AND HARNESS CONNECTORS

- Check transfer control unit pin terminals for damage or loose connection with harness connector.
- Check 4WD switch assembly pin terminals for damage or loose connection with harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

# Component Inspection

INFOID:0000000006222265

[TRANSFER: ATX90A]

# 1. CHECK 4WD SHIFT SWITCH

- 1. Turn the ignition switch OFF.
- 2. Remove 4WD switch assembly. Refer to <a href="DLN-108">DLN-108</a>, "Removal and Installation".
- 3. Check the continuity between 4WD switch assembly harness connector terminals.

4WD switch assembly		Condition	Continuity	
Terminal		Condition	Continuity	
12	9	4WD shift switch: AUTO	Existed	
12	9	4WD shift switch: 4H or 4L	Not existed	
12	12 10	4WD shift switch: 4H	Existed	
12	10	4WD shift switch: AUTO or 4L	Not existed	
12 11	4WD shift switch: 4L	Existed		
12		4WD shift switch: AUTO or 4H	Not existed	

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace 4WD switch assembly. Refer to <u>DLN-108</u>, "Removal and Installation".

### P1816 PARKING/NEUTRAL POSITION SWITCH

[TRANSFER: ATX90A] < DTC/CIRCUIT DIAGNOSIS >

## P1816 PARKING/NEUTRAL POSITION SWITCH

DTC Logic INFOID:00000000006222266

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1816	PNP SW/CIRC	Malfunction is detected in PNP switch signal that is output from TCM through CAN communication	Harness or connector (CAN communication line)     TCM     Internal malfunction of TCM     A/T shift selector error

DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Shift the A/T shift selector P position.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P1816" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-69">DLN-69</a>, "Diagnosis Procedure".

NO >> INSPECTION END

# Diagnosis Procedure

## 1.PERFORM TCM SELF-DIAGNOSIS

# (P)With CONSULT-III

Perform self-diagnosis for "TRANSMISSION".

### Is any DTCs detected?

YES >> Check the DTC.

NO >> GO TO 2.

# 2.erase self-diagnostic result

### (P)With CONSULT-III

- Erase self-diagnostic results for "ALL MODE AWD/4WD".
- Start the engine and drive vehicle at 30 km/h (19 MPH) or more.
- Check that A/T CHECK indictor lamp turns OFF.

### Does A/T CHECK indicator lamp turn OFF?

YES >> GO TO 3.

NO >> Refer to TM-165, "Symptom Table".

# ${f 3.}$ CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1816" is detected, Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

**DLN-69** Revision: 2010 May 2011 QX56

DLN

Α

В

Е

F

INFOID:00000000006222267

M

Ν

### P1817 TRANSFER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## P1817 TRANSFER MOTOR

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1817	SHIFT ACTUATOR	Malfunction is detected in transfer motor.	Transfer control actuator Transfer motor error malfunction of transfer motor circuit

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- 2. Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- 3. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P1817" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-70</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

# Diagnosis Procedure

INFOID:0000000006222269

[TRANSFER: ATX90A]

# 1. CHECK TRANSFER MOTOR CIRCUIT (1)

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector Terminal		Continuity
E60	45	F52	8	Existed
	43	1 32	1	LAISIEU

4. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit			Continuity	
Connector	Terminal	_	Continuity	
E60	45	Ground	Not existed	
43		Giouna	Not existed	

### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

## 2.CHECK TRANSFER MOTOR

Check the transfer control actuator. Refer to <a href="DLN-71">DLN-71</a>, "Component Inspection".

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Transfer motor is malfunctioning. Replace transfer control actuator. Refer to <u>DLN-114</u>, "Removal and Installation".

# 3. CHECK TRANSFER INTERNAL FUNCTION

### (I) With CONSULT-III

1. Remove transfer control actuator. Refer to <a href="DLN-114">DLN-114</a>, "Removal and Installation".

### P1817 TRANSFER MOTOR

### < DTC/CIRCUIT DIAGNOSIS >

Turn the actuator shaft. Refer to <u>DLN-114, "Inspection"</u>.

Check "ROTARY POSI SEN" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing

В

Α

### Is the inspection result normal?

YES >> GO TO 4.

NO

>> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to <u>DLN-121</u>, <u>"Removal and Installation"</u>.

DLN

Е

Н

# 4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <a href="DLN-107">DLN-107</a>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

# Component Inspection

## INFOID:0000000006222270

[TRANSFER: ATX90A]

# 1. CHECK TRANSFER MOTOR

Remove transfer control actuator. Refer to <u>DLN-114, "Exploded View"</u>.

Apply 12 V to transfer control actuator connector No. 1 terminal and No. 8 terminal. CAUTION:

- Never make the terminals short.
- · Connect the fuse between the terminals when applying the voltage.
- 3. Check the operation of transfer control actuator.

Transfer control actuator Terminal		Condition	Operation
		Condition	
1	8	Apply the voltage between No. 1 (+) terminal and No. 8 (–) terminal.	Operate clockwise
		Apply the voltage between No. 1 (–) terminal and No. 8 (+) terminal.	Operate counter- clockwise

### Is the inspection result normal?

YES >> INSPECTION END

NO

>> Replace transfer control actuator. Refer to <u>DLN-114</u>, "<u>Exploded View</u>".

K

Revision: 2010 May DLN-71

0

Ν

Р

2011 QX56

## P181A TRANSFER MOTOR TEMPERATURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## P181A TRANSFER MOTOR TEMPERATURE SENSOR

DTC Logic

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181A	MOTOR TEMP SEN	When vehicle speed is 40km/h or more and transfer motor temperature is lower than normal	Transfer control actuator Malfunction of transfer motor temperature sensor circuit. (open)
		When transfer motor temperature is higher than normal	Transfer control actuator     Malfunction of transfer motor temperature sensor circuit. (short)

### DTC CONFIRMATION PROCEDURE

# 1. DTC REPRODUCTION PROCEDURE

## (E)With CONSULT-III

- 1. Start the engine and drive at 40 km/h (25 MPH) or more for approximately 1 minute.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P181A" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-72</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

# Diagnosis Procedure

INFOID:0000000006222272

[TRANSFER: ATX90A]

# 1. CHECK TRANSFER MOTOR TEMPERATURE SENSOR POWER SUPPLY

- 1. Turn the ignition switch OFF.
- Disconnect transfer control actuator harness connector.
- 3. Turn the ignition switch ON.

### **CAUTION:**

### Never start the engine.

4. Check the voltage between transfer control actuator harness connector terminals.

+		_	
Transfer control actuator			Voltage
Connector	Terr		
F52	4	7	Approx. 5 V

### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

# 2.CHECK TRANSFER MOTOR TEMPERATURE SENSOR CIRCUIT

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity	
Connector	Terminal	Connector	Terminal	Continuity	
E59	28	F52	4	Existed	
	9		7	LAISIEU	

4. Check the continuity between transfer control actuator harness connector and ground.

### P181A TRANSFER MOTOR TEMPERATURE SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

Transfer control actuator			Continuity
Connector	Terminal	_	Continuity
F52 7		Ground	Not existed
s the inspection	n result normal?	?	

Α

[TRANSFER: ATX90A]

В

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

С

3.CHECK TRANSFER MOTOR TEMPERATURE SENSOR

Check the transfer control actuator. Refer to DLN-73, "Component Inspection".

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Transfer motor temperature sensor is malfunctioning. Replace transfer control actuator. Refer to DLN-114. "Exploded View".

DLN

## f 4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

#### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

Н

INFOID:0000000006222273

## Component Inspection

## 1. CHECK TRANSFER MOTOR TEMPERATURE SENSOR

1. Turn the ignition switch OFF.

- Disconnect transfer control actuator harness connector.
- 3. Check the resistance between transfer control actuator harness connector terminals.

Transfer control actuator Terminal		Condition	Resistance
		Condition	Resistance
4	7	20 °C (68 °F)	Approx. 12.5 kΩ
7	4	80 °C (176 °F)	Approx. 1.3 kΩ

## Is the inspection result normal?

YES >> INSPECTION END

NO

>> Transfer motor temperature sensor is malfunctioning. Replace transfer control actuator. Refer to DLN-114, "Exploded View".

M

K

Ν

P

Revision: 2010 May **DLN-73** 2011 QX56

#### P181B INCOMPLETE SELFSHUT

[TRANSFER: ATX90A]

< DTC/CIRCUIT DIAGNOSIS >

## P181B INCOMPLETE SELFSHUT

DTC Logic INFOID:0000000006222274

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181B	IMCOMP SELFSHUT	When ignition switch is OFF and transfer control unit power supply is lower or higher than normal	Self-shut is incomplete.

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- Turn the ignition switch OFF.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P181B" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-74">DLN-74</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222275

## 1. CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		_	Voltage
Connector	Connector Terminal		voltage
E59	20	Ground	Battery voltage

Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

5. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit			Voltage
Connector	Connector Terminal		voltage
E59	20	Ground	Battery voltage

#### Is the inspection result normal?

>> GO TO 3. YES NO >> GO TO 2.

## 2.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

- Turn the ignition switch OFF.
- Check the 10A fuse (#34).
- Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to PG-11, "Wiring Diagram - BAT-TERY POWER SUPPLY -".

NO >> Repair or replace error-detected parts.

## ${f 3.}$ CHECK TRANSFER CONTROL UNIT GROUND

Turn the ignition switch OFF.

### P181B INCOMPLETE SELFSHUT

#### < DTC/CIRCUIT DIAGNOSIS >

2. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit			Continuity	
Connector	Terminal	_	Continuity	
E60	44	- Ground Existed		
200	46	Giodila	LXISIEU	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector. Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P181B" is detected, Replace transfer control unit. Refer to <a href="DLN-107">DLN-107</a>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

C

Α

В

[TRANSFER: ATX90A]

DLN

Е

F

Н

ı

Κ

L

Ν

0

#### P181C TRANSFER MOTOR POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

## P181C TRANSFER MOTOR POWER SUPPLY

Description INFOID:000000006222276

Supplies power to transfer control actuator (transfer motor).

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181C	MOTOR POWER SUPPLY	When transfer control actuator power supply is lower or higher than normal	Malfunction of transfer control actuator (transfer motor) power supply circuit

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P181C" detected?

YES >> Proceed to diagnosis procedure. Refer to DLN-76, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222278

[TRANSFER: ATX90A]

## 1. CHECK TRANSFER MOTOR POWER SUPPLY (2)

Check the voltage between transfer control unit harness connector and ground.

	+	_	
Transfer control unit			Voltage
Connector	nnector Terminal		
E60	41	46	Battery voltage

#### Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

## 2.CHECK TRANSFER MOTOR POWER SUPPLY CIRCUIT (2)

- 1. Turn the ignition switch OFF.
- Check the 30A fusible link (J).
- Check the harness for open or short between transfer control unit harness connector No.41 terminal and 30A fusible link (J).

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to <u>PG-11, "Wiring Diagram - BAT-TERY POWER SUPPLY -"</u>.

NO >> Repair or replace error-detected parts.

## 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

#### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

### P181E STEERING ANGLE SENSOR

#### < DTC/CIRCUIT DIAGNOSIS >

## P181E STEERING ANGLE SENSOR

**DTC** Logic INFOID:0000000006222279

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181E	ST ANGLE SEN SIG	Malfunction is detected in steering angle sensor signal through CAN communication.	Harness or connector (CAN communication line)     Steering angle sensor     Steering angle sensor error     Malfunction of steering angle sensor circuit error

### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

### (II) With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P181E" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-77, "Diagnosis Procedure"</u>.

>> INSPECTION END NO

## Diagnosis Procedure

## ${f 1}$ .PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

### (P)With CONSULT-III

Perform self-diagnosis for "ABS".

#### Is DTC "C1143" detected?

>> Proceed to diagnosis procedure. Refer to <u>BRC-97</u>, "Diagnosis Procedure". YES

NO >> GO TO 2.

## 2.CHECK CAN COMMUNICATION LINE

Check communication line. Refer to LAN-69, "Diagnosis Procedure".

#### Is inspection result normal?

YES >> Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

Е

F

INFOID:0000000006222280

Α

В

[TRANSFER: ATX90A]

DLN

Ν

M

### P181F INCOMPLETE CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

## P181F INCOMPLETE CALIBRATION

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181F	INCOMP CALIBRATION	When incomplete calibration of transfer control unit is detected.	Initial calibration of transfer is incomplete

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (I) With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P181F" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-78</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222282

[TRANSFER: ATX90A]

## 1.PERFORM INITIAL CALIBRATION

- 1. Erase self-diagnostic result for "ALL MODE AWD/4WD".
- 2. Perform initial calibration. Refer to DLN-41, "Work Procedure".
- 3. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is any DTC except "P181F" detected?

YES >> Check DTC.

NO >> GO TO 2.

## 2. PERFORM SELF-DIAGNOSIS

### (P)With CONSULT-III

- 1. Erase self-diagnostic result for "ALL MODE AWD/4WD".
- 2. Turn the ignition switch OFF, and then wait 10 seconds or more.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P181F" detected?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace the error-detected parts.

#### P1820 ENGINE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

P1820	<b>ENGINE</b>	SPEED	SIGNAL
$\Gamma$ $\Gamma$ $\Gamma$ $\Gamma$ $\Gamma$	1 14(31141	<b>STEET</b>	

DTC Logic INFOID:0000000006222283

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1820	ENGINE SPEED SIG	Malfunction is detected in engine speed signal that is output from ECM through CAN communication.	Harness or connector (CAN communication line)     Internal malfunction of ECM

#### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- Start the engine and drive at 20 km/h (12 MPH) or more.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P1820" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-79">DLN-79</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

## PERFORM ECM SELF-DIAGNOSIS

### (P)With CONSULT-III

Perform self-diagnosis for "ENGINE".

## Is any DTCs detected?

YES >> Check the DTCs.

NO >> GO TO 2.

## 2.erase self-diagnostic result

### (E) With CONSULT-III

- Erase self-diagnostic results for "ALL MODE AWD/4WD".
- Turn the ignition switch OFF.
- Start the engine and drive vehicle for a while.
- Check that malfunction indicator lamp (MIL) turns OFF.

#### Does malfunction indicator lamp (MIL) turn OFF?

YES >> GO TO 3.

NO >> Refer to EC-515, "Diagnosis Procedure".

## ${f 3.}$ CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

#### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1820" is detected. Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts. DLN

Α

В

[TRANSFER: ATX90A]

F

INFOID:0000000006222284

M

Ν

### P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

## P1826 TRANSFER FLUID TEMPERATURE

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1826	P1826 OIL TEMP SEN	When vehicle speed is 40km/h or more and transfer fluid temperature is lower than normal	Transfer fluid temperature  Malfunction of transfer fluid temperature sensor circuit (open)
1 1020	OIL TEIWII GEIN	When transfer fluid temperature is higher than normal	Transfer fluid temperature  Malfunction of transfer fluid temperature sensor circuit (short)

#### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

### (E)With CONSULT-III

- 1. Start the engine and drive at 40 km/h (25 MPH) or more for approximately 1 minute.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P1826" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-80, "Diagnosis Procedure"</u>.

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222286

[TRANSFER: ATX90A]

## 1. CHECK TRANSFER FLUID TEMPERATURE SENSOR POWER SUPPLY

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer fluid temperature sensor harness connector.
- 3. Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

4. Check the voltage between transfer fluid temperature sensor harness connector terminals.

	+	_			
Transfe	Transfer fluid temperature sensor				
Connector	Connector Terminal				
F37	2	1	Approx. 5 V		

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

## 2.CHECK TRANSFER FLUID TEMPERATURE SENSOR CIRCUIT

- Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer fluid temperature sensor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E59	7	F37	2	Existed
	36	1 37	1	LAISIEU

4. Check the continuity between transfer fluid temperature sensor harness connector and ground.

## P1826 TRANSFER FLUID TEMPERATURE

[TRANSFER: ATX90A]

## < DTC/CIRCUIT DIAGNOSIS >

Transfer fluid tem	nperature sensor		Continuity		1
Connector	Terminal	_	Continuity		
F37	2	Ground	Not existed		
Is the inspection		?			
YES >> GO NO >> Rep		error-detected p	orto		
3.CHECK TRA	•	•			
Is the inspection	-		Refer to <u>DLN-81</u>	, "Component Inspection".	D
YES >> GO		<u>:</u>			
		uid temperature	e sensor. Refer	to DLN-120, "Exploded View".	
4.CHECK TER	MINALS AND	HARNESS CO	NNECTORS	•	
Check the pin te	erminals for dar	mage or loose o	connection with	each harness connector.	
Is the inspection		•			
				"Removal and Installation".	
NO >> Rep	pair or replace	error-detected p	oarts.		
Component	Inspection			INFOID:0000000006222287	
1 00504554		. TEN 1000 ATL			
1.CHECK TRA			RE SENSOR		
	nition switch OF	FF. emperature sen	ear harness ca	pnector	
3. Check the r	esistance betw	een transfer co	ntrol fluid temp	erature sensor connector terminals.	
			·		
Transfer fluid tem	nperature sensor	Condition	Resistance		
Term	ninal	Condition	Resistance		
2	1	20 °C (68 °F)	Approx. 2.5 kΩ	_	
2	ľ	80 °C (176 °F)	Approx. 0.3 kΩ		
Is the inspection	n result normal	?			
	PECTION EN		D-f	to DINI 400 "Francis de d'Africa"	
NO >> Rep	place transfer fi	uid temperature	e sensor. Refer	to DLN-120, "Exploded View".	
					(

### P1829 ACCELERATOR PEDAL POSITION SENSOR

[TRANSFER: ATX90A]

< DTC/CIRCUIT DIAGNOSIS >

## P1829 ACCELERATOR PEDAL POSITION SENSOR

DTC Logic INFOID:0000000006222288

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1829	THROTTLE POSI SEN	Malfunction is detected in accelerator pedal position signal that is output from ECM through CAN communication.	Harness or connector (CAN communication line)     Internal malfunction of ECM

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- Start the engine and drive at 30 km/h (19 MPH) or more.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P1829" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-82">DLN-82</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222289

## 1.PERFORM ECM SELF-DIAGNOSIS

### (P)With CONSULT-III

Perform self-diagnosis for "ENGINE".

### Is any DTCs detected?

>> Check the DTCs. YES

NO >> GO TO 2.

## 2.erase self-diagnostic result

### (P)With CONSULT-III

- Erase self-diagnostic results for "ALL MODE AWD/4WD".
- Turn the ignition switch OFF.
- Start the engine and drive vehicle for a while.
- Check that malfunction indicator lamp (MIL) turns OFF.

#### Does malfunction indicator lamp (MIL) turn OFF?

YES >> GO TO 3.

NO >> Refer to EC-515, "Diagnosis Procedure".

## 3.check terminals and harness connectors

Check transfer control unit pin terminals for damage or loose connection with harness connector.

#### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1829" is detected. Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

#### P182A TRANSFER HI-LO POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## P182A TRANSFER HI-LO POSITION SENSOR

DTC Logic INFOID:0000000006222290

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P182A	HI-LO POSITION SEN	Malfunction related to transfer Hi-Lo position sensor has been detected.	Internal malfunction of transfer Hi-Lo position sensor

#### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

Start the engine.

#### CAUTION:

#### Never drive the vehicle.

- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- 3. Drive at 20 km/h (12MPH) or more for 1 minute or more.
- 4. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P182A" detected?

>> Proceed to diagnosis procedure. Refer to DLN-83, "Diagnosis Procedure". YES

>> INSPECTION END NO

## Diagnosis Procedure

1. CHECK TRANSFER HI-LO POSITION SENSOR SIGNAL

Turn the ignition switch ON.

#### **CAUTION:**

Never start the engine.

2. Check the voltage between transfer control unit harness connector and ground.

+				Voltage
Transfer control unit		_	Condition	
Connector	Terminal			
	6 25	Ground	4WD mode: AUTO or 4H	Approx. 0 V
E59			4WD mode: 4L	Approx. 5 V
L39			4WD mode: AUTO or 4H	Approx. 0 V
			4WD mode: 4L	Approx. 5 V

After operating 4WD shift switch, move the vehicle back and forth to check voltage.

#### Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 2.

## 2.CHECK TRANSFER HI-LO POSITION SENSOR POWER SUPPLY

- Turn the ignition switch OFF.
- Disconnect transfer Hi-Lo position sensor harness connector.
- Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

4. Check the voltage between transfer Hi-Lo position sensor harness connector terminals.

DLN

Α

В

[TRANSFER: ATX90A]

Е

F

INFOID:0000000006222291

K

Ν

#### P182A TRANSFER HI-LO POSITION SENSOR

[TRANSFER: ATX90A]

#### < DTC/CIRCUIT DIAGNOSIS >

	+		
Transfer Hi-Lo	position sensor	_	Voltage
Connector	Terminal		
F42	1 2	Ground	Approx. 5 V

#### Is the inspection result normal?

YES >> GO TO 4. NO >> GO TO 3.

## 3.CHECK TRANSFER HI-LO POSITION SENSOR CIRCUIT

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer Hi-Lo position sensor harness connector.

Transfer control unit		Transfer Hi-Lo position sensor		Continuity
Connector	Terminal	Connector Terminal		Continuity
	6		1	
E59	25	F42	2	Existed
	29		3	

4. Check the continuity between transfer Hi-Lo position sensor harness connector and ground.

Transfer Hi-Lo	position sensor		Continuity	
Connector Terminal		_	Continuity	
	1			
F42	2	Ground	Not existed	
	3			

### Is the inspection result normal?

YES >> GO TO 4.

IO >> Repair or replace error-detected parts.

## 4. REPLACE TRANSFER HI-LO POSITION SENSOR

- 1. Replace transfer Hi-Lo position sensor. Refer to DLN-116, "Exploded View".
- 2. Perform confirmation procedure again. Refer to DLN-83, "DTC Logic".

#### Is DTC "P182A" detected?

YES >> GO TO 5.

NO >> INSPECTION END

### 5. CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

#### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

### P182B TRANSFER LOCK POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## P182B TRANSFER LOCK POSITION SENSOR

DTC Logic INFOID:0000000006222292

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P182B	Lock POSITION SEN	Malfunction related to transfer lock position sensor has been detected.	Transfer lock position sensor Transfer lock position sensor error Malfunction of transfer lock position sensor circuit

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- Turn the ignition switch OFF to ON.
- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

### Is DTC "P182B" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-85">DLN-85</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

1. CHECK TRANSFER LOCK POSITION SENSOR

## (P)With CONSULT-III

- Start the engine.
- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Check "LOCK POSI SEN" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
	4WD shift switch: AUTO or 4H	OPEN
	4WD shift switch: 4L	LOCK
	When transfer lock position sensor is unlearned.	UNLEAN
LOCK POSI SEN	When the temperature of transfer lock position sensor is high.	HI TEMP
	When transfer lock position sensor is malfunctioning.	ERROR
	When transfer lock position sensor signal circuit is short. (Battery short)	BAT
	When transfer lock position sensor signal circuit is short. (Ground short)	GND

#### What is the item on "DATA MONITOR"?

OPEN >> GO TO 7.

LOCK >> GO TO 7.

UNLEAN>>GO TO 6.

HI TEMP>>GO TO 5.

ERROR>>GO TO 5.

BAT >> GO TO 2.

GND >> GO TO 2.

## 2.CHECK TRANSFER LOCK POSITION POWER SUPPLY

- Turn the ignition switch OFF.
- 2. Disconnect transfer position sensor harness connector.
- Turn the ignition switch ON.

**CAUTION:** 

DLN

Α

В

[TRANSFER: ATX90A]

F

INFOID:0000000006222293

Н

K

Ν

#### P182B TRANSFER LOCK POSITION SENSOR

[TRANSFER: ATX90A]

#### < DTC/CIRCUIT DIAGNOSIS >

#### Never start the engine.

4. Check the voltage between transfer position sensor harness connector terminals.

	+	_	
 Tran	Voltage		
 Connector			
 F40	1	2	Approx. 5 V

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

# 3.check transfer lock position sensor power supply circuit

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

Transfer control unit		Transfer lock position sensor		Continuity
Connector	Terminal	Connector Terminal		Continuity
E59	17	F40	1	Existed
E39	30	F40	2	Existed

4. Check the continuity between transfer lock position harness connector and ground.

Transfer lock	position sensor	_	Continuity
Connector Terminal		_	Continuity
F40 1		Ground	Not existed

#### Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts.

## 4. CHECK TRANSFER LOCK POSITION SENSOR SIGNAL CIRCUIT

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

Transfer control unit		Transfer lock position sensor		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E59	38	F40	3	Existed

Check the continuity between transfer lock position harness connector and ground.

Transfer lock	position sensor	_	Continuity	
Connector Terminal		_	Continuity	
F40	3	Ground	Not existed	

#### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

## 5. REPLACE TRANSFER LOCK POSITION SENSOR

- 1. Replace transfer lock position sensor. Refer to DLN-119, "Removal and Installation".
- 2. Perform confirmation procedure again. Refer to <a href="DLN-85">DLN-85</a>, "DTC Logic".

#### Is the inspection result normal?

P182B TRANSFER LOCK POSITION SENSO < DTC/CIRCUIT DIAGNOSIS >	OR [TRANSFER: ATX90A]
YES >> INSPECTION END	Thousand The American
NO >> GO TO 7.	A
6. PERFORM LEARNING OF TRANSFER LOCK POSITION SENSOR	
Transfer lock position sensor. Refer to <u>DLN-44, "Work Procedure"</u> .	В
>> GO TO 7.	
7. CHECK TERMINALS AND HARNESS CONNECTORS	С
Check the pin terminals for damage or loose connection with each harness connection	ctor.
Is the inspection result normal?  YES >> Replace transfer control unit. Refer to <a href="DLN-107">DLN-107</a> , "Removal and Installation."	DLI
NO >> Repair or replace error-detected parts.	atori.
	Е
	F
	G
	Н
	1
	J
	K
	L
	M
	N
	14
	0
	O

### P1830 ABS OPERATION SIGNAL

[TRANSFER: ATX90A]

INFOID:0000000006222295

< DTC/CIRCUIT DIAGNOSIS >

## P1830 ABS OPERATION SIGNAL

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1830	ABS OP SIG	Malfunction is detected in ABS operation signal that is output from ABS actuator and electric unit (control unit) through CAN communication.	Malfunction of ABS system

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- 1. Start the engine and drive at 30 km/h (19 MPH) or more.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P1830" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-88">DLN-88</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

1.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

#### (P)With CONSULT-III

Perform self-diagnosis for "ABS".

#### Is any DTCs detected?

YES >> Check the DTCs.

NO >> GO TO 2.

## 2.erase self-diagnostic result

#### (P)With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Start the engine and drive vehicle at 30 km/h (19 MPH) or more.
- Check that ABS warning lamp turns OFF.

#### Does ABS warning lamp turn OFF?

YES >> GO TO 3.

NO >> Refer to <u>BRC-123, "Diagnosis Procedure"</u>.

## 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

#### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1830" is detected, Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

P1831 VDC OPERATION SIGNAL [TRANSFER: ATX90A] < DTC/CIRCUIT DIAGNOSIS > P1831 VDC OPERATION SIGNAL Α DTC Logic INFOID:0000000006222296 DTC DETECTION LOGIC В DTC Possible cause Display item Malfunction detected condition Malfunction is detected in VDC operation signal that is output from ABS actu-P1831 VDC OP SIG Malfunction of ABS system ator and electric unit (control unit) through CAN communication. DLN DTC CONFIRMATION PROCEDURE 1.DTC REPRODUCTION PROCEDURE (P)With CONSULT-III Start the engine and drive at 30 km/h (19 MPH) or more. Perform self-diagnosis for "ALL MODE AWD/4WD". F Is DTC "P1831" detected? YES >> Proceed to diagnosis procedure. Refer to <u>DLN-89</u>, "<u>Diagnosis Procedure</u>". NO >> INSPECTION END Diagnosis Procedure INFOID:0000000006222297  ${f 1}$  .PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS Н (P)With CONSULT-III Perform self-diagnosis for "ABS". Is any DTCs detected? YES >> Check the DTCs. NO >> GO TO 2. 2 erase self-diagnostic result (P)With CONSULT-III Erase self-diagnostic results for "ALL MODE AWD/4WD". Start the engine and drive vehicle at 30 km/h (19 MPH) or more. Check that ABS warning lamp turns OFF. Does ABS warning lamp turn OFF? YES >> GO TO 3. NO >> Refer to BRC-122, "Diagnosis Procedure". M

## 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

#### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1831" is detected, Replace transfer control unit. Refer to DLN-107, "Removal and Installation".

NO >> Repair or replace error-detected parts.

**DLN-89** Revision: 2010 May 2011 QX56

Ν

#### P1832 TCS OPERATION SIGNAL

[TRANSFER: ATX90A]

INFOID:0000000006222299

< DTC/CIRCUIT DIAGNOSIS >

## P1832 TCS OPERATION SIGNAL

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1832	TCS OP SIG	Malfunction is detected in TCS operation signal that is output from ABS actuator and electric unit (control unit) through CAN communication.	Malfunction of TCS system

#### DTC CONFIRMATION PROCEDURE

## 1. DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- 1. Start the engine and drive at 30 km/h (19 MPH) or more.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "P1832" detected?

YES >> Proceed to diagnosis procedure. Refer to <a href="DLN-90">DLN-90</a>, "Diagnosis Procedure".

NO >> INSPECTION END

## Diagnosis Procedure

1.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

#### (P)With CONSULT-III

Perform self-diagnosis for "ABS".

#### Is any DTCs detected?

YES >> Check the DTCs.

NO >> GO TO 2.

## 2.erase self-diagnostic result

#### (P)With CONSULT-III

- 1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
- 2. Start the engine and drive vehicle at 30 km/h (19 MPH) or more.
- Check that ABS warning lamp turns OFF.

#### Does ABS warning lamp turn OFF?

YES >> GO TO 3.

NO >> Refer to <u>BRC-122</u>, "<u>Diagnosis Procedure</u>".

## 3.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

#### Is inspection result normal?

YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1832" is detected, Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

#### **U1000 CAN COMM CIRCUIT**

< DTC/CIRCUIT DIAGNOSIS >

### U1000 CAN COMM CIRCUIT

Description INFOID:0000000006222300

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

DTC Logic INFOID:0000000006222301

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	Transfer control unit is not transmitting/ receiving CAN communication signal for 2 seconds or more.	CAN communication error     Malfunction of transfer control unit

#### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "U1000" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-91</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

## Diagnosis Procedure

## 1. PERFORM SELF-DIAGNOSIS

(P)With CONSULT-III Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "U1000" detected?

>> Proceed to LAN-18, "Trouble Diagnosis Flow Chart". YES

>> INSPECTION END NO

DLN

Α

[TRANSFER: ATX90A]

F

Н

K

INFOID:0000000006222302

N

## **U1010 CONTROL UNIT (CAN)**

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

**Description** 

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

DTC Logic

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of transfer control unit.	Malfunction of transfer control unit

#### DTC CONFIRMATION PROCEDURE

## 1.DTC REPRODUCTION PROCEDURE

#### (P)With CONSULT-III

- 1. Turn the ignition switch OFF to ON.
- 2. Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is DTC "U1010" detected?

YES >> Proceed to diagnosis procedure. Refer to <u>DLN-92</u>, "<u>Diagnosis Procedure</u>".

NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000006222305

[TRANSFER: ATX90A]

## 1. CHECK TRANSFER CONTROL UNIT

Check transfer control unit harness connector for disconnection and deformation.

#### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Repair or replace error-detected parts.

[TRANSFER: ATX90A] < DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

Description INFOID:0000000006222306

Supplies power to 4WD system.

Diagnosis Procedure

# 1.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

- 1. Turn the ignition switch OFF.
- 2. Disconnect transfer control unit harness connector.
- Check the voltage between transfer control unit harness connector and ground.

Transfer of	control unit	_	Voltage
Connector Terminal			voltage
E59	20	Ground	Battery voltage

Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

5. Check the voltage between transfer control unit harness connector and ground.

Transfer	control unit	_	Voltage
Connector Terminal			Voltage
E59	20	Ground	Battery voltage

#### Is the inspection result normal?

YES >> GO TO 3. NO >> GO TO 2.

## 2.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

- Turn the ignition switch OFF.
- Check the 10A fuse (#34).
- Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to PG-11, "Wiring Diagram - BAT-TERY POWER SUPPLY -".

NO >> Repair or replace error-detected parts.

## 3.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (3)

- Turn the ignition switch OFF.
- Check the voltage between transfer control unit harness connector and ground.

Transfer control unit			Voltage
Connector	Terminal		vollage
E59	32	Ground	Approx. 0 V

Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

Check the voltage between transfer control unit harness connector and ground.

Transfer of	control unit		Voltage
Connector	Terminal		voltage
E59	32	Ground	Battery voltage

**DLN-93** Revision: 2010 May 2011 QX56

DLN

Α

В

INFOID:0000000006222307

Е

Н

K

M

Ν

[TRANSFER: ATX90A]

#### < DTC/CIRCUIT DIAGNOSIS >

#### Is the inspection result normal?

YES >> GO TO 5. NO >> GO TO 4.

## 4.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (4)

- 1. Turn the ignition switch OFF.
- Check the 10A fuse (#56).
- 3. Disconnect IPDM E/R harness connector.
- 4. Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

IPDM E/R		Transfer control unit		Continuity
Connector	Terminal	Connector	Terminal	Continuity
E15	58	E59	32	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

Transfer control unit		_	Continuity
Connector	Terminal		Continuity
E59	32	Ground	Not existed

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to <u>PG-89, "Wiring Diagram - IGNITION POWER SUPPLY -".</u>

NO >> Repair or replace error-detected parts.

## 5. CHECK TRANSFER MOTOR POWER SUPPLY

- 1. Turn the ignition switch OFF.
- 2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		_	Voltage
Connector	Terminal	_	voltage
E60	41	Ground	Battery voltage

3. Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

4. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		_	Voltage
Connector	Terminal		voltage
E60	41	Ground	Battery voltage

### Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

## 6.CHECK TRANSFER MOTOR POWER SUPPLY CIRCUIT

- 1. Turn the ignition switch OFF.
- 2. Check the 30A fusible link (J).
- Check the harness for open or short between transfer control unit harness connector No.41 terminal and 30A fusible link (J).

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to <u>PG-11, "Wiring Diagram - BAT-TERY POWER SUPPLY -"</u>.

NO >> Repair or replace error-detected parts.

## 7.CHECK 4WD SWITCH ASSEMBLY POWER SUPPLY (1)

1. Turn the ignition switch OFF.

#### < DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Α

В

DLN

Е

K

M

Ν

Р

2. Disconnect 4WD switch assembly harness connector.

Check the voltage between 4WD switch assembly harness connector and ground.

4WD switch assembly			Voltage
Connector	Terminal		voltage
M54	12	Ground	Approx. 0 V

4. Turn the ignition switch ON.

#### **CAUTION:**

#### Never start the engine.

5. Check the voltage between 4WD switch assembly harness connector and ground.

4WD switch assembly			Voltage
Connector	Terminal	_	voltage
M54	12	Ground	Battery voltage

#### Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 8.

## 8.CHECK 4WD SWITCH ASSEMBLY POWER SUPPLY (2)

- 1. Turn the ignition switch OFF.
- 2. Check the 10A fuse (#13).
- 3. Disconnect fuse block (J/B) harness connector.
- 4. Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

Fuse bl	ock (J/B)	4WD switch assembly		Continuity
Connector	Terminal	Connector	Terminal	Continuity
M3	10C	M54	12	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

4WD switch assembly			Continuity
Connector	Terminal		Continuity
M54	12	Ground	Not existed

#### Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to <u>PG-89, "Wiring Diagram - IGNITION POWER SUPPLY -".</u>

NO >> Repair or replace error-detected parts.

## 9. CHECK TRANSFER CONTROL UNIT GROUND

Turn the ignition switch OFF.

2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit			Voltage
Connector	Terminal	_	voltage
E60	44	Ground	Approx. 0 V
Loo	46	Ground	Арргох. 0 V

3. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit			Continuity
Connector	Terminal	_	Continuity
E60	44	Ground	Existed
E00	46		LAISIEU

[TRANSFER: ATX90A]

### < DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace error-detected parts.

10.check 4wd switch assembly ground

- 1. Turn the ignition switch OFF.
- 2. Check the voltage between transfer control unit harness connector and ground.

4WD switc	h assembly		Voltage	
Connector	Terminal	_		
M54	20	Ground	Approx. 0 V	

#### Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

#### **4WD WARNING LAMP**

## [TRANSFER: ATX90A] < DTC/CIRCUIT DIAGNOSIS > **4WD WARNING LAMP** Α Component Function Check INFOID:0000000006222308 1.CHECK 4WD WARNING LAMP FUNCTION В Turn the ignition switch OFF to ON. Check that 4WD warning lamp light up. Is the inspection result normal? YES >> INSPECTION END NO >> Proceed diagnosis procedure. Refer to <u>DLN-97</u>, "<u>Diagnosis Procedure</u>". DLN Diagnosis Procedure INFOID:00000000006222309 1. CHECK POWER SUPPLY AND GROUND CIRCUIT Е Perform the trouble diagnosis for power supply and ground circuit. Refer to DLN-64, "Diagnosis Procedure" Is the inspection result normal? YES >> GO TO 2. F NO >> Repair or replace the error-detected parts. 2. PERFORM SELF-DIAGNOSIS (P)With CONSULT-III Perform self-diagnosis for "ALL MODE AWD/4WD". Is any DTC detected? Н YES >> Check the DTC. NO >> GO TO 3. 3.CHECK 4WD WARNING LAMP SIGNAL (II) With CONSULT-III Turn the ignition switch ON. **CAUTION:** Never start the engine. Check "4WD FAIL LAMP" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD". Does the item on "DATA MONITOR" indicate "On"? YES >> Check combination meter. Refer to MWI-64, "COMBINATION METER: Diagnosis Procedure". >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation". NO L Ν

#### **4WD INDICATOR LAMP**

< DTC/CIRCUIT DIAGNOSIS >

### **4WD INDICATOR LAMP**

## Component Function Check

INFOID:0000000006222310

[TRANSFER: ATX90A]

## 1. CHECK 4WD MODE INDICATOR LAMP FUNCTION

1. Start the engine

#### **CAUTION:**

#### Never drive the vehicle.

- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Check the 4WD shift switch position ("AUTO", "4H" and "4L") and the indication of the 4WD mode indicator lamp mutually coincide.

#### Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to <a href="DLN-98">DLN-98</a>, "Diagnosis Procedure".

### Diagnosis Procedure

INFOID:0000000006222311

## 1. CHECK POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for power supply and ground circuit. Refer to <u>DLN-64, "Diagnosis Procedure"</u>. <u>Is the inspection result normal?</u>

YES >> GO TO 2.

NO >> Repair or replace the error-detected parts.

## 2.CHECK 4WD WARNING LAMP SIGNAL

### (I) With CONSULT-III

1. Strat the engine.

#### **CAUTION:**

#### Never drive the vehicle.

- Turn the 4WD shift switch AUTO⇒4H⇒4LO⇒4H⇒AUTO.
- Check "4WD MODE IND" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status		
	4WD shift switch: AUTO	AUTO		
4WD MODE IND	4WD shift switch: 4H	4H		
	4WD shift switch: 4L	4L		

### Is the inspection result normal?

YES >> Check combination meter. Refer to MWI-64, "COMBINATION METER: Diagnosis Procedure".

NO >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

### HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

[TRANSFER: ATX90A] < SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

## HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

Description INFOID:0000000006222312

Heavy tight-corner braking symptom occurs when the vehicle is driven and the steering wheel is turned fully to either side after the engine is started. NOTE:

Light tight-corner braking symptom may occur depending on driving conditions. This is not malfunction.

## 1.PERFORM ECM SELF-DIAGNOSIS

(P)With CONSULT-III Perform self-diagnosis for "ECM".

#### Is any DTC detected?

Diagnosis Procedure

YES >> Check the DTC. Refer to EC-98, "DTC Index".

NO >> GO TO 2.

## 2.perform self-diagnosis

#### With CONSULT-III

Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is any DTC detected?

YES >> Check the DTC. Refer to <u>DLN-29</u>, "<u>DTC Index</u>".

NO >> GO TO 3.

## 3.CHECK TRANSFER INTERNAL FUNCTION

#### (II) With CONSULT-III

- Remove transfer control actuator. Refer to <u>DLN-114</u>, "Removal and Installation".
- Turn the actuator shaft. Refer to <u>DLN-114</u>, "Inspection".
- Check "ROTARY POSI SEN" of CONSULT-III "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status			
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing			

#### Is the inspection result normal?

#### YES >> INSPECTION END

NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to <u>DLN-121</u>, "Removal and Installation".

**DLN-99** Revision: 2010 May 2011 QX56 Α

В

C

INFOID:0000000006222313

DLN

Е

F

Н

L

M

Ν

### **4WD MODE DOES NOT CHANGE**

< SYMPTOM DIAGNOSIS >

## **4WD MODE DOES NOT CHANGE**

Description INFOID:0000000006222314

Vehicle does not enter 4-wheel drive mode even though 4WD warning lamp turned to OFF.

### Diagnosis Procedure

INFOID:0000000006222315

[TRANSFER: ATX90A]

## 1.PERFORM SELF-DIAGNOSIS

### ®With CONSULT-III

Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is any DTC detected?

YES >> Check DTC. Refer to <u>DLN-29</u>, "<u>DTC Index</u>".

NO >> GO TO 2.

### 2. CHECK 4WD MODE INDICATOR LAMP

Check 4WD mode indicator lamp function. Refer to DLN-98, "Component Function Check".

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Proceed to diagnosis procedure. Refer to <u>DLN-98</u>, "<u>Diagnosis Procedure</u>".

## 3.CHECK 4WD SHIFT SWITCH

Perform rouble diagnosis of the 4WD shift switch. Refer to <u>DLN-67</u>, "<u>Diagnosis Procedure</u>".

#### Is the inspection result normal?

YES >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to <u>DLN-121</u>, <u>"Removal and Installation"</u>.

NO >> Replace 4WD switch assembly. Refer to <u>DLN-108</u>, "Removal and Installation".

### **4WD MODE INDICATOR LAMP CONTINUES BLINKING**

[TRANSFER: ATX90A] < SYMPTOM DIAGNOSIS > 4WD MODE INDICATOR LAMP CONTINUES BLINKING Α Description INFOID:0000000006222316 After shift the 4WD mode 4H to 4L, 4WD mode indicator lamp continues to blink. В Diagnosis Procedure INFOID:0000000006222317 1. MOVE THE VEHICLE C Move the vehicle back and forth. Does the 4WD indicator lamp stop to blink? DLN >> INSPECTION END YES NO >> GO TO 2. 2.CHECK 4WD MODE INDICATOR LAMP Е Check 4WD mode indicator lamp function. Refer to DLN-98, "Component Function Check". Is the inspection result normal? F YES >> GO TO 3. NO >> Proceed to diagnosis procedure. Refer to <u>DLN-98</u>, "Diagnosis Procedure". 3.PERFORM SELF-DIAGNOSIS (P)With CONSULT-III Perform self-diagnosis for "ALL MODE AWD/4WD". Is any DTC detected? Н YES >> Check DTC. Refer to DLN-29, "DTC Index". NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to DLN-121, "Removal and Installation". K L M Ν

### **4WD WARNING LAMP BLINKS QUICKLY**

[TRANSFER: ATX90A]

< SYMPTOM DIAGNOSIS >

## **4WD WARNING LAMP BLINKS QUICKLY**

Description INFOID:00000000000222318

While driving, 4WD warning lamp blinks 2 times in 1 second and it turns OFF after 1 minute.

- This symptom protects drivetrain parts when a heavy load is applied to the electric controlled coupling and multiple disc clutch temperature increases. Also, optional distribution of torque sometimes becomes rigid before lamp blinks quickly. Both cases are not malfunction.
- When this symptom occurs, stop vehicle and allow it to idle for some times. Blinking will stop and system will be restored.

**4WD WARNING LAMP BLINKS SLOWLY** [TRANSFER: ATX90A] < SYMPTOM DIAGNOSIS > **4WD WARNING LAMP BLINKS SLOWLY** Α Description INFOID:0000000006222319 4WD warning lamp blinks at approximately 2 seconds intervals while driving. В Diagnosis Procedure INFOID:0000000006222320 1. CHECK TIRE C Check the following. Tire pressure DLN Wear condition • Front and rear tire size (There is no difference between front and rear tires.) Is the inspection result normal? Е YES >> GO TO 2. >> Repair or replace error-detected parts. And then, drive the vehicle at speed of 20 km/h (12 MPH) NO or more for 5 seconds or more. Improper size information is initialized accordingly. 2. TERMINAL INSPECTION F Check 4WD control unit harness connector for disconnection. Is the inspection result normal? YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation". NO >> Repair or replace the error-detected parts. Н K L M Ν

Revision: 2010 May **DLN-103** 2011 QX56

### INFORMATION DISPLAY IS NOT DISPLAYED

< SYMPTOM DIAGNOSIS >

## INFORMATION DISPLAY IS NOT DISPLAYED

**Description** 

Information display is not displayed.

#### NOTE:

When the combination meter receives 4WD shift switch signal, it displays a message on the information display and inform the driver of 4WD mode status. About indication contents, refer to <a href="DLN-18">DLN-18</a>, "4WD SYSTEM: System Description" (4WD mode).

## Diagnosis Procedure

INFOID:0000000006222322

[TRANSFER: ATX90A]

### 1. CHECK 4WD SHIFT SWITCH

Perform trouble diagnosis for 4WD shift switch. Refer to <u>DLN-67</u>, "Diagnosis Procedure".

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

### CHECK 4WD MODE INDICATOR LAMP

Perform trouble diagnosis for 4WD mode indicator. Refer to <u>DLN-98</u>, "<u>Diagnosis Procedure</u>".

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

### 3.CHECK THE INFORMATION DISPLAY

Check that information except 4WD mode is displayed on information display.

#### Is the inspection result normal?

YES >> Replace transfer control unit. Refer to <u>DLN-107</u>, "Removal and Installation".

NO >> Check information display. Refer to MWI-29, "On Board Diagnosis Function".

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING [TRANSFER: ATX90A]

< SYMPTOM DIAGNOSIS >

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## **NVH Troubleshooting Chart**

INFOID:0000000006222323

Α

В

С

DLN

Е

F

G

Н

Use the chart below to find the cause of the symptom. parts.	The numbers indicate the order	er of the inspection. If	necessary, r	epair or rep	lace these
		= 1			

Reference			DLN-106, "Inspection"		I	Front oil seal: <u>DLN-109, "Exploded View"</u> Rear oil seal: <u>DLN-111, "Exploded View"</u>	I		
SUSPECTED P/ (Possible cause)		TRANSFER FLUID (Level low)	TRANSFER FLUID (Wrong)	TRANSFER FLUID (Level too high)	LIQUID GASKET (Damaged)	OIL SEAL (Worn or damaged)	GEAR (Worn or damaged)	BEARING (Worn or damaged)	TRANSFER CASE (Damaged)
Symptom	Noise	1	2				3	3	3
Symptom	Transfer fluid leakage		4	1	2	2			3

L

K

M

Ν

0

## PERIODIC MAINTENANCE

### TRANSFER FLUID

Inspection INFOID:000000006222324

#### FLUID LEAKAGE

Check transfer surrounding area (oil seal, drain plug, and filler plug etc.) for fluid leakage.

#### **FLUID LEVEL**

1. Remove filler plug (1) and gasket. Then check that fluid is filled up from mounting hole for the filler plug.

#### **CAUTION:**


Never start engine while checking fluid level.

2. Set a new gasket onto filler plug (1), and install it on transfer and then tighten to the specified torque.

Specified torque : 33 N·m (3.4 kg-m, 24 ft-lb)

**CAUTION:** 

Never reuse gasket.



[TRANSFER: ATX90A]

INFOID:0000000006222325

INFOID:0000000006222326


## Draining

- Run the vehicle to warm up the transfer unit sufficiently.
- 2. Stop the engine.
- 3. Remove the drain plug (1) and drain transfer fluid.
- 4. Set a new gasket onto drain plug (1), and install it to transfer and tighten to the specified torque.

Specified torque : 33 N-m (3.4 kg-m, 24 ft-lb)

**CAUTION:** 

Never reuse gasket.



## Refilling

1. Remove filler plug (1). Fill up with new transfer fluid up to mounting hole for the filler plug.

Fluid grade and Viscosity : Refer to MA-10, "Fluids

and Lubricants".


Fluid capacity : Refer to <u>DLN-124</u>, "Gen-

eral Specifications".

#### **CAUTION:**

Carefully fill the fluid. (Fill up for approximately 3 minutes.)

- 2. Leave the vehicle for 3 minutes, and check the fluid level again.
- Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque.



Specified torque : 33 N-m (3.4 kg-m, 24 ft-lb)

#### **CAUTION:**

Never reuse gasket.

Perform learning of transfer fluid viscosity. Refer to <u>DLN-47, "Work Procedure"</u>.

### TRANSFER CONTROL UNIT

< REMOVAL AND INSTALLATION >

# REMOVAL AND INSTALLATION

## TRANSFER CONTROL UNIT

#### Removal and Installation

#### **REMOVAL**

- 1. Turn the ignition switch OFF.
- 2. Disconnect negative battery terminal.

#### **CAUTION:**

### Wait for 5 seconds after turning ignition switch OFF.

- 3. Remove the glove box assembly. Refer to IP-14, "Removal and Installation".
- 4. Disconnect the transfer control unit connector.
- Move instrument lower cover to backward. Refer to IP-14, "Removal and Installation".
- 6. Remove the transfer control unit.

#### **INSTALLATION**

Note the following, and install in the reverse order of removal.

 When replacing transfer control unit, perform writing unit parameter and initial calibration. Refer to <u>DLN-41</u>, "Work Procedure".

DLN

Α

В

C

[TRANSFER: ATX90A]

INFOID:0000000006222327

Е

F

Н

K

L

M

Ν

### **4WD MODE SWITCH**

## < REMOVAL AND INSTALLATION >

## **4WD MODE SWITCH**

### Removal and Installation

INFOID:00000000006222328

[TRANSFER: ATX90A]

#### **REMOVAL**

#### NOTE:

4WD shift switch is integrated in 4WD switch assembly.


- Remove console finisher assembly from center console assembly. Refer to <u>IP-25, "Removal and Installation"</u>
- 2. Disconnect 4WD switch assembly harness connector.
- 3. Press 4WD switch assembly fixing pawls, and remove 4WD switch assembly from console finisher assembly.

#### **INSTALLATION**

Install in the reverse order of removal.

### FRONT OIL SEAL

**Exploded View** INFOID:0000000006222329



- Plug
- Transfer assembly
- Front shaft flange
- ∀
   □: Vehicle front
- ?: Apply transfer fluid. Refer to MA-10, "Fluids and Lubricants". Refer to GI-4, "Components" for symbols not described above.
- O-ring
- Front oil seal
- Snap ring
- Dust shield

### Removal and Installation

**REMOVAL** 

- Remove the drain plug to drain the transfer fluid. Refer to <u>DLN-106, "Draining"</u>.
- Remove the front propeller shaft. Refer to <u>DLN-129</u>, "Removal and Installation".
- Remove the plug.
- 4. Remove the O-ring from the plug.
- 5. Remove the snap ring.
- 6. Remove the front shaft flange, using a plastic hammer.
- 7. Remove the dust shield from the front shaft flange, using puller and replacer.

: Puller (commercial service tool) : Replacer (commercial service tool)

8. Remove front oil seal from front case. **CAUTION:** 

Never damage the front case.

JPDIE0163ZZ

**INSTALLATION** 

Α

В

DLN

[TRANSFER: ATX90A]

Н

INFOID:0000000006222330

Ν

#### FRONT OIL SEAL

#### < REMOVAL AND INSTALLATION >

1. Install front oil seal with a drift (A) (commercial service tool) within the dimension (L) shown as follows.

#### **CAUTION:**

- Never reuse front oil seal.
- Apply transfer fluid onto circumference of oil seal.
- 2. Install the dust shield to the front shaft flange.
- 3. Install the front shaft flange.
- 4. Install the snap ring.


#### **CAUTION:**

Never reuse the snap ring.

5. Install the O-ring to plug.

#### **CAUTION:**


- Never reuse the O-ring.
- Never damage the O-ring.
- 6. Tighten the plug to specified torque.
- 7. Install front propeller shaft. Refer to <u>DLN-129</u>, "Removal and Installation".
- 8. Fill with new transfer fluid, check fluid level and for fluid leakage. Refer to <u>DLN-106</u>, "Inspection".



[TRANSFER: ATX90A]

### REAR OIL SEAL

**Exploded View** INFOID:0000000006222331



Adjusting shim

Dust shield

- Snap ring
- Rear companion flange
- Transfer assembly
- ∀
   □: Vehicle front

**REMOVAL** 

?: Apply transfer fluid. Refer to MA-10, "Fluids and Lubricants".

Refer to GI-4, "Components" for symbols not described above.

- O-ring
- Rear oil seal

#### Removal and Installation


Remove the rear propeller shaft. Refer to <u>DLN-144, "Removal and Installation"</u>.

2. Put matching marks (A) on the end of the main shaft and the rear companion flange.

**CAUTION:** 

For matching mark, using paint. Never damage main shaft.

- Remove the snap ring.
- 4. Remove the adjusting shim.
- 5. Remove the rear companion flange, using a plastic hammer.



Remove the dust shield from rear companion flange, using the drift, puller and replacer.

> : Drift [SST: ST30701000 (J-25742-2)] В : Puller (commercial service tool)

: Replacer (commercial service tool)


- 7. Remove the o-ring from rear companion flange.
- Remove the rear oil seal from rear case.

**CAUTION:** 

Never damage rear case and main shaft.

INSTALLATION

Revision: 2010 May



DLN

Α

В

[TRANSFER: ATX90A]

INFOID:0000000006222332

K


Ν

#### < REMOVAL AND INSTALLATION >

 Install rear oil seal, with a drift (A) [SST: KV40104710 ( ] within the dimension (L) show as follows.

#### **CAUTION:**


- Never reuse front oil seal.
- Apply transfer fluid onto circumference of oil seal.
- 2. Install the dust shield to the rear companion flange.




[TRANSFER: ATX90A]

Install the rear companion flange to main shaft. CAUTION:

# Align the matching marks (A) of main shaft and rear companion flange.




 Install bolt (A) (M12×1.75 mm) to main shaft, then install the rear companion flange by hammering while pulling the bolt.



4. Install the O-ring (3) to gap between rear companion flange (1) and main shaft (2).

#### **CAUTION:**

- · Never reuse the O-ring.
- Never damage the O-ring.
- 5. Select adjusting shim. Refer to <a href="DLN-112">DLN-112</a>, "Adjustment".
- 6. Install adjusting shim.
- 7. Install the snap ring.
- 8. Install the rear propeller shaft. Refer to <a href="DLN-144">DLN-144</a>, "Removal and Installation".
- 9. Check fluid level and for fluid leakage. Refer to <u>DLN-106.</u> "Inspection".



Adjustment INFOID:000000006222333


#### **ADJUSTING SHIM**

- 1. Remove the snap ring.
- 2. Remove the adjusting shim.
- Remove the O-ring.

#### **REAR OIL SEAL**

#### < REMOVAL AND INSTALLATION >

- Install the thinnest adjusting shim.
- 5. Install the snap ring to main shaft.
- 6. Install the bolt (A) (M12×1.75 mm) to main shaft, then hummer the rear companion flange while pulling the bolt.



[TRANSFER: ATX90A]

DLN

Е

F

Н

Α

В

- 7. Fit a dial indicator onto the end of main shaft.
- 8. Check the clearance between rear companion flange and main shaft during pushing the bolt (A) at  $\leftarrow$  direction.
- 9. Use the formula below to calculate adjusting shim thickness.




$$T = T_0 + (C - 0.1)$$

T: **Correct shim thickness** 

To: The thinnest shim thickness

C: Measured clearance between rear companion flange and main shaft



**CAUTION:** 

Adjusting shim thickness is in step of 0.1 mm. When a calculation result includes the second decimal place, it must be rounded down.

**Example:** 

$$T = 2.1 + (0.34 - 0.1) = 2.34$$

To: 2.1 C: 0.34

Caluculated value... T = 2.34 mm

Used shim... T = 2.3 mm

10. Select the proper adjusting shim. For selecting adjusting shim, refer to the latest parts information.

J

K


L

Ν

Р

### TRANSFER CONTROL ACTUATOR

Exploded View



- 1. Transfer assembly
- 2. Transfer control actuator

∀
 : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

INFOID:0000000006222335

[TRANSFER: ATX90A]

#### **REMOVAL**

#### **CAUTION:**

If DTC about transfer control actuator is detected, perform inspection after removal.

- 1. Turn the ignition switch OFF.
- Disconnect negative battery terminal.

#### **CAUTION:**

Wait for 5 seconds after turning ignition switch OFF.

- 3. Disconnect the transfer control actuator connector.
- 4. Remove the bolts and detach the transfer control actuator.
- 5. Perform inspection after removal. Refer to <a href="DLN-114">DLN-114</a>, "Inspection".

#### **INSTALLATION**

Note the following, and installing the reverse order of removal.

- · Never damage oil seal of transfer motor.
- If transfer control actuator has been replaced, perform writing the unit parameter. Refer to <u>DLN-48</u>, "Work Procedure"
- Perform inspection after installation. Refer to <a href="DLN-114">DLN-114</a>, "Inspection"</a>

Inspection INFOID:0000000000222336

#### INSPECTION AFTER REMOVAL

- Check the oil seal assembled transfer control actuator for wear, crack and damage. Replace if there is malfunction.
- Check the transfer assembly as follows.

#### TRANSFER CONTROL ACTUATOR


#### < REMOVAL AND INSTALLATION >

Install the spline socket (A) [SST: KV10119400 ( — )] to transfer assembly in the figure.

When turn the shaft in (B) direction, check returning to (C) direction by spring power.
 CAUTION:

The maximum turning force shall be 30 N·m (3.1 kg-m, 22 ft-lb).

c. When turn the shaft in (C) direction, check locking the shaft.



[TRANSFER: ATX90A]

### INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer control actuator to transfer assembly for fluid leakage.

С

Α

В

DLN

Е

F

G

Н

J

Κ

L

M


Ν

0

Р

### TRANSFER HI-LO POSITION SENSOR

Exploded View



- 1. Transfer Hi-Lo position sensor
- 2. Transfer assembly

∀ : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

INFOID:0000000006222338

[TRANSFER: ATX90A]

#### **REMOVAL**

- 1. Turn the ignition switch OFF.
- Disconnect negative battery terminal.

#### **CAUTION:**

#### Wait for 5 seconds after turning ignition switch OFF.

- 3. Remove exhaust front tube (LH). Refer to EX-5, "Removal and Installation".
- 4. Support transfer assembly and transmission assembly with a jack.
- 5. Remove front suspension rear cross member with a power tool. Refer to TM-208, "4WD: Removal and Installation".
- 6. Remove rear engine mounting cross member with a power tool. Refer to <u>TM-208</u>, "4WD: Removal and <u>Installation"</u>.
- 7. Remove heat insulator of exhaust front tube (LH).
- 8. Lower jack to the position where the transfer Hi-Lo position sensor can be removed.
- 9. Disconnect the transfer Hi-Lo position sensor connector.
- 10. Remove the transfer Hi-Lo position sensor.
- 11. Perform inspection after removal. Refer to <a href="DLN-116">DLN-116</a>, "Inspection".

#### **INSTALLATION**

Note the following, and install in the reverse order of removal.

- Never damage O-ring of transfer Hi-Lo position sensor.
- Perform inspection after installation. Refer to <u>DLN-116</u>, "Inspection".

Inspection

#### INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer Hi-Lo position sensor for wear, crack and damage. Replace the transfer Hi-Lo position sensor if there is malfunction.


#### INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer Hi-Lo position sensor to transfer assembly for fluid leakage.

Revision: 2010 May **DLN-116** 2011 QX56

### TRANSFER ROTARY POSITION SENSOR

Exploded View



- 1. Transfer assembly
- 2. Transfer rotary position sensor

∀
 : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

**REMOVAL** 

- Turn the ignition switch OFF.
- Disconnect negative battery terminal.

#### CAUTION:


Wait for 5 seconds after turning ignition switch OFF.

- 3. Support transfer assembly and transmission assembly with a jack.
- 4. Remove front suspension rear cross member with a power tool. Refer to <u>TM-208</u>, "4WD : Removal and <u>Installation"</u>.
- 5. Remove rear engine mounting cross member with a power tool. Refer to <u>TM-208, "4WD : Removal and Installation"</u>.
- 6. Disconnect the transfer rotary position sensor connector.
- 7. Remove the transfer rotary position sensor.
- 8. Perform inspection after removal. Refer to <a href="DLN-118">DLN-118</a>, "Inspection".

#### INSTALLATION

- Remove the transfer control actuator. Refer to DLN-114, "Exploded View"
- 2. Shift transfer assembly into AUTO as follows.
- a. Install the spline socket (A) [SST: KV10119400 ( )] to transfer assembly in the figure.
- Turn the shaft (B) direction and remove the spline socket at a position returning to (C) direction by spring power.

The maximum turning force shall be 30 N·m (3.1 kg-m, 22 ft-lb).



DLN

Α

В

[TRANSFER: ATX90A]

Е

G

Н

INFOID:0000000006222341

K

IVI

Ν


0

#### TRANSFER ROTARY POSITION SENSOR

#### < REMOVAL AND INSTALLATION >

c. Check that the surface fitting transfer rotary position sensor to transfer assembly is in the figure.


∀ : Vehicle front



[TRANSFER: ATX90A]

Install the transfer rotary position sensor. CAUTION:

- Check that part (A) of transfer rotary position sensor is in the position (B).
- Never damage O-ring of transfer rotary position sensor.
- 4. Connect transfer rotary position sensor connector.
- 5. Install the transfer control actuator. Refer to <a href="DLN-114">DLN-114</a>, "Exploded <a href="View"</a>.
- 6. Perform inspection after installation. Refer to <u>DLN-118</u>, "Inspection".
- 7. When replacing the transfer rotary position sensor, perform learning of transfer rotary position sensor. Refer to <a href="DLN-46">DLN-46</a>, "Work Procedure".



Inspection INFOID:0000000000222342

#### INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer rotary position sensor for wear, crack and damage. Replace the transfer rotary position sensor if there is malfunction.

#### INSPECTION AFTER INSTALLATION


After driving, check the surface fitting transfer rotary position sensor to transfer assembly for fluid leakage.

#### TRANSFER LOCK POSITION SENSOR

< REMOVAL AND INSTALLATION >

### TRANSFER LOCK POSITION SENSOR

**Exploded View** INFOID:0000000006222343



- 1. Transfer lock position sensor
- Transfer assembly

∀
 : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

**REMOVAL** 

- 1. Turn the ignition switch OFF.
- Disconnect negative battery terminal.

#### CAUTION:

Wait for 5 seconds after turning ignition OFF.

- 3. Support transfer assembly and transmission assembly with a jack.
- 4. Remove rear engine mounting cross member with a power tool. Refer to TM-208, "4WD: Removal and Installation".
- Lower jack to the position where the transfer lock position sensor can be removed.
- Disconnect the transfer lock position sensor connector.
- Remove the transfer lock position sensor.
- Perform inspection after removal. Refer to <u>DLN-119</u>, "Inspection".

#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Never damage O-ring of transfer lock position sensor.
- Perform inspection after installation. Refer to <u>DLN-119</u>, "Inspection".
- When replacing the transfer lock position sensor, perform learning of transfer lock position sensor. Refer to DLN-44, "Work Procedure"

Inspection INFOID:0000000006222345

#### INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer lock position sensor for wear, crack and damage. Replace the transfer lock position sensor if there is malfunction.

#### INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer lock position sensor to transfer assembly for fluid leakage.

**DLN-119** Revision: 2010 May 2011 QX56

В

Α

[TRANSFER: ATX90A]

DLN

INFOID:0000000006222344


N

#### TRANSFER FLUID TEMPERATURE SENSOR

< REMOVAL AND INSTALLATION >

### TRANSFER FLUID TEMPERATURE SENSOR

Exploded View



- 1. Transfer assembly
- 2. Transfer fluid temperature sensor

∀
 □: Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

INFOID:0000000006222347

[TRANSFER: ATX90A]

#### **REMOVAL**

- 1. Drain transfer fluid. Refer to <a href="DLN-106">DLN-106</a>, "Draining".
- 2. Disconnect the transfer fluid temperature sensor connector.
- 3. Remove the transfer fluid temperature sensor.
- 4. Perform inspection after removal. Refer to DLN-120, "Inspection".

#### **INSTALLATION**

Note the following, and install in the reverse order of removal.

- Perform inspection after installation. Refer to <u>DLN-120</u>, "Inspection".
- After refilling new transfer fluid, perform learning of transfer fluid viscosity. Refer to <u>DLN-47</u>, "Work <u>Procedure"</u>.

Inspection INFOID:000000006222348

#### INSPECTION AFTER REMOVAL

Check the washer assembled transfer fluid temperature sensor for wear, crack and damage. Replace the transfer fluid temperature sensor if there is malfunction.


#### INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer fluid temperature sensor to transfer assembly for fluid leakage.

## UNIT REMOVAL AND INSTALLATION

### TRANSFER ASSEMBLY

**Exploded View** INFOID:0000000006222349



1. Bracket

2. Bracket

3. Transfer assembly

: Vehicle front

#### Removal and Installation

**REMOVAL** 

- Remove rear propeller shaft. Refer to <u>DLN-144</u>, "Removal and Installation".
- Remove front propeller shaft. Refer to <u>DLN-129</u>, "Removal and Installation".
- Disconnect transfer control actuator, transfer rotary position sensor, transfer lock position sensor, transfer Hi-Lo position sensor and transfer fluid temperature sensor harness connectors and separate harnesses from transfer assembly.
- Remove transfer breather hose.
- Remove exhaust front tube (LH) with a power tool. Refer to <u>EX-5, "Removal and Installation"</u>.
- Remove exhaust front tube (RH) with a power tool. Refer to EX-5, "Removal and Installation".
- Remove main muffler with a power tool. Refer to EX-5, "Removal and Installation".
- Support transfer assembly and transmission assembly with a jack. **CAUTION:**

Secure transfer assembly and transmission assembly to a jack.

- Remove rear engine mounting member and engine mounting insulator with a power tool. Refer to <u>EM-99</u>. "Removal and Installation".
- Lower jack to the position where the top transfer mounting bolts can be removed.
- 11. Remove transfer mounting bolts and separate transfer from transmission.

**CAUTION:** Secure transfer assembly and transmission assembly to a jack.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

INFOID:00000000006222350

[TRANSFER: ATX90A]

Α

В

DLN

Е

Н

M

K

Ν

Р

2011 QX56


#### TRANSFER ASSEMBLY

#### < UNIT REMOVAL AND INSTALLATION >

 When installing the transfer to the transmission, install the mounting bolts following the standard below, tighten bolts to the specified torque.


Bolt symbol	A	В
Insertion direction	Transfer to transmission	Transmission to transfer

: Tightening the bolt with bracket




[TRANSFER: ATX90A]

- When installing transfer breather hose, make sure there are no pinched or restricted areas on the transfer breather hose caused by bending or winding.
- Install the transfer breather hose (1) of transmission side with the paint mark (A) facing upward and the mark (B) (: ←) facing right side.




- Install the transfer breather hose (1) of transfer side with the paint mark (A) facing upward, and insert breather hose to breather tube (2) until dimension (B) shown as follows.

B: 20 mm (0.79 in)




- Be sure to fix breather hose in (A) and (B) positions. Fix with the paint mark facing upward in the (A) position.
- Check oil level and check for oil leakage after installation. Refer to DLN-106, "Inspection".
- If replacing transfer assembly, perform writing unit parameter, learning of fluid viscosity and initial calibration. Refer to <u>DLN-42</u>. "Work Procedure".



### **INPUT OIL SEAL**

Exploded View



- 1. Transfer assembly
- 2. Input oil seal
- : Apply transfer fluid. Refer to MA-10, "Fluids and Lubricants".

∀
 □: Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### Removal and Installation

**REMOVAL** 


- 1. Remove transfer assembly from vehicle. Refer to <a href="DLN-121">DLN-121</a>, "Exploded View".
- Remove input oil seal from front case, using a suitable tool. CAUTION:

Never damage the front case and input.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Install input oil seal, with a drift (A) [SST: KV40104710 (
   —
   )] until it is flush with the end face of front case with the drift
   CAUTION:
  - Never reuse input oil seal.
  - · Apply transfer fluid onto circumference of oil seal.



С

Α

В

[TRANSFER: ATX90A]

DLN

Е

G

Н

INFOID:0000000006222352

K

\_

M

Ν

Р

### SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

## **General Specifications**

INFOID:0000000006222353

[TRANSFER: ATX90A]

		4WD
Applied model		V56VD
		A/T
Transfer model		ATX90A
Fluid capacity (Approx.)	$\ell$ (US pt, Imp pt)	1.5 (3-1/8, 2-5/8)

### **PREPARATION**

< PREPARATION >

[FRONT PROPELLER SHAFT: 2F P15]

## **PREPARATION**

### **PREPARATION**

**Commercial Service Tools** 

Tool name		Description	C
Power tool		Loosening bolts and nuts	DLN
	PBIC0190F		Е

Н Κ L M

Ν

0

Р

Α

В

F

G

INFOID:0000000006226729

### NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

### [FRONT PROPELLER SHAFT: 2F P15]

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

### **NVH Troubleshooting Chart**

INFOID:0000000006222354

×: Applicable

[FRONT PROPELLER SHAFT: 2F P15]

### PERIODIC MAINTENANCE

### FRONT PROPELLER SHAFT

Inspection INFOID:0000000006222355 В

#### NOISE


Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.

If vibration is present at high speed, inspect propeller shaft runout

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

Vehicle front

**Propeller shaft runout** : Refer to DLN-133, "Propeller Shaft Runout".



- 3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
- Check the vibration by driving vehicle.

#### RUNOUT MEASURING POINT


Propeller shaft runout measuring point (Point "△").

∀
 : Vehicle front

#### **Dimension**

Α : 80 - 100 mm (3.15 - 3.94 in) В : 100 - 120 mm (3.94 - 4.72 in)

C : 254.5 mm (10.02 in)



Front propeller shaft

Н

JPDID0321ZZ

Ν

M

Р

**DLN-127** Revision: 2010 May 2011 QX56

DLN

Е

F

Α


[FRONT PROPELLER SHAFT: 2F P15]

## REMOVAL AND INSTALLATION

### FRONT PROPELLER SHAFT

Exploded View

#### **REMOVAL**




1. Propeller shaft assembly

∀: Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### **DISASSEMBLY**



1. Flange yoke

2. Snap ring\*

3. Bearing\*

4. Journal\*

- 5. Propeller shaft
- \*: Replace "2", "3" and "4" as a set.

∀ : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### < REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]

#### Removal and Installation

INFOID:00000000006222357

#### REMOVAL

- 1. Shift the transmission to the neutral position, and then release the parking brake.
- 2. Remove protector A and B with power tool. Refer to SCS-39, "PPMU, MIDDLE TUBE ASSEMBLY, PPMU PIPE: Removal and Installation".
- Remove rear engine mount cross member with a power tool. Refer to <u>TM-208, "4WD : Removal and</u> Installation".
- 4. Put matching mark (A) on front propeller shaft flange yoke and final drive companion flange.

#### **CAUTION:**

For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.

5. Put matching mark (A) on front propeller shaft flange yoke and transfer companion flange.

#### **CAUTION:**


For matching mark, use paint. Never damage propeller shaft flange and transfer companion flange.

- 6. Remove the propeller shaft assembly fixing bolts.
- Remove propeller shaft assembly from the front final drive and transfer.
- Perform inspection after removal. Refer to <u>DLN-131, "Inspection"</u>.



Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
- Align matching mark (A) to install propeller shaft flange yoke and front final drive companion flange.
- After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange after rotating it by 90, 180, 270 degrees. Then perform driving test and check propeller shaft vibration again at each point.
- JPDIDO207ZZ
- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



Disassembly and Assembly

DISASSEMBLY

**A** 

DLN

Α

Е

F

Н

K

M

N

INFOID:0000000006222358


#### < REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]

1. Put a matching mark (A) between propeller shaft and flange yoke and remove snap rings (1).

#### **CAUTION:**


For matching mark, use paint. Never damage the surface.



2. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

#### **CAUTION:**

Never damage the yoke.



#### **ASSEMBLY**


1. Install journal bearing to journal.

#### **CAUTION:**

- Never reuse journal or journal bearing.
- · Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.
- 2. Install bearing (1) using a vise.

#### **CAUTION:**


Never damage bearing or flange yoke.



3. Install journal to propeller shaft so that grease nipple (1) on journal portion is in the same direction.

#### **CAUTION:**

Never reuse journal.



4. Measure journal axial play. If necessary, select the appropriate snap ring.

#### < REMOVAL AND INSTALLATION >

#### [FRONT PROPELLER SHAFT: 2F P15]


a. While pushing to 98 N·m (10 kg-m, 72 ft-lb), check the clearance between snap ring (1) and flange yoke (2).


Journal axial play : Refer to <u>DLN-133,</u> "Journal Axial Play"

b. If journal axial play is outside the specification, use a thicker/thinner snap ring to adjust.

#### **CAUTION:**

- · Never reuse snap ring.
- Select snap rings so that thickness difference between LH and RH is within 0.06 mm.
- 5. Install selected snap ring as shown in the figure.





6. Check that joint moves smoothly.

Reference value (After adaptation)


Bending resistance : 1.96 N·m (0.20 kg-m, 17 in-lb)

or less

#### NOTE:

The bending resistance [1.96 N.m (0.20 kg-m, 17 in-lb) or less] may not be satisfied soon after the installation.

7. Check the journal axial play. Refer to <a href="DLN-131">DLN-131</a>, "Inspection".



INFOID:0000000006222359

### INSPECTION AFTER REMOVAL

#### **Appearance**

Inspection

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.


#### Propeller Shaft Runout

Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly. For measuring point, refer to <a href="https://doi.org/linear.2017/bl/">DLN-127</a>. "Inspection".

Propeller shaft runout : Refer to <u>DLN-133</u>,

"Propeller Shaft

Runout"



Journal Axial Play

Revision: 2010 May **DLN-131** 2011 QX56

Α

В

С

DLN

Е

F

G

Н

J

K

M

L

N

0


P

< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play : Refer to <u>DLN-133,</u>
"Journal Axial Play"



### **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT PROPELLER SHAFT: 2F P15]

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### **General Specification**

		4WD						
Applied model		VK56VD						
		A/T						
Propeller shaft model		2F P15						
Number of joints		2						
1st joint		Shell type						
Type of journal bearings	2rd joint	Shell type						
Coupling method with transfe	er	Flange type						
Coupling method with rear fire	nal drive	Flange type						
Shaft length (Spider to spider)		729 mm (28.70 in)						
Shaft outer diameter		68.9 mm (2.713 in)						

### **Propeller Shaft Runout**

	Unit: mm (in)
Item	Limit
Propeller shaft runout	1.0 (0.04)

### Journal Axial Play

	Unit: mm (in)
Item	Standard
Journal axial play	0.06 (0.0024)

Α

В

INFOID:0000000006222360

C

DLN

F

Е

G

Н

INFOID:0000000006222362

INFOID:00000000006222361

J

K

L

 $\mathbb{N}$ 

Ν

0

Р

### NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING [REAR PROPELLER SHAFT: 2F P26]

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

### **NVH Troubleshooting Chart**

INFOID:0000000006222363

Use the chart below to help you fi	nd the cause of the sy	mpton	n. If ne	cessa	у, гера	air or r	eplace	these	parts.	,					,
Reference		DLN-142, "Inspection"	I	I	I	I	DLN-142, "Inspection"	DLN-142, "Inspection"	NVH of FRONT FINAL DRIVE in this section. NVH of REAR FINAL DRIVE in this section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECT	ΓED PARTS	Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
	Noise	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Symptom	Shake		×	.,	· ·	×	.,			×	×	×	×	×	×
A P I I .	Vibration	×	×	×	×	×	×	×		×	×		×		×

<sup>×:</sup> Applicable

[REAR PROPELLER SHAFT: 2F P26]

### PERIODIC MAINTENANCE

### REAR PROPELLER SHAFT

Inspection INFOID:00000000006222364 В

#### NOISE

Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.


If vibration is present at high speed, inspect propeller shaft runout

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

Vehicle front

**Propeller shaft runout** 

: Refer to DLN-147, "Propeller Shaft Runout".



- 3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
- Check the vibration by driving vehicle.

#### RUNOUT MEASURING POINT


Propeller shaft runout measuring point (Point "△").

∀
 : Vehicle front

#### **Dimension**

Α : 120 - 150 mm (4.72 - 5.91 in) В : 150 – 180 mm (5.91 – 7.09 in)

C : 703.5 mm (27.70 in)



DLN

Α

F

Н

M

Ν


Р

## REMOVAL AND INSTALLATION

### **REAR PROPELLER SHAFT**

Exploded View

#### **REMOVAL**




1. Propeller shaft assembly

∀: Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### DISASSEMBLY



1. Flange yoke

2. Snap ring\*

3. Bearing\*

4. Journal<sup>\*</sup>

- 5. Propeller shaft
- \*: Replace "2", "3" and "4" as a set.

∀ : Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### [REAR PROPELLER SHAFT: 2F P26]

### Removal and Installation

INFOID:0000000006222366

#### **REMOVAL**

- 1. Shift the transmission to the neutral position, and then release the parking brake.
- 2. Put matching mark (A) on rear propeller shaft flange yoke and rear drive companion flange.

#### **CAUTION:**

For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.

3. Put matching mark (A) on rear propeller shaft flange yoke and transfer companion flange.

#### **CAUTION:**


For matching mark, use paint. Never damage propeller shaft flange and transfer companion flange.

- 4. Remove the propeller shaft assembly fixing bolts.
- Remove propeller shaft assembly from the rear final drive and transfer.
- 6. Perform inspection after removal. Refer to <a href="DLN-146">DLN-146</a>, "Inspection".




Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
- Align matching mark (A) to install propeller shaft flange yoke and rear final drive companion flange.
- After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange after rotating it by 90, 180, 270 degrees. Then perform driving test and check propeller shaft vibration again at each point.



- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



Disassembly and Assembly

DISASSEMBLY

INFOID:00000000006222367

A JPDID0207ZZ

DLN

Α

F

Н

I

/

L

M

Ν

Р

#### **REAR PROPELLER SHAFT**


#### < REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]

1. Put a matching mark between propeller shaft and flange yoke and remove snap rings (1).

#### **CAUTION:**

For matching mark, use paint. Never damage the surface.




2. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

#### **CAUTION:**

Never damage the yoke.

3. Remove grease nipple.



#### **ASSEMBLY**


1. Install journal bearing to journal.

#### **CAUTION:**

- Never reuse journal or journal bearing.
- Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.
- 2. Install bearing (1) using a vise.

#### **CAUTION:**


Never damage bearing or flange yoke.



3. Install journal to propeller shaft so that grease nipple (1) on journal portion is in the same direction.

#### **CAUTION:**

Never reuse journal.




#### REAR PROPELLER SHAFT

#### < REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]

4. Install snap ring (1).



5. Check that joint moves smoothly.

Reference value (After adaptation)


Bending resistance : 2.26 N·m (0.23 kg-m, 20 in-lb)

or less

NOTE:

The bending resistance [2.26 N.m (0.23 kg-m, 20 in-lb) or less] may not be satisfied soon after the installation.

Check the journal axial play. Refer to <u>DLN-146, "Inspection"</u>.



INFOID:0000000006222368

Inspection

INSPECTION AFTER REMOVAL

Appearance

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.


Propeller Shaft Runout

Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly. For measuring point, refer to <u>DLN-142</u>, "Inspection".

Propeller shaft runout : Refer to <u>DLN-147</u>,

"Propeller Shaft


Runout"



Journal Axial Play

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play : Refer to <u>DLN-147</u>, "Journal Axial Play"



Α

В

С

DLN

Е

F

G

Н

J

K

L

M

Ν

0

Р

### SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 2F P26]

## SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### **General Specification**

INFOID:0000000006222369

		4WD						
Applied model		VK56VD						
		A/T						
Propeller shaft model		2F P26						
Number of joints		2						
Tune of journal bearings	1st joint	Shell type						
Гуре of journal bearings 2rd joint		Shell type						
Coupling method with transfe	er .	Flange type						
Coupling method with rear fir	nal drive	Flange type						
Shaft length (Spider to spider)		1168mm (45.98 in)						
Shaft outer diameter		101.6 mm (4.00 in)						

### Propeller Shaft Runout

INFOID:0000000006222370

	Unit: mm (in)
Item	Limit
Propeller shaft runout	1.0 (0.04)

### Journal Axial Play

INFOID:0000000006222371

	Unit: mm (in)
Item	Standard
Journal axial play	0 (0)

### NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING [REAR PROPELLER SHAFT: 2S1410]

Α

В

Р

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

### **NVH Troubleshooting Chart**

INFOID:00000000006222436

Use the chart below to help you fi	nd the cause of the sy	/mptor	n. If ne	cessa	ry, rep	air or r	eplace	these								
Reference		DLN-142, "Inspection"	I	I	I	I	DLN-142, "Inspection"	DLN-142, "Inspection"	NVH of FRONT FINAL DRIVE in this section. NVH of REAR FINAL DRIVE in this section.	NVH in RAX and RSU section.	NVH in WT section.	NVH in WT section.	NVH in RAX section.	NVH in BR section.	NVH in ST section.	C DLN E
Possible cause and SUSPECT		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING	H J K L
	Noise	×	×	×	×	×	×	×	×	×	×	×	×	×	×	Ν
Symptom	Shake		×			×				×	×	×	×	×	×	
	Vibration	×	×	×	×	×	×	×		×	×		×		×	$\circ$

<sup>×:</sup> Applicable

[REAR PROPELLER SHAFT: 2S1410]

## PERIODIC MAINTENANCE

### REAR PROPELLER SHAFT

Inspection INFOID:0000000006222437

#### **NOISE**

Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.

#### VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

 With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

**Propeller shaft runout** 


: Refer to <u>DLN-147, "Propeller Shaft Runout"</u>.


- If runout still exceeds specifications, separate propeller shaft at final drive companion flange; then rotate companion flange 90, 180, 270 degrees and install propeller shaft.
- 3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
- 4. Check the vibration by driving vehicle.

#### **RUNOUT MEASURING POINT**

Propeller shaft runout measuring range.

∀
 : Vehicle front





Α

C

DLN

Е

F

Н

K

M

Ν

0


Р

## REMOVAL AND INSTALLATION

### **REAR PROPELLER SHAFT**

Exploded View

**REMOVAL** 




1. Propeller shaft assembly

: Vehicle front

Refer to GI-4, "Components" for symbols not described above.

#### **DISASSEMBLY**



1. Flange yoke

Snap ring

Bearing

4. Journal

5. Propeller shaft

6. Sleeve yoke

∀
 : Vehicle front

Refer to  $\underline{\mbox{GI-4. "Components"}}$  for symbols not described above.

#### Removal and Installation

INFOID:0000000006222439


#### **REMOVAL**

- 1. Shift the transmission to the neutral position, and then release the parking brake.
- 2. Put matching mark (A) on rear propeller shaft flange yoke and rear drive companion flange.

#### **CAUTION:**

For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.


- 3. Remove the propeller shaft assembly fixing bolts.
- Remove propeller shaft assembly from the rear final drive and transfer.
- 5. Perform inspection after removal. Refer to <u>DLN-146, "Inspection"</u>.




#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
- Align matching mark (A) to install propeller shaft flange yoke and rear final drive companion flange.
- After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange after rotating it by 90, 180, 270 degrees. Then perform driving test and check propeller shaft vibration again at each point.



- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



### Disassembly and Assembly


INFOID:0000000006222440

#### DISASSEMBLY

1. Put a matching mark between propeller shaft and flange yoke as shown.

#### **CAUTION:**

For matching mark, use paint. Never damage the surface.




## REAR PROPELLER SHAFT

## < REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]


Remove snap ring.



3. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

### **CAUTION:**

Never damage the yoke.



### **ASSEMBLY**


1. Install journal bearing to journal.

### **CAUTION:**

- · Never reuse journal or journal bearing.
- · Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.
- 2. Install bearing (1) using a vise.

# **CAUTION:**

Never damage bearing or flange yoke.




- Measure journal axial play. If necessary, select the appropriate snap ring.
- While pushing to 98 N·m (10 kg-m, 72 ft-lb), check the clearance between snap ring (1) and needle bearing (2).

Journal axial play : Refer to DLN-147, "Journal Axial Play"

b. If journal axial play is outside the specification, use a thicker/ thinner snap ring to adjust.

### **CAUTION:**

- Never reuse snap ring.
- Select snap rings so that thickness difference between LH and RH is within 0.02 mm (0.0008 in).



Α

В

DLN

Е

F

Н

K

M


Ν

### REAR PROPELLER SHAFT

## < REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]

4. Install snap ring (1).



Check that joint moves smoothly.

Reference value (After adaptation)


Bending resistance : 2.26 N·m (0.23 kg-m, 20 in-lb)

or less

NOTE:

The bending resistance [2.26 N.m (0.23 kg-m, 20 in-lb) or less] may not be satisfied soon after the installation.

Check the journal axial play. Refer to <u>DLN-146</u>, "Inspection".



INFOID:0000000006222441

Inspection

# **INSPECTION AFTER REMOVAL**

**Appearance** 

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.


Propeller Shaft Runout

Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly. For measuring point, refer to <u>DLN-142</u>, "Inspection".

Propeller shaft runout : Refer to <u>DLN-147</u>,

"Propeller Shaft


Runout"



Journal Axial Play

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play : Refer to <u>DLN-147,</u> "Journal Axial Play"



# **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 2S1410]

# SERVICE DATA AND SPECIFICATIONS (SDS)

# SERVICE DATA AND SPECIFICATIONS (SDS)

# **General Specification**

Applied model		2WD		
		VK56VD		
		A/T		
Propeller shaft model		2S1410		
Number of joints		2		
Town of income the series of	1st joint	Shell type		
Type of journal bearings	2rd joint	Shell type		
Coupling method with transfe	er	Sleeve type		
Coupling method with rear final drive		Flange type		
Shaft length (Spider to spider)		1590.4 mm (62.61 in)		
Shaft outer diameter		127.6 mm (5.02 in)		

# Propeller Shaft Runout

	Unit: mm (in)
Item	Limit
Propeller shaft runout	1.02 (0.0402)

# Journal Axial Play

	Unit: mm (in)
Item	Standard
Journal axial play	0.02 (0.0008)

Α

В

C

INFOID:0000000006222442

INFOID:0000000006222443

DLN

Е

F

G

Н

INFOID:0000000006222444

J

K

M

Ν

0

### **PRECAUTIONS**

< PRECAUTION >

# **PRECAUTION**

# **PRECAUTIONS**

# Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:0000000006222372

[FRONT FINAL DRIVE: R180A]

### NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work.
   If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

### **OPERATION PROCEDURE**

1. Connect both battery cables.

#### NOTE:

Supply power using jumper cables if battery is discharged.

- 2. Turn the push-button ignition switch to ACC position.
  - (At this time, the steering lock will be released.)
- Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
- 4. Perform the necessary repair operation.
- 5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- 6. Perform self-diagnosis check of all control units using CONSULT-III.

# Precaution for Servicing Front Final Drive

INFOID:0000000006222373

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

# [FRONT FINAL DRIVE: R180A]

# **PREPARATION**

# **PREPARATION**

Special Service Tool

INFOID:00000000006222374

Α

В

Tool number (Kent-Moore No.) Tool name		Description	
ST3127S000 (J-25765-A) Preload gauge		Measuring pinion bearing preload and total preload	DI
KV381054S0 (J-34286)	ZZAOSOGD	Removing front oil seal	— F
Puller			C
	ZZA0601D		-
ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.		<ul> <li>Installing front oil seal</li> <li>Installing side oil seal</li> <li>Installing pinion front bearing outer race</li> </ul>	
ST27863000 ( — ) Drift	ZZA0811D	Installing front oil seal     Installing side oil seal	
a: 74.5 mm (2.933 in) dia. b: 62.5 mm (2.461 in) dia.	ablo		L
	ZZA1003D		
KV10111100 (J-37228)		Removing carrier cover	
Seal cutter			1
	S-NT046		

[FRONT FINAL DRIVE: R180A]

PREPARATION >		[ NOW THAT DIVE: NIOUA]
Tool number (Kent-Moore No.) Tool name		Description
ST3306S001 (J-22888-D) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2) Base a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	2 a a b b b b b b b	Removing and installing side bearing inner race
KV10112100 (BT-8653-A) Angle wrench	ZZA0120D	Tightening the drive gear mounting bolts
ST33230000 (J-35867) Drift a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia. c: 28 mm (1.10 in) dia.	ZZA1046D	Installing side bearing inner race
ST30611000 (J-25742-1) Drift bar		Installing pinion rear bearing outer race (Use with ST30613000)
ST30613000 (J-25742-3) Drift a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.	S-NT090	Installing pinion rear bearing outer race
KV38100200 (J-26233) Drift a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.	ZZA1143D	Installing pinion front bearing outer race

### < PRFPARATION >

[FRONT FINAL DRIVE: R180A]

PREPARATION >		[FRONT FINAL DRIVE, K160A]
Tool number (Kent-Moore No.) Tool name		Description
ST30901000 (J-26010-01) Drift a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.	a b c ZZA0978D	Installing drive pinion rear bearing inner race
ST33200000 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.	a b ZZA1002D	Installing drive pinion front bearing inner race
 (J-34309) Differential shim selector tool	NT134	Adjusting bearing preload and pinion gear height
 (J-25269-18) Side bearing disc (2 Req′d)		Selecting pinion height adjusting washer
	NT135	

# **Commercial Service Tool**

INFOID:0000000006222375

Tool name		Description
Power tool		Loosening bolts and nuts
Flange wrench	PBIC0190E	Removing and installing drive pinion lock nut
	NT035	

# < PREPARATION >


[FRONT FINAL DRIVE: R180A]

Tool name		Description
Puller		Removing companion flange
Drift a: 63 mm (2.48 in) dia. or less b: 49 mm (1.93 in) dia. or more	ZZA0119D	Removing and Installing bushing
Sliding hammer	NT125	Removing differential case assembly
Replacer	NITZS  ZZA0700D	Removing pinion rear bearing inner race

# SYSTEM DESCRIPTION

# STRUCTURE AND OPERATION

Sectional View



- 1. Side shaft
- 4. Drive gear
- 7. Side bearing
- 10. Collapsible spacer
- 13. Pinion rear bearing

- 2. Side shaft bearing
- 5. Pinion mate shaft
- 8. Pinion mate gear
- 11. Companion flange
- 14. Housing spacer

- 3. Side gear
- 6. Differential case
- 9. Drive pinion
- 12. Pinion front bearing

C

Α

DLN

Е

F

G

Н

J

Κ

L

M

Ν

0

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

# SYMPTOM DIAGNOSIS

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

# **NVH Troubleshooting Chart**

INFOID:0000000006222377

[FRONT FINAL DRIVE: R180A]

 $<sup>\</sup>times$ : Applicable

# FRONT DIFFERENTIAL GEAR OIL

< PERIODIC MAINTENANCE >

[FRONT FINAL DRIVE: R180A]

# PERIODIC MAINTENANCE

# FRONT DIFFERENTIAL GEAR OIL

Inspection Brook INFOID:0000000006222378

### **OIL LEAKAGE**

Check that oil is not leaking from the front final drive assembly or around it.

#### OIL LEVEL

• Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


#### **CAUTION:**

Never start engine while checking oil level.

Set a gasket on filler plug (1) and install it on final drive assembly.
 Refer to <u>DLN-167</u>, "<u>Exploded View</u>".

### **CAUTION:**

Never reuse gasket.



Draining


1. Stop engine.

2. Remove drain plug (1) and drain gear oil.

Set a gasket on drain plug (1) and install it to final drive assembly and tighten to the specified torque. Refer to <u>DLN-167</u>.
 "Exploded View".

### **CAUTION:**

Never reuse gasket.



Refilling

1. Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Oil grade and Viscosity : Refer to MA-10, "Fluids

and Lubricants".


Oil capacity : Refer to <u>DLN-185, "Gen-</u>

eral Specifications".

 After refilling oil, check oil level. Set a gasket to filler plug (1), then install it to final drive assembly. Refer to <u>DLN-167</u>. "Exploded View".

### **CAUTION:**

Never reuse gasket.



DLN

Α

Е

F

INFOID:0000000006222379

Н

.

J

K

L

M


Ν

0

# REMOVAL AND INSTALLATION

# FRONT OIL SEAL

Exploded View



- 1. Front final drive assembly
- 2. Front oil seal

Companion flange

- 4. Drive pinon lock nut
- A. Oil seal lip
- Apply multi-purpose grease.
- \*: Apply anti-corrosion oil.

Refer to GI-4, "Components" for symbols not described on the above.

### Removal and Installation

INFOID:0000000006222382

### **REMOVAL**

#### **CAUTION:**

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer. Refer to <u>DLN-162</u>, "Removal and Installation" and <u>DLN-168</u>, "Disassembly".

#### NOTE:


The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.

Identification Stamp of Replacement Frequency of Front Oil Seal

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
- The following table shows if collapsible spacer replacement is needed before replacing front oil seal.

When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to <u>DLN-168</u>, "<u>Disassembly</u>".

Stamp	collapsible spacer replacement	
No stamp	Not required	
"0" or "0" on the far right of stamp	Required	
"01" or "1" on the far right of stamp	Not required	



### **CAUTION:**

### Make a stamping after replacing front oil seal.

 After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

#### **CAUTION:**


Make a stamping from left to right.

Stamp before stamping	Stamping on the far right	Stamping	
No stamp	0	0	
"0" (Front oil seal was replaced once.)	1	01	
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010	
"0" is on the far right. (Only front oil seal was replaced last time.)	1	01	
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	010	

- 1. Make a judgement if a collapsible spacer replace is required.
- 2. Drain gear oil. Refer to <a href="DLN-155">DLN-155</a>, "Draining".
- 3. Remove the drive shafts from the front final drive assembly. Refer to FAX-22, "Removal and Installation".
- 4. Remove the front propeller shaft from the front final drive assembly. Refer to <u>DLN-129</u>, "Removal and <u>Installation"</u>.
- 5. Measure the total preload torque using preload gauge (A) [SST: ST3127S000 (J-25765-A)].

## NOTE:


Record the total preload torque measurement.




6. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

### **CAUTION:**

For matching, marks use paint. Never damage companion flange and drive pinion.



7. Remove the drive pinion lock nut using flange wrench (commercial service tool).



В

Α

DLN

Е

G

Н

K

ı


M

Ν


O

Ρ

8. Remove the companion flange using puller (commercial service tool).



9. Remove front oil seal using the puller [SST: KV381054S0 (J-34286)].



### INSTALLATION

1. Drive the front oil seal in evenly until it becomes flush with the gear carrier using drifts (A and B).


```
A: Drift [SST: ST30720000 (J-25405)]
B: Drift [SST: ST27863000 ( — )]
```


### **CAUTION:**

- Never reuse oil seal.
- · Never incline oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of oil seal.
- 2. Install companion flange (1).

## NOTE:

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).





## FRONT OIL SEAL

## < REMOVAL AND INSTALLATION >

Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).
 CAUTION:

Never reuse drive pinion lock nut.

 Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using preload gauge (A) [SST: ST3127S000 (J-25765-A)].


Total preload torque: A value that add 0.1 – 0.4 N·m

(0.01 - 0.04 kg-m, 1 - 3 in-lb) to the measured value when re-

moving.

### **CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.



[FRONT FINAL DRIVE: R180A]

- Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
- 6. Rotate the companion flange to check for runout.

Companion flange runout : Refer to <u>DLN-185, "Companion Flange Runout"</u>.

- Fit a test indicator to the inner side of the companion flange (socket diameter).
- 8. Rotate the companion flange to check for runout.



- 9. If the runout value is outside the repair limit, follow the procedure below to adjust.
- a. Check for runout while changing the phase between companion flange and drive pinion gear by 90° step, and search for the position where the runout is the minimum.
- b. If the runout value is still outside of the limit after the phase has been changed, possible causes are be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
- c. If the runout value is still outside of the limit after the check and repair, replace companion flange.
- 10. Install front propeller shaft. Refer to <a href="DLN-129">DLN-129</a>, "Removal and Installation".
- 11. Install drive shaft. Refer to FAX-22, "Removal and Installation".
- 12. Refill gear oil to the final drive and check oil level. Refer to <a href="DLN-155">DLN-155</a>, "Refilling".
- 13. Check the final drive for oil leakage. Refer to <a href="DLN-155">DLN-155</a>, "Inspection".

J.SDIAD116ZZ

Α

В

С

DLN

\_

F

3

Н

J

<

L


M

N

0

# SIDE OIL SEAL

Exploded View



- 1. Front final drive assembly
- 2. Side oil seal

- A. Oil seal lip
- : Apply gear oil.
- Apply multi-purpose grease.

Refer to GI-4, "Components" for symbols not described on the above.


### Removal and Installation

INFOID:0000000006222384

### REMOVAL

- 1. Drain gear oil. Refer to <a href="DLN-155">DLN-155</a>, "Draining".
- 2. Remove the drive shafts from the front final drive assembly. Refer to FAX-22, "Removal and Installation".
- Remove the side oil seal using suitable tool. CAUTION:

Never damage gear carrier.




### **INSTALLATION**

 Drive the new side oil seal in evenly until it becomes flush with the gear carrier using drifts (A and B).

```
A: Drift [SST: ST30720000 (J-25405)]
B: Drift [SST: ST27863000 ( — )]
```

#### **CAUTION:**

- · Never reuse side oil seal.
- · Never incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal.



# SIDE OIL SEAL

# < REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

- 2. Install drive shaft. Refer to FAX-22, "Removal and Installation".
- 3. Refill gear oil to the final drive and check oil level. Refer to <u>DLN-155</u>, "Refilling".
- 4. Check the final drive for oil leakage. Refer to <u>DLN-155</u>, "Inspection".

Α

В

С

DLN

Е

F

G

Н

J

K

L

M


Ν

0

# UNIT REMOVAL AND INSTALLATION

# FRONT FINAL DRIVE ASSEMBLY

Exploded View



1. Front final drive assembly

Refer to GI-4, "Components" for symbols in figure.

# Removal and Installation

INFOID:00000000006222386

### **REMOVAL**

- Drain the differential gear oil. Refer to <u>DLN-155, "Draining"</u>.
- Remove the drive shafts. Refer to <u>FAX-22</u>, "<u>Removal and Installation</u>".
- 3. Remove the front propeller shaft from the front final drive assembly. Refer to <u>DLN-129</u>, "Removal and Installation".
- 4. Disconnect the breather hose from the front final drive assembly.
- 5. Support the front final drive assembly using a suitable jack.
- 6. Remove the front final drive assembly bolts, then remove the front final drive assembly with a power tool. **CAUTION:**

Secure the front final drive assembly to a suitable jack while removing it.

#### INSTALLATION

Note the following, and installation is in the reverse order of removal.

#### **CAUTION:**

Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.

# FRONT FINAL DRIVE ASSEMBLY

### < UNIT REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

• Install the breather hose (1) as shown in the figure.

: Vehicle front

- Install the breather hose (1) of final side with the paint mark (A) facing vehicle front, and insert the breather hose until dimension (B) shown as follows.


## B: 20 mm (0.79 in)

# **CAUTION:**

- Never reuse hose clamp.
- Install the hose clamp with the tab facing vehicle front.
- Be sure to fix the breather hose in (C) position.
- If remove the bracket (2), align stopper part (D) to part (E) of suspension mounting bracket (3), and tighten the mounting bolt (4) to specified torque.

# Specified torque: 8.3 N•m (0.85 kg-m, 73 in-lb)

 When oil leaks while removing final drive assembly, check oil level after the installation. Refer to <u>DLN-142</u>, "Inspection".



Α

В

C

DLN

Е

F

G

Н

K

L

M


Ν

Revision: 2010 May **DLN-163** 2011 QX56

# **UNIT DISASSEMBLY AND ASSEMBLY**

# SIDE SHAFT

Exploded View



- 1. Bushing
- 4. Side bearing adjusting washer
- 7. Pinion rear bearing
- 10. Drain plug
- 13. Front oil seal
- 16. Gear carrier
- 19. Snap ring
- 22. Drive gear
- 25. Filler plug
- A: Oil seal lip

- 2. Bearing cap
- 5. Drive pinion
- Collapsible spacer
- 11. Side oil seal (left side)
- 14. Companion flange
- 17. Side shaft
- 20. Snap ring
- 23. Differential case assembly
- 26. Carrier cover
- B: Screw hole

- 3. Side bearing
- 6. Pinion height adjusting washer
- 9. Gasket
- 12. Pinion front bearing
- 15. Drive pinion lock nut
- 18. Side shaft bearing
- 21. Side oil seal (right side)
- 24. Housing spacer
- C. Comply with the assembly procedure when tightening. Refer to <u>DLN-169</u>. "Assembly".

: Apply gear oil.


☆: Apply anti-corrosion oil.

- Apply multi-purpose grease.
- Apply Genuine Silicone RTV or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".
- (Line of the description of the

Refer to GI-4, "Components" for symbols not described above.


Disassembly

- 1. Drain the differential gear oil if necessary.
- 2. Remove the carrier cover bolts
- Remove carrier cover to insert the seal cutter (A) [SST: KV10111100 (J-37228)] between gear carrier and carrier cover. CAUTION:
  - Never damage the mating surface.
  - Never insert flat-bladed screwdriver, this will damage the mating surface.




 Remove side oil seal (right side) with a suitable tool. CAUTION:

Never damage gear carrier.



Remove snap ring (hole side) with a suitable tool.




Remove differential side shaft assembly out of gear carrier with a suitable tool.

### NOTE:

Tap on differential side shaft assembly from side gear side.

7. Remove snap ring (differential side shaft side).



DLN

Α

В

Е

F

G

Н

K

M

Ν

0

Ρ


## SIDE SHAFT

### < UNIT DISASSEMBLY AND ASSEMBLY >

Press differential side shaft out of differential side shaft bearing. CAUTION:

Never drop differential side shaft.

 Perform inspection after disassembly. Refer to <u>DLN-166</u>. "Inspection".



INFOID:0000000006222389


[FRONT FINAL DRIVE: R180A]

Assembly

 Press differential side shaft bearing to differential side shaft. CAUTION:

Never reuse differential side shaft bearing.

- 2. Install snap ring (differential side shaft side).
- Install differential side shaft assembly into gear carrier.
- 4. Install snap ring (hole side).




5. Install side oil seal (right side) until it becomes flush with the gear carrier, with the drifts (A and B).

```
A: Drift [SST: ST30720000 (J-25405)]
B: Drift [SST: ST27863000 ( — )]
```

## **CAUTION:**

- · Never reuse side oil seal.
- . When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips and gear oil onto the circumference of oil seal.



Inspection

### INSPECTION AFTER DISASSEMBLY

#### Side Shaft

• If it is chipped (by friction), cracked, damaged, or unusually worn, replace.

#### Bearing

- · Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### Oil Seal

- · Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

Α

В

C

DLN

Е

F

Н

K

L


M

Ν

Р

# **DIFFERENTIAL ASSEMBLY**

Exploded View



- 1. Bushing
- 4. Side bearing adjusting washer
- 7. Pinion rear bearing
- 10. Drain plug
- 13. Front oil seal
- 16. Gear carrier
- 19. Snap ring
- 22. Drive gear
- 25. Filler plug
- A: Oil seal lip

- 2. Bearing cap
- 5. Drive pinion
- 8. Collapsible spacer
- 11. Side oil seal (left side)
- 14. Companion flange
- 17. Side shaft
- 20. Snap ring
- 23. Differential case assembly
- 26. Carrier cover
- B: Screw hole

- 3. Side bearing
- 6. Pinion height adjusting washer
- 9. Gasket
- 12. Pinion front bearing
- 15. Drive pinion lock nut
- 18. Side shaft bearing
- 21. Side oil seal (right side)
- 24. Housing spacer
- C. Comply with the assembly procedure when tightening. Refer to <u>DLN-169</u>, "Assembly".

? Apply gear oil.

Apply anti-corrosion oil.

Apply multi-purpose grease.


[FRONT FINAL DRIVE: R180A]

- Apply Genuine Silicone RTV or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".
- (2): Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".


Refer to GI-4, "Components" for symbols not described above.

Disassembly


- 1. Remove bushing with drift (commercial service tool).
- 2. Remove differential side shaft assembly. Refer to <u>DLN-165</u>, "Disassembly".
- 3. Remove side oil seal (left side) from gear carrier with a suitable tool.
- For proper reinstallation, paint matching marks on one side of the side bearing cap and gear carrier.
   CAUTION:
  - For matching marks, use paint. Never damage side bearing cap and gear carrier.
  - Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.




Remove the side bearing caps.



6. Lift the differential case assembly out of the gear carrier with sliding hammer (commercial service tool).



- Remove the differential case assembly with the side bearing outer race and side bearing adjusting washer.
   CAUTION:
  - Keep side bearing outer races together with side bearing inner races. Do not mix them up.
  - Keep side bearing adjusting washers together with side bearings.



### < UNIT DISASSEMBLY AND ASSEMBLY >


- Remove housing spacer.
- 9. Remove side bearing inner race with the puller (A) and base (B).

A: Puller [SST: ST33051001 (J-22888-20)]

B: Base [SST: ST33061000 (J-8107-2)]

#### **CAUTION:**

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is necessary to remove side bearing inner race except when it is replaced.



[FRONT FINAL DRIVE: R180A]

DLN

Α

10. For proper reinstallation, paint matching marks on the differential case and drive gear.


#### **CAUTION:**

For matching marks, use paint. Never damage differential case and drive gear.

- 11. Remove the drive mounting gear bolts.
- 12. Tap the drive gear off the differential case using suitable tool. **CAUTION:**

Tap evenly all around to keep drive gear from bending.

13. Perform inspection after disassembly. Refer to <a href="DLN-174">DLN-174</a>, <a href=""">"Inspection"</a>.



Н

Assembly INFOID:0000000006222393

- 1. Apply thread locking sealant into the threaded holes of the drive gear and install the new drive gear bolts.
  - Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

#### **CAUTION:**

Clean degrees drive gear back and threaded holes sufficiently.

2. Install the drive gear to differential case assembly.

#### **CAUTION:**

Align the matching marks of differential case assembly and drive gear

3. Tighten the drive gear mounting bolts with the following procedure. **CAUTION:** 

Apply anti-corrosion oil to the thread and seat of mounting bolts.

a. Tighten the bolts in a crisscross fashion to the specified torque.


Drive gear mounting : 58.8 N•m (6.0 kg-m, 43 ft-lb) bolts tightening torque

b. Tighten the bolts additionally at the specified angle.

Drive gear mounting : 34 to 39 degree bolts tightening angle

### **CAUTION:**

Check the tightening angle using the angle wrench (A) [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.



M

Ν

0

Р

AWBIA0722ZZ

Revision: 2010 May **DLN-169** 2011 QX56

### < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


4. Press side bearing inner races to the differential case with the drift (A) and the base (B).

A: Drift [SST: ST33230000 (J-35867)]
B: Base [SST: ST33061000 (J-8107-2)]

### **CAUTION:**

Never reuse side bearing inner races.


5. Install housing spacer.




6. Install the differential case assembly with the side bearing outer races into the gear carrier.

#### **CAUTION:**

- Never reuse side bearing outer race when replacing side bearing inner race (replace as a set).
- Apply differential gear oil to the side bearings.




7. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.



8. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque. **CAUTION:** 

Align matching marks on bearing cap with that on gear carrier




9. Install side oil seal (left side) until it becomes flush with the gear carrier with the drift (A and B).

A: Drift [SST: ST30720000 (J-25405)]
B: Drift [SST: ST27863000 ( — )]

#### **CAUTION:**

- Never reuse side oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

10. Check and adjust drive gear runout, tooth contact, backlash, and total preload torque. Refer to <a href="DLN-171">DLN-171</a>. <a href="Mailto:"Adjustment"</a>.

Recheck above items. Readjust the above description, if necessary.


- 11. Apply sealant to match surface of carrier cover.
  - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-22</u>, "Recommended Chemical Products and Sealants".

#### **CAUTION:**

Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.

- 12. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque.
- 13. Install side shaft. Refer to <a href="DLN-166">DLN-166</a>, "Assembly".
- 14. Install bushing with drift (commercial service tool).

Adjustment



### TOTAL PRELOAD TORQUE

1. Install the differential side shaft. Refer to <a href="DLN-166">DLN-166</a>, "Assembly".

- 2. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- 3. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
- 4. Measure total preload torque with the preload gauge [SST: ST3127S000 (J-25765-A)].

Total preload torque : Refer to <u>DLN-185, "Pre-load Torque".</u>

#### NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque

Tool PDIA0697E

• If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

### When the preload torque is large

On drive pinion bearings: Decrease the drive pinion bearing adjusting washer and drive

pinion adjusting washer thickness. For selecting adjusting

washer, refer to the latest parts information.

On side bearings: Increase the side bearing adjusting washer thickness. For se-

lecting adjusting washer, refer to the latest parts information.

## When the preload torque is small

On drive pinion bearings: Increase the drive pinion bearing adjusting washer and drive

pinion adjusting washer thickness. For selecting adjusting

washer, refer to the latest parts information.

On side bearings: Decrease the side bearing adjusting washer thickness. For se-

lecting adjusting washer, refer to the latest parts information.

### DRIVE GEAR RUNOUT

Remove carrier cover. Refer to <u>DLN-168, "Disassembly"</u>.

Revision: 2010 May **DLN-171** 2011 QX56

В

Α

С

DLN

F

F

G

Н

I

J

K

L

M

N

0

### < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

- 2. Fit a dial indicator to the drive gear back face.
- 3. Rotate the drive gear to measure runout.

**Drive gear runout** 

: Refer to <u>DLN-185, "Drive</u> Gear Runout".

 If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between the drive gear and differential case, or differential case or drive gear may be deformed.

### **CAUTION:**


Replace drive gear and drive pinion as a set.


### TOOTH CONTACT

- 1. Remove carrier cover. Refer to <u>DLN-168</u>, "<u>Disassembly</u>".
- 2. Apply red lead to the drive gear.

### **CAUTION:**


Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on the drive gear.





 Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown. CAUTION:


Check tooth contact on drive side and reverse side.




# [FRONT FINAL DRIVE: R180A]

Tooth contact condition		Drive pinion adjusting		Adjustment	Possible cause
Drive side	Back side	shim selection value [ mm (in) ]		(Yes/No)	Possible cause
Heel side Toe side	Toe side Heel side		+0.09 (+0.0035)	Yes	Occurrence of noise and scoring sound in all speed ranges.
		Thicker	+0.06 (+0.0024)	Tes	Occurrence of noise when accelerating.
			+0.03 (+0.0012)		
			0	No	-
			-0.03 (-0.0012)		
		Thinner	-0.06 (-0.0024)	Yes	Occurrence of noise at constant speed and decreasing speed.
			-0.09 (-0.0035)	res	Occurrence of noise and scoring sound in all speed ranges.

4. If the tooth contact is improperly adjusted, adjust the drive pinion height (dimension X).



 If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washer to move drive pinion closer to the drive gear
 For selecting adjusting washer, refer to the latest parts information.



Α

В

С

DLN

Е

F

G

Н

K

\_


M

Ν

0

# < UNIT DISASSEMBLY AND ASSEMBLY >

 If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washer to move the drive pinion farther from the drive gear.
 For selecting adjusting washer, refer to the latest parts information.



[FRONT FINAL DRIVE: R180A]

### **BACKLASH**

- Remove carrier cover. Refer to DLN-168, "Disassembly".
- Fit a dial indicator to the drive gear face to measure the backlash.

# **Backlash**

: Refer to <u>DLN-185, "Back-lash".</u>

 If the backlash is outside of the specification, change the thickness of the side bearing adjusting washers.

## When the backlash is large:

Make drive gear back side adjusting washer thicker, and drive tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.

### If the backlash is less than specification:

Make drive gear back side adjusting washer thinner, and drive tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.

### **CAUTION:**

Never change the total amount of washers as it changes the preload torque.

Inspection INFOID:0000000006222395

### INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

#### Bearing

- · Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### Side Gear and Pinion Mate Gear

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

### Side Gear Thrust Washer and Pinion Mate Thrust Washer

- · Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

#### Oil Seal

# < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

**Differential Case** 

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

С

Α

В

DLN

Е

F

G

Н

1

K

L


M

Ν

0

# **DRIVE PINION**

Exploded View



- 1. Bushing
- 4. Side bearing adjusting washer
- 7. Pinion rear bearing
- 10. Drain plug
- 13. Front oil seal
- 16. Gear carrier
- 19. Snap ring
- 22. Drive gear
- 25. Filler plug
- A: Oil seal lip

- 2. Bearing cap
- Drive pinion
- 8. Collapsible spacer
- 11. Side oil seal (left side)
- 14. Companion flange
- 17. Side shaft
- 20. Snap ring
- 23. Differential case assembly
- 26. Carrier cover
- B: Screw hole

- 3. Side bearing
- 6. Pinion height adjusting washer
- 9. Gasket
- 12. Pinion front bearing
- 15. Drive pinion lock nut
- 18. Side shaft bearing
- 21. Side oil seal (right side)
- 24. Housing spacer
- C. Comply with the assembly procedure when tightening. Refer to <u>DLN-169</u>, "Assembly".

?: Apply gear oil.

\*: Apply anti-corrosion oil.

Apply multi-purpose grease.

Apply Genuine Silicone RTV or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".


Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

Refer to GI-4, "Components" for symbols not described above.

Disassembly

1. Remove the side shaft. Refer to <u>DLN-165</u>, "<u>Disassembly</u>".


- 2. Remove the differential assembly. Refer to <a href="DLN-168">DLN-168</a>, "Disassembly".
- 3. Remove the drive pinion lock nut with a flange wrench (commercial service tool).




4. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

**CAUTION:** 

For matching, marks use paint. Never damage companion flange and drive pinion.




5. Remove the companion flange with the puller (commercial service tool).



Press the drive pinion assembly. CAUTION:

Never drop drive pinion assembly.



Revision: 2010 May **DLN-177** 2011 QX56

DLN

Α

В

Е

G

Н

I

K

L

M

Ν

С

Ρ

## **DRIVE PINION**


## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


Remove the front oil seal with a suitable tool. CAUTION:

### Never damage gear carrier.

- 8. Remove the drive pinion front bearing inner race.
- 9. Remove the collapsible spacer.



10. Remove the drive pinion rear bearing inner race and drive pinion height adjusting washer with the replacer (commercial service tool).




11. Remove the drive pinion front and rear bearing outer races by tapping them uniformly with a suitable tool.

### **CAUTION:**

Never damage gear carrier.

12. Perform inspection after disassembly. Refer to <a href="DLN-184">DLN-184</a>, <a href=""">"Inspection"</a>.




Assembly

1. Install drive pinion rear bearing outer race and drive pinion front bearing outer race using Tools.

A: Drift bar [SST: ST30611000 (J-25742-1)]
B: Drift [SST: ST30313000 (J-25742-3)]
C: Drift [SST: KV38100200 (J-26233)]

### **CAUTION:**


- First tap the drive pinion bearing outer race until it becomes flush with the gear carrier.
- Never reuse drive pinion front and rear bearing outer race.
- 2. Select pinion height adjusting washer. Refer to <a href="DLN-181">DLN-181</a>. "Adjustment".



 Install selected drive pinion height adjusting washer (2) to drive pinion. Press pinion rear bearing inner race (1) to it, using drift (A) [SST: ST30901000 (J-26010-01)].

#### **CAUTION:**

- Be careful of the direction of pinion height adjusting washer. (Assemble as shown in the figure.)
- Never reuse pinion rear bearing inner race.



4. Assemble collapsible spacer.

#### **CAUTION:**

Never reuse collapsible spacer.

5. Assemble drive pinion into gear carrier.


### **CAUTION:**

Apply gear oil to pinion rear bearing.

Assemble pinion front bearing inner race to drive pinion assembly.

### **CAUTION:**

- Never reuse pinion front bearing inner race.
- Apply gear oil to pinion front bearing.



Α

В

DLN

Е

F

Н

K


M

N

 $\bigcirc$ 

# < UNIT DISASSEMBLY AND ASSEMBLY >

 Using drift [SST: ST33200000 (J-26082)], press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.




[FRONT FINAL DRIVE: R180A]

8. Install front oil seal as shown in figure with the drifts (A and B).

```
A: Drift [SST: ST30720000 (J-25405)]
B: Drift [SST: ST27863000 ( — )]
```

#### **CAUTION:**


- · Never reuse oil seal.
- · When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



9. Install companion flange (1).

#### NOTE:

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



10. Temporarily tighten drive pinion lock nut to drive pinion.

#### **CAUTION:**


- Apply anti-corrosion oil to the thread and seat of the drive pinion lock nut
- Never reuse drive pinion lock nut.
- 11. Tighten to drive pinion lock nut using flange wrench (A), while adjusting pinion bearing preload torque using preload gauge (B).
  - A: Flange wrench (commercial service tool)
  - B: Preload gauge [SST: ST3127S000 (J-25765-A)]

Pinion bearing preload : Refer to <u>DLN-185, "Preload Torque"</u>.

#### **CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 12. Install differential case assembly. Refer to <a href="DLN-169">DLN-169</a>. "Assembly".

**CAUTION:** 



#### [FRONT FINAL DRIVE: R180A]


#### Never install carrier cover yet.

- 13. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash. Refer to <u>DLN-171</u>, <u>"Adjustment"</u>.
- 14. Install side shaft. Refer to <a href="DLN-166">DLN-166</a>, "Assembly".
- 15. Check and adjust companion flange runout. Refer to DLN-181, "Adjustment".
- 16. Check total preload torque. Refer to DLN-171, "Adjustment".
- 17. Install carrier cover. Refer to DLN-169, "Assembly".


Adjustment


#### PINION GEAR HEIGHT

- Make sure all parts are clean and that the bearings are well lubricated.
- 2. Assemble the pinion gear bearings into the differential shim selector tool [SST: (J-34309)].




- **Pinion front bearing**; make sure the J-34309-3 pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the pinion front bearing pilot, J-34309-7, to secure the bearing in its proper position.
- **Pinion rear bearing**; the pinion rear bearing pilot, J-34309-8, is used to center the pinion rear bearing only. The pinion rear bearing locking seat, J-34309-4, is used to lock the bearing to the assembly.
- Installation of J-34309-9 and J-34309-16; place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).
- Install the pinion rear bearing inner race into gear carrier. Then
  place the pinion preload shim selector tool, J-34309-1, gauge
  screw assembly.





4. Assemble the pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in gear carrier. Make sure that the pinion height gauge plate, J-34309-16, turns a full 360 degrees. Tighten the two sections together by hand.



DLN

В

Е

|-

Н

K

M

N


0

Р

Revision: 2010 May **DLN-181** 2011 QX56


[FRONT FINAL DRIVE: R180A]

5. Turn the assembly several times to seat the bearings.



6. Measure the turning torque at the end of the J-34309-2 gauge anvil using preload gauge [SST: ST3127S000 (J-25765-A)].


Turning torque specification : 1.08 – 1.66 N·m (0.11 – 0.16 kg-m, 10 – 14 in-lb)




7. Place the J-34309-10 "R180A" pinion height adapter onto the gauge plate and tighten it by hand.

#### **CAUTION:**


Make sure all machined surfaces are clean.



 Position the side bearing discs, J-25269-18, and arbor firmly into the side bearing bores. Install the bearing caps and tighten bearing cap mounting bolts to the specified torque. Refer to <u>DLN-176</u>, "Exploded View".




Select the correct standard pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and J-34309-101 feeler gauge. Measure the distance between the J-34309-11 pinion height adapter including the standard gauge and the arbor.




### [FRONT FINAL DRIVE: R180A]

10. Write down exact measurement (the value of feeler gauge).



11. Correct the pinion height washer size by referring to the "pinion head number".


There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the "pinion head height number". It refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.



Pinion head height number	Add or remove from the standard pinion height adjusting washer thickness measurement
<u> </u>	Add 0.06 mm (0.0024 in)
<b>- 5</b>	Add 0.05 mm (0.0020 in)
– 4	Add 0.04 mm (0.0016 in)
- 3	Add 0.03 mm (0.0012 in)
<b>-2</b>	Add 0.02 mm (0.0008 in)
<b>– 1</b>	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

12. Select the correct pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.

 Remove the J-34309 differential shim selector tool from the final drive housing. Then disassemble to retrieve the pinion bearings.



**COMPANION FLANGE RUNOUT** 

Α

В

C

DLN

F

G

Н

1

K

L

M

Ν

0

Ρ

### DRIVE PINION

### < UNIT DISASSEMBLY AND ASSEMBLY >

- 1. Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
- Rotate companion flange to check for runout.


Companion flange runout

: Refer to <u>DLN-185, "Companion Flange Runout"</u>.

- 3. Fit a test indicator to the inner side of companion flange (socket diameter).
- 4. Rotate companion flange to check for runout.

**Companion flange runout** 

: Refer to <u>DLN-185, "Companion Flange Runout"</u>.



- a. Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
- b. If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
- c. If the runout value is still outside of the limit after the check and repair, replace companion flange.

Inspection INFOID:0000000000222400

#### INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- · Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

#### Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

#### Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### Companion Flange

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

[FRONT FINAL DRIVE: R180A]

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

## [FRONT FINAL DRIVE: R180A]

Α

В

C

DLN

Е

J

INFOID:0000000006222401

INFOID:0000000006222402

INFOID:0000000006222403

Unit: N·m (kg-m, in-lb)

1.67 - 2.74 (0.17 - 0.27, 15 - 24)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

## **General Specifications**

		4WD
Applied model		VK56VD
		A/T
Final drive model		R180A
Gear ratio		2.937
Number of teeth (Drive gear/Drive pinion)		47/16
Oil capacity (Approx.)	$\ell$ (US pt, Imp pt)	0.75 (1-5/8, 1-3/8)
Number of pinion gears		4
Drive pinion adjustment spacer type		Collapsible

## **Drive Gear Runout**

	Unit: mm (in)
Item	Limit
Drive gear back face runout	0.05 (0.0020)

## **Preload Torque**

(Total preload =  $P_1 + P_2$ )

	,
Item	Standard
Pinion bearing (P1)	1.08 – 1.66 (0.11 – 0.16, 10 – 14)
Side bearing (P2)	0.59 – 1.08 (0.06 – 0.11, 6 – 9)
Side bearing to pinion bearing (Total preload)	4.67. 2.74 (0.47. 0.27.45. 24)

Backlash	INFOID:000000006222404

	Unit: mm (in)
Item	Standard
Drive gear to drive pinion gear	0.10 - 0.15 (0.0039 - 0.0059)

## Companion Flange Runout

	Offic. Hill (III)
Item	Limit
Companion flange face	0.10 (0.004)
Inner side of the companion flange	0.10 (0.004)

Unit: mm (in)

INFOID:0000000006222405

Ρ

Ν

0

## **PRECAUTIONS**

< PRECAUTION >

## **PRECAUTION**

## **PRECAUTIONS**

### Service Notice or Precautions for Rear Final Drive

INFOID:0000000006222406

[REAR FINAL DRIVE: R230]

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dustproof area.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones, if necessary.
- Gaskets, seals and O-rings should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Never use cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new gear oil, petroleum jelly, or multipurpose grease as specified for each vehicle, if necessary.

[REAR FINAL DRIVE: R230]

Α

# **PREPARATION**

## **PREPARATION**

Special Service Tool		INFOID:000000006222407	7 B
The actual shapes of Kent-Moore tools ma	ay differ from those of special service tools illust	trated here.	
Tool number (Kent-Moore No.) Tool name	,	Description	С
KV40104100 ( — ) Attachment		Removing side flange	DLN E
ST36230000 (J-25840-A)	ZZA0804D	Removing side flange	F
Sliding hammer	ZZA0803D		G H
ST3127S000 (J-25765-A) Preload gauge		Measuring pinion bearing preload and total preload	I
	ZZA0806D		J
KV381054S0 (J-34286) Puller		Removing front oil seal	K
	ZZA0601D		M
ST15310000 (J-25640-B) Drift a: 96 mm (3.78 in) dia. b: 84 mm (3.31 in) dia.	a b	Installing front oil seal	N
KV38108000	S-NT673	Installing side flange	0
( — ) Protector	S-NT129		Р

_	PR		۸ د	$\mathbf{D}$	۸т	$\sim$	NΙ	_
_	РК	-	νД	ĸ	4 I	I( )	N	`>

[REAR FINAL DRIVE: R230]

T1		
Tool number (Kent-Moore No.) Tool name		Description
ST35271000		Installing side oil seal
(J26091)		
Drift		
a: 72 mm (2.83 in) dia.		
o: 63 mm (2.48 in) dia.	a b  ((( U)) )	
	77044400	
KV10111100	ZZA1143D	Removing carrier cover
(J-37228)		
Seal cutter	8	
	$\langle\!\langle \rangle\!\rangle$	
	<b>V</b>	
0.000.000	S-NT046	
KV38100800		Securing unit assembly
(J-25604-01) Attachment		
Attacnment A: 541 mm (21.30 in)	A	
B: 200 mm (7.87 in)		
2. 200 11111 (7.107 111)	В	
	1619 COOL	
	o de	
ST33051001	SDIA0267E	Removing side bearing inner race
(J-22888-20)		Trainioving side bearing inflet face
Puller		
	PDIA0747J	
KV40104730		Removing and installing side bearing inner
_ )		race
Drift		
a: 53.7 mm (2.11 in) dia. b: 47 mm (1.85 in) dia.	ATTAN )	
5. 77 IIIII (1.05 III) uid.	) p	
	a	
	S-NT108	
(V10112100		Tightening the drive gear mounting bolt
BT-8653-A)		
Angle wrench		
	A CONTRACTOR OF THE PARTY OF TH	
	9	
	$\forall$	
ST01550002	ZZA0120D	Installing side hearing inner roce
5101550002 ' — )		Installing side bearing inner race
Orift		
a: 65 mm (2.56 in) dia.	C THE WAY	
b: 56 mm (2.20 in) dia.		
c: 40 mm (1.57 in) dia.	77 T () ) )   December 1	
	a o	
	ZZA1046D	
	22A1040D	

_	PR	FF	ΔΕ	2Δ-	$FI \cap$	$\sim$

[REAR FINAL DRIVE: R230]

PREPARATION >			_
Tool number (Kent-Moore No.) Tool name		Description	А
 (J-8129) Spring gauge		Measuring turning torque	В
	NT127		С
KV38103300 ( — ) Drift a: 99 mm (3.90 in) dia.		Installing drive pinion rear bearing outer race	DLN E
ST30611000	PDIA0933E	Installing drive pinion front bearing outer race	F
(J-25742-1) Drift bar			G
	S-NT090		Н
ST30621000 (J-25742-5) Drift a: 79 mm (3.11 in) dia.	<b>→</b> b →	Installing drive pinion front bearing outer race	I
b: 59 mm (2.32 in) dia.	→a→		J
ST30022000 ( — )	ZZA1000D	Installing pinion rear bearing inner race	K
Drift a: 110 mm (4.33 in) dia. b: 56 mm (2.20 in) dia. c: 46 mm (1.81 in) dia.	a b c		L
	ZZA0978D		M

**Commercial Service Tool** 

INFOID:00000000006222408

Revision: 2010 May **DLN-189** 2011 QX56

0

Ν

[REAR FINAL DRIVE: R230]

Tool name		Description
Flange wrench		Removing and installing drive pinion lock nut
	NT035	
Puller	6	Removing companion flange
Sliding hammer	ZZA0119D	Removing differential case assembly
Chairig hammer		The state of the s
Puller	NT125	Removing drive pinion rear bearing inner race
. 4.15.	9	The state of the s
	ZZA0700D	
Spacer	EA01000	Installing drive pinion front bearing inner race
a: 60 mm (2.36 in) dia. b: 36 mm (1.42 in) dia.	<del> - b</del>	
c: 30 mm (1.18 in)		
	a zzA1133D	
Power tool		Loosing nuts and bolts
	PBIC0190E	


## [REAR FINAL DRIVE: R230]

# SYSTEM DESCRIPTION

## STRUCTURE AND OPERATION

Sectional View

## **CROSS-SECTIONAL VIEW**



- 1. Side flange
- 4. Pinion mate shaft
- 7. Drive pinion
- 10. Collapsible spacer
- 2. Pinion mate gear
- 5. Differential case
- 8. Pinion front bearing
- 11. Pinion rear bearing
- 3. Drive gear
- 6. Side bearing
- 9. Companion flange
- 12. Side gear

DLN

C

Α

Е

F

G

Н

J

Κ

L

M

Ν

0

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## **NVH Troubleshooting Chart**

INFOID:0000000006222410

[REAR FINAL DRIVE: R230]

Gear tooth rough Gear contact improper Tooth surfaces worn Backlash incorrect	Companion flange Gear oil improper PROPELLER SH AXLE AND SUSF TIRES TIRES ROAD WHEEL DRIVE SHAFT BRAKES	STEERING
use and SUSPECTED PARTS	Companion flange excessive runout Gear oil improper PROPELLER SHAFT AXLE AND SUSPENSION TIRES ROAD WHEEL DRIVE SHAFT BRAKES	
	DLN-210, "Adjustment"  DLN-193, "Inspection"  NVH of FRONT PROPELLER SHAFT in this section.  NVH in FAX, RAX, and RSU sections.  NVH in WT section.  NVH in WT section.  NVH in RAX section.	NVH in ST section.

 $<sup>\</sup>times$ : Applicable

## REAR DIFFERENTIAL GEAR OIL

< PERIODIC MAINTENANCE >

## [REAR FINAL DRIVE: R230]

## PERIODIC MAINTENANCE

## REAR DIFFERENTIAL GEAR OIL

Inspection INFOID:000000006222411 B

#### **OIL LEAKAGE**

Check that differential gear oil is not leaking from the rear final drive assembly or around it.

#### OILLEVEL

• Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


#### **CAUTION:**

Never start engine while checking oil level.

Set a gasket on filler plug (1) and install it on final drive assembly.
 Refer to <u>DLN-203</u>, "<u>Exploded View</u>".

#### **CAUTION:**

Never reuse gasket.



Draining INFOID:000000006222412


1. Stop the engine.

2. Remove drain plug (1) and drain gear oil.

3. Set a gasket on drain plug (1) and install it to final drive assembly and tighten to the specified torque. Refer to <a href="DLN-203">DLN-203</a>. <a href=""">"Exploded View"</a>.

## **CAUTION:**

Never reuse gasket.



Refilling INFOID:0000000000222413

1. Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Oil grade and viscosity: Refer to MA-10, "Fluids and

Lubricants".


Oil capacity : Refer to <u>DLN-222</u>, "General

Specification".

2. After refilling oil, check oil level. Set a gasket to filler plug (1), then install it to final drive assembly. Refer to <u>DLN-203</u>, "Exploded View".

### **CAUTION:**

Never reuse gasket.



DLN

Α

Е

Н

I

0

K

M

Ν


0

## [REAR FINAL DRIVE: R230]

## REMOVAL AND INSTALLATION

## FRONT OIL SEAL

Exploded View



- 1. Final drive assembly
- Front oil seal

3. Companion flange

- 4. Drive pinion lock nut
- A. Oil seal lip
- ∀ : Vehicle front
- : Apply gear oil.
- \*: Apply anti-corrosion oil.

Refer to GI-4, "Components" for symbols not described above.

### Removal and Installation

### **REMOVAL**

#### **CAUTION:**

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer.


The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.

Identification Stamp of Replacement Frequency of Front Oil Seal

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
- The following table shows if collapsible spacer replacement is needed before replacing front oil seal.

When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to <u>DLN-217</u>, "<u>Disassembly</u>".

Stamp	collapsible spacer replacement	
No stamp	Not required	



INFOID:0000000006222415

### < REMOVAL AND INSTALLATION >

"01" or "1" on the far right of stamp

Stamp collapsible spacer replacement

"0" or "0" on the far right of stamp Required

Α

[REAR FINAL DRIVE: R230]

### **CAUTION:**

Make a stamping after replacing front oil seal.

 After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

Not required

**CAUTION:** 

Make a stamping from left to right.

Stamp before stamping	Stamping on the far right	Stamping	
No stamp	0	0	
"0" (Front oil seal was replaced once.)	1	01	
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010	
"0" is on the far right. (Only front oil seal was replaced last time.)	1	01	
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	010	

- 1. Make a judgment if a collapsible spacer replacement is required.
- 2. Drain gear oil. Refer to <a href="DLN-193">DLN-193</a>, "Draining".
- 3. Remove the drive shafts from final drive. Then suspend it by wire, etc. Refer to <a href="RAX-11">RAX-11</a>, "Removal and Installation".
- 4. Remove the side flange using sliding hammer and attachment.


A : Attachment [SST: KV40104100 ( — )]

B : Sliding hammer [SST: ST36230000 (J-25840-A)]

#### NOTE:

Circular clip installation position: Side flange


5. Remove the rear propeller shaft. Refer to <u>DLN-144, "Removal</u> and Installation".



6. Measure the total preload torque with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

#### NOTE:

Record the total preload torque measurement.



В

DLN

С

Е

F

G

Н

1

K

M

Ν

0


Ρ

## < REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R230]

 Put matching mark (B) on the end of the drive pinion. The matching mark (A) on companion flange (1). CAUTION:


For matching mark, use paint. Never damage companion flange and drive pinion.




8. Remove the drive pinion lock nut using a flange wrench (commercial service tool).



9. Remove the companion flange using a puller (commercial service tool).



10. Remove the front oil seal using the puller (A) [SST: KV381054S0 (J-34286)].




**INSTALLATION** 

## < REMOVAL AND INSTALLATION >

 Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using the drift (A) [SST: ST15310000 (J-25640-B)].


### **CAUTION:**

- · Never reuse front oil seal.
- Never incline the new front oil seal when installing.



[REAR FINAL DRIVE: R230]

2. Align the matching mark (B) of drive pinion with the matching mark (A) of companion flange (1), and then install the companion flange.



Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using a flange wrench (commercial service tool).
 CAUTION:

## Never reuse drive pinion lock nut.


 Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

Total preload torque

: A value that add 0.1 – 0.4 N·m (0.01 – 0.04 kg-m, 0.9 – 3.5 in-lb) to the measured value before removing.

#### **CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.




- 5. Fit a test indicator to the inner side of companion flange (socket diameter).
- Rotate companion flange to check for runout.

# Companion flange runout : Refer to <u>DLN-222, "Companion Flange Runout".</u>

• If the runout value is outside the runout limit, follow the procedure below to adjust.

Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.



Α

В

DLN

Е

F

G

Н

I

K

M

Ν

0

## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

- If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
- If the runout value is still outside of the limit after the check and repair, replace companion flange.
- 7. Make a stamping for identification of front oil seal replacement frequency. Refer to "Identification stamp of replacement frequency of front oil seal".

#### **CAUTION:**

## Make a stamping after replacing front oil seal.

- Install rear propeller shaft. Refer to <u>DLN-144</u>, "<u>Removal and Installation</u>".
- 9. Install side flange with the following procedure.
- a. Attach the protector [SST: KV38108000 ( )] to side oil seal.
- b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
- c. Put a suitable drift on the center of side flange, then drive it until sound changes.


#### NOTE:


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

d. Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

## A : 342.2 mm (13.47 in)

- 10. Install drive shaft. Refer to RAX-11, "Removal and Installation".
- Refill gear oil to the final drive and check oil level. Refer to <u>DLN-193</u>, "Refilling".
- 12. Check the final drive for oil leakage. Refer to <u>DLN-193, "Inspection"</u>.






## [REAR FINAL DRIVE: R230]

## SIDE OIL SEAL

**Exploded View** INFOID:0000000006222416



- Final drive assembly
- 2. Side oil seal

Side flange

Oil seal lip

←: Apply anti-corrosion oil.

: Apply gear oil.

Refer to GI-4, "Components" for symbols not described above.

## Removal and Installation

INFOID:0000000006222417

#### **REMOVAL**

- Drain gear oil. Refer to <a href="DLN-193">DLN-193</a>, "Draining".
- Remove the drive shaft from the rear final drive assembly. Refer to RAX-11, "Removal and Installation".

**DLN-199** 

Remove the side flange using sliding hammer and attachment.

Α : Attachment [SST: KV40104100 ( В : Sliding hammer [SST: ST36230000 (J-25840-A)]


## NOTE:

Circular clip installation position: Side flange side

4. Remove the side oil seal using a suitable tool.

#### **CAUTION:**

Never damage gear carrier.



INSTALLATION

2011 QX56

Revision: 2010 May

В

Α

DLN

Е

Н

K

M

Ν

## SIDE OIL SEAL


### < REMOVAL AND INSTALLATION >

## [REAR FINAL DRIVE: R230]

 Install side oil seal until it becomes flush with the case end, using the drift (A) [SST: ST35271000 (J-26091)].

### **CAUTION:**

- Never reuse side oil seal.
- Never incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips of the new side oil seal.



- Install the side flange with the following procedure.
- a. Install the protector [SST: KV38108000 ( )] to the side oil seal as shown.
- Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the Tool.
- c. Drive in the side flange using suitable tool.


#### NOTE:


Installation is completed when the driving sound of the side flange turns into a sound which seems to affect the whole rear final drive assembly.

d. Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

## A : 342.2 mm (13.47 in)

- 3. Install drive shaft. Refer to RAX-11, "Removal and Installation".
- Refill gear oil to final drove and check oil level. Refer to <u>DLN-193, "Refilling"</u>.
- 5. When oil leaks while removing, check oil level after the installation. Refer to <u>DLN-193</u>, "Inspection".






## [REAR FINAL DRIVE: R230]

## **UNIT REMOVAL AND INSTALLATION**

## **REAR FINAL DRIVE**

Exploded View



- 1. Rear final drive assembly
- 2. Upper stopper

3. Lower stopper

- 4. Washer
- ∀
   □: Vehicle front


Refer to GI-4, "Components" for symbols in the figure.

## Removal and Installation

INFOID:0000000006222419

## **REMOVAL**

- 1. Remove spare tire.
- 2. Remove rear propeller shaft from the final drive. Refer to DLN-144, "Removal and Installation".
- Remove drive shaft from final drive with power tool. Then suspend it by wire, etc. Refer to <u>RAX-11</u>, "Removal and Installation".
- 4. Remove breather hose from the final drive.



С

Α

DLN

Е

F

G

Н

L

K

M

Ν

## **REAR FINAL DRIVE**

### < UNIT REMOVAL AND INSTALLATION >

Set a suitable jack to rear final drive assembly.


#### **CAUTION:**

Never place a jack under the rear cover (aluminum case).

Remove the mounting bolts and nuts connecting to the suspension member with power tool. And then, remove rear final drive assembly.

#### **CAUTION:**

Secure rear final drive assembly to a suitable jack while removing it.



[REAR FINAL DRIVE: R230]

### **INSTALLATION**

Note the following, and installation is in the reverse order of removal.

#### **CAUTION:**

Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.

• In (A) position, install the breather hose (1) until dimension (D) shown as follows.

: Vehicle front

## D : 20 mm (0.79 in)

#### **CAUTION:**

- Never reuse hose clamp.
- Install the hose clamp, with the tab facing downward.
- In (B) position, install the breather hose (2) until hose reaches the plane tube surface connector.

## **CAUTION:**

- Never reuse hose clamp.
- Install the hose clamp, with the tab facing rightward and upward direction of the vehicle at 45°.
- In (C) position, install the breather hose (2) until dimension (E) shown as follows.

## E: 20 mm (0.79 in)

• Install breather hose (1) and (2), breather tube (3) and metal connector (4) as shown in the figure.

∵: Vehicle front

- Fix breather hose (2) with clip in (A) position

## **CAUTION:**


## Never reuse clip.


- Install metal connector (4) to rear cover with a part to insert breather hose with facing vehicle left.

#### **CAUTION:**

#### Never reuse metal connector.

- Fix a point with paint mark (B) of breather tube (3) in (C) position.
- Fix breather tube (3) in (D) position.
- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to <u>DLN-193</u>, "Inspection".





Α

В

C

DLN

F

Н

K

L

M


Ν

Р

## UNIT DISASSEMBLY AND ASSEMBLY

## **DIFFERENTIAL ASSEMBLY**

Exploded View



- 1. Rear cover
- 4. Side gear
- 7. Pinion mate shaft
- 10. Side bearing adjusting washer
- 13. Pinion rear bearing
- 16. Circlip
- 19. Pinion front bearing
- 22. Drive pinion lock nut
- 25. Gasket
- A. Oil seal lip

- 2. Bearing cap
- 5. Pinion mate thrust washer
- 8. Lock pin
- 11. Drive pinion
- 14. Collapsible spacer
- 17. Side oil seal
- 20. Front oil seal
- 23. Drive gear
- 26. Drain plug
- B. Screw hole

- 3. Side gear thrust washer
- 6. Pinion mate gear
- 9. Side bearing
- 12. Pinion height adjusting washer
- 15. Side flange
- 18. Gear carrier
- 21. Companion flange
- 24. Differential case
- 27. Filler plug
- Comply with the assembly procedure when tightening. Refer to <u>DLN-206</u>. "Assembly".

: Apply gear oil.

\*: Apply anti-corrosion oil.

[REAR FINAL DRIVE: R230]

Apply Genuine Silicone RTV or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".


Refer to GI-4, "Components" for symbols not described above.

Disassembly


- 1. Drain gear oil, if necessary.
- 2. Remove side flanges.
- Remove rear cover mounting bolts.
- 4. Remove rear cover to insert the seal cutter [SST: KV10111100 (J-37228)] between gear carrier and rear cover.

#### **CAUTION:**

- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this may damage the mating surface.




5. Using spacers, mount carrier on the attachment (A) [SST: KV38100800 (J-25604-01)].




For proper reinstallation, paint matching marks on one side of the bearing cap.

#### **CAUTION:**

- For matching marks, use paint. Never damage bearing caps and gear carrier.
- Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.




7. Remove bearing caps.



## < UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R230]

8. Lift differential case assembly out with a suitable tool.



 Keep side bearing outer races together with inner race. Never mix them up.

Also, keep side bearing adjusting washers together with bearings.




9. Remove side bearing inner race.

To prevent damage to bearing, engage puller jaws in groove (\(\llime\)).

A : Puller [SST: ST33051001 (J-22888-20)]
B : Base [SST: KV40104730 ( — )]

## **CAUTION:**

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except when it is replaced.




10. For proper reinstallation, paint matching marks on one differential case assembly.

#### **CAUTION:**

For matching marks, use paint. Never damage differential case and drive gear.

- 11. Remove drive gear mounting bolts.
- 12. Tap drive gear off differential case assembly with a soft hammer. **CAUTION:**

Tap evenly all around to keep drive gear from bending.



Α

В

С

DLN

Е

F

G

Н

K

L

M


Ν

0


## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]


13. Remove lock pin of pinion mate shaft with a punch from drive gear side.



14. Remove pinion mate shaft.




- 15. Turn pinion mate gear, then remove pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.
- 16. Perform inspection after disassembly. Refer to <u>DLN-215, "Inspection"</u>.



Assembly

1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on the side gears.




## < UNIT DISASSEMBLY AND ASSEMBLY >

### [REAR FINAL DRIVE: R230]


Install side gears and thrust washers into differential case. CAUTION:

Make sure that the circular clip is installed to side gears.


3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and install them into differential case after installing thrust washer to pinion mate gear.



4. Align the lock pin holes on differential case with shaft, and install pinion mate shaft.



- 5. Measure side gear end play. If necessary, select the appropriate side gear thrust washers.
- a. Place differential case straight up so that side gear to be measured comes upward.



В

C

Α

DLN

F

Е

G

Н

J

K

M

N

0

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

Feeler gauges with the same thickness

Feeler gauges with the same thickness

b. Using feeler gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance of the other side as well.

#### Standard

Side gear back clearance : Refer to <u>DLN-222, "Side</u> <u>Gear Clearance".</u>

### **CAUTION:**

To prevent side gear from tilting, insert feeler gauges with the same thickness from both sides.

c. If the back clearance is outside the specification, use a thicker/ thinner side gear thrust washer to adjust. For selecting thrust washer, refer to the latest parts information.

When the back clearance is large:

Use a thicker thrust washer

When the back clearance is small:

Use a thinner thrust wash-


er.

#### **CAUTION:**

Select a side gear thrust washer for right and left individually.

 Drive a lock pin into pinion mate shaft, using a punch. Make sure lock pin is flush with differential case. CAUTION:

Never reuse lock pin.



PDIA0576E

- 7. Apply thread locking sealant into the thread hole of drive gear.
  - Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

#### **CAUTION:**

Clean and degrease drive gear back and threaded holes sufficiently.

8. Install drive gear to differential case.

#### **CAUTION:**

Align the matching marks of differential case and drive gear.


Tighten the mounting bolts with the following procedure. CAUTION:


Apply anti-corrosin oil to the thread and seat of mounting bolts.

a. Tighten the bolts in a crisscross fashion to the specified torque.

Drive gear mounting : 78.5 N•m (8.0 kg-m, 58 ft-lb) bolts tightening torque

b. Tighten the bolts additionally to the specified angle.





[REAR FINAL DRIVE: R230]

Drive gear mounting bolts tightening angle

: 31 to 36 degree

#### **CAUTION:**


Check the tightening angle using the angle wrench [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.

Press side bearing inner races to differential case, using the drift
 (A) and the base (B).


```
A : Drift [SST: ST01550002 ( — )]
B : Drift [SST: KV40104730 ( — )]
```

#### **CAUTION:**


Never reuse side bearing inner race.




- 11. Install differential case assembly with side bearing outer races into gear carrier.
- 12. Measure side bearing preload. If necessary, select the appropriate side bearing adjusting washers. Refer to <a href="DLN-210">DLN-210</a>, "Adjustment".



13. Insert selected left and right side bearing adjusting washers in place between side bearings and gear carrier. Refer to <a href="DLN-210">DLN-210</a>, "Adjustment".



- 14. Align matching marks on bearing cap with that on gear carrier.
- 15. Install bearing caps and tighten bearing cap mounting bolts.



DLN

Α

В

C

Ε

G

Н

|

K

L

M

Ν

0

### < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

16. Using the drift [SST: ST35271000 (J-26091)], drive side oil seals until it becomes flush with the case end.

#### **CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.
- 17. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to <u>DLN-210</u>, "Adjustment".


Recheck above items. Readjust the above description, if necessary.


- 18. Apply sealant to mating surface of rear cover.
  - Use Genuine Silicone RTV or equivalent. Refer to <u>GI-22</u>, "Recommended Chemical Products and Sealants".

#### **CAUTION:**

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

19. Install rear cover on gear carrier and tighten mounting bolts.






- 20. Install side flange with the following procedure.
- a. Attach the protector [SST: KV38108000 ( )] to side oil seal.
- After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
- c. Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the protector.


#### NOTE:

When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

d. Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

A : 342.2 mm (13.47 in)





Adjustment

## TOTAL PRELOAD TORQUE

Before inspection and adjustment, drain gear oil.

- 1. Secure final drive assembly onto an attachment [SST: KV38100800 ( )].
- Remove side flanges.
- 3. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

Rotate drive pinion at least 20 times to check for smooth operation of the bearing.


5. Measure total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

Total preload torque : Refer to <u>DLN-222, "Pre-load Torque".</u>

#### NOTE:

Total preload torque = Pinion bearing preload torque + Side bearing preload torque

 If measured value is out of the specification, disassemble it to check and adjust each part. Adjust the pinion bearing preload and side bearing preload. Adjust the pinion bearing preload first, then adjust the side bearing preload.



## When the preload torque is large

On pinion bearings: Replace the collapsible spacer.

On side bearings: Use thinner side bearing adjusting washers by the same amount to

each side. For selecting adjusting washer, refer to the latest parts in-

formation.

## When the preload is small

On pinion bearings: Tighten the drive pinion lock nut.

On side bearings: Use thicker side bearing adjusting washers by the same amount to

each side. For selecting adjusting washer, refer to the latest parts in-

formation.


#### SIDE BEARING PRELOAD

Before inspection and adjustment, drain gear oil.


1. Remove rear cover. Refer to DLN-204, "Disassembly".

2. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.

3. Place the differential case, with side bearings and bearing races installed, into gear carrier.



4. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.



Α

В

С

DLN

Е

Н

J

K

L

M


Ν

0

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]


- 5. Install bearing caps in their correct locations and tighten bearing cap mounting bolts.
- Turn the carrier several times to seat the bearings.



 Measure the turning torque of the carrier at the drive gear mounting bolts with a spring gauge [SST: — (J-8129)].

**Specification** 

: 34.2 – 39.2N (3.5 – 4.0 kg, 7.7 – 8.8 lb) of pulling force at the drive gear bolt



8. If the turning torque is outside the specification, use a thicker/ thinner side bearing adjusting washer to adjust. For selecting adjusting washer, refer to the latest parts information.

If the turning torque is less U than the specified range: el

Use a thicker thrust washer.

If the turning torque is greater than the specifica-

Use a thinner thrust wash-

tion:

#### **CAUTION:**

Select a side bearing adjusting washer for right and left individually.

9. Record the total amount of washer thickness required for the correct carrier side bearing preload.

#### DRIVE GEAR RUNOUT

- 1. Remove rear cover. Refer to <a href="DLN-204">DLN-204</a>, "Disassembly".
- 2. Fit a dial indicator to the drive gear back face.
- 3. Rotate the drive gear to measure runout.

Drive gear runout : Refer to <u>DLN-222, "Drive</u> Gear Runout".

 If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between drive gear and differential case, or differential case or drive gear may be deformed, etc.





Replace drive gear and drive pinion gear as a set.

#### TOOTH CONTACT

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to <u>DLN-204</u>, "<u>Disassembly</u>".






## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

2. Apply red lead to drive gear.


### **CAUTION:**

Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.



 Rotate drive gear back and forth several times, check drive pinion gear to drive gear tooth contact.
 CAUTION:

Check tooth contact on drive side and reverse side.



		Pinion height adjusting washer selection value		Adjustment	Possible cause		
Drive sid	e	Back sid	е	wasner selection value [ mm (in) ]		(Yes/No)	1 ossible cause
Heel side	Toe side	Toe side	Heel side		+0.06 (+0.0024)	Yes	Occurrence of noise and scoring sound in all speed ranges.
The state of the s		(1)	$\neg$	Thicker	+0.04 (+0.0016)	165	Occurrence of noise when accelerating.
		(			+0.02 (+0.0008)		
( )					0	No	-
	<u> </u>				-0.02 (-0.0008)		
****	» )		``	Thinner	-0.04 (-0.0016)	Yes	Occurrence of noise at constant speed and decreasing speed.
	***		<u> </u>		-0.06 (-0.0024)	Yes	Occurrence of noise and scoring sound in all speed ranges.

Α

В

С

DLN

Е

F

G

Н

J

K

L

 $\mathbb{N}$ 

N

0

Р


Revision: 2010 May **DLN-213** 2011 QX56

JPDID0398GB

## < UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R230]

4. If tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height [dimension (X)].




• If the tooth contact is near the face (face contact), or near the heel (heel contact), thicken pinion height adjusting washers to move drive pinion closer to drive gear.

For selecting adjusting washer, refer to the latest parts information.



• If the tooth contact is near the flank (flank contact), or near the toe (toe contact), thin pinion height adjusting washers to move drive pinion farther from drive gear.

For selecting adjusting washer, refer to the latest parts information.



#### **BACKLASH**

Before inspection and adjustment, drain gear oil.


- 1. Remove rear cover. Refer to <u>DLN-204</u>, "<u>Disassembly</u>".
- 2. Fit a dial indicator to the drive gear face to measure the backlash.

Backlash : Refer to DLN-222, "Backlash".

• If the backlash is outside of the specified value, change the thickness of side bearing adjusting washer.

### When the backlash is large:

Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.



## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

When the backlash is small:

Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.

В

Α

**CAUTION:** 

Never change the total amount of washers as it changes the bearing preload.

INFOID:0000000006222424

Inspection

#### INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

Bearing

Clean up the disassembled parts.

 If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

Side Gear and Pinion Mate Gear

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

Differential case

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

DLN

Е

F

Н


L

N

## [REAR FINAL DRIVE: R230]

## **DRIVE PINION**

Exploded View



- 1. Rear cover
- 4. Side gear
- 7. Pinion mate shaft
- 10. Side bearing adjusting washer
- 13. Pinion rear bearing
- 16. Circlip
- 19. Pinion front bearing
- 22. Drive pinion lock nut
- 25. Gasket
- A. Oil seal lip

- 2. Bearing cap
- 5. Pinion mate thrust washer
- 8. Lock pin
- 11. Drive pinion
- 14. Collapsible spacer
- 17. Side oil seal
- 20. Front oil seal
- 23. Drive gear
- 26. Drain plug
- B. Screw hole

- 3. Side gear thrust washer
- 6. Pinion mate gear
- 9. Side bearing
- 12. Pinion height adjusting washer
- 15. Side flange
- Gear carrier
- 21. Companion flange
- 24. Differential case
- 27. Filler plug
- C. Comply with the assembly procedure when tightening. Refer to <u>DLN-206</u>, "Assembly".

- Apply gear oil.
- \*: Apply anti-corrosion oil.
- Apply Genuine Silicone RTV or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

[REAR FINAL DRIVE: R230]

Α

В

C

DLN

Е

Н

M

Ν


Р

Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to GI-22, "Recommended Chemical Products and Sealants".

Refer to GI-4, "Components" for symbols not described above.

Disassembly INFOID:0000000000222426

- 1. Remove differential case assembly. Refer to <u>DLN-204, "Disassembly"</u>.
- 2. Remove drive pinion lock nut with the flange wrench (commercial service tool).



3. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

### **CAUTION:**


For matching mark, use paint. Never damage companion flange and drive pinion.


#### NOTE:

The matching mark on the final drive companion flange indicates the maximum vertical runout position.

When replacing companion flange, matching mark is not necessary.

4. Remove companion flange using the suitable puller (commercial service tool).






5. Press drive pinion assembly out of gear carrier. **CAUTION:** 

## Never drop drive pinion assembly.

- Remove front oil seal.
- Remove side oil seal.
- 8. Remove pinion front bearing inner race.
- 9. Remove collapsible spacer.




Revision: 2010 May **DLN-217** 2011 QX56

## **DRIVE PINION**

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

10. Remove pinion rear bearing inner race and pinion height adjusting washer with the replacer (A) (commercial service tool).




11. Tap pinion front/rear bearing outer races uniformly using a brass rod or equivalent to remove them.

### **CAUTION:**

Never damage gear carrier.

 Perform inspection after disassembly. Refer to <u>DLN-220</u>, "Inspection".



Assembly

 Install front bearing outer race and rear bearing outer race using drifts.


A : Drift [SST: KV38103300 ( — )]

B : Drift [SST: ST30611000 (J-25742-1)]

C : Drift bar [SST: ST30621000 (J-25742-5)]

#### **CAUTION:**


- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse pinion front and rear bearing outer race.
- 2. Select drive pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.



## **DRIVE PINION**

### < UNIT DISASSEMBLY AND ASSEMBLY >

- Install selected drive pinion height adjusting washer (2) to drive pinion. Press pinion rear bearing inner race (1) to it, using drift (A) [SST: ST30022000 ( )].
   CAUTION:
  - Be careful of the direction of pinion height adjusting washer. (Assemble as shown in the figure.)
  - Never reuse pinion rear bearing inner race.



Collapsible spacer

Pinion front bearing inner race

[REAR FINAL DRIVE: R230]

4. Assemble collapsible spacer to drive pinion.


#### **CAUTION:**

Never reuse collapsible spacer.

- Apply gear oil to pinion rear bearing, and assemble drive pinion into gear carrier.
- Apply gear oil to pinion front bearing, and assemble pinion front bearing inner race to drive pinion assembly. CAUTION:


Never reuse pinion front bearing inner race.

7. Using suitable spacer (A), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.



- 8. Using the drift (A) [SST: ST15310000 (J-25640-B)], install front oil seal in evenly until it becomes flush with the gear carrier.


  CAUTION:
  - Never reuse oil seal.
  - When installing, never incline oil seal.
  - Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



9. Install companion flange (1).

#### NOTE:

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange.



DLN

Α

В

Е

Drive pinion

Pinion rear bearing

inner race 💢 🏠

PDIA0492E

F

G

Н

<

L

 $\mathbb{N}$ 

Ν

0

[REAR FINAL DRIVE: R230]

10. Apply anti-corrosion oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool). **CAUTION:** 

## Never reuse drive pinion lock nut.

11. Adjust to the drive pinion lock nut tightening torque and pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

> Pinion bearing preload : Refer to DLN-222, "Preload Torque".

#### **CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
- 12. Install differential case assembly. Refer to DLN-206, "Assembly".



#### Never install rear cover at this timing.

- 13. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and companion flange runout. Refer to <u>DLN-210, "Adjustment"</u> and <u>DLN-220, "Adjustment"</u>. Recheck above items. Readjust the above description, if necessary.
- 14. Check total preload torque. Refer to DLN-210, "Adjustment".
- 15. Install rear cover. Refer to DLN-206, "Assembly".

Adjustment INFOID:0000000006222428

#### COMPANION FLANGE RUNOUT

- 1. Fit a test indicator to the inner side of the companion flange (socket diameter).
- Rotate companion flange to check for runout.

Inner side of companion : Refer to DLN-222, "Comflange runout panion Flange Runout".

- 3. If the runout value is outside the runout limit, follow the procedure below to adjust.
- Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
- If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
- If the runout value is still outside of the limit after the check and repair, replace companion flange.


Inspection INFOID:0000000006222429



#### INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.



JPDID039977

## **DRIVE PINION**

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

• If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

## Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

#### Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

#### Companion Flange

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

DLN

Α

В

C

Е

F

U

Н

Κ

L

M

Ν

0

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

## **General Specification**

INFOID:0000000006222430

[REAR FINAL DRIVE: R230]

		2WD	4WD	
Applied model		VK56	6VD	
		A/	Т	
Final drive model		R2	30	
Gear ratio		2.937		
Number of teeth (Drive gear/Drive pinio	on)	47/	16	
Oil capacity (Approx.)	ℓ (US pt, Imp pt)	1.75 (3-3/	(4, 3-1/8)	
Number of pinion gears		2	!	
Drive pinion adjustment spacer type		Collap	osible	

## **Drive Gear Runout**

INFOID:0000000006222431

Unit: mm (in)

Item	Runout limit
Drive gear back face	0.05 (0.0020) or less

## Side Gear Clearance

INFOID:0000000006222432

Unit: mm (in)

Item	Specification	
Side gear back clearance (Clearance limit between side gear and differential case for adjusting side gear backlash)	0.20 (0.0079) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)	

## **Preload Torque**

INFOID:0000000006222433

Item	Specification
Drive pinion bearing preload torque	1.76 – 2.65 N⋅m (0.18 – 0.27 kg–m, 16 – 23 in-lb)
Side bearing preload torque (reference value determined by drive gear bolt pulling force)	0.29 – 1.47 N·m (0.03 – 0.14 kg−m, 3 – 13 in-lb)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.06 – 4.12 N·m (0.21 – 0.42 kg−m, 19 – 36 in-lb)

Backlash INFOID:0000000006222434

Unit: mm (in)

Item	Specification	
Drive gear to drive pinion gear	0.13 – 0.18 (0.0051 – 0.0070)	

## Companion Flange Runout

INFOID:0000000006222435

Unit: mm (in)

Item	Runout limit
Inner side of the companion flange	0.08 (0.0031) or less