

INTIMIDATOR SCAN 360

User Manual



TABLE OF CONTENTS

1. Before You Begin	1
What Is Included	1
Unpacking Instructions.....	1
Claims	1
Text Conventions	1
Symbols	1
Disclaimer	1
Intellectual Property	1
Safety Notes.....	2
2. Introduction	3
Product Overview.....	3
Product Dimensions	3
3. Setup	4
AC Power.....	4
Fuse Replacement	4
Power Linking.....	4
Mounting	5
Orientation.....	5
Rigging	5
4. Operation	6
Control Panel Operation.....	6
Menu Map	6
DMX Configuration.....	7
Starting Address.....	7
DMX Personalities.....	7
Gobos.....	7
DMX Channel Assignments and Values	8
DMX Values	8
Standalone Configuration.....	10
Automatic Programs.....	10
Sound-Active Mode	10
Sound Sensitivity.....	10
Manual Mode.....	10
Settings Configuration.....	11
Pan Reverse.....	11
Tilt Reverse	11
Screen Reverse.....	11
Signal Loss.....	11
Indicator.....	11
Flash if DMX.....	11
Factory Reset.....	12
System Information	12
IRC-6 Infrared Remote Control	12
IRC-6 Operation	12
Master/Slave Mode	13
5. Maintenance.....	14
Product Maintenance	14
6. Technical Specifications	15
Contact Us	16
Warranty & Returns.....	16

1. Before You Begin

What Is Included

- Intimidator Scan 360
- Quick Reference Guide
- Power cable

Unpacking Instructions

Carefully unpack the product immediately and check the container to make sure all the parts are in the package and are in good condition.

Claims

If the box or the contents (the product and included accessories) appear damaged from shipping, or show signs of mishandling, notify the carrier immediately, not Chauvet. Failure to report damage to the carrier immediately may invalidate a claim. In addition, keep the box and contents for inspection.

For other issues, such as missing components or parts, damage not related to shipping, or concealed damage, file a claim with Chauvet within 7 days of delivery.

Text Conventions

Convention	Meaning
1–512	A range of values
50/60	A set of values of which only one can be chosen
Settings	A menu option not to be modified
<ENTER>	A key to be pressed on the product's control panel
ON	A value to be entered or selected

Symbols

Symbol	Meaning
	Electrical warning. Not following these instructions may cause electrical damage to the product, accessories, or the user.
	Critical installation, configuration, or operation information. Not following these instructions may make the product not work, cause damage to the product, or cause harm to the operator.
	Important installation or configuration information. The product may not function correctly if this information is not used.
	Useful information.

Disclaimer

Chauvet believes that the information contained in this manual is accurate in all respects. However, Chauvet assumes no responsibility and specifically disclaims any and all liability to any party for any loss, damage or disruption caused by any errors or omissions in this document, whether such errors or omissions result from negligence, accident or any other cause. Chauvet reserves the right to revise the content of this document without any obligation to notify any person or company of such revision, however, Chauvet has no obligation to make, and does not commit to make, any such revisions. Download the latest version from www.chauvetdj.com.

Intellectual Property

The works of authorship contained in this manual, including, but not limited to, all designs, text, and images are owned by Chauvet.

© Copyright 2023 Chauvet & Sons, LLC. All rights reserved.

Electronically published by Chauvet in the United States of America.

Chauvet, the Chauvet logo, Chauvet DJ, and Intimidator Scan 360 are registered trademarks or trademarks of Chauvet & Sons LLC (d/b/a Chauvet and Chauvet Lighting) in the United States and other countries. Other company and product names and logos referred to herein may be trademarks of their respective companies.

Safety Notes

■ ALWAYS:



- Connect to a grounded circuit.
- Connect to operating voltages as specified on the product's spec sticker.
- Disconnect from power before replacing the fuse.
- Disconnect from its power source during periods of inactivity.
- Use a safety cable when suspending overhead.
- Heed all restrictions and warnings on the spec sticker.
- Mount in a location with at least 20 in (50 cm) of ventilation.
- Replace the fuse with the same type and rating.
- Use a clamp with a captive bolt when a single hanging bracket is used.

- In the event of a serious operating problem, stop using immediately.

■ DO NOT:




- Open this product or attempt any repairs. It contains no user-serviceable parts.
- Look at the light source when the product is on.
- Use if the power cord is crimped or damaged.
- Disconnect by pulling on the power cord.
- Allow flammable materials close to the product when it is operating.
- Touch the housing when it is on.
- Block any ventilation holes/slots in the housing.
- Connect to a dimmer or rheostat.
- Carry the product by its power cord.
- Operate in temperatures higher than 104°F (40°C).
- Expose to environments that exceed the Ingress Protection (IP) rating.
- Expose to rain or moisture.
- Use outdoors.
- Expose to corrosive environmental conditions such as temperature, humidity, salinity, pressure, radiation, or shock.
- Set this product on a flammable surface.




Keep this User Manual for future use. If the product is sold to someone else, be sure that they also receive this document.

2. Introduction

Product Overview



Product Dimensions



3. Setup

AC Power

The Intimidator Scan 360 has an auto-ranging power supply, and it can work with an input voltage range of 100 to 240 VAC, 50/60 Hz.

To determine the product's power requirements (circuit breaker, power outlet, and wiring), use the current value listed on the label affixed to the product's back panel, or refer to the product's specifications chart.

The listed current rating indicates the product's average current draw under normal conditions.




- **Always connect the product to a protected circuit (a circuit breaker or fuse). Make sure the product has an appropriate electrical ground to avoid the risk of electrocution or fire.**
- **To eliminate unnecessary wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it.**



Never connect the product to a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel serves only as a 0 to 100% switch.

Fuse Replacement

1. Disconnect the product from power.
2. Wedge the tip of a flat-head screwdriver into the slot of the fuse holder.
3. Pry the fuse holder out of the housing.
4. Remove the blown fuse from the holder and replace with a fuse of the exact same type and rating.
5. Insert the fuse holder back in place and reconnect power.




Disconnect the product from the power outlet before replacing the fuse.

Power Linking

The product provides power linking via the outlets located in the back of the product. See the diagram below for further explanation.

Power Linking Diagram



It is possible to power link up to 4 Intimidator Scan 360 products on 120 VAC or up to 7 products on 230 VAC.



The power-linking diagram shown above corresponds to the North American version of the product ONLY! If using the product in other markets, consult with the local Chauvet distributor, as power linking connectors and requirements may differ by country or region.

Mounting

Before mounting the product, read and follow the safety recommendations indicated in the [Safety Notes](#).


Orientation

The Intimidator Scan 360 may be mounted in any position; however, make sure adequate ventilation is provided around the product.

Rigging

- Before deciding on a location, always make sure there is easy access to the product for maintenance and programming.
- Make sure adequate ventilation is provided around the product.
- Make sure that the structure or surface onto which the product is being mounted can support the product's weight (see the [Technical Specifications](#)).
- When mounting the product overhead, always use a safety cable. Mount the product securely to a rigging point, whether an elevated platform or a truss.
- When rigging the product onto a truss, use a mounting clamp of appropriate weight capacity.
- When power linking multiple products, mount the products close enough for power-linking cables to reach.
- The rubber feet also serve as floor supports and allow for surface mounting. When mounting the product on the floor, make sure that the product and cables are away from people and vehicles.

Mounting Diagram



When using only one mounting clamp with this fixture, use a clamp with a captive bolt to prevent accidental loosening.

4. Operation

Control Panel Operation

To access the control panel functions, use the four buttons located underneath the display. Refer to the [Product Overview](#) to see the button locations on the control panel.

Button	Function
<MENU>	Press to find an operation mode or to back out of the current menu option
<UP>	Press to scroll up the list of options or to increase the numeric value in a function
<DOWN>	Press to scroll down the list of options or to decrease the numeric value in a function
<ENTER>	Press to activate a menu option or set the selected value in a function

Menu Map

Refer for the Intimidator Scan 360 product page on www.chauvetdj.com for the latest menu map.

Main Function	Programming Levels		Description
Address	001–512		Sets the DMX starting address
Run Mode	DMX	8Ch	Selects DMX mode
		12Ch	
	Slave		Sets unit to Slave mode
	Auto		Sets unit to Auto mode
	Sound		Sets unit to Sound-active mode
	IR		Sets unit to infrared control mode
	Manual	Pan	Controls pan settings
		Tilt	Controls tilt settings
		Color	Selects color options
		Gobo	Selects gobo options
		Gobo Rotate	Controls gobo rotation effects
		Prism	Selects prism effects
		Focus	Controls focus
		Dimmer	Sets dimmer value
		Strobe	Controls strobe effects
Setup	Pan Reverse	OFF	Normal pan operation
		ON	Reverse pan operation
	Tilt Reverse	OFF	Normal tilt operation
		ON	Reverse tilt operation
	Screen Reverse	OFF	Normal display
		ON	Reverse display
	Signal Loss	Blackout	Turns the unit off when DMX signal is lost
		Hold	Holds the last setting when DMX signal is lost
		Auto	Sets the unit to Auto mode when signal is lost
		Sound	Sets the unit to Sound mode when signal is lost
	Sensitivity	001–100	Sound sensitivity control
	Indicator	OFF	Turns indicator on or off
		ON	
	Flash if DMX	OFF	LED Indicator flashes when DMX is turned ON or OFF
		ON	
	Reset		Revert to factory settings
Sys Info	Ver	V_._	Displays software version
	Running Mode	-----	Displays current running mode
	DMX Address	---	Displays current DMX mode
	Temperature	---	Displays the product temperature in Celsius

Operation

DMX Configuration

The Intimidator Scan 360 works with a DMX controller. Information about DMX is in the CHAUVET DMX Primer, which is available from the Chauvet website

http://www.chauvetlighting.com/downloads/DMX_Primer_rev05_WO.pdf.

Starting Address

When selecting a starting DMX address, always consider the number of DMX channels the selected DMX mode uses. If the starting address is set too high, access to some of the product's channels could be restricted.

The Intimidator Scan 360 uses up to 12 DMX channels, which defines the highest configurable address to **501**.

For information about the DMX protocol, download the DMX Primer from www.chauvetdj.com.

To select the starting address, do the following:

1. Press **<MENU>** repeatedly until **Address** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select the starting address, from **001–512**.
4. Press **<ENTER>**.


DMX Personalities

The Intimidator Scan 360 has two DMX personalities: an 8-channel personality and a 12-channel personality.

To select a DMX personality, follow the instructions below.

1. Press **<MENU>** repeatedly until **Run Mode** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select **DMX**.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select the DMX personality, from **8Ch** or **12Ch**.
6. Press **<ENTER>**.

Gobos



DMX Channel Assignments and Values

DMX Values

8Ch	12Ch	Function	Value	Percent/Setting
1	1	Pan	000 ⇄ 255	0–172°
2	2	Tilt	000 ⇄ 255	0–39°
-	3	Pan/tilt speed	000 ⇄ 255	Fast to slow
3	4	Color	000 ⇄ 006	Open
			007 ⇄ 013	Orange
			014 ⇄ 020	Lime
			021 ⇄ 027	Cyan
			028 ⇄ 034	Red
			035 ⇄ 041	Green
			042 ⇄ 048	Magenta
			049 ⇄ 055	Yellow
			056 ⇄ 062	Blue
			063 ⇄ 064	White
			065 ⇄ 189	Split colors
			190 ⇄ 221	Clockwise scroll, fast to slow
			222 ⇄ 223	Stop
			224 ⇄ 255	Counterclockwise scroll, slow to fast
4	5	Gobo wheel (see Gobos)	000 ⇄ 007	Open
			008 ⇄ 015	Gobo 1
			016 ⇄ 023	Gobo 2
			024 ⇄ 031	Gobo 3
			032 ⇄ 039	Gobo 4
			040 ⇄ 047	Gobo 5
			048 ⇄ 055	Gobo 6
			056 ⇄ 063	Gobo 7
			064 ⇄ 071	Gobo 7 shaking, slow to fast
			072 ⇄ 079	Gobo 6 shaking, slow to fast
			080 ⇄ 087	Gobo 5 shaking, slow to fast
			088 ⇄ 095	Gobo 4 shaking, slow to fast
			096 ⇄ 103	Gobo 3 shaking, slow to fast
			104 ⇄ 111	Gobo 2 shaking, slow to fast
			112 ⇄ 119	Gobo 1 shaking, slow to fast
			120 ⇄ 127	Open
			128 ⇄ 189	Clockwise rotation, fast to slow
			190 ⇄ 193	Stop
			194 ⇄ 255	Counterclockwise rotation, slow to fast
5	6	Gobo rotation	000 ⇄ 063	Gobo index
			064 ⇄ 145	Clockwise rotation, slow to fast
			146 ⇄ 149	Stop
			150 ⇄ 231	Counterclockwise rotation, slow to fast
6	7	Prism	232 ⇄ 255	Boomerang, short to long
			000 ⇄ 015	No function
			016 ⇄ 127	Prism on (static)
7	8	Focus	128 ⇄ 255	Clockwise rotation, slow to fast
			000 ⇄ 255	0–100%
-	9	Dimmer	000 ⇄ 255	0–100%

Operation

8Ch	12Ch	Function	Value	Percent/Setting
8	10	Strobe	000 ⇄ 003	No function
			004 ⇄ 007	Open
			008 ⇄ 076	Synchronized strobe, slow to fast
			077 ⇄ 145	Pulse strobe, slow to fast
			146 ⇄ 215	Random strobe, slow to fast
			216 ⇄ 255	Open
-	11	Functions	000 ⇄ 007	No function
			008 ⇄ 015	Blackout on pan/tilt movement
			016 ⇄ 023	Blackout on color wheel movement
			024 ⇄ 031	Blackout on gobo wheel movement
			032 ⇄ 039	Blackout on pan/tilt/color wheel movement
			040 ⇄ 047	Blackout on pan/tilt/gobo wheel movement
			048 ⇄ 055	Blackout on pan/tilt/color wheel/gobo wheel movement
			056 ⇄ 095	No function
			096 ⇄ 103	Pan reset
			104 ⇄ 111	Tilt reset
			112 ⇄ 119	Color reset
			120 ⇄ 127	Gobo reset
			128 ⇄ 135	No function
			136 ⇄ 143	Prism reset
			144 ⇄ 151	Focus reset
			152 ⇄ 159	All reset
			160 ⇄ 255	No function
-	12	Movement macros	000 ⇄ 007	No function
			008 ⇄ 023	Movement macro 1
			024 ⇄ 039	Movement macro 2
			040 ⇄ 055	Movement macro 3
			056 ⇄ 071	Movement macro 4
			072 ⇄ 087	Movement macro 5
			088 ⇄ 103	Movement macro 6
			104 ⇄ 119	Movement macro 7
			120 ⇄ 135	Movement macro 8
			136 ⇄ 151	Sound-active movement macro 1
			152 ⇄ 167	Sound-active movement macro 2
			168 ⇄ 183	Sound-active movement macro 3
			184 ⇄ 199	Sound-active movement macro 4
			200 ⇄ 215	Sound-active movement macro 5
			216 ⇄ 231	Sound-active movement macro 6
			232 ⇄ 247	Sound-active movement macro 7
			248 ⇄ 255	Sound-active movement macro 8

Standalone Configuration

Set the product in one of the standalone modes to control without a DMX controller.



Never connect a product that is operating in any standalone mode to a DMX string connected to a DMX controller. Products in standalone mode may transmit DMX signals that could interfere with the DMX signals from the controller.

Automatic Programs

To run the Intimidator Scan 360 in automatic mode, follow the instructions below:

1. Press **<MENU>** repeatedly until **Run Mode** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select **Auto**.
4. Press **<ENTER>**.

Sound-Active Mode

To run the Intimidator Scan 360 in sound-active mode, do the following:

1. Press **<MENU>** repeatedly until **Run Mode** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select **Sound**.
4. Press **<ENTER>**.

Sound Sensitivity

To set the sound sensitivity on the Intimidator Scan 360, follow the instructions below:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select **Sound Sensitivity**.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to increase or decrease the sound sensitivity, from **001–100**.
6. Press **<ENTER>**.



The product will only respond to low frequencies of music (bass and drums).

Manual Mode

To operate the Intimidator Scan 360 manually through the menu, do the following:

1. Press **<MENU>** repeatedly until **Run Mode** shows on the display.
2. Press **<ENTER>**.
3. Use **<UP>** or **<DOWN>** to select **Manual**.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select from **Pan, Tilt, Color, Gobo, Gobo Rotate, Prism, Focus, Dimmer, or Strobe**.
6. Press **<ENTER>**.
7. Use **<UP>** or **<DOWN>** to increase or decrease the value of the function, from **000–255**.
8. Press **<ENTER>**.
9. Repeat steps 3-6 until the product is set as desired.

Settings Configuration

Pan Reverse

To set the pan orientation on the Intimidator Scan 360, follow the instructions below:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Press **<MENU>** repeatedly until **Pan Reverse** shows on the display.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select **OFF** (normal pan orientation) or **ON** (reverse pan orientation).
6. Press **<ENTER>**.

Tilt Reverse

To set the tilt orientation on the Intimidator Scan 360, do the following:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Press **<MENU>** repeatedly until **Tilt Reverse** shows on the display.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select **OFF** (normal tilt orientation) or **ON** (reverse tilt orientation).
6. Press **<ENTER>**.

Screen Reverse

To set the screen display on the Intimidator Scan 360, follow the instructions below:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Press **<MENU>** repeatedly until **Screen Reverse** shows on the display.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select **OFF** (normal screen display) or **ON** (reverse screen display).
6. Press **<ENTER>**.

Signal Loss

To set the action that the Intimidator Scan 360 does once DMX signal is lost, follow the instructions below:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Press **<MENU>** repeatedly until **Signal Loss** shows on the display.
4. Press **<ENTER>**.
5. Use **<UP>** or **<DOWN>** to select **Blackout** (turns the unit off), **Hold** (retains the last setting), **Auto** (sets the unit to Auto mode), or **Sound** (sets the unit to Sound mode).
6. Press **<ENTER>**.

Indicator

To enable or disable the LED indicator, do the following:

1. Press **<MENU>**.
2. Use **<UP>** or **<DOWN>** to select **Setup**.
3. Press **<ENTER>**.
4. Use **<UP>** or **<DOWN>** to select **Indicator**.
5. Press **<ENTER>**.
6. Use **<UP>** or **<DOWN>** to select **OFF** (disabled) or **ON** (enabled).
7. Press **<ENTER>**.

Flash if DMX

To enable or disable the LED indicator flashing to indicate DMX, do the following:

1. Press **<MENU>**.
2. Use **<UP>** or **<DOWN>** to select **Setup**.
3. Press **<ENTER>**.
4. Use **<UP>** or **<DOWN>** to select **Flash if DMX**.
5. Press **<ENTER>**.
6. Use **<UP>** or **<DOWN>** to select **OFF** (will not indicate DMX) or **ON** (Will indicate DMX).
7. Press **<ENTER>**.

Factory Reset

To restore the Intimidator Scan 360 to factory default settings, follow the instructions below:

1. Press **<MENU>** repeatedly until **Setup** shows on the display.
2. Press **<ENTER>**.
3. Select **Reset** to revert the fixture to its default factory settings.
4. Press **<ENTER>**.

System Information

To view the system information on the Intimidator Scan 360, do the following:


1. Press **<MENU>**.
2. Use **<UP>** or **<DOWN>** to select **Sys Info**.
3. Press **<ENTER>**.
4. Select **Ver** (displays the fixture's software version), **Running Mode** (displays the current running mode), **DMX Address** (displays the current DMX mode), and **Temperature** (displays the fixture's current temperature in Celsius).

IRC-6 Infrared Remote Control

The Intimidator Scan 360 is compatible with the IRC-6 infrared remote control from Chauvet. To set the Intimidator Scan 360 to IR mode, follow the instructions below:

1. Press **<MENU>** repeatedly until **Run Mode** shows on the display.
2. Press **<ENTER>**.
3. Press **<UP>** or **<DOWN>** to select **IR**.
4. Press **<ENTER>**.

IRC-6 Operation



Automatic Mode

Automatic mode will enable the user to run the automatic programs on the product. To turn on Automatic mode:

- Press **<AUTO>** on the IRC-6.

To adjust the speed of the automatic program:

1. Press **<SPEED>** on the IRC-6.
2. Press **<+>** or **<->** to increase or decrease the speed of the program.

Sound-Active Mode

Sound-Active mode will enable the product to respond to the music.

To turn on Sound-Active mode:

- Press **<SOUND>** on the IRC-6.

Sound Sensitivity

- To adjust the fixture's sensitivity to sound:

1. Press **<SENSITIVITY>** on the IRC-6.
2. Press **<+>** or **<->** to increase or decrease the sound sensitivity.

To set all LEDs to full intensity:

- Press **<0>** on the IRC-6.

Miscellaneous Operation

To adjust the output level of the LEDs in manual color mode:

- Press **<%>** repeatedly on the IRC-6.

To black out the lights:

- Press **<BLACK OUT>** on the IRC-6.

This will turn off all the lights until the button is pressed again.

NOTE: The IRC-6 will not respond to any inputs when Black Out is activated. If the remote does not respond when a button is pressed, try pressing **<BLACK OUT>**. Black Out might inadvertently been activated.

Master/Slave Mode

The Master/Slave mode allows a single Intimidator Scan 360 product (the “master”) to control the actions of one or more Intimidator Scan 360 products (the “slaves”) without the need of a DMX controller. The master product will be set to operate in either standalone mode or with the IRC-6, while the slave products will be set to operate in slave mode. Once set and connected, the slave products will operate in unison with the master product.

Configure the products as indicated below.

Slave products:

1. Press **<MENU>**.
2. Use **<UP>** or **<DOWN>** to select **Run Mode**.
3. Press **<ENTER>**.
4. Use **<UP>** or **<DOWN>** to select **Slave**.
5. Press **<ENTER>**.
6. Connect the DMX input of the first slave product to the DMX output of the master product.
7. Connect the DMX input of the subsequent slave products to the DMX output of the previous slave product.
8. Finish setting and connecting all the slave products.

Master product:

1. Set the master product to operate in standalone mode.
2. Make the master product the first product in the DMX daisy chain.



- **Configure all the slave products before connecting the master to the daisy chain.**
- **Never connect a DMX controller to a DMX string configured for Master/Slave operation because the controller may interfere with the signals from the master.**
- **Do not connect more than 31 slaves to the master.**

5. Maintenance

Product Maintenance

Dust build-up reduces light output performance and can cause overheating. This can lead to reduction of the light source's life and/or mechanical wear. To maintain optimum performance and minimize wear, clean all lighting products at least twice a month. However, be aware that usage and environmental conditions could be contributing factors to increase the cleaning frequency.

To clean the product, follow the instructions below:

1. Unplug the product from power.
2. Wait until the product is at room temperature.
3. Use a vacuum (or dry compressed air) and a soft brush to remove dust collected on the external surface/vents.
4. Clean all transparent surfaces with a mild soap solution, ammonia-free glass cleaner, or isopropyl alcohol.
5. Apply the solution directly to a soft, lint free cotton cloth or a lens cleaning tissue.
6. Softly drag any dirt or grime to the outside of the transparent surface.
7. Gently polish the transparent surfaces until they are free of haze and lint.



Always dry the transparent surfaces carefully after cleaning them.



Do not spin the cooling fans using compressed air because they could be damaged.

6. Technical Specifications

Dimensions and Weight

Length	Width	Height	Weight
10 in (255 mm)	6 in (155 mm)	16.3 in (415 mm)	12.6 lb (5.7 kg)

Note: Dimensions in inches rounded to the nearest decimal digit.

Power

Power Supply Type	Range	Voltage Selection
Switching (internal)	100 to 240 VAC, 50/60 Hz	Auto-ranging
Parameter	120 V, 60 Hz	230 V, 50 Hz
Consumption	147 W	143 W
Operating current	1.9 A	1.1 A
Power linking	8 A (4 products)	8 A (7 products)
Fuse	F 3 A, 250 V	F 3 A, 250 V
Power I/O	U.S./Worldwide	UK/Europe
Power input connector	IEC	IEC
Power cord plug	Edison (U.S.)	Local plug

Light Source

Type	Color	Quantity	Power	Current	Lifespan
LED	White	1	100 W	4.2 A	50,000 hours

Photometrics

Strobe Rate	Beam Angle	Illuminance @ 2 m
0 to 20 Hz	21°	4,050 lux

Thermal

Maximum External Temperature	Cooling System
104 °F (40 °C)	Fan-assisted convection

DMX

I/O Connector	Channel Range
3-pin XLR	8 or 12

Ordering

Product Name	Item Code	UPC Number
Intimidator Scan 360	07021724	781462220723



Contact Us

General Information	Technical Support
Chauvet World Headquarters	
Address: 3360 Davie Rd. Davie, FL 33314 Voice: (954) 577-4455 Fax: (954) 929-5560 Toll Free: (800) 762-1084	Voice: (844) 393-7575 Fax: (954) 756-8015 Email: chauvetcs@chauvetlighting.com Website: www.chauvetdj.com
Chauvet U.K.	
Address: Pod 1 EVO Park Little Oak Drive, Sherwood Park Nottinghamshire, NG15 0EB UK Voice: +44 (0) 1773 511115 Fax: +44 (0) 1773 511110	Email: UKtech@chauvetlighting.eu Website: www.chauvetdj.eu
Chauvet Benelux	
Address: Stokstraat 18 9770 Kruishoutem Belgium Voice: +32 9 388 93 97	Email: BNLtech@chauvetlighting.eu Website: www.chauvetdj.eu
Chauvet France	
Address: 3, Rue Ampère 91380 Chilly-Mazarin France Voice: +33 1 78 85 33 59	Email: FRtech@chauvetlighting.fr Website: www.chauvetdj.eu
Chauvet Germany	
Address: Bruno-Bürgel-Str. 11 28759 Bremen Germany Voice: +49 421 62 60 20	Email: DEtech@chauvetlighting.de Website: www.chauvetdj.eu
Chauvet Mexico	
Address: Av. de las Partidas 34 - 3B (Entrance by Calle 2) Zona Industrial Lerma Lerma, Edo. de México, CP 52000 Voice: +52 (728) 690-2010	Email: servicio@chauvet.com.mx Website: www.chauvetdj.mx

Warranty & Returns

For warranty terms and conditions and return information, please visit our website.

For customers in the United States and Mexico: www.chauvetlighting.com/warranty-registration.

For customers in the United Kingdom, Republic of Ireland, Belgium, the Netherlands, Luxembourg, France, and Germany: www.chauvetlighting.eu/warranty-registration.