

版本号	修改时间	修改内容
V1.0	2024.04.16	创建文档
V1.1	2024.05.21	修改内容
V1.2	2024.05.21	缩小尺寸 修改内容

POLARMETA

Multi-Function Gesture Trackpad Operating Manual

多功能手势触控板操作说明书

Please read instructions carefully before use
使用前请仔细阅读说明书

欢迎使用多功能手势触控板

多功能手势触控板，本产品配备USB2.4G接收器/Type-c数据线，请使用USB接收器或数据线连接您的电脑。

系统版本要求

若要使用多功能手势触控板及其完整功能，请将Mac更新至最新版本的MacOS（最低要求OSX10.11）。

若要更新至最新版本的MacOS，请选取苹果菜单>App Store来查看是否有更新，按照屏幕指示更新MacOS。

多功能手势触控板与MAC连接方式：

若要使多功能手势触控板与Mac连接，请使用随附的USB接收器插入Mac主机中（开关往最左边拨），或者将Type-c线插入触控板的Type-c端口，同时将另一端插入Mac端口上。然后触控板的绿色指示灯闪烁，触控板将自动与Mac连接。

MAC手势设置步骤：

①打开“系统设置”。

②点击“触控板”。

③点击设置“光标与点按”。

④点击设置“滚动与缩放”。

⑤点击设置“更多手势”。

设置“启用拖移”步骤：

①打开“系统设置”>点击“辅助功能”。

②指针控制>触控板选项>启动使用触控板拖移。

③拖移样式中选择“使用三指拖移”。点击“确认”。

Windows手势设置步骤

Windows系统可以通过USB接收器/数据线任一方式连接。

①USB连接：开关往右边拨动，请将接收器插入电脑中。

②有线连接：请将开关往右拨，插入数据线即可。

待机超过10分钟后，需要按压唤醒使用本产品。

MAC触控板手势说明

单指操作

打开文件

双指操作

翻动页面

切换页面

显示通知中心

放大

缩放

智能缩放

旋转图片

多指操作

选中文本

拖动物页

显示特定窗口

打开调度中心

桌面切换

打开启动台

显示桌面

Windows触控板手势说明

点按

拖动文件

辅助点按（右键点按）

滚动

缩放

三指或四指手势可在系统重新设置，路径如下：设置>蓝牙和其他设备>触控板

选中文本

显示桌面

切换应用

切换应用

清洁多功能手势触控板

请使用不起绒的布清洁触控板表面，请勿使用化学物品擦拭产品。

人体工程学

使用多功能手势触控板时，注意找到舒适的坐姿，不时变换身体姿势，时常休息一下，这样能减轻疲劳。

更多信息

有关使用触控板的更多信息，请打开“Mac帮助”并搜索“触控板”。

产品保修卡

感谢您购买使用本产品，为了您能享受更好的服务，请您仔细阅读以下内容并妥善保管此保修卡。本公司出品的产品在正常使用情况下如发生非人为故障，客户可凭此保修卡及有效购买凭证向原经销商申请维修服务，但不包含以下情况：

1. 人为因素造成的损坏，包括不按说明书操作引起的故障，或因保管不善造成产品撞击、跌落、受潮等引起的损坏（产品表面有明显磨损痕迹等）。

2. 私自拆卸自行维修和改装或由非特约维修站点维修所引起的故障。

3. 用于非指定用途的产品使用及有效购买凭证。

4. 对购买记录或产品信息等人为涂改的。

5. 超出产品保修期限。

产品型号	用户姓名	联系电话	购买时间	商家盖章

用户地址

(注：用户未能提供购买日期凭证者以产品出厂日期为准)

产品清单

多功能手势触控板

USB接收器

转接头 (Type-C转USB)

说明书

产品合格证

本产品经质量检验合格

产品合格证

质检员：01

Made in China

POLARMETA

Multi-Function Gesture Trackpad Operating Manual

多功能手势触控板操作说明书

Please read instructions carefully before use
使用前请仔细阅读说明书

Welcome to Multi-function Gesture Trackpad

Multi-function gesture trackpad is equipped with USB2.4G receiver / type-c data cable. Please use USB receiver or data cable to connect your Computer.

System Version Requirement

To use trackpad and its full functionality, please update your Mac to the latest version of mac OS (minimum OSX 10.11 required).

To update to the latest version of mac OS, select Apple menu > 'App Store' to check for updates - follow the instructions to update mac OS.

How to connect the trackpad to MAC.

To connect the trackpad to a Mac, use the included USB receiver to plug into the Mac (flip the switch to the left) or plug the type-c cable into the trackpad's type-c port, and plug the other end into the Mac port. The green light flashes, indicating the trackpad is connecting to the Mac automatically .

Using Multi-Function Gesture Touchpad

Multi-Gesture trackpad has a Force Touch surface for moving mouse pointer and performing gestures. To set up gestures and set other options, select Apple Menu > System Settings, then click "trackpad". Place the Multi-Function Gesture Trackpad on a smooth, horizontal surface. When moving mouse pointer or performing a gesture, you can rest your hand comfortably on the trackpad and gently slide your finger across its surface.

MAC gesture setting steps:

①Open "System Settings"

②Click "Trackpad"

③Click to set "Point & Click"

④Click to set "Scroll & Zoom"

⑤Click to set "More Gesture"

Steps to set "Drag & Drop":

①Open > "System Setting" > click "Accessibility".

②Click > "Pointer Control" > click "Trackpad Options" > turn on "Use trackpad for dragging"

③Choose "Three Finger Drag" > Click "OK".

Windows gesture setup steps

Windows system can be connected by USB receiver and data cable.

①USB receiver connection: Please flip the switch to the right and plug the receiver into the computer.

②USB cable connection: please flip the switch to the right and insert the usb cable to both side.

After more than 10 minutes of standby, you need to press to wake up the trackpad.

MAC Trackpad Gesture Description

One Finger Operation

Open file

Two Finger Operation

Flip the page

Switch page

Display notification center

Zoom in

Zoom out

Smart Zoom

Rotating pictures

Multi-Finger Operation

Select text

Drag the page

Show specific windows

Open Dispatch Center

Desktop switching

Open the launchpad

Show desktop

Windows trackpad gestures explained

Tap

Drag and drop files

Auxiliary tap (right-click)

Scrolling

Zoom

Three- or four-finger gestures can be reset in the system by going to System Settings > Devices > Trackpad

Selected text

Show Desktop

Switching Applications

Switching Applications

Clean Multi-Function Gesture trackpad

When using trackpad, find a comfortable sitting position, change your body posture from time to time, and take a break. It is very important.

ergonomics

More information

For more information, open "Mac Help" and search "Trackpad".

Product Warranty Card

Thank you for purchasing this product, in order to provide you with better service, please read the following content and keep this warranty card. If a non-human fault occurs during the daily use of the product, you can show this warranty card and a valid proof of purchase to the original dealer to apply for warranty service. However, the following are not included.

1. Damage caused by human factors, including failure caused by not operating in accordance with the manual, or due to poor storage of the product caused by impact, falling, bending and other damage (product surface has obvious wear marks, etc.).

2. Failure caused by private disassembly, repair and modification, or maintenance by non-special maintenance sites.

3. The user is unable to provide product warranty card and valid proof of purchase

4. Artificially altered purchase records or product information.

5. Beyond the product warranty period.

Product Model	User Name	Contact Number	Time of Purchase	Merchant Stamp

User Address

ALL Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can use radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirements. The device can be used to portable exposure conditions without restriction.

Product List

Multi-Function Gesture Trackpad

Type-C Data Cable

USB Receiver

Adaptor (Type-C to USB)

User Manual

Certificate of Conformity

This product has passed the quality inspection

Certificate of Conformity

Quality Inspector: 01

Made in China