

CHEROKEE USER GUIDE



This Owner Handbook is intended to show the vehicle's operating conditions.

For the enthusiast user who wants to have insights, curiosities and detailed information about the characteristics and functions of the vehicle, Jeep gives the opportunity to consult a dedicated section which is available in electronic format.



The following symbol eLUM is reported within the text of the Owner Landback the Owner Handbook, next to the subjects for which details are provided. Go to the www.mopar.eu/owner website and access your personal area.

> The "Maintenance and Care" page includes all the information about your vehicle and the link to access eLUM, where you will find all the details of the Owner Handbook. Alternatively, to access this information, go to the Internet website at http://aftersales.fiat.com/elum/.

The eLUM website is free and will allow you, among many other things, to easily consult the on-board documents of all the other vehicles of the Group.

HAVE A NICE READING AND HAPPY MOTORING!

Congratulations on selecting your new FCA US LLC vehicle. Be assured that it represents precision workmanship, distinctive styling, and high quality.

ALWAYS drive safely and pay attention to the road. ALWAYS drive safely with your hands on the steering wheel. You have full responsibility and assume all risks related to the use of the features and applications in this vehicle. Only use the features and applications when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.

This guide illustrates and describes the operation of features and equipment that are either standard or optional on this vehicle. This guide may also include a description of features and equipment that are no longer available or were not ordered on this vehicle. Please disregard any features and equipment described in this guide that are not available on this vehicle. FCA US LLC reserves the right to make changes in design and specifications and/or make additions to or improve-

ments to its products without imposing any obligation upon itself to install them on products previously manufactured.

This User Guide has been prepared to help you quickly become acquainted with the important features of your vehicle. It contains most things you will need to operate and maintain the vehicle, including emergency information.

When it comes to service, remember that your authorized dealer knows your Jeep® vehicle best, has factory-trained technicians and genuine MOPAR® parts, and cares about your satisfaction.

HOW TO FIND YOUR OWNER'S MANUAL ONLINE

This publication has been prepared as a reference item to help you quickly become acquainted with the most important features and processes of your vehicle. It contains most things you will need to operate and maintain the vehicle, including emergency information and procedures.

This User Guide is not a replacement for the full Owner's Manual, and does not fully cover every operation and procedure possible with your vehicle.

For more detailed descriptions of the topics discussed in this User Guide, as well as information covering features and processes not covered in this User Guide, the full vehicle Owner's Manual can be accessed for free online in a printer-friendly PDF format.

To get the full Owner's Manual or applicable supplement for your vehicle, follow the appropriate web address below:

www.mopar.eu/owner or alternatively, to access this information, go to the Internet website at http://aftersales.fiat.com/elum/.

FCA US LLC is committed to protecting our environment and natural resources. By converting from paper to electronic delivery for the majority of the user information for your vehicle, together we greatly reduce the demand for tree-based products and lessen the stress on our environment.

HOW TO USE THIS MANUAL

Essential Information

Consult the Table of Contents to determine which section contains the information you desire.

Since the specification of your vehicle depends on the items of equipment ordered, certain descriptions and illustrations may differ from your vehicle's equipment.

The detailed index at the back of this Owner's Manual contains a complete listing of all subjects.

Symbols

Some vehicle components have colored labels whose symbols indicate precautions to be observed when using this component.

ROLLOVER WARNING

Utility vehicles have a significantly higher rollover rate than other types of vehicles. This vehicle has a higher ground clearance and a higher center of gravity than many passenger vehicles. It is capable of performing better in

a wide variety of off-road applications. Driven in an unsafe manner, all vehicles can go out of control. Because of the higher center of gravity, if this vehicle is out of control it may roll over when some other vehicles may not.

Do not attempt sharp turns, abrupt maneuvers, or other unsafe driving actions that can cause loss of vehicle control. Failure to operate this vehicle safely may result in a collision, rollover of the vehicle, and severe or fatal injury. Drive carefully.



80bfe0t

Rollover Warning Label

Failure to use the driver and passenger seat belts provided is a major cause of severe or fatal injury. In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. Always buckle up.

IMPORTANT NOTICE

ALL MATERIAL CONTAINED IN THIS PUBLICATION IS BASED ON THE LATEST INFORMATION AVAILABLE AT TIME OF PUBLICATION APPROVAL. THE RIGHT IS RESERVED TO PUBLISH REVISIONS AT ANY TIME.

This User Guide has been prepared with the assistance of service and engineering specialists to acquaint you with the operation and maintenance of your new vehicle. It is supplemented by a Warranty Information Booklet and various customer-oriented documents. You are urged to read these publications carefully. Following the instructions and recommendations in this User Guide will help assure safe and enjoyable operation of your vehicle.

After you have read the User Guide, it should be stored in the vehicle for convenient reference and remain with the vehicle when sold.

The manufacturer reserves the right to make changes in design and specifications, and/or to make additions to or improvements in its products without imposing any obligations upon itself to install them on products previously manufactured.

The User Guide illustrates and describes the features that are standard or available as extra cost options. Therefore, some of the equipment and accessories in this publication may not appear on your vehicle.

NOTE:

Be sure to read the User guide first before driving your vehicle and before attaching or installing parts/accessories or making other modifications to the vehicle.

In view of the many replacement parts and accessories from various manufacturers available on the market, the manufacturer cannot be certain that the driving safety of your vehicle will not be impaired by the attachment or installation of such parts. Even if such parts are officially-approved (for example, by a general operating permit for the part or by constructing the part in an officially

approved design), or if an individual operating permit was issued for the vehicle after the attachment or installation of such parts, it cannot be implicitly assumed that the driving safety of your vehicle is unimpaired. Therefore, neither experts nor official agencies are liable. The manufacturer only assumes responsibility when parts, which are expressly authorized or recommended by the manufacturer, are attached or installed at an authorized dealer. The same applies when modifications to the original condition are subsequently made on the manufacturer's vehicles.

Your warranties do not cover any part that the manufacturer did not supply. Nor do they cover the cost of any repairs or adjustments that might be caused or needed because of the installation or use of non-manufacturer parts, components, equipment, materials, or additives. Nor do your warranties cover the costs of repairing damage or conditions caused by any changes to your vehicle that do not comply with the manufacturers specifications.

WARNINGS AND CAUTIONS

This User Guide contains **WARNINGS** against operating procedures that could result in a collision, bodily injury and/or death. It also contains **CAUTIONS** against procedures that could result in damage to your vehicle. If you do not read this entire guide, you may miss important information. Observe all Warnings and Cautions.

VEHICLE MODIFICATIONS/ ALTERATIONS

WARNING!

Any modifications or alterations to this vehicle could seriously affect its roadworthiness and safety and may lead to a collision resulting in serious injury or death.

GRAPHICAL TABLE OF CONTENTS

GETTING TO KNOW YOUR VEHICLE



GETTING TO KNOW YOUR INSTRUMENT PANEL



SAFETY



STARTING AND OPERATING



IN CASE OF EMERGENCY



SERVICING AND MAINTENANCE



TECHNICAL SPECIFICATIONS



MULTIMEDIA



CUSTOMER ASSISTANCE



INDEX



GRAPHICAL TABLE OF CONTENTS

INSTRUMENT	P	A	Ν	Ε	L											
INTERIOR	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_(























INSTRUMENT PANEL



Instrument Panel

- 1 Air Vents
- 2 Glove Compartment
- 3 Multifunction Lever

- 4 Instrument Cluster
- 5 Steering Wheel
- 6 Windshield Wiper Lever

INTERIOR



Interior Features

5 — Climate Controls

7 — Ignition Start/Stop Button

6 — Gear Selector

- 1 Power Window Switches
- 2 Seat
- 3 Uconnect Radio
- 4 Switch Panel























GETTING TO KNOW YOUR VEHICLE

1.		-)
-17		
ш		
-U		-

KEYS13	Child-Protection Door Lock System —
Key Fob	Rear Doors
IGNITION SWITCH	SEATS23
Ignition Node Module (IGNM) — If Equipped	Memory Seat
Keyless Enter-N-Go — Ignition	HEAD RESTRAINTS25
Electronic Steering Wheel Lock — If Equipped	Front Adjustment
REMOTE STARTING SYSTEM —	Rear Adjustment
IF EQUIPPED	Rear Removal
SENTRY KEY	STEERING WHEEL28
Irregular Operation	Adjustment
VEHICLE SECURITY ALARM —	Heated Steering Wheel
IF EQUIPPED	MIRRORS29
To Arm The System	Power Folding Mirrors — If Equipped29 Heated Mirrors — If Equipped29
DOORS	EXTERIOR LIGHTS30
Keyless Enter-N-Go — Passive Entry19 Locking The Doors With One Or More Doors Open	Headlight Switch























Automatic Temperature Control (ATC) — If Equipped	POWER SUNROOF .45 Opening .46 Closing .46 Wind Buffeting .46	LIFTGATE
WINDOWS	Power Sun Shade	Closing
Reset Auto-Up		Power Inverter

KEYS

Key Fob

The key fob operates the ignition switch. Insert the square end of the key fob into the ignition switch located on the instrument panel and rotate to the desired position. The key fob also contains an emergency key, which is stored in the rear of the key fob.



Key Fob

- 1 Liftgate
- 2 Lock
- 3 Unlock
- 4 Remote Start
- 5 Emergency Key Release
- 6 Emergency Key

Your vehicle may be equipped with a keyless ignition system. The ignition system consists of a key fob with Remote Keyless Entry (RKE) and a START/STOP push button ignition system. The Remote Keyless Entry system consists of a key fob and Keyless Enter-N-Go feature if equipped.







NOTE:

The key fob may not be found if it is located next to a mobile phone, laptop or other electronic device; these devices may block the key fob's wireless signal.





The key fob allows you to lock or unlock the doors and liftgate from distances up to approximately 66 ft (20 m) using a handheld key fob. The key fob does not need to be pointed at the vehicle to activate the system.







 This feature allows the driver to operate the ignition switch with the push of a button as long as the key fob is in the passenger compartment.







In case the ignition switch does not change with the push of a button, the key fob may have a low or dead battery. In this situation, a back up method can be used to operate the ignition switch. Put the nose side (side opposite of the emergency key) of the key fob against the ENGINE START/STOP button and push to operate the ignition switch.



Key Fob

- 1 Liftgate
- 2 Unlock
- 3 Lock
- 4 Remote Start

NOTE:

In case the ignition switch does not change with the push of a button, the key fob may have a low or dead battery. In this situation, a backup method can be used to operate the ignition switch. Put the nose side of the key fob (side opposite of the Emergency Key) against the ENGINE START/STOP button and push to operate the ignition switch.

To Unlock The Doors And Liftgate

Push and release the unlock button on the key fob once to unlock the driver's door or twice within five seconds to unlock all doors and the liftgate.

All doors can be programmed to unlock on the first push of the unlock button. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

If the vehicle is unlocked by key fob, and no door is opened within 60 seconds, the vehicle will re-lock and if equipped, the security alarm will arm. To change the current setting, refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

To Lock The Doors And Liftgate

Push and release the lock button on the key fob to lock all doors and liftgate.

Vehicles Equipped With Keyless Enter-N-Go — **Passive Entry**

If one or more doors are open, or the liftgate is open, the doors will lock. The doors will unlock again automatically if the key is left inside the passenger compartment, otherwise the doors will stay locked.

Request For Additional Key Fobs

NOTE:

Only key fobs that are programmed to the vehicle electronics can be used to start and operate the vehicle. Once a key fob is programmed to a vehicle, it cannot be programmed to any other vehicle.

WARNING!

- Always remove the key fobs from the vehicle and lock all doors when leaving the vehicle unattended.
- For vehicles equipped with Keyless Enter-N-Go — Ignition, always remember to place the ignition in the OFF mode.

Duplication of key fobs may be performed at an authorized dealer. This procedure consists of programming a blank key fob to the vehicle electronics. A blank key fob is one that has never been programmed.

NOTE:

When having the Sentry Key Immobilizer System serviced, bring all vehicle keys with you to an authorized dealer.

IGNITION SWITCH

Ignition Node Module (IGNM) — If Equipped



The Ignition Node Module (IGNM) operates similar to an ignition switch. It has four operating positions, three with detents and one that is spring-loaded. The detent positions are OFF, ACC, and ON/RUN. The START position is a spring-loaded momentary contact position. When released from the START



position, the switch automatically returns to the ON/RUN position.



Keyless Enter-N-Go — Ignition

This feature allows the driver to operate the ignition switch with the push of a button as long as the key fob is in the passenger compartment.



The push button ignition operating modes are OFF, ACC, RUN, and START.







If the ignition switch does not change with the push of a button, the key fob may have a low or dead battery. In this situation, a back up method can be used to operate the ignition switch. Put the nose side (side opposite of the emergency key) of the key fob against the ENGINE START/STOP button and push to operate the ignition switch.



START/STOP Ignition Button

The push button ignition can be placed in the following modes:

OFF

- The engine is stopped.
- Some electrical devices (e.g. Central locking, alarm, etc.) are still available.

ACC

- Engine is not started.
- Some electrical devices are available.

RUN

- Driving position.
- All the electrical devices are available.

START

• Start the engine.

NOTE:

The vehicle will not start if the key fob is located inside the cargo area and the liftgate is opened.

WARNING!

- When exiting the vehicle, always remove the key fob from the vehicle and lock your vehicle.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle.
- Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the gear selector.
- Do not leave the key fob in or near the vehicle, or in a location accessible to children, and do not leave the ignition of a vehicle equipped with Keyless Enter-N-Go in the ON/RUN mode. A child could operate power windows, other controls, or move the vehicle.
- Do not leave children or animals inside parked vehicles in hot weather. Interior heat build-up may cause serious injury or death.

CAUTION!

An unlocked vehicle is an invitation for thieves. Always remove key fob from the vehicle and lock all doors when leaving the vehicle unattended.

NOTE:

For further information, refer to "Starting The Engine" in "Starting And Operating."

Electronic Steering Wheel Lock — If Equipped

Your vehicle may be equipped with a passive electronic steering wheel lock. This lock prevents steering the vehicle with the ignition OFF. The steering wheel lock releases with the ignition ON. If the lock does not disengage and the vehicle does not start, turn the wheel to the left and right to disengage the lock.

REMOTE STARTING SYSTEM — IF EQUIPPED



Push the remote start button on the key fob twice within five seconds. Pushing the remote start button a third time shuts the engine off.

To drive the vehicle, push the START/STOP button to turn the ignition to the ON/RUN mode.

NOTE:

- With remote start, the engine will only run for 15 minutes (timeout) unless the ignition is placed in the ON/RUN mode.
- The vehicle must be started with the key after two consecutive timeouts.

SENTRY KEY

The Sentry Key Immobilizer system prevents unauthorized vehicle operation by disabling the engine. The system does not need to be armed or activated. Operation is automatic. regardless of whether the vehicle is locked or unlocked.

CAUTION!



The Sentry Key Immobilizer system is not compatible with some aftermarket remote starting systems. Use of these systems may result in vehicle starting problems and loss of security protection.





All of the key fobs provided with your new vehicle have been programmed to the vehicle electronics.



Irregular Operation



The system uses a key fob, an Ignition Node Module, Keyless Push Button Ignition and a RF receiver to prevent unauthorized vehicle operation. Therefore, only key fobs that are programmed to the vehicle can be used to start and operate the vehicle. The system will not allow the engine to crank if an invalid key fob is used to start and operate the vehicle. The system will shut the engine off in two seconds if an invalid key fob is used to start the engine.











NOTE:

A key fob that has not been programmed is also considered an invalid kev.

During normal operation, after placing the keyless ignition in the ON/RUN mode, the Vehicle Security Light will turn on for three seconds for a bulb check. If the light remains on after the bulb check, it indicates that there is a problem with the electronics. In addition, if the light begins to flash after the bulb check, it indicates that someone used an invalid key fob to try to start the engine. Either of these conditions will result in the engine being shut off after two seconds.

If the Vehicle Security Light turns on during normal vehicle operation (vehicle running for longer than 10 seconds), it indicates that there is a fault in the electronics. Should this occur, have the vehicle serviced as soon as possible by an authorized dealer.

VEHICLE SECURITY ALARM — IF EQUIPPED

This vehicle security alarm monitors the vehicle doors, hood, liftgate, and ignition for unauthorized operation. While the vehicle security alarm is armed, interior switches for door locks and liftgate release are disabled. If something triggers the vehicle security

alarm, the horn will sound for 29 seconds and turn off all of the visual signals after an additional 31 seconds. If the triggering device is not deactivated, the horn will sound again after a five second delay for another 29 seconds. If the trigger remains present, this cycle will repeat for up to five minutes.

To Arm The System

Follow these steps to arm the vehicle security alarm:

- 1. Make sure the vehicle's ignition is placed in the "OFF" mode.
 - For vehicles equipped with Keyless Entry, make sure the vehicle's keyless ignition system is OFF.
- 2. Perform one of the following methods to lock the vehicle:
 - Push the lock button on the interior power door lock switch with the driver and/or passenger door open.
 - Push the lock button on the exterior Passive Entry Door Handle with a valid key fob available in the same exterior

zone. Refer to "Doors" in "Getting To Know Your Vehicle" in your Owner's Manual for further information.

- Push the lock button on the key fob.
- 3. If any doors are open, close them.

To Disarm The System

The vehicle security alarm can be disarmed using any of the following methods:

- Push the unlock button on the key fob.
- Grasp the passive entry door handle to unlock the door, refer to "Doors" in "Getting To Know Your Vehicle" in your Owner's Manual for further information.
- Cycle the ignition out of the off mode to disarm the system.

NOTE:

 The driver's door key cylinder and the liftgate button on the key fob cannot arm or disarm the vehicle security alarm.

- The vehicle security alarm remains armed during power liftgate entry. Pushing the liftgate button will not disarm the vehicle security alarm. If someone enters the vehicle through the liftgate and opens any door, the alarm will sound.
- When the vehicle security alarm is armed, the interior power door lock switches will not unlock the doors.

The vehicle security alarm is designed to protect your vehicle. However, you can create conditions where the system will give you a false alarm. If one of the previously described arming sequences has occurred, the vehicle security alarm will arm, regardless of whether you are in the vehicle or not. If you remain in the vehicle and open a door, the alarm will sound. If this occurs, disarm the vehicle security alarm.

If the vehicle security alarm is armed and the battery becomes disconnected, the vehicle security alarm will remain armed when the battery is reconnected: the exterior lights will flash, and the horn will sound. If this occurs, disarm the vehicle security alarm.

DOORS

Keyless Enter-N-Go — Passive Entry

The Passive Entry system is an enhancement to the vehicle's Remote Keyless Entry system and a feature of Keyless Enter-N-Go — Passive Entry. This feature allows you to lock and unlock the vehicle's door(s) and fuel door without having to push the key fob lock or unlock buttons.

NOTE:

- Passive Entry may be programmed ON/OFF: refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.
- If wearing gloves on your hands, or if it has been raining/snowing on the Passive Entry door handle, the unlock sensitivity can be affected, resulting in a slower response time.
- If the vehicle is unlocked by Passive Entry and no door is opened within 60 seconds, the vehicle will re-lock and if equipped will arm the security alarm.

- The key fob may not be able to be detected by the vehicle passive entry system if it is located next to a mobile phone, laptop or other electronic device; these devices may block the key fob's wireless signal and prevent the passive entry handle from locking/ unlocking the vehicle.
- · Passive Entry activates illuminated approach for the time set by the customer (0, 30, 60, or 90 seconds), and flashes the turn signal lights. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information

To Unlock From The Driver's Side

With a valid Passive Entry key fob within 5ft (1.5m) of the driver's door handle, grab the front driver door handle to unlock the driver's door automatically.

























Grab The Door Handle To Unlock

If "Unlock All Doors 1st Press" is programmed, all doors will unlock when you grab hold of the front driver's door handle. To select between "Unlock Driver Door 1st Push" and "Unlock All Doors 1st Press," refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

To Unlock From The Passenger Side

With a valid Passive Entry key fob within 5ft (1.5m) of the passenger door handle, grab the front passenger door handle to unlock all four doors and the liftgate automatically.

NOTE:

All doors will unlock when the front passenger door handle is grabbed regardless of the driver's door unlock preference setting ("1st Press of Key Fob Unlocks" or "Unlock All Doors 1st Press").

Preventing Inadvertent Locking Of Passive Entry Key Fob In Vehicle (FOBIK-Safe)

To minimize the possibility of unintentionally locking a Passive Entry key fob inside your vehicle, the Passive Entry system is equipped with an automatic door unlock feature which will function if the ignition is OFF.

FOBIK-Safe only executes in vehicles with passive entry. There are three situations that trigger a FOBIK-Safe search in any passive entry vehicle:

• A lock request is made by a valid Passive Entry key fob while a door is open.

- A lock request is made by the Passive Entry door handle while a door is open.
- A lock request is made by the door panel switch while the door is open.

When any of these situations occur, after all open doors are shut, the FOBIK-Safe search will be executed. If it finds a Passive Entry key fob inside the car, the car will unlock and alert the customer.

NOTE:

The vehicle will only unlock the doors when a valid Passive Entry key fob is detected inside the vehicle. The vehicle will not unlock the doors when any of the following conditions are true:

- The doors are manually locked using the door lock knobs.
- Three attempts are made to lock the doors using the door panel switch and then close the doors.
- If the liftgate is opened and then all 4 doors are locked, the key fob will become locked in the vehicle if the liftgate is closed and will not alert the customer.

To Unlock/Enter The Liftgate

The liftgate passive entry unlock feature is built into liftgate handle release. With a valid Passive Entry key fob within 5ft (1.5m) of the liftgate, push the electronic liftgate release to open with one fluid motion.

To Lock The Liftgate

With a valid Passive Entry key fob within 5ft (1.5m) of the liftgate, push the passive entry lock button located to the right of liftgate handle release.


NOTE:

The liftgate passive entry lock button will lock all doors and the liftgate. The liftgate unlock feature is built into the electronic liftgate release.



Electronic Liftgate Release/Liftgate Passive Entry Location

To Lock The Vehicle's Doors And Liftgate



























fob within 5ft (1.5m) of the driver or passenger front door handles, push the Passive Entry lock button located on the outside door handle.

Push The Door Handle Button To Lock

DO NOT grab the door handle, when pushing the door handle lock button. This could unlock the door(s).



DO NOT Grab The Door Handle When Locking

NOTE:

- After pushing the door handle button, you
 must wait two seconds before you can lock
 or unlock the doors, using either Passive
 Entry door handle. This is done to allow you
 to check if the vehicle is locked by pulling
 the door handle without the vehicle reacting and unlocking.
- If Passive Entry is disabled using the Uconnect System, the key protection described in "Preventing Inadvertent Locking of Passive Entry key fob in Vehicle" remains active/functional.
- The Passive Entry system will not operate if the key fob battery is dead.

The vehicle doors can also be locked by using the lock button located on the vehicle's interior door panel.

Locking The Doors With One Or More Doors Open

If the door lock switch is pushed while the ignition is in ACC or ON/RUN and the driver's door is open, the doors will not lock.

Auto Relocking

The auto door lock feature default condition is enabled. When enabled, the door locks will lock automatically when the vehicle's speed exceeds 15 mph (24 km/h). The auto door lock feature can be enabled or disabled by your authorized dealer. The auto door lock feature is enabled/disabled in the Uconnect Settings.

Child-Protection Door Lock System — Rear Doors

To provide a safer environment for small children riding in the rear seats, the rear doors are equipped with a Child-Protection Door Lock system.

To use the system, open each rear door, use a flat blade screwdriver (or emergency key) and rotate the dial to the lock or unlock position. When the system on a door is engaged, that door can only be opened by using the outside door handle even if the inside door lock is in the unlocked position.



Child-Protection Door Lock Function

SEATS


Memory Seat

The memory seat feature allows you to save two different driver seating positions, driver's outside mirror, and radio station preset settings. The memory seat buttons are located on the driver's door panel.




Memory Seat Buttons


To set a memory position:











NOTE:

Before programming your key fob you must select the "Linking And Unlinking The Remote Keyless Entry Key Fob To Memory" feature through the Uconnect system. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further details.

To program a key fob to the memory position:

- 1. Cycle the vehicle's ignition to the OFF position.
- 2. Select the desired memory profile 1 or 2.
- 3. Push and release the S (set) button on the memory switch, then within five seconds push and release memory button (1) or (2) accordingly.



























4. Push and release the lock button on the key fob within 10 seconds.

To recall the saved positions, push memory button (1) or (2), or push unlock on the programmed key fob.

Easy Entry/Exit Feature

The memory seat has an Easy Entry/Exit feature. This feature provides automatic driver seat positioning to enhance driver mobility when entering and exiting the vehicle.

NOTE:

The Easy Entry/Exit feature is not enabled when the vehicle is delivered from the factory. To enable (or later disable) this feature you must select "Easy Exit Seats" in "Engine Off Options" through the programmable features in the Uconnect system.

For further details refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further details.

Heated/Ventilated Seats

Front Heated Seats

If your vehicle is equipped with front heated seats, the control buttons are located within the Uconnect system. You can gain access to the control buttons through the climate screen or the controls screen.

- Press the heated seat button would once to turn the HI setting ON.
- Press the heated seat button a second time to turn the LO setting ON.
- Press the heated seat button # a third time to turn the heating elements OFF.

If the HI-level setting is selected, the system will automatically switch to LO-level after approximately 60 minutes of continuous operation. At that time, the display will change from HI to LO, indicating the change. The LO-level setting will turn OFF automatically after approximately 45 minutes.

NOTE:

The engine must be running for the heated seats to operate.

Vehicles Equipped With Remote Start

On models that are equipped with remote start, the heated seats can be programmed to come on during a remote start.

This feature can be programmed through the Uconnect system. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further details.

WARNING!

- Persons who are unable to feel pain to the skin because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion or other physical condition must exercise care when using the seat heater. It may cause burns even at low temperatures, especially if used for long periods of time.
- Do not place anything on the seat or seatback that insulates against heat, such as a blanket or cushion. This may cause the seat heater to overheat. Sitting in a seat that has been overheated

WARNING!

could cause serious burns due to the increased surface temperature of the seat.

Front Ventilated Seats

If your vehicle is equipped with ventilated seats, the seat cushion and seat back will have fans that draw the air from the passenger compartment and move air through fine perforations in the seat cover to help keep the driver and front passenger cooler in higher ambient temperatures. The fans operate at two speeds, HI and LO.

The front ventilated seats control buttons are located within the Uconnect system. You can gain access to the control buttons through the climate screen or the controls screen.

- Press the ventilated seat button 💆 once to choose HI.
- Press the ventilated seat button ***** a second time to choose LO.
- Press the ventilated seat button **2** a third time to turn the ventilated seat OFF.

NOTE:

The engine must be running for the ventilated seats to operate.

Vehicles Equipped With Remote Start

On models that are equipped with remote start, the ventilated seats can be programmed to come on during a remote start.

This feature can be programmed through the Uconnect system. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further details.

HEAD RESTRAINTS

Head restraints are designed to reduce the risk of injury by restricting head movement in the event of a rear impact. Head restraints should be adjusted so that the top of the head restraint is located above the top of your ear.

WARNING!

 All occupants, including the driver, should not operate a vehicle or sit in a vehicle's seat until the head restraints are placed in their proper positions in

WARNING!



order to minimize the risk of neck injury in the event of a crash.


Head restraints should never be adjusted while the vehicle is in motion.
 Driving a vehicle with the head restraints improperly adjusted or removed could cause serious injury or death in the event of a collision.







NOTE:





Front Adjustment

back of your head.

The front driver and passenger seats are equipped with Reactive Head Restraints (RHR). In the event of a rear impact, the RHRs will automatically extend forward minimizing the gap between the back of the occupant's head and the RHR.









The RHRs will automatically return to their normal position following a rear impact. If the RHRs do not return to their normal position, see your authorized dealer immediately.

To raise the head restraint, pull upward on the head restraint. To lower the head restraint, push the adjustment button, located at the base of the head restraint, and push downward on the head restraint.



Front Head Restraint

- 1 Adjustment Button
- 2 Release Button

WARNING!

- A loose head restraint thrown forward in a collision or hard stop could cause serious injury or death to occupants of the vehicle. Always securely stow removed head restraints in a location outside the occupant compartment.
- ALL the head restraints MUST be reinstalled in the vehicle to properly protect
 the occupants. Follow the re-installation
 instructions above prior to operating the
 vehicle or occupying a seat.
- Do not place items over the top of the Reactive Head Restraint, such as coats, seat covers or portable DVD players. These items may interfere with the operation of the Reactive Head Restraint in the event of a collision and could result in serious injury or death.

Front Removal

To remove the head restraint, raise it as far as it can go. Then, push the release button and the adjustment button at the base of each post while pulling the head restraint up. Seatback angle may need to be adjusted to fully remove the head restraint. To reinstall the head restraint, put the head restraint posts into the holes and push downward. Then, adjust the head restraint to the appropriate height.

WARNING!

- All occupants, including the driver, should not operate a vehicle or sit in a vehicle's seat until the head restraints are placed in their proper positions in order to minimize the risk of neck injury in the event of a collision.
- Do not place items over the top of the Active Head Restraint, such as coats, seat covers or portable DVD players. These items may interfere with the operation of the Active Head Restraint in

WARNING!

the event of a collision and could result in serious injury or death.

• Active Head Restraints may be deployed if they are struck by an object such as a hand, foot or loose cargo. To avoid accidental deployment of the Active Head Restraint ensure that all cargo is secured, as loose cargo could contact the Active Head Restraint during sudden stops. Failure to follow this warning could cause personal injury if the Active Head Restraint is deployed.

Rear Adjustment

The rear outboard head restraints have three positions up, mid and down. The center head restraint has only two positions, up and down. When the center seat is being occupied, the head restraint should be in the raised position. When there is no occupant in the center seat, the head restraint can be lowered for maximum visibility for the driver.

To raise the head restraint, pull upward on the head restraint. To lower the head restraint. push the adjustment button, located at the base of the head restraint, and push downward on the head restraint.



Outboard Head Restraint

- 1 Release Button
- 2 Adjustment Button





- 1— Adjustment Button
- 2— Release Button





WARNING!

Sitting in a seat with the head restraint in its lowered position could result in serious injury or death in a collision. Always make









WARNING!

sure the outboard head restraints are in their upright positions when the seat is to be occupied.

NOTE:

For proper routing of a Child Seat Tether, refer to "Occupant Restraint Systems" in "Safety" for further information.

Rear Removal

To remove the head restraint, raise it as far as it can go. Then, push the release button and the adjustment button at the base of each post while pulling the head restraint up. To reinstall the head restraint, put the head restraint posts into the holes and push downward. Then, adjust the head restraint to the appropriate height.

WARNING!

ALL the head restraints MUST be reinstalled in the vehicle to properly protect the occupants. Follow the re-installation instructions above prior to operating the vehicle or occupying a seat.

STEERING WHEEL

Adjustment

This feature allows you to tilt the steering column upward or downward. It also allows you to lengthen or shorten the steering column. The tilt/telescoping lever is located below the steering wheel at the end of the steering column.



Tilt/Telescoping Lever

To unlock the steering column, push the control handle downward (toward the floor). To tilt the steering column, move the steering wheel upward or downward as desired. To lengthen or shorten the steering column, pull the steering wheel outward or push it inward as desired. To lock the steering column in position, push the control handle upward until fully engaged.

WARNING!

Do not adjust the steering column while driving. Adjusting the steering column while driving or driving with the steering column unlocked, could cause the driver to lose control of the vehicle. Failure to follow this warning may result in serious injury or death.

Heated Steering Wheel

If your vehicle is equipped with a heated steering wheel, it contains a heating element that will keep your hands warm in cold weather. The heated steering wheel has only one temperature setting. Once the heated steering wheel has been turned on, it can

operate for an average of 80 minutes or more before automatically shutting off. This time may vary depending on environmental temperatures. The heated steering wheel can shut off early or may not turn on when the steering wheel is already warm.

The heated steering wheel control button is located within the Uconnect system. You can gain access to the control button through the climate screen or the controls screen.

- Press the heated steering wheel button \oplus once to turn the heating element on.
- Press the heated steering wheel button \oplus a second time to turn the heating element off.

NOTE:

The engine must be running for the heated steering wheel to operate.

Vehicles With Remote Start — If Equipped

On models that are equipped with remote start, the heated steering wheel can be programmed to come on during a remote start through the Uconnect system. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

WARNING!


- Persons who are unable to feel pain to the skin because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion, or other physical conditions must exercise care when using the steering wheel heater. It may cause burns even at low temperatures, especially if used for long periods.
- Do not place anything on the steering wheel that insulates against heat, such as a blanket or steering wheel covers of any type and material. This may cause the steering wheel heater to overheat.

MIRRORS


Power Folding Mirrors — If Equipped

If equipped, the switch for the power folding mirrors is located between the power mirror switches L (left) and R (right). Push the switch once and the mirrors will fold in. Pushing the switch a second time will return the mirrors to the normal driving position.

NOTE:









If the mirrors are in the folded position, and the vehicle speed is equal or greater than 10 mph (16 km/h), they will automatically unfold.



Resetting The Power Folding Outside Mirrors

To reset the power folding mirrors: Fold and unfold them by pushing the button (this may require multiple button pushes). This resets them to their normal position.



Heated Mirrors — If Equipped





tivated whenever you turn on the rear window defroster. Refer to "Climate Controls" in this chapter for further information.









EXTERIOR LIGHTS

Headlight Switch



Headlight Switch

- 1 Instrument Panel Dimmer
- 2 Rotate Headlight
- 3 Push Rear Fog Light
- 4 Push Front Fog Light

Headlights

The headlight switch is located on the instrument panel to the left of the steering wheel.

From the off (O) position, rotate the headlight switch counterclockwise to enable the parking lights. This feature will allow one side of the vehicle park lights to be on when the vehicle is locked dependant on the turn stalk position. Rotate the headlight switch clockwise from the off (O) position to the first detent for headlight, parking light and instrument panel light operation

Adaptive Bi-Xenon High Intensity Discharge Headlights — If Equipped

This system automatically swivels the headlight beam pattern horizontally to provide increased illumination in the direction the vehicle is steering.

NOTE:

 Each time the Adaptive Headlight System is turned on, the headlights will initialize by performing a brief sequence of rotations. • The Adaptive Headlight System is active only when the vehicle is moving forward.

The Adaptive Headlight System can be turned on or off using the Uconnect System, refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

Daytime Running Lights (DRL) — If Equipped

The Daytime Running Lights will turn on when the engine is started and remain on unless the headlamps are turned on, the parking brake is applied, or the engine is shut off.

NOTE:

If allowed by law in the country in which the vehicle was purchased, the Daytime Running Lights can be turned on and off using the Uconnect System, refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

High Beams



Push the multifunction lever toward the instrument panel to switch the headlights to high beams. Pulling the multifunction back toward the steering wheel will turn the low beams back on, or shut the high beams off.

Flash-To-Pass

You can signal another vehicle with your headlights by lightly pulling the multifunction lever toward you. This will cause the headlights to turn on at high beam and remain on until the lever is released.

Automatic Lighting

The Automatic High Beams system provides increased forward lighting at night by automating high beam control through the use of a digital camera mounted above the inside rearview mirror. This camera detects vehicle specific light and automatically switches from high beams to low beams until the approaching vehicle is out of view. This feature is activated by selecting "ON" under "Auto High Beam" within your Uconnect settings, as well as turning the headlight switch to the AUTO position. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

NOTE:

There is not an adjustable sensitivity level for this feature.

The headlight switch is located on the instrument panel to the left of the steering wheel.

When set to AUTO, the system automatically turns the headlights on or off based on ambient light levels.

Parking Lighting

To operate the parking lighting, the ignition must be in the OFF position. Rotate the headlight switch counterclockwise to the "P" position. Then move the multifunction lever up or down to turn on the left or right side parking lights.

Headlight Delay

This feature provides the safety of headlight illumination for up to 90 seconds (programmable) when leaving your vehicle in an unlit area.

To activate the delay feature, place the ignition in the OFF position while the headlights are still on. Then, turn off the headlights within 45 seconds. The delay interval begins when the headlight switch is turned off.





If you turn the headlights or parking lights on, or place the ignition in ACC or RUN, the system will cancel the delay.



If you turn the headlights off before the ignition, they will turn off in the normal manner.

NOTE:







• The lights must be turned off within 45 seconds of placing the ignition in the OFF position to activate this feature.



• The headlight delay time is programmable using the Uconnect System, refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.









Front And Rear Fog Lights — If Equipped

The fog light switches are built into the headlight switch.

- **≢** To activate the front fog lights, push the upper half of the headlight switch. To turn off the front fog lights, push the upper half of the headlight switch a second time.
- O\(\pm\$ To activate the rear fog lights, push the lower half of the headlight switch. To turn off the rear fog lights, push the lower half of the headlight switch a second time.

NOTE:

To turn on the rear fog lamps, the low beam lamps or front fog lamps must first be active.

An indicator light in the instrument cluster illuminates when the fog lights are turned on.

Turn Signals

- Move the multifunction lever up or down
- and the arrows on each side of the instrument cluster display flash to show proper operation of the front and rear turn signal lights.

NOTE:

- If either light remains on and does not flash, or there is a very fast flash rate, check for a defective outside light bulb. If an indicator fails to light when the lever is moved, it would suggest that the indicator bulb is defective.
- When the Daytime Running Lights are on and a turn signal is activated, the Daytime Running Lamp will turn off on the side of the vehicle in which the turn signal is flashing. The Daytime Running Lamp will turn back on when the turn signal is turned off.


Lane Change Assist

Tap the lever up or down once, without moving beyond the detent, and the turn signal (right or left) will flash three times. Then, automatically turn off.

Automatic Headlight Leveling — HID Headlights Only

This feature prevents the headlights from interfering with the vision of oncoming drivers. Headlight leveling automatically adjusts the height of the headlight beam in reaction to changes in vehicle pitch.

WIPER AND WASHERS



Windshield Wiper/Washer Lever

- 1 Push For Rear Washer
- 2 Rotate For Rear Wiper
- 3 Rotate For Front Wiper

Front Wipers

The windshield wiper/washer controls are located on the lever on the right side of the steering column. The front wipers are operated by rotating a switch, located on the end of the lever.

For information on the rear wiper/washer, refer to "Rear Wiper" in this section.

Front Wiper Operation

Intermittent, Low And High Operation

Rotate the end of the lever to one of the first four detent positions for intermittent settings, the fifth detent for low wiper operation and the sixth detent for high wiper operation.

Washer Operation

Pull the lever rearward toward you and hold for as long as spray is desired.

Mist

Push the lever upward to the Mist position and release for a single wiping cycle.

NOTE:

The mist feature does not activate the washer pump; therefore, no washer fluid will be sprayed on the windshield. The wash function must be activated in order to spray the windshield with washer fluid.

Rain Sensing Wipers


This feature senses moisture on the vehicle's windshield and automatically activates the wipers for the driver when the switch is in the intermittent position. The feature is especially useful for road splash or overspray from the windshield washers of the vehicle ahead. Rotate the end of the multifunction lever to one of four settings to activate this feature.

Automatic Wiping

The sensitivity of the system can be adjusted with the multifunction lever. Wiper delay position one is the least sensitive, and wiper delay position four is the most sensitive. Settings one and two can be used if the driver desires less wiper sensitivity.

NOTE:

Setting three should be used for normal rain conditions.



NOTE:

- The Rain Sensing feature will not operate when the wiper switch is in the low or high-speed position.
- The Rain Sensing feature may not function properly when ice or dried salt water is present on the windshield.
- Use of Rain-X or products containing wax or silicone may reduce Rain Sensing performance.
- The Rain Sensing feature can be turned on and off using the Uconnect System. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.























The Rain Sensing system has protection features for the wiper blades and arms, and will not operate under the following conditions:

- Low Ambient Temperature When the ignition is first turned ON, the Rain Sensing system will not operate until the wiper switch is moved, vehicle speed is greater than 3 mph (5 km/h), or the outside temperature is greater than 32°F (0°C).
- Transmission In NEUTRAL Position When the ignition is ON, and the automatic transmission is in the NEUTRAL position, the Rain Sensing system will not operate until the wiper switch is moved, vehicle speed is greater than 3 mph (5 km/h), or the gear selector is moved out of the NEUTRAL position.

Remote Start Mode Inhibit — On vehicles equipped with Remote Starting system, Rain Sensing wipers are not operational when the vehicle is in the remote start mode. Once the operator is in the vehicle and has placed the ignition switch in the RUN position, rain sensing wiper operation can resume, if it has been selected, and no other inhibit conditions (mentioned previously) exist.

Rear Wiper

The rear wiper/washer controls are located on the windshield wiper/washer lever on the right side of the steering column. The rear wiper/washer is operated by rotating a switch, located at the middle of the lever.

Rear Wiper Operation

Rotate the center portion of the lever upward to the first detent for intermittent operation and to the second detent for continuous rear wiper operation.

Rear Washer Operation

Push the lever forward and hold while spray is desired. Once the switch is released, it will return to the OFF position and the wipers will cycle several times before returning to the parked position.

CAUTION!

Failure to follow these cautions can cause damage to the heating elements:

- Use care when washing the inside of the rear window. Do not use abrasive window cleaners on the interior surface of the window. Use a soft cloth and a mild washing solution, wiping parallel to the heating elements. Labels can be peeled off after soaking with warm water.
- Do not use scrapers, sharp instruments, or abrasive window cleaners on the interior surface of the window.
- Keep all objects a safe distance from the window.

CLIMATE CONTROLS

Climate Controls With A Touchscreen Overview



Uconnect 3 With 5-inch Display With Automatic Temperature Controls

























Uconnect 3C/3C NAV With 8.4-inch Display With Automatic Temperature Controls



Automatic Temperature Faceplate Controls























Climate Control With A Touchscreen Descriptions

Icon	Description
MAX A/C	MAX A/C Button Press and release to change the current setting. The indicator illuminates when MAX A/C is on. Performing this function again will cause the MAX A/C operation to switch into manual mode and the MAX A/C indicator will turn off.
A/C	A/C Button Press and release to change the current setting. The indicator illuminates when A/C is on.
	Recirculation Button Press and release this button on the touchscreen, or push the button on the faceplate, to change the system between recirculation mode and outside air mode.
(E)	 NOTE: Recirculation can be used when outside conditions such as smoke, odors, dust, or high humidity are present. Recirculation can be used in all modes except for Defrost. The A/C can be deselected manually without disturbing the mode control selection. Continuous use of the Recirculation mode may make the inside air stuffy and window fogging may occur. Extended use of this mode is not recommended.
AUTO	AUTO Button — If Equipped Automatically controls the interior cabin temperature by adjusting airflow distribution and amount. Performing this function will cause the system to switch between manual mode and automatic modes. Refer to "Automatic Operation" within this section for more information.

FRONT	Press and release the touchscreen button, or push and release the button on the faceplate, to change the current airflow setting to Defrost mode. The indicator illuminates when this feature is on. Air comes from the windshield and side window demist outlets. When the defrost button is selected, the blower level may increase. Use Defrost mode with maximum temperature settings for best windshield and side window defrosting and defogging. When toggling the front defrost mode button, the climate system will return to the previous setting.	
?}}} REAR	Rear Defrost Button Push and release the button on the touchscreen, or push and release the button on the faceplate, to turn on the rear window defroster and the heated outside mirrors (if equipped). An indicator will illuminate when the rear window defroster is on. The rear window defroster automatically turns off after ten minutes.	
Uconnect 3 Temp 18 18 Uconnect 3C/3C NAV	Driver and Passenger Temperature Up and Down Buttons Provides the driver and passenger with independent temperature control. Push the red button on the faceplate or touch-screen or press and slide the temperature bar towards the red arrow button on the touchscreen for warmer temperature settings. Push the blue button on the faceplate or touchscreen or press and slide the temperature bar towards the blue arrow button on the touchscreen for cooler temperature settings. NOTE: The numbers within the temperature display will only appear if the system is equipped with an automatic climate control system.	

Icon

Front Defrost Button

Description





















Icon	Description
SYNC	SYNC Button — If Equipped Press the SYNC button on the touchscreen to toggle the SYNC feature on/off. The SYNC indicator is illuminated when this feature is enabled. SYNC is used to synchronize the passenger temperature setting with the driver temperature setting. Changing the passenger's temperature setting while in SYNC will automatically exit this feature.
Faceplate Knob	
Touchscreen Buttons	Blower Control Blower Control is used to regulate the amount of air forced through the climate system. There are seven blower speeds available. Adjusting the blower will cause automatic mode to switch to manual operation. The speeds can be selected using either the blower control knob on the faceplate or the buttons on the touchscreen. • Faceplate: The blower speed increases as you turn the blower control knob clockwise from the lowest blower setting. The blower speed decreases as you turn the blower control knob counterclockwise. • Touchscreen: Use the small blower icon to reduce the blower setting and the large blower icon to increase the blower setting. Blower can also be selected by pressing the blower bar area between the icons.
Panel Mode	Panel Mode
ن,-	Air comes from the outlets in the instrument panel. Each of these outlets can be individually adjusted to direct the flow of air. The air vanes of the center outlets and outboard outlets can be moved up and down or side to side to regulate airflow direction. There is a shut off wheel located below the air vanes to shut off or adjust the amount of airflow from these outlets.
Bi-Level Mode → ●	Bi-Level Mode Air comes from the instrument panel outlets and floor outlets. A slight amount of air is directed through the defrost and side window demister outlets.
'	NOTE: Bi-Level mode is designed under comfort conditions to provide cooler air out of the panel outlets and warmer air from the floor outlets.

Icon	Description	11
Floor Mode	Floor Mode Air comes from the floor outlets. A slight amount of air is directed through the defrost and side window demister outlets.	
Mix Mode	Mix Mode Air is directed through the floor, defrost, and side window demister outlets. This setting works best in cold or snowy conditions that require extra heat to the windshield. This setting is good for maintaining comfort while reducing moisture on the windshield.	
OFF	Climate Control OFF Button Press and release this button to turn the Climate Controls off.	























Climate Control Functions

A/C (Air Conditioning)

The Air Conditioning (A/C) button allows the operator to manually activate or deactivate the air conditioning system. When the air conditioning system is turned on, cool dehumidified air will flow through the outlets into the cabin. For improved fuel economy, press the A/C button to turn off the air conditioning and manually adjust the blower and airflow mode settings. Also, make sure to select only Panel, Bi-Level, or Floor modes.

NOTE:

- If fog or mist appears on the windshield or side glass, select Defrost mode, and increase blower speed if needed.
- If your air conditioning performance seems lower than expected, check the front of the A/C condenser (located in front of the radiator), for an accumulation of dirt or insects. Clean with a gentle water spray from the front of the radiator and through the condenser.

MAX A/C

MAX A/C sets the control for maximum cooling performance.

Press and release to toggle between MAX A/C and the prior settings. The button illuminates when MAX A/C is on.

In MAX A/C, the blower level and mode position can be adjusted to desired user settings. Pressing other settings will cause the MAX A/C operation to switch to the selected setting and MAX A/C to exit.

Recirculation

In cold weather, use of Recirculation mode may lead to excessive window fogging. The Recirculation feature may be unavailable (button on the touchscreen greyed out) if conditions exist that could create fogging on the inside of the windshield.

On systems with Manual Climate Controls, the Recirculation mode is not allowed in Defrost mode to improve window clearing operation. Recirculation is disabled automatically if this mode is selected. Attempting to use Recirculation while in this mode causes the LED in the control button to blink and then turns off.

Automatic Temperature Control (ATC) — If Equipped

Automatic Operation

- Push the AUTO button on the faceplate, or the AUTO button on the touchscreen on the Automatic Temperature Control (ATC) Panel.
- Next, adjust the temperature you would like the system to maintain by adjusting the driver and passenger temperature control buttons. Once the desired temperature is displayed, the system will achieve and automatically maintain that comfort level.
- 3. When the system is set up for your comfort level, it is not necessary to change the settings. You will experience the greatest efficiency by simply allowing the system to function automatically.

NOTE:

- It is not necessary to move the temperature settings for cold or hot vehicles. The system automatically adjusts the temperature, mode, and blower speed to provide comfort as quickly as possible.
- The temperature can be displayed in U.S. or Metric units by selecting the US/Metric customer-programmable feature. Refer to the "Uconnect Settings" in "Multimedia" in your Owner's Manual for further information.

To provide you with maximum comfort in the Automatic mode during cold start-ups, the blower fan will remain on low until the engine warms up. The blower will increase in speed and transition into Auto mode.

Manual Operation Override

This system offers a full complement of manual override features. The AUTO symbol in the front ATC display will be turned off when the system is being used in the manual mode.

Operating Tips

Summer Operation

The engine cooling system must be protected with a high-quality antifreeze coolant to provide proper corrosion protection and to protect against engine overheating. OAT coolant (conforming to MS.90032) is recommended.

Winter Operation

To ensure the best possible heater and defroster performance, make sure the engine cooling system is functioning properly and the proper amount, type, and concentration of coolant is used. Use of the Air Recirculation mode during Winter months is not recommended, because it may cause window fogging.

Vacation/Storage

Before you store your vehicle, or keep it out of service (i.e., vacation) for two weeks or more, run the air conditioning system at idle for about five minutes, in fresh air with the blower setting on high. This will ensure adequate system lubrication to minimize the possibility of compressor damage when the system is started again.

Window Fogging

Vehicle windows tend to fog on the inside in mild, rainy, and/or humid weather. To clear the windows, select Defrost or Mix mode and increase the front blower speed. Do not use the Recirculation mode without A/C for long periods, as fogging may occur.










CAUTION!

Failure to follow these cautions can cause damage to the heating elements:























Outside Air Intake

Make sure the air intake, located directly in front of the windshield, is free of obstructions, such as leaves. Leaves collected in the air intake may reduce airflow, and if they enter the plenum, they could plug the water drains. In Winter months, make sure the air intake is clear of ice, slush, and snow.

Cabin Air Filter

The climate control system filters out dust and pollen from the air. Contact an authorized dealer to service your cabin air filter, and to have it replaced when needed.

WINDOWS

Power Window Controls

The window controls on the driver's door control all the door windows.



Power Window Switches

- 1 Front Power Window Switches
- 2 Rear Power Window Switches

There are single window controls on each passenger door trim panel, which operate the passenger door windows. The window controls will operate only when the ignition is in the ACC or ON/RUN position.

WARNING!

Never leave children unattended in a vehicle, and do not let children play with power windows. Do not leave the key fob in or near the vehicle, or in a location accessible to children, and do not leave the ignition of a vehicle equipped with Keyless Enter-N-Go in the ACC or ON/RUN mode. Occupants, particularly unattended children, can become entrapped by the windows while operating the power window switches. Such entrapment may result in serious injury or death.

Auto-Up Feature With Anti-Pinch Protection

NOTE:

 If the window runs into any obstacle during auto-closure, it will reverse direction and then go back down. Remove the obstacle and use the window switch again to close the window. Any impact due to rough road conditions may trigger the auto-reverse function unexpectedly during auto-closure. If this happens, pull the switch lightly and hold to close the window manually.

WARNING!

There is no anti-pinch protection when the window is almost closed. To avoid personal injury be sure to clear your arms, hands, fingers and all objects from the window path before closing.

Reset Auto-Up

Should the Auto-Up feature stop working, the window probably needs to be reset. To reset Auto-Up:

- Pull the window switch up to close the window completely and continue to hold the switch up for an additional two seconds after the window is closed.
- Push the window switch down firmly to open the window completely and continue to hold the switch down for an additional two seconds after the window is fully open.

Window Lockout Switch

The window lockout switch on the driver's door trim panel allows you to disable the window controls on the rear passenger doors. To disable the window controls, push and release the window lockout button (the indicator light on the button with turn on). To enable the window controls, push and release the window lockout button again (the indicator light on the button will turn back off).



Power Window Lockout Button

POWER SUNROOF

The power sunroof switches are located on the overhead console.





- Closing Sunroof
- 2 Venting Sunroof
- 3 Opening Sunroof
 - Opening Power Shade
- 5 Closing Power Shade

























Opening

Opening Sunroof — **Express**

- Push the sunroof switch rearward and release it within one-half second. The sunroof will automatically open to the halfway position and stop automatically.
- Push the sunroof switch a second time from the halfway position and the sunroof will automatically open to the full open position and stop automatically.

Opening Sunroof — Manual

- Push and hold the sunroof switch rearward.
 The sunroof will open and stop automatically at the half-open position.
- Push and hold the sunroof switch rearward again and the sunroof will open automatically to the full-open position.

NOTE:

Any release of the sunroof switch will stop the movement and the sunroof will remain in a partially opened condition until the sunroof switch is pushed and held rearward again.

Venting Sunroof — **Express**

Push and release the button and the sunroof will open to the vent position.

This is called "Express Vent" and will occur regardless of sunroof position. During Express Vent operation, any movement of the switch will stop the sunroof.

Closing

Closing Sunroof — Express

Push the sunroof switch forward and release it within one-half second. The sunroof will close automatically from any position.

Closing Sunroof — Manual

To close the sunroof, push and hold the sunroof switch in the forward position.

NOTE:

Any release of the sunroof switch will stop the sunroof movement. The sunroof will remain in a partially closed condition until the switch is pushed and held forward again.

Wind Buffeting

Wind buffeting can be described as a helicopter-type percussion sound. If buffeting occurs with the rear windows open, adjust the front and rear windows together.

If buffeting occurs with the sunroof open, adjust the sunroof opening, or adjust any window. This will minimize buffeting.

Power Sun Shade

Express Open

Push the shade switch rearward and release it within one-half second and the shade will automatically open to the halfway position and stop automatically.

Push the switch a second time from the halfway position and the shade will automatically open to the full open position and stop automatically.

Manual Open

To open the shade, push and hold the switch rearward. The shade will open and stop automatically at the half-open position.

Push and hold the shade switch rearward again and the shade will open automatically to the full-open position.

Express Close

Push the switch forward and release it within one-half second and the shade will close automatically from any position.

Manual Close

To close the shade, push and hold the switch in the forward position.

Pinch Protection Feature

This feature will detect an obstruction in the opening of the sunroof during Express Close operation. If an obstruction in the path of the sunroof is detected, the sunroof will automatically retract. Remove the obstruction if this occurs. Next, push the switch forward and release to Express Close.

NOTE:

If three consecutive sunroof close attempts result in Pinch Protect reversals, the fourth close attempt will be a Manual Close movement with Pinch Protect disabled.

WARNING!

- Do not let children play with the sunroof. Never leave children unattended in a vehicle, or with access to an unlocked vehicle. Do not leave the key fob in or near the vehicle, and do not leave the ignition of a vehicle equipped with Keyless Enter-N-Go in the ACC or ON/RUN mode. Occupants, particularly unattended children, can become entrapped by the power sunroof while operating the power sunroof switch. Such entrapment may result in serious injury or death.
- In a collision, there is a greater risk of being thrown from a vehicle with an open sunroof. You could also be severely injured or killed. Always fasten your seat belt properly and make sure all passengers are properly secured.

WARNING!



 Do not allow small children to operate the sunroof. Never allow your fingers, other body parts, or any object to project through the sunroof opening. Injury may result.







Use only a non-abrasive cleaner and a soft cloth to clean the glass panel.



HOOD





Two latches must be released to open the hood.



1. Pull the hood release lever located under the driver's side of the instrument panel.









2. Move to the outside of the vehicle and pull the safety latch release lever forward (toward you). The safety latch release lever is located behind the front edge of the hood, slightly off-center to the right.



Safety Latch Location

Closing The Hood

WARNING!

Be sure the hood is fully latched before driving your vehicle. If the hood is not fully latched, it could open when the vehicle is in motion and block your vision. Failure to follow this warning could result in serious injury or death.

CAUTION!

To prevent possible damage, do not slam the hood to close it. Lower hood to approximately 12 inches (30 cm) and drop the hood to close. Make sure hood is fully closed for both latches. Never drive vehicle unless hood is fully closed, with both latches engaged.

LIFTGATE

Opening

To Unlock/Enter The Liftgate

The power liftgate may be opened by pushing the electronic liftgate release (refer to "Keyless Enter-N-Go — Passive Entry" located in "Getting To Know Your Vehicle") or by pushing the liftgate button on the key fob. Push the liftgate button on the key fob twice within five seconds to open the power liftgate. Once the liftgate is open, pushing the button twice within five seconds a second time will close the liftgate.

The power liftgate may also be opened or closed by pushing the liftgate button located on the front overhead console. If the liftgate is fully open, the liftgate can be closed by pushing the liftgate button located on the left rear trim panel, near the liftgate opening. If the liftgate is in motion, pushing the liftgate button located on the left rear trim panel will reverse the liftgate.

The liftgate passive entry unlock feature is built into the electronic liftgate release. With a valid Passive Entry key fob within 5 ft (1.5 m) of the liftgate, push the electronic liftgate release to open with one fluid motion. Push the button on the key fob twice within five seconds to release the liftgate.



Liftgate Entry

Closing

Grasp the liftgate closing handle and initiate lowering the liftgate. Release the handle when the liftgate takes over the closing effort.

To Lock The Liftgate

With a valid Passive Entry key fob within 5 ft (1.5 m) of the liftgate, pushing the Keyless Enter-N-Go — Passive Entry lock button located to the left of the outside handle release will lock the vehicle.

The power liftgate may be closed by pushing the button, located in the upper left trim in the liftgate opening. Pushing button will only close the liftgate. This button cannot be used to open the liftgate.




Rear Power Liftgate Switch

NOTE:



INTERNAL EQUIPMENT

Power Outlets





The front 12 Volt power outlet is located below the climate controls in the Media Center, and is powered when the ignition switch is in the ON/RUN position. The outlet can operate a conventional cigar lighter unit or power accessories designed for use with a standard power outlet adapter.

















Front Power Outlet

The center console 12 Volt power outlet is powered directly from the battery (power available at all times). Items plugged into this outlet may discharge the battery and/or prevent the engine from starting.



Center Console Power Outlet

There is also a 12 Volt power outlet located in the rear cargo area of the vehicle. This power outlet has power available directly from the battery (power available at all times). Items plugged into this outlet also may discharge the battery and/or prevent the engine from starting.



Rear Cargo Power Outlet

NOTE:

- Do not exceed the maximum power of 160 Watts (13 Amps) at 12 Volts. If the 160 Watt (13 Amp) power rating is exceeded, the fuse protecting the system will need to be replaced.
- Power outlets are designed for accessory plugs only. Do not insert any other object in the power outlet as this will damage the outlet and blow the fuse. Improper use of the power outlet can cause damage not covered by your New Vehicle Limited Warranty.

• The rear cargo power outlet can be switched to "battery" powered all the time by switching the power outlet right rear quarter panel fuse in the fuse panel.



Power Outlets Fuse Locations

- 1 F75 Fuse 20A Yellow Front Power Outlet/Cigar Lighter Console Bin
- 2 F81 Fuse 20A Yellow Rear Power Outlet (battery powered at all times)
- 3 F91 Fuse 20A Yellow Rear Power Outlet (powered when the ignition switch is in the ON or ACC position)
- 4 F60 Fuse 20A Yellow Power Outlet Center Console























Power Inverter



Power Inverter

A 115 or 230 Volt, 150 Watt power inverter outlet is located on the rear of the center console. This outlet can power cellular phones, electronics and other low power devices requiring power up to 150 Watts.

The power inverter is designed with built-in overload protection. If the power rating of 150 Watts is exceeded, the power inverter will automatically shut down. Once the electrical device has been removed from the outlet, the inverter should automatically reset.

If the power rating exceeds approximately 170 Watts, the power inverter may have to be reset manually. To reset the inverter manu-

ally, unplug the device and plug it in again. To avoid overloading the circuit, check the power ratings on electrical devices prior to using the inverter.

WARNING!

To Avoid Serious Injury or Death DO NOT:

- insert any objects into the receptacles
- touch with wet hands

Close the lid when not in use. If this outlet is mishandled, it may cause an electric shock and failure.

GETTING TO KNOW YOUR INSTRUMENT PANEL



INSTRUMENT CLUSTER			
DISPLAY	54		
Instrument Cluster Display Controls	.54		
Oil Change Reset — If Equipped	.55		
Instrument Cluster Display Selectable			
Items	.55		

WARNING LIGHTS AND				
MESSAGES	56			
Red Warning Lights	56			
Yellow Warning Lights	59			
Yellow Indicator Lights	63			
Green Indicator Lights	63			

White Indicator Lights	
ONBOARD DIAGNOSTIC	
SYSTEM — OBD II	66



















INSTRUMENT CLUSTER DISPLAY

Your vehicle may be equipped with an instrument cluster display, which offers useful information to the driver. With the ignition in the STOP/OFF mode, opening/closing of a door will activate the display for viewing, and display the total miles, or kilometers, in the odometer. Your instrument cluster display is designed to display important information about your vehicle's systems and features. Using a driver interactive display located on the instrument panel, your instrument cluster display can show you how systems are working and give you warnings when they aren't. The steering wheel mounted controls allow you to scroll through and enter the main menus and submenus. You can access the specific information you want and make selections and adjustments.

Instrument Cluster Display Controls



Instrument Cluster Display Controls

The instrument cluster display features a driver interactive display that is located in the instrument cluster. Pushing the instrument cluster display controls on the left side of the steering wheel allows the driver to select vehicle information and Personal Settings.

- Push the up button to scroll upward through the main menus (Speedometer, Vehicle Info, Driver Assist, Fuel Economy, Trip, Audio, Messages, Screen Set Up).
- Push the down arrow button to scroll downward through the main menu and submenus (Speedometer, Vehicle Info, Driver Assist, Fuel Economy, Trip, Audio, Messages, Screen Set Up).
- Push the right arrow button to access the information screens or submenu screens of a main menu item.
- Push the left arrow button to access the information screens or submenu screens of a main menu item.
- Push the **OK** button to access/select the information screens or submenu screens of a main menu item. Push and hold the **OK** arrow button for two seconds to reset displayed/selected features that can be reset.

Oil Change Reset — If Equipped

Your vehicle is equipped with an engine oil change indicator system. The "Oil Change Required" message will display in the instrument cluster display for five seconds after a single chime has sounded to indicate the next scheduled oil change interval. The engine oil change indicator system is duty cycle based, which means the engine oil change interval may fluctuate, dependent upon your personal driving style.

Unless reset, this message will continue to display each time you cycle the ignition to the ON/RUN position. To turn off the message temporarily, push and release the **OK** button. To reset the oil change indicator system (after performing the scheduled maintenance), refer to the following procedure.

Oil Life Reset

1. Without pushing the brake pedal, push and release the ENGINE START/STOP button and place the ignition to the ON/ RUN position (do not start the engine).

- 2. Navigate to "Oil Life" submenu in "Vehicle Info" in the instrument cluster display.
- 3. Push and hold the OK button until the gauge resets to 100%.

Secondary Method For Oil Change Reset Procedure

- 1. Without pushing the brake pedal, push and release the ENGINE START/STOP button and place the ignition to the ON/ RUN position (do not start the engine).
- 2. Fully press the accelerator pedal, slowly, three times within ten seconds.
- 3. Without pushing the brake pedal, push and release the ENGINE START/STOP button once to return the ignition to the OFF/LOCK position.

NOTE:

If the indicator message illuminates when you start the vehicle, the oil change indicator system did not reset. If necessary, repeat this procedure.

Instrument Cluster Display Selectable Items



The instrument cluster display can be used to view the following main menu items:



Speedometer Vehicle Info Driver Assist

Stop/Start Audio



Messages Screen Setup


Trip

Gear Shift Indicator

(GSI)



NOTF:

















WARNING LIGHTS AND MESSAGES

The warning/indicator lights will illuminate in the instrument panel together with a dedicated message and/or acoustic signal when applicable. These indications are indicative and precautionary and as such must not be considered as exhaustive and/or alternative to the information contained in the Owner's Manual, which you are advised to read carefully in all cases. Always refer to the information in this chapter in the event of a failure indication. All active telltales will display first if applicable. The system check menu may appear different based upon equipment options and current vehicle status. Some telltales are optional and may not appear.

Red Warning Lights

👗 — Seat Belt Reminder Warning Light

This light indicates when the driver or passenger seat belt is unbuckled. When the ignition is first placed in the ON/RUN or ACC/ON/RUN position and if the driver's seat belt is unbuckled, a chime will sound and the

light will turn on. When driving, if the driver or front passenger seat belt remains unbuckled, the Seat Belt Reminder Light will flash or remain on continuously and a chime will sound. Refer to "Occupant Restraint Systems" in "Safety" for further information.

🧩 — Air Bag Warning Light

This light indicates a fault with the air bag, and will turn on for four to eight seconds as a bulb check when the ignition is placed in the ON/RUN or ACC/ON/RUN position. This light will illuminate with a single chime when a fault with the air bag has been detected, it will stay on until the fault is cleared. If the light is either not on during startup, stays on, or turns on while driving, have the system inspected at an authorized dealer as soon as possible.

(1) — Brake Warning Light

This light monitors various brake functions, including brake fluid level and parking brake application. If the brake light turns on it may indicate that the parking brake is applied, that the brake fluid level is low, or that there is a problem with the anti-lock brake system.

If the light remains on when the parking brake has been disengaged, and the fluid level is at the full mark on the master cylinder reservoir, it indicates a possible brake hydraulic system malfunction or that a problem with the Brake Booster has been detected by the Anti-Lock Brake System (ABS) / Electronic Stability Control (ESC) system. In this case, the light will remain on until the condition has been corrected. If the problem is related to the brake booster, the ABS pump will run when applying the brake, and a brake pedal pulsation may be felt during each stop.

The dual brake system provides a reserve braking capacity in the event of a failure to a portion of the hydraulic system. A leak in either half of the dual brake system is indicated by the Brake Warning Light, which will turn on when the brake fluid level in the master cylinder has dropped below a specified level.

The light will remain on until the cause is corrected.

NOTE:

The light may flash momentarily during sharp cornering maneuvers, which change fluid level conditions. The vehicle should have service performed, and the brake fluid level checked.

If brake failure is indicated, immediate repair is necessary.

WARNING!

Driving a vehicle with the red brake light on is dangerous. Part of the brake system may have failed. It will take longer to stop the vehicle. You could have a collision. Have the vehicle checked immediately.

Vehicles equipped with the Anti-Lock Brake System (ABS) are also equipped with Electronic Brake Force Distribution (EBD). In the event of an EBD failure, the Brake Warning Light will turn on along with the ABS Light. Immediate repair to the ABS system is required.

Operation of the Brake Warning Light can be checked by turning the ignition switch from the OFF position to the ON/RUN position. The light should illuminate for approximately four seconds. The light should then turn off unless the parking brake is applied or a brake fault is detected. If the light does not illuminate, have the light inspected by an authorized dealer.

The light also will turn on when the parking brake is applied with the ignition switch in the ON/RUN position.


NOTE:

This light shows only that the parking brake is applied. It does not show the degree of brake application.

Vehicle Security Warning Light — If Equipped

This light will flash at a fast rate for approximately 15 seconds when the vehicle security alarm is arming, and then will flash slowly until the vehicle is disarmed.

— Oil Pressure Warning Light





Do not operate the vehicle until the cause is corrected. This light does not indicate how much oil is in the engine. The engine oil level must be checked under the hood.





This light indicates high transmission fluid temperature. This may occur with strenuous usage such as trailer towing. If this light turns on, stop the vehicle and run the engine at idle or slightly faster, with the transmission in PARK or NEUTRAL, until the light turns off. Once the light turns off, you may continue to drive normally.









WARNING!

If you continue operating the vehicle when the Transmission Temperature Warning Light is illuminated you could cause the fluid to boil over, come in contact with hot engine or exhaust components and cause a fire.

CAUTION!

Continuous driving with the Transmission Temperature Warning Light illuminated will eventually cause severe transmission damage or transmission failure.

Engine Coolant Temperature Warning Light

This light warns of an overheated engine condition. If the engine coolant temperature is too high, this indicator will illuminate and a single chime will sound.

If the light turns on while driving, safely pull over and stop the vehicle. If the A/C system is on, turn it off. Also, shift the transmission

into NEUTRAL and idle the vehicle. If the temperature reading does not return to normal, turn the engine off immediately and call for service. Refer to "If Your Engine Overheats" in "In Case Of Emergency" for further information.

This telltale indicates engine oil temperature is high. If the light turns on while driving, stop the vehicle and shut off the engine as soon as possible. Wait for oil temperature to return to normal levels.

E Battery Charge Warning Light

This light illuminates when the battery is not charging properly. If it stays on while the engine is running, there may be a malfunction with the charging system. Contact your authorized dealer as soon as possible.

This indicates a possible problem with the electrical system or a related component.

This light informs you of a problem with the Electronic Throttle Control (ETC) system. If a problem is detected while the vehicle is running, the light will either stay on or flash depending on the nature of the problem. Cycle the ignition when the vehicle is safely and completely stopped and the transmission is placed in the PARK position. The light should turn off. If the light remains on with the vehicle running, your vehicle will usually be drivable; however, see an authorized dealer for service as soon as possible.

NOTE:

This light may turn on if the accelerator and brake pedals are pressed at the same time.

If the light continues to flash when the vehicle is running, immediate service is required and you may experience reduced performance, an elevated/rough idle, or engine stall and your vehicle may require towing. The light will come on when the ignition is placed in the ON/RUN or ACC/ON/RUN posi-

tion and remain on briefly as a bulb check. If the light does not come on during starting, have the system checked by an authorized dealer.

— Electric Power Steering Fault **Warning Light**

This light will turn on when there's a fault with the EPS (Electric Power Steering) system. Refer to "Power Steering" in "Starting And Operating" in the Owner's Manual for further information.

WARNING!

Continued operation with reduced assist could pose a safety risk to yourself and others. Service should be obtained as soon as possible.

— Door Open Warning Light

This indicator will illuminate when a door is ajar/open and not fully closed.

NOTE:

If the vehicle is moving, there will also be a single chime.



— Liftgate Open Warning Light

This indicator light will illuminate when the liftgate is open.

NOTE:

If the vehicle is moving, there will also be a single chime.

Yellow Warning Lights


- Engine Check/Malfunction Indicator Warning Light (MIL)


The Engine Check/Malfunction Indicator Light (MIL) is a part of an Onboard Diagnostic System called OBD II that monitors engine and automatic transmission control systems. This warning light will illuminate when the ignition is in the ON/RUN position before engine start. If the bulb does not come on when turning the ignition switch from OFF to ON/RUN, have the condition checked promptly.

Certain conditions, such as a loose or missing gas cap, poor quality fuel, etc., may illuminate the light after engine start. The vehicle should be serviced if the light stays on

through several typical driving styles. In most situations, the vehicle will drive normally and will not require towing.











WARNING!

should be serviced as soon as possible if this

occurs.

A malfunctioning catalytic converter, as referenced above, can reach higher temperatures than in normal operating conditions. This can cause a fire if you drive slowly or park over flammable substances such as dry plants, wood, cardboard, etc. This could result in death or serious injury to the driver, occupants or others.









Prolonged driving with the Malfunction Indicator Light (MIL) on could cause damage to the vehicle control system. It also





CAUTION!

could affect fuel economy and driveability. If the MIL is flashing, severe catalytic converter damage and power loss will soon occur. Immediate service is required.

□ Electronic Stability Control (ESC) Active Warning Light — If Equipped

This light will indicate when the Electronic Stability Control system is Active. The "ESC Indicator Light" in the instrument cluster will come on when the ignition is placed in the ON/RUN or ACC/ON/RUN position, and when ESC is activated. It should go out with the engine running. If the "ESC Indicator Light" comes on continuously with the engine running, a malfunction has been detected in the ESC system. If this light remains on after several ignition cycles, and the vehicle has been driven several miles (kilometers) at speeds greater than 30 mph (48 km/h), see your authorized dealer as soon as possible to have the problem diagnosed and corrected.

- The "ESC Off Indicator Light" and the "ESC Indicator Light" come on momentarily each time the ignition is placed in the ON/RUN or ACC/ON/RUN position.
- The ESC system will make buzzing or clicking sounds when it is active. This is normal; the sounds will stop when ESC becomes inactive.
- This light will come on when the vehicle is in an ESC event.

\$\frac{2}{8}\$ — Electronic Stability Control (ESC) Off Warning Light — If Equipped

This light indicates the Electronic Stability Control (ESC) is off.

Each time the ignition is turned to ON/RUN or ACC/ON/RUN, the ESC system will be on, even if it was turned off previously.

P. Electronic Park Brake Warning Light

This warning light will illuminate to indicate the Electronic Park Brake is not functioning properly and service is required. Contact an authorized dealer.

(!) — Tire Pressure Monitoring System (TPMS) Warning Light

The warning light switches on and a message is displayed to indicate that the tire pressure is lower than the recommended value and/or that slow pressure loss is occurring. In these cases, optimal tire duration and fuel consumption may not be guaranteed.

Should one or more tires be in the condition mentioned above, the display will show the indications corresponding to each tire in sequence.

CAUTION!

Do not continue driving with one or more flat tires as handling may be compromised. Stop the vehicle, avoiding sharp braking and steering. If a tire puncture occurs, repair immediately using the dedicated tire repair kit and contact your authorized dealer as soon as possible.

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the

vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

CAUTION!

original equipment tires and wheels.

TPMS pressures and warning have been

established for the tire size equipped on

vour vehicle. Undesirable system opera-

tion or sensor damage may result when

using replacement equipment that is not

of the same size, type, and/or style. After-

market wheels can cause sensor damage.

Using aftermarket tire sealants may cause

the Tire Pressure Monitoring System

(TPMS) sensor to become inoperable. After using an aftermarket tire sealant it is

recommended that you take your vehicle to

your authorized dealer to have your sensor















(ABS) — Anti-Lock Brake (ABS) Warning Light

function checked.



This light monitors the Anti-Lock Brake System (ABS). The light will turn on when the ignition is placed in the ON/RUN or ACC/ON/ RUN position and may stay on for as long as four seconds.







If the ABS light remains on or turns on while driving, then the Anti-Lock portion of the brake system is not functioning and service is required as soon as possible. However, the conventional brake system will continue to operate normally, assuming the Brake Warning Light is not also on.

If the ABS light does not turn on when the ignition is placed in the ON/RUN or ACC/ON/RUN position, have the brake system inspected by an authorized dealer.

When the fuel level reaches approximately 2.4 gal (9.1 L) this light will turn on, and remain on until fuel is added.

A single warning chime will sound with Low Fuel Warning.

(A)! — Service Stop/Start System Warning Light — If Equipped

This telltale will turn on to indicate the Stop/ Start system is not functioning properly and service is required. Contact your authorized dealer for service.

♣! — Service Forward Collision Warning (FCW) Light — If Equipped

This telltale will turn on to indicate a fault in the Forward Collision Warning System. Contact your local authorized dealer for service. Refer to "Forward Collision Warning (FCW)" in "Safety" for further information.

— Low Washer Fluid Warning Light — If Equipped

This indicator will illuminate when the windshield washer fluid is low.

₹! — Adaptive Cruise Control (ACC) Fault Warning Light — If Equipped

This telltale will turn on to indicate a fault in the ACC system. Contact your local authorized dealer for service. For further information, refer to "Adaptive Cruise Control (ACC)" in "Starting And Operating."

SERV — Service 4WD Warning Light — If Equipped

If the light stays on or comes on during driving, it means that the 4WD system is not functioning properly and that service is required. We recommend you drive to the nearest service center and have the vehicle serviced immediately.

| **☆** — LaneSense Warning Light — If Equipped

The LaneSense Warning Light will be solid yellow when the vehicle is approaching a lane marker. The warning light will flash when the vehicle is crossing the lane marker.

Refer to "LaneSense — If Equipped" in "Starting And Operating" for further information.

ାରୀ! — Service LaneSense Warning Light — If Equipped

This light will turn on when the LaneSense system is not operating and needs service. Please see an authorized dealer.

≥ — Loose Fuel Filler Cap Warning Light — If Equipped

This warning light will illuminate when the fuel filler cap is loose. Properly close the filler cap to disengage the light. If the light does not turn off, please see an authorized dealer.

Yellow Indicator Lights

(i) — Glow Plug Light — If Equipped

This vehicle will inhibit engine cranking when the ambient temperature is less than -22° F (-30° C) and the oil temperature sensor reading indicates an engine block heater has not been used. The Glow Plug light will flash during in cold weather for up to ten seconds.

If equipped with a block heater harness the message "Plug In Engine Heater", will be displayed in the instrument cluster when the ambient temperature is below 5°F (-15° C) at the time the engine is shut off as a reminder to avoid possible crank delays at the next cold start.

🚔 — Low Diesel Exhaust Fluid (DEF) Indicator Light — If Equipped

The Low Diesel Exhaust Fluid (DEF) Indicator will illuminate if the vehicle is low on Diesel Exhaust Fluid (DEF). Refer to "Starting And Operating" for further information.

— Forward Collision Warning Off Indicator Light — If Equipped

This light indicates that Forward Collision Warning is off.

4WD — 4WD Low Indicator Light — If Equipped

This light alerts the driver that the vehicle is in the four-wheel drive LOW mode. The front and rear driveshafts are mechanically locked together forcing the front and rear wheels to rotate at the same speed. Low range provides a greater gear reduction ratio to provide increased torque at the wheels.

Refer to "Four-Wheel Drive Operation — If Equipped" in "Starting And Operating" for further information on four-wheel drive operation and proper use.

- NEUTRAL Indicator Light — If Equipped



This light alerts the driver that the 4WD power transfer case is in the NEUTRAL mode and the front and rear driveshafts are disengaged from the powertrain.



()≢ — Rear Fog Indicator — If Equipped



This indicator light will illuminate when the rear fog lights are on.



REAR — Rear Axle Lock Indicator Light



This light indicates when the rear axle lock has been activated.

Green Indicator Lights



— Adaptive Cruise Control (ACC) Set With Target Vehicle Light — If Equipped



This will display when the ACC is set and a target vehicle is detected. Refer to "Adaptive Cruise Control (ACC)" in "Starting And Operating" for further information.







Adaptive Cruise Control (ACC) Set Without Target Vehicle Light — If Equipped

This will display the distance setting for the ACC system when the system is engaged. Refer to "Adaptive Cruise Control (ACC)" in "Starting And Operating" for further information.

ECO Mode Indicator Light

This light will turn on when ECO Mode is active.

Cruise Control Set Indicator Light If Equipped

This light will turn on when the speed control is set to the desired speed. Refer to "Speed Control" in "Starting And Operating" for further information.

≢○ — Front Fog Indicator Light — If Equipped

This indicator will illuminate when the front fog lights are on.

$|\mathcal{L}|$ — LaneSense Indicator Light — If Equipped

The LaneSense indicator is solid green when both lane markings have been detected and the system is "armed" and ready to provide visual and torque warnings if an unintentional lane departure occurs. Refer to "LaneSense — If Equipped" in "Starting And Operating" for further information.

⇒DO: — Park/Headlight On Indicator Light

This indicator light will illuminate when the park lights or headlights are turned on.

(A) — Stop/Start Active Indicator Light — If Equipped

This indicator light will illuminate when the Stop/Start function is in "Autostop" mode.

↓ → → — Turn Signal Indicator Lights

When the left or right turn signal is activated, the turn signal indicator will flash independently and the corresponding exterior turn signal lamps will flash. Turn signals can be activated when the multifunction lever is moved down (left) or up (right).

NOTE:

- A continuous chime will sound if the vehicle is driven more than 1 mile (1.6 km) with either turn signal on.
- Check for an inoperative outside light bulb if either indicator flashes at a rapid rate.

White Indicator Lights

Adaptive Cruise Control (ACC) Ready Light — If Equipped

This light will turn on when Adaptive Cruise Control (ACC) has been turned on, but is not set. Refer to "Adaptive Cruise Control (ACC)" in "Starting And Operating" for further information.

Adaptive Cruise Control (ACC) Set Light — If Equipped

This light will turn on when the vehicle equipped with Adaptive Cruise Control (ACC) has reached the speed desired and the set button has been selected. Refer to "Adaptive Cruise Control" in "Starting And Operating" for further information.

🙇 — Selec Speed Control Indicator Light — If Equipped

This light will turn on when "Selec Speed Control" is activated.

To activate "Selec Speed Control", assure the vehicle is Four Wheel Drive Low (4WD) and push the button on the Instrument Panel.

NOTE:

If the vehicle is not in 4WD Low, "To Enter Selec-Speed Shift to 4WD Low" will appear in the instrument cluster display.

() — Cruise Control Ready Indicator Light

This light will turn on when the speed control has been turned on, but not set. Refer to "Speed Control — If Equipped" in "Starting And Operating" for further information.

— Hill Descent Control (HDC) Indicator Light — If Equipped

This indicator shows when the Hill Descent Control (HDC) feature is turned on. The lamp will be on solid when HDC is armed. HDC can only be armed when the transfer case is in the "4WD LOW" position and the vehicle speed is less then 30 mph (48 km/h). If these conditions are not met while attempting to use the HDC feature, the HDC indicator light will flash on/off.

🖄 — LaneSense Indicator Light — If Equipped

When the LaneSense system is ON, but not armed, the LaneSense indicator is solid white. This occurs when only left, right, or neither lane line has been detected. If a single lane line is detected, the system is ready to provide only visual warnings if an unintentional lane departure occurs on the detected lane line.

Refer to "LaneSense — If Equipped" in "Starting And Operating" for further information.

31 — Passive Speed Limiter Engaged

The indication light up white along with a notification text message (speed warning set to xx followed by unit). When the set speed is

just exceeded, a single chime will sound along with pop up message of speed warning exceeded. When the set speed is exceeded by 2 mph (3 km/h) or more, the indication will light up yellow and flash along with a continuous chime (up to 10 seconds or until the speed is no longer exceeded).







NOTE:

The number "31" is only an example of a speed that can be select.



Blue Indicator Lights





This indicator shows that the high beam headlights are on. With the low beams activated, push the multifunction lever forward (toward the front of the vehicle) to turn on the high beams. Pull the multifunction lever rearward (toward the rear of the vehicle) to turn off the high beams. If the high beams are off, pull the lever toward you for a temporary high beam on, "flash to pass" scenario.











ONBOARD DIAGNOSTIC SYSTEM – OBD II

Your vehicle is equipped with a sophisticated Onboard Diagnostic system called OBD II. This system monitors the performance of the emissions, engine, and automatic transmission control systems. When these systems are operating properly, your vehicle will provide excellent performance and fuel economy, as well as emissions well within current government regulations.

If any of these systems require service, the OBD II system will turn on the Malfunction Indicator Light (MIL). It will also store diagnostic codes and other information to assist your service technician in making repairs. Although your vehicle will usually be drivable and not need towing, see an authorized dealer for service as soon as possible.

CAUTION!

- Prolonged driving with the MIL on could cause further damage to the emission control system. It could also affect fuel economy and driveability. The vehicle must be serviced before any emissions tests can be performed.
- If the MIL is flashing while the vehicle is running, severe catalytic converter damage and power loss will soon occur. Immediate service is required.

Onboard Diagnostic System (OBD II) Cybersecurity

Your vehicle is required to have an Onboard Diagnostic system (OBD II) and a connection port to allow access to information related to the performance of your emissions controls. Authorized service technicians may need to access this information to assist with the diagnosis and service of your vehicle and emissions system.

WARNING!

- ONLY an authorized service technician should connect equipment to the OBD II connection port in order to diagnose or service your vehicle.
- If unauthorized equipment is connected to the OBD II connection port, such as a driver-behavior tracking device, it may:
 - Be possible that vehicle systems, including safety related systems, could be impaired or a loss of vehicle control could occur that may result in an accident involving serious injury or death.
 - Access, or allow others to access, information stored in your vehicle systems, including personal information.

For further information, refer to "Cybersecurity" in "Multimedia".

SAFETY

1 /		
1%		
11		1

SAFETY FEATURES68
Anti-Lock Brake System (ABS)68
Electronic Brake Control System 69
AUXILIARY DRIVING SYSTEMS79
Blind Spot Monitoring
Forward Collision Warning (FCW) 8
Tire Pressure Monitor System (TPMS)82

OCCUPANT RESTRAINT
SYSTEMS
Occupant Restraint Systems Features87
Important Safety Precautions
Seat Belt Systems
Supplemental Restraint Systems (SRS)
Child Restraints — Carrying Children Safely

Transporting Pets	
SAFETY TIPS	
Transporting Passengers	
Exhaust Gas	
Safety Checks You Should Make Inside The Vehicle	
Make Outside The Vehicle	





















SAFETY FEATURES

Anti-Lock Brake System (ABS)

The Anti-Lock Brake System (ABS) provides increased vehicle stability and brake performance under most braking conditions. The system automatically prevents wheel lock, and enhances vehicle control during braking.

The ABS performs a self-check cycle to ensure that the ABS is working properly each time the vehicle is started and driven. During this self-check, you may hear a slight clicking sound as well as some related motor noises.

ABS is activated during braking when the system detects one or more wheels begin to lock. Road conditions such as ice, snow, gravel, bumps, railroad tracks, loose debris, or panic stops may increase the likelihood of ABS activation(s).

You also may experience the following when ABS activates:

- The ABS motor noise (it may continue to run for a short time after the stop).
- The clicking sound of solenoid valves.

- Brake pedal pulsations.
- A slight drop of the brake pedal at the end of the stop.

These are all normal characteristics of ABS.

WARNING!

- The ABS contains sophisticated electronic equipment that may be susceptible to interference caused by improperly installed or high output radio transmitting equipment. This interference can cause possible loss of anti-lock braking capability. Installation of such equipment should be performed by qualified professionals.
- Pumping of the Anti-Lock Brakes will diminish their effectiveness and may lead to a collision. Pumping makes the stopping distance longer. Just press firmly on your brake pedal when you need to slow down or stop.
- The ABS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking or steering efficiency beyond that afforded by the

WARNING!

condition of the vehicle brakes and tires or the traction afforded.

- The ABS cannot prevent collisions, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning.
- The capabilities of an ABS equipped vehicle must never be exploited in a reckless or dangerous manner that could jeopardize the user's safety or the safety of others.

ABS is designed to function with the OEM tires. Modification may result in degraded ABS performance.

Anti-Lock Brake Warning Light

The yellow "Anti-Lock Brake Warning Light" will turn on when the ignition is turned to the ON/RUN mode and may stay on for as long as four seconds.

If the "Anti-Lock Brake Warning Light" remains on or comes on while driving, it indicates that the anti-lock portion of the brake system is not functioning and that service is

required. However, the conventional brake system will continue to operate normally if the "Anti-Lock Brake Warning Light" is on.

If the "Anti-Lock Brake Warning Light" is on, the brake system should be serviced as soon as possible to restore the benefits of anti-lock brakes. If the "Anti-Lock Brake Warning Light" does not come on when the ignition is turned to the ON/RUN mode, have the light repaired as soon as possible.

Electronic Brake Control System

Your vehicle is equipped with an advanced Electronic Brake Control system (EBC). This system includes Electronic Brake Force Distribution (EBD), Anti-Lock Brake System (ABS), Brake Assist System (BAS), Hill Start Assist (HSA), Traction Control System (TCS), Electronic Stability Control (ESC), and Electronic Roll Mitigation (ERM). These systems work together to enhance both vehicle stability and control in various driving conditions.

Your vehicle may also be equipped with Trailer Sway Control (TSC), Ready Alert Braking (RAB), Rain Brake Support (RBS), Dynamic Steering Torque (DST), Hill Descent Control (HDC), and Selec-Speed Control (SSC).

Electronic Brake Force Distribution (EBD)

This function manages the distribution of the braking torque between the front and rear axles by limiting braking pressure to the rear axle. This is done to prevent overslip of the rear wheels to avoid vehicle instability, and to prevent the rear axle from entering ABS before the front axle.

Brake System Warning Light

The red "Brake System Warning Light" will turn on when the ignition is turned to the ON/RUN mode and may stay on for as long as four seconds.

If the "Brake System Warning Light" remains on or comes on while driving, it indicates that the brake system is not functioning properly and that immediate service is required. If the "Brake System Warning Light" does not come on when the ignition is turned to the ON/RUN mode, have the light repaired as soon as possible.

applies optimum pressure to the brakes. This

can help reduce braking distances. The BAS

complements the anti-lock brake system

(ABS). Applying the brakes very quickly re-

sults in the best BAS assistance. To receive

the benefit of the system, you must apply

continuous braking pressure during the stop-

ping sequence, (do not "pump" the brakes).


Do not reduce brake pedal pressure unless


braking is no longer desired. Once the brake


pedal is released, the BAS is deactivated.

























WARNING!

The Brake Assist System (BAS) cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded by prevailing road conditions. BAS cannot prevent collisions, including those resulting from excessive speed in turns, driving on very slippery surfaces, or hydroplaning. The capabilities of a BAS-equipped vehicle must never be exploited in a reckless or dangerous manner, which could jeopardize the user's safety or the safety of others.

Hill Start Assist (HSA)

The HSA system is designed to mitigate roll back from a complete stop while on an incline. If the driver releases the brake while stopped on an incline, HSA will continue to hold the brake pressure for a short period. If the driver does not apply the throttle before this time expires, the system will release brake pressure and the vehicle will roll down the hill as normal.

The following conditions must be met in order for HSA to activate:

- The feature must be enabled.
- The vehicle must be stopped.
- Park brake must be off.
- Driver door must be closed.
- The vehicle must be on a sufficient grade.
- The gear selection must match vehicle uphill direction (i.e., vehicle facing uphill is in forward gear; vehicle backing uphill is in REVERSE gear).
- HSA will work in REVERSE gear and all forward gears. The system will not activate if the transmission is in PARK or NEU-TRAL. For vehicles equipped with a manual transmission, if the clutch is pressed, HSA will remain active.

WARNING!

There may be situations where the Hill Start Assist (HSA) will not activate and slight rolling may occur, such as on minor hills or with a loaded vehicle, or while pulling a trailer. HSA is not a substitute for

WARNING!

active driving involvement. It is always the driver's responsibility to be attentive to distance to other vehicles, people, and objects, and most importantly brake operation to ensure safe operation of the vehicle under all road conditions. Your complete attention is always required while driving to maintain safe control of your vehicle. Failure to follow these warnings can result in a collision or serious personal injury.

Disabling And Enabling HSA

This feature can be turned on or turned off. To change the current setting, proceed as follows:

- If disabling HSA using your instrument cluster display, refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" for further information.
- If disabling HSA using Uconnect Settings, refer to "Uconnect Settings" in "Multimedia" for further information.

For vehicles not equipped with an instrument cluster display, perform the following steps:

- 1. Center the steering wheel (front wheels pointing straight forward).
- 2. Shift the transmission into PARK.
- 3. Apply the parking brake.
- 4. Start the engine.
- 5. Rotate the steering wheel slightly more than one-half turn to the left.
- 6. Push the "ESC Off" button located in the lower switch bank below the climate control four times within 20 seconds. The "ESC Off Indicator Light" should turn on and turn off two times.
- 7. Rotate the steering wheel back to center and then an additional slightly more than one-half turn to the right.
- 8. Turn the ignition to the OFF mode and then back to ON. If the sequence was completed properly, the "ESC Off Indicator Light" will blink several times to confirm HSA is disabled.
- 9. Repeat these steps if you want to return this feature to its previous setting.

Towing With HSA

HSA will also provide assistance to mitigate roll back while towing a trailer.

WARNING!

- If you use a trailer brake controller with your trailer, the trailer brakes may be activated and deactivated with the brake switch. If so, there may not be enough brake pressure to hold both the vehicle and the trailer on a hill when the brake pedal is released. In order to avoid rolling down an incline while resuming acceleration, manually activate the trailer brake or apply more vehicle brake pressure prior to releasing the brake pedal.
- HSA is not a parking brake. Always apply the parking brake fully when exiting your vehicle. Also, be certain to place the transmission in PARK.
- Failure to follow these warnings can result in a collision or serious personal injury.

Traction Control System (TCS)

pressure to the spinning wheel(s) and/or re-

duce engine power to provide enhanced ac-

celeration and stability. A feature of the TCS,

Brake Limited Differential (BLD), functions

similar to a limited slip differential and con-

trols the wheel spin across a driven axle. If

one wheel on a driven axle is spinning faster


than the other, the system will apply the

brake of the spinning wheel. This will allow

more engine torque to be applied to the wheel

that is not spinning. BLD may remain en-

abled even if TCS and FSC are in a reduced















Electronic Stability Control (ESC)

mode.



This system enhances directional control and stability of the vehicle under various driving conditions. ESC corrects for oversteering or understeering of the vehicle by applying the brake of the appropriate wheel(s) to assist in counteracting the oversteer or understeer condition. Engine power may also be reduced to help the vehicle maintain the desired path.







ESC uses sensors in the vehicle to determine the vehicle path intended by the driver and compares it to the actual path of the vehicle. When the actual path does not match the intended path, ESC applies the brake of the appropriate wheel to assist in counteracting the oversteer or understeer condition.

- Oversteer when the vehicle is turning more than appropriate for the steering wheel position.
- Understeer when the vehicle is turning less than appropriate for the steering wheel position.

The "ESC Activation/Malfunction Indicator Light" located in the instrument cluster will start to flash as soon as the ESC system becomes active. The "ESC Activation/Malfunction Indicator Light" also flashes when the TCS is active. If the "ESC Activation/Malfunction Indicator Light" begins to flash during acceleration, ease up on the accelerator and apply as little throttle as possible. Be sure to adapt your speed and driving to the prevailing road conditions.

WARNING!

- Electronic Stability Control (ESC) cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded by prevailing road conditions. ESC cannot prevent accidents, including those resulting from excessive speed in turns, driving on very slippery surfaces, or hydroplaning. ESC also cannot prevent accidents resulting from loss of vehicle control due to inappropriate driver input for the conditions. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ESC equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others
- Vehicle modifications, or failure to properly maintain your vehicle, may change
 the handling characteristics of your vehicle, and may negatively affect the performance of the ESC system. Changes to
 the steering system, suspension, brak-

WARNING!

ing system, tire type and size or wheel size may adversely affect ESC performance. Improperly inflated and unevenly worn tires may also degrade ESC performance. Any vehicle modification or poor vehicle maintenance that reduces the effectiveness of the ESC system can increase the risk of loss of vehicle control, vehicle rollover, personal injury and death.

ESC Operating Modes

NOTE:

Depending upon model and mode of operation, the ESC system may have multiple operating modes.

ESC On

This is the normal operating mode for the ESC. Whenever the vehicle is started, the ESC system will be in this mode. This mode

should be used for most driving conditions. Alternate ESC modes should only be used for specific reasons as noted in the following paragraphs.

Partial Off

The "Partial Off" mode is intended for times when a more spirited driving experience is desired. This mode may modify TCS and ESC thresholds for activation, which allows for more wheel spin than normally allowed. This mode may be useful if the vehicle becomes stuck.

To enter the "Partial Off" mode, momentarily push the "ESC Off" switch and the "ESC Off Indicator Light" will illuminate. To turn the ESC on again, momentarily push the "ESC Off" switch and the "ESC Off Indicator Light" will turn off.

NOTE:

For vehicles with multiple partial ESC modes a momentary button push will toggle the ESC mode. Multiple momentary button pushed may be required to return to ESC On.

WARNING!

- When in "Partial Off" mode, the TCS functionality of ESC, (except for the limited slip feature described in the TCS section), has been disabled and the "ESC Off Indicator Light" will be illuminated. When in "Partial Off" mode, the engine power reduction feature of TCS is disabled, and the enhanced vehicle stability offered by the ESC system is reduced.
- Trailer Sway control (TSC) is disabled when the ESC system is in the "Partial Off" mode.


Full Off — If Equipped

This mode is intended for off-highway or off-road use only and should not be used on any public roadways. In this mode, TCS and ESC features are turned OFF. To enter the "Full Off" mode, push and hold the "ESC Off" switch for five seconds while the vehicle is stopped with the engine running. After five seconds, a chime will sound, the "ESC Off Indicator Light" will illuminate, and the

"ESC OFF" message will display in the instrument cluster. To turn ESC ON again, momentarily push the "ESC Off" switch.









ESC modes may also be affected by drive modes if so equipped.



WARNING!



 In the ESC "Full Off" mode, the engine torque reduction and stability features are disabled. Therefore, enhanced vehicle stability offered by the ESC system is unavailable. In an emergency evasive maneuver, the ESC system will not engage to assist in maintaining stability. ESC "Full Off" mode is intended for off-highway or off-road use only.



With the ESC switched off, the enhanced vehicle stability offered by ESC is unavailable. In an emergency evasive





maneuver, the ESC system will not engage to assist in maintaining stability. ESC "Full Off" mode is only intended for off-highway or off-road use.

• The Electronic Stability Control (ESC) cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded by prevailing road conditions. ESC cannot prevent all accidents, including those resulting from excessive speed in turns, driving on very slippery surfaces, or hydroplaning. ESC also cannot prevent collisions.

ESC Activation/Malfunction Indicator Light And ESC OFF Indicator Light



The "ESC Activation/Malfunction Indicator Light" in the instrument cluster will come on when the ignition is turned to the ON mode. It should go out with the engine

running. If the "ESC Activation/Malfunction Indicator Light" comes on continuously with

the engine running, a malfunction has been detected in the ESC system. If this light remains on after several ignition cycles, and the vehicle has been driven several miles (kilometers) at speeds greater than 30 mph (48 km/h), see an authorized dealer as soon as possible to have the problem diagnosed and corrected.

The "ESC Activation/Malfunction Indicator Light" (located in the instrument cluster) starts to flash as soon as the tires lose traction and the ESC system becomes active. The "FSC Activation/Malfunction Indicator Light" also flashes when TCS is active. If the "ESC Activation/Malfunction Indicator Light" begins to flash during acceleration. ease up on the accelerator and apply as little throttle as possible. Be sure to adapt your speed and driving to the prevailing road conditions.

NOTE:

 The "ESC Activation/Malfunction Indicator Light" and the "ESC OFF Indicator Light" come on momentarily each time the ignition is turned ON.

- Each time the ignition is turned ON, the ESC system will be on even if it was turned off previously.
- The ESC system will make buzzing or clicking sounds when it is active. This is normal; the sounds will stop when ESC becomes inactive following the maneuver that caused the ESC activation.



The "ESC OFF Indicator Light" indicates the customer has elected to have the Electronic Stability Control (ESC) in a reduced mode.

Electronic Roll Mitigation (ERM)

This system anticipates the potential for wheel lift by monitoring the driver's steering wheel input and the speed of the vehicle. When ERM determines that the rate of change of the steering wheel angle and vehicle's speed are sufficient to potentially cause wheel lift, it then applies the appropriate brake and may also reduce engine power to lessen the chance that wheel lift will occur. ERM can only reduce the chance of wheel lift occurring during severe or evasive driving

maneuvers; it cannot prevent wheel lift due to other factors, such as road conditions, leaving the roadway, or striking objects or other vehicles.

NOTE:

ERM is disabled anytime the ESC is in "Full Off" mode (if equipped). Refer to "Electronic Stability Control (ESC)" in this section for a complete explanation of the available ESC modes.

WARNING!

Many factors, such as vehicle loading, road conditions and driving conditions, influence the chance that wheel lift or rollover may occur. ERM cannot prevent all wheel lift or roll overs, especially those that involve leaving the roadway or striking objects or other vehicles. The capabilities of an ERM-equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

Trailer Sway Control (TSC)

TSC uses sensors in the vehicle to recognize an excessively swaying trailer and will take the appropriate actions to attempt to stop the sway. TSC will become active automatically once an excessively swaying trailer is recognized.

NOTE:

TSC cannot stop all trailers from swaying. Always use caution when towing a trailer and follow the trailer tongue weight recommendations. Refer to "Trailer Towing" in "Starting And Operating" for further information.

When TSC is functioning, the "ESC Activation/Malfunction Indicator Light" will flash, the engine power may be reduced and you may feel the brakes being applied to individual wheels to attempt to stop the trailer from swaying. TSC is disabled when the ESC system is in the "Partial Off" or "Full Off" modes.

WARNING!



If TSC activates while driving, slow the vehicle down, stop at the nearest safe location, and adjust the trailer load to eliminate trailer sway.







Ready Alert Braking may reduce the time required to reach full braking during emergency braking situations. It anticipates when an emergency braking situation may occur by monitoring how fast the throttle is released by the driver. The EBC will prepare the brake system for a panic stop.



Rain Brake Support (RBS)



Rain Brake Support may improve braking performance in wet conditions. It will periodically apply a small amount of brake pressure to remove any water buildup on the front brake rotors. It functions when the windshield wipers are in LO or HI speed. When Rain Brake Support is active, there is no notification to the driver and no driver interaction is required.









Dynamic Steering Torque (DST)

Dynamic Steering Torque is a feature of the ESC and Electric Power Steering (EPS) modules that provides torque at the steering wheel for certain driving conditions in which the ESC module is detecting vehicle instability. The torque that the steering wheel receives is only meant to help the driver realize optimal steering behavior in order to reach/maintain vehicle stability. The only notification the driver receives that the feature is active is the torque applied to the steering wheel.

NOTE:

The DST feature is only meant to help the driver realize the correct course of action through small torques on the steering wheel, which means the effectiveness of the DST feature is highly dependent on the driver's sensitivity and overall reaction to the applied torque. It is very important to realize that this feature will not steer the vehicle, meaning the driver is still responsible for steering the vehicle.

Hill Descent Control (HDC) — If Equipped

HDC is intended for low speed off road driving while in 4WD Low Range. HDC maintains vehicle speed while descending hills during various driving situations. HDC controls vehicle speed by actively controlling the brakes.

HDC Has Three States:

- 1. Off (feature is not enabled and will not activate).
- Enabled (feature is enabled and ready but activation conditions are not met, or driver is actively overriding with brake or throttle application).
- 3. Active (feature is enabled and actively controlling vehicle speed).

Enabling HDC

HDC is enabled by pushing the HDC switch, but the following conditions must also be met to enable HDC:

- Driveline is in 4WD Low Range.
- Vehicle speed is below 5 mph (8 km/h).
- Parking brake is released.
- Driver door is closed.

Activating HDC

Once HDC is enabled it will activate automatically if driven down a grade of sufficient magnitude. The set speed for HDC is selectable by the driver, and can be adjusted by using the gear shift +/-. The following summarizes the HDC set speeds:

HDC Target Set Speeds

- P = No set speed. HDC may be enabled but will not activate.
- R = 0.6 mph (1 km/h)
- N = 1.2 mph (2 km/h)
- D = 0.6 mph (1 km/h)
- 1st = 0.6 mph (1 km/h)
- 2nd = 1.2 mph (2 km/h)
- 3rd = 1.8 mph (3 km/h)
- 4th = 2.5 mph (4 km/h)
- 5th = 3.1 mph (5 km/h)
- 6th = 3.7 mph (6 km/h)
- 7th = 4.3 mph (7 km/h)
- 8th = 5.0 mph (8 km/h)
- 9th = 5.6 mph (9 km/h) If Equipped

NOTE:

During HDC the +/- shifter input is used for HDC target speed selection, but will not affect the gear chosen by the transmission. When actively controlling HDC the transmission will shift appropriately for the driverselected set speed and corresponding driving conditions.

Driver Override

The driver may override HDC activation with throttle or brake application at anytime.

Deactivating HDC

HDC will be deactivated but remain available if any of the following conditions occur:

- Driver overrides HDC set speed with throttle or brake application.
- Vehicle speed exceeds 20 mph (32 km/h) but remains below 40 mph (64 km/h).
- · Vehicle is on a downhill grade of insufficient magnitude, is on level ground, or is on an uphill grade.
- Vehicle is shifted to park.

Disabling HDC

HDC will be deactivated and disabled if any of the following conditions occur:

- The driver pushes the HDC switch.
- The driveline is shifted out of 4WD Low Range.
- The parking brake is applied.
- Driver door opens.
- The vehicle is driven greater than 20 mph (32 km/h) for greater than 70 seconds.
- The vehicle is driven greater than 40 mph (64 km/h) (HDC exits immediately).
- HDC detects excessive brake temperature.

Feedback To The Driver

The instrument cluster has an HDC icon and the HDC switch has an LED icon, which offers feedback to the driver about the state HDC is in.

• The cluster icon and switch lamp will illuminate and remain on solid when HDC is enabled or activated. This is the normal operating condition for HDC.

- The cluster icon and switch lamp will flash for several seconds then extinguish when the driver pushes the HDC switch but enable conditions are not met.



• The cluster icon and switch lamp will flash for several seconds then extinguish when HDC disables due to excess speed.



• The cluster icon and switch lamp will flash when HDC deactivates due to overheated brakes. The flashing will stop and HDC will activate again once the brakes have cooled sufficiently.





WARNING!

HDC is only intended to assist the driver in controlling vehicle speed when descending hills. The driver must remain attentive to the driving conditions and is responsible for maintaining a safe vehicle speed.



Selec Speed Control (SSC) — If Equipped



SSC is intended for off road driving in 4WD Low Range only. SSC maintains vehicle speed by actively controlling engine torque and brakes.





SSC has three states:

- 1. Off (feature is not enabled and will not activate).
- Enabled (feature is enabled and ready but activation conditions are not met, or driver is actively overriding with brake or throttle application).
- 3. Active (feature is enabled and actively controlling vehicle speed).

Enabling SSC

SSC is enabled by pushing the SSC switch, but the following conditions must also be met to enable SSC:

- Driveline is in 4WD Low Range.
- Vehicle speed is below 5 mph (8 km/h).
- Parking brake is released.
- Driver door is closed.
- Driver is not applying throttle.

Activating SSC

Once SSC is enabled it will activate automatically once the following conditions are met:

• Driver releases throttle.

- · Driver releases brake.
- Transmission is in any selection other than P.
- Vehicle speed is below 20 mph (32 km/h).

The set speed for SSC is selectable by the driver, and can be adjusted by using the gear shift +/-. Additionally, the SSC set speed may be reduced when climbing a grade and the level of set speed reduction depends on the magnitude of grade. The following summarizes the SSC set speeds:

SSC Target Set Speeds

- 1st = .6 mph (1 km/h)
- 2nd = 1.2 mph (2 km/h)
- 3rd = 1.8 mph (3 km/h)
- 4th = 2.5 mph (4 km/h)
- 5th = 3.1 mph (5 km/h)
- 6th = 3.7 mph (6 km/h)
- 7th = 4.3 mph (7 km/h)
- 8th = 5 mph (8 km/h)
- 9th = 5.6 mph (9 km/h) If Equipped
- REVERSE = .6 mph (1 km/h)

- NEUTRAL = 1.2 mph (2 km/h)
- PARK = SSC remains enabled but not active

NOTE:

- During SSC the +/- shifter input is used for SSC target speed selection but will not affect the gear chosen by the transmission.
 While actively controlling SSC the transmission will shift appropriately for the driver-selected set speed and corresponding driving conditions.
- SSC performance is influenced by the Terrain Select mode. This difference may be notable to the driver and may be perceived as a varying level of aggressiveness.

Driver Override:

The driver may override SSC activation with throttle or brake application at any time.

Deactivating SSC

SSC will be deactivated but remain available if any of the following conditions occur:

• Driver overrides SSC set speed with throttle or brake application.

- Vehicle speed exceeds 20 mph (32 km/h) but remains below 40 mph (64 km/h).
- Vehicle is shifted to PARK.

Disabling SSC

SSC will deactivate and be disabled if any of the following conditions occur:

- The driver pushes the SSC switch.
- The driveline is shifted out of 4WD Low Range.
- The parking brake is applied.
- Driver door opens.
- The vehicle is driven greater than 20 mph (32 km/h) for greater than 70 seconds.
- The vehicle is driven greater than 40 mph (64 km/h) (SSC exits immediately).

Feedback To The Driver:

The instrument cluster has an SSC icon and the SSC switch has an LFD which offer feedback to the driver about the state SSC is in.

- The cluster icon and switch lamp will illuminate and remain on solid when SSC is enabled or activated. This is the normal operating condition for SSC.
- The cluster icon and switch lamp will flash for several seconds then extinguish when the driver pushes the SSC switch but enable conditions are not met.
- The cluster icon and switch lamp will flash for several seconds then extinguish when SSC disables due to excess speed.
- The cluster icon and switch lamp will flash then extinguish when SSC deactivates due to overheated brakes.

WARNING!

SSC is only intended to assist the driver in controlling vehicle speed when driving in off road conditions. The driver must remain attentive to the driving conditions and is responsible for maintaining a safe vehicle speed.

AUXILIARY DRIVING SYSTEMS







The Blind Spot Monitoring (BSM) system uses two radar-based sensors, located inside the rear bumper fascia, to detect highway licensable vehicles (automobiles, trucks, motorcycles etc.) that enter the blind spot zones from the rear/front/side of the vehicle.

approximately 10 ft (3 m) beyond the rear

bumper of the vehicle. The BSM system


monitors the detection zones on both sides of

the vehicle when the vehicle speed reaches

approximately 6 mph (10 km/h) or higher and

will alert the driver of vehicles in these areas.





vehicle 12 ft (3.8 m). The zone length starts at the outside rear view mirror and extends
















Rear Detection Zones

When the vehicle is started, the BSM warning light will momentarily illuminate in both outside rear view mirrors to let the driver know that the system is operational. The BSM system sensors operate when the vehicle is in any forward gear or REVERSE and enters stand by mode when the vehicle is in PARK.

The BSM warning light, located in the outside mirrors, will illuminate if a vehicle moves into a blind spot zone.



BSM Warning Light

The BSM system can also be configured to sound an audible (chime) alert and mute the radio to notify you of objects that have entered the detection zones.

Rear Cross Path (RCP)

The Rear Cross Path (RCP) feature is intended to aid the driver when backing out of parking spaces where the vision of oncoming vehicles may be blocked. Proceed slowly and cautiously out of the parking space until the rear end of the vehicle is exposed. The RCP system will then have a clear view of the cross

traffic and if an oncoming vehicle is detected, will alert the driver. When RCP is on and the vehicle is in REVERSE, the driver is alerted using both the visual and audible alarms, including reducing the radio volume.

Refer to "Blind Spot Monitoring" in "Safety" in the Owner's Manual for further information.

Modes Of Operation

Three selectable modes of operation are available in the Uconnect System. Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further details.

Blind Spot Alert Lights Only

When operating in Blind Spot Alert mode, the BSM system will provide a visual alert in the appropriate side view mirror based on a detected object. However, when the system is operating in Rear Cross Path (RCP) mode, the system will respond with both visual and audible alerts when a detected object is present. Whenever an audible alert is requested, the radio is muted.

Blind Spot Alert Lights/Chime

When operating in Blind Spot Alert Lights/ Chime mode, the BSM system will provide a visual alert in the appropriate side view mirror based on a detected object. If the turn signal is then activated, and it corresponds to an alert present on that side of the vehicle, an audible chime will also be sounded. Whenever a turn signal and detected object are present on the same side at the same time. both the visual and audible alerts will be issued. In addition to the audible alert, the radio (if on) will also be muted.

NOTE:

Whenever an audible alert is requested by the BSM system, the radio is also muted.

When the system is in RCP, the system shall respond with both visual and audible alerts when a detected object is present. Whenever an audible alert is requested, the radio is also muted. Turn/hazard signal status is ignored; the RCP state always requests the chime.

Blind Spot Alert Off

When the BSM system is turned off, there will be no visual or audible alerts from either the BSM or RCP systems.

NOTE:

The BSM system will store the current operating mode when the vehicle is shut off. Each time the vehicle is started the previously stored mode will be recalled and used.

Forward Collision Warning (FCW)

The Forward Collision Warning (FCW) system provides the driver with audible and visual warnings within the instrument cluster display to warn the driver when it detects a potential frontal collision. The warnings are intended to provide the driver with enough time to react. avoid or mitigate the potential collision.

NOTE:

FCW monitors the information from the forward looking sensors, as well as the Electronic Brake Controller (EBC), to calculate the probability of a forward collision. When the system determines that a forward collision is probable, the driver will be provided with audible and visual warnings.

Turning FCW On Or Off



The FCW button is located on the switch panel below the Uconnect display.



• To turn the FCW system off, push the forward collision button once to turn the system OFF.



• To turn the FCW system back on, push the forward collision button again to turn the system on.



NOTE:




• The default status of FCW is "on", this allows the system to warn you of a possible collision with the vehicle in front of you.



 Changing the FCW status to "off" prevents the system from warning you of a possible collision with the vehicle in front of you. If FCW is set to off, "FCW OFF" will appear in the instrument cluster display.








Changing FCW Status

The FCW feature has two settings and can be changed within the Uconnect System Screen:









Far

The far setting provides warnings for potential collisions more distant in front of the vehicle, allowing the driver to have the most reaction time to avoid a collision.

More cautious drivers that do not mind frequent warnings may prefer this setting.

NOTE:

This setting gives you the most reaction time.

Near

Changing the FCW status to the "Near" setting, allows the system to warn you of a potential frontal collision when you are much closer.

This setting provides less reaction time than the "Far" setting, which allows for a more dynamic driving experience.

More dynamic or aggressive drivers that want to avoid frequent warnings may prefer this setting.

NOTE:

Changing the Active Braking status to off prevents the system from providing autonomous braking, or additional brake support if the driver is not braking adequately in the event of a potential frontal collision. Active braking can be turned off in the Uconnect controls settings.

Refer to your Owner's Manual for further information.

WARNING!

Forward Collision Warning (FCW) is not intended to avoid a collision on its own, nor can FCW detect every type of potential collision. The driver has the responsibility to avoid a collision by controlling the vehicle via braking and steering. Failure to follow this warning could lead to serious injury or death.

Tire Pressure Monitor System (TPMS)

The Tire Pressure Monitor System (TPMS) will warn the driver of a low tire pressure based on the vehicle recommended cold placard pressure.

The tire pressure will vary with temperature by approximately 1 psi (7 kPa) for every 12°F (6.5°C). This means that when the outside temperature decreases, the tire pressure will decrease. Tire pressure should always be set based on cold inflation tire pressure. This is defined as the tire pressure after the vehicle has not been driven for at least three hours, or driven less than 1 mile (1.6 km) after a three hour period. The cold tire inflation pressure must not exceed the maximum inflation pressure molded into the tire sidewall. Refer to "Tires" in "Servicing And Maintenance" for information on how to properly inflate the vehicle's tires. The tire pressure will also increase as the vehicle is driven. This is normal and there should be no adjustment for this increased pressure.

The TPMS will warn the driver of a low tire pressure if the tire pressure falls below the low-pressure warning limit for any reason, including low temperature effects and natural pressure loss through the tire.

The TPMS will continue to warn the driver of low tire pressure as long as the condition exists, and will not turn off until the tire pressure is at or above the recommended cold placard pressure. Once the low tire pressure warning (Tire Pressure Monitoring Telltale Light) illuminates, you must increase the tire pressure to the recommended cold placard pressure in order for the "Tire Pressure Monitoring Telltale Light" to turn off.

NOTE:

When filling warm tires, the tire pressure may need to be increased up to an additional 4 psi (28 kPa) above the recommended cold placard pressure in order to turn the Tire Pressure Monitoring Telltale Light off.


The system will automatically update and the "Tire Pressure Monitoring Telltale Light" will turn off once the system receives the updated

tire pressures. The vehicle may need to be driven for up to 10 minutes above 15 mph (24 km/h) in order for the TPMS to receive this information.

For example, your vehicle may have a recommended cold (parked for more than three hours) placard pressure of 33 psi (227 kPa). If the ambient temperature is 68°F (20°C) and the measured tire pressure is 28 psi (193 kPa), a temperature drop to 20°F (-7°C) will decrease the tire pressure to approximately 24 psi (165 kPa). This tire pressure is low enough to turn ON the "Tire Pressure Monitoring Telltale Light." Driving the vehicle may cause the tire pressure to rise to approximately 28 psi (193 kPa), but the "Tire Pressure Monitoring Telltale Light" will still be on. In this situation, the "Tire Pressure Monitoring Telltale Light" will turn off only after the tires are inflated to the vehicle's recommended cold placard pressure value.

NOTE:

tion.











• The TPMS has been optimized for the

original equipment tires and wheels.

TPMS pressures and warning have been

established for the tire size equipped on

your vehicle. Undesirable system opera-

tion or sensor damage may result when

using replacement equipment that is not of the same size, type, and/or style. The

TPM sensor is not designed for use on

aftermarket wheels, and may contribute

to a poor overall system performance.

Customers are encouraged to use OEM

wheels to assure TPMS feature opera-

• Using aftermarket tire sealants may

cause the Tire Pressure Monitoring Sys-

tem (TPMS) sensor to become inoper-

able. After using an aftermarket tire



















need to be increased up to an additional 4 psi (28 kPa) above the recommended cold placard pressure in order to turn the Tire Pressure

CAUTION!

sealant it is recommended that you take your vehicle to an authorized dealer to have your sensor function checked.

 After inspecting or adjusting the tire pressure always reinstall the valve stem cap. This will prevent moisture and dirt from entering the valve stem, which could damage the TPMS sensor.

NOTE:

- The TPMS is not intended to replace normal tire care and maintenance, or to provide warning of a tire failure or condition.
- The TPMS should not be used as a tire pressure gauge while adjusting your tire pressure.
- Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.
- The TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure

- using an accurate tire pressure gauge, even if underinflation has not reached the level to trigger illumination of the "Tire Pressure Monitoring Telltale Light".
- Seasonal temperature changes will affect tire pressure, and the TPMS will monitor the actual tire pressure in the tire.

Premium System

The Tire Pressure Monitor System (TPMS) uses wireless technology with wheel rim mounted electronic sensors to monitor tire pressure levels. Sensors, mounted to each wheel as part of the valve stem, transmit tire pressure readings to the receiver module.

NOTE:

It is particularly important for you to check the tire pressure in all of the tires on your vehicle monthly and to maintain the proper pressure.

The TPMS consists of the following components:

- Receiver module
- Four tire pressure monitoring sensors

- Various tire pressure monitoring system messages, which display in the instrument cluster
- Tire Pressure Monitoring System Warning Light

Tire Pressure Monitoring Low Pressure Warnings



The "Tire Pressure Monitoring Telltale Light" will illuminate in the instrument cluster and a chime will sound when tire pressure is low in one or more of the

four active road tires. In addition, the instrument cluster will display a "Tire Low" message for a minimum of five seconds and a graphic showing the pressure values of each tire with the low tire pressure values in a different color.



Tire Pressure Monitoring Low Pressure Warning

Should this occur, you should stop as soon as possible and inflate the tires with low pressure (those in a different color in the instrument cluster graphic) to the vehicle's recommended cold placard pressure value. Once the system receives the updated tire pressures, the system will automatically update, the pressure values in the graphic display in the instrument cluster will return to their original color, and the "Tire Pressure Monitoring Telltale Light" will turn off.

NOTE:

When filling warm tires, the tire pressure may need to be increased up to an additional 4 psi (28 kPa) above the recommended cold placard pressure in order to turn the Tire Pressure Monitoring Telltale Light off. The vehicle may need to be driven for up to 10 minutes above 15 mph (24 km/h) in order for the TPMS to receive this information.

Service TPMS Warning

When a system fault is detected, the "Tire Pressure Monitoring Telltale Light" will flash on and off for 75 seconds and then remain on solid. The system fault will also sound a chime. In addition, the instrument cluster will display a "SERVICE TPM SYSTEM" message for a minimum of five seconds and then display dashes (- -) in place of the pressure value to indicate which sensor is not being received.

If the ignition key is cycled, this sequence will repeat, providing the system fault still exists. If the system fault no longer exists, the "Tire Pressure Monitoring Telltale Light" will no longer flash, and the "SERVICE TPM SYS-

TEM" message will no longer display, and a pressure value will display in place of the dashes. A system fault can occur due to any of the following:





 Jamming due to electronic devices or driving next to facilities emitting the same radio frequencies as the TPMS sensors.



 Installing some form of aftermarket window tinting that affects radio wave signals.



 Lots of snow or ice around the wheels or wheel housings.



• Using tire chains on the vehicle.



• Using wheels/tires not equipped with TPMS sensors.

Vehicles With Compact Spare or Non-Matching Full Size Spare



 The compact spare tire or non-matching full size does not have a tire pressure monitoring sensor. Therefore, the TPMS will not monitor the pressure in the compact spare tire.



2. If you install the compact or nonmatching full size spare tire in place of a road tire that has a pressure below the low-pressure warning limit, upon the next







ignition key cycle, the "TPMS Telltale Light" will remain on and a chime will sound. In addition, the graphic in the instrument cluster will still display a different color pressure value.

- 3. After driving the vehicle for up to 10 minutes above 15 mph (24 km/h), the "TPMS Telltale Light" will flash on and off for 75 seconds and then remain on solid. In addition, the instrument cluster will display a "Service Tire Pressure System" message for five seconds and then display dashes (- -) in place of the pressure value.
- 4. For each subsequent ignition key cycle, a chime will sound, the "TPMS Telltale Light" will flash on and off for 75 seconds and then remain on solid, and the instrument cluster will display a "SERVICE TPM SYSTEM" message for five seconds and then display dashes (- -) in place of the pressure value.
- 5. Once you repair or replace the original road tire and reinstall it on the vehicle in place of the compact spare or non-matching full size, the TPMS will update automatically. In addition, the "TPMS

Telltale Light" will turn off and the graphic in the instrument cluster will display a new pressure value instead of dashes (--), as long as no tire pressure is below the low-pressure warning limit in any of the four active road tires. The vehicle may need to be driven for up to 10 minutes above 15 mph (24 km/h) in order for the TPMS to receive this information.

TPMS Deactivation — If Equipped

The TPMS can be deactivated if replacing all four wheel and tire assemblies (road tires) with wheel and tire assemblies that do not have TPMS Sensors, such as when installing winter wheel and tire assemblies on your vehicle.

To deactivate the TPMS, first replace all four wheel and tire assemblies (road tires) with tires not equipped with Tire Pressure Monitoring (TPM) Sensors. Then, drive the vehicle for 10 minutes above 15 mph (24 km/h). The TPMS will chime, the "TPM Telltale Light" will flash on and off for 75 seconds and then

remain on. The instrument cluster will display the "SERVICE TPM SYSTEM" message and then display dashes (--) in place of the pressure values.

Beginning with the next ignition cycle, the TPMS will no longer chime or display the "SERVICE TPM SYSTEM" message in the instrument cluster but dashes (--) will remain in place of the pressure values.

To reactivate the TPMS, replace all four wheel and tire assemblies (road tires) with tires equipped with TPM sensors. Then, drive the vehicle for up to 10 minutes above 15 mph (24 km/h). The TPMS will chime, the "TPM Telltale Light" will flash on and off for 75 seconds and then turn off. The instrument cluster will display the "SERVICE TPM SYSTEM" message and then display pressure values in place of the dashes. On the next ignition cycle the "SERVICE TPM SYSTEM" message will no longer be displayed as long as no system fault exists.

OCCUPANT RESTRAINT SYSTEMS

Some of the most important safety features in your vehicle are the restraint systems:

Occupant Restraint Systems Features

- · Seat Belt Systems
- Supplemental Restraint Systems (SRS) Air Bags
- Child Restraints

Some of the safety features described in this section may be standard equipment on some models, or may be optional equipment on others. If you are not sure, ask your authorized dealer.

Important Safety Precautions

Please pay close attention to the information in this section. It tells you how to use your restraint system properly, to keep you and your passengers as safe as possible.

Here are some simple steps you can take to minimize the risk of harm from a deploying air bag:

1. Children 12 years old and under should always ride buckled up in the rear seat of a vehicle with a rear seat.




Warning Label On Front Passenger Sun Visor

2. If a child from 2 to 12 years old (not in a rear-facing child restraint) must ride in the front passenger seat, move the seat as far back as possible and use the proper child restraint (refer to "Child Restraints" in this section for further information).

- 3. Children that are not big enough to wear seat of a vehicle with a rear seat.
 - the vehicle seat belt properly (refer to "Child Restraints" in this section for further information) should be secured in the rear seat of a vehicle with a rear seat in child restraints or belt-positioning booster seats. Older children who do not use child restraints or belt-positioning booster seats should ride properly buckled up in the rear









5. You should read the instructions provided with your child restraint to make sure that you are using it properly.



6. All occupants should always wear their lap and shoulder belts properly.



7. The driver and front passenger seats should be moved back as far as practical to allow the front air bags room to inflate.



8. Do not lean against the door or window. If your vehicle has side air bags, and deployment occurs, the side air bags will inflate forcefully into the space between occupants and the door and occupants could be injured.







 If the air bag system in this vehicle needs to be modified to accommodate a disabled person, refer to the "Customer Assistance" section for customer service contact information.

WARNING!

- NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERI-OUS INJURY to the CHILD can occur.
- Only use a rear-facing child restraint in the rear seat of a vehicle with a rear seat.
- A deploying passenger front air bag can cause death or serious injury to a child 12 years or younger, including a child in a rear-facing child restraint.

Seat Belt Systems

Buckle up even though you are an excellent driver, even on short trips. Someone on the road may be a poor driver and could cause a collision that includes you. This can happen far away from home or on your own street. Research has shown that seat belts save lives, and they can reduce the seriousness of injuries in a collision. Some of the worst injuries happen when people are thrown from the vehicle. Seat belts reduce the possibility of ejection and the risk of injury caused by striking the inside of the vehicle. Everyone in a motor vehicle should be belted at all times.

Enhanced Seat Belt Use Reminder System (BeltAlert)

Front And Rear Seat BeltAlert (If Equipped)

Front Seat BeltAlert

A BeltAlert is a feature intended to remind the driver and outboard front seat passenger to buckle their seat belts. The BeltAlert feature is active whenever the ignition switch is in the START or ON/RUN position.

Initial Indication

If the driver is unbuckled when the ignition switch is first in the START or ON/RUN position a chime will signal for a few seconds. If the driver or outboard front seat passenger is unbuckled when the ignition switch is first in the START or ON/RUN position the respec-

tive Seat Belt Reminder Light will turn solid red and remain red until the seat belt is buckled. The respective Seat Belt Reminder Light will turn solid green once the seat belt is buckled. After the driver and outboard front seat passenger have buckled their seat belts all Seat Belt Reminder Lights will turn off. The outboard front passenger seat BeltAlert is not active when the outboard front passenger seat is unoccupied.

BeltAlert Warning Sequence

The BeltAlert warning sequence is activated when the vehicle is moving above a specified vehicle speed range and the driver or outboard front seat passenger is unbuckled (the outboard front passenger seat BeltAlert is not active when the outboard front passenger seat is unoccupied). The BeltAlert warning sequence starts by blinking the respective Seat Belt Reminder Light and sounding an intermittent chime. Once the BeltAlert warning sequence has completed, the Seat Belt Reminder Light will remain solid red until the driver and outboard front seat passenger are buckled. The BeltAlert warning sequence may repeat based on vehicle speed until the

driver and occupied outboard front seat passenger seat belts are buckled. The driver should instruct all occupants to buckle their seat belts.

Change Of Status

If the driver or outboard front seat passenger unbuckles their seat belt while the vehicle is traveling, the BeltAlert warning sequence will begin until the seat belts are buckled again.

The outboard front passenger seat BeltAlert is not active when the outboard front passenger seat is unoccupied. BeltAlert may be triggered when an animal or other items are placed on the outboard front passenger seat or when the seat is folded flat (if equipped). It is recommended that pets be restrained in the rear seat (if equipped) in pet harnesses or pet carriers that are secured by seat belts. and cargo is properly stowed.

Rear Seat BeltAlert

Rear Seat BeltAlert shows the driver whether the seat belts in the rear seat are buckled or unbuckled. When the ignition switch is in the START or ON/RUN position, a Seat Belt Reminder Light turns on for each rear seat position. If a seat belt is buckled, the Seat Belt Reminder Light for that position will illuminate solid green. If a seat belt is unbuckled, the Seat Belt Reminder Light will illuminate red. If a rear passenger unbuckles a seat belt that was buckled at the start of the trip, a single chime will sound and the Seat Belt Reminder Light for that position will change from solid green to blinking red. This will alert the driver to stop the vehicle until the rear passenger buckles the seat belt again. After the driver and outboard front seat passenger have buckled their seat belts all Seat Belt Reminder Lights will turn off.

BeltAlert can be activated or deactivated by vour authorized dealer. FCA US LLC does not recommend deactivating BeltAlert.

NOTE:

If BeltAlert has been deactivated, the Seat Belt Reminder Light will turn on and remain on until the driver and outboard front seat passenger seat belts are buckled.

Lap/Shoulder Belts

All seating positions in your vehicle are equipped with lap/shoulder belts.

The seat belt webbing retractor will lock only during very sudden stops or collisions. This feature allows the shoulder part of the seat belt to move freely with you under normal conditions. However, in a collision the seat belt will lock and reduce your risk of striking the inside of the vehicle or being thrown out of the vehicle.







WARNING!

wear your seat belt even though you have

• In a collision, you and your passengers

can suffer much greater injuries if you

are not properly buckled up. You can

strike the interior of your vehicle or other


passengers, or you can be thrown out of

the vehicle. Always be sure you and

others in your vehicle are buckled up

air bags.

properly.

















- It is dangerous to ride in a cargo area, inside or outside of a vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed.
- Do not allow people to ride in any area of your vehicle that is not equipped with seats and seat helts.
- Be sure everyone in your vehicle is in a seat and using a seat belt properly. Occupants, including the driver, should always wear their seat belts whether or not an air bag is also provided at their seating position to minimize the risk of severe injury or death in the event of a crash.
- Wearing your seat belt incorrectly could make your injuries in a collision much worse. You might suffer internal injuries, or you could even slide out of the seat belt. Follow these instructions to wear your seat belt safely and to keep your passengers safe, too.
- Two people should never be belted into a single seat belt. People belted together

WARNING!

can crash into one another in a collision, hurting one another badly. Never use a lap/shoulder belt or a lap belt for more than one person, no matter what their size.

WARNING!

- A lap belt worn too high can increase the risk of injury in a collision. The seat belt forces won't be at the strong hip and pelvic bones, but across your abdomen. Always wear the lap part of your seat belt as low as possible and keep it snug.
- A twisted seat belt may not protect you properly. In a collision, it could even cut into you. Be sure the seat belt is flat against your body, without twists. If you can't straighten a seat belt in your vehicle, take it to your authorized dealer immediately and have it fixed.
- A seat belt that is buckled into the wrong buckle will not protect you properly. The lap portion could ride too high on your body, possibly causing internal injuries.

WARNING!

Always buckle your seat belt into the buckle nearest you.

- A seat belt that is too loose will not protect you properly. In a sudden stop, you could move too far forward, increasing the possibility of injury. Wear your seat belt snugly.
- A seat belt that is worn under your arm is dangerous. Your body could strike the inside surfaces of the vehicle in a collision, increasing head and neck injury. A seat belt worn under the arm can cause internal injuries. Ribs aren't as strong as shoulder bones. Wear the seat belt over your shoulder so that your strongest bones will take the force in a collision.
- A shoulder belt placed behind you will not protect you from injury during a collision. You are more likely to hit your head in a collision if you do not wear your shoulder belt. The lap and shoulder belt are meant to be used together.
- A frayed or torn seat belt could rip apart in a collision and leave you with no protection. Inspect the seat belt system

periodically, checking for cuts, frays, or loose parts. Damaged parts must be replaced immediately. Do not disassemble or modify the seat belt system. Seat belt assemblies must be replaced after a collision.

Lap/Shoulder Belt Operating Instructions


- 1. Enter the vehicle and close the door. Sit back and adjust the seat.
- 2. The seat belt latch plate is above the back of the front seat, and next to your arm in the rear seat (for vehicles equipped with a rear seat). Grasp the latch plate and pull out the seat belt. Slide the latch plate up the webbing as far as necessary to allow the seat belt to go around your lap.





Pulling Out The Latch Plate

- 1 Seat Belt Latch Plate
- 2 Seat Belt Buckle
- 3. When the seat belt is long enough to fit. insert the latch plate into the buckle until you hear a "click."































- 5. Position the shoulder belt across the shoulder and chest with minimal, if any slack so that it is comfortable and not resting on your neck. The retractor will withdraw any slack in the shoulder belt.
- 6. To release the seat belt, push the red button on the buckle. The seat belt will automatically retract to its stowed position. If necessary, slide the latch plate down the webbing to allow the seat belt to retract fully.

Lap/Shoulder Belt Untwisting Procedure

Use the following procedure to untwist a twisted lap/shoulder belt.

- 1. Position the latch plate as close as possible to the anchor point.
- 2. At about 6 to 12 inches (15 to 30 cm) above the latch plate, grasp and twist the seat belt webbing 180 degrees to create a fold that begins immediately above the latch plate.
- 3. Slide the latch plate upward over the folded webbing. The folded webbing must enter the slot at the top of the latch plate.

 Continue to slide the latch plate up until it clears the folded webbing and the seat belt is no longer twisted.

Adjustable Upper Shoulder Belt Anchorage

In the driver and front passenger seats, the top of the shoulder belt can be adjusted upward or downward to position the seat belt away from your neck. Push or squeeze the anchorage button to release the anchorage, and move it up or down to the position that serves you best.



Adjustable Anchorage

As a guide, if you are shorter than average, you will prefer the shoulder belt anchorage in a lower position, and if you are taller than average, you will prefer the shoulder belt anchorage in a higher position. After you release the anchorage button, try to move it up or down to make sure that it is locked in position.

NOTE:

The adjustable upper shoulder belt anchorage is equipped with an Easy Up feature. This feature allows the shoulder belt anchorage to be adjusted in the upward position without pushing or squeezing the release button. To verify the shoulder belt anchorage is latched, pull downward on the shoulder belt anchorage until it is locked into position.

WARNING!

 Wearing your seat belt incorrectly could make your injuries in a collision much worse. You might suffer internal injuries, or you could even slide out of the seat belt. Follow these instructions to wear

your seat belt safely and to keep your passengers safe, too.

- Position the shoulder belt across the shoulder and chest with minimal, if any slack so that it is comfortable and not resting on your neck. The retractor will withdraw any slack in the shoulder belt.
- · Misadiustment of the seat belt could reduce the effectiveness of the safety belt in a crash.

Seat Belts And Pregnant Women



Pregnant Women And Seat Belts

Seat belts must be worn by all occupants including pregnant women: the risk of injury in the event of an accident is reduced for the mother and the unborn child if they are wearing a seat belt.

Position the lap belt snug and low below the abdomen and across the strong bones of the hips. Place the shoulder belt across the chest and away from the neck. Never place the shoulder belt behind the back or under the arm.

Seat Belt Pretensioner

The front seat belt system is equipped with pretensioning devices that are designed to remove slack from the seat belt in the event of a collision. These devices may improve the performance of the seat belt by removing slack from the seat belt early in a collision. Pretensioners work for all size occupants, including those in child restraints.

NOTE:

These devices are not a substitute for proper seat belt placement by the occupant. The seat belt still must be worn snugly and positioned properly.

The pretensioners are triggered by the Occupant Restraint Controller (ORC). Like the air bags, the pretensioners are single use items. A deployed pretensioner or a deployed air bag must be replaced immediately.

a collision. The seat belt system has a retrac-

tor assembly that is designed to release web-

Switchable Automatic Locking Retractors

additional information, refer to "Installing

Child Restraints Using The Vehicle Seat

Belt" under the "Child Restraints" section of

this manual. The figure below illustrates the

locking feature for each seating position.

Energy Management Feature


bing in a controlled manner.

(ALR) — If Equipped
































ALR — Switchable Automatic Locking Retractor

If the passenger seating position is equipped with an ALR and is being used for normal usage, only pull the seat belt webbing out far enough to comfortably wrap around the occupant's mid-section so as to not activate the ALR. If the ALR is activated, you will hear a clicking sound as the seat belt retracts. Allow the webbing to retract completely in this case and then carefully pull out only the amount of webbing necessary to comfortably wrap around the occupant's mid-section. Slide the latch plate into the buckle until you hear a "click."

In Automatic Locking Mode, the shoulder belt is automatically pre-locked. The seat belt will still retract to remove any slack in the shoulder belt. Use the Automatic Locking Mode anytime a child restraint is installed in a seating position that has a seat belt with this feature. Children 12 years old and under should always be properly restrained in the rear seat of a vehicle with a rear seat.

WARNING!

- NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.
- Only use a rear-facing child restraint in the rear seat of a vehicle with a rear seat.
- A deploying passenger front air bag can cause death or serious injury to a child 12 years or younger, including a child in a rear-facing child restraint.

How To Engage The Automatic Locking Mode

 Buckle the combination lap and shoulder belt.

- 2. Grasp the shoulder portion and pull downward until the entire seat belt is extracted.
- Allow the seat belt to retract. As the seat belt retracts, you will hear a clicking sound. This indicates the seat belt is now in the Automatic Locking Mode.

How To Disengage The Automatic Locking Mode

Unbuckle the combination lap/shoulder belt and allow it to retract completely to disengage the Automatic Locking Mode and activate the vehicle sensitive (emergency) locking mode.

WARNING!

- The seat belt assembly must be replaced if the switchable Automatic Locking Retractor (ALR) feature or any other seat belt function is not working properly when checked according to the procedures in the Service Manual.
- Failure to replace the seat belt assembly could increase the risk of injury in collisions.
- Do not use the Automatic Locking Mode to restrain occupants who are wearing

the seat belt or children who are using booster seats. The locked mode is only used to install rear-facing or forwardfacing child restraints that have a harness for restraining the child.

Supplemental Restraint Systems (SRS)

Some of the safety features described in this section may be standard equipment on some models, or may be optional equipment on others. If you are not sure, ask your authorized dealer.

The air bag system must be ready to protect you in a collision. The Occupant Restraint Controller (ORC) monitors the internal circuits and interconnecting wiring associated with the electrical Air Bag System Components. Your vehicle may be equipped with the following Air Bag System Components:

Air Bag System Components

- Occupant Restraint Controller (ORC)
- Air Bag Warning Light
- Steering Wheel and Column

- Instrument Panel
- Knee Impact Bolsters
- Driver and Front Passenger Air Bags
- Seat Belt Buckle Switch
- Supplemental Side Air Bags
- Supplemental Knee Air Bags
- Front and Side Impact Sensors
- Seat Belt Pretensioners

Air Bag Warning Light

The ORC monitors the readiness of the electronic parts of the air bag system whenever the ignition switch is in the START or ON/RUN position. If the ignition switch is in the OFF position or in the ACC position, the air bag system is not on and the air bags will not inflate.

The ORC contains a backup power supply system that may deploy the air bag system even if the battery loses power or it becomes disconnected prior to deployment.

The ORC turns on the Air Bag Warning Light in the instrument panel for approximately four to eight seconds for a self-check when

the ignition switch is first in the ON/RUN position. After the self-check, the Air Bag Warning Light will turn off. If the ORC detects a malfunction in any part of the system, it turns on the Air Bag Warning Light, either momentarily or continuously. A single chime will sound to alert you if the light comes on again after initial startup.

The ORC also includes diagnostics that will

Warning Light if a malfunction is detected

that could affect the air bag system. The

diagnostics also record the nature of the

malfunction. While the air bag system is

designed to be maintenance free, if any of the


following occurs, have an authorized dealer

service the air bag system immediately.

position.





























• The Air Bag Warning Light comes on intermittently or remains on while driving.

• The Air Bag Warning Light remains on after

the four to eight-second interval.

NOTE:

If the speedometer, tachometer, or any engine related gauges are not working, the Occupant Restraint Controller (ORC) may also be disabled. In this condition the air bags may not be ready to inflate for your protection. Have an authorized dealer service the air bag system immediately.

WARNING!

Ignoring the Air Bag Warning Light in your instrument panel could mean you won't have the air bag system to protect you in a collision. If the light does not come on as a bulb check when the ignition is first turned on, stays on after you start the vehicle, or if it comes on as you drive, have an authorized dealer service the air bag system immediately.

Redundant Air Bag Warning Light

If a fault with the Air Bag Warning Light is detected, which could affect the Supplemental Restraint System (SRS), the Redundant Air Bag Warning Light will illuminate on the

instrument panel. The Redundant Air Bag Warning Light will stay on until the fault is cleared. In addition, a single chime will sound to alert you that the Redundant Air Bag Warning Light has come on and a fault has been detected. If the Redundant Air Bag Warning Light comes on intermittently or remains on while driving have an authorized dealer service the vehicle immediately. For additional information regarding the Redundant Air Bag Warning Light refer to "Getting To Know Your Instrument Panel" section of this manual.

Front Air Bags

This vehicle has front air bags and lap/ shoulder belts for both the driver and front passenger. The front air bags are a supplement to the seat belt restraint systems. The driver front air bag is mounted in the center of the steering wheel. The passenger front air bag is mounted in the instrument panel, above the glove compartment. The words "SRS AIRBAG" or "AIRBAG" are embossed on the air bag covers.



Front Air Bag/Knee Impact Bolster Locations

1 — Driver And Passenger Front Air Bags

2 — Supplemental Driver Knee Air Bag/Driver Knee Impact Bolster

3 — Passenger Knee Impact Bolster

- Being too close to the steering wheel or instrument panel during front air bag deployment could cause serious injury, including death. Air bags need room to inflate. Sit back, comfortably extending your arms to reach the steering wheel or instrument panel.
- Never place a rear-facing child restraint in front of an air bag. A deploying passenger front air bag can cause death or serious injury to a child 12 years or younger, including a child in a rearfacing child restraint.
- Only use a rear-facing child restraint in the rear seat of a vehicle with a rear seat.

Driver And Passenger Front Air Bag Features

The front air bag system is designed to inflate based on the severity and type of collision as determined by the Occupant Restraint Controller (ORC), which may receive information from the front impact sensors (if equipped) or other system components. The driver front air bag system has a single stage air bag. The passenger front air bag system has a multi-

stage front air bag. The first stage inflator is triggered immediately during an impact that requires air bag deployment. For the multistage air bag, a low energy output is used in less severe collisions. A higher energy output is used for more severe collisions.


This vehicle may be equipped with a driver and/or front passenger seat belt buckle switch that detects whether the driver or front passenger seat belt is buckled. The seat belt buckle switch may adjust the inflation rate of the passenger multistage Front Air Bag.

WARNING!

- No objects should be placed over or near the air bag on the instrument panel or steering wheel because any such objects could cause harm if the vehicle is in a collision severe enough to cause the air bag to inflate.
- Do not put anything on or around the air bag covers or attempt to open them manually. You may damage the air bags and you could be injured because the air bags may no longer be functional. The

WARNING!







 Relying on the air bags alone could lead to more severe injuries in a collision. The air bags work with your seat belt to restrain you properly. In some collisions, air bags won't deploy at all. Always wear your seat belts even though you have air bags.





Front Air Bag Operation



Front Air Bags are designed to provide additional protection by supplementing the seat belts. Front air bags are not expected to reduce the risk of injury in rear, side, or rollover collisions. The front air bags will not deploy in all frontal collisions, including some that may produce substantial vehicle damage — for example, some pole collisions, truck underrides, and angle offset collisions.









On the other hand, depending on the type and location of impact, front air bags may deploy in crashes with little vehicle front-end damage but that produce a severe initial deceleration.

Because air bag sensors measure vehicle deceleration over time, vehicle speed and damage by themselves are not good indicators of whether or not an air bag should have deployed.

Seat belts are necessary for your protection in all collisions, and also are needed to help keep you in position, away from an inflating air bag.

When the ORC detects a collision requiring the front air bags, it signals the inflator units. A large quantity of non-toxic gas is generated to inflate the front air bags.

The steering wheel hub trim cover and the upper passenger side of the instrument panel separate and fold out of the way as the air bags inflate to their full size. The front air bags fully inflate in less time than it takes to blink your eyes. The front air bags then quickly deflate while helping to restrain the driver and front passenger.

Knee Impact Bolsters

The Knee Impact Bolsters help protect the knees of the driver and front passenger, and position the front occupants for improved interaction with the front air bags.

WARNING!

- Do not drill, cut, or tamper with the knee impact bolsters in any way.
- Do not mount any accessories to the knee impact bolsters such as alarm lights, stereos, citizen band radios, etc.

Supplemental Driver Knee Air Bag

This vehicle is equipped with a Supplemental Driver Knee Air Bag mounted in the instrument panel below the steering column. The Supplemental Driver Knee Air Bag provides enhanced protection during a frontal impact by working together with the seat belts, pretensioners, and front air bags.

Supplemental Side Air Bags

Supplemental Seat-Mounted Side Air Bags (SABs) (if equipped)

Your vehicle may be equipped with Supplemental Seat-Mounted Side Air Bags (SABs). If your vehicle is equipped with Supplemental Seat-Mounted Side Air Bags (SABs), please refer to the information below.

Supplemental Seat-Mounted Side Air Bags (SABs) are located in the outboard side of the front seats. The SABs are marked with "SRS AIRBAG" or "AIRBAG" on a label or on the seat trim on the outboard side of the seats.



Front Supplemental Seat-Mounted Side Air Bag Label

The SABs (if equipped with SABs) may help to reduce the risk of occupant injury during certain side impacts, in addition to the injury reduction potential provided by the seat belts and body structure.

When the SAB deploys, it opens the seam on the outboard side of the seatback's trim cover. The inflating SAB deploys through the seat seam into the space between the occupant and the door. The SAB moves at a very high speed and with such a high force that it could injure occupants if they are not seated properly, or if items are positioned in the area where the SAB inflates. Children are at an even greater risk of injury from a deploying air bag.

WARNING!

Do not use accessory seat covers or place objects between you and the Side Air Bags; the performance could be adversely affected and/or objects could be pushed into you, causing serious injury.

Supplemental Side Air Bag Inflatable Curtains (SABICs) — If Equipped


Your vehicle may be equipped with Supplemental Side Air Bag Inflatable Curtains (SABICs). If your vehicle is equipped with Supplemental Side Air Bag Inflatable Curtains (SABICs), please refer to the information below.

Supplemental Side Air Bag Inflatable Curtains (SABICs) are located above the side windows. The trim covering the SABICs is labeled "SRS AIRBAG" or "AIRBAG."





SABICs (if equipped with SABICs) may help reduce the risk of head and other injuries to front and rear seat outboard occupants in certain side impacts, in addition to the injury reduction potential provided by the seat belts and body structure.

























with enough force to injure occupants if they are not belted and seated properly, or if items are positioned in the area where the SABICs inflate. Children are at an even greater risk of injury from a deploying air bag.

The SABICs (if equipped with SABICs) may help reduce the risk of partial or complete ejection of vehicle occupants through side windows in certain side impact events.

WARNING!

- Do not mount equipment, or stack luggage or other cargo up high enough to block the deployment of the SABICs. The trim covering above the side windows where the SABIC and its deployment path are located should remain free from any obstructions.
- In order for the SABICs to work as intended, do not install any accessory items in your vehicle which could alter the roof. Do not add an aftermarket sunroof to your vehicle. Do not add roof racks that require permanent attachments (bolts or screws) for installation

WARNING!

on the vehicle roof. Do not drill into the roof of the vehicle for any reason.

Side Impacts

The Side Air Bags are designed to activate in certain side impacts. The Occupant Restraint Controller (ORC) determines whether the deployment of the Side Air Bags in a particular impact event is appropriate, based on the severity and type of collision. The side impact sensors aid the ORC in determining the appropriate response to impact events. The system is calibrated to deploy the Side Air Bags on the impact side of the vehicle during impacts that require Side Air Bag occupant protection. In side impacts, the Side Air Bags deploy independently: a left side impact deploys the left Side Air Bags only and a rightside impact deploys the right Side Air Bags only. Vehicle damage by itself is not a good indicator of whether or not Side Air Bags should have deployed

The Side Air Bags will not deploy in all side collisions, including some collisions at certain angles, or some side collisions that do

not impact the area of the passenger compartment. The Side Air Bags may deploy during angled or offset frontal collisions where the front air bags deploy.

Side Air Bags are a supplement to the seat belt restraint system. Side Air Bags deploy in less time than it takes to blink your eyes.

WARNING!

- Occupants, including children, who are up against or very close to Side Air Bags can be seriously injured or killed. Occupants, including children, should never lean on or sleep against the door, side windows, or area where the side air bags inflate, even if they are in an infant or child restraint.
- Seat belts (and child restraints where appropriate) are necessary for your protection in all collisions. They also help keep you in position, away from an inflating Side Air Bag. To get the best protection from the Side Air Bags, occupants must wear their seat belts properly and sit upright with their backs against

the seats. Children must be properly restrained in a child restraint or booster seat that is appropriate for the size of the child.

WARNING!

- Side Air Bags need room to inflate. Do not lean against the door or window. Sit upright in the center of the seat.
- Being too close to the Side Air Bags during deployment could cause you to be severely injured or killed.
- Relying on the Side Air Bags alone could lead to more severe injuries in a collision. The Side Air Bags work with your seat belt to restrain you properly. In some collisions, Side Air Bags won't deploy at all. Always wear your seat belt even though you have Side Air Bags.

NOTE:

Air bag covers may not be obvious in the interior trim, but they will open during air bag deployment.

Rollover Events — If Equipped With Rollover Sensing


Side Air Bags are designed to activate in certain rollover events. The Occupant Restraint Controller (ORC) determines whether the deployment of the Side Air Bags in a particular rollover event is appropriate, based on the severity and type of collision. Vehicle damage by itself is not a good indicator of whether or not Side Air Bags should have deployed.

The Side Air Bags will not deploy in all rollover events. The rollover sensing-system determines if a rollover event may be in progress and whether deployment is appropriate. A slower-developing event may deploy the seat belt pretensioners on both sides of the vehicle. A faster-developing event may deploy the seat belt pretensioners as well as the Side Air Bags on both sides of the vehicle. The rollover sensing-system may also deploy the seat belt pretensioners, with or without the Side Air Bags, on both sides of the vehicle if the vehicle experiences a near rollover event.

The SABICs may help reduce the risk of partial or complete ejection of vehicle occupants through side windows in certain rollover or side impact events.







NOTE:

The Occupant Restraint Controller (ORC) monitors the internal circuits and interconnecting wiring associated with electrical Air Bag System Components listed below:


















• Supplemental Side Air Bags

Supplemental Knee Air Bags

Front and Side Impact Sensors

Seat Belt Pretensioners















If A Deployment Occurs

The front air bags are designed to deflate immediately after deployment.

NOTE:

Front and/or side air bags will not deploy in all collisions. This does not mean something is wrong with the air bag system.

If you do have a collision which deploys the air bags, any or all of the following may occur:

- The air bag material may sometimes cause abrasions and/or skin reddening to the occupants as the air bags deploy and unfold. The abrasions are similar to friction rope burns or those you might get sliding along a carpet or gymnasium floor. They are not caused by contact with chemicals. They are not permanent and normally heal quickly. However, if you haven't healed significantly within a few days, or if you have any blistering, see your doctor immediately.
- As the air bags deflate, you may see some smoke-like particles. The particles are a normal by-product of the process that generates the non-toxic gas used for air bag inflation. These airborne particles may irritate the skin, eyes, nose, or throat. If you

have skin or eye irritation, rinse the area with cool water. For nose or throat irritation, move to fresh air. If the irritation continues, see your doctor. If these particles settle on your clothing, follow the garment manufacturer's instructions for cleaning.

Do not drive your vehicle after the air bags have deployed. If you are involved in another collision, the air bags will not be in place to protect you.

WARNING!

Deployed air bags and seat belt pretensioners cannot protect you in another collision. Have the air bags, seat belt pretensioners, and the seat belt retractor assemblies replaced by an authorized dealer immediately. Also, have the Occupant Restraint Controller System serviced as well.

NOTE:

 Air bag covers may not be obvious in the interior trim, but they will open during air bag deployment. • After any collision, the vehicle should be taken to an authorized dealer immediately.

Enhanced Accident Response System

In the event of an impact, if the communication network remains intact, and the power remains intact, depending on the nature of the event, the ORC will determine whether to have the Enhanced Accident Response System perform the following functions:

- Cut off fuel to the engine (If Equipped)
- Cut off battery power to the electric motor (If Equipped)
- Flash hazard lights as long as the battery has power
- Turn on the interior lights, which remain on as long as the battery has power or for 15 minutes from the intervention of the Enhanced Accident Response System.
- Unlock the power door locks.

Your vehicle may also be designed to perform any of these other functions in response to the Enhanced Accident Response System:

- Turn off the Fuel Filter Heater. Turn off the HVAC Blower Motor, Close the HVAC Circulation Door
- Cut off battery power to the:
 - Engine
 - Electric Motor (if equipped)
 - Electric power steering
 - Brake booster
 - Electric park brake
 - Automatic transmission gear selector
 - Horn
 - Front wiper
 - Headlamp washer pump

NOTE:

After an accident, remember to cycle the ignition to the STOP (OFF/LOCK) position and remove the key from the ignition switch to avoid draining the battery. Carefully check the vehicle for fuel leaks in the engine compartment and on the ground near the engine compartment and fuel tank before resetting the system and starting the engine. If there are no fuel leaks or damage to the vehicle electrical devices (e.g. headlights) after an accident, reset the system by following the procedure described below.

Enhanced Accident Response System Reset Procedure

In order to reset the Enhanced Accident Response System functions after an event, the ignition switch must be changed from ignition START or ON/RUN to ignition OFF. Carefully check the vehicle for fuel leaks in the engine compartment and on the ground near the engine compartment and fuel tank before resetting the system and starting the engine.

Maintaining Your Air Bag System

























- Modifications to any part of the air bag system could cause it to fail when you need it. You could be injured if the air bag system is not there to protect you. Do not modify the components or wiring, including adding any kind of badges or stickers to the steering wheel hub trim cover or the upper right side of the instrument panel. Do not modify the front bumper, vehicle body structure, or add aftermarket side steps or running boards.
- It is dangerous to try to repair any part of the air bag system yourself. Be sure to tell anyone who works on your vehicle that it has an air bag system.
- Do not attempt to modify any part of your air bag system. The air bag may inflate accidentally or may not function properly if modifications are made. Take your vehicle to an authorized dealer for any air bag system service. If your seat, including your trim cover and cushion, needs to be serviced in any way (includ-

ing removal or loosening/tightening of seat attachment bolts), take the vehicle to your authorized dealer. Only manufacturer approved seat accessories may be used. If it is necessary to modify the air bag system for persons with disabilities, contact your authorized dealer.

Event Data Recorder (EDR)

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;

- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE:

EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

Child Restraints — Carrying Children Safely



Warning Label On Front Passenger Sun Visor

Everyone in your vehicle needs to be buckled up at all times, including babies and children. EC directive 2003/20/EC requires proper use of restraints in all EC countries.

Children less than 1.5 meters tall and 12 years or younger should ride properly buckled up in a rear seat, if available. Ac-

cording to crash statistics, children are safer when properly restrained in the rear seats rather than in the front.

WARNING!

- NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERI-OUS INJURY to the CHILD can occur.
- Only use a rear-facing child restraint in the rear seat of a vehicle with a rear seat.
- A deploying passenger front airbag can cause death or serious injury to a child 12 years or younger, including a child in a rear-facing child restraint.
- In a collision, an unrestrained child can become a projectile inside the vehicle. The force required to hold even an infant on your lap could become so great that you could not hold the child, no matter how strong you are. The child and others could be badly injured or killed. Any child riding in your vehicle should be in a proper restraint for the child's size.

There are different sizes and types of restraints for children from newborn size to the child almost large enough for an adult safety belt. Children should ride rearward facing as long as possible; this is the most protected position for a child in the event of a crash. Always check the child seat Owner's Manual to make sure you have the correct seat for your child. Carefully read and follow all the instructions and warnings in the child restraint Owner's Manual and on all the labels attached to the child restraint.

In Europe, children restraint systems are defined by regulation ECE-R44, which divides them into five weight groups:

Restraint Group	Weight Group
Group 0	up to 10 kg
Group 0+	up to 13 kg
Group 1	9-18 kg
Group 2	15-25 kg
Group 3	22-36 kg

Check the label of your child restraint. All approved child restraints must include typeapproval data and the control mark on its label. The label must be permanently secured to the child restraint system. You should not remove this label from the child restraint.

Extreme Hazard! Do not place a rear-

facing child restraint in front of an active

air bag. Refer to visor mounted labels for

information. Deployment of the air bag in

an accident could cause fatal injuries to

the baby regardless of the severity of the


collision. It is advisable to always carry

children in a child restraint system on the

rear seat, which is the most protected



















"Universal" Child Restraint Systems

position in the event of a collision.









- See the section "Installing Child Restraints
 Using the Vehicle Seat Belt" for the steps
 to properly lock the seat belt over the child
 restraint.
- Child restraint systems with ISOFIX anchorages are available for installing the child restraint system to the vehicle without using the vehicle's seat belts.

Group O And O+



Fig. A

Safety experts recommend that children ride rearward facing in the vehicle as long as possible. Infants up to 13 kg must be restrained in a rear-facing seat like the child seat shown in fig. A. This type of child restraint supports the child's head and does not induce stress on the neck in the event of sudden decelerations or a crash.

The rear-facing child restraint is restrained by the vehicle's seat belts, as shown in fig. A. The child seat restrains the child with its own harness.

WARNING!

- Never place a rear-facing child restraint in front of an air bag. A deploying passenger Front Air Bag can cause death or serious injury to a child 12 years or younger, including a child in a rear-facing child restraint.
- Only use a rear-facing child restraint in the rear seat of a vehicle with a rear seat.

Group 1



Fig. B

Children who weigh between 9 kg and 18 kg may be carried in a Group 1, forward facing seat like the one in fig. B. This type of child restraint is for older children who are too big for a Group 0 or 0+ child restraint.

Group 2



Fig. C

Children who weigh between 15 kg and 25 kg and who are too big for the Group 1 child restraint may use a Group 2 child restraint system.

As shown in fig. C, the Group 2 child restraint system positions the child correctly with respect to the seat belt so that the shoulder belt crosses the child's chest and not the neck. and the lap belt is snug on the pelvis and not the abdomen.

Group 3




Fig. D

Children who weigh between 22 kg and 36 kg and who are tall enough to use the adult shoulder belt may use a Group 3 child restraint. Group 3 child restraints position the lap belt on the child's pelvis. The child must be tall enough that the shoulder belt crosses the child's chest and not their neck.

Fig. D shows an example of a Group 3 child restraint system correctly positioning the child on the rear seat.

WARNING! Improper installation can lead to failure

of an infant or child restraint. It could

come loose in a collision. The child could be badly injured or killed. Follow the child restraint manufacturer's directions exactly when installing an infant or

 After a child restraint is installed in the vehicle, do not move the vehicle seat forward or rearward because it can loosen the child restraint attachments.

Remove the child restraint before adjusting the vehicle seat position. When

the vehicle seat has been adjusted, re-

When your child restraint is not in use.

secure it in the vehicle with the seat belt

or ISOFIX anchorages, or remove it from

the vehicle. Do not leave it loose in the

vehicle. In a sudden stop or accident, it

could strike the occupants or seatbacks

and cause serious personal injury.

install the child restraint.

child restraint.

























Suitability Of Passenger Seats For Universal Child Restraint System Use

According to the European Directive 2000/3/ EC, the suitability of each passenger seat position for the installation of Universal Child Restraint Systems is shown in the following table:

Universal Child Seating Position Chart						
Front Passenger	Rear Outboard	Rear Center	Intermediate Outboard	Intermediate Center		
Х	Х	Х	U	Χ		
Х	Χ	Х	U	Χ		
Х	Χ	X	U	UF		
Х	Χ	Х	U	UF		
Х	Х	Х	U	UF		
	Front Passenger X X X X X					

Key of letters to be inserted in the above table :

- U = Suitable for "universal" category restraints approved for use in this mass group.
- UF = Suitable for forward-facing "universal" category restraints approved for use in this age/weight group.
- X = Seat position not suitable for children in this age/weight group.

If the head restraint interferes with the installation of the child restraint system when it is installed on the front passenger seat, adjust the front seat head restraint.

Seat Belts For Older Children

Children over 1.50 m in height can wear seat belts instead of using child restraints.

Use this simple 5-step test to decide whether the seat belt properly fits the child or if they should still use a Group 2 or Group 3 child restraint to improve the fit of the seat belt:

- 1. Can the child sit all the way back against the back of the vehicle seat?
- 2. Do the child's knees bend comfortably over the front of the vehicle seat - while they are still sitting all the way back?
- 3. Does the shoulder belt cross the child's shoulder between their neck and arm?
- 4. Is the lap part of the belt as low as possible, touching the child's thighs and not their stomach?
- 5. Can the child stay seated like this for the whole trip?

If the answer to any of these questions was "no," then the child still needs to use a Group 2 or 3 child restraint in this vehicle. If the child is using the lap/shoulder belt, check belt fit periodically and make sure the seat belt buckle is latched. A child's squirming or slouching can move the belt out of position. If the shoulder belt contacts the face or neck. move the child closer to the center of the vehicle, or use a booster seat to position the seat belt on the child correctly.

WARNING!

Never allow a child to put the shoulder belt under an arm or behind their back. In a crash, the shoulder belt will not protect a child properly, which may result in serious injury or death. A child must always wear both the lap and shoulder portions of the seat belt correctly.

ISOFIX Restraint System































Fig. E

Your vehicle is equipped with the child restraint anchorage system called ISOFIX. This system allows ISOFIX-equipped child seats to be installed without using the vehicle's seat belts. The ISOFIX system has two lower anchorages located at the back of the seat cushion where it meets the seatback and a top tether anchorage located behind the seating position.

An example of a Universal ISOFIX child restraint system for weight group 1 is shown in fig. E. ISOFIX child restraints are also available in the other weight groups.

Locating The ISOFIX Anchorages

The lower anchorages are round bars that are found at the rear of the seat cushion where it meets the seatback. They are just visible when you lean into the rear seat to install the child restraint. You will easily feel them if you run your finger along the gap between the seatback and seat cushion.



ISOFIX Anchorage Locations

Locating the Tether Anchorages

There are tether strap anchorages behind each rear outboard seating position located on the back of the seat.

ISOFIX child restraint systems will be equipped with a rigid bar on each side. Each will have a connector to attach to the lower anchorage and a way to tighten the connection to the anchorage. Forward-facing child restraints and some rear-facing child restraints may also be equipped with a tether strap. The tether strap will have a hook at the end to attach to the top tether anchorage and a way to tighten the strap after it is attached to the anchorage.



Tether Anchorage Locations

Center Seat ISOFIX

WARNING!

 This vehicle does not have center ISOFIX or tether anchorages. This position is not approved for any type of ISOFIX child restraint system. Do not install a forward facing child seat with a tether strap in the center seating position.

WARNING!

- Use the seat belt to install a child seat in the center seating position.
- Never use the same lower anchorage to attach more than one child restraint. Please refer to "To Install An ISOFIX Child Restraint" for typical installation instructions.

Suitability Of Passenger Seats For ISOFIX Child Restraint System Use



The table below shows the various installation possibilities for ISOFIX child restraint systems on seats fitted with ISOFIX anchorages in accordance with European standard ECE 16.







Vehicle ISOFIX Positions Table								
Mass Group	Size Class	Fixture	Front Passenger	Rear Outboard Rt./Lt.	Rear Center	Intermediate Outboard	Intermediate Center	Other Sites
	F	ISO/L1	Х	Х	Χ	N/A	N/A	N/A
Carrycot	G	ISO/L2	Х	Х	Х	N/A	N/A	N/A
		(1)	Х	N/A	Χ	N/A	N/A	N/A
0 — up to	E	ISO/R1	Х	IUF/IUF	Х	N/A	N/A	N/A
10 kg		(1)	Х	N/A	Х	N/A	N/A	N/A
	E	ISO/R1	Х	IUF/IUF	Χ	N/A	N/A	N/A
0+ — up to	D	ISO/R2	Х	IUF/IUF	Χ	N/A	N/A	N/A
13 kg	С	ISO/R3	Х	IUF/IUF	Х	N/A	N/A	N/A
		(1)	X	X	Χ	N/A	N/A	N/A
		I	I			[I















Vehicle ISOFIX Positions Table								
Mass Group	Size Class	Fixture	Front Passenger	Rear Outboard Rt./Lt.	Rear Center	Intermediate Outboard	Intermediate Center	Other Sites
	D	ISO/R2	Х	IUF/IUF	Х	N/A	N/A	N/A
	С	ISO/R3	Х	IUF/IUF	Χ	N/A	N/A	N/A
I – 9 to 18 kg	В	ISO/F2	Х	IUF/IUF	Х	N/A	N/A	N/A
	B1	ISO/F2X	Х	IUF/IUF	Χ	N/A	N/A	N/A
	Α	ISO/F3	X	IUF/IUF	Χ	N/A	N/A	N/A
		(1)	Х	N/A	Х	N/A	N/A	N/A
II – 15 to 25 kg		(1)	Х	N/A	Χ	N/A	N/A	N/A
III – 22 to 36 kg		(1)	Х	N/A	Х	N/A	N/A	N/A

Key of letters used in the table above:

- (1) = For the CRS which do not carry the ISO/XX size class identification (A to G), for the applicable mass group, the car manufacturer shall indicate the vehicle specific ISOFIX child restraint system(s) recommended for each position.
- IUF = Suitable for ISOFIX forward child restraint systems of universal category approved for use in the mass group.

• X = ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.

Always follow the directions of the child restraint manufacturer when installing your child restraint. Not all child restraint systems will be installed as described here. When using a Universal ISOFIX child restraint system, you can only use approved child restraint systems with the marking ECE R44 (release R44/03 or superior) "Universal ISOFIX".

To Install An ISOFIX Child Restraint

If the selected seating position has a Switchable Automatic Locking Retractor (ALR) seat belt, stow the seat belt, following the instructions below. See the section "Installing Child Restraints Using the Vehicle Seat Belt" to check what type of seat belt each seating position has.

- Loosen the adjusters on the lower connectors and on the tether strap of the child seat so that you can more easily attach the connectors to the vehicle anchorages.
- 2. Place the child seat between the lower anchorages for that seating position. For some second row seats, you may need to recline the seat and / or raise the head restraint to get a better fit. If the rear seat can be moved forward and rearward in the vehicle, you may wish to move it to its rear-most position to make room for the child seat. You may also move the front seat forward to allow more room for the child seat.
- Attach the connectors of the child restraint to the lower anchorages in the selected seating position.

- 4. If the child restraint has a tether strap, connect it to the top tether anchorage. See the section "Installing Child Restraints Using the Top Tether Anchorage" for directions to attach a tether anchor.
- Tighten all of the straps as you push the child restraint rearward and downward into the seat. Remove slack in the straps according to the child restraint manufacturer's instructions.
- Test that the child restraint is installed tightly by pulling back and forth on the child seat at the belt path. It should not move more than 25 mm in any direction.

WARNING!

- Improper installation of a child restraint to the ISOFIX anchorages can lead to failure of the restraint. The child could be badly injured or killed. Follow the child restraint manufacturer's directions exactly when installing an infant or child restraint.
- Child restraint anchorages are designed to withstand only those loads imposed

WARNING!



by correctly-fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.



 Install the child restraint system when the vehicle is stationary. The ISOFIX child restraint system is correctly fixed to the brackets when you hear the click.



Installing Child Restraints Using The Top Tether Anchorage



 Look behind the seating position where you plan to install the child restraint to find the tether anchorage. You may need to move the seat forward to provide better access to the tether anchorage. If there is no top tether anchorage for that seating position, move the child restraint to another position in the vehicle if one is available.





2. Route the tether strap to provide the most direct path for the strap between the anchor and the child seat. If your vehicle is





equipped with adjustable rear head restraints, raise the head restraint, and where possible, route the tether strap under the head restraint and between the two posts. If not possible, lower the head restraint and pass the tether strap around the outboard side of the head restraint.



Tether Anchorage Locations

3. Attach the tether strap hook of the child restraint to the top tether anchorage as shown in the diagram.

 Remove slack in the tether strap according to the child restraint manufacturer's instructions.

WARNING!

- An incorrectly anchored tether strap could lead to increased head motion and possible injury to the child. Use only the anchorage position directly behind the child seat to secure a child restraint top tether strap.
- If your vehicle is equipped with a split rear seat, make sure the tether strap does not slip into the opening between the seatbacks as you remove slack in the strap.

Installing Child Restraints Using The Vehicle Seat Belt

Child restraint systems are designed to be secured in vehicle seats by lap belts or the lap belt portion of a lap/shoulder belt.

WARNING!

- Improper installation or failure to properly secure a child restraint can lead to failure of the restraint. The child could be badly injured or killed.
- Follow the child restraint manufacturer's directions exactly when installing an infant or child restraint.

The seat belts in the rear passenger seating positions are equipped with a Switchable Automatic Locking Retractor (ALR) that is designed to keep the lap portion of the seat belt tight around the child restraint. The ALR retractor can be "switched" into a locked mode by pulling all of the webbing out of the retractor and then letting the webbing retract back into the retractor. If it is locked, the ALR will make a clicking noise while the webbing is pulled back into the retractor. Refer to the "Automatic Locking Mode" description in "Switchable Automatic Locking Retractors (ALR)" under "Occupant Restraint Systems" for additional information on ALR.

How To Stow An Unused Switchable-ALR (ALR) Seat Belt:

When using the ISOFIX attaching system to install a child restraint, stow all ALR seat belts that are not being used by other occupants or being used to secure child restraints. An unused belt could injure a child if they play with it and accidentally lock the seat belt retractor. Before installing a child restraint using the ISOFIX system, buckle the seat belt behind the child restraint and out of the child's reach. If the buckled seat belt interferes with the child restraint installation, instead of buckling it behind the child restraint, route the seat belt through the child restraint belt path and then buckle it. Do not lock the seat belt. Remind all children in the vehicle that the seat belts are not toys and that they should not play with them.

Installing A Child Restraint With A Switchable Automatic Locking Retractor (ALR)

Child restraint systems are designed to be secured in vehicle seats by lap belts or the lap belt portion of a lap/shoulder belt.

WARNING!

- Improper installation or failure to properly secure a child restraint can lead to failure of the restraint. The child could be badly injured or killed.
- Follow the child restraint manufacturer's directions exactly when installing an infant or child restraint.
- 1. Place the child seat in the center of the seating position. For some second row seats, you may need to recline the seat and/or raise the head restraint to get a better fit. If the rear seat can be moved forward and rearward in the vehicle, you may wish to move it to its rear-most position to make room for the child seat. You may also move the front seat forward to allow more room for the child seat.
- 2. Pull enough of the seat belt webbing from the retractor to pass it through the belt path of the child restraint. Do not twist the belt webbing in the belt path.
- 3. Slide the latch plate into the buckle until vou hear a "click."

4. Pull on the webbing to make the lap portion tight against the child seat.



5. To lock the seat belt, pull down on the shoulder part of the belt until you have pulled all the seat belt webbing out of the retractor. Then, allow the webbing to retract back into the retractor. As the webbing retracts, you will hear a clicking sound. This means the seat belt is now in the Automatic Locking mode.





6. Try to pull the webbing out of the retractor. If it is locked, you should not be able to pull out any webbing. If the retractor is not locked, repeat step 5.



7. Finally, pull up on any excess webbing to tighten the lap portion around the child restraint while you push the child restraint rearward and downward into the vehicle seat.



8. Test that the child restraint is installed tightly by pulling back and forth on the child seat at the belt path. It should not move more than 25 mm in any direction.



Any seat belt system will loosen with time, so check the belt occasionally, and pull it tight if necessary.





Transporting Pets

Air Bags deploying in the front seat could harm your pet. An unrestrained pet will be thrown about and possibly injured, or injure a passenger during panic braking or in a collision.

Pets should be restrained in the rear seat in pet harnesses or pet carriers that are secured by seat belts.

SAFETY TIPS

Transporting Passengers

NEVER TRANSPORT PASSENGERS IN THE CARGO AREA.

WARNING!

- Do not leave children or animals inside parked vehicles in hot weather. Interior heat build-up may cause serious injury or death.
- It is extremely dangerous to ride in a cargo area, inside or outside of a vehicle.
 In a collision, people riding in these

WARNING!

areas are more likely to be seriously injured or killed.

- Do not allow people to ride in any area of your vehicle that is not equipped with seats and seat belts.
- Be sure everyone in your vehicle is in a seat and using a seat belt properly.

Exhaust Gas

WARNING!

Exhaust gases can injure or kill. They contain carbon monoxide (CO), which is colorless and odorless. Breathing it can make you unconscious and can eventually poison you. To avoid breathing (CO), follow these safety tips:

- Do not run the engine in a closed garage or in confined areas any longer than needed to move your vehicle in or out of the area.
- If you are required to drive with the trunk/liftgate/rear doors open, make

WARNING!

sure that all windows are closed and the climate control BLOWER switch is set at high speed. DO NOT use the recirculation mode.

 If it is necessary to sit in a parked vehicle with the engine running, adjust your heating or cooling controls to force outside air into the vehicle. Set the blower at high speed.

The best protection against carbon monoxide entry into the vehicle body is a properly maintained engine exhaust system.

Whenever a change is noticed in the sound of the exhaust system, when exhaust fumes can be detected inside the vehicle, or when the underside or rear of the vehicle is damaged, have a competent mechanic inspect the complete exhaust system and adjacent body areas for broken, damaged, deteriorated, or mispositioned parts. Open seams or loose connections could permit exhaust fumes to seep into the passenger compartment. In addition, inspect the exhaust system each time the vehicle is raised for lubrication or oil change. Replace as required.

Safety Checks You Should Make Inside The Vehicle

Seat Belts

Inspect the seat belt system periodically, checking for cuts, frays, and loose parts. Damaged parts must be replaced immediately. Do not disassemble or modify the system.

Front seat belt assemblies must be replaced after a collision. Rear seat belt assemblies must be replaced after a collision if they have been damaged (i.e., bent retractor, torn webbing, etc.). If there is any question regarding seat belt or retractor condition, replace the seat belt.

Air Bag Warning Light

The Air Bag warning light *will turn on for four to eight seconds as a bulb check when the ignition switch is first turned to ON/RUN. If the light is either not on during starting, stays on, or turns on while driving, have the system inspected at your authorized dealer as soon as possible. After the bulb check, this light will illuminate with a single chime when

a fault with the Air Bag System has been detected. It will stay on until the fault is removed. If the light comes on intermittently or remains on while driving, have your authorized dealer service the vehicle immediately. Refer to "Occupant Restraint Systems" in "Safety" for further information.

Defroster

Check operation by selecting the defrost mode and place the blower control on high speed. You should be able to feel the air directed against the windshield. See your authorized dealer for service if your defroster is inoperable.

Floor Mat Safety Information

Always use floor mats designed to fit your vehicle. Only use a floor mat that does not interfere with the operation of the accelerator, brake or clutch pedals. Only use a floor mat that is securely attached using the floor mat fasteners so it cannot slip out of position and interfere with the accelerator, brake or clutch pedals or impair safe operation of your vehicle in other ways.

WARNING!

























An improperly attached, damaged, folded, or stacked floor mat, or damaged floor mat fasteners may cause your floor mat to interfere with the accelerator, brake, or clutch pedals and cause a loss of vehicle control. To prevent SERIOUS INJURY or DFATH:

- ALWAYS securely attach
 your floor mat using the floor mat fasteners. DO NOT install your floor mat upside down or turn your floor mat over. Lightly pull to confirm mat is secured using the floor mat fasteners on a regular basis.
- ALWAYS REMOVE THE EXISTING FLOOR MAT FROM THE VEHICLE before installing any other floor mat. NEVER install or stack an additional floor mat on top of an existing floor mat.
- ONLY install floor mats designed to fit vour vehicle. NEVER install a floor mat that cannot be properly attached and secured to your vehicle. If a floor mat needs to be replaced, only use a FCA approved floor mat for the specific make, model, and year of your vehicle.

WARNING!

- ONLY use the driver's side floor mat on the driver's side floor area. To check for interference, with the vehicle properly parked with the engine off, fully depress the accelerator, the brake, and the clutch pedal (if present) to check for interference. If your floor mat interferes with the operation of any pedal, or is not secure to the floor, remove the floor mat from the vehicle and place the floor mat in your trunk.
- ONLY use the passenger's side floor mat on the passenger's side floor area.
- ALWAYS make sure objects cannot fall or slide into the driver's side floor area when the vehicle is moving. Objects can become trapped under accelerator, brake, or clutch pedals and could cause a loss of vehicle control.
- NEVER place any objects under the floor mat (e.g., towels, keys, etc.). These objects could change the position of the floor mat and may cause interference with the accelerator, brake, or clutch pedals.

WARNING!

- If the vehicle carpet has been removed and re-installed, always properly attach carpet to the floor and check the floor mat fasteners are secure to the vehicle carpet.
 Fully depress each pedal to check for interference with the accelerator, brake, or clutch pedals then re-install the floor mats.
- It is recommended to only use mild soap and water to clean your floor mats. After cleaning, always check your floor mat has been properly installed and is secured to your vehicle using the floor mat fasteners by lightly pulling mat.

Periodic Safety Checks You Should Make Outside The Vehicle

Tires

Examine tires for excessive tread wear and uneven wear patterns. Check for stones, nails, glass, or other objects lodged in the tread or sidewall. Inspect the tread for cuts and cracks. Inspect sidewalls for cuts,

cracks, and bulges. Check the wheel nuts for tightness. Check the tires (including spare) for proper cold inflation pressure.

Lights

Have someone observe the operation of brake lights and exterior lights while you work the controls. Check turn signal and high beam indicator lights on the instrument panel.

Door Latches

Check for proper closing, latching, and locking.

Fluid Leaks

Check area under the vehicle after overnight parking for fuel, coolant, oil, or other fluid leaks. Also, if gasoline fumes are detected or if fuel, or brake fluid leaks are suspected. The cause should be located and corrected immediately.

STARTING AND OPERATING

)
	- 9

STARTING THE ENGINE	1-Speed Four-Wheel Drive (4X4) — If Equipped	Automatic Mode
PARKING BRAKE	SELEC-TERRAIN	,
Electric Park Brake (EPB)	Description	SPEED CONTROL
MANUAL TRANSMISSION —	STOP/START SYSTEM —	Activation
IF EQUIPPED	IF EQUIPPED	Setting A Desired Speed
Shifting	Automatic Mode	Varying The Speed
Downshifting	Possible Reasons The Engine Does	Resume
AUTOMATIC TRANSMISSION —	Not Autostop	Accelerating For Passing
IF EQUIPPED	To Start The Engine While In Autostop Mode	Deactivation
Key Ignition Park Interlock	To Manually Turn Off The Stop/Start	ADAPTIVE CRUISE CONTROL
Brake/Transmission Shift Interlock	System	(ACC)143
System	To Manually Turn On The Stop/Start	Activation
Nine-Speed Automatic Transmission129	System	Setting A Desired ACC Speed
FOUR-WHEEL DRIVE OPERA- TION	STOP/START SYSTEM — DIESEL MODELS ONLY	Varying The Speed

























Deactivation	LANESENSE
Setting The Following Distance145 Changing Modes	LaneSense Operation
PARKSENSE REAR PARK	LaneSense Warning Message 152
ASSIST147	Changing LaneSense Status
ParkSense Sensors	PARKVIEW REAR BACK-UP CAMERA
Instrument Cluster Display — Warning	Symbols And Messages On The Display
PARKSENSE FRONT AND REAR	REFUELING THE VEHICLE 155
PARK ASSIST149	TRAILER TOWING
ParkSense Sensors	Trailer Towing Weights (Maximum Trailer Weight Ratings)
Engagement/Disengagement	RECREATIONAL TOWING (BEHIND
Operation With A Trailer	MOTORHOME, ETC.)
General Warnings	Towing This Vehicle Behind Another
PARKSENSE ACTIVE	Vehicle
PARK ASSIST	Recreational Towing — Front-Wheel Drive (FWD) Models
Active Park Assist	Recreational Towing — 4x4 Models158

STARTING THE ENGINE

Before starting your vehicle, adjust your seat, adjust both inside and outside mirrors, and fasten your seat belts.

WARNING!

- When leaving the vehicle, always remove the key fob from the ignition and lock your vehicle. If equipped with Keyless Enter-N-Go, always make sure the keyless ignition node is in "OFF" mode, remove the key fob from the vehicle and lock the vehicle.
- Never leave children alone in a vehicle. or with access to an unlocked vehicle.
- Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the gear selector.
- Do not leave the key fob in or near the vehicle, or in a location accessible to children, and do not leave the ignition of a vehicle equipped with Keyless Enter-

WARNING!

N-Go in the ACC or ON/RUN mode. A child could operate power windows, other controls, or move the vehicle.

Start the engine with the gear selector in the NEUTRAL or PARK position. Apply the brake before shifting to any driving range.

Normal Starting — Gasoline Engine

NOTE:


Normal starting of either a cold or a warm engine is obtained without pumping or pushing the accelerator pedal.

Place your foot on the brake and place the ignition to the START mode and release when the engine starts. If the engine fails to start within 10 seconds:

- 1. Place the ignition in the OFF mode.
- 2. Wait 10 to 15 seconds.
- 3. Repeat the "Normal Starting" procedure.

Tip Start Feature

Wait 10 to 15 seconds.
















Extreme Cold Weather (Below -22°F Or -30°C)

To ensure reliable starting at these temperatures, use of an externally powered electric engine block heater (available from an authorized dealer) is recommended.





Before starting your vehicle, adjust your seat, both inside and outside mirrors, and fasten vour seat belts.









The starter is allowed to crank for up to 30-second intervals. Waiting a few minutes between such intervals will protect the starter from overheating.

WARNING!

- Before exiting a vehicle, always come to a complete stop, then shift the automatic transmission into PARK and apply the parking brake.
- Always make sure the keyless ignition node is in the OFF mode, key fob is removed from the vehicle and vehicle is locked.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle. Leaving children in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the gear selector.
- Do not leave the key fob in or near the vehicle, or in a location accessible to children, and do not leave the ignition of a vehicle equipped with Keyless Enter-

WARNING!

N-Go in the ACC or ON/RUN mode. A child could operate power windows, other controls, or move the vehicle.

 Do not leave children or animals inside parked vehicles in hot weather. Interior heat build-up may cause serious injury or death.

NOTE:

Engine start up in very low ambient temperature could result in evident white smoke. This condition will disappear as the engine warms up.

CAUTION!

The engine is allowed to crank as long as 30 seconds. If the engine fails to start during this period, please wait at least two minutes for the starter to cool before repeating start procedure.

Battery Blanket Usage

A battery loses 60% of its cranking power as the battery temperature decreases to 0°F (-18°C). For the same decrease in temperature, the engine requires twice as much power to crank at the same RPM. The use of battery blankets will greatly increase starting capability at low temperatures. Suitable battery blankets are available from your authorized Mopar dealer.

Normal Starting Procedure — Keyless Enter-N-Go

Observe the instrument panel cluster lights when starting the engine.

NOTE:

Normal starting of either a cold or a warm engine is obtained without pumping or pressing the accelerator pedal.

- 1. Always apply the parking brake.
- Press and hold the brake pedal while pushing the ENGINE START/STOP button once.

NOTE:

A delay of the start of up to five seconds is possible under very cold conditions. The "Wait to Start" telltale will be illuminated during the pre-heat process, When the engine Wait To Start light goes off the engine will automatically crank.

CAUTION!

If the "Water in Fuel Indicator Light" remains on, DO NOT START the engine before the water is drained from the fuel filters to avoid engine damage.

- 3. The system will automatically engage the starter to crank the engine. If the vehicle fails to start, the starter will disengage automatically after 30 seconds.
- 4. If you wish to stop the cranking of the engine prior to the engine starting, push the button again.
- 5. Check that the oil pressure warning light has turned off.
- 6. Release the parking brake.

Engine Warm Up

Avoid full throttle operation when the engine is cold. When starting a cold engine, bring the engine up to operating speed slowly to allow the oil pressure to stabilize as the engine warms up.

NOTE:

High-speed, no-load running of a cold engine can result in excessive white smoke and poor engine performance. No-load engine speeds should be kept under 1,200 RPM during the warm-up period, especially in cold ambient temperature conditions.

ENGINE BREAK-IN RECOMMENDATIONS

A long break-in period is not required for the engine and drivetrain (transmission and axle) in your vehicle.

Drive moderately during the first 300 miles (500 km). After the initial 60 miles (100 km), speeds up to 50 or 55 mph (80 or 90 km/h) are desirable.

While cruising, brief full-throttle acceleration within the limits of local traffic laws contributes to a good break-in. Wide-open throttle acceleration in low gear can be detrimental and should be avoided.

tent with anticipated climate conditions un-

CAUTION!


Never use Non-Detergent Oil or Straight


Mineral Oil in the engine or damage may


"Technical Specifications".















result. NOTE:

A new engine may consume some oil during its first few thousand miles (kilometers) of operation. This should be considered a normal part of the break-in and not interpreted as a problem.







PARKING BRAKE

Electric Park Brake (EPB)

Your vehicle is equipped with a new Electric Park Brake System (EPB) that offers greater convenience. The park brake switch is located in the center console.



Parking Brake Switch

To apply the park brake manually, pull up on the switch momentarily. The BRAKE telltale light in the instrument cluster and an indicator on the switch will illuminate. To release the park brake manually, the ignition must be in ON/RUN. Then put your foot on the brake pedal and push the park brake switch down momentarily. Once the park brake is fully disengaged, the BRAKE telltale light and the switch indicator will extinguish.

The park brake can also be automatically released. With the engine running and the transmission in gear, release the brake pedal and depress the throttle pedal. For safety reasons, your seat belt must also be fastened.

NOTE:

- You may hear a slight whirring sound from the back of the vehicle while the parking brake engages or disengages.
- If your foot is on the brake pedal while you are engaging or disengaging the parking brake, you may notice a small amount of brake pedal movement.
- The new Auto Park Brake feature can be used to apply the park brake automatically every time you park the vehicle. Auto Park Brake can be enabled and disabled in the Settings menu in Uconnect.

- The parking brake can be engaged even when the ignition is OFF, however, it can only be disengaged when the ignition is in the ON/RUN mode.
- SafeHold a new feature that will automatically apply the park brake under certain conditions.
 The EPB monitors the status of the driver's seat belt, driver's door and pedal positions to determine if the driver may have exited while the vehicle is still capable of moving and will then automatically apply the park brake to prevent the vehicle from rolling.
- The EPB fault light will illuminate if the EPB switch is held for longer than 20 seconds in either the released or applied position. The light will extinguish upon releasing the switch.
- Refer to the Starting And Operating section in the Owner's Manual.

CAUTION!

If the Brake System Warning Light remains on with the parking brake released, a brake system malfunction is indicated. Have the brake system serviced by an authorized dealer immediately.

WARNING!

- Never use the PARK position as a substitute for the parking brake. Always apply the parking brake fully when exiting the vehicle to guard against vehicle movement and possible injury or damage.
- When exiting the vehicle, always make sure the ignition is in the OFF mode, remove the key fob from the vehicle, and lock your vehicle.
- Never leave children alone in a vehicle. or with access to an unlocked vehicle. Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the transmission gear selector.
- Do not leave the key fob in or near the vehicle, (or in a location accessible to children), and do not leave the ignition in the ACC or ON/RUN mode. A child

WARNING!

could operate power windows, other controls, or move the vehicle.

- Be sure the parking brake is fully disengaged before driving: failure to do so can lead to brake failure and a collision.
- Always fully apply the parking brake when leaving your vehicle, or it may roll and cause damage or injury. Also be certain to leave the transmission in PARK. Failure to do so may allow the vehicle to roll and cause damage or injury.
- Driving the vehicle with the parking brake engaged, or repeated use of the parking brake to slow the vehicle may cause serious damage to the brake system.

Auto Park Brake

The electric park brake can be programmed to be applied automatically whenever the vehicle is at a standstill and the automatic transmission is placed in PARK, or with a manual transmission, whenever the ignition is turned "OFF". Auto Park Brake is enabled

and disabled by customer selection through the customer programmable features section of the Uconnect Settings.



Any single auto park brake application can be bypassed by pushing the EPB switch to the release position while the transmission is placed in PARK.



SafeHold

SafeHold is a safety feature of the Electric Park Brake System that will engage the park brake automatically if the vehicle is left unsecured while the ignition is in ON/RUN.



For automatic transmissions, the park brake will automatically engage if all of the following conditions are met:







• There is no attempt to depress the brake pedal or accelerator pedal.



The seat belt is unbuckled.



• The driver door is open.







For manual transmissions, the park brake will automatically engage if all of the following conditions are met:

- The vehicle is at a standstill.
- There is no attempt to depress the brake pedal or accelerator pedal.
- The clutch pedal is not pressed.
- The seat belt is unbuckled.
- The driver door is open.

SafeHold can be temporarily bypassed by pushing the Electric Park Brake Switch while the driver door is open. Once manually bypassed, SafeHold will be enabled again once the vehicle reaches 12 mph (20 km/h) or the ignition is turned to the OFF position and back to ON again.

MANUAL TRANSMISSION — IF EQUIPPED

WARNING!

You or others could be injured if you leave the vehicle unattended without having the parking brake fully applied. The parking brake should always be applied when the driver is not in the vehicle, especially on an incline.

CAUTION!

Never drive with your foot resting on the clutch pedal, or attempt to hold the vehicle on a hill with the clutch pedal partially engaged, as this will cause abnormal wear on the clutch.

NOTE:

During cold weather, you may experience increased effort in shifting until the transmission fluid warms up. This is normal.

Shifting

Fully press the clutch pedal before shifting gears. As you release the clutch pedal, lightly press the accelerator pedal.

You should always use first gear when starting from a standing position.

Recommended Vehicle Shift Speeds

To utilize your manual transmission efficiently for fuel economy and performance, it should be upshifted as listed in the recommended shift speed chart. Shift at the vehicle speeds listed for acceleration. When heavily loaded or pulling a trailer, these recommended up-shift speeds may not apply.

Manual Transmission Shift Speeds in MPH (KM/H)					
	Gear Selection	2 to 3	3 to 4	4 to 5	5 to 6
All Engines	Accel.	24 (39)	34 (55)	47 (76)	56 (90)
	Cruise	19 (31)	27 (43)	37 (60)	41 (66)

Downshifting

Moving from a high gear down to a lower gear is recommended to preserve brakes when driving down steep hills. In addition, downshifting at the right time provides better acceleration when you desire to resume speed. Downshift progressively. Do not skip gears to avoid overspeeding the engine and clutch.

WARNING!

Do not downshift for additional engine braking on a slippery surface. The drive wheels could lose their grip, and the vehicle could skid.

CAUTION!

• Skipping gears and downshifting into lower gears at higher vehicle speeds can damage the engine and clutch systems.

6 to 5

80 (129)

Gear Selection

Maximum Speed

CAUTION!

Any attempt to shift into lower gear with clutch pedal depressed may result damage to the clutch system. Shifting into lower gear and releasing the clutch may result in engine damage.

- When descending a hill, be very careful to downshift one gear at a time to prevent overspeeding the engine which can cause engine damage, and/or clutch damage, even if the clutch pedal is pressed. If transfer case is in low range the vehicle speeds to cause engine and clutch damage are significantly lower.
- pressed.

Manual Transmission Shift Speeds in MPH (KM/H)

4 to 3


50 (81)

5 to 4

70 (113)

CAUTION!







Maximum Recommended Downshift Speeds

mended downshifting speeds may cause

the engine to overspeed and/or damage the

clutch disc, even if the clutch pedal is

pressed.

3 to 2

30 (48)

















\subseteq



• Failure to follow the maximum recommended downshifting speeds may cause the engine damage and/or damage the clutch, even if the clutch pedal is

2 to 1

15 (24)

CAUTION!

If you skip a gear while downshifting or downshift at too high of a vehicle speed, these conditions may cause the engine to overspeed if too low of a gear is selected and the clutch pedal is released. Damage to the clutch and the transmission can result from skipping a gear while downshifting or downshifting at too high of a vehicle speed even if the clutch pedal is held pressed (i.e., not released).

AUTOMATIC TRANSMISSION — IF EQUIPPED

WARNING!

 It is dangerous to shift out of PARK or NEUTRAL if the engine speed is higher than idle speed. If your foot is not firmly pressing the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the

WARNING!

vehicle and hit someone or something. Only shift into gear when the engine is idling normally and your foot is firmly pressing the brake pedal.

- Unintended movement of a vehicle could injure those in or near the vehicle. As with all vehicles, you should never exit a vehicle while the engine is running. Before exiting a vehicle, always come to a complete stop, then apply the parking brake, shift the transmission into PARK, turn the engine OFF, and remove the key fob. When the ignition is in the LOCK/OFF (key removal) position, (or, with Keyless Enter-N-Go, when the ignition is in the OFF mode) the transmission is locked in PARK, securing the vehicle against unwanted movement.
- When leaving the vehicle, always make sure the ignition is in the OFF mode, remove the key fob from the vehicle, and lock the vehicle.
- Never use the PARK position as a substitute for the parking brake. Always apply the parking brake fully when exiting the ve-

WARNING!

hicle to guard against vehicle movement and possible injury or damage.

- Your vehicle could move and injure you and others if it is not in PARK. Check by trying to move the gear selector out of PARK with the brake pedal released. Make sure the transmission is in PARK before exiting the vehicle.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle. Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the transmission gear selector.
- Do not leave the key fob in or near the vehicle (or in a location accessible to children), and do not leave the ignition (in a vehicle equipped with Keyless Enter-N-Go) in the ACC or ON/RUN mode. A child could operate power windows, other controls, or move the vehicle.

CAUTION!

Damage to the transmission may occur if the following precautions are not observed:

- · Shift into or out of PARK or REVERSE only after the vehicle has come to a complete stop.
- Do not shift between PARK, REVERSE, NEUTRAL, or DRIVE when the engine is above idle speed.
- Before shifting into any gear, make sure your foot is firmly pressing the brake pedal.

NOTE:

You must press and hold the brake pedal while shifting out of PARK.

Key Ignition Park Interlock

This vehicle is equipped with a Key Ignition Park Interlock which requires the transmission to be in PARK before the ignition can be turned to the LOCK/OFF (key removal) position. The key fob can only be removed from

the ignition when the ignition is in the LOCK/ OFF position, and the transmission is locked in PARK whenever the ignition is in the LOCK/OFF position.

Brake/Transmission Shift Interlock System

This vehicle is equipped with a Brake Transmission Shift Interlock system (BTSI) that holds the transmission gear selector in PARK unless the brakes are applied. To shift the transmission out of PARK, the ignition must be in the ON/RUN mode (engine running or not) and the brake pedal must be pressed.

The brake pedal must also be pressed to shift from NEUTRAL into DRIVE or REVERSE when the vehicle is stopped or moving at low speeds.

Nine-Speed Automatic Transmission

The transmission gear range (PRND) is displayed both beside the gear selector and in the instrument cluster. To select a gear range, press the lock button on the gear selector and move the selector rearward or forward. You must also press the brake pedal to shift the transmission out of PARK (or NEUTRAL when the vehicle is stopped or moving at low speeds). Select the DRIVE range for normal driving.







(kilometers).

In the event of a mismatch between the gear selector position and the actual transmission gear (for example, driver selects REVERSE while driving forward), the position indicator will blink continuously until the selector is returned to the proper position, or the requested shift can be completed.

conditions. The transmission electronics are

self-calibrating: therefore, the first few shifts

on a new vehicle may be somewhat abrupt.

This is a normal condition, and precision

shifts will develop within a few hundred miles

The nine-speed transmission has been devel-


FWD/AWD vehicles. Software and calibration

experience and fuel economy. By design,























129

some vehicle and driveline combinations utilize 9th gear only in very specific driving situations and conditions.

Only shift from DRIVE to PARK or REVERSE when the accelerator pedal is released and the vehicle is stopped. Be sure to keep your foot on the brake pedal when shifting between these gears.

The transmission gear selector provides PARK, REVERSE, NEUTRAL, DRIVE, and Electronic Range Select (ERS) shift positions. Manual downshifts can be made using the ERS shift control. Moving the gear selector into the ERS (-/+) position (beside the DRIVE position) activates ERS mode, displays the current gear in the instrument cluster, and prevents automatic upshifts beyond this gear. In ERS mode, toggling the gear selector forward (-) or rearward (+) will change the highest available gear.

Refer to "Electronic Range Select (ERS) Operation" in the Owner's Manual.

NOTE:

If the gear selector cannot be moved to the PARK, REVERSE, or NEUTRAL position (when pushed forward) it is probably in the ERS (+/-) position (beside the DRIVE position). In ERS mode, the transmission gear limit (1, 2, 3, etc.) is displayed in the instrument cluster. Move the gear selector to the right (into the DRIVE [D] position) for access to PARK, REVERSE, and NEUTRAL.



Gear Selector

FOUR-WHEEL DRIVE OPERATION

1-Speed Four-Wheel Drive (4X4) — If Equipped

This feature provides on-demand four-wheel drive (4X4). The system is automatic with no driver inputs or additional driving skills required. Under normal driving conditions, the front wheels provide most of the traction. If the front wheels begin to lose traction, power is shifted automatically to the rear wheels. The greater the front wheel traction loss, the greater the power transfer to the rear wheels.



1-Speed 4X4 Switch

Additionally, on dry pavement under heavy throttle input (where one may have no wheel spin), torque will be sent to the rear in a pre-emptive effort to improve vehicle launch and performance characteristics.

CAUTION!

All wheels must have the same size and type tires. Unequal tire sizes must not be used. Unequal tire size may cause failure of the power transfer unit.

2-Speed Four-Wheel Drive (4x4) — If Equipped



2-Speed 4x4 Switch



2-Speed 4x4 Switch (with Rear Lock)



The Four-Wheel Drive is fully automatic in the normal driving mode. The Selec-Terrain buttons provide three selectable mode positions:



- 4WD LOW
- REAR LOCK (If Equipped)
- NEUTRAL







When additional traction is required, the 4WD LOW range position can be used to provide an additional gear reduction which allows for increased torque to be delivered to both the front and rear wheels. 4WD LOW is intended for loose, slippery road surfaces only. Driving in 4WD LOW on dry, hard-surfaced roads may cause increased tire wear and damage to driveline components.

When operating your vehicle in 4WD LOW, the engine speed is approximately three times that of the normal driving mode at a given road speed. Take care not to overspeed the engine and do not exceed 25 mph (40 km/h).

Proper operation of four-wheel drive vehicles depends on tires of equal size, type, and circumference on each wheel. Any difference will adversely affect shifting and cause damage to the driveline components.

Because four-wheel drive provides improved traction, there is a tendency to exceed safe turning and stopping speeds. Do not go faster than road conditions permit.

Shift Positions

For additional information on the appropriate use of each 4WD system mode position, see the information below:

NEUTRAL

This range disengages the driveline from the powertrain.

WARNING!

You or others could be injured or killed if you leave the vehicle unattended with the power transfer unit in the NEUTRAL (N) position without first fully engaging the parking brake. The NEUTRAL (N) position disengages both the front and rear driveshafts from the powertrain and will allow the vehicle to roll, even if the automatic transmission is in PARK (or manual transmission is in gear). The parking brake should always be applied when the driver is not in the vehicle.

4WD LOW

This range is for low speed four-wheel drive. It provides an additional gear reduction which allows for increased torque to be delivered to both the front and rear wheels while providing maximum pulling power for loose, slippery road surfaces only. Do not exceed 25 mph (40 km/h).

NOTE:

Refer to "Selec-Terrain — If Equipped" for further information on the various positions and their intended usages.

Shifting Procedures

Shifting Into 4X4 LOW

With the vehicle at speeds of 0 to 3 mph (0 to 5 km/h), the ignition in the ON mode and the engine running, shift the transmission into NEUTRAL, and push the "4WD LOW" button once. The "4WD LOW" indicator light in the instrument cluster will begin to flash and remain on solid when the shift is complete.



Selec-Terrain Switch

NOTE:

If shift conditions/interlocks are not met, a message will flash from the instrument cluster display with instructions on how to complete the requested shift. Refer to "Instrument Cluster Display" in "Getting To know Your Instrument Panel" for further information.

Shifting Out Of 4X4 LOW

With the vehicle at speeds of 0 to 3 mph (0 to 5 km/h), the ignition in the ON mode and the engine running, shift the transmission into NEUTRAL, and push the "4WD LOW" button once. The "4WD LOW" indicator light in the instrument cluster will flash and go out when the shift is complete.

NOTE:

- If shift conditions/interlocks are not met, a message will flash from the instrument cluster display with instructions on how to complete the requested shift. Refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" for further information.
- Shifting into or out of 4WD LOW is possible with the vehicle completely stopped; however, difficulty may occur due to the mating clutch teeth not being properly aligned. Several attempts may be required for clutch teeth alignment and shift completion to occur. The preferred method is with the vehicle rolling 0 to 3 mph (0 to 5 km/h). If the vehicle is moving faster than 3 mph (5 km/h), the 4WD system will not allow the shift.

NEUTRAL Shift Procedure



WARNING!


parking brake. The NEUTRAL (N) position disengages both the front and rear drive-

shafts from the powertrain and will allow the vehicle to roll, even if the automatic

transmission is in PARK (or manual trans-

mission is in gear). The parking brake


should always be applied when the driver















is not in the vehicle.



3. Turn the ignition to the ON/RUN mode, but do not start the engine.



4. Press and hold the brake pedal.





- 5. Shift the transmission into NEUTRAL.
- 6. Using a ballpoint pen or similar object, push and hold the recessed power transfer unit NEUTRAL (N) button (located by the selector switch) for four seconds. The light behind the NEUTRAL (N) symbol will blink, indicating shift in progress. The light will stop blinking (stay on solid) when the shift to NEUTRAL (N) is complete.



Neutral Switch

- After the shift is completed and the NEU-TRAL (N) light stays on, release the NEU-TRAL (N) button.
- 8. Start the engine.
- 9. Release the parking brake.
- 10. Shift the transmission into REVERSE.
- 11. Release the brake pedal (and clutch pedal on manual transmissions) for five seconds and ensure that there is no vehicle movement.
- 12. Shift the transmission to NEUTRAL.
- 13. Apply the parking brake.
- 14. Shift the automatic transmission into PARK, or place manual transmission in gear (NOT in Neutral). Turn the engine OFF, and remove the key fob.

Repeat steps 1-7 to shift out of NEUTRAL.

Rear Electronic Locker (E-Locker) System — If Equipped

The Rear E-Locker System features a mechanical locking rear differential to provide better traction in the 4WD LOW position. The "REAR LOCK" button is on the Selec-Terrain Knob.

Activating The Rear E-Locker

To activate the Rear E-Locker System, the following conditions must be met:

- 1. The 4WD system must be in 4WD LOW.
- 2. The ignition in the ON mode and the engine running.
- 3. Vehicle speed must be below 15 MPH (24 km/h).
- 4. To engage Rear E-Locker, push the REAR LOCK button once.

Deactivating The Rear E-Locker System

To deactivate the Rear E-Locker System, the following conditions must be met:

1. Rear E-Locker must be engaged, and the REAR LOCK indicator light on.

- 2. The ignition in the ON mode and the engine running.
- 3. To disengage Rear E-Locker, push the REAR LOCK button once.

NOTE:

- It may also be necessary to drive slowly steering back and forth to complete engagement and disengagement of the F-locker.
- When engaging Rear E-Locker, the indicator lights in the instrument cluster and on the REAR LOCK button will begin to flash.
 When the shift is complete the REAR LOCK indicator lights will remain on.
- When disengaging Rear E-Locker, the indicator lights in the instrument cluster and on the REAR LOCK button will begin to flash.
 When the shift is complete the REAR LOCK indicator lights will remain off.
- Shifting into or out of Rear E-Locker is possible with the vehicle completely stopped; however, difficulty may occur due to the mating clutch teeth not being properly aligned. Several attempts may be required for clutch teeth alignment and shift completion to occur. The preferred method

- is for the vehicle to be rolling, below 15 MPH (24 km/h), while including right and left steering maneuvers to allow for the clutch teeth to align.
- The Rear E-Locker System must be disengaged prior to taking the vehicle out of 4WD LOW range. If 4WD LOW shift conditions/ interlocks are not met, a message will flash from the instrument cluster display with instructions on how to complete the requested shift.

SELEC-TERRAIN

Description

Selec-Terrain combines the capabilities of the vehicle control systems, along with driver input, to provide the best performance for all terrains.

Rotate the Selec-Terrain knob to select the desired mode.







- Auto Fully automatic full time four-wheel drive operation can be used on and off road. Balances traction with seamless steering feel to provide improved handling and acceleration over two-wheel drive vehicles.
- Snow Tuning set for additional stability in inclement weather. Use on and off road on loose traction surfaces such as snow. When in SNOW mode (depending on cer-





















tain operating conditions), the transmission may use second gear (rather than first gear) during launches, to minimize wheel slippage.

Sport — This mode alters the transmission's automatic shift schedule for sportier driving. Upshift speeds are increased to make full use of available engine power.

NOTE:

SPORT mode is not available when 4WD LOW is selected.

- Sand/Mud Off-road calibration for use on low traction surfaces such as mud, sand, or wet grass. Driveline is maximized for traction. Some binding may be felt on less forgiving surfaces. The electronic brake controls are set to limit traction control management of throttle and wheel spin.
- Rock Off-road calibration only available in 4WD LOW range. Traction based tuning with improved steer-ability for use on high traction off-road surfaces. Use for low speed obstacles such as large rocks, deep ruts, etc.

NOTE:

- Rock mode is only available on the vehicles equipped with the Off-Road package.
- Activate the Hill Descent Control or Selec Speed Control for steep downhill control.
 See "Electronic Brake Control System" in "Safety" for further information.

STOP/START SYSTEM — IF EQUIPPED

The Stop/Start function was developed to reduce fuel consumption. The system will stop the engine automatically during a vehicle stop if the required conditions are met. Releasing the brake pedal or pressing the accelerator pedal will automatically restart the engine.

This vehicle has been upgraded with a Heavy Duty Battery, Starter, as well as other engine parts, to handle the Additional engine starts.

Automatic Mode

The Stop/Start feature is enabled after every normal customer engine start. At that time, the system will go into STOP/START READY and if all other conditions are met, can go into a STOP/START AUTOSTOP ACTIVE "Autostop" mode.

To Activate The Autostop Mode, The Following Must Occur:

- The system must be in STOP/START READY state. A STOP/START READY message will be displayed in the instrument cluster display within the Stop/Start section. Refer to "Warning Lights And Messages" in "Getting To Know Your Instrument Panel" in your Owner's Manual.
- The vehicle must be completely stopped.
- The gear selector must be in a forward gear and the brake pedal depressed.

The engine will shut down, the tachometer will move to the zero position and the Stop/ Start telltale will illuminate indicating you are in Autostop. Customer settings will be maintained upon return to an engine running condition.

Refer to the "Stop/Start System" in the "Starting And Operating" in your Owner's Manual.

Possible Reasons The Engine Does Not Autostop

Prior to engine shut down, the system will check many safety and comfort conditions to see if they are fulfilled. Detailed information about the operation of the Stop/Start system may be viewed in the instrument cluster display Stop/Start Screen. In the following situations the engine will not stop:

- Driver's seat belt is not buckled.
- Driver's door is not closed.
- Battery temperature is too warm or cold.
- Battery charge is low.
- The vehicle is on a steep grade.
- Cabin heating or cooling is in process and an acceptable cabin temperature has not been achieved.
- HVAC is set to full defrost mode at a high blower speed.
- HVAC set to MAX A/C.

- Engine has not reached normal operating temperature.
- The transmission is not in a forward or reverse gear.
- Hood is open.
- Vehicle is in 4LO transfer case mode (if equipped with 4WD).
- Brake pedal is not pressed with sufficient pressure with vehicle in DRIVE position.

Other Factors Which Can Inhibit Autostop Include:

- Accelerator pedal input.
- Engine temp too high.
- 5 mph threshold not achieved from previous AUTOSTOP.
- Steering angle beyond threshold.
- ACC is on and speed is set.

It may be possible for the vehicle to be driven several times without the STOP/START system going into a STOP/START READY state under more extreme conditions of the items listed above.

To Start The Engine While In Autostop Mode



While in a forward gear, the engine will start when the brake pedal is released or the throttle pedal is depressed. The transmission will automatically re-engage upon engine restart.



Conditions That Will Cause The Engine To Start Automatically While In Autostop Mode:



• The transmission gear selector is moved out of DRIVE except in the PARK position.



- To maintain cabin temperature comfort.
- HVAC is set to full defrost mode.



 HVAC system temperature or fan speed is manually adjusted.



• Battery voltage drops too low.



• Low brake vacuum (e.g. after several brake pedal applications).



• STOP/START OFF switch is pushed.



• A STOP/START system error occurs.



• 4WD system is put into 4LO mode (if equipped with 4WD).





Conditions That Force An Application Of The Electric Park Brake While In Autostop Mode:

- The driver's door is open and brake pedal released.
- The driver's door is open and the driver's seat belt is unbuckled.
- The engine hood has been opened.
- A STOP/START system error occurs.

If the Electric Park Brake is applied with the engine off, the engine may require a manual restart and the electric park brake may require a manual release (depress brake pedal and push Electric Park Brake switch). Refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" in your Owner's Manual.

To Manually Turn Off The Stop/Start System

 Push the STOP/START Off switch (located on the switch bank). The light on the switch will illuminate.



STOP/START OFF Switch

- 2. The "STOP/START OFF" message will appear in the instrument cluster display. Refer to "Warning Lights And Messages" in "Getting To Know Your Instrument Panel" in your Owner's Manual.
- At the next vehicle stop (after turning off the STOP/START system), the engine will not be stopped.
- The STOP/START system will reset itself back to the ON mode every time the ignition is turned off and back on.

To Manually Turn On The Stop/Start System

Push the STOP/START Off switch (located on the switch bank). The light on the switch will turn off.

For complete details on the Stop/Start System, refer to the "Stop/Start System" in the "Starting And Operating" section located in your Owner's Manual.

STOP/START SYSTEM — DIESEL MODELS ONLY

The Stop/Start function is developed to save fuel and reduce emissions. The system will stop the engine automatically during a vehicle stop if the required conditions are met. Releasing the brake pedal or pressing the accelerator pedal on an automatic transmission or pressing the clutch pedal on a manual transmission will automatically restart the engine.

Automatic Mode

The Stop/Start feature is enabled after every normal customer engine start. It will remain in STOP/START NOT READY until you drive forward with a vehicle speed greater than 4 mph (7 km/h). At that time, the system will go into STOP/START READY and if all other conditions are met, can go into a STOP/START AUTOSTOP ACTIVE "Autostop" mode.

To Activate The Autostop Mode, The Following Must Occur:

- The system must be in STOP/START READY state. A STOP/START READY message will be displayed in the instrument cluster display within the Stop/Start section. Refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" in your Owner's information for further details.
- The vehicle must be completely stopped.
- The gear selector must be in DRIVE and the brake pedal depressed (automatic transmission) or the gear selector must be in NEUTRAL and the clutch pedal must be fully released (manual transmission).

The engine will shut down, the tachometer will move to the zero position and the Stop/Start telltale will illuminate indicating you are in Autostop. While in Autostop, the Climate Controls system may automatically adjust airflow to maintain cabin comfort. Customer settings will be maintained upon return to an engine running condition.


Possible Reasons The Engine Does Not Autostop

Prior to engine shut down, the system will check many safety and comfort conditions to see if they are fulfilled. Detailed information about the operation of the Stop/Start system may be viewed in the instrument cluster Stop/Start Screen. In the following situations the engine will not stop:

- Driver's seat belt is not buckled.
- Driver's door is not closed.
- Battery temperature is too warm or cold.
- The vehicle is on a steep grade.
- Cabin heating or cooling is in process and an acceptable cabin temperature has not been achieved.

 HVAC is set to full defrost mode at a high blower speed.







• Battery charge is low.



The transmission is not in DRIVE (automatic transmission) or NEUTRAL (manual transmission).




• Hood is open.



• Vehicle is in 4LO transfer case mode.



• Exhaust system regeneration in process.





Fuel level.



Accelerator pedal input (automatic transmission only).



Engine temperature too high.



It may be possible for the vehicle to be driven several times without the STOP/START system going into a STOP/START READY state under more extreme conditions of the items listed above.





To Start The Engine While In Autostop Mode

Automatic Transmission:

While in DRIVE, the engine will start when the brake pedal is released or the throttle pedal is depressed. The transmission will automatically re-engage upon engine restart. During this transition, the brakes will hold the vehicle to avoid undesired vehicle movement.

Manual Transmission:

When the gear selector is in NEUTRAL, the engine will start when the clutch pedal is pressed. The vehicle will go into STOP/START SYSTEM NOT READY mode until the vehicle speed is greater than 4 mph (7 km/h).

Conditions That Will Cause The Engine To Start Automatically While In Autostop Mode:

- The transmission gear selector is moved from DRIVE to REVERSE or NEUTRAL.
- To maintain cabin temperature comfort.
- HVAC is set to full defrost mode.

- Battery voltage drops too low.
- Low brake vacuum (e.g. after several brake pedal applications).
- STOP/START OFF switch is pushed.
- 4WD system is put into 4LO mode.
- The emissions system requires it.
- A STOP/START system error occurs.
- HVAC system temperature or fan speed is manually adjusted.

Conditions That Force An Application Of The Electric Park Brake While In Autostop Mode:

- The driver door is open and brake pedal released.
- The driver door is open and the driver seat belt is unbuckled.
- The engine hood has been opened.
- A STOP/START system error occurs.

If the Electric Park Brake is applied with the engine off, the engine may require a manual restart and the electric park brake may require a manual release (depress brake pedal and push Electric Park Brake switch). Refer

to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" in your Owner's Manual for further information.

To Manually Turn Off The Stop/Start System

 Push the STOP/START Off switch (located on the switch bank). The light on the switch will illuminate.



STOP/START OFF Switch

The "STOP/START OFF" message will appear in the instrument cluster display.
 Refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" in your Owner's manual for further information.

- At the next vehicle stop (after turning off the STOP/START system) the engine will not be stopped.
- If the STOP/START system is manually turned off, the engine can only be started and stopped by cycling the ignition switch.
- The STOP/START system will reset itself back to an ON condition every time the key is turned off and back on.

To Manually Turn On The Stop/Start System

Push the STOP/START Off switch (located on the switch bank). The light on the switch will turn off.

SPEED CONTROL

The Speed Control switches are located on the right side of the steering wheel.



Speed Control Switches

- 1 Push Cancel
- 2 Push Set+/Accel
- 3 Push Resume
- 4 Push On/Off
- 5 Push Set-/Decel

Activation

Push the on/off button to activate the Speed Control, "CRUISE CONTROL READY" will appear on the instrument cluster display to indicate the Speed Control is on. Push the on/off button a second time to turn the system off, "CRUISE CONTROL OFF" will appear on the instrument cluster display to indicate the Speed Control is off. The system should be turned off when not in use.

WARNING!

Leaving the Speed Control system on when not in use is dangerous. You could acci-

dentally set the system or cause it to go

faster than you want. You could lose con-

trol and have an accident. Always leave the system off when you are not using it.















Turn the Speed Control on. When the vehicle has reached the desired speed, push the SET (+) or SET (-) button and release. Release the accelerator and the vehicle will operate at the selected speed. Once a speed has been set, a message "CRUISE CONTROL SET TO MPH (km/h)" will appear indicating what speed











was set. A cruise indicator lamp, along with set speed will also appear and stay on in the instrument cluster display when the speed is set.

Varying The Speed

Once the Speed Control has been activated, the speed can be increased or decreased.

To Increase Speed

When the Speed Control is set, you can increase speed by pushing the SET (+) button.

The driver's preferred units can be selected through the instrument panel settings if equipped. Refer to "Getting To Know Your Instrument Panel" in the Owner's Manual for more information. The speed increment shown is dependant on the chosen speed unit of U.S. (mph) or Metric (km/h):

U.S. Speed (mph)

• Pushing the SET (+) button once will result in a 1 mph increase in set speed. Each subsequent tap of the button results in an increase of 1 mph. If the button is continually pushed, the set speed will continue to increase until the button is released, then the new set speed will be established.

Metric Speed (km/h)

- Pushing the SET (+) button once will result in a 1 km/h increase in set speed. Each subsequent tap of the button results in an increase of 1 km/h.
- If the button is continually pushed, the set speed will continue to increase until the button is released, then the new set speed will be established.

To Decrease Speed

When the Speed Control is set, you can decrease speed by pushing the SET (-) button.

The driver's preferred units can be selected through the instrument panel settings if equipped. Refer to "Getting To Know Your Instrument Panel" in the Owner's Manual for more information. The speed increment shown is dependant on the chosen speed unit of U.S. (mph) or Metric (km/h):

U.S. Speed (mph)

- Pushing the SET (-) button once will result in a 1 mph decrease in set speed. Each subsequent tap of the button results in a decrease of 1 mph.
- If the button is continually pushed, the set speed will continue to decrease until the button is released, then the new set speed will be established.

Metric Speed (km/h)

- Pushing the SET (-) button once will result in a 1 km/h decrease in set speed. Each subsequent tap of the button results in a decrease of 1 km/h.
- If the button is continually pushed, the set speed will continue to decrease until the button is released, then the new set speed will be established.

Resume

To resume a previously selected set speed in memory, push and release the RES button.

Accelerating For Passing

Press the accelerator as you would normally. When the pedal is released, the vehicle will return to the set speed.

Deactivation

A soft tap on the brake pedal, pushing the CANC button, or normal brake pressure while slowing the vehicle will deactivate the Speed Control without erasing the set speed from memory.

Pushing the on/off button or turning the ignition switch OFF erases the set speed from memory.

ADAPTIVE CRUISE CONTROL (ACC)

If your vehicle is equipped with Adaptive Cruise Control, the controls operate exactly the same as the Speed Control with only a couple of differences. With this option, you can set a specified distance you would like to maintain between you and the vehicle in front of you.



Adaptive Cruise Switches


- 1 Adaptive Cruise Control (ACC) On/Off
- 2 Distance Setting Decrease
- 3 Distance Setting Increase

If the ACC sensor detects a vehicle ahead. ACC will apply limited braking or acceleration automatically to maintain a preset following distance, while matching the speed of the vehicle ahead.

If the sensor does not detect a vehicle ahead of you, ACC will maintain a fixed set speed.



Activation



"ACC READY" will appear in the instrument cluster display to indicate the ACC is on.



Setting A Desired ACC Speed

When the vehicle reaches the speed desired, push the SET (+) button or the SET (-) button and release. The instrument cluster display will show the set speed.



If the system is set when the vehicle speed is below 19 mph (30 km/h), the set speed shall be defaulted to 19 mph (30 km/h). If the system is set when the vehicle speed is above 19 mph (30 km/h), the set speed shall be the current speed of the vehicle.



NOTE:

ACC cannot be set if there is a stationary vehicle in front of your vehicle in close proximity.









Remove your foot from the accelerator pedal. If you do not, the vehicle may continue to accelerate beyond the set speed. If this occurs:

- The message "DRIVER OVERRIDE" will appear in the instrument cluster display.
- The system will not be controlling the distance between your vehicle and the vehicle ahead. The vehicle speed will only be determined by the position of the accelerator pedal.

Varying The Speed

Once the ACC has been activated, the speed can be increased or decreased.

NOTE:

- When you override and push the SET (+) button or SET (-) buttons, the new set speed will be the current speed of the vehicle.
- When you use the SET (-) button to decelerate, if the engine's braking power does not slow the vehicle sufficiently to reach the set speed, the brake system will automatically slow the vehicle.

- The ACC system applies the brake down to a full stop when following a target vehicle.
 If an ACC host vehicle follows a target vehicle to a standstill, the host vehicle will release the vehicle brakes two seconds after coming to a full stop.
- The ACC system maintains set speed when driving up hill and down hill. However, a slight speed change on moderate hills is normal. In addition, downshifting may occur while climbing uphill or descending downhill. This is normal operation and necessary to maintain set speed. When driving up hill and down hill, the ACC system will cancel if the braking temperature exceeds normal range (overheated).

To Increase Speed

While ACC is set, you can increase the set speed by pushing the SET (+) button.

The driver's preferred units can be selected through the instrument panel settings if equipped. Refer to "Getting To Know Your Instrument Panel" in the Owner's Manual for further information. The speed increment shown is dependant on the chosen speed unit of U.S. (mph) or Metric (km/h):

U.S. Speed (mph)

- Pushing the SET (+) button once will result in a 1 mph increase in set speed. Each subsequent tap of the button results in an increase of 1 mph.
- If the button is continually pushed, the set speed will continue to increase in 5 mph increments until the button is released.
 The increase in set speed is reflected in the instrument cluster display.

Metric Speed (km/h)

- Pushing the SET (+) button once will result in a 1 km/h increase in set speed. Each subsequent tap of the button results in an increase of 1 km/h.
- If the button is continually pushed, the set speed will continue to increase in 10 km/h increments until the button is released. The increase in set speed is reflected in the instrument cluster display.

To Decrease Speed

While ACC is set, the set speed can be decreased by pushing the SET (-) button.

The driver's preferred units can be selected through the instrument panel settings if equipped. Refer to "Getting To Know Your Instrument Panel" in the Owner's Manual for further information. The speed increment shown is dependant on the chosen speed unit of U.S. (mph) or Metric (km/h):

U.S. Speed (mph)

- Pushing the SET (-) button once will result in a 1 mph decrease in set speed. Each subsequent tap of the button results in a decrease of 1 mph.
- If the button is continually pushed, the set speed will continue to decrease in 5 mph decrements until the button is released. The decrease in set speed is reflected in the instrument cluster display.

Metric Speed (km/h)

 Pushing the SET (-) button once will result in a 1 km/h decrease in set speed. Each subsequent tap of the button results in a decrease of 1 km/h. If the button is continually pushed, the set speed will continue to decrease in 10 km/h decrements until the button is released. The decrease in set speed is reflected in the instrument cluster display.

Resume

If there is a set speed in memory, push the RES (resume) button and remove your foot from the accelerator pedal. The instrument cluster display will show the last set speed.

NOTE:

- If your vehicle stays at standstill for longer than two seconds, the driver will either have to push the RES (resume) button or apply the accelerator pedal to reengage the ACC to the existing set speed.
- ACC cannot be resumed if there is a stationary vehicle in-front of your vehicle in close proximity.

WARNING!

The Resume function should only be used if traffic and road conditions permit. Resuming a set speed that is too high or too

WARNING!



low for prevailing traffic and road conditions could cause the vehicle to accelerate or decelerate too sharply for safe operation. Failure to follow these warnings can result in a collision and death or serious personal injury.



ious





Push and release the Adaptive Cruise Control (ACC) on/off button a second time to turn the system off.



"Adaptive Cruise Control (ACC) Off" will appear in the instrument cluster display to indicate the ACC is off.



Setting The Following Distance



The specified following distance for ACC can be set by varying the distance setting between four bars (longest), three bars (long), two bars (medium) and one bar (short). Using this distance setting and the vehicle speed, ACC calculates and sets the distance to the vehicle ahead. This distance setting appears in the instrument cluster display.







- To increase the distance setting, push the Distance Setting—Increase button and release. Each time the button is pushed, the distance setting increases by one bar (longer).
- To decrease the distance setting, push the Distance Setting—Decrease button and release. Each time the button is pushed, the distance setting decreases by one bar (shorter).

Changing Modes

If desired, the Adaptive Cruise Control mode can be turned off and the system can be operated as a Normal (Fixed Speed) Cruise Control mode. When in the Normal (Fixed Speed) Cruise Control mode the distance setting feature will be disabled and the system will maintain the speed you set.

 To change between the different cruise control modes, push the Adaptive Cruise Control (ACC) on/off button which turns the ACC and the Normal (Fixed Speed) Cruise Control off. Pushing the Normal (Fixed Speed) Cruise Control on/off button will result in turning on (changing to) the Normal (Fixed Speed) Cruise Control mode.

Refer to "Normal (Fixed Speed) Cruise Control Mode" in "Starting And Operating" in your Owner's Manual for further information.

WARNING!

Adaptive Cruise Control (ACC) is a convenience system. It is not a substitute for active driving involvement. It is always the driver's responsibility to be attentive of road, traffic, and weather conditions, vehicle speed, distance to the vehicle ahead; and, most importantly, brake operation to ensure safe operation of the vehicle under all road conditions. Your complete attention is always required while driving to maintain safe control of your vehicle. Failure to follow these warnings can result in a collision and death or serious personal injury.

The ACC system:

• Does not react to pedestrians, oncoming vehicles, and stationary objects (e.g., a

WARNING!

stopped vehicle in a traffic jam or a disabled vehicle).

- Cannot take street, traffic, and weather conditions into account, and may be limited upon adverse sight distance conditions.
- Does not always fully recognize complex driving conditions, which can result in wrong or missing distance warnings.
- Will bring the vehicle to a complete stop
 while following a target vehicle and hold
 the vehicle for 2 seconds in the stop
 position. If the target vehicle does not
 start moving within two seconds the ACC
 system will display a message that the
 system will release the brakes and that
 the brakes must be applied manually. An
 audible chime will sound when the
 brakes are released.

You should switch off the ACC system:

 When driving in fog, heavy rain, heavy snow, sleet, heavy traffic, and complex driving situations (i.e., in highway construction zones).

- When entering a turn lane or highway off ramp; when driving on roads that are winding, icy, snow-covered, slippery, or have steep uphill or downhill slopes.
- When towing a trailer up or down steep slopes.
- When circumstances do not allow safe driving at a constant speed.

The Cruise Control system has two control modes:

- Adaptive Cruise Control mode for maintaining an appropriate distance between vehicles.
- Normal (Fixed Speed) Cruise Control mode for cruising at a constant preset speed. For additional information, refer to "Normal (Fixed Speed) Cruise Control Mode" in your Owner's Manual for further information.

Normal (Fixed Speed) Cruise Control will not react to preceding vehicles. Always be aware of the mode selected. You can change the mode by using the Cruise Control buttons. The two control modes function differently. Always confirm which mode is selected.

PARKSENSE REAR PARK ASSIST

ParkSense Sensors

The four ParkSense sensors, located in the rear fascia/bumper, monitor the area behind the vehicle that is within the sensors' field of view. The sensors can detect obstacles from approximately 12 inches (30 cm) up to 79 inches (200 cm) from the rear fascia/bumper in the horizontal direction, depending on the location, type and orientation of the obstacle.

Enabling And Disabling ParkSense

ParkSense can be enabled and disabled with the ParkSense switch, located on the switch panel below the Uconnect display.


When the ParkSense switch is pushed to disable the system, the instrument cluster display will show the "PARKSENSE OFF" message for approximately five seconds. Refer to "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" in your

Owner's Manual for further information. When the gear selector is moved to REVERSE and the system is disabled, the instrument cluster display will show the "PARKSENSE OFF" message for as long as the vehicle is in REVERSE.















tarily, and then the LED will be on.

switch is pushed, and requires service, the

ParkSense switch LED will blink momen-

The ParkSense Warning screen will only be displayed if Sound and Display is selected from the Customer - Programmable Features section of the Uconnect System. Refer to "Uconnect Settings" in "Multimedia" in your Owner's Manual for further information.









The ParkSense Warning screen is located within the instrument cluster display. It provides visual warnings to indicate the distance between the rear fascia/bumper and the detected obstacle. Refer to "Instrument Cluster Display" in your Owner's Manual for further information.

ParkSense System Usage Precautions

- Ensure that the rear bumper is free of snow, ice, mud, dirt and debris to keep the ParkSense system operating properly.
- Jackhammers, large trucks, and other vibrations could affect the performance of ParkSense.
- When you turn ParkSense off, the instrument cluster display will read "PARKSENSE OFF". Furthermore, once you turn ParkSense off, it remains off until you turn it on again, even if you cycle the ignition.
- When you move the gear selector to the REVERSE position and ParkSense is turned off, the instrument cluster display will show a "PARKSENSE OFF" message for as long as the vehicle is in REVERSE.

- ParkSense, when on, will reduce the volume of the radio when it is sounding a tone.
- Clean the ParkSense sensors regularly, taking care not to scratch or damage them.
 The sensors must not be covered with ice, snow, slush, mud, dirt or debris. Failure to do so can result in the system not working properly. The ParkSense system might not detect an obstacle behind the fascia/bumper, or it could provide a false indication that an obstacle is behind the fascia/bumper.
- Use the ParkSense switch to turn the ParkSense system OFF if objects such as bicycle carriers, etc. are placed within 12 inches (30 cm) from the rear fascia/ bumper. Failure to do so can result in the system misinterpreting a close object as a sensor problem, causing the "PARKSENSE UNAVAILABLE SERVICE REQUIRED" message to be displayed in the instrument cluster display.
- ParkSense should be disabled when the liftgate is in the open position and the vehicle is in REVERSE. An open liftgate could provide a false indication that an obstacle is behind the vehicle.

WARNING!

- Drivers must be careful when backing up even when using ParkSense. Always check carefully behind your vehicle, look behind you, and be sure to check for pedestrians, animals, other vehicles, obstructions, and blind spots before backing up. You are responsible for safety and must continue to pay attention to your surroundings. Failure to do so can result in serious injury or death.
- Before using ParkSense, it is strongly recommended that the ball mount and hitch ball assembly is disconnected from the vehicle when the vehicle is not used for towing. Failure to do so can result in injury or damage to vehicles or obstacles because the hitch ball will be much closer to the obstacle than the rear fascia when the loudspeaker sounds the continuous tone. Also, the sensors could detect the ball mount and hitch ball assembly, depending on its size and shape, giving a false indication that an obstacle is behind the vehicle.

CAUTION!

- ParkSense is only a parking aid and it is unable to recognize every obstacle, including small obstacles. Parking curbs might be temporarily detected or not detected at all. Obstacles located above or below the sensors will not be detected when they are in close proximity.
- The vehicle must be driven slowly when using ParkSense in order to be able to stop in time when an obstacle is detected. It is recommended that the driver looks over his/her shoulder when using ParkSense.

PARKSENSE FRONT AND REAR PARK ASSIST

ParkSense Sensors

The four ParkSense sensors, located in the rear fascia/bumper, monitor the area behind the vehicle that is within the sensors' field of view. The sensors can detect obstacles from approximately 12 inches (30 cm) up to

79 inches (200 cm) from the rear fascia/ bumper in the horizontal direction, depending on the location, type and orientation of the obstacle.

NOTE:

If your vehicle is equipped with the ParkSense Active Park Assist system, six sensors will be located in the rear fascia/bumper. Refer to the "ParkSense Active Park Assist System" section for further information.


The six ParkSense sensors, located in the front fascia/bumper, monitor the area in front of the vehicle that is within the sensors' field of view. The sensors can detect obstacles from approximately 12 inches (30 cm) up to 47 inches (120 cm) from the front fascia/bumper in the horizontal direction, depending on the location, type and orientation of the obstacle.

Enabling And Disabling ParkSense

ParkSense can be enabled and disabled with the ParkSense switch, located on the switch panel below the Uconnect display.





























and the system is disabled, the instrument cluster display will show the "PARKSENSE OFF" message for as long as the vehicle is in REVERSE.

The ParkSense switch LED will be on when ParkSense is disabled or requires service. The ParkSense switch LED will be off when the system is enabled. If the ParkSense switch is pushed, and requires service, the ParkSense switch LED will blink momentarily, and then the LED will be on.

Engagement/Disengagement

To disengage the system, push the ParkSense switch, located on the switch panel below the Uconnect display.

When the system passes from engaged to disengaged and vice versa, it is always accompanied by a dedicated message in the instrument cluster display.

System engaged: ParkSense switch LED off.

System disengaged: ParkSense switch LED on constantly.

The ParkSense switch LED lights up also in the case of a ParkSense system failure. If the button is pushed with a system failure, the ParkSense switch LED flashes for about 5 seconds, then it stays on constantly.

After the ParkSense has been disengaged, it will stay in this condition until the following engagement, even if the ignition device passes from ON/RUN to OFF and then again to ON/RUN.

Operation With A Trailer

The operation of the sensors is automatically deactivated when the trailer's electric plug is inserted in the vehicle's tow hook socket. The sensors are automatically reactivated when the trailer's cable plug is removed.

General Warnings

If "PARKSENSE UNAVAILABLE WIPE REAR SENSORS" or "PARKSENSE UNAVAILABLE WIPE FRONT SENSORS" appears in the instrument cluster display, clean the ParkSense sensors with water, car wash soap and a soft cloth. Do not use rough or hard cloths. Do not scratch or poke the sensors. Otherwise, you could damage the sensors.

PARKSENSE ACTIVE PARK ASSIST

Enabling And Disabling ParkSense Active Park Assist

The ParkSense Active Park Assist system can be enabled and disabled with the ParkSense Active Park Assist switch, located on the switch panel below the Uconnect display.



ParkSense Active Park Assist Switch

The ParkSense Active Park Assist system is intended to assist the driver during parallel and perpendicular parking maneuvers by identifying a proper parking space, providing audible/visual instructions, and controlling the steering wheel. The ParkSense Active Park Assist system is defined as "semi-automatic" since the driver maintains control of the accelerator, gear selector and brakes. Depending on the driver's parking maneuver selection, the ParkSense Active Park Assist system is capable of maneuvering a vehicle into a parallel or a perpendicular parking space on either side (i.e., driver side or passenger side).

NOTE:

The ParkSense Active Park Assist system automatically defaults to looking for vehicles on the right. To search for a parking spot on the left, use the left turn signal.

Refer to your Owner's Manual for further information.

WARNING!

- Drivers must be careful when backing up even when using ParkSense. Always check carefully behind your vehicle, look behind you, and be sure to check for pedestrians, animals, other vehicles, obstructions, and blind spots before backing up. You are responsible for safety and must continue to pay attention to your surroundings. Failure to do so can result in serious injury or death.
- Before using ParkSense, it is strongly recommended that the ball mount and hitch ball assembly is disconnected from the vehicle when the vehicle is not used for towing. Failure to do so can result in injury or damage to vehicles or obstacles because the hitch ball will be much closer to the obstacle than the rear fascia when the loudspeaker sounds the continuous tone. Also, the sensors could detect the ball mount and hitch ball assembly, depending on its size and shape, giving a false indication that an obstacle is behind the vehicle.

• ParkSense is only a parking aid and it is

unable to recognize every obstacle, in-

cluding small obstacles. Parking curbs

might be temporarily detected or not

detected at all. Obstacles located above

or below the sensors will not be detected.

using ParkSense in order to be able to

stop in time when an obstacle is de-

tected. It is recommended that the

driver looks over his/her shoulder when

when they are in close proximity.

• The vehicle must be driven slowly when















using ParkSense.



The LaneSense system is operational at speeds above 37 mph (60 km/h) and below 112 mph (180 km/h). The LaneSense system uses a forward looking camera to detect lane markings and measure vehicle position within the lane boundaries.









When both lane markings are detected and the driver unintentionally drifts out of the lane (no turn signal applied), the LaneSense system provides a haptic warning in the form of torque applied to the steering wheel, as well as a visual warning in the instrument cluster display, to prompt the driver to remain within the lane boundaries.

The driver may manually override the haptic warning by applying torque into the steering wheel at any time.

When only a single lane marking is detected and the driver unintentionally drifts across the lane marking (no turn signal applied), the LaneSense system provides a visual warning through the instrument cluster display to prompt the driver to remain within the lane. When only a single lane marking is detected, a haptic (torque) warning will not be provided.

NOTE:

When operating conditions have been met, the LaneSense system will monitor if the driver's hands are on the steering wheel and provide an audible and visual warning to the driver when the driver's hands are not detected on the steering wheel. The system will cancel if the driver does not return their hands to the wheel.

Turning LaneSense On Or Off

The default status of LaneSense is "off".

The LaneSense button is located on the switch panel below the Uconnect display.

To turn the LaneSense system on, push the LaneSense button (LED turns off). A "LaneSense On" message is shown in the instrument cluster display.

To turn the LaneSense system off, push the LaneSense button once (LED turns on).

NOTE:

The LaneSense system will retain the last system state, on or off, from the last ignition cycle when the ignition is changed to the ON/RUN position.

LaneSense Warning Message

The LaneSense system will indicate the current lane drift condition through the instrument cluster display.

Base Instrument Cluster Display — If Equipped

When the LaneSense system is on; the lane lines are gray when both of the lane boundaries have not been detected and the Lane-Sense telltale is solid white.

Left Lane Departure — Only Left Lane Detected

- When the LaneSense system is on, the LaneSense telltale is solid white when only the left lane marking has been detected and the system is ready to provide visual warnings in the instrument cluster display if an unintentional lane departure occurs.
- When the LaneSense system senses the lane has been approached and is in a lane departure situation, the left thick lane line flashes from white to gray, the left thin line remains solid white and the LaneSense telltale changes from solid white to flashing yellow.

NOTE:

The LaneSense system operates with the similar behavior for a right lane departure when only the right lane marking has been detected.

Left Lane Departure — Both Lanes Detected

- When the LaneSense system is on, the lane lines turn from grav to white to indicate that both of the lane markings have been detected. The LaneSense telltale is solid green when both lane markings have been detected and the system is "armed" to provide visual warnings in the instrument cluster display and a torque warning in the steering wheel if an unintentional lane departure occurs.
- When the LaneSense system senses a lane drift situation, the left thick lane line and the left thin line turn solid white. The Lane-Sense telltale changes from solid green to solid vellow. At this time torque is applied to the steering wheel in the opposite direction of the lane boundary.

For example: If approaching the left side of the lane the steering wheel will turn to the right.

 When the LaneSense system senses the lane has been approached and is in a lane departure situation, the left thick lane line flashes from white to gray, the left thin line remains solid white and the LaneSense telltale changes from solid yellow to flashing yellow. At this time torque is applied to the steering wheel in the opposite direction of the lane boundary.

For example: If approaching the left side of the lane the steering wheel will turn to the right.

NOTE:

The LaneSense system operates with the similar behavior for a right lane departure.

Premium Instrument Cluster Display — If Equipped

When the LaneSense system is on; the lane lines are gray when both of the lane boundaries have not been detected and the Lane-Sense telltale is solid white.

Left Lane Departure — Only Left Lane Detected



 When the LaneSense system is on, the LaneSense telltale is solid white when only the left lane marking has been detected and the system is ready to provide visual warnings in the instrument cluster display if an unintentional lane departure occurs.



 When the LaneSense system senses the lane has been approached and is in a lane departure situation, the left thick lane line flashes yellow (on/off), the left thin line remains solid yellow and the LaneSense telltale changes from solid white to flashing







yellow. NOTE:

The LaneSense system operates with the similar behavior for a right lane departure when only the right lane marking has been detected.





Left Lane Departure — Both Lanes Detected

• When the LaneSense system is on, the lane lines turn from gray to white to indicate that both of the lane markings have been detected. The LaneSense telltale is solid green when both lane markings have been detected and the system is "armed" to







provide visual warnings in the instrument cluster display and a torque warning in the steering wheel if an unintentional lane departure occurs.

 When the LaneSense system senses a lane drift situation, the left thick lane line and left thin line turn solid yellow. The Lane-Sense telltale changes from solid green to solid yellow. At this time torque is applied to the steering wheel in the opposite direction of the lane boundary.

For example: If approaching the left side of the lane the steering wheel will turn to the right.

• When the LaneSense system senses the lane has been approached and is in a lane departure situation, the left thick lane line flashes yellow (on/off) and the left thin line remains solid yellow. The LaneSense telltale changes from solid yellow to flashing yellow. At this time torque is applied to the steering wheel in the opposite direction of the lane boundary.

For example: If approaching the left side of the lane the steering wheel will turn to the right.

NOTE:

The LaneSense system operates with the similar behavior for a right lane departure.

Changing LaneSense Status

The LaneSense system has settings to adjust the intensity of the torque warning and the warning zone sensitivity (early/late) that you can configure through the Uconnect system screen. Refer to "Uconnect Settings" in "Multimedia" in your Owner's Manual for further information.

NOTE:

- When enabled the system operates above 37 mph (60 km/h) and below 112 mph (180 km/h).
- Use of the turn signal suppresses the warnings.
- The system will not apply torque to the steering wheel whenever a safety system engages (anti-lock brakes, traction control system, electronic stability control, forward collision warning, etc.).

PARKVIEW REAR BACK-UP CAMERA

Symbols And Messages On The Display

You can see an on-screen image of the rear of your vehicle whenever the transmission is shifted into REVERSE. The ParkView Rear Back-Up Camera image will be displayed on the Uconnect Display, located on the center stack of the instrument panel.

If the Uconnect Display appears foggy, clean the camera lens located on the rear of the vehicle above the rear license plate.

Refer to "ParkView Back-Up Camera" in "Starting And Operating" in your Owner's Manual for further information.

WARNING!

Drivers must be careful when backing up; even when using the ParkView Rear Back-Up Camera. Always check carefully behind your vehicle, and be sure to check for pedestrians, animals, other vehicles, obstructions, or blind spots before backing

up. You must continue to pay attention while backing up. Failure to do so can result in serious injury or death.

CAUTION!

- To avoid vehicle damage, ParkView should only be used as a parking aid. The ParkView camera is unable to view every obstacle or object in your drive path.
- To avoid vehicle damage, the vehicle must be driven slowly when using ParkView to be able to stop in time when an obstacle is seen. It is recommended that the driver look frequently over his/ her shoulder when using ParkView.

REFUELING THE VEHICLE

The gas cap is located behind the fuel filler door, on the passenger side of the vehicle. If the gas cap is lost or damaged, be sure the replacement cap has been designed for use with this vehicle.

NOTE:

When removing the fuel filler cap, lay the cap tether in the hook. located on the fuel filler door reinforcement.


- 1. Push the fuel filler door release switch (located on the driver's side door trim).
- 2. Open the fuel filler door, and remove the fuel filler cap.



Fuel Filler Cap (Gas Cap)

NOTE:

the fuel tank is full.



until you hear one click. This is an indica-

tion that the cap is properly tightened.

every time the vehicle is refueled.

• If the gas cap is not tightened properly, the

Malfunction Indicator Light (MIL) will























WARNING!

 Never have any smoking materials lit in or near the vehicle when the fuel door is open or the tank is being filled.









- Never add fuel when the engine is running. This is in violation of most countries regulations and may cause the "Malfunction Indicator Light" to turn on.
- A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place fuel containers on the ground while filling.

CAUTION!

- Damage to the fuel system or emission control system could result from using an improper fuel filler cap. A poorly fitting cap could let impurities into the fuel system. Also, a poorly fitting aftermarket cap can cause the "Malfunction Indicator Light (MIL)" to illuminate, due to fuel vapors escaping from the system.
- A poorly fitting fuel filler cap may cause the MIL to turn on.

CAUTION!

- To avoid fuel spillage and overfilling, do not "top off" the fuel tank after filling.
- If fuel is spilled on surface on the paint, clear it immediately to avoid damage the paint.

TRAILER TOWING

Trailer Towing Weights (Maximum Trailer Weight Ratings)

Engine/Transmission	Model	Frontal Area	Maximum GTW (Gross Trailer Wt.)	Maximum Tongue Wt. (See Note)
2.4L/Automatic with or without Trailer Tow Package	FWD	40 sq ft (3.72 sq m)	4,409 lbs (2,000 kg)	220 lbs (100 kg)
2.4L/Automatic with or without Trailer Tow Package	4WD	40 sq ft (3.72 sq m)	4,850 lbs (2,200 kg)	243 lbs (110 kg)
3.2L/Automatic with or without Trailer Tow Package	FWD or 4WD	40 sq ft (3.72 sq m)	4,850 lbs (2,200 kg)	243 lbs (110 kg)
2.0L Diesel/Manual	FWD	40 sq ft (3.72 sq m)	3,968 lbs (1,800 kg)	198 lbs (90 kg)
2.0L Diesel/Manual	4WD	40 sq ft (3.72 sq m)	3,527 lbs (1,600 kg)	176 lbs (80 kg)

Engine/Transmission	Model	Frontal Area	Maximum GTW (Gross Trailer Wt.)	Maximum Tongue Wt. (See Note)
2.0L Diesel/Automatic	4WD	55 sq ft (5.11 sq m)	5,456 lbs (2,475 kg)	273 lbs (124 kg)
2.0L Diesel/Automatic	4WD with 2-speed PTU (4LO)	55 sq ft (5.11 sq m)	5,500 lbs (2,495 kg)	276 lbs (125 kg)
2.2L Diesel/Automatic	4WD	55 sq ft (5.11 sq m)	5,500 lbs (2,495 kg)	276 lbs (125 kg)
2.2L Diesel/Automatic	4WD with 2-speed PTU (4LO)	55 sq ft (5.11 sq m)	5,500 lbs (2,495 kg)	276 lbs (125 kg)

When towing a trailer the technically permissible laden weight may be exceeded by not more than 10% or 220 lbs (100 kg), whichever is lower provided that the operating speed is restricted to 62 mph (100 km/h) or less. Refer to local laws for maximum trailer towing speeds and loads. Towing limits quoted represent the maximum towing ability of the vehicle at its Gross Combined Mass to restart on a 12% gradient at sea level. The performance and economy of all models will be reduced when used for towing.















RECREATIONAL TOWING (BEHIND MOTORHOME, ETC.)

Towing This Vehicle Behind Another Vehicle

		Front-Wheel Drive (FWD) Models	Four Wheel Drive (4WD) Models	
Towing Condition	Wheels OFF The Ground	NOT ALLOWED	NOT ALLOWED	
Flat Tow	NONE	NOT ALLOWED	NOT ALLOWED	
Dally, Taux	Front	OK	NOT ALLOWED	
Dolly Tow	Rear	NOT ALLOWED	NOT ALLOWED	
On Trailer	ALL	OK	OK	











NOTE:

- You must ensure that the Auto Park Brake feature is disabled before towing this vehicle, to avoid inadvertent Electric Park Brake engagement. The Auto Park Brake feature is enabled or disabled via the customer programmable features in the Uconnect Settings.
- When towing your vehicle, always follow applicable state and provincial laws. Contact state and provincial Highway Safety offices for additional details.

$\label{eq:Recreational Towing - Front-Wheel Drive} \ensuremath{\left(\text{FWD}\right)} \ensuremath{\left(\text{Models}\right)}$

DO NOT flat tow this vehicle.

Recreational towing (for front-wheel drive models) is allowed ONLY if the front wheels are **OFF** the ground. This may be accomplished using a tow dolly or vehicle trailer. If using a tow dolly, follow this procedure:

Properly secure the dolly to the tow vehicle, following the dolly manufacturer's instructions.

- 2. Drive the front wheels onto the tow dolly.
- Apply the parking brake. Place automatic transmission in PARK, or manual transmission in gear. Turn the engine OFF.
- Properly secure the front wheels to the dolly, following the dolly manufacturer's instructions.
- 5. Turn the ignition to the ON/RUN mode, but do not start the engine.
- 6. Press and hold the brake pedal.
- 7. Release the parking brake.
- 8. Turn the ignition OFF, remove the key fob, and release the brake pedal.

CAUTION!

 Towing with the front wheels on the ground will cause severe transmission damage. Damage from improper towing is not covered under the New Vehicle Limited Warranty.

CAUTION!

• Ensure that the Electric Park Brake is released, and remains released, while being towed.

Recreational Towing — 4x4 Models

Recreational towing is not allowed.

NOTE:

This vehicle may be towed on a flatbed or vehicle trailer provided all four wheels are OFF the ground.

CAUTION!

Towing this vehicle with **ANY** of its wheels on the ground can cause severe transmission and/or power transfer unit damage. Damage from improper towing is not covered under the New Vehicle Limited Warranty.

IN CASE OF EMERGENCY



HAZARD WARNING
FLASHERS160
Control
BULB REPLACEMENT160
Replacement Bulbs
Replacing Exterior Bulbs
FUSES
General Information
Underhood Fuses
Interior Fuses
JACKING AND TIRE
CHANGING
Jack Location/Spare Tire Stowage173
Changing Procedure 177

lack Usage Precautions
FIRE SERVICE KIT —
Fire Service Kit Storage
Fire Service Kit Components And Operation
Sealing A Tire With Tire Service Kit 182
JUMP STARTING186
Preparations For Jump Start
REFUELING IN EMERGENCY 188
Emergency Fuel Filler Door Release 188

IF YOUR ENGINE OVERHEATS188
GEAR SELECTOR OVERRIDE189
FREEING A STUCK VEHICLE 189
TOWING A DISABLED VEHICLE
Without The Key Fob
ENHANCED ACCIDENT RESPONSE SYSTEM (EARS)193
EVENT DATA RECORDER (EDR)193





















HAZARD WARNING FLASHERS

Control

The Hazard Warning flasher switch is located on the switch bank just above the climate controls.

Push the switch to turn on the Hazard Warning flasher. When the switch is activated, all directional turn signals will flash on and off to

warn oncoming traffic of an emergency. Push the switch a second time to turn off the Hazard Warning flashers.

This is an emergency warning system and it should not be used when the vehicle is in motion. Use it when your vehicle is disabled and it is creating a safety hazard for other motorists.

When you must leave the vehicle to seek assistance, the Hazard Warning flashers will continue to operate even though the ignition is placed in the OFF position.

NOTE:

With extended use, the Hazard Warning flashers may discharge the battery.

BULB REPLACEMENT

Replacement Bulbs

Interior Bulbs

	Bulb Number
Cargo Lamp	TL212-2
Overhead Console Lamp	PLW214-2A
Reading Lamp	WL212–2

Exterior Bulbs

	Bulb Number	
Low Beam/High Beam (Bi-Halogen) Headlamps	9005HL +	
Low Beam/High Beam (Bi-Xenon) Headlamps	D3S (Serviced at an authorized dealer)	
Front Park/Daytime Running Lamps	LED (Serviced at an authorized dealer)	
Front Turn Signal Lamps	WY21W	
Front Fog Lamps	PSX24W	ין
Rear Tail/Stop Lamps	Rear Tail/Stop Lamps LED (Serviced at an authorized dealer)	
Rear Turn Signal Lamps WY21W		
Center High Mounted Stop Lamp (CHMSL) LED (Serviced at an authorized dealer)		
Back-Up Lamps W16W or 921		
License Plate Lamp	W5W	
Rear Fog Lamps	W21W	



Bi-Xenon High Intensity Discharge (HID) Headlamps — If Equipped

The headlamps contain a type of high voltage discharge light source. High voltage can remain in the circuit even with the headlamp switch off. Because of this, you should not attempt to service a HID headlamp light

source yourself. If an HID headlamp light source fails, take your vehicle to an authorized dealer for service.

NOTE:

On vehicles equipped with HID headlamps, when the headlamps are turned on, there is a blue hue to the lights. This diminishes and becomes more white after approximately 10 seconds, as the system charges.

WARNING!

A transient high voltage occurs at the bulb sockets of HID headlamps when the headlamp switch is turned ON. It may cause serious electrical shock or electrocution if not serviced properly. See your authorized dealer for service.























Bi-Halogen Headlamps

- Remove the three hex head screws from the wheel liner.
- Pull the exterior edge of the liner towards the tire to gain access to the headlamp bulb cap.
- 3. Firmly grasp the cap and rotate it counterclockwise to unlock it.
- Firmly grasp the bulb and connector assembly and rotate counterclockwise to remove from the housing.
- Disconnect the bulb from the electrical connector and then connect the replacement bulb.

CAUTION!

Do not touch the new bulb with your fingers. Oil contamination will severely shorten bulb life. If the bulb comes in contact with any oily surface, clean the bulb with rubbing alcohol.

6. Install the bulb and connector assembly into the headlamp housing and rotate clockwise to lock it in place.

- Install the bulb cap in the headlamp housing and rotate clockwise to lock it in place.
- 8. Install the three hex head screws into the wheel liner.

Front Turn Signals And Front Side Marker Lamps

1. Open the hood.

NOTE:

Removal of the air cleaner filter housing may be necessary prior to replacing bulbs in the upper lamp assembly on the passenger side of the vehicle.

- Twist the appropriate bulb and socket assembly counterclockwise, and then remove the bulb and socket assembly from the lamp housing.
- 3. Pull the bulb out of the socket and insert the replacement bulb.
- 4. Install the bulb and socket assembly into the housing, and rotate the socket clockwise to lock it in place.
- 5. Re-install air cleaner filter housing if removed.

Front Fog Lamp

- 1. Remove the three hex head screws from the wheel liner.
- 2. Pull the exterior edge of the wheel liner towards the tire to gain access to the bulb.
- Squeeze the two tabs on the side of the bulb socket and pull straight out from the fog lamp.
- 4. Disconnect the wire harness from the bulb.

CAUTION!

Do not touch the new bulb with your fingers. Oil contamination will severely shorten bulb life. If the bulb comes in contact with any oily surface, clean the bulb with rubbing alcohol.

- Reconnect the wiring harness to the new bulb and reinstall by inserting the new bulb straight into the fog lamp housing until it locks in place.
- 6. Lock the lower door in the wheel liner.

Bodyside Mounted Back-Up Lamp

- 1. Open the liftgate.
- Remove the screws that fasten the bodyside mounted lamp housing to the vehicle.
- Grasp the tail lamp and pull firmly rearward to disengage the lamp from the vehicle.
- 4. Disconnect the electrical connector.
- 5. Twist the socket counterclockwise and remove from housing.
- 6. Pull the bulb to remove it from the socket.
- 7. Replace the bulb and install the socket.
- 8. Reconnect the electrical connector.
- Reinstall the bodyside lamp housing and screws.
- 10. Close the liftgate.

Liftgate Mounted Back-up Lamp

1. Open the liftgate.

- 2. Use a fiber stick or flat blade screw driver to pry the lower trim from the liftgate.
- 3. Once the trim is loose, pull it back exposing the trim panel.
- Using a fiber stick or flat blade screw driver, open the trim panel exposing the back of the liftgate lamp.
- 5. Disconnect the electrical connector.
- 6. Twist the socket counterclockwise and remove from lamp.
- 7. Pull the bulb to remove it from the socket.
- 8. Replace the bulb, reinstall the socket.
- 9. Connect the electrical connector.
- Reinstall the trim panel and the lower trim.
- 11. Close the liftgate.

License Plate Lamp

 Using a small screwdriver, press inward the locking tab on the side of the lamp assembly and pull down on the lamp assembly for removal. Pull bulb from socket, replace, and reinstall the lamp assembly into place ensuring the locking tab is secure.






1. Using a small screwdriver or fiber stick, press the locking tab on the reflex side of the lamp and pull the lamp assembly out for removal.




2. Disconnect the electrical connector.





4. Pull the bulb to remove it from the socket.





6. Connect the electrical connector.



7. Reinstall the lamp by sliding the hook on the fog lamp side over the locking tab in the bumper opening and pushing the reflex side into the bumper to snap the lamp assembly back into place.







FUSES

WARNING!

- When replacing a blown fuse, always use an appropriate replacement fuse with the same amp rating as the original fuse. Never replace a fuse with another fuse of higher amp rating. Never replace a blown fuse with metal wires or any other material. Do not place a fuse inside a circuit breaker cavity or vice versa. Failure to use proper fuses may result in serious personal injury, fire and/or property damage.
- Before replacing a fuse, make sure that the ignition is off and that all the other services are switched off and/or disengaged.
- If the replaced fuse blows again, contact an authorized dealer.

WARNING!

 If a general protection fuse for safety systems (air bag system, braking system), power unit systems (engine system, transmission system) or steering system blows, contact an authorized dealer.

General Information

The fuses protect electrical systems against excessive current.

When a device does not work, you must check the fuse element inside the blade fuse for a break/melt.

Also, please be aware that when using power outlets for extended periods of time with the engine off may result in vehicle battery discharge.

Underhood Fuses

The Power Distribution Center is located in the engine compartment near the battery. This center contains cartridge fuses, minifuses and relays. A label that identifies each component is printed on the inside of the cover.

Cavity	Blade Fuse	Cartridge Fuse	Description
F06			Not Used
F07	15 Amp Blue	_	Powertrain Control Mod - PCM (Diesel Only)
F08	25 Amp Clear	_	Power Control Mod (PCM)/Engine Control Module (ECM)/Fuel Injec- tion
F09	_	_	Not Used
F10	20 Amp Yellow	_	Power Transfer Unit (PTU) – If Equipped
F11	_	_	Not Used
F12	20 Amp Yellow	-	Brake Vacuum Pump – If Equipped
F13	10 Amp Red	-	Voltage Stability Mod (VSM)/ Powertrain Control Mod (PCM)/ Engine Control Module (ECM)
F14	10 Amp Red	_	Drivetrain Control Module (DTCM)/ Power Take-Off Unit (PTU)/Electric Park Brake (EPB)/RDM/Brake System Module (BSM) – If Equipped/ Brake Pedal Switch/Back Up Switch (Diesel Only)
F15	-	_	Not Used
F16	20 Amp Yellow	-	Ign Coil (Gas)/Engine Sensor (Diesel)
F17	-	-	Not Used
F18	-	_	Not Used























Cavity	Blade Fuse	Cartridge Fuse	Description
F19	-	40 Amp Green	Starter Solenoid
F20	10 Amp Red	_	A/C Compressor Clutch
F21	-	_	Not Used
F22	5 Amp Tan	_	Radiator Fan
F23	70 Amp Tan	_	Body Controller Module (BCM) – Feed 2
F23	50 Amp Red	-	Voltage Stability Module (VSM) Feed #2 – If Equipped With Stop/ Start Engine Option
F24	20 Amp Yellow	_	Rear Wiper – If Equipped With Stop/Start Engine Option
F25B	20 Amp Yellow	_	Front Washer – If Equipped With Stop/Start Engine Option
F26	-	30 Amp Pink	Fuel Heater – Diesel Only
F27	-	_	Not Used
F28	15 Amp Blue	_	Transmission Control Module (TCM)
F29	-	_	Not Used
F30	10 Amp Red	-	Engine Control Module (ECM)/ (EPS)/Fuel Pump Relay Feed/ (PCM)
F31	-	-	Not Used
F32	-	_	Not Used
F33	-		Not Used
F34	-	_	Not Used

Cavity	Blade Fuse	Cartridge Fuse	Description
F35	-	-	Not Used
F36	-	-	Not Used
F37	_	_	Not Used
F38	-	60 Amp Yellow	Glow Plugs (Diesel Only) – If Equipped
F39	-	40 Amp Green	HVAC Blower Motor
F40	-	20 Amp Blue	Trailer Tow Park Light – If Equipped
F40	-	30 Amp Pink	Headlamp Washer Pump – If Equipped
F41	-	60 Amp Yellow	Body Controller Module (BCM) – Feed 1
F41	-	50 Amp Red	Voltage Stability Module - Feed 1 – If Equipped With Stop/Start Engine Option
F42	-	30 Amp Pink	Trailer Tow Electric Brake Module – If Equipped
F43	20 Amp Yellow	-	Fuel Pump Motor
F44	-	30 Amp Pink	Trailer Tow / 7-Way Connector - If Equipped
F45	-	30 Amp Pink	Passenger Door Module (PDM) – If Equipped
F46	_	25 Amp Clear	Sunroof – If Equipped
F48	-	30 Amp Pink	Driver Door Module – If Equipped























Cavity	Blade Fuse	Cartridge Fuse	Description
F49	-	30 Amp Pink	Power Inverter (115V A/C) — If Equipped
F50	-	30 Amp Pink	Power Liftgate – If Equipped
F51	_	-	Not Used
F52	-	30 Amp Pink	Front Wipers – If Equipped With Stop/Start Engine Option
F53	-	30 Amp Pink	Brake System Module & Valves
F54	-	30 Amp Pink	Body Control Module (BCM) Feed 3
F55	10 Amp Red	-	Blind Spot Sensors/Rearview Camera
F56	15 Amp Blue	-	Ignition Node Module (IGNM)/ KIN/RF Hub/Electric Steering Column Lock (ESCL)
F57	20 Amp Yellow	-	Trailer Tow Lights Left – If Equipped
F58	10 Amp Red	-	Occupant Classification Module/ VSM/TT Mod/ESCL
F59	-	30 Amp Pink	Drivetrain Control Module (DTCM) – If Equipped
F60	20 Amp Yellow	_	Power Outlet – Center Console
F61	20 Amp Yellow	-	Trailer Tow Lights Right – If Equipped
F62	20 Amp Yellow	-	Windshield De-Icer – If Equipped

Cavity	Blade Fuse	Cartridge Fuse	Description
F63	20 Amp Yellow	-	Front Heated/Vented Seats – If Equipped
F64	20 Amp Yellow	-	Heated Steering Wheel – If Equipped
F65	10 Amp Red	_	In Vehicle Temperature Sensor/ Humidity Sensor/Driver Assist Sys- tem Module (DASM)/Park Assist (PAM) – If Equipped With Stop/ Start option
F66	15 Amp Blue	-	HVAC (ECC)/Instrument Panel Cluster (IPC)
F67	10 Amp Red	_	In Vehicle Temperature Sensor/ Humidity Sensor/Driver Assist Sys- tem Module (DASM)/Park Assist (PAM) – If Not Equipped With Stop/Start Option
F68	_	-	Not Used
F69	10 Amp Red	-	Power Transfer Unit Switch (TSBM)/Active Grill Shutter (AGS) – If Equipped With Gas Engine
F69A	10 Amp Red	-	Power Transfer Unit Switch (TSBM) – If Equipped With Diesel Engine
F70	5 Amp Tan	-	Intelligent Battery Sensor – If Equipped With Stop/Start Engine Option























Cavity	Blade Fuse	Cartridge Fuse	Description
F71	20 Amp Yellow	-	HID Headlamp Right – If Equipped With Stop/Start Engine Option
F72	10 Amp Red	-	Heated Mirrors – If Equipped
F73	_	20 Amp Blue	Trailer Tow Back Up – If Equipped
F74	-	30 Amp Pink	Rear Defroster
F75	20 Amp Yellow	_	Cigar Lighter – If Equipped
F76	20 Amp Yellow	-	Rear Differential Module (RDM) – If Equipped
F77	10 Amp Red	-	Fuel Door Release/Brake Pedal Switch
F78	10 Amp Red	-	Diagnostic Port/Digital TV (Japan Only)
F79	10 Amp Red	_	Integrated Center Stack (ICS)/ Electric Park Brake (EPB) SW/CD Mod/Steering Control Mod (SCCM)/ HVAC/Instrument Panel Cluster (IPC)
F80	20 Amp Yellow	_	Radio / CD – If Equipped
F81	-	-	Not Used
F82	_	-	Not Used
F83	-	20 Amp Blue	Engine Controller Module (Gas)
F84	-	30 Amp Pink	Electric Park Brake (EPB) – Left
F85	-	-	Not Used

Cavity	Blade Fuse	Cartridge Fuse	Description
F86	20 Amp Yellow	_	Horns – If Equipped With Stop/ Start Engine Option
F87A	20 Amp Yellow	-	HID Headlamp Left – If Equipped With Stop/Start Engine Option
F88	15 Amp Blue	-	Seat Belt Reminder (SBR)
F89	10 Amp Red	-	Headlamp Leveling – If Equipped
F90	_	-	Not Used
F91	20 Amp Yellow	-	Power Outlet Rear – If Equipped – Customer Selectable
F92	_	-	Not Used
F93	-	40 Amp Green	Brake System Module (BSM) – Pump Motor
F94	_	30 Amp Pink	Electric Park Brake (EPB) – Right
F95	10 Amp Red	-	Electrochromatic Mirror/Rain Sensor/Sunroof – If Equipped/ Passenger Window Switch/Power Outlet Console/Digital TV (Japan Only)
F96	10 Amp Red	-	Occupant Restraint Controller (ORC)/(Airbag)
F97	10 Amp Red	-	Occupant Restraint Controller (ORC)/(Airbag)
F98	25 Amp Clear	_	Audio Amplifier – If Equipped
F99	_	-	Not Used
F100	-	_	Not Used























Interior Fuses

The interior fuse panel is located on the Body Control Module (BCM) in the passenger compartment on the left side dash panel under the instrument panel.

Cavity	Blade Fuse	Description	
F13	15 Amp Blue	Low Beam Left	
F32	10 Amp Red	Interior Lighting	
F36	10 Amp Red	Intrusion Module/Siren – If Equipped	
F38	20 Amp Yellow	Deadbolt All Unlock	
F43	20 Amp Yellow	Washer Pump Front	
F48	25 Amp Clear	Fog Lamp Rear Left/Right – If Equipped	
F49	7.5 Amp Brown	Lumbar Support	
F50	7.5 Amp Brown	Wireless Charging Pad – If Equipped	
F51	10 Amp Red	Driver Window Switch/Power Mirrors – If Equipped	
F53	7.5 Amp Brown	UCI Port (USB & AUX)	
F89	10 Amp Red	Door Locks – Driver Unlock	
F91	7.5 Amp Brown	Left Front Fog Lamp (Low And High Line)	
F92	7.5 Amp Brown	Right Front Fog Lamp (High Line)	
F93	10 Amp Red	Low Beam Right	

JACKING AND TIRE CHANGING

WARNING!

- Do not attempt to change a tire on the side of the vehicle close to moving traffic. Pull far enough off the road to avoid the danger of being hit when operating the jack or changing the wheel.
- Being under a jacked-up vehicle is dangerous. The vehicle could slip off the jack and fall on you. You could be crushed. Never put any part of your body under a vehicle that is on a jack. If you need to get under a raised vehicle, take it to a service center where it can be raised on a lift.
- Never start or run the engine while the vehicle is on a jack.
- The jack is designed to be used as a tool for changing tires only. The jack should not be used to lift the vehicle for service purposes. The vehicle should be jacked on a firm level surface only. Avoid ice or slippery areas.

Jack Location/Spare Tire Stowage

The jack, wheel chocks and spare tire are stowed under the load floor behind the rear seat.

- 1. Open the liftgate.
- 2. Lift the access cover using the load floor handle.



Load Floor Handle

3. Remove the hook from the stowed position on the back side of the load floor and place the hook over the top body flange and weather seal. This will hold the load floor up while obtaining the jack and spare tire.









5 Remove the chocks



6. Remove the scissors jack and wheel bolt wrench from the spare wheel as an assembly. Turn the jack screw to the left to loosen the wheel bolt wrench, and remove the wrench from the jack assembly.



NOTE:



The jack handle attaches to the side of the jack with two attachment points. When the jack is partially expanded, the tension between the two attachment points holds the jack handle in place.



7. Remove the spare tire.







A loose tire or jack thrown forward in a collision or hard stop could endanger the occupants of the vehicle. Always stow the jack parts and the spare tire in the places provided. Have the deflated (flat) tire repaired or replaced immediately.

Preparations For Jacking


1. Park the vehicle on a firm level surface as far from the edge of the roadway as possible. Avoid icy or slippery areas.

WARNING!

Do not attempt to change a tire on the side of the vehicle close to moving traffic. Pull far enough off the road to avoid being hit when operating the jack or changing the wheel.

- 2. Turn on the Hazard Warning flasher.
- 3. Apply the parking brake.
- Place the gear selector into PARK (automatic transmission) or REVERSE (manual transmission).

- 5. Turn the ignition off to the LOCK position.
- 6. Chock both the front and rear of the wheel diagonally opposite of the jacking position. For example, if changing the right front tire, chock the left rear wheel.



Wheel Chocks

NOTE:

Passengers should not remain in the vehicle when the vehicle is being jacked.

Jacking Instructions

WARNING!

Carefully follow these tire changing warnings to help prevent personal injury or damage to your vehicle:

- Always park on a firm, level surface as far from the edge of the roadway as possible before raising the vehicle.
- Turn on the Hazard Warning flasher.
- Chock the wheel diagonally opposite the wheel to be raised.
- Apply the parking brake firmly and set an automatic transmission in PARK; a manual transmission in REVERSE.
- Never start or run the engine with the vehicle on a jack.
- Do not let anyone sit in the vehicle when it is on a jack.
- Do not get under the vehicle when it is on a jack. If you need to get under a raised vehicle, take it to a service center where it can be raised on a lift.
- Only use the jack in the positions indicated and for lifting this vehicle during a tire change.

- If working on or near a roadway, be extremely careful of motor traffic.
- To assure that spare tires, flat or inflated, are securely stowed, spares must be stowed with the valve stem facing the ground.



CAUTION!

Do not attempt to raise the vehicle by jacking on locations other than those indicated in the Jacking Instructions for this vehicle.

- 1. Remove the spare tire, jack, and wheel bolt wrench.
- 2. If equipped with aluminum wheels where the center cap covers the wheel bolts, use the wheel bolt wrench to pry the center cap off carefully before raising the vehicle.
- 3. Before raising the vehicle, use the wheel bolt wrench to loosen, but not remove, the wheel bolts on the wheel with the flat tire. Turn the wheel bolts counterclockwise one turn while the wheel is still on the ground.

4. Place the jack underneath the lift area that is closest to the flat tire. Turn the jack screw clockwise to firmly engage the jack saddle with the lift area of the sill flange, centering the jack saddle inside the cutout in the sill cladding.





















Jacking Locations







Warning Label



Rear Jack Location Engaged



Front Jack Location Engaged

5. Raise the vehicle just enough to remove the flat tire.

WARNING!

Raising the vehicle higher than necessary can make the vehicle less stable. It could slip off the jack and hurt someone near it. Raise the vehicle only enough to remove the tire.

6. Remove the wheel bolts and tire.

- Remove the alignment pin from the jack assembly and thread the pin into the wheel hub to assist in mounting the spare tire.
- 8. Mount the spare tire.

CAUTION!

Be sure to mount the spare tire with the valve stem facing outward. The vehicle could be damaged if the spare tire is mounted incorrectly.

NOTE:

- For vehicles so equipped, do not attempt to install a center cap or wheel cover on the compact spare.
- Refer to "Tires" in "Servicing And Maintenance" in the Owner's Manual for further information about the spare tire, its use, and operation.
- Install the wheel bolts with the threaded end of the wheel bolt toward the wheel. Lightly tighten the wheel bolts.

To avoid the risk of forcing the vehicle off the jack, do not tighten the wheel nuts fully until the vehicle has been lowered. Failure to follow this warning may result in serious injury.

- 10. Lower the vehicle to the ground by turning the jack handle counterclockwise.
- 11. Finish tightening the wheel bolts. Push down on the wrench while at the end of the handle for increased leverage. Tighten the wheel bolts in a star pattern until each wheel bolt has been tightened twice. Refer to "Torque Specifications" in "Technical Specifications" for the proper lug bolt torque. If in doubt about the correct tightness, have them checked with a torque wrench by your authorized dealer or at a service station.
- 12. Securely stow the jack, tools, chocks, and flat tire.

WARNING!

A loose tire or jack thrown forward in a collision or hard stop could endanger the occupants of the vehicle. Always stow the jack parts and the spare tire in the places provided. Have the deflated (flat) tire repaired or replaced immediately.

Changing Procedure


- 1. Mount the road tire on the axle.
- 2. Install the remaining wheel bolts with the threaded end of the wheel bolt toward the wheel. Lightly tighten the wheel bolts.

WARNING!

To avoid the risk of forcing the vehicle off the jack, do not tighten the wheel nuts fully until the vehicle has been lowered. Failure to follow this warning may result in serious injury.

3. Lower the vehicle to the ground by turning the jack handle counterclockwise.











5. Lower the jack until it is free. Remove the wheel chocks. Reassemble the lug wrench to the lack assembly and stow it in the spare tire area. Secure the assembly using the means provided. Release the parking brake before driving the vehicle.

against the wheel.





6. After 25 miles (40 km) check the wheel bolt torque with a torque wrench to ensure that all wheel bolts are properly seated







Declaration Of Conformance

- The undersigned, Tony Fabiano, representing the manufacturer, herewith declares that the machinery described below fulfills all relevant provisions of:
 - The EC-directive 2006/42/EC on Machinery
- 2. Description of machinery.
 - a) Generic Denomination: Vehicle Jack
 - b) Function: Lifting Vehicle

d) Ve- hicle Model	c) Model Code	f) Work- ing Load	e) Jack Type
Jeep® Compass	MK	1200 kg Max	FGMF1
Jeep Cherokee	KL	1000 kg Max	FGLF1
Jeep Wrangler	JK	1000 kg Max	FGLF2
Jeep Grand Cherokee	WK	1700 kg Max	FGLF3

3. Manufacturers (1):

FlexNGate Seeburn, a division of Ventra Group Co

P.O. Box 1170, 65 Industrial Road, Tottenham, ON CANADA LOG 1WO

4. Manufacturers (2):

FlexNGate Querétaro Ventramex, S.A. de C.V

Av. Manantiales No. 3

Parque Industrial Bernardo Quintana, El Marqués Querétaro C.P. 76249 – Mexico

5. Legal Person authorized to compile the technical file:

FlexNGate - Barcelona

Avda de la Riera, 7-9

Sant Just Desvern, Barcelona, SPAIN 08960

- 6. References to harmonized standards: PF-12074
- 7. Done at: Bradford, ON CANADA
- 8. Date: 09/30/2015



Tony Fabiano

0605091831US

Deutsch (German)

EG-Konformitätserklärung

- 1. Der Unterzeichner, Tony Fabiano, Vertreter der Hersteller, erklärt hiermit, das die unten beschriebenen Maschinen den relevanten Bestimmungen von folgender Richtlinie entsprechen:
 - EG-Richtlinie 2006/42/EC für Maschinen
- 2. Beschreibung der Maschine
- a) Allgemeine Bezeichnung: Scherenwagenheber
- b) Funktion: Anhebung des Kraftfahrzeugs
- c) Typenschlüssel
- d) Modell Kommerzielle Informationen
- e) Typ
- f) Nutzlast
- 3. Hersteller (1)

- 4. Hersteller (2)
- 5. Juristische Person, die bevollmächtig ist, die technische Datei zu erstellen
- 6. Bezug auf Standard Übereinstimmungen
- 7. Ausgestellt in
- 8. Datum



























German Translation

0605110411US

Jack Usage Precautions

To complete the Use and Maintenance Handbook to which this supplement is attached, given below are some instructions on the proper use of the jack.

WARNING!

When using the crank, make sure it turns freely without the risk of scraping hands against the ground.

Even the moving parts of the jack, the "worm screw" and joints can cause injuries: avoid contact with them. Clean it thoroughly if dirtied with grease.

CAUTION!

The jack is a tool designed exclusively for changing a wheel, in case of a puncture or damage to a tire of the vehicle on which it is fitted or on vehicles of the same model. Any other use, e.g. to jack up other vehicle models or different things, is strictly prohibited. Never use it to carry out maintenance or repairs under the vehicle or to

CAUTION!

change summer/winter wheels and vice versa. Never go under the raised vehicle. If any work under the vehicle is necessary, contact an authorized dealer. Incorrect placing of the jack can cause the vehicle to drop: use it only in the positions indicated. Do not use the jack for loads higher than that specified on the label. Never start the engine with vehicle raised. If the vehicle is raised more than necessary, everything can become more unstable, with the risk of the vehicle dropping violently. Therefore raise the vehicle only as much as necessary for the wheel/spare.

Maintenance

- Make sure grime does not build up on the "worm screw."
- Keep the "worm screw" lubricated.
- Never modify the jack.

Conditions Of Non-Use:

- Temperatures below -40°C.
- On sandy or muddy ground.
- On uneven ground.

- On steep roads.
- In extreme weather conditions: thunderstorms, typhoons, hurricanes, blizzards, storms, etc.

TIRE SERVICE KIT — IF EQUIPPED

Small punctures up to 1/4 inch (6 mm) in the tire tread can be sealed with Tire Service Kit. Foreign objects (e.g., screws or nails) should not be removed from the tire. Tire Service Kit can be used in outside temperatures down to approximately -4°F (-20°C).


This kit will provide a temporary tire seal, allowing you to drive your vehicle up to 100 miles (160 km) with a maximum speed of 55 mph (90 km/h).

Tire Service Kit Storage

The Tire Service Kit is stowed under the load floor behind the rear seat.

- 1. Open the liftgate.
- Lift the access cover using the load floor handle.

Tire Service Kit Components And Operation



Tire Service Kit Components

Knob

1 — Sealant **Bottle** 2 — Deflation Button 3 — Pressure Gauge 4 — Power Button

(Clear) 7 — Air Pump Hose (Black) 8 — Power Plug (located on the bottom side of the

Tire Service Kit)

5 — Mode Select

6 — Sealant Hose

Using The Mode Select Knob And Hoses

Your Tire Service Kit is equipped with the following symbols to indicate the air or sealant mode.

Selecting Air Mode

Turn the Mode Select Knob (5) to this position for air pump operation only. Use the Black Air Pump Hose (7) when selecting this mode.

** Selecting Sealant Mode

Turn the Mode Select Knob (5) to this position to inject the Tire Service Kit Sealant and to inflate the tire. Use the Sealant Hose (clear hose) (6) when selecting this mode.

(1) Using The Power Button

Push and release the Power Button (4) once to turn on the Tire Service Kit. Push and release the Power Button (4) again to turn Off the Tire Service Kit.

W Using The Deflation Button

Push the Deflation Button (2) to reduce the air pressure in the tire if it becomes overinflated.

Tire Service Kit Usage Precautions



• Replace the Tire Service Kit Sealant Bottle (1) and Sealant Hose (6) prior to the expiration date (printed at the lower right hand corner on the bottle label) to assure optimum operation of the system. Refer to section "(F) Sealant Bottle and Hose Replacement" in "Sealing a Tire with Tire Service Kit" in this section.







 The Sealant Bottle (1) and Sealant Hose (6) are a one tire application use and need to be replaced after each use. Always replace these components immediately at your original equipment vehicle dealer.



• When the Tire Service Kit sealant is in a liquid form, clean water and a damp cloth will remove the material from the vehicle or tire and wheel components. Once the sealant dries, it can easily be peeled off and properly discarded.





• For optimum performance, make sure the valve stem on the wheel is free of debris before connecting the Tire Service Kit.





- You can use the Tire Service Kit air pump to inflate bicycle tires. The kit also comes with two needles, located in the Accessory Storage Compartment (on the bottom of the air pump) for inflating sport balls, rafts, or similar inflatable items. However, use only the Air Pump Hose (7) and make sure the Mode Select Knob (5) is in the Air Mode when inflating such items to avoid injecting sealant into them. The Tire Service Kit Sealant is only intended to seal punctures less than 1/4 inch (6 mm) diameter in the tread of your vehicle.
- Do not lift or carry the Tire Service Kit by the hoses.

WARNING!

- Do not attempt to seal a tire on the side of the vehicle closest to traffic. Pull far enough off the road to avoid the danger of being hit when using the Tire Service Kit.
- Do not use Tire Service Kit or drive the vehicle under the following circumstances:
 - If the puncture in the tire tread is approximately 1/4 inch (6 mm) or larger.

WARNING!

- If the tire has any sidewall damage.
- If the tire has any damage from driving with extremely low tire pressure.
- If the tire has any damage from driving on a flat tire.
- If the wheel has any damage.
- If you are unsure of the condition of the tire or the wheel.
- Keep Tire Service Kit away from open flames or heat source.
- A loose Tire Service Kit thrown forward in a collision or hard stop could endanger the occupants of the vehicle. Always stow the Tire Service Kit in the place provided. Failure to follow these warnings can result in injuries that are serious or fatal to you, your passengers, and others around you.
- Take care not to allow the contents of Tire Service Kit to come in contact with hair, eyes, or clothing. Tire Service Kit sealant is harmful if inhaled, swallowed, or absorbed through the skin. It causes skin, eye, and respiratory irritation.

WARNING!

Flush immediately with plenty of water if there is any contact with eyes or skin. Change clothing as soon as possible, if there is any contact with clothing.

Tire Service Kit Sealant solution contains latex. In case of an allergic reaction or rash, consult a physician immediately. Keep Tire Service Kit out of reach of children. If swallowed, rinse mouth immediately with plenty of water and drink plenty of water. Do not induce vomiting! Consult a physician immediately.

Sealing A Tire With Tire Service Kit

(A) Whenever You Stop To Use Tire Service Kit:

- 1. Pull over to a safe location and turn on the vehicle's Hazard Warning flashers.
- 2. Verify that the valve stem (on the wheel with the deflated tire) is in a position that is near to the ground. This will allow the Tire Service Kit Hoses (6) and (7) to reach the valve stem and keep the Tire Service

Kit flat on the ground. This will provide the best positioning of the kit when injecting the sealant into the deflated tire and running the air pump. Move the vehicle as necessary to place the valve stem in this position before proceeding.

- 3. Place the transmission in PARK (auto transmission) or in Gear (manual transmission) and place the ignition in the OFF position.
- 4. Apply the parking brake.

(B) Setting Up To Use Tire Service Kit:

- 1. Push in the Mode Select Knob (5) and turn to the Sealant Mode position.
- 2. Uncoil the Sealant Hose (6) and then remove the cap from the fitting at the end of the hose.
- 3. Place the Tire Service Kit flat on the ground next to the deflated tire.
- 4. Remove the cap from the valve stem and then screw the fitting at the end of the Sealant Hose (6) onto the valve stem.

5. Uncoil the Power Plug (8) and insert the plug into the vehicle's 12 Volt power outlet.

NOTE:

Do not remove foreign objects (e.g., screws or nails) from the tire.

(C) Injecting Tire Service Kit Sealant Into The Deflated Tire:

 Always start the engine before turning ON the Tire Service Kit.

NOTE:

Manual transmission vehicles must have the parking brake engaged and the gear selector in NFUTRAL.

• After pushing the Power Button (4), the sealant (white fluid) will flow from the Sealant Bottle (1) through the Sealant Hose (6) and into the tire.

NOTE:

Sealant may leak out through the puncture in the tire.

If the sealant (white fluid) does not flow within O - 10 seconds through the Sealant Hose (6):



1. Push the Power Button (4) to turn Off the Tire Service Kit, Disconnect the Sealant Hose (6) from the valve stem. Make sure the valve stem is free of debris. Reconnect the Sealant Hose (6) to the valve stem. Check that the Mode Select Knob (5) is in the Sealant Mode position and not Air Mode. Push the Power Button (4) to turn On the Tire Service Kit.








2. Connect the Power Plug (8) to a different 12 Volt power outlet in your vehicle or another vehicle, if available. Make sure the engine is running before turning ON the Tire Service Kit.











If the Mode Select Knob (5) is on Air Mode and the pump is operating, air will dispense from the Air Pump Hose (7) only, not the Sealant Hose (6).

to previous use. Call for assistance.







If the sealant (white fluid) does flow through the Sealant Hose (6):

- 1. Continue to operate the pump until sealant is no longer flowing through the hose (typically takes 30 70 seconds). As the sealant flows through the Sealant Hose (6), the Pressure Gauge (3) can read as high as 70 psi (4.8 Bar). The Pressure Gauge (3) will decrease quickly from approximately 70 psi (4.8 Bar) to the actual tire pressure when the Sealant Bottle (1) is empty.
- The pump will start to inject air into the tire immediately after the Sealant Bottle (1) is empty. Continue to operate the pump and inflate the tire to the pressure indicated on the tire pressure label on the driver-side latch pillar (recommended pressure). Check the tire pressure by looking at the Pressure Gauge (3).

If the tire does not inflate to at least 26 psi (1.8 Bar) pressure within 15 minutes:

 The tire is too badly damaged. Do not attempt to drive the vehicle further. Call for assistance.

NOTE:

If the tire becomes overinflated, push the Deflation Button to reduce the tire pressure to the recommended inflation pressure before continuing.

If the tire inflates to the recommended pressure or is at least 26 psi (1.8 Bar) pressure within 15 minutes:

- 1. Push the Power Button (4) to turn off the Tire Service Kit.
- 2. Remove the Speed Limit sticker from the top of the Sealant Bottle (1) and place the sticker on the instrument panel.
- 3. Immediately disconnect the Sealant Hose (6) from the valve stem, reinstall the cap on the fitting at the end of the hose, and place the Tire Service Kit in the vehicle storage location. Quickly proceed to (D) "Drive Vehicle."

CAUTION!

• The metal end fitting from Power Plug (8) may get hot after use, so it should be handled carefully.

CAUTION!

 Failure to reinstall the cap on the fitting at the end of the Sealant Hose (6) can result in sealant contacting your skin, clothing, and the vehicle's interior. It can also result in sealant contacting internal Tire Service Kit components which may cause permanent damage to the kit.

(D) Drive Vehicle:

Immediately after injecting sealant and inflating the tire, drive the vehicle 5 miles (8 km) or ten minutes to ensure distribution of the Tire Service Kit Sealant within the tire. Do not exceed 55 mph (90 km/h).

WARNING!

Tire Service Kit is not a permanent flat tire repair. Have the tire inspected and repaired or replaced after using Tire Service Kit. Do not exceed 55 mph (90 km/h) until the tire is repaired or replaced. Failure to follow this warning can result in injuries that are serious or fatal to you, your passengers, and others around you.

(E) After Driving:

Pull over to a safe location. Refer to "Whenever You Stop To Use Tire Service Kit" before continuing.

- 1. Push in the Mode Select Knob (5) and turn to the Air Mode position.
- 2. Uncoil the power plug and insert the plug into the vehicle's 12 Volt power outlet.
- 3. Uncoil the Air Pump Hose (7) (black in color) and screw the fitting at the end of hose (7) onto the valve stem.
- 4. Check the pressure in the tire by reading the Pressure Gauge (3).

If tire pressure is less than 19 psi (1.3 Bar):

The tire is too badly damaged. Do not attempt to drive the vehicle further. Call for assistance.

If the tire pressure is 19 psi (1.3 Bar) or higher:

1. Push the Power Button (4) to turn on Tire Service Kit and inflate the tire to the pressure indicated on the tire and loading information label on the driver-side door opening.

NOTE:

If the tire becomes over-inflated, push the Deflation Button to reduce the tire pressure to the recommended inflation pressure before continuing.

- 2. Disconnect the Tire Service Kit from the valve stem, reinstall the cap on the valve stem and unplug from 12 Volt outlet.
- 3. Place the Tire Service Kit in its proper storage area in the vehicle.
- 4. Have the tire inspected and repaired or replaced at the earliest opportunity at an authorized dealer or tire service center.
- 5. Remove the Speed Limit sticker from the instrument panel after the tire has been repaired.
- 6. Replace the Sealant Bottle (1) and Sealant Hose (6) assembly at an authorized dealer as soon as possible. Refer to "(F) Sealant Bottle And Hose Replacement".

NOTE:

When having the tire serviced, advise the authorized dealer or service center that the tire has been sealed using the Tire Service Kit.

(F) Sealant Bottle And Hose Replacement:



1. Uncoil the Sealant Hose (6) (clear in color).



2. Locate the round Sealant Bottle release button in the recessed area under the sealant bottle.



3. Push the Sealant Bottle release button. The Sealant Bottle (1) will pop up. Remove the bottle and dispose of it accordingly.



4. Clean any remaining sealant from the Tire Service Kit housing.



5. Position the new Sealant Bottle (1) in the housing so that the Sealant Hose (6) aligns with the hose slot in the front of the housing. Push the bottle into the housing. An audible click will be heard indicating



the bottle is locked into place.



6. Verify that the cap is installed on the fitting at the end of the Sealant Hose (6) and return the hose to its storage area



7. Return the Tire Service Kit to its storage location in the vehicle.

(located on the bottom of the air pump).



JUMP STARTING

If your vehicle has a discharged battery, it can be jump started using a set of jumper cables and a battery in another vehicle or by using a portable battery booster pack. Jump starting can be dangerous if done improperly, so please follow the procedures in this section carefully.

NOTE:

When using a portable battery booster pack, follow the manufacturer's operating instructions and precautions.

WARNING!

Do not attempt jump starting if the battery is frozen. It could rupture or explode and cause personal injury.

CAUTION!

Do not use a portable battery booster pack or any other booster source with a system voltage greater than 12 Volts or damage to the battery, starter motor, alternator or electrical system may occur.

Preparations For Jump Start

The battery in your vehicle is located in the front of the engine compartment, behind the left headlight assembly.



Positive Battery Post

WARNING!

 Take care to avoid the radiator cooling fan whenever the hood is raised. It can start anytime the ignition switch is ON.

WARNING!

You can be injured by moving fan blades.

- Remove any metal jewelry such as rings, watch bands and bracelets that could make an inadvertent electrical contact. You could be seriously injured.
- Batteries contain sulfuric acid that can burn your skin or eyes and generate hydrogen gas which is flammable and explosive. Keep open flames or sparks away from the battery.
- Apply the parking brake, shift the automatic transmission into PARK (manual transmission in NEUTRAL) and turn the ignition to LOCK.
- 2. Turn off the heater, radio, and all unnecessary electrical accessories.
- If using another vehicle to jump start the battery, park the vehicle within the jumper cables reach, apply the parking brake and make sure the ignition is OFF.

WARNING!

Do not allow vehicles to touch each other as this could establish a ground connection and personal injury could result.

Jump Starting Procedure

WARNING!

Failure to follow this jump starting procedure could result in personal injury or property damage due to battery explosion.

CAUTION!

Failure to follow these procedures could result in damage to the charging system of the booster vehicle or the discharged vehicle.

Connecting The Jumper Cables

 Connect the positive (+) end of the jumper cable to the positive (+) post of the discharged vehicle.

- Connect the opposite end of the positive

 (+) jumper cable to the positive (+) post of
 the booster battery.
- Connect the negative (-) end of the jumper cable to the negative (-) post of the booster battery.
- 4. Connect the opposite end of the negative (-) jumper cable to a good engine ground (exposed metal part of the discharged vehicle's engine) away from the battery and the fuel injection system.

WARNING!

Do not connect the jumper cable to the negative (-) post of the discharged battery. The resulting electrical spark could cause the battery to explode and could result in personal injury. Only use the specific ground point, do not use any other exposed metal parts.

5. Start the engine in the vehicle that has the booster battery, let the engine idle for a few minutes, and then start the engine in the vehicle with the discharged battery.

6. Once the engine is started, remove the jumper cables in the reverse sequence:



Disconnecting The Jumper Cables



 Disconnect the negative (-) end of the jumper cable from the engine ground of the vehicle with the discharged battery.



2. Disconnect the opposite end of the negative (-) jumper cable from the negative (-) post of the booster battery.



3. Disconnect the positive (+) end of the jumper cable from the positive (+) post of the booster battery.



Disconnect the opposite end of the positive (+) jumper cable from the positive (+) post of the vehicle with the discharged battery.



If frequent jump starting is required to start your vehicle, you should have the battery and charging system inspected at an authorized dealer.







CAUTION!

Accessories plugged into the vehicle power outlets draw power from the vehicle's battery, even when not in use (i.e., cellular devices, etc.). Eventually, if plugged in long enough without engine operation, the vehicle's battery will discharge sufficiently to degrade battery life and/or prevent the engine from starting.

REFUELING IN EMERGENCY

Emergency Fuel Filler Door Release

If you are unable to open the fuel filler door, use the fuel filler door emergency release.

- 1. Open the liftgate.
- 2. Remove access door located on right interior trim panel for release cable with the tip of your key.
- 3. Grab the release cable tether and pull up to release the fuel filler door.

IF YOUR ENGINE OVERHEATS

In any of the following situations, you can reduce the potential for overheating your engine by taking the appropriate action.

- On the highways slow down.
- In city traffic while stopped, place the transmission in NEUTRAL, but do not increase engine idle speed.

CAUTION!

Driving with a hot cooling system could damage your vehicle. If the temperature gauge reads "H," pull over and stop the vehicle. Idle the vehicle with the air conditioner turned off until the pointer drops back into the normal range. If the pointer remains on the "H" and you hear continuous chimes, turn the engine off immediately and call for service.

NOTE:

There are steps that you can take to slow down an impending overheat condition:

- If your Air Conditioner (A/C) is on, turn it off. The A/C system adds heat to the engine cooling system and turning the A/C off can help remove this heat.
- You can also turn the temperature control to maximum heat, the mode control to floor and the blower control to high. This allows the heater core to act as a supplement to the radiator and aids in removing heat from the engine cooling system.

WARNING!

You or others can be badly burned by hot engine coolant (antifreeze) or steam from your radiator. If you see or hear steam coming from under the hood, do not open the hood until the radiator has had time to cool. Never try to open a cooling system pressure cap when the radiator or coolant bottle is hot.

GEAR SELECTOR OVERRIDE

If a malfunction occurs and the gear selector cannot be moved out of the PARK position, you can use the following procedure to temporarily move the gear selector:

- 1. Turn the engine OFF.
- 2. Apply the parking brake.
- Using a screwdriver or similar tool, carefully separate the shifter bezel and boot assembly from the center console, and raise it up to access the gear selector mechanism.
- 4. Press and maintain firm pressure on the brake pedal.
- Insert a small screwdriver or similar tool down into the gear selector override access hole (at the left front corner of the gear selector assembly), and push and hold the override release lever down.
- Move the gear selector to the NEUTRAL position.
- 7. The vehicle may then be started in NEUTRAL.
- 8. Reinstall the gear selector boot.

FREEING A STUCK VEHICLE

If your vehicle becomes stuck in mud, sand or snow, it can often be moved using a rocking motion. Turn the steering wheel right and left to clear the area around the front wheels. For vehicles with automatic transmission, push and hold the lock button on the gear selector. Then shift back and forth between DRIVE and REVERSE (with automatic transmission) or SECOND GEAR and REVERSE (with manual transmission), while gently pressing the accelerator.

NOTE:

For vehicles with automatic transmission: Shifts between DRIVE and REVERSE can only be achieved at wheel speeds of 5 mph (8 km/h) or less. Whenever the transmission remains in NEUTRAL for more than two seconds, you must press the brake pedal to engage DRIVE or REVERSE.

Use the least amount of accelerator pedal pressure that will maintain the rocking motion without spinning the wheels or racing the engine.

• Racing the engine or spinning the

wheels may lead to transmission over-

heating and failure. Allow the engine to

idle with the transmission in NEUTRAL

for at least one minute after every five

rocking-motion cycles. This will mini-

mize overheating and reduce the risk of

clutch or transmission failure during

prolonged efforts to free a stuck vehicle.

ing between DRIVE/SECOND GEAR and

REVERSE, do not spin the wheels faster

than 15 mph (24 km/h), or drivetrain

Revving the engine or spinning the

wheels too fast may lead to transmission

overheating and failure. It can also dam-

age the tires. Do not spin the wheels

above 30 mph (48 km/h) while in gear

(no transmission shifting occurring).

damage may result.

• When "rocking" a stuck vehicle by shift-























NOTE:

Push the "ESC Off" switch (if necessary), to place the Electronic Stability Control (ESC) system in "Partial Off" mode, before rocking the vehicle. Refer to "Electronic Brake Control System" in "Safety" for further information. Once the vehicle has been freed, push the "ESC Off" switch again to restore "ESC On" mode.

WARNING!

Fast spinning tires can be dangerous. Forces generated by excessive wheel speeds may cause damage, or even failure, of the axle and tires. A tire could explode and injure someone. Do not spin your vehicle's wheels faster than 30 mph (48 km/h) or for longer than 30 seconds continuously without stopping when you are stuck and do not let anyone near a spinning wheel, no matter what the speed.

TOWING A DISABLED VEHICLE

This section describes procedures for towing a disabled vehicle using a commercial towing service.

Towing Condition	Wheels OFF The Ground	FWD MODELS	4X4 MODELS
Flat Tow	NONE	NOT ALLOWED	NOT ALLOWED
Wheel Lift Or Delly Tow	Rear	NOT ALLOWED	NOT ALLOWED
Wheel Lift Or Dolly Tow	Front	OK	NOT ALLOWED
Flatbed	ALL	BEST METHOD	ONLY METHOD

Proper towing or lifting equipment is required to prevent damage to your vehicle. Use only tow bars and other equipment designed for this purpose, following equipment manufacturer's instructions. Use of safety chains is mandatory. Attach a tow bar or other towing devices to main structural members of the vehicle, not to bumpers or associated brackets. State and local laws regarding vehicles under tow must be observed.

NOTE:

- You must ensure that the Auto Park Brake feature is disabled before towing this vehicle, to avoid inadvertent Electric Park Brake engagement. The Auto Park Brake feature is enabled or disabled via the customer programmable features in the Uconnect Settings.
- Vehicles with a discharged battery or total electrical failure when the electric park brake (EPB) is engaged, will need a wheel dolly or jack to raise the rear wheels off the ground when moving the vehicle onto a flatbed.

If you must use the accessories (wipers, defrosters, etc.) while being towed, the ignition must be in the ON/RUN mode, not the ACC mode.

Note that the Safehold feature will engage the Electric Park Brake whenever the driver's door is opened (if the battery is connected, ignition is ON, transmission is not in PARK, and brake pedal is released). If you are towing this vehicle with the ignition in the ON/RUN mode, you must manually disable the Electric Park Brake each time the driver's door is opened, by pressing the brake pedal and then releasing the EPB.

If the vehicle's battery is discharged, refer to "Gear Selector Override" in this section for instructions on shifting the automatic transmission out of PARK so that the vehicle can be moved.

CAUTION!

- Do not use sling-type equipment when towing. Vehicle damage may occur.
- When securing the vehicle to a flatbed truck, do not attach to front or rear

CAUTION!



suspension components. Damage to your vehicle may result from improper towing.



 Ensure that the Electric Park Brake is released, and remains released, while being towed.



Without The Key Fob



Special care must be taken when the vehicle is towed with the ignition in the LOCK/OFF mode. The only approved method of towing without the key fob is with a flatbed truck. Proper towing equipment is necessary to prevent damage to the vehicle.







The manufacturer recommends towing your vehicle with all four wheels **OFF** the ground using a flatbed.







If flatbed equipment is not available, this vehicle must be towed with the front wheels OFF the ground (using a towing dolly, or wheel lift equipment with the front wheels raised).

Ensure that the Electric Park Brake is released, and remains released, while being towed. The Electric Park Brake does not need to be released, if all four wheels are off the ground.

CAUTION!

Towing this vehicle in violation of the above requirements can cause severe engine and/or transmission damage. Damage from improper towing is not covered under the New Vehicle Limited Warranty.

4x4 Models

The manufacturer requires towing with all four wheels **OFF** the ground.

Acceptable methods are to tow the vehicle on a flatbed, or with one end of vehicle raised and the opposite end on a towing dolly.

CAUTION!

- Front or rear wheel lifts must not be used (if the remaining wheels are on the ground). Internal damage to the transmission or power transfer unit will occur if a front or rear wheel lift is used when towing.
- Towing this vehicle in violation of the above requirements can cause severe transmission and/or power transfer unit damage. Damage from improper towing is not covered under the New Vehicle Limited Warranty.

Recovery Strap — If Equipped

Your vehicle may be included with a recovery strap. Recovery straps do not act like traditional tow straps, chains, or winch cables.

WARNING!

Recovery straps should only be used in emergencies to rescue stranded vehicles. Only use Recovery straps on vehicles that fit within the recommended GVW of your

WARNING!

recovery strap. Only attach recovery straps to OE recommended anchor points or emergency towing anchor points. Never attach to tow ball or vehicle tie down point, these are not designed for this purpose. Never attach to vehicle steering, drive train, or any other suspension components. NEVER pull a strap over sharp edges or abrasive surfaces that can damage the recovery strap. NEVER use a damaged strap, it has reduced strength. DO NOT attempt to repair straps. ONLY persons involved in the recovery should be in either vehicle. No passengers. Anyone inside the vehicles can be struck by strap recoil, causing serious injury. MOVE bystanders at least 40 ft (12.2 m) from the recovery area when using the recovery strap.

Using Recovery Strap

- 1. Review all warnings and instructions first.
- 2. Position the recovery vehicle.
- 3. Connect the recovery strap.
- 4. Add a recovery damper or blanket.

- 5. Clear the danger zone.
- 6. Safely and slowly start pulling.
- 7. Disconnect the recovery strap after both vehicles are secure and parked.

ENHANCED ACCIDENT RESPONSE SYSTEM (EARS)

This vehicle is equipped with an Enhanced Accident Response System.

Please refer to "Occupant Restraint Systems" in "Safety" for further information on the Enhanced Accident Response System (EARS) function.

EVENT DATA RECORDER (EDR)

This vehicle is equipped with an Event Data Recorder (EDR). The main purpose of an EDR is to record data that will assist in understanding how a vehicle's systems performed under certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle.

Please refer to "Occupant Restraint Systems" in "Safety" for further information on the Event Data Recorder (EDR).























SERVICING AND MAINTENANCE



SCHEDULED SERVICING196	Brake System
Scheduled Servicing —	Manual Transmission — If Equipped210
Gasoline Engine	Automatic Transmission
Scheduled Servicing —	Maintenance-Free Battery
Diesel Engine	DEALER SERVICE211
ENGINE COMPARTMENT204	Windshield Wiper Blades
2.4L Engine	milasinola mpor Biados 111111111111111
	DAIGING THE VEHICLE 010
3.2L Engine	RAISING THE VEHICLE216
3	RAISING THE VEHICLE216 TIRES
3.2L Engine	
3.2L Engine	TIRES
3.2L Engine .205 2.0L Diesel Engine .206 2.2L Diesel Engine .207	TIRES
3.2L Engine .205 2.0L Diesel Engine .206 2.2L Diesel Engine .207 Checking Oil Level .208	TIRES

re Chains (Traction Devices)223 re Rotation Recommendations224	
TORING THE VEHICLE	5
ODYWORK	3
reserving The Bodywork	ŝ
NTERIORS	7
eats And Fabric Parts	7
lastic And Coated Parts	7 5
eather Parts	3 [
lass Surfaces	3





















SCHEDULED SERVICING

Scheduled Servicing — Gasoline Engine

The scheduled services listed in this manual must be done at the times or mileages specified to protect your vehicle warranty and ensure the best vehicle performance and reliability. More frequent maintenance may be needed for vehicles in severe operating conditions, such as dusty areas and very short trip driving. Inspection and service should also be done anytime a malfunction is suspected.

The oil change indicator system will remind you that it is time to take your vehicle in for scheduled maintenance.

An "Oil Change Required" will be displayed in the instrument cluster and a single chime will sound, indicating that an oil change is necessary.

The oil change indicator message will illuminate approximately 7,000 miles (11,200 km) after the most recent oil change was performed. Have your vehicle serviced as soon as possible, within 500 miles (800 km).

NOTE:

- The oil change indicator message will not monitor the time since the last oil change. Change your vehicle's oil if it has been 12 months since your last oil change even if the oil change indicator message is NOT illuminated.
- Change your engine oil more often if you drive your vehicle off-road for an extended period of time.
- Under no circumstances should oil change intervals exceed 7,500 miles (12,000 km) or 12 months, whichever comes first.

Your authorized dealer will reset the oil change indicator message after completing the scheduled oil change. If this scheduled oil change is performed by someone other than your authorized dealer the message can be reset by referring to the steps described under "Instrument Cluster Display" in "Getting To Know Your Instrument Panel" for further information.

Once A Month Or Before A Long Trip

- Check engine oil level.
- · Check windshield washer fluid level.
- Check tire pressure and look for unusual wear or damage. Rotate tires at the first sign of irregular wear, even if it occurs before the oil indicator system turns on.
- Check the fluid levels of the coolant reservoir and brake master cylinder, fill as needed.
- Check function of all interior and exterior lights.

At Each Oil Change

- Change oil and filter.
- Rotate the tires. Rotate at the first sign of irregular wear, even if it occurs before the oil indicator system turns on.
- Inspect battery and clean and tighten terminals as required.
- Inspect brake pads, shoes, rotors, drums, hoses and park brake.
- Inspect engine cooling system protection and hoses.
- Inspect exhaust system.
- Inspect engine air cleaner if using in dusty or off-road conditions.

CAUTION!

Failure to perform the required maintenance items may result in damage to the vehicle.
























Maintenance Plan — Gasoline Engine

Mileage or time passed (whichever comes first)		15,000	22,500	30,000	37,500	45,000	52,500	000'09	67,500	75,000	82,500	90,000	97,500	105,000	112,500	120,000	127,500	135,000	142,500	150,000
Or Months:	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240
Or Kilometers:	12,000	24,000	36,000	48,000	000'09	72,000	84,000	96,000	108,000	120,000	132,000	144,000	156,000	168,000	180,000	192,000	204,000	216,000	228,000	240,000
Change engine oil and oil filter.††	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Rotate tires	Х	Х	Х	Х	Х	Χ	Х	Х	Х	Χ	Χ	Х	Χ	Х	Х	Х	Х	Χ	Х	Х
If using your vehicle in dusty or off-road conditions, inspect the air cleaner filter, and replace if necessary.		х		х		Х		Х		Х		Х		Х		Х		Х		Х
Inspect the brake linings, replace if necessary.	Χ		Х		Х		Х		Х		Х		Х		Х		Х		Х	
Inspect the front suspension, tie rod ends and boot seals, replace if necessary.	Х		Х		Х		Х		х		Х		Х		Х		Х		Х	
Visually inspect condition of: exterior bodywork, underbody protection, pipes and hoses (ex- haust - fuel system - brakes), rubber elements (boots, sleeves, bushings, etc.).		Х		х		Х		Х		Х		Х		Х		Х		х		Х
Inspect the CV joints.	Х		Х		Х		Х		Χ		Х		Х		Х		Х		Х	
Change brake fluid every 24 months if using DOT 4 brake fluid.*		Х		Х		Х		Х		Х		Х		Х		Х		Х		Х

Mileage or time passed (whichever comes first)	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000	67,500	75,000	82,500	90,000	97,500	105,000	112,500	120,000	127,500	135,000	142,500	150,000
Or Months:	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240
Or Kilometers:	12,000	24,000	36,000	48,000	000'09	72,000	84,000	96,000	108,000	120,000	132,000	144,000	156,000	168,000	180,000	192,000	204,000	216,000	228,000	240,000
Inspect parking brake function.	Х		Χ		Х		Χ		Χ		Χ		Х		Х		Х		Х	
Replace engine air cleaner filter.				Х				Х				Х				Х				Х
Replace air conditioning/cabin air filter.	Х		Х		Х		Х		Х		Х		Х		Х		Х		Х	
Replace spark plugs (2.4L & 3.2L engines).**									Х									Х		
Flush and replace the engine coolant at 10 years or 150,000 miles (240,000 km) whichever comes first.										Х										Х
Inspect and replace PCV valve if necessary.†													Х							
Inspect and replace, if required, front end accessory drive belt, tensioner, and, idler pulley.											·									х



^{**} The spark plug change interval is mileage based only, yearly intervals do not apply.

WARNING!

 You can be badly injured working on or around a motor vehicle. Do only service work for which you have the knowledge























[†] This maintenance is recommended by the manufacturer to the owner, but is not required to maintain emissions warranty.

WARNING!

and the right equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent mechanic.

 Failure to properly inspect and maintain your vehicle could result in a component malfunction and effect vehicle handling and performance. This could cause an accident.

Heavy Duty Use Of Vehicle

†† Change the engine oil and engine oil filter at every 4500 miles (7,500 km) or 12 months if using your vehicle under any of the following severe duty conditions:

- Stop and go driving.
- Driving in dusty conditions.
- Short trips of less than 10 miles (16 km).
- Trailer towing.
- Taxi, police, or delivery service (commercial service).
- Off-road or desert operation.

Scheduled Servicing — Diesel Engine

Your vehicle is equipped with an automatic oil change indicator system. The oil change indicator system will remind you that it is time to take your vehicle in for scheduled maintenance.

Based on engine operation conditions, the oil change indicator message will illuminate. This means that service is required for your vehicle. Operating conditions such as frequent short-trips, trailer tow, extremely hot or cold ambient temperatures will influence when the "Oil Change Required" message is displayed. Severe Operating Conditions can cause the change oil message to illuminate as earlier than specified. Have your vehicle serviced as soon as possible, within the next 500 miles (805 km).

To help you have the best driving experience possible, the manufacturer has identified the specific vehicle maintenance service intervals that are required to keep your vehicle operating properly and safely.

The manufacturer recommends that these maintenance intervals be performed at your selling dealer. The technicians at your dealership know your vehicle best, and have access to factory trained information, genuine Mopar parts, and specially designed electronic and mechanical tools that can help prevent future costly repairs.

The maintenance intervals shown should be performed as indicated in this section.

NOTE:

- The actual interval for changing the oil and replacing the engine oil filter depends on the vehicle usage conditions, it is signaled by the warning light or message (if present) in the instrument panel. It should not exceed 12,500 miles (20,000 km) or 12 months.
- Flush and replace the engine coolant at 120 months or 150,000 miles (240,000 km) whichever comes first.

Regardless of the distance covered, the timing and accessory belts must be changed every 4 years for particularly demanding use (cold climates, city driving, long periods of idling) or at least every 6 years. Under no circumstances should these intervals be exceeded.

Once A Month Or Before A Long Trip

- Check engine oil level.
- Check windshield washer fluid level.
- Check tire pressure and look for unusual wear or damage. Rotate tires at the first sign of irregular wear, even if it occurs before the oil indicator system turns on.
- Check the fluid levels of the coolant reservoir and brake master cylinder, fill as needed.
- Check function of all interior and exterior lights.

At Each Oil Change

- Change the engine oil filter.
- Inspect the brake hoses and lines.
- Inspect for the presence of water in the fuel filter/water separator unit.

CAUTION!

Failure to perform the required maintenance items may result in damage to the vehicle.
























Maintenance Plan — Diesel Engine

Mileage or time passed (whichever comes first)	12,500	25,000	37,500	50,000	62,500	75,000	87,500	100,000	112,500	125,000	137,500	150,000	162,500	175,000	187,500
Or Years:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Or Kilometers:	20,000	40,000	000'09	000'08	100,000	120,000	140,000	160,000	180,000	200,000	220,000	240,000	260,000	280,000	300,000
Additional Inspections															
Change the engine oil and engine oil filter. (*)	Х	Х	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ	Χ
Inspect the CV joints.		Х		Χ		Χ		Χ		Χ		Χ		Χ	
Inspect front suspension, boot seals, tie rod ends, and replace if necessary.		Х		Х		Х		Х		Х		Х		Х	
Visually inspect condition of: exterior bodywork, underbody protection, pipes and hoses (exhaust - fuel system - brakes), rubber elements (boots, sleeves, bushings, etc.).		Х		Х		Х		Х		Х		Х		Х	
If using your vehicle in dusty or off-road conditions, inspect the air cleaner filter, and replace if necessary.	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Inspect the brake linings, parking brake function.		Х		Χ		Χ		Х		Х		Х		Х	
Additional Maintenance															
Replace engine air cleaner filter.		Х		Χ		Χ		Χ		Χ		Χ		Χ	
Replace air conditioning/cabin air filter.		Х		Χ		Χ		Х		Х		Х		Χ	
Change brake fluid every 24 months if using DOT 4 brake fluid. (**)		Х		Х		Х		Х		Х		Х		Χ	
Replace the engine fuel filter.		Х		Х		Х		Х		Х		Х		Χ	
Inspect accessory drive belt.		Х						Х						Х	
Replace accessory drive belt. (***)						Χ						Х			

Mileage or time passed (whichever comes first)	12,500	25,000	37,500	50,000	62,500	75,000	87,500	100,000	112,500	125,000	137,500	150,000	162,500	175,000	187,500
Or Years:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Or Kilometers:	20,000	40,000	60,000	80,000	100,000	120,000	140,000	160,000	180,000	200,000	220,000	240,000	260,000	280,000	300,000
Change the manual transmission fluid if using your vehicle for any of the following: trailer towing, heavy loading, taxi, police, delivery service (commercial service), off-road, desert operation or more than 50% of your driving is at sustained speeds during hot weather, above 90°F (32°C).				х				Х				Х			
Flush and replace the engine coolant at 10 years or 150,000 miles (240,000 km) whichever comes first.										Х		Х			
Replace timing drive belt. (***)						Х						Х			



- (**) The brake fluid interval is time based only, mileage intervals do not apply.
- (***) Regardless of the distance covered, the timing and accessory belts must be changed every four years for particularly demanding

use (cold climates, city driving, long periods of idling), or at least every six years. Under no circumstances should these intervals be exceeded.

WARNING!

 You can be badly injured working on or around a motor vehicle. Do only service work for which you have the knowledge and the right equipment. If you have any doubt about your ability to perform a

WARNING!

service job, take your vehicle to a competent mechanic.

 Failure to properly inspect and maintain your vehicle could result in a component malfunction and effect vehicle handling and performance. This could cause an accident.





















ENGINE COMPARTMENT


2.4L Engine



- 1 Engine Coolant Reservoir
- 2 Oil Fill Cap
- 3 Brake Fluid Reservoir
- 4 Power Distribution Center (Fuses)

- 5 Battery
- 6 Washer Fluid Reservoir
- 7 Engine Oil Dipstick
- 8 Air Cleaner Filter

3.2L Engine



- 1 Engine Coolant Reservoir
- 2 Oil Filter Access Cover
- 3 Brake Fluid Reservoir
- 4 Power Distribution Center (Fuses)
- 5 Battery

- 6 Washer Fluid Reservoir
- 7 Engine Oil Dipstick
- 8 Engine Oil Fill
- 9 Air Cleaner Filter























2.0L Diesel Engine



- 1 Engine Coolant Reservoir
- 2 Engine Oil Fill
- 3 Brake Fluid Reservoir
- 4 Power Distribution Center (Fuses)

- 5 Battery
- 6 Washer Fluid Reservoir
- 7 Engine Oil Dipstick
- 8 Air Cleaner Filter

2.2L Diesel Engine



- 1 Engine Coolant Reservoir
- 2 Engine Oil Fill
- 3 Brake Fluid Reservoir
- 4 Power Distribution Center (Fuses)

- 5 Battery
- 6 Washer Fluid Reservoir
- 7 Engine Oil Dipstick
- 8 Air Cleaner Filter























Checking Oil Level

To assure proper engine lubrication, the engine oil must be maintained at the correct level. Check the oil level at regular intervals, such as every fuel stop. The best time to check the engine oil level is about five minutes after a fully warmed up engine is shut off.

Checking the oil while the vehicle is on level ground will improve the accuracy of the oil level readings.

There are three possible dipstick types,

- Crosshatched zone.
- Crosshatched zone marked SAFE.
- Crosshatched zone marked with MIN at the low end of the range and MAX at the high end of the range.

NOTE:

Always maintain the oil level within the crosshatch markings on the dipstick.

Adding 1 quart (1.0 liters) of oil when the reading is at the low end of the dipstick range will raise the oil level to the high end of the range marking.

CAUTION!

Overfilling or underfilling the crankcase will cause aeration or loss of oil pressure. This could damage your engine.

Cooling System

WARNING!

- You or others can be badly burned by hot engine coolant (antifreeze) or steam from your radiator. If you see or hear steam coming from under the hood, do not open the hood until the radiator has had time to cool. Never open a cooling system pressure cap when the radiator or coolant bottle is hot.
- Keep hands, tools, clothing, and jewelry away from the radiator cooling fan when the hood is raised. The fan starts automatically and may start at any time, whether the engine is running or not.
- When working near the radiator cooling fan, disconnect the fan motor lead or turn the ignition to the OFF mode. The

WARNING!

fan is temperature controlled and can start at any time the ignition is in the ON mode.

Engine Coolant Checks

Check the engine coolant (antifreeze) protection every 12 months (before the onset of freezing weather, where applicable). If the engine coolant (antifreeze) is dirty, the system should be drained, flushed, and refilled with fresh PARAFLU UP Formula OAT (Organic Additive Technology) or equivalent meeting the requirements of FCA Material Standard MS.90032. by an authorized dealer. Check the front of the A/C condenser for any accumulation of bugs, leaves, etc. If dirty, clean by gently spraying water from a garden hose vertically down the face of the condenser.

Check the engine cooling system hoses for brittle rubber, cracking, tears, cuts, and tightness of the connection at the coolant recovery bottle and radiator. Inspect the en-

208

tire system for leaks. DO NOT REMOVE THE COOLANT PRESSURE CAP WHEN THE COOLING SYSTEM IS HOT.

Adding Washer Fluid

The windshield and rear window washers share the same fluid reservoir. The fluid reservoir is located in the front of the engine compartment. Be sure to check the fluid level in the reservoir at regular intervals. Fill the reservoir with windshield washer solvent (not radiator antifreeze) and operate the system for a few seconds to flush out the residual water.

When refilling the washer fluid reservoir, take some washer fluid and apply it to a cloth or towel and wipe clean the wiper blades, this will help blade performance.

To prevent freeze-up of your windshield washer system in cold weather, select a solution or mixture that meets or exceeds the temperature range of your climate. This rating information can be found on most washer fluid containers.

WARNING!

Commercially available windshield washer solvents are flammable. They could ignite and burn vou. Care must be exercised when filling or working around the washer solution.

Brake System

In order to assure brake system performance, all brake system components should be inspected periodically. Refer to the "Maintenance Plan" in this section for the proper maintenance intervals.

WARNING!

Riding the brakes can lead to brake failure and possibly a collision. Driving with your foot resting or riding on the brake pedal can result in abnormally high brake temperatures, excessive lining wear, and possible brake damage. You would not have your full braking capacity in an emergency.

Fluid Level Check — Brake Master Cylinder




The fluid level of the master cylinder should be checked whenever the vehicle is serviced, or immediately if the brake system warning light is on. If necessary, add fluid to bring level within the designated marks on the side of the reservoir of the brake master cylinder. Be sure to clean the top of the master cylinder area before removing cap. With disc brakes, fluid level can be expected to fall as the brake pads wear. Brake fluid level should be checked when pads are replaced. If the brake fluid is abnormally low, check the system for leaks.











WARNING!

cal Specifications" for further information.



• Use only manufacturer's recommended brake fluid. Refer to "Fluids And Lubricants" in "Technical Specifications" for further information. Using the wrong type of brake fluid can severely damage your brake system and/or impair its performance. The proper type of brake fluid







WARNING!

for your vehicle is also identified on the original factory installed hydraulic master cylinder reservoir.

- To avoid contamination from foreign matter or moisture, use only new brake fluid or fluid that has been in a tightly closed container. Keep the master cylinder reservoir cap secured at all times. Brake fluid in a open container absorbs moisture from the air resulting in a lower boiling point. This may cause it to boil unexpectedly during hard or prolonged braking, resulting in sudden brake failure. This could result in a collision.
- Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts, causing the brake fluid to catch fire. Brake fluid can also damage painted and vinyl surfaces, care should be taken to avoid its contact with these surfaces.

WARNING!

 Do not allow petroleum based fluid to contaminate the brake fluid. Brake seal components could be damaged, causing partial or complete brake failure. This could result in a collision.

Manual Transmission — If Equipped

Fluid Level Check

Check the fluid level by removing the fill plug. The fluid level should be between the bottom of the fill hole and a point not more than 3/16 inch (4.7 mm) below the bottom of the hole.

Add fluid, if necessary, to maintain the proper level.

Please see your authorized dealer for service.

Automatic Transmission

Fluid Level Check

The fluid level is preset at the factory and does not require adjustment under normal operating conditions. Routine fluid level checks are not required; therefore the transmission has no dipstick. An authorized dealer can check your transmission fluid level using special service tools. If you notice fluid leakage or transmission malfunction, visit an authorized dealer immediately to have the transmission fluid level checked. Operating the vehicle with an improper fluid level can cause severe transmission damage.

CAUTION!

If a transmission fluid leak occurs, visit an authorized dealer immediately. Severe transmission damage may occur. An authorized dealer has the proper tools to adjust the fluid level accurately.

Maintenance-Free Battery

Your vehicle is equipped with a maintenancefree battery. You will never have to add water, nor is periodic maintenance required.

WARNING!

- Battery fluid is a corrosive acid solution and can burn or even blind you. Do not allow battery fluid to contact your eyes, skin, or clothing. Do not lean over a battery when attaching clamps. If acid splashes in eyes or on skin, flush the area immediately with large amounts of water. Refer to "Jump Starting Procedure" in "In Case Of Emergency" for further information.
- Battery gas is flammable and explosive. Keep flame or sparks away from the battery. Do not use a booster battery or any other booster source with an output greater than 12 Volts. Do not allow cable clamps to touch each other.
- Battery posts, terminals, and related accessories contain lead and lead compounds. Wash hands after handling.


CAUTION!

- It is essential when replacing the cables on the battery that the positive cable is attached to the positive post and the negative cable is attached to the negative post. Battery posts are marked positive (+) and negative (-) and are identified on the battery case. Cable clamps should be tight on the terminal posts and free of corrosion.
- If a "fast charger" is used while the battery is in the vehicle, disconnect both vehicle battery cables before connecting the charger to the battery. Do not use a "fast charger" to provide starting voltage.

DEALER SERVICE

An authorized dealer has the qualified service personnel, special tools, and equipment to perform all service operations in an expert manner. Service Manuals are available which include detailed service information for your vehicle. Refer to these Service Manuals before attempting any procedure yourself.

NOTE:











You can be badly injured working on or around a motor vehicle. Only do service work for which you have the knowledge and the proper equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent





Windshield Wiper Blades

mechanic.



Clean the rubber edges of the wiper blades and the windshield periodically with a sponge or soft cloth and a mild nonabrasive cleaner. This will remove accumulations of salt or road film









Operation of the wipers on dry glass for long periods may cause deterioration of the wiper blades. Always use washer fluid when using the wipers to remove salt or dirt from a dry windshield.

Avoid using the wiper blades to remove frost or ice from the windshield. Keep the blade rubber out of contact with petroleum products such as engine oil, gasoline, etc.

NOTE:

Life expectancy of wiper blades varies depending on geographical area and frequency of use. Poor performance of blades may be present with chattering, marks, water lines or wet spots. If any of these conditions are present, clean the wiper blades or replace as necessary.

The wiper blades and wiper arms should be inspected periodically, not just when wiper performance problems are experienced. This inspection should include the following points:

- Wear or uneven edges
- Foreign material

- · Hardening or cracking
- Deformation or fatigue


If a wiper blade or wiper arm is damaged, replace the affected wiper arm or blade with a new unit. Do not attempt to repair a wiper arm or blade that is damaged.

Front Wiper Blade Removal/Installation

CAUTION!


Do not allow the wiper arm to spring back against the glass without the wiper blade in place or the glass may be damaged.

1. Lift the wiper arm to raise the wiper blade off of the glass, until the wiper arm is in the full up position.



Wiper Blade With Release Tab In Locked Position


- 1 Wiper
- 2 Release Tab
- 3 Wiper Arm
- To disengage the wiper blade from the wiper arm, flip up the release tab on the wiper blade and while holding the wiper arm with one hand, slide the wiper blade down towards the base of the wiper arm.



Wiper Blade With Release Tab In **Unlocked Position**

- 1 Wiper Blade
- 2 Release Tab
- 3 Wiper Arm
- 3. With the wiper blade disengaged, remove the wiper blade from the wiper arm by holding the wiper arm with one hand and separating the wiper blade from the wiper

arm with the other hand (move the wiper blade toward the right side of the vehicle to separate the wiper blade from the wiper arm).




Wiper Blade Removed From Wiper Arm

- 1 Wiper Blade
- 2 Wiper Arm
- 3 Release Tab
- 4. Gently lower the wiper arm onto the glass.

Installing The Front Wipers







2. Position the wiper blade near the hook on the tip of the wiper arm with the wiper release tab open and the blade side of the wiper facing up and away from the windshield.



3. Insert the hook on the tip of the arm through the opening in the wiper blade



under the release tab.



4. Slide the wiper blade up into the hook on the wiper arm and rotate the wiper blade until it is flush against the wiper arm. Fold down the latch release tab and snap it into its locked position. Latch engagement will be accompanied by an audible click.













Rear Wiper Blade Removal/Installation

 Lift the rear wiper arm pivot cap away from the glass to allow the rear wiper blade to be raised off of the glass.

NOTE:

The rear wiper arm cannot be fully raised off the glass unless the wiper arm pivot cap is unsnapped first. Attempting to fully raise the rear wiper arm without unsnapping the wiper arm pivot cap may damage the vehicle.



Wiper Arm

- 1 Wiper Arm Pivot Cap
- 2 Wiper Arm
- 3 Wiper Blade
- 2. Lift the rear wiper arm fully off the glass.



Wiper Blade In Folded Out Position

- 1 Wiper Arm Pivot Cap
- 2 Wiper Arm
- 3 Wiper Blade

3. To remove the wiper blade from the wiper arm, grasp the bottom end of the wiper blade nearest to wiper arm with your right hand. With your left hand hold the wiper arm as you pull the wiper blade away from the wiper arm past its stop far enough to unsnap the wiper blade pivot pin from the receptacle on the end of the wiper arm.

NOTE:

Resistance will be accompanied by an audible snap.


4. Still grasping the bottom end of the wiper blade, move the wiper blade upward and away from the wiper arm to disengage.



Wiper Blade Removed From Wiper Arm


- 1 Wiper Arm
- 2 Wiper Blade
- 5. Gently lower the tip of the wiper arm onto the glass.

Installing The Rear Wiper











NOTE:

The rear wiper arm cannot be fully raised off the glass unless the wiper arm pivot cap is unsnapped first. Attempting to fully raise the rear wiper arm without unsnapping the wiper arm pivot cap may damage the vehicle.



2. Lift the rear wiper arm fully off the glass.



3. Insert the wiper blade pivot pin into the opening on the end of the wiper arm. Grab the bottom end of the wiper arm with one hand, and apply pressure on the wiper blade flush with the wiper arm until it snaps into place.



4. Lower the wiper blade onto the glass and snap the wiper arm pivot cap back into place.







RAISING THE VEHICLE

In the case where it is necessary to raise the vehicle, go to an authorized dealer or service station.

TIRES

Tires — General Information

Tire Pressure

Proper tire inflation pressure is essential to the safe and satisfactory operation of your vehicle. Four primary areas are affected by improper tire pressure:

- Safety and Vehicle Stability
- Economy
- Tread Wear
- Ride Comfort

Safety

WARNING!

- Improperly inflated tires are dangerous and can cause collisions.
- Underinflation increases tire flexing and can result in overheating and tire failure.
- Overinflation reduces a tire's ability to cushion shock. Objects on the road and chuckholes can cause damage that result in tire failure.
- Overinflated or underinflated tires can affect vehicle handling and can fail suddenly, resulting in loss of vehicle control.
- Unequal tire pressures can cause steering problems. You could lose control of your vehicle.
- Unequal tire pressures from one side of the vehicle to the other can cause the vehicle to drift to the right or left.
- Always drive with each tire inflated to the recommended cold tire inflation pressure.

Both under-inflation and over-inflation affect the stability of the vehicle and can produce a feeling of sluggish response or over responsiveness in the steering.

NOTE:

- Unequal tire pressures from side to side may cause erratic and unpredictable steering response.
- Unequal tire pressure from side to side may cause the vehicle to drift left or right.

Fuel Economy

Underinflated tires will increase tire rolling resistance resulting in higher fuel consumption.

Tread Wear

Improper cold tire inflation pressures can cause abnormal wear patterns and reduced tread life, resulting in the need for earlier tire replacement.

Ride Comfort And Vehicle Stability

Proper tire inflation contributes to a comfortable ride. Over-inflation produces a jarring and uncomfortable ride.

Tire Inflation Pressures

The proper cold tire inflation pressure is listed on the left side B-Pillar or rear edge of the passenger door.

At least once a month:

- Check and adjust tire pressure with a good quality pocket-type pressure gauge. Do not make a visual judgement when determining proper inflation. Tires may look properly inflated even when they are under-inflated.
- Inspect tires for signs of tire wear or visible damage.

CAUTION!

After inspecting or adjusting the tire pressure, always reinstall the valve stem cap. This will prevent moisture and dirt from entering the valve stem, which could damage the valve stem.

Inflation pressures specified on the placard are always "cold tire inflation pressure". Cold tire inflation pressure is defined as the tire pressure after the vehicle has not been driven for at least three hours, or driven less than

1 mile (1.6 km) after sitting for a minimum of three hours. The cold tire inflation pressure must not exceed the maximum inflation pressure molded into the tire sidewall.

Check tire pressures more often if subject to a wide range of outdoor temperatures, as tire pressures vary with temperature changes.

Tire pressures change by approximately 1 psi (7 kPa) per 12°F (7°C) of air temperature change. Keep this in mind when checking tire pressure inside a garage, especially in the Winter.

Example: If garage temperature = $68^{\circ}F$ (20°C) and the outside temperature = $32^{\circ}F$ (0°C) then the cold tire inflation pressure should be increased by 3 psi (21 kPa), which equals 1 psi (7 kPa) for every $12^{\circ}F$ (7°C) for this outside temperature condition.

Tire pressure may increase from 2 to 6 psi (13 to 40 kPa) during operation. DO NOT reduce this normal pressure build up or your tire pressure will be too low.

Tire Pressures For High Speed Operation



The manufacturer advocates driving at safe speeds and within posted speed limits. Where speed limits or conditions are such that the vehicle can be driven at high speeds, maintaining correct tire inflation pressure is very important. Increased tire pressure and reduced vehicle loading may be required for high-speed vehicle operation. Refer to an authorized tire dealer or original equipment vehicle dealer for recommended safe operating speeds, loading and cold tire inflation pressures.













High speed driving with your vehicle under maximum load is dangerous. The added strain on your tires could cause them to fail. You could have a serious collision. Do not drive a vehicle loaded to the maximum capacity at continuous speeds above 75 mph (120 km/h).









Radial Ply Tires

WARNING!

Combining radial ply tires with other types of tires on your vehicle will cause your vehicle to handle poorly. The instability could cause a collision. Always use radial ply tires in sets of four. Never combine them with other types of tires.

Tire Repair

If your tire becomes damaged, it may be repaired if it meets the following criteria:

- The tire has not been driven on when flat.
- The damage is only on the tread section of your tire (sidewall damage is not repairable).
- The puncture is no greater than a ¼ of an inch (6 mm).

Consult an authorized tire dealer for tire repairs and additional information.

Damaged Run Flat tires, or Run Flat tires that have experienced a loss of pressure should be replaced immediately with another Run Flat tire of identical size and service description (Load Index and Speed Symbol).

Run Flat Tires — If Equipped

Run Flat tires allow you the capability to drive 50 miles (80 km) at 50 mph (80 km/h) after a rapid loss of inflation pressure. This rapid loss of inflation is referred to as the Run Flat mode. A Run Flat mode occurs when the tire inflation pressure is of/or below 14 psi (96 kPa). Once a Run Flat tire reaches the run flat mode it has limited driving capabilities and needs to be replaced immediately. A Run Flat tire is not repairable.

It is not recommended driving a vehicle loaded at full capacity or to tow a trailer while a tire is in the run flat mode.

See the tire pressure monitoring section for more information.

Tire Spinning

When stuck in mud, sand, snow, or ice conditions, do not spin your vehicle's wheels above 30 mph (48 km/h) or for longer than 30 seconds continuously without stopping.

Refer to "Freeing A Stuck Vehicle" in "In Case Of Emergency" for further information.

WARNING!

Fast spinning tires can be dangerous. Forces generated by excessive wheel speeds may cause tire damage or failure. A tire could explode and injure someone. Do not spin your vehicle's wheels faster than 30 mph (48 km/h) for more than 30 seconds continuously when you are stuck, and do not let anyone near a spinning wheel, no matter what the speed.

Tread Wear Indicators

Tread wear indicators are in the original equipment tires to help you in determining when your tires should be replaced.



Tire Tread

- 1 Worn Tire
- 2 New Tire

These indicators are molded into the bottom of the tread grooves. They will appear as bands when the tread depth becomes a 1/16 of an inch (1.6 mm). When the tread is worn to the tread wear indicators, the tire should be replaced. Refer to "Replacement Tires" in this section for further information.

Life Of Tire

The service life of a tire is dependent upon varying factors including, but not limited to:

- Driving style.
- Tire pressure Improper cold tire inflation pressures can cause uneven wear patterns to develop across the tire tread. These abnormal wear patterns will reduce tread life, resulting in the need for earlier tire replacement.
- Distance driven.
- Performance tires, tires with a speed rating of V or higher, and Summer tires typically have a reduced tread life. Rotation of these tires per the vehicle scheduled maintenance is highly recommended.

WARNING!

Tires and the spare tire should be replaced after six years, regardless of the remaining tread. Failure to follow this warning can result in sudden tire failure. You could lose control and have a collision resulting in serious injury or death.

Keep dismounted tires in a cool, dry place with as little exposure to light as possible. Protect tires from contact with oil, grease, and gasoline.

inspected regularly for wear and correct cold

tire inflation pressures. The manufacturer

strongly recommends that you use tires

equivalent to the originals in size, quality and

performance when replacement is needed.

Refer to the paragraph on "Tread Wear Indi-

Certification Label for the size designation of

your tire. The Load Index and Speed Symbol

for your tire will be found on the original

It is recommended to replace the two front

tires or two rear tires as a pair. Replacing just

one tire can seriously affect your vehicle's

handling. If you ever replace a wheel, make








equipment tire sidewall.

those of the original wheels.






















It is recommended you contact an authorized tire dealer or original equipment dealer with any questions you may have on tire specifications or capability. Failure to use equivalent replacement tires may adversely affect the safety, handling, and ride of your vehicle.

WARNING!

- Do not use a tire, wheel size, load rating, or speed rating other than that specified for your vehicle. Some combinations of unapproved tires and wheels may change suspension dimensions and performance characteristics, resulting in changes to steering, handling, and braking of your vehicle. This can cause unpredictable handling and stress to steering and suspension components. You could lose control and have a collision resulting in serious injury or death. Use only the tire and wheel sizes with load ratings approved for your vehicle.
- Never use a tire with a smaller load index or capacity, other than what was originally equipped on your vehicle. Using a tire with a smaller load index could re-

WARNING!

sult in tire overloading and failure. You could lose control and have a collision.

 Failure to equip your vehicle with tires having adequate speed capability can result in sudden tire failure and loss of vehicle control.

CAUTION!

Replacing original tires with tires of a different size may result in false speedometer and odometer readings.

Tire Types

All Season Tires — If Equipped

All Season tires provide traction for all seasons (Spring, Summer, Fall, and Winter). Traction levels may vary between different all season tires. All season tires can be identified by the M+S, M&S, M/S or MS designation on the tire sidewall. Use all season tires only in sets of four; failure to do so may adversely affect the safety and handling of your vehicle.

Summer Or Three Season Tires — If Equipped

Summer tires provide traction in both wet and dry conditions, and are not intended to be driven in snow or on ice. If your vehicle is equipped with Summer tires, be aware these tires are not designed for Winter or cold driving conditions. Install Winter tires on your vehicle when ambient temperatures are less than 40°F (5°C) or if roads are covered with ice or snow. For more information, contact an authorized dealer.

Summer tires do not contain the all season designation or mountain/snowflake symbol on the tire sidewall. Use Summer tires only in sets of four; failure to do so may adversely affect the safety and handling of your vehicle.

WARNING!

Do not use Summer tires in snow/ice conditions. You could lose vehicle control, resulting in severe injury or death. Driving too fast for conditions also creates the possibility of loss of vehicle control.

Snow Tires

Some areas of the country require the use of snow tires during the Winter. Snow tires can be identified by a "mountain/snowflake" symbol on the tire sidewall.



If you need snow tires. select tires equivalent in size and type to the original equipment tires. Use snow tires only in sets of four: failure to do so may adversely affect the

safety and handling of your vehicle.

Snow tires generally have lower speed ratings than what was originally equipped with your vehicle and should not be operated at sustained speeds over 75 mph (120 km/h). For speeds above 75 mph (120 km/h) refer to original equipment or an authorized tire dealer for recommended safe operating speeds, loading and cold tire inflation pressures.

While studded tires improve performance on ice, skid and traction capability on wet or dry surfaces may be poorer than that of nonstudded tires. Some states prohibit studded tires: therefore, local laws should be checked before using these tire types.

Spare Tires — If Equipped

For vehicles equipped with Tire Service Kit instead of a spare tire, please refer to "Tire Service Kit" in "In Case Of Emergency" in the Owner's Manual for further information.

CAUTION!

Because of the reduced ground clearance, do not take your vehicle through an automatic car wash with a compact or limited use temporary spare installed. Damage to the vehicle may result.

Spare Tire Matching Original Equipped Tire And Wheel — If Equipped

Your vehicle may be equipped with a spare tire and wheel equivalent in look and function to the original equipment tire and wheel found on the front or rear axle of your vehicle. This spare tire may be used in the tire rotation for your vehicle. If your vehicle has this option, refer to an authorized tire dealer for the recommended tire rotation pattern.

hicle is equipped with a compact spare by

looking at the spare tire description on the

Tire and Loading Information Placard located

on the driver's side door opening or on the

sidewall of the tire. Compact spare tire de-

scriptions begin with the letter "T" or "S"

preceding the size designation. Example:


T145/80D18 103M.

the first opportunity.

















original equipment tire should be repaired (or



Do not install a wheel cover or attempt to mount a conventional tire on the compact spare wheel, since the wheel is designed





specifically for the compact spare tire. Do not install more than one compact spare tire and wheel on the vehicle at any given time.

WARNING!

Compact and collapsible spares are for temporary emergency use only. With these spares, do not drive more than 50 mph (80 km/h). Temporary use spares have limited tread life. When the tread is worn to the tread wear indicators, the temporary use spare tire needs to be replaced. Be sure to follow the warnings, which apply to your spare. Failure to do so could result in spare tire failure and loss of vehicle control.

Full Size Spare — If Equipped

The full size spare is for temporary emergency use only. This tire may look like the originally equipped tire on the front or rear axle of your vehicle, but it is not. This spare tire may have limited tread life. When the tread is worn to the tread wear indicators, the temporary use full size spare tire needs to be replaced. Since it is not the same as your

original equipment tire, replace (or repair) the original equipment tire and reinstall on the vehicle at the first opportunity.

Limited Use Spare — If Equipped

The limited use spare tire is for temporary emergency use only. This tire is identified by a label located on the limited use spare wheel. This label contains the driving limitations for this spare. This tire may look like the original equipped tire on the front or rear axle of your vehicle, but it is not. Installation of this limited use spare tire affects vehicle handling. Since it is not the same as your original equipment tire, replace (or repair) the original equipment tire and reinstall on the vehicle at the first opportunity.

WARNING!

Limited use spares are for emergency use only. Installation of this limited use spare tire affects vehicle handling. With this tire, do not drive more than the speed listed on the limited use spare wheel. Keep inflated to the cold tire inflation pressures listed on your Tire and Loading Information Placard

WARNING!

located on the driver's side B-Pillar or the rear edge of the driver's side door. Replace (or repair) the original equipment tire at the first opportunity and reinstall it on your vehicle. Failure to do so could result in loss of vehicle control.

Wheel And Wheel Trim Care

All wheels and wheel trim, especially aluminum and chrome plated wheels, should be cleaned regularly using mild (neutral Ph) soap and water to maintain their luster and to prevent corrosion. Wash wheels with the same soap solution recommended for the body of the vehicle and remember to always wash when the surfaces are not hot to the touch.

Your wheels are susceptible to deterioration caused by salt, sodium chloride, magnesium chloride, calcium chloride, etc., and other road chemicals used to melt ice or control dust on dirt roads. Use a soft cloth or sponge and mild soap to wipe away promptly. Do not use harsh chemicals or a stiff brush. They can damage the wheel's protective coating that helps keep them from corroding and tarnishing.

CAUTION!

Avoid products or automatic car washes that use acidic solutions or strong alkaline additives or harsh brushes. Many aftermarket wheel cleaners and automatic car washes may damage the wheel's protective finish. Such damage is not covered by the New Vehicle Limited Warranty. Only car wash soap is recommended.

When cleaning extremely dirty wheels including excessive brake dust, care must be taken in the selection of tire and wheel cleaning chemicals and equipment to prevent damage to the wheels. Select a non-abrasive, non-acidic cleaner for aluminum or chrome wheels.

CAUTION!

Do not use scouring pads, steel wool, a bristle brush, metal polishes or oven cleaner. These products may damage the wheel's protective finish. Such damage is not covered by the New Vehicle Limited Warranty. Only car wash soap is recommended.

NOTE:


If you intend parking or storing your vehicle for an extended period after cleaning the wheels with wheel cleaner, drive your vehicle and apply the brakes to remove the water droplets from the brake components. This activity will remove the red rust on the brake rotors and prevent vehicle vibration when braking.

Dark Vapor Chrome, Black Satin Chrome, or Low **Gloss Clear Coat Wheels**

CAUTION!

If your vehicle is equipped with these specialty wheels. DO NOT USE wheel cleaners, abrasives, or polishing compounds. They will permanently damage this finish and such damage is not covered by the New Vehicle Limited Warranty. HAND WASH ONLY USING MILD SOAP AND WATER WITH A SOFT CLOTH, Used on a regular basis; this is all that is reguired to maintain this finish.

Tire Chains (Traction Devices)





 Traction device must be of proper size for the tire, as recommended by the traction device manufacturer




Use on Front Tires Only



• Due to limited clearance, the following traction devices are recommended:



Front Wheel Drive (FWD) Models






• The use of 7mm snow chains is permitted with the use of 215/60R17 tires on size 17 x 7.0 FT41 wheels.



Four Wheel Drive (4WD) Non-Trailhawk Models Without A Two-Speed Power Takeoff Unit





• The use of 9mm snow chains is permitted with the use of 215/60R17 tires on size 17 x 7.0 FT41 wheels.









Four Wheel Drive (4WD) Non-Trailhawk Models With A Two-Speed Power Takeoff Unit

 The use of 7mm snow chains is permitted with 225/60R17 and 225/55R18 tires.

Four Wheel Drive (4WD) Trailhawk Models

• The use of 9mm snow chains is permitted with the use of 225/65R17 tires on size 17 x 7.5 ET31 wheels.

CAUTION!

- Use on Front Tires Only
- Damage to Front Wheel Drive (FWD)
 Models may result if tire chains or traction devices are used with original
 equipment size tires.
- Damage to Four Wheel Drive (4WD)
 Models without a Two-Speed Power
 Takeoff Unit may result if tire chains or
 traction devices are used with original
 equipment size tires.
- Damage to Four Wheel Drive (4WD)
 Trailhawk Models may result if tire
 chains or traction devices are used with
 original equipment size tires.

WARNING!

Using tires of different size and type (M+S, Snow) between front and rear axles can cause unpredictable handling. You could lose control and have a collision.

CAUTION!

To avoid damage to your vehicle or tires, observe the following precautions:

- Because of restricted traction device clearance between tires and other suspension components, it is important that only traction devices in good condition are used. Broken devices can cause serious damage. Stop the vehicle immediately if noise occurs that could indicate device breakage. Remove the damaged parts of the device before further use.
- Install device as tightly as possible and then retighten after driving about ½ mile (0.8 km).
- Do not exceed 30 mph (48 km/h).

CAUTION!

- Drive cautiously and avoid severe turns and large bumps, especially with a loaded vehicle.
- Do not drive for a prolonged period on dry pavement.
- Observe the traction device manufacturer's instructions on the method of installation, operating speed, and conditions for use. Always use the suggested operating speed of the device manufacturer's if it is less than 30 mph (48 km/h).
- Do not use traction devices on a compact spare tire.

Tire Rotation Recommendations


The tires on the front and rear of your vehicle operate at different loads and perform different steering, handling, and braking functions. For these reasons, they wear at unequal rates.

These effects can be reduced by timely rotation of tires. The benefits of rotation are especially worthwhile with aggressive tread designs such as those on On/Off Road type

tires. Rotation will increase tread life, help to maintain mud, snow, and wet traction levels, and contribute to a smooth, quiet ride.


Refer to the "Maintenance Plan" for the proper maintenance intervals. The reasons for any rapid or unusual wear should be corrected prior to rotation being performed.

The suggested Front Wheel Drive (FWD) rotation method is the "forward cross" shown in the following diagram. This rotation pattern does not apply to some directional tires that must not be reversed.



Front Wheel Drive (FWD) Tire Rotation

The suggested Four Wheel Drive (4WD) Tire rotation method is the "rearward cross" shown in the following diagram.



Four Wheel Drive (4WD) Tire Rotation


CAUTION!

Proper operation of four-wheel drive vehicles depends on tires of equal size, type and circumference on each wheel. Any difference in tire size can cause damage to the power transfer unit. Tire rotation schedule should be followed to balance tire wear.

STORING THE VEHICLE


If the vehicle should remain stationary for more than a month, observe the following precautions:

 Park your vehicle in a covered, dry and possibly airy location the windows open slightly. Check that the Electric Park Brake is not engaged.



tery charge quarterly.

at-





• Clean and protect the painted parts by applying protective waxes.



 Clean and protect polished metal parts by applying protective waxes.



 Apply talcum powder to the front and rear wiper blades and leave raised from the glass.



 Cover the vehicle with an appropriate cover taking care not to damage the painted surface by dragging across dirty surfaces. Do not use plastic sheeting which will not allow the evaporation of moisture present on the surface of the vehicle.



 Inflate the tires at a pressure of +7.25 psi (+0.5 bar) higher than recommended on the tire placard and check it periodically.







- Do not drain the engine cooling system.
- Whenever you leave the vehicle is stationary for two weeks or more, run idle the engine for approximately five minutes, with the air conditioning system on and high fan speed. This will ensure a proper lubrication of the system, thus minimizing the possibility of damage to the compressor when the vehicle is put back into operation.

NOTE:

When the vehicle has not been started or driven for at least 30 days, an Extended Park Start Procedure is required to start the vehicle. Refer to "Starting The Engine" in "Starting And Operating" for further information.

CAUTION!

Before removal of the positive and negative terminals to the battery, wait at least a minute with ignition switch in the OFF position and close the driver's door. When reconnecting the positive and negative terminals to the battery be sure the ignition switch is in the OFF position and the driver's door is closed.

BODYWORK

Preserving The Bodywork

Washing

- Wash your vehicle regularly. Always wash your vehicle in the shade using a mild car wash soap, and rinse the panels completely with clear water.
- Use a high quality cleaner wax to remove road film, stains and to protect your paint finish. Take care never to scratch the paint.
- Avoid using abrasive compounds and power buffing that may diminish the gloss or thin out the paint finish.

CAUTION!

- Do not use abrasive or strong cleaning materials such as steel wool or scouring powder that will scratch metal and painted surfaces.
- Use of power washers exceeding 1,200 psi (8,274 kPa) can result in damage or removal of paint and decals.

Special Care

- If you drive on salted or dusty roads or if you drive near the ocean, hose off the undercarriage at least once a month.
- It is important that the drain holes in the lower edges of the doors, rocker panels, and trunk be kept clear and open.
- If you detect any stone chips or scratches in the paint, touch them up immediately. The cost of such repairs is considered the responsibility of the owner.
- If your vehicle is damaged due to a collision or similar cause that destroys the paint and protective coating, have your vehicle repaired as soon as possible. The cost of such repairs is considered the responsibility of the owner.
- If you carry special cargo such as chemicals, fertilizers, de-icer salt, etc., be sure that such materials are well packaged and sealed.
- If a lot of driving is done on gravel roads, consider mud or stone shields behind each wheel.
- An authorized dealer has touch up paint to match the color of your vehicle.

INTERIORS

Seats And Fabric Parts

WARNING!

Do not use volatile solvents for cleaning purposes. Many are potentially flammable, and if used in closed areas they may cause respiratory harm.

Seat Belt Maintenance

Do not bleach, dye or clean the belts with chemical solvents or abrasive cleaners. This will weaken the fabric. Sun damage can also weaken the fabric.

If the belts need cleaning, use a mild soap solution or lukewarm water. Do not remove the belts from the vehicle to wash them. Dry with a soft cloth.

Replace the belts if they appear frayed or worn or if the buckles do not work properly.

WARNING!

A frayed or torn belt could rip apart in a collision and leave you with no protection. Inspect the belt system periodically, checking for cuts, frays, or loose parts. Damaged parts must be replaced immediately. Do not disassemble or modify the system. Seat belt assemblies must be replaced after a collision if they have been damaged (i.e., bent retractor, torn webbing, etc.).

Plastic And Coated Parts

Use a specific product to clean vinyl upholstery.

CAUTION!

 Direct contact of air fresheners, insect repellents, suntan lotions, or hand sanitizers to the plastic, painted, or decorated surfaces of the interior may cause permanent damage. Wipe away immediately.

CAUTION!



 Damage caused by these type of products may not be covered by your New Vehicle Limited Warranty.



Cleaning Plastic Instrument Cluster Lenses



The lenses in front of the instruments in this vehicle are molded in clear plastic. When cleaning the lenses, care must be taken to avoid scratching the plastic.



 Clean with a wet soft cloth. A mild soap solution may be used, but do not use high alcohol content or abrasive cleaners. If soap is used, wipe clean with a clean damp cloth.















Leather Parts

Your leather upholstery can be best preserved by regular cleaning with a damp soft cloth. Small particles of dirt can act as an abrasive and damage the leather upholstery and should be removed promptly with a damp cloth. Care should be taken to avoid soaking your leather upholstery with any liquid. Please do not use polishes, oils, cleaning fluids, solvents, detergents, or ammonia-based cleaners to clean your leather upholstery. Application of a leather conditioner is not required to maintain the original condition.

NOTE:

If equipped with light colored leather, it tends to show any foreign material, dirt, and fabric dye transfer more so than darker colors. The leather is designed for easy cleaning.

CAUTION!

Do not use Alcohol and Alcohol-based and/or Ketone based cleaning products to clean leather seats, as damage to the seat may result.

Glass Surfaces

All glass surfaces should be cleaned on a regular basis with any commercial household-type glass cleaner. Never use an abrasive type cleaner. Use caution when cleaning the inside rear window equipped with electric defrosters or windows equipped with radio antennas. Do not use scrapers or other sharp instruments that may scratch the elements.

When cleaning the rear view mirror, spray cleaner on the towel or cloth that you are using. Do not spray cleaner directly on the mirror.

TECHNICAL SPECIFICATIONS

VEHICLE IDENTIFICATION NUMBER230		
WHEEL AND TIRE TORQUE SPECIFICATIONS231	I	
Torque Specifications		
FUEL REQUIREMENTS — GASOLINE ENGINE231	ı	
Methanol .232 Ethanol .232)	
Clean Air Gasoline		
MMT In Gasoline)	
Materials Added To Fuel		

FUEL REQUIREMENTS — DIESEL ENGINE
Fuel Icon Identification Compliant To EN16942
FLUID CAPACITIES23
FLUIDS AND LUBRICANTS23
Engine
Chassis
MOPAR ACCESSORIES24























VEHICLE IDENTIFICATION NUMBER

The Vehicle Identification Number (VIN) is found on the left front corner of the instrument panel. The VIN is visible from outside of the vehicle through the windshield. The VIN number also is stamped into the right front body, on the right front seat cross member. With the seat in the rear most position a flap in the carpet can be cut open and lifted to reveal the VIN. It also appears on the Automobile Information Disclosure Label affixed to a window on your vehicle, the vehicle registration, and the title.

The VIN is also stamped on either right or left hand side of the engine block.



VIN Location



Right Front Body VIN Location

NOTE:

It is illegal to remove or alter the VIN.

WHEEL AND TIRE TORQUE SPECIFICATIONS

Proper lug nut/bolt torque is very important to ensure that the wheel is properly mounted to the vehicle. Any time a wheel has been removed and reinstalled on the vehicle, the lug nuts/bolts should be torqued using a properly calibrated torque wrench using a high quality six sided (hex) deep wall socket.


Torque Specifications

Lug Nut/Bolt	**Lug Nut/Bolt	Lug Nut/Bolt
Torque	Size	Socket Size
100 Ft-Lbs (135 N⋅m)	M12 x 1.25	19 mm

**Use only an authorized dealer recommended lug nuts/bolts and clean or remove any dirt or oil before tightening.

Inspect the wheel mounting surface prior to mounting the tire and remove any corrosion or loose particles.

Tighten the lug nuts/bolts in a star pattern until each nut/bolt has been tightened twice. Ensure that the socket is fully engaged on the lug nut/bolt (do not insert it halfway).



Torque Pattern

After 25 miles (40 km), check the lug nut/bolt torque to be sure that all the lug nuts/bolts are properly seated against the wheel.

WARNING!



To avoid the risk of forcing the vehicle off the jack, do not tighten the lug nuts fully until the vehicle has been lowered. Failure to follow this warning may result in personal injury.





FUEL REQUIREMENTS — GASOLINE ENGINE



This engine is designed to meet all emissions regulations and provide excellent fuel economy and performance when using high quality unleaded gasoline with a minimum research octane rating (RON) of 91.





Light spark knock at low engine speeds is not harmful to your engine. However, continued heavy spark knock at high speeds can cause damage, and immediate service is required.



Poor quality gasoline can cause problems such as hard starting, stalling, and hesitations. If you experience these symptoms, try another brand of gasoline before considering

service for the vehicle.





Methanol

(Methyl) is used in a variety of concentrations when blended with unleaded gasoline. You may find fuels containing 3% or more methanol along with other alcohols called cosolvents. Problems that result from using methanol/gasoline are not the responsibility of the manufacturer. While MTBE is an oxygenate made from Methanol, it does not have the negative effects of Methanol.

WARNING!

Do not use gasolines containing Methanol. Use of these blends may result in starting and drivability problems and may damage critical fuel system components.

Ethanol

The manufacturer recommends that your vehicle be operated on fuel containing no more than 15% ethanol. Purchasing your fuel from a reputable supplier may reduce the risk of exceeding this 15% limit and/or of receiving fuel with abnormal properties. It should also be noted that an increase in fuel consumption should be expected when using ethanol-

blended fuels, due to the lower energy content of ethanol. Problems that result from using methanol/gasoline or E-85 ethanol blends are not the responsibility of the manufacturer.

CAUTION!

Use of fuel with Ethanol content higher than 15% may result in engine malfunction, starting and operating difficulties, and materials degradation. These adverse effects could result in permanent damage to your vehicle.

Clean Air Gasoline

Many gasolines are now being blended to contribute to cleaner air, especially in those areas where air pollution levels are high. These new blends provide a cleaner burning fuel and some are referred to as "reformulated gasoline."

The manufacturer supports these efforts toward cleaner air. You can help by using these blends as they become available.

CNG And LP Fuel System Modifications

Modifications that allow the engine to run on compressed natural gas (CNG) or liquid propane (LP) may result in damage to the engine, emissions, and fuel system components. Problems that result from running CNG or LP are not the responsibility of the manufacturer and may void or not be covered under the New Vehicle Limited Warranty.

MMT In Gasoline

Methylcyclopentadienyl Manganese Tricarbonyl (MMT) is a manganese containing metallic additive that is blended into some gasoline to increase octane. Gasoline blended with MMT provides no performance advantage beyond gasoline of the same octane number without MMT. Gasoline blended with MMT reduces spark plug life and reduces emission system performance in some vehicles. The manufacturer recommends that gasoline without MMT be used in your vehicle. The MMT content of gasoline may not be indicated on the gasoline pump; therefore, you should ask your gasoline retailer whether or not his/her gasoline contains MMT.

Materials Added To Fuel

Fuel Icons

Indiscriminate use of fuel system cleaning agents should be avoided. Many of these materials intended for gum and varnish removal may contain active solvents or similar ingredients. These can harm fuel system gasket and diaphragm materials.



















Fuel Icon Identification Compliant To EN16942

ruei iculis	Wild It Wealls
E 5	Unleaded fuel containing up to 2,7 % (m/m) oxygen and a maximum ethanol content of 5,0 % (V/V) EN228 compliant fuel
E10	Unleaded fuel containing up to 3,7 % (m/m) oxygen and a maximum ethanol content of 10,0 % (V/V) EN228 compliant fuel

What It Means

Fuel Icons	What It Means
CNG	Compressed Natural Gas and biomethane for automotive applications EN16723 compliant fuel
LPG	Liquefied Petroleum Gas for automotive applications EN589 compliant fuel
В7	Diesel fuel containing up to 7 % (V/V) Fatty Acid Methyl Esters (FAME) EN590 compliant fuel
B10	Diesel fuel containing up to 10 % (V/V) Fatty Acid Methyl Esters (FAME) EN16734 compliant fuel

FUEL REQUIREMENTS — DIESEL ENGINE

Use good quality diesel fuel from a reputable supplier. If the outside temperature is very low, the diesel fuel thickens due to the formation of paraffin clots with consequent defective operation of the fuel supply system.

In order to avoid these problems different types of fuel are distributed according to the season: summer type, winter type and arctic type (cold/mountain areas). If fueling with diesel fuel whose features are not suitable for the temperature of use, it is advisable to mix in a suitable additive with the fuel. With the proportions shown on the container, pour the additive in the tank before fueling.

When using or parking the vehicle for a long time in the mountains or cold areas, it is advisable to refuel using locally available fuel. In this case, it is also advisable to keep the tank over half full.

This vehicle must only use premium diesel fuel that meets the requirements of EN 590. Biodiesel blends up to 7% that meet EN 590 may also be used.

WARNING!

Do not use alcohol or gasoline as a fuelblending agent. They can be unstable under certain conditions and hazardous or explosive when mixed with diesel fuel.

Diesel fuel is seldom completely free of water. To prevent fuel system trouble, drain the accumulated water from the fuel/water separator using the provided fuel/water separator drain. If you buy good quality fuel and follow the cold weather advice above, fuel conditioners should not be required in your vehicle. If available in your area, a high cetane "premium" diesel fuel may offer improved cold-starting and warm-up performance.























Fuel Icon Identification Compliant To EN16942

Fuel Icons	What It Means	
E5	Unleaded fuel containing up to 2,7 % (m/m) oxygen and a maximum ethanol content of 5,0 % (V/V) EN228 compliant fuel	
E10	Unleaded fuel containing up to 3,7 % (m/m) oxygen and a maximum ethanol content of 10,0 % (V/V) EN228 compliant fuel	
CNG	Compressed Natural Gas and biomethane for automotive applications EN16723 compliant fuel	
LPG	Liquefied Petroleum Gas for automotive applications EN589 compliant fuel	

Fuel Icons	What It Means	
В7	Diesel fuel containing up to 7 % (V/V) Fatty Acid Methyl Esters (FAME) EN590 compliant fuel	
B10	Diesel fuel containing up to 10 % (V/V) Fatty Acid Methyl Esters (FAME) EN16734 compliant fuel	

FLUID CAPACITIES

	U.S.	Metric
Fuel (Approximate)		
All Engines	15.8 Gallons	60 Liters
Engine Oil With Filter		
2.4 Liter Gasoline Engine (SAE 0W-20, API Certified)	5.5 Quarts	5.2 Liters
3.2 Liter Gasoline Engine (SAE 5W-20, API Certified)	6 Quarts	5.6 Liters
2.0 Liter Diesel Engine (SAE OW-30, FCA Material Standard 9.55535–DS1 and ACEA C2)	4.3 Quarts	4.1 Liters
2.2 Liter Diesel Engine (SAE OW-30, FCA Material Standard 9.55535–DS1 and ACEA C2)	4.3 Quarts	4.1 Liters























arts 6.8 Liters
arts 6.8 Liters
0.0 Elters
arts 9.5 Liters
arts 6.8 Liters
arts 6.8 Liters
16

Includes heater and coolant recovery bottle filled to MAX level.

FLUIDS AND LUBRICANTS

Engine

Component	Fluid, Lubricant, or Genuine Part
Engine Coolant	We recommend you use PARAFLU ^{UP} Formula OAT (Organic Additive Technology) or equivalent meeting the requirements of FCA Material Standard MS.90032.
Engine Oil – (2.4L Engine)	We recommend you use SAE 0W-20 API Certified Engine Oil, meeting the requirements of FCA Material Standard MS-6395. Refer to your engine oil filler cap for correct SAE grade.
Engine Oil – (3.2L Engine)	We recommend you use SAE 5W-20 API Certified Engine Oil, meeting the requirements of FCA Material Standard MS-6395. Refer to your engine oil filler cap for correct SAE grade. SAE 5W-30 engine oil approved to MS-6395 may be used when SAE 5W-20 engine oil is not available.

Component	Fluid, Lubricant, or Genuine Part
Engine Oil – 2.0L Diesel Engine	For best performance and maximum protection under all types of operating conditions, the manufacturer recommends Fully Synthetic Low Ash OW-30 engine oils that meet the requirements of FCA Material Standard 9.55535–DS1 and ACEA C2.
	NOTE: • If lubricants compliant with the required specifications are not available, products that comply with the minimum required characteristics can be used for topping off; in this case optimal performance of the engine is not guaranteed. • The use of products with specifications other than those indicated above could cause damage to the engine not covered by the warranty.
Engine Oil – 2.2L Diesel Engine	For best performance and maximum protection under all types of operating conditions, the manufacturer recommends Fully Synthetic Low Ash OW-30 engine oils that meet the requirements of FCA Material Standard 9.55535–DS1 and ACEA C2.
	 NOTE: If lubricants compliant with the required specifications are not available, products that comply with the minimum required characteristics can be used for topping off; in this case optimal performance of the engine is not guaranteed. The use of products with specifications other than those indicated above could cause damage to the engine not covered by the warranty.























Component	Fluid, Lubricant, or Genuine Part
Engine Oil Filter	We recommend you use a Mopar Engine Oil Filter.
Spark Plugs – Gas Engines	We recommend you use Mopar Spark Plugs.
Fuel Selection – 2.4L Engine	Minimum 91 Research Octane Number (RON)
Fuel Selection – 3.2L Engine	Minimum 91 Research Octane Number (RON)
Fuel Selection – 2.0L Diesel Engine	Specification EN590
Fuel Selection – 2.2L Diesel Engine	Specification EN590

Chassis

Component	Fluid, Lubricant, or Genuine Part
Automatic Transmission – If Equipped	Use only Mopar ZF 8&9 Speed ATF Automatic Transmission Fluid, or equivalent. Failure to use the correct fluid may affect the function or performance of your transmission.
Manual Transmission – If Equipped	We recommend you use Mopar C635 DDCT/MTX Transmission Fluid.
Brake Master Cylinder	We recommend you use Mopar DOT 3 Brake Fluid, SAE J1703 should be used. If DOT 3, SAE J1703 brake fluid is not available, then DOT 4 is acceptable. Use only recommended brake fluids. If using DOT 4 brake fluid change interval is time based only, regardless of mileage.

MOPAR ACCESSORIES

Authentic Accessories By Mopar

 The following highlights just some of the many Authentic Jeep Accessories by Mopar featuring a fit, finish, and functionality specifically for your Jeep Cherokee.

JEEP CARGO MANAGEMENT SYSTEM:

- Off Road Kit
- First Aid Kit

EXTERIOR:

- Rock Rails
- Wheels
- Wheel Locks
- License Plate Frames
- Valve Stem Caps

INTERIOR:

- Premium Floor Mats
- Security Cover
- All-Weather Mats

 In choosing Authentic Accessories you gain far more than expressive style, premium protection, or extreme entertainment, you also benefit from enhancing your vehicle with accessories that have been thoroughly tested and factory-approved.

- Roadside Safety Kit
- Collapsible Tote
- Front End Cover
- Splash Guards
- Locking Gas Cap
- Side Window Air Deflectors
- Vehicle Cover
- Emergency Roadside Kit
- Bright Pedal Kit
- Door Sill Guards

 For the full line of Authentic Jeep Accessories by Mopar, visit your local dealership or online at mopar.com for U.S. residents and mopar.ca for Canadian residents.





NOTE:

Cooler

All parts are subject to availability.









Cargo Area Cover





• Camping Tent







- Molded Cargo Tray
- Katzkin Leather Interiors
- Carpet Cargo Mat







ELECTRONICS:

- Mopar Web (WiFi)
- Remote Start

CARRIERS:

- Hitch-mount Bike Carrier
- Roof Top Cargo Basket
- Hitch Receiver
- Roof-Mount Kayak Carrier

- Speaker Upgrades
- Rear View Camera
- Sport Utility Bars
- Roof-mount Ski and Snowboard Carrier
- Roof-Mount Canoe Carrier
- Roof-Mount Surfboard Carrier

- Electronic Vehicle Tracking System
- Roof-mount Bike Carrier
- Roof Cargo Box Carrier

MULTIMEDIA

П.		-
- 11		
ı		-

CYBERSECURITY245
TIPS CONTROLS AND GENERAL INFORMATION
Steering Wheel Audio Controls 246
Reception Conditions
Care And Maintenance
Anti-Theft Protection
UCONNECT 3 WITH 5-INCH
DISPLAY
Controls On The Front Panel
Clock Setting
Equalizer, Balance And Fade
Radio Mode
Media Mode
Bluetooth Source
UCONNECT 3C/3C NAV253
Uconnect 3C/3C NAV At A Glance253
Drag & Drop Menu Bar
Radio Mode
Media Mode

POD/USB/SD CARD/MEDIA
PLAYER CONTROL257
Audio Jack (AUX)
JSB Port
SD Card
Bluetooth Streaming Audio
NAVIGATION258
Changing The Navigation Voice
Prompt Volume
Finding Points Of Interest
inding A Place By Spelling
he Name
One-Step Voice Destination Entry259
Setting Your Home Location
Go Home
Adding A Stop
aking A Detour
JCONNECT PHONE
Operation
Journal Phone Features
Journal Phone (Bluetooth Hands

57	Pairing (Wirelessly Connecting) Your Mobile Phone To The
57	Uconnect System
57	Common Phone Commands (Examples)
58 58	Mute (Or Unmute) Microphone During Call
58	Transfer Ongoing Call Between
	Handset And Vehicle
58	Phonebook
59	Voice Command Tips
	Changing The Volume
59	Using Do Not Disturb267
59	Incoming Text Messages
59	Voice Text Reply (Not Compatible
60	With iPhone)
60	Helpful Tips And Common Questions
60	To Improve Bluetooth Performance
61	With Your Uconnect System
61	UCONNECT VOICE RECOGNITION
63	QUICK TIPS
	Introducing Uconnect

Pairing (Wirelessly Connecting)
Your Mobile Phone To The
Uconnect System
Common Phone Commands
(Examples)
Mute (Or Unmute) Microphone
During Call
Transfer Ongoing Call Between
Handset And Vehicle
Phonebook
Voice Command Tips
Changing The Volume26
Using Do Not Disturb26
Incoming Text Messages26
Voice Text Reply (Not Compatible
With iPhone)
Helpful Tips And Common Questions
To Improve Bluetooth Performance

























Basic Voice Commands
Radio
Media
Phone
Voice Text Reply
Climate (3C/3C NAV)
Navigation (3C/3C NAV)
Siri Eyes Free — If Equipped
Do Not Disturb
Additional Information

CYBERSECURITY

Your vehicle may be a connected vehicle and may be equipped with both wired and wireless networks. These networks allow your vehicle to send and receive information. This information allows systems and features in your vehicle to function properly.

Your vehicle may be equipped with certain security features to reduce the risk of unauthorized and unlawful access to vehicle systems and wireless communications. Vehicle software technology continues to evolve over time and FCA US LLC, working with its suppliers, evaluates and takes appropriate steps as needed. Similar to a computer or other devices, your vehicle may require software updates to improve the usability and performance of your systems or to reduce the potential risk of unauthorized and unlawful access to your vehicle systems.


The risk of unauthorized and unlawful access to your vehicle systems may still exist, even if the most recent version of vehicle software (such as Uconnect software) is installed.

WARNING!

- It is not possible to know or to predict all
 of the possible outcomes if your vehi cle's systems are breached. It may be
 possible that vehicle systems, including
 safety related systems, could be im paired or a loss of vehicle control could
 occur that may result in an accident
 involving serious injury or death.
- ONLY insert media (e.g., USB, SD card, or CD) into your vehicle if it came from a trusted source. Media of unknown origin could possibly contain malicious software, and if installed in your vehicle, it may increase the possibility for vehicle systems to be breached.
- As always, if you experience unusual vehicle behavior, take your vehicle to your nearest authorized dealer immediately.

NOTE:







 To help further improve vehicle security and minimize the potential risk of a security breach, vehicle owners should:



 Routinely check www.driveuconnect.com/ support/software-update.html to learn about available Uconnect software updates.



 Only connect and use trusted media devices (e.g. personal mobile phones, USBs, CDs).



Privacy of any wireless and wired communications cannot be assured. Third parties may unlawfully intercept information and private communications without your consent. For further information, refer to "Onboard Diagnostic System (OBD II) Cybersecurity" in "Getting To Know Your Instrument Panel" in your Owner's Manual.











TIPS CONTROLS AND GENERAL INFORMATION

Steering Wheel Audio Controls

The steering wheel audio controls are located on the rear surface of the steering wheel.



Steering Wheel Audio Controls

Left Switch

• Push the switch up or down to search for the next listenable station.

 Push the button in the center to change modes AM/FM/DAB.

Right Switch

- Push the switch up or down to increase or decrease the volume.
- Push the button in the center to mute the radio.

Reception Conditions

Reception conditions change constantly while driving. Reception may be interfered with by the presence of mountains, buildings or bridges, especially when you are far away from the broadcaster.

The volume may be increased when receiving traffic alerts and news.

Care And Maintenance

Observe the following precautions to ensure the system is fully operational:

The display lens should not come into contact with pointed or rigid objects which could damage its surface; use a soft, dry anti-static cloth to clean and do not press.

- Never use alcohol, gas and derivatives to clean the display lens.
- Prevent any liquid from entering the system: this could damage it beyond repair.

Anti-Theft Protection

The system is equipped with an anti-theft protection system based on the exchange of information with the electronic control unit (Body Computer) on the vehicle.


This guarantees maximum safety and prevents the secret code from being entered after the power supply has been disconnected.

If the check has a positive outcome, the system will start to operate, whereas if the comparison codes are not the same or if the electronic control unit (Body Computer) is replaced, the system will ask the user to enter the secret code. See an authorized dealer for further information.

UCONNECT 3 WITH 5-INCH DISPLAY

Controls On The Front Panel





- 1 RADIO Button
- 2 COMPASS Button

- 3 CLIMATE Button
- 4 MORE Functions Button

- 5 Uconnect PHONE Button
- 6 MEDIA Button























Clock Setting

To start the clock setting procedure:

- Push the MORE button on the faceplate. Next press the "Settings" button on the touchscreen and then press the "Clock and Date" button on the touchscreen.
- 2. Press the "Set Time" button on the touchscreen.
- Press the "Up" or "Down" arrows to adjust the hours or minutes, next select the "AM" or "PM" button on the touchscreen.
 You can also select 12hr or 24hr format by pressing the desired button on the touchscreen.
- 4. Once the time is set press the "Done" button on the touchscreen to exit the time screen.

NOTE:

In the Clock Setting Menu you can also select the "Show Time Status" button on the touchscreen, then select from "On" or "Off" to display the time in the status bar.

Equalizer, Balance And Fade

- Push the MORE button on the faceplate. Next press the "Settings" button on the touchscreen.
- Then scroll down and press the "Audio" button on the touchscreen to get to the Audio menu.
- 3. The Audio Menu shows the following options for you to customize your audio settings.

Equalizer

Press the "Equalizer" button on the touchscreen to adjust the Bass, Mid and Treble. Use the "+" or "-" button on the touchscreen to adjust the equalizer to your desired settings. Press the "Back Arrow" button on the touchscreen when done.

Balance/Fade

Press the "Balance/Fade" button on the touchscreen to adjust the sound from the speakers. Use the arrow button on the touchscreen to adjust the sound level from the front and rear or right and left side speakers. Press the Center "C" button on the touch-

screen to reset the balance and fade to the factory setting. Press the "Back Arrow" button on the touchscreen when done.

Speed Adjusted Volume

Press the "Speed Adjusted Volume" button on the touchscreen to select between OFF, 1, 2 or 3. This will decrease the radio volume relative to a decrease in vehicle speed. Press the "Back Arrow" button on the touchscreen when done.

Loudness

Press the "Loudness" button on the touchscreen to select the Loudness feature. When this feature is activated it improves sound quality at lower volumes.

Surround Sound

Press the "Surround Sound" button on the touchscreen, select "On" or "Off" followed by pressing the "Back Arrow" button on the touchscreen. When this feature is activated, it provides simulated surround sound mode.

Radio Mode

Seek Previous/Next Buttons

Seek Up ▶▶

Press and release the "Seek Up" ▶▶ button on the touchscreen to tune the radio to the next listenable station or channel.

During a Seek Up function, if the radio reaches the starting station after passing through the entire band two times, the radio will stop at the station where it began.

Fast Seek Up ▶▶

Press and hold the "Seek Up" ▶▶ button on the touchscreen to advance the radio through the available stations or channels at a faster rate, the radio stops at the next available station or channel when the button on the touchscreen is released.

Seek Down ◄◀

Press and release the "Seek Down" ◄ button on the touchscreen to tune the radio to the next listenable station or channel.

During a Seek Down function, if the radio reaches the starting station after passing through the entire band two times, the radio will stop at the station where it began.

Fast Seek Down ◄◀

Press and hold the "Seek Down" ◄ button on the touchscreen to advance the radio through the available stations or channel at a faster rate, the radio stops at the next available station or channel when the button on the touchscreen is released.

Store Radio Presets

The Radio stores up to 12 presets in each of the Radio modes. There are four visible presets at the top of the radio screen. Pressing the "All" button on the touchscreen on the radio home screen will display all of the preset stations for that mode.

To store a radio preset manually, follow the steps below:

1. Tune to the desired station.

2. Press and hold the desired numbered button on the touchscreen for more than two seconds or until you hear a confirmation beep.





Media Mode

Audio Source Selection





1 —	SEEK
Down	

2 — SEEK Up

3 — Additional

Functions



4 — Info

5 — Pause/Plav 6 — Source


7 — Browse













Media Mode is entered by pushing the ME-DIA button located on the faceplate. Once in Media Mode, press the "Source" button on the touchscreen and the desired mode button on the touchscreen. Disc (if equipped), USB, AUX, and Bluetooth (if equipped), are the Media sources available. When available, you can select the "Browse" button on the touch-screen to be given these options:

- Now Playing
- Artists
- Albums
- Genres
- Songs
- Playlists
- Folders

Source

Press the "Source" button on the touchscreen to select the desired audio source: Disc (if equipped), USB, AUX and Bluetooth (if equipped). This screen will time out after a few seconds and return to the main radio screen if no selection is made. You can press the "Source," "Pause/Play" or the "Info" button on the touchscreen for artist information on the current song playing.

Disc Mode — If Equipped

Your vehicle may have a remote Disc player located in the center console storage bin.

Disc Mode is entered by either inserting a CD/Disc or by pushing the MEDIA button on the faceplate. Once in Media Mode, press the "Source" button on the touchscreen and select "Disc."

Inserting Compact Disc

Gently insert one disc into the disc player with the disc label following the illustration indicated on the player. The disc automatically pulls into the disc player and the disc icon illuminates on the radio display. If a disc does not go into the slot more than 1 inch (2.5 cm), a disc may already be loaded and must be ejected before a new disc can be loaded.

If you insert a disc with the ignition ON and the radio ON, the unit will switch to disc mode and begin to play when you insert the disc. The display will show the track number and index time in minutes and seconds. Play will begin at the start of track one.

Browse

Press the "Browse" button on the touchscreen to scroll through and select a desired track on the Disc. Press the "Exit" button on the touchscreen if you wish to cancel the browse function.

Eject Button — Ejecting a Disc

Push the eject button to eject the disc. If you have ejected a disc and have not removed it within ten seconds, it will be reloaded. If the Disc is not removed, the radio will reinsert the disc but will not play it.

A disc can be ejected with the radio and ignition OFF.

USB/iPod Mode

USB/iPod Mode is entered by either inserting a USB Jump Drive or iPod cable into the USB port, or by pushing the MEDIA button located on the faceplate. Once in Media Mode, press the "Source" button on the touchscreen and select "USB/iPod."

Inserting USB/iPod Device

Gently insert the USB/iPod device into the USB Port. If you insert a USB/iPod device with the ignition ON, the unit will switch to USB/iPod mode and begin to play when you insert the device. The display will show the track number and index time in minutes and seconds. Play will begin at the start of track one.

Browse

Press the "Browse" button on the touchscreen to select Artist, Albums, Genres, Songs, Playlists or Folders from the USB/ iPod device. Once the desired selection is made you can chose from the available media by pressing the button on the touchscreen. Press the "Fxit" button on the touchscreen if you wish to cancel the browse function.

AUX Mode

AUX Mode is entered by inserting a AUX device using a stereo cable with a 3.5 mm audio jack into the AUX port, or by pushing the MEDIA button located on the faceplate. Once in Media Mode, press the "Source" button on the touchscreen and select "AUX."

Inserting Auxiliary Device

Gently insert the Auxiliary device cable into the AUX Port. If you insert a Auxiliary device with the ignition ON, the unit will switch to AUX mode and begin to play when you insert the device cable.

Controlling The Auxiliary Device

The control of the Auxiliary device (e.g., selecting playlists, play, fast forward, etc.) cannot be provided by the radio: use the device controls instead. Adjust the volume with the VOLUME/MUTE rotary knob, or with the volume of the attached device.

The radio unit is acting as the amplifier for audio output from the Auxiliary device. Therefore if the volume control on the Auxiliary device is set too low, there will be insufficient audio signal for the radio unit to play the music on the device.

Track Selection

Seek Up ▶► /Seek Down ◄◀

Press and release the "Right Arrow" ▶▶ button on the touchscreen for the next selection. Press and release the "Left Arrow" ◄ button

on the touchscreen to return to the beginning of the current selection, or return to the beginning of the previous selection if the Disc is within the first second of the current selection.







Press and hold the "Right Arrow" ▶▶ button on the touchscreen and the desired mode will begin to fast forward through the current track until the button on the touchscreen is released.





Fast Seek Down ◄◀

Press and hold the "Left Arrow" ◄ button on the touchscreen and the desired mode will begin to rewind through the current track until the button on the touchscreen is released.







Info

Press the "Info" button on the touchscreen to display the current track information. Press the "X" button on the touchscreen to cancel this feature.







Shuffle

Press the "Shuffle" button on the touchscreen to play the selections on the USB/iPod device in random order to provide an interesting change of pace. Press the "Shuffle" button on the touchscreen a second time to turn this feature off.

Repeat

Press the "Repeat" button on the touchscreen to repeat the song selection. To cancel repeat, press the "Repeat" button on the touchscreen a second time.

Bluetooth Source

Bluetooth Streaming Audio (BTSA) or Bluetooth Mode is entered by pairing a Bluetooth device containing music to the Uconnect system.

Before proceeding, the Bluetooth device must be paired with the Uconnect Phone to communicate with the Uconnect system.

See the "Pairing Procedure" in this manual for further details.

Once the Bluetooth device is paired to the Uconnect system, push the MEDIA button located on the faceplate. Once in Media Mode, press the "Source" button on the touchscreen and select "Bluetooth."

NOTE:

For mobile phone compatibility and pairing instructions, please visit UconnectPhone.com.

Uconnect LIVE

The Uconnect LIVE app is available in the Apple Store or the Google Play Store. A whole range of apps can be viewed and controlled through the touchscreen of the Uconnect system. The apps have been designed to ensure that the driver's concentration remains focused on driving. For further information refer to www.driveuconnect.eu/.

Pairing A Bluetooth Audio Device

To begin using your audio device, you must pair your compatible Bluetooth enabled audio device. Pairing is the process of establishing a wireless connection between a device and the Uconnect system.

NOTE:

- You must have Bluetooth enabled on your device to complete this procedure.
- The vehicle must be in PARK.
- 1. Place the ignition in the ACC or ON position.
- 2. Push the PHONE button on the faceplate.
 - If there is no devices currently connected with the system, a pop-up will appear asking if you would like to pair a device.
- 3. Select "Yes" to begin the pairing process.
- 4. Search for available devices on your Bluetooth enabled device.
 - Select Bluetooth and ensure it is enabled. Once enabled, the device will begin to search for Bluetooth connections.
- If No is selected, and you still would like to pair a device, press the "Settings" button from the Uconnect Phone main screen.

- Select "Paired Phones" then press the "Add Device" button on the touchscreen.
- · Search for available devices on your Bluetooth enabled device (see below). When prompted on the device, select "Uconnect" and accept the connection request.
- 6. Uconnect Phone will display an in progress screen while the system is connecting.
- 7. When your device finds the Uconnect system, select "Uconnect."
- 8. When prompted on the device, accept the connection request from Uconnect Phone.

NOTE:

Some devices will require you to enter the PIN number.

9. When the pairing process has successfully completed, the system will prompt you to choose whether or not this is your favorite device. Selecting "Yes" will make this device the highest priority. This device will take precedence over other paired devices within range and will connect to the Uconnect system automatically when entering the vehicle. Only one Bluetooth device can be connected to the Uconnect system at a time. If "No" is selected, simply select "Uconnect" from the device Bluetooth screen, and the Uconnect system will reconnect to the Bluetooth device.

UCONNECT 3C/3C NAV

















WARNING!



ALWAYS drive safely with your hands on the wheel. You have full responsibility and assume all risks related to the use of the Uconnect features and applications in this vehicle. Only use Uconnect when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.







CAUTION!

Do NOT attach any object to the touchscreen, doing so can result in damage to the screen.

Setting The Time

- Model 3C NAV synchronizes time automatically via GPS, so it should not require any time adjustment. If you do need to set the time manually, follow the instructions below for Model 3C.
- For Model 3C, turn the unit on, then press the time display at the top of the screen. Press "Yes."
- If the time is not displayed at the top of the screen, press the "Settings" button on the touchscreen. In the Settings screen, press the "Clock" button on the touchscreen, then check or uncheck this option.
- Press "+" or "-" next to Set Time Hours and Set Time Minutes to adjust the time.
- If these features are not available, uncheck the Sync Time box.

• Press "X" to save your settings and exit out of the Clock Setting screen.

Background Themes

- Screen background themes are selectable from a pre-loaded list of themes. If you'd like to set a theme, follow the instructions below.
- Press the "Settings" button on the touchscreen.
- Press the "Display" button on the touchscreen.
- Then press "Set Theme" button on the touchscreen and select a theme.

Audio Settings

- Press of the "Audio" button on the touchscreen to activate the Audio settings screen to adjust Balance\Fade, Equalizer, and Speed Adjusted Volume.
- You can return to the Radio screen by pressing the "X" located at the top right.

Balance/Fade

- Press the "Balance/Fade" button on the touchscreen to Balance audio between the front speakers or fade the audio between the rear and front speakers.
- Pressing the "Front," "Rear," "Left," or "Right" buttons on the touchscreen or press and drag the Speaker Icon to adjust the Balance/Fade.

Equalizer

- Press the "Equalizer" button on the touchscreen to activate the Equalizer screen.
- Press the "+" or "-" buttons on the touchscreen, or press and drag over the level bar for each of the equalizer bands. The level value, which spans between plus or minus nine, is displayed at the bottom of each of the Bands.

Speed Adjusted Volume

Press the "Speed Adjusted Volume" button on the touchscreen to activate the Speed Adjusted Volume screen. The Speed Adjusted Volume is adjusted by pressing the volume level indicator. This alters the automatic adjustment of the audio volume with variation to vehicle speed.

Drag & Drop Menu Bar

The Uconnect features and services in the main menu bar are easily changed for your convenience. Simply follow these steps:



Uconnect 3C/3C NAV Main Menu

- 1. Press the "Apps **(a)**" button to open the App screen.
- Press and hold, then drag the selected App to replace an existing shortcut in the main menu bar.

The replaced shortcut will now be an active App/shortcut on the main menu bar.

Radio Mode



Uconnect 3C NAV Radio

1 — Radio Station Presets
2 — Toggle Between Presets
3 — Status Bar
4 — View Small
Navigation Map
5 — Main Category Bar
6 — Audio Settings

7 — Seek Up 8 — Direct Tune To A Radio Station 9 — Seek Down 10 — Browse And Manage Presets 11 — Radio Bands

WARNING!



ALWAYS drive safely with your hands on the wheel. You have full responsibility and assume all risks related to the use of the Uconnect features and applications in this vehicle. Only use Uconnect when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.





To access the Radio mode, press the "Radio" button on the touchscreen.



Selecting Radio Stations



Press the desired radio band (AM, or FM) button on the touchscreen.



Seek Up/Seek Down



 Press the Seek up or down arrow buttons on the touchscreen for less than two seconds to seek through radio stations.



 Press and hold either arrow button on the touchscreen for more than two seconds to bypass stations without stopping. The radio will stop at the next listenable station once the arrow button on the touchscreen is released.







Direct Tune

 Tune directly to a radio station by pressing the "Tune" button on the screen, and entering the desired station number.

Store Radio Presets Manually

Your radio can store 24 total preset stations, 12 presets per band (AM, and FM). They are shown at the top of your radio screen. To see the 12 preset stations per band, press the arrow button on the touchscreen at the top right of the screen to toggle between the two sets of six presets.

To store a radio preset manually, follow the steps below:

- 1. Tune to the desired station.
- Press and hold the desired numbered button on the touchscreen for more than two seconds or until you hear a confirmation beep.

Media Mode



Uconnect 3C/3C NAV Media

1 — Repeat
Music Track
2 — Music
Track And Time
3 — Shuffle
Music Tracks
4 — Music
Track Information

5 — Show Songs Currently In Queue To Be Played 6 — Browse Music By 7 — Music Source The controls are accessed by pressing the desired button on the touchscreen and choosing between Disc, AUX, USB, Bluetooth or SD Card.

NOTE:

Uconnect will automatically switch to the appropriate mode when something is first connected or inserted into the system.

UCONNECT SETTINGS

The Uconnect system allows you to access Customer Programmable feature settings such as Display, Voice, Clock, Safety & Driving Assistance, Lights, Doors & Locks, Auto-On Comfort, Engine Off Options, Compass Settings, Audio, Phone/Bluetooth, Radio Setup, Restore Settings, Clear Personal Data, and System Information through buttons on the touchscreen.

Push the SETTINGS button (Uconnect 3), or press the "Apps" button (Uconnect 3C/3C NAV) located near the bottom of the touch-screen, then press the "Settings" button on the touchscreen to access the Settings screen. When making a selection, scroll up or down until the preferred setting is high-

lighted, then press the preferred setting until a check-mark appears next to the setting. showing that setting has been selected. The following feature settings are available:

- Display
- Voice
- Clock
- Safety & Driving Assistance
- Lights
- Doors & Locks
- Auto-On Comfort
- Compass (Uconnect 3)

- Engine Off Options
- Audio
- Phone/Bluetooth
- Radio Setup
- Restore Settings
- Clear Personal Data
- System Information

NOTE:

Depending on the vehicles options, feature settings may vary.

Refer to "Uconnect Settings" in "Multimedia" in the Owner's Manual for further information.

IPOD/USB/SD CARD/MEDIA **PLAYER CONTROL**




Uconnect Media Hub


- 1 SD Card Port
- 2 AUX Jack
- 3 USB Port

There are many ways to play music from MP3 players, USB devices, or SD Cards through your vehicle's sound system. Press your Media button on the touchscreen to begin.


Audio Jack (AUX)













the AUX, plug in the audio jack.



• The functions of the device are controlled using the device buttons. The volume may be controlled using the radio or device.



USB Port

• Connect your compatible device into the USB Port using a USB cable. USB Memory sticks with audio files can also be used. Audio from the device can be played on the vehicle's sound system while providing metadata (artist, track title, album, etc.) information on the radio display.







- When connected, the compatible USB device can be controlled using the radio or Steering Wheel Audio Controls to play, skip to the next or previous track, browse, and list the contents.
- The battery charges when plugged into the USB port (if supported by the specific device).
- To route the USB cable out of the center console, use the access cut out.

NOTE:

When connecting your device for the first time, the system may take several minutes to read your music, depending on the number of files. For example, the system will take approximately five minutes for every 1,000 songs loaded on the device. Also during the reading process, the Shuffle and Browse functions will be disabled. This process is needed to ensure the full use of your features and only happens the first time it is connected. After the first time, the reading process of your device will take considerably less time unless changes are made or new songs are added to the playlist.

SD Card

- Play songs stored on an SD card inserted into the SD card slot.
- Song playback can be controlled using the radio or Steering Wheel Audio Controls to play, skip to the next or previous track, browse, and list the contents.

Bluetooth Streaming Audio

If using a Bluetooth equipped device you may also be able to stream music to your vehicle's sound system. Your connected device must be Bluetooth compatible and paired with your system (see Uconnect Phone for pairing instructions). You can access the music from your connected Bluetooth device by pressing the Bluetooth button on the touchscreen while in Media mode.

NAVIGATION

- The information in the section below is only applicable if you have the 3C NAV system or the Navigation has been activated on your 3C system.
- If you have a Uconnect 3C system your radio is "Navigation-Ready," and can be equipped with Navigation at an extra cost. Please see your dealer for details.

Press the "Nav" button on the touchscreen in the menu bar to access the Navigation system.

Changing The Navigation Voice Prompt Volume

- 1. Press the "View Map" button on the touchscreen from the Nav Main Menu.
- 2. With the map displayed, press the "Settings" button on the touchscreen in the lower right area of the screen.
- 3. In the Settings menu, press the "Guidance" button on the touchscreen.

 In the Guidance menu, adjust the Nav Volume by pressing the "+" or "-" buttons on the touchscreen.



Uconnect 3C NAV Navigation

1 — Find A Destination

2 — View Map

3 — Informa-

tion

4 — Emergency

5 — Navigation

Settings

6 — Stop A Route 7 — Detour A

Route 8 — Repeat

Route Guidance Prompt

Finding Points Of Interest


- From the main Navigation menu, press the "Where To?" button on the touchscreen, then press the "Points of Interest" button on the touchscreen.
- Select a Category and then a subcategory, if necessary.
- Select your destination and press the "Yes" button on the touchscreen.

Finding A Place By Spelling The Name

- From the Main Navigation Menu press the "Where to?" button on the touchscreen, press the "Points of Interest" button on the touchscreen, then press the "Spell Name" button on the touchscreen.
- Enter the name of your destination.
- Press the "List" button on the touchscreen.
- Select your destination and press the "Yes" button on the touchscreen.

One-Step Voice Destination Entry








• Just push the Uconnect Voice Command ((½vR button on the steering wheel, wait for the beep and say something like, "Find Address 800 Chrysler Drive Auburn Hills MI."



NOTE:









further information.





• Press the "Where To?" button on the touchscreen, then press the "Go Home" button on the touchscreen.







- You may enter your address directly, use your current location as your home address, or choose from recently found locations.
- To delete your Home location (or other saved locations) so you can save a new Home location, press the "Where To?" button on the touchscreen from the Main Navigation menu, then press the "Go Home" button on the touchscreen, and in the Yes screen press the "Options" button on the touchscreen. In the Options menu press the "Clear Home" button on the touchscreen. Set a new Home location by following the previous instructions.

Go Home

 A Home location must be saved in the system. From the Main Navigation menu, press the "Where To?" button on the touchscreen, then press the "Go Home" button on the touchscreen.



Uconnect 3C NAV Map

- 1 Distance To Next Turn
- 2 Next Turn Street
- 3 Estimated Time Of Arrival
- 4 Zoom In And Out
- 5 Your Location On The Map
- 6 Navigation Main Menu
- 7 Current Street Location
- 8 Navigation Routing Options

Your route is marked with a blue line on the map. If you depart from the original route, your route is recalculated. A speed limit icon could appear as you travel on major roadways.

Adding A Stop

- To add a stop you must be navigating a route.
- Press the "Menu" button on the touchscreen to return to the Main Navigation menu.
- Press the "Where To?" button on the touchscreen, then search for the extra stop.
 When another location has been selected, you can choose to cancel your previous route, add as the first destination or add as the last destination.
- Press the desired selection and press the "Yes" button on the touchscreen.

Taking A Detour

- To take a detour you must be navigating a route.
- Press the "Detour" button on the touchscreen.

NOTE:

If the route you are currently taking is the only reasonable option, the device may not calculate a detour. For more information, see your Uconnect Owner's Manual Supplement.

UCONNECT PHONE

Operation



Uconnect 3 Phone Menu

- 1 Call/Redial/Hold
- 2 Mobile Phone Signal Strength
- 3 Currently Paired Mobile Phone
- 4 Mobile Phone Battery Life
- 5 Mute Microphone
- 6 Transfer To/From Uconnect System

- 7 Uconnect Phone Settings Menu
- 8 Text Messaging
- 9 Direct Dial Pad
- 10 Recent Call Log
- 11 Browse Phone Book
- 12 End Call

























Uconnect 3C/3C NAV Phone Menu

- 1 Favorite Contacts
- 2 Mobile Phone Battery Life
- 3 Currently Paired Mobile Phone
- 4 Mobile Phone Signal Strength
- 5 Mute Microphone
- 6 Transfer To/From Uconnect System
- 7 Conference Call*
- 8 Uconnect Phone Settings Menu
- 9 Text Messaging** 10 — Direct Dial Pad

- 11 Recent Call Log
- 12 Browse Phone Book Entries
- 13 End Call
- 14 Call/Redial/Hold
- 15 Do Not Disturb
- 16 Reply with Text Message
- * Conference call feature only available on GSM mobile devices
- ** Text messaging feature not available on all mobile phones (requires
- Bluetooth MAP profile)

Uconnect Phone Features

The Uconnect Phone feature enables you to place and receive hands-free mobile phone calls. Drivers can also place mobile phone calls using their voice or by using the buttons on the touchscreen (see Voice Command section).

The hands-free calling feature is made possible through Bluetooth technology — the global standard that enables different electronic devices to connect to each other wirelessly.

If the Uconnect Phone Button \(\sqrt{e} \) exists on vour steering wheel, vou then have the Uconnect Phone features.

NOTE:

- The Uconnect Phone requires a mobile phone equipped with the Bluetooth Hands-Free Profile, Version 1.0 or higher.
- Most mobile phones/devices are compatible with the Uconnect system, however some mobile phones/devices may not be equipped with all of the required features to utilize all of the Uconnect system features.

Uconnect Phone (Bluetooth Hands Free Calling)

The Uconnect Phone feature enables you to place and receive hands-free mobile phone calls. Drivers can also place mobile phone calls using their voice or by using the buttons on the touchscreen (see Voice Command section).

The hands-free calling feature is made possible through Bluetooth technology — the global standard that enables different electronic devices to connect to each other wirelessly.

If the Uconnect Phone Button \(\sigma \) exists on your steering wheel, you then have the Uconnect Phone features.

NOTE:

- The Uconnect Phone requires a mobile phone equipped with the Bluetooth Hands-Free Profile, Version 1.0 or higher.
- Most mobile phones/devices are compatible with the Uconnect system, however some mobile phones/devices may not be equipped with all of the required features to utilize all of the Uconnect system features.

Pairing (Wirelessly Connecting) Your Mobile Phone To The Uconnect System



Mobile phone pairing is the process of establishing a wireless connection between a cel-Jular phone and the Uconnect system.




NOTE:



• To use the Uconnect Phone feature, you first must determine if your mobile phone and software are compatible with the Uconnect system. Please visit UconnectPhone.com for complete mobile phone compatibility information.







• A maximum of ten mobile phones can be paired to the Uconnect system.



NOTE:



Keep in mind that software updates – either on your phone or Uconnect system – may interfere with the Bluetooth connection. If this happens, simply repeat the pairing process. However, first, make sure to delete the device from the list of phones on your Uconnect system, Next. be sure to remove Uconnect from the list of devices in your phone's Bluetooth settings.







Start Pairing Procedure On The Radio Uconnect 3:



Uconnect 3

- 1. Place the ignition in the ACC or ON position.
- 2. Press the "Phone" button.
- 3. Select "Settings."
- 4. Select "Paired Phones."
- 5. Select "Add device."
 - Uconnect Phone will display an "In progress" screen while the system is connecting.

Uconnect 3C, 3C NAV:



Uconnect 3C & 3C NAV

- 1. Place the ignition in the ACC or ON position.
- 2. Press the "Phone" button in the Menu Bar on the touchscreen.
- 3. Select "Settings."
- 4. Select "Paired Phones."
- 5. Select "Add device."
 - Uconnect Phone will display an "In progress" screen while the system is connecting.

Pair Your iPhone



Bluetooth On/Uconnect Device

To search for available devices on your Bluetooth enabled iPhone:

- 1. Press the Settings button.
- 2. Select Bluetooth.
 - Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.

3. When your mobile phone finds the Uconnect system, select "Uconnect".

Complete The iPhone Pairing Procedure



Pairing Request

 When prompted on the mobile phone, accept the connection request from Uconnect Phone.

NOTE:

Some mobile phones will require you to enter the PIN number.

Select The iPhone's Priority Level

When the pairing process has successfully completed, the system will prompt you to choose whether or not this is your favorite mobile phone. Selecting "Yes" will make this mobile phone the highest priority. This mobile phone will take precedence over other paired mobile phones within range and will connect to the Uconnect system automatically when entering the vehicle. Only one mobile phone and/or one Bluetooth audio device can be connected to the Uconnect system at a time. If "No" is selected, simply select "Uconnect" from the mobile phone/ audio device Bluetooth screen, and the Uconnect system will reconnect to the Bluetooth device.

Pair Your Android Device



Uconnect Device

To search for available devices on your Bluetooth enabled Android Device:



- 2. Select Settings.
- 3. Select Connections.
- 4. Turn Bluetooth setting to "On."
 - Ensure the Bluetooth feature is enabled. Once enabled, the mobile phone will begin to search for Bluetooth connections.
























- 5. Once your mobile phone finds the Uconnect system, select "Uconnect".
 - You may be prompted by your mobile phone to download the phonebook, check "Do Not Ask Again" to automatically download the phonebook. This is so you can make calls by saying the name of your contact.

Complete The Android Pairing Procedure



Pairing Request

 Confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system then accept the Bluetooth pairing request.

NOTE:

Some mobile phones require the PIN to be entered manually, enter the PIN number shown on the Uconnect screen.

Select The Android Mobile Phone's Priority Level

When the pairing process has successfully completed, the system will prompt you to choose whether or not this is your favorite mobile phone. Selecting "Yes" will make this mobile phone the highest priority. This mobile phone will take precedence over other paired mobile phones within range and will connect to the Uconnect system automatically when entering the vehicle. Only one mobile phone and/or one Bluetooth audio device can be connected to the Uconnect system at a time. If "No" is selected, simply select "Uconnect" from the mobile phone/ audio device Bluetooth screen, and the Uconnect system will reconnect to the Bluetooth device.

You are now ready to make hands-free calls. Press the Uconnect "Phone" button on your steering wheel to begin.

NOTE:

Refer to UconnectPhone.com website for additional information on mobile phone pairing and for a list of compatible phones.

Common Phone Commands (Examples)

- "Call John Smith"
- "Call John Smith mobile"
- "Dial 1 248 555 1212"
- "Redial"

Mute (Or Unmute) Microphone During Call

 During a call, press the "Mute" button on the Phone main screen to mute and unmute the call.

Transfer Ongoing Call Between Handset And Vehicle

 During an on-going call, press the "Transfer" button on the Phone main screen to transfer an on-going call between handset and vehicle.

Phonebook

The Uconnect system will automatically sync your phonebook from your paired phone, if this feature is supported by your phone. Phonebook contacts are updated each time that the phone is connected. If your phone book entries do not appear, check the settings on your phone. Some phones require you to enable this feature manually.

• Your phonebook can be browsed on the Uconnect system touchscreen, but editing can only be done on your phone. To browse. press the "Phone" button on the touchscreen, then the "Phonebook" button on the touchscreen.

Favorite phonebook entries can be saved as Favorites for quicker access. Favorites are shown at the top of the main phone screen.

Voice Command Tips

- Speaking complete names (i.e; Call John Doe vs. Call John) will result in greater system accuracy.
- You can "link" commands together for faster results. Say "Call John Doe, mobile," for example.

• If you are listening to available voice command options, you do not have to listen to the entire list. When you hear the command that you need, push the (%vr button on the steering wheel, wait for the beep and say your command.

Changing The Volume

- Start a dialogue by pushing the Phone button , then say a command for example - "Help".
- Use the radio VOLUME/MUTE rotary knob to adjust the volume to a comfortable level while the Uconnect system is speaking.


NOTE:

The volume setting for Uconnect is different than the audio system.

NOTE:

To access help, push the Uconnect Phone button on the steering wheel and say "help." Push the Uconnect Phone Pickup button or the VR button of and say "cancel" to cancel the help session.

Using Do Not Disturb






Do Not Disturb can automatically reply with a text message, a call or both, when declining an incoming call and send it to voicemail.



Automatic reply messages can be:

- "I am driving right now, I will get back to you shortly."
- Create a custom auto reply message up to 160 characters.









 Only the beginning of your custom message will be seen on the touchscreen.



















- Reply with text message is not compatible with iPhones.
- Auto reply with text message is only available on phones that support Bluetooth MAP.

Incoming Text Messages

After pairing your Uconnect system with a Bluetooth enabled mobile device with the Message Access Profile (MAP), the Uconnect system can announce a new incoming text message and read it to you over the vehicle's audio system.

NOTE:

Only incoming text messages received during the current ignition cycle can be viewed/read.

NOTE:

All incoming text messages received during the current ignition cycle will be deleted from the Uconnect system when the ignition is turned to the Off position.

To enable incoming text messaging:

iPhone

- 1. Press the settings button on the mobile phone.
- 2. Select Bluetooth.
 - Ensure Bluetooth is enabled, and the mobile phone is paired to the Uconnect system.
- 3. Select (i) located under DEVICES next to Uconnect.
- 4. Turn "Show Notifications" to On.



Enable iPhone Incoming Text Messages

Android Devices

- 1. Push the Menu button on the mobile phone.
- 2. Select Settings.
- Select Connections.
- 4. Turn "Show Notifications" to On.
 - A pop up will appear asking you to accept a request for permission to connect to your messages. Select "Don't ask again" and press OK.



Enable Android Device Incoming Text Messages

Voice Text Reply (Not Compatible With iPhone)




NOTE:

Voice texting reply and voice texting features require a compatible mobile device enabled with Bluetooth Message Access Profile (MAP). iPhone, and some other smartphones, may not entirely support Bluetooth MAP. Visit UconnectPhone.com for the latest system














Here's How

and device compatibility.

the 18 pre-defined messages.

1. Push the Uconnect Phone button and wait for the beep, then say "reply." Uconnect will give the following prompt: "Please say the message you would like to send."





- Wait for the beep and say one of the pre-defined messages. (If you are not sure, you can say "help"). Uconnect will then read the pre-defined messages allowed.
- 3. As soon as you hear the message you would like to send, you can interrupt the list of prompts by pushing the Uconnect phone button and saying the phrase. Uconnect will confirm the message by reading it back to you.
- 4. Push the Phone button and say "Send."

PRE-DEFINED VOICE TEXT REPLY RESPONSES				
Yes.	Stuck in traffic.	See you later.		
No.	Start without me.	I'll be late.		
Okay.	Where are you?	I will be <5, 10,		
Call me.	Are you there yet?	15,etc.> minutes late.		
l'll call you later.	I need directions.	See you in <5, 10,		
I'm on my way.	Can't talk right now.	15,etc.> of minutes.		
I'm lost.		Thanks.		

NOTE:

To make the SMS voice reading function available, the SMS notification option on phone must be enabled; this option is usually available on the phone, in the Bluetooth connections menu for a device registered as Uconnect. After enabling this function on the mobile phone, it must be disconnected and reconnected with the Uconnect system in order to make it effective.

Helpful Tips And Common Questions To Improve Bluetooth Performance With Your Uconnect System

Mobile Phone won't reconnect to system after pairing:

- Set mobile phone to auto-connect or trusted device in mobile phone Bluetooth settings (Blackberry devices).
- Perform a factory reset on your mobile phone. Refer to your mobile phone manufacturer or cellular provider for instructions.

 Many mobile phones do not automatically reconnect after being restarted (hard reboot). Your mobile phone can still be connected manually. Close all applications that may be operating (refer to mobile phone manufacturer's instructions), and follow "Pairing (Wirelessly Connecting) Your Mobile Phone To The Uconnect System".

Mobile Phone won't pair to system:

- Perform a hard reset in the mobile phone by removing the battery (if removable — see your mobile phone's owner manual).
- Delete pairing history in mobile phone and Uconnect system; usually found in phone's Bluetooth connection settings.
- Verify you are selecting "Uconnect" in the discovered Bluetooth devices on your mobile phone.
- If your vehicle system generates a pin code the default is 0000.

Mobile Phonebook didn't download:

 Check "Do not ask again," then accept the "phonebook download" request on your mobile phone.

- Up to 5,000 contact names with four numbers per contact will transfer to the Uconnect 3C/3C NAV system phonebook.
- Up to 2,000 contact names with six numbers per contact will transfer to the Uconnect 3 system phonebook.

Text messaging won't work:

- Check "Do not ask again," then accept the "connect to your messages" request on your mobile phone.
- Verify that your mobile phone has the Bluetooth feature (Message Access Profile).

Can't make a conference call:

 CDMA (Code-Division Multiple Access) carriers do not support conference calling. Refer to your mobile phone user's manual for further information.

Making calls while connected to AUX:

 Plugging in your mobile phone to AUX while connected to Bluetooth will disable Hands-Free Calling. Do not make calls while your mobile phone is plugged into the AUX jack.

UCONNECT VOICE RECOGNITION QUICK TIPS

Introducing Uconnect

Start using Uconnect Voice Recognition with these helpful quick tips. It provides the key Voice Commands and tips you need to know to control your Uconnect 3 or 3C/3C NAV system.

Uconnect 3



Uconnect 3

Uconnect 3C/3C NAV



Uconnect 3C NAV

WARNING!

ALWAYS drive safely with your hands on the wheel. You have full responsibility and assume all risks related to the use of the Uconnect features and applications in this vehicle. Only use Uconnect when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.























Get Started

- Visit UconnectPhone.com to check device and feature compatibility and to find device pairing instructions.
- Reduce background noise. Wind and passenger conversations are examples of noise that may impact recognition.
- 3. Speak clearly at a normal pace and volume while facing straight ahead.
- Each time you give a Voice Command, you
 must first push either the VR or Phone
 button, wait until after the beep, then say
 your Voice Command.
- You can interrupt the help message or system prompts by pushing the VR or Phone button and saying a Voice Command from current category.

All you need to control your Uconnect system with your voice are the buttons on your steering wheel.



Uconnect VR And Phone Buttons

- Uconnect Phone Button , Push to initiate, answer, or end a phone call, send or receive a text.
- 2. Uconnect Voice Recognition Button ($\sqrt[6]{2}$ vR .
 - a. Short Press: Push and release the VR button to begin Radio, Climate, Navigation, and other embedded functions. After you hear the single beep, say a command.

- b. Long Press: Push and hold continuously for a few milliseconds, then release the VR button for Siri functions. After you hear the familiar Siri "double beep," say a command.
- 3. Phone Hang Up Button.


Basic Voice Commands

The basic Voice Commands below can be given at any point while using your Uconnect system.

Push the VR button (% VR. After the beep, say:

- "Cancel to stop a current voice session"
- "Help to hear a list of suggested Voice Commands"
- "Repeat to listen to the system prompts again"

Notice the visual cues that inform you of your voice recognition system's status. Cues appear on the touchscreen.



Uconnect 3 Visual Cues



Uconnect 3C/3C NAV

Radio

Use your voice to quickly get to the AM, or FM stations you would like to hear.

Push the VR button (YVR. After the beep, say:

• "Tune to ninety-five-point-five FM"

TIP: At any time, if you are not sure of what to say or want to learn a Voice Command, push the VR button (%vR and say "Help." The system providesyou with a list of commands.




Uconnect 3 Radio




Uconnect 3C/3C NAV Radio

Media

Uconnect offers connections via USB. SD. Bluetooth and auxiliary ports (If Equipped). Voice operation is only available for connected USB and iPod devices. (Remote CD player optional and not available on all vehicles.)







• "Change source to USB"
























"Play artist Beethoven" "Play album Greatest Hits" "Play song Moonlight Sonata" "Play genre Classical"

TIP: Press the Browse button on the touch-screen to see all of the music on your iPod or USB device. Your Voice Command must match **exactly** how the artist, album, song and genre information is displayed.



Uconnect 3 Media



Uconnect 3C/3C NAV Media

Phone

Making and answering hands-free phone calls is easy with Uconnect. When the Phonebook button is illuminated on your touch-screen, your system is ready.

Push the Phone button 📞 . After the beep, say one of the following commands:

- "Call John Smith"
- "Dial 123-456-7890 and follow the system prompts"

- "Redial (call previous outgoing phone number)"
- "Call back (call previous incoming phone number)"

TIP: When providing a Voice Command, push the Phone button and say "Call," Then pronounce the name exactly as it appears in your phone book. When a contact has multiple phone numbers, you can say "Call John Smith work."



Uconnect 3 Phone



Uconnect 3C/3C NAV Phone

Voice Text Reply

Uconnect announces **incoming** text messages. Push the Phone button and say **Listen**. (Must have compatible device paired to Uconnect system.)

- Once an incoming text message is read to you, push the Phone button . After the beep, say: **Reply**.
- Listen to the Uconnect prompts. After the beep, repeat one of the pre-defined messages and follow the system prompts.

PRE-DEFINED VOICE TEXT REPLY RESPONSES			
Yes.	Stuck in traffic.	See you later.	
No.	Start without me.	I'll be late.	
Okay.	Where are you?	I will be <number> minutes late.</number>	
Call me.	Are you there yet?		
l'll call you later.	I need directions.	See you in	
I'm on my way.	Can't talk right now.	minutes.	
I'm lost.		Thanks.	

TIP:

Your device must have the full implementation of the **Message Access Profile (MAP)** to take advantage of this feature. For details about MAP, visit UconnectPhone.com for U.S. residents. Apple iPhone iOS6 or later supports reading **incoming** text messages only. To enable this feature on your Apple iPhone, follow these four simple steps:





- 1. Select "Settings."
- 2. Select "Bluetooth."
- 3. Select The (i) For The Paired Vehicle.
- 4. Turn On "Show Notifications."

TIP: Voice Text Reply is not compatible with iPhone, but if your vehicle is equipped with Siri Eyes Free, you can use your voice to send a text message.

























Climate (3C/3C NAV)

Too hot? Too cold? Adjust vehicle temperatures hands-free and keep everyone comfortable while you keep moving ahead. (If vehicle is equipped with climate control.)

Push the VR button (\(\frac{1}{2} \text{VR} \). After the beep, say one of the following commands:

- "Set driver temperature to 20 degrees"
- "Set passenger temperature to 20 degrees"

TIP: Voice Command for Climate may only be used to adjust the interior temperature of your vehicle. Voice Command will not work to adjust the heated seats or steering wheel (if equipped).



Uconnect 3C/3C NAV Climate

Navigation (3C/3C NAV)

The Uconnect navigation feature helps you save time and become more productive when you know exactly how to get to where you want to go. (Navigation is optional on the Uconnect 3C system. See your dealer to activate navigation at any time.)

- 1. To enter a destination, push the VR button (\(\frac{1}{2}\nabla R\). After the beep, say:
 - For the 3C Uconnect System, say: "Enter state."
 - For the 3C NAV Uconnect System, say:
 "Find Address 800 Chrysler Drive Auburn Hills, Michigan."
- 2. Then follow the system prompts.

TIP: To start a Point Of Interest (POI) search, push the VR button ("¿VR. After the beep, say "Find nearest coffee shop."



Uconnect 3C/3C NAV Navigation

Siri Eyes Free — If Equipped

Siri lets you use your voice to send text messages, select media, place phone calls and much more. Siri uses your natural language to understand what you mean and will respond back to confirm your requests. The system is designed to keep your eyes on the road and your hands on the wheel by letting Siri help you perform useful tasks.

To enable Siri push and hold, then release the Uconnect Voice Recognition (VR) button on the steering wheel. After you hear a double beep you can ask Siri to play podcasts and music, get directions, read text messages and many other useful requests.



Siri Eyes Free Available

Getting Started

Ensure Siri is enabled on your iPhone.



Enable Siri

1 — Select	2 — Select
Settings On	General
Your iPhone	3 — Select Siri
	4 — Enable Siri

Pair your Siri enabled device to the vehicles sound system. Refer to "Uconnect Phone" in "Multimedia" for a detailed pairing procedure.





VR/Siri Button

2. Push and Hold, then release the Uconnect Voice Recognition (VR) button (LEVR on the steering wheel. After you hear the familiar Siri "double beep," say a command.























NOTE:

A push and release of the (% vR button will start normal embedded VR functions. The push and hold, then release of the (% vR button will start Siri functions.

3. After the double beep, begin speaking to Siri.

Examples of Siri commands and questions:

- "Play Rolling Stones"
- "Send text message to John"
- "Read text message from Sarah"
- "Take me to the nearest coffee shop"

NOTE:

- Speak clearly at a normal pace and volume while facing straight ahead to ensure your command is understood.
- Siri is available on iPhone 4S and later.



Siri Eyes Free

Do Not Disturb

With Do Not Disturb, you can disable notifications from incoming calls and texts, allowing you to keep your eyes on the road and hands on the wheel. For your convenience, there is a counter display to keep track of your missed calls and text messages while you were using Do Not Disturb.

Do Not Disturb can automatically reply with a text message, a call or both, when declining an incoming call and send it to voicemail.

Automatic reply messages can be:

• "I am driving right now, I will get back to you shortly."

 Create a custom auto reply message up to 160 characters.

NOTE:

Only the first 25 characters can be seen on the touchscreen while typing a custom message.

While in Do Not Disturb, Conference Call can be selected so you can still place a second call without being interrupted by incoming calls.

NOTE:

- Reply with text message is not compatible with iPhones.
- Auto reply with text message is only available on phones that support Bluetooth MAP.

Additional Information

© 2018 FCA US LLC. All rights reserved. Mopar and Uconnect are registered trademarks and Mopar Owner Connect is a trademark of FCA US LLC. Android is a trademark of Google Inc.

CUSTOMER ASSISTANCE



IF YOU NEED ASSISTANCE 280	FINLAND	PORTUGAL
ARGENTINA	FRANCE	PUERTO RICO AND U.S. VIRGIN
AUSTRALIA	GERMANY	ISLANDS
AUSTRIA	GREECE	REUNION
BALANCE OF THE CARIBBEAN	GUATEMALA	ROMANIA
BELGIUM	HONDURAS	RUSSIA
BOLIVIA	HUNGARY	SERBIA
BRAZIL	INDIA	SLOVAKIA
BULGARIA	IRELAND	SLOVENIA
CHILE	ITALY	SOUTH AFRICA
CHINA	LATVIA	SPAIN
COLOMBIA	LITHUANIA	SWEDEN
COSTA RICA	LUXEMBURG	SWITZERLAND
CROATIA	NETHERLANDS	TAIWAN
CZECH REPUBLIC	NEW ZEALAND	TURKEY
DENMARK	NORWAY	UKRAINE
DOMINICAN REPUBLIC	PANAMA	UNITED KINGDOM
ECUADOR	PARAGUAY	URUGUAY
EL SALVADOR	PERU	VENEZUELA
ESTONIA	POLAND	VEIVEZOLE/(





















IF YOU NEED ASSISTANCE

The manufacturer distributors are vitally interested in your satisfaction with their products and services. If a servicing problem or other difficulty should occur, we recommend that you take the following steps:

Discuss the problem at the authorized dealer with the dealer principal or the service manager. Management personnel at the authorized dealer are in the best position to resolve the problem.

When you contact the distributor please provide all of the following information:

- Your name, address and phone number.
- Vehicle Identification Number (this 17 digit number is found on a label, located on the left front corner of the instrument panel, visible through the windshield. It is also available from your vehicle registration or title).
- Selling and servicing authorized dealer.
- Vehicle's delivery date and current odometer distance.
- Service history of your vehicle.
- An accurate description of the problem and the conditions under which it occurs.

ARGENTINA

Chrysler Argentina S.A

Boulevard Azucena Villaflor 435

C1107CII

Buenos Aires, Argentina

Tel: +54-11-4891 7900

Fax: +54-11-4891 7901

AUSTRALIA

FCA Australia Pty. Ltd.

ABN 23 125 956 505

PO Box 23267. Docklands Victoria 3008

Ph. 1300 133 079

AUSTRIA

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 00 800 0 426 5337
- Local Toll Free NumberTel: 0800 20 1741
- International Toll NumberTel: + 39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 00 800 1692 1692
- Local Toll Free NumberTel: 0800 201745
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 0800 201747
- International Toll Number
 Tel: Not Available

BALANCE OF THE CARIBBEAN

Interamericana Trading Corporation

Warrens, St. Michael

Barbados, West Indies

BB22026, PO Box 98

Tel.: 246-417-8000

Fax: 246-425-2888























^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

BELGIUM

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- Local Toll Free NumberTel: 0800 55 888
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- Local Toll Free NumberTel: 0800 18 142
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 0800 16 166
- International Toll Number
 Tel: Not Available

BOLIVIA

Ovando & Cia S.A.

Av. Cristobal de Mendoza (2do Anillo) y Canal Isuto

Santa Cruz, Bolivia

PO Box 6852

Tel.: (591-3) 336 3100

Fax: (591-3) 334 0229

BRAZIL

Chrysler do Brasil

Rua Funchal, 418 - 16° andar CJ 1601/1602, Vila Olímpia

04551-060 Sao Paulo - S.P., Brazil

Tel: +5511 4949 3900

Fax: +5511 4949 3905

BULGARIA

BALKAN STAR

Resbarska Str. 5

1510 Sofia

Tel.: +359 2 4082 800

Fax: +359 2 846 8481

CHILE

Comercial Chrysler S.A.

Av. Americo Vespucio 1601, Quilicura

Santiago, Chile

Zip Code 101931-7, 367-V

Tel.: +562 837 1300

Fax: +562 6039196

^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

CHINA

Chrysler Group (China) Sales Limited

No. 1509, Building# 63, Dongsanhuan Middle Road

Beijing

PR. China

Zip Code: 100022

Tel: 400-650-0118 Ext. 2

COLOMBIA

Chrysler Colombia S.A.

Avenida Calle 26 # 70A-25

Zip Code 110931

Bogotá Colombia

Tel: +57 1 745 5777

Fax: +57 1 410 5667

COSTA RICA

AutoStar

La Uruca, frente al Banco Nacional

San José, Costa Rica

PO Box 705-1150

Tel.: (506) 295 - 0000

Fax: (506) 295 - 0052

CROATIA

Autocommerce Hrvatska d.o.o.

Jablanska 80

10 000 Zagreb

Tel: 00 385 1 3869 001

Fax: 00 385 1 3869 069

CZECH REPUBLIC

Jeep Customer Service*

Universal Toll Free Number
 Tel: 800 200 233

International Toll NumberTel: +420 800 200 233

Chrysler Customer Service*

Universal Toll Free Number
 Tel: 800 200 233

International Toll NumberTel: +420 800 200 233

Dodge Customer Service*

Universal Toll Free NumberTel: 800 200 233

International Toll NumberTel: +420 800 200 233























^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

DENMARK

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- Local Toll Free Number

Tel: 80 20 5337

International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- Local Toll Free NumberTel: 80 20 30 35
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 80 20 30 36
- International Toll Number

Tel: Not Available

DOMINICAN REPUBLIC

Reid y Compañia

John F. Kennedy Casi Esq. Lope de Vega

Santo Domingo, Dominican Republic

Tel.: (809) 562-7211

Fax: (809) 565-8774

ECUADOR

Chrysler Jeep Automotriz del Ecuador

Av. Juan Tanca Marengo km. 4.5

Guayaquil, Ecuador

Tel.: +593 4 2244101

Fax: +593 4 2244273

EL SALVADOR

Grupo Q del Salvador

Ave. Las Amapolas (Autopista Sur)

Blvd. Los Próceres y Avenida No. 1, Lomas de San Francisco,

San Salvador, El Salvador

Zip Code 152

Tel.: +503 2248 6400

Fax: +503 278 5731

ESTONIA

Silberauto AS

Järvevana tee 11

11314 Tallinn

Tel.: +372 53337946

Tel.: 06 266 072

Fax: 06 266 066

service@silberauto.ee

^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

FINLAND

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- International Toll NumberTel: +39 02 444 12 045

FRANCE

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- Local Toll Free NumberTel: 0800 0 42653
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- Local Toll Free NumberTel: 0800 169216
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 0800 363430
- International Toll Number
 Tel: Not Available

GERMANY

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- Local Toll Free NumberTel: 0800 0426533
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number Tel: 00 800 1692 1692
- Local Toll Free NumberTel: 0800 1692 169
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 0800 3634 300
- International Toll Number
 Tel: Not Available

GREECE

Chrysler Jeep Dodge Hellas

240-242 Kifisias Avenue

15231 Halandri Athens, Greece

Tel.: +30 210 6700800

Fax: +30 210 6700820

GUATEMALA

Grupo Q del Guatemala

Km 16 carretera a El Salvador, condado concepción

Ciudad de Guatemala, Guatemala

Zip Code 1004

Tel.: +502 6685 9500























^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

HONDURAS

Grupo Q de Honduras

Blvd.. Centro América frente a Plaza Miraflores.

Tegucigalpa, Honduras

Tel.: +504 2290 3700

Fax: +504 2232 6564

HUNGARY

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 80 10 10 80
- International Toll NumberTel: +36 80 10 10 80

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 82 10 10 80
- International Toll NumberTel: +36 80 10 10 80

Dodge Customer Service*

- Universal Toll Free Number
- Tel: 81 10 10 80
- International Toll NumberTel: +36 80 10 10 80

INDIA

FCA India Automobile Private Limited

Benefice Building, 2nd Floor, Mathuradas Mill Compound,

Opposite Kamala Mill, Lower Parel West,

Mumbai 400013, India

Tel - +912239462600

Customer Care - 18002665337

^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

IRELAND

Jeep Customer Service*

- Universal Toll Free Number Tel: 00 800 0 426 5337
- Local Toll Free Number Tel: 1800 505337
- International Toll Number Tel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number Tel: 00 800 1692 1692
- Local Toll Free Number Tel: 1800 363463
- International Toll Number Tel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free Number Tel: 00 800 36343 000
- Local Toll Free Number Tel: 1800 363430
- International Toll Number Tel: Not Available

ITALY

Jeep Customer Service*

- Universal Toll Free Number Tel: 00 800 0 426 5337
- Local Toll Free Number Tel: 800 0 42653
- International Toll Number Tel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number Tel: 00 800 1692 1692
- Local Toll Free Number Tel: 800 1692 16
- International Toll Number Tel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free Number Tel: 00 800 36343 000
- Local Toll Free Number Tel: 800 363430
- International Toll Number Tel: Not Available

LATVIA

TC MOTORS LTD.

41 Krasta Str.

LV-1003 Riga

Tel.: +37167812 313

Mob.: +371 29498662

Fax: +371 67812313

SIA "Autobrava"

G.Astras street 5.

LV-1084 Riga

Tel.: +371 67812312

Moh · +371 29498662

Fax +371 671 462 56





















^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

LITHUANIA

Silberauto AS

Pirkliu g. 9

LT-02300 Vilnius

Tel +370 52 665956, GSM +370 698 24950

Fax +370 52 665951

service24h@silberauto.lt

LUXEMBURG

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 00 800 0 426 5337
- Local Toll Free NumberTel: 8002 5888
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- Local Toll Free NumberTel: 8002 8216
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free Number
 - Tel: 8002 8217
- International Toll Number
 Tel: Not Available

NETHERLANDS

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- International Toll Number
 Tel: Not Available

(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

NEW ZEALAND

Chrysler New Zealand

Private Bag 14907

Panmure New Zealand

Tel: 09573 7800

Fax: 09573 7808

NORWAY

Jeep Customer Service*

Universal Toll Free NumberTel: 00 800 0 426 5337

International Toll NumberTel: +39 02 444 12 045

PANAMA

Automotora Autostar S. A.

Avenida Domingo Diaz, Via Tocumen, Frente a la Urbanizacion El Crisol

Panamá, Panamá

Tel.: +507 233 7222

Fax: +507 233 2843

PARAGUAY

Garden Autolider S.A

Av. República de Argentina esq. Facundo

Machain

Asuncion, Paraguay

Tel.: +595 21 664 580

Fax: +595 21 664 579

PERU

Divemotor S.A.

Av. Canada 1160, Urb. Sta. Catalina

Lima, Peru

Zip Code Lima 13

Tel.: (51-1) 712 2000

Fax: (51-1) 712 2002























^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

POLAND

FCA Poland

UI. M.Grażyńskiego 141.

43-300 Bielsko-Biała

Tel: +48 (033) 813-21-00, 813-51-00

Jeep Customer Service*

Universal Toll Free NumberTel: 00 800 0 426 5337

Local Toll Free NumberTel: 800 533700

International Toll NumberTel: +39 02 444 12 045

• (Polish language - select code 23)

Chrysler Customer Service*

Universal Toll Free NumberTel: 00 800 0 426 5337

International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

Universal Toll Free Number
 Tel: 00 800 3 634 3000

International Toll Number
 Not Available

PORTUGAL

Fiat Chrysler Automobiles Portugal, S.A.

Mopar - Dept. Customer Care

Lagoas Park, Edificio 15, Piso 2

2740-262 Porto Salvo (Oeiras)

Universal Toll Free Number

Tel: 00 800 0 426 5337

International Toll Number

Tel: +39 02 444 12 045

PUERTO RICO AND U.S. VIRGIN ISLANDS

FCA Caribbean LLC

P.O. Box 191857

San Juan 009191857

Tel.: 8882426342

Fax: 7877823345

REUNION

COTRANS AUTOMOBILES

17 Bd du Chaudron, 97490 Sainte Clotilde

Tel: 0262920000

Fax: 0262488443

ROMANIA

AUTO ITALIA IMPEX SRL

Bd. Timisoara nr. 60/D

Bucuresti, ROMANIA

Tel: +40 (0)21.444.333.4

Fax: +40 (0)21.444.2779

www.autoitalia.ro

(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

290

RUSSIA

Jeep Customer Service*

- Universal Toll Free NumberTel: 88 001 00 8182
- International Toll NumberTel: +495 212 21 38

Chrysler Customer Service*

- Universal Toll Free NumberTel: 88 001 00 8182
- International Toll NumberTel: +495 212 21 38

Dodge Customer Service*

- Universal Toll Free NumberTel: 88 001 00 8182
- International Toll NumberTel: +495 212 21 38

SERBIA

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 0800 120120
- International Toll NumberTel: +381 34 356712

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 0800 363636
- International Toll NumberTel: +381 34 356713

SLOVAKIA

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 800 900 001
- International Toll NumberTel: +421 800 900 001

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 802 900 001
- International Toll NumberTel: +421 800 900 001

Dodge Customer Service*

- Universal Toll Free Number
 Tel: 801 900 001
- International Toll NumberTel: +421 800 900 001























SLOVENIA

Avto Triglav d.o.o.

Dunajska 122

1000 Ljubljana

Tel: 01 5883 400

Fax: 01 5883 487

SOUTH AFRICA

Jeep Customer Service*

- Universal Toll Free NumberTel: 8066727869
- International Toll NumberTel: +27102525000

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 8066727869
- International Toll NumberTel: +27102525000

Dodge Customer Service*

- Universal Toll Free NumberTel: 8066727869
- International Toll Number
 Tel: Not Available

SPAIN

Jeep Customer Service*

- Universal Toll Free NumberTel: 00 800 0 426 5337
- Local Toll Free NumberTel: 900 10 5337
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free NumberTel: 00 800 1692 1692
- Local Toll Free NumberTel: 900 1692 00
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free NumberTel: 900 363430
- International Toll Number
 Tel: Not Available

^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

SWEDEN

Jeep Customer Service*

- Universal Toll Free Number Tel: 00 800 0 426 5337
- Local Toll Free Number Tel: 020 5337 00
- International Toll Number Tel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number Tel: 00 800 1692 1692
- Local Toll Free Number Tel: 020 303035
- International Toll Number Tel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free Number Tel: 00 800 36343 000
- Local Toll Free Number Tel: 020 303036
- International Toll Number Tel: Not Available

SWITZERLAND

Jeep Customer Service*

- Universal Toll Free Number Tel: 00 800 0 426 5337
- Local Toll Free Number Tel: 0800 0426 53
- International Toll Number Tel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number Tel: 00 800 1692 1692
- Local Toll Free Number Tel: 0800 1692 16
- International Toll Number Tel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free Number Tel: 00 800 36343 000
- Local Toll Free Number Tel: 0800 3634 30
- International Toll Number Tel: Not Available

TAIWAN

Chrysler Taiwan Co., LTD.

13th Floor Union Enterprise Plaza

1109 Min Sheng East Road, Section 3

Taipei Taiwan R.O.C.

Tel.: 080081581

Fax: 886225471871

TURKEY

Tofas Türk Otomobil Fabrikasi A.S.

Büyükdere Cad, No:145 Tofaş Han

Zincirlikuyu

ISTAMBUL

Tel: (0212) 444 5337

Tel: (0212) 275 2960

Telefax: (0212) 275 0357


























UKRAINE

PJSC "AUTOCAPITAL"

Chervonoarmiyska Str. 15/2

01004 Kyiv

Tel: +380 44 206 8888

+380 44 201 6060

Fax: +380 44 206 8889

UNITED KINGDOM

Jeep Customer Service*

- Universal Toll Free Number
 Tel: 00 800 0 426 5337
- Local Toll Free NumberTel: 0800 1692966
- International Toll NumberTel: +39 02 444 12 045

Chrysler Customer Service*

- Universal Toll Free Number
 Tel: 00 800 1692 1692
- Local Toll Free NumberTel: 0800 1692169
- International Toll NumberTel: +39 02 444 12046

Dodge Customer Service*

- Universal Toll Free NumberTel: 00 800 36343 000
- Local Toll Free Number
- Tel: 0800 1692956

 International Toll Number
 - Tel: Not Available

URUGUAY

SEVEL Uruguay S. A.

Convenio 820

Montevideo, Uruguay

Zip Code 11700

Tel: +598 220 02980

Fax: +598 2209-0116

^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

VENEZUELA

FCA Venezuela LLC

Avenida Pancho Pepe Croquer. Zona

Industrial Norte

Valencia, Estado Caraboro

Tel: +(58) 241-613 2400

Fax: +(58) 241-613 2538

Fax: (58) 241-6132602

(58) 241-6132438

PO BOX: 1960

Services And Parts

Zona Industrial II, Av. Norte-Sur 5 C/C Calle

Este-Oeste

C.C LD Center Local B-2

Valencia, Estado Carabobo

Telf: (58) 241-6132757

(58) 241-6132773

Fax: (58) 241-6132743























^(*) The Customer Service offers information and assistance on products, services, dealerships and 24H Roadside Assistance. It can be contacted from the main European countries by calling the Universal Toll Free Number. In case of problems, please use the Local Toll Free Number or the International Toll Number.

		CH	ANGE	OF	OW	NER	SHI	P N	ОТІІ	FICA	TIO	N			
MODEL REGISTRATION OR LICENSE NUMBER															_
	VIN L														
NEW OWNER'S NAME															
NEW OWNER'S ADDRESS	S														
TELEPHONE NO.														DEALERS X ABOVE	

FIRST OWNER

80f40712

		CI	HAN	GE	OF	ow	NEF	RSHI	PΝ	ОТІ	FICA	TIO	N					
MODEL _ REGISTRATION OR LICENSE NUMBER _																		_
	VIN L																	
NEW OWNER'S NAM	E																	
NEW OWNER'S ADDRES	s																	
																	DEALERS	
TELEPHONE N	D											E	:NTER I	DEALER	STAM	IN BO	X ABOVE	























80f40753

INDEX

Accessories	Air Pressure	Fluid Type
Mopar	Tires	Auto Up Power Windows
Adaptive Cruise Control (ACC)	Alarm	
Off143, 145	Arm The System	Back-Up
On	Disarm The System	Back-Up Camera
Adaptive Cruise Control (ACC) (Cruise	Security Alarm	Battery
Control)	Alarm (Security Alarm)	Charging System Light
Additives, Fuel	Alarm System (Security Alarm) 18	Belts, Seat
Air Bag	All Wheel Drive (AWD)	Blind Spot Monitoring
Air Bag Operation	Alterations/Modifications	Brake Assist System
Air Bag Warning Light	Vehicle	Brake Control System, Electronic 69
Enhanced Accident Response102	Antifreeze (Engine Coolant)	Brake Fluid
Enhanced Accident Response 193	Anti-Lock Brake System (ABS)	Brake System
Event Data Recorder (EDR) 193	Anti-Lock Warning Light	Fluid Check
Front Air Bag	Arming System (Security Alarm) 18	Master Cylinder
If Deployment Occurs	Assist, Hill Start	Parking
Knee Impact Bolsters98	Audio Jack	Warning Light
Maintaining Your Air Bag System103	Automatic Door Locks	Brake/Transmission Interlock
Maintenance	Automatic Headlights	Bulb Replacement
Redundant Air Bag Warning Light96	Automatic Temperature Control (ATC)42	Bulbs, Light
Transporting Pets	Automatic Transaxle	
Air Bag Light	Automatic Transmission	Camera
Air Conditioning Filter	Adding Fluid	Capacities, Fluid
Air Conditioning, Operating Tips	Fluid Level Check	Caps, Filler
Air Conditioning System	Fluid Level Check	Fuel

























Oil (Engine)	Cruise Light	Emergency, In Case Of Hazard Warning Flasher
Carbon Monoxide Warning	Customer Programmable Features 256	Jacking
Car Washes		Jump Starting
Change Oil Indicator	Daytime Running Lights	Overheating
Changing A Flat Tire	Dealer Service	Towing
Checking Your Vehicle For Safety 116	Defroster, Windshield	Engine
Checks, Safety	Diagnostic System, Onboard	Break-In Recommendations
Child Restraints	Dipsticks	Checking Oil Level
How To Stow An Unused ALR Seat	Oil (Engine)	Cooling
Belt	Disabled Vehicle Towing	Exhaust Gas Caution
Child Safety Locks	Disturb	Jump Starting
Clean Air Gasoline	Do Not Disturb	0il
Cleaning	Door Ajar	Oil Filler Cap
Wheels	Door Ajar Light	Oil Filler Cap
Climate Control	Door Locks, Automatic	Oil Filler Cap 205, 206, 207
Manual		Oil Selection
Clock	Electric Brake Control System	Overheating
Clock Setting	Anti-Lock Brake System	Enhanced Accident Response
Cold Weather Operation	Electronic Roll Mitigation71, 74	Feature
Compact Spare Tire	Electric Parking Brake	Ethanol
Cooling System	Electronic Brake Control System 69	Exhaust Gas Cautions
Coolant Capacity	Electronic Speed Control (Cruise	Exhaust System
Inspection	Control)	Exterior Lights
Selection Of Coolant	Electronic Stability Control (ESC)71	
(Antifreeze)	Electronic Throttle Control Warning	
Cruise Control (Speed Control)	Light	
300		

Filters Air Conditioning	Light	Hood Release	
Engine Oil	Octane Rating	Instrument Cluster	
Flashers	Specifications	Instrument Cluster	7
Hazard Warning	Tank Capacity	Instrument Panel Lens Cleaning	
Turn Signal	Fuses	Interior Appearance Care	-6-
Turn Signals		Intermittent Wipers (Delay Wipers)33	
Fluid, Brake	Gas Cap (Fuel Filler Cap)	Introduction	
Fluid Capacities	Gasoline, Clean Air	Inverter, Power	
Fluid Leaks	Gasoline (Fuel)	iPod/USB/MP3 Control	
Fluid Level Checks	Gear Ranges	Bluetooth Streaming Audio	10
Brake	Gear Select Lever Override		
Engine Oil	Glass Cleaning	Jacking Instructions	
Fluids And Lubricants		Jack Location	// '
Fog Lights	Hands-Free Phone (Uconnect)	Jack Operation	
Fog Light Service	Hazard Warning Flasher	Jump Starting	- Y
Fog Lights, Rear	Headlights		
Forward Collision Warning	Automatic	Key Fob	1 1
Four Wheel Drive	Delay	Arm The Alarm18	
Freeing A Stuck Vehicle	Time Delay	Disarm The Alarm	
Front And Rear ParkSense System 149	Head Restraints	Keyless Enter-N-Go	
Front ParkSense System	Head Rests	Key, Replacement	(0)
Fuel	Heated Mirrors	Keys	
Additives	Hill Descent Control		
Ethanol	Hill Descent Control Indicator	Lane Change And Turn Signals	
Filler Cap (Gas Cap)	Hill Start Assist	Lane Change Assist	ZOSE
Gasoline		LaneSense	B C T D
		301	

























Lap/Shoulder Belts	Rear Fog	Memory Feature (Memory Seat)
Latches	Seat Belt Reminder	Memory Seat
Hood	Security Alarm	Memory Seats And Radio
Leaks, Fluid	Service	Methanol
Life Of Tires	Tire Pressure Monitoring (TPMS) 60	Methanol Fuel
Liftgate	Tire Pressure Monitoring (TPMS)82	Mirrors
Liftgate Window Wiper/Washer	Traction Control	Heated
Light Bulbs118	Turn Signal	Modifications/Alterations
Lights	Turn Signals	Vehicle
9	Warning (Instrument Cluster	Monitor, Tire Pressure System
Air Bag		
Air Bag	Description)	Mopar
Brake Assist Warning	Locks	Mopar Accessories
Brake Warning	Automatic Door	N : .:
Bulb Replacement	Child Protection	Navigation
Cruise	Steering Wheel	New Vehicle Break-In Period
Daytime Running	Low Tire Pressure System	
Engine Temperature Warning 58	Lug Nuts	Occupant Restraints
Exterior		Octane Rating, Gasoline (Fuel)231, 238
Fog	Maintenance Free Battery	Oil Change Indicator
Hazard Warning Flasher	Maintenance Schedule	Oil Change Indicator, Reset
Headlights	Malfunction Indicator Light (Check	Oil, Engine
Hill Descent Control Indicator	Engine)	Capacity
Low Fuel	Manual Transmission	Checking
Malfunction Indicator	Fluid Level Check	Dipstick
(Check Engine)	Lubricant Selection	Filter
Park	Shift Speeds126	Pressure Warning Light 57
Park	Media Hub	Recommendation237

Viscosity	Preparation For Jacking	Roll Over Warning
Oil Pressure Light	Pretensioners	Rotation, Tires
Onboard Diagnostic System	Seat Belts	
Operating Precautions		Safety Checks Inside Vehicle
Operator Manual	Radial Ply Tires	Safety Checks Outside Vehicle
Owner's Manual	Radio	Safety, Exhaust Gas
Outlet	Presets	Safety Tips
Power	Radio Operation	Schedule, Maintenance
Overheating, Engine	Radio Screens	SD Card Port
Owner's Manual (Operator Manual) 2	Radio (Sound Systems)	Seat Belt
	Rain Sensitive Wiper System	Adjustable Upper Shoulder
Parking Brake	Rear Camera	Belt Anchorage
ParkSense Active Park Assist	Rear Cross Path	Automatic Locking Retractor (ALR)93
ParkSense System, Front And Rear149	Rear ParkSense System147, 149, 154	Energy Management Feature
ParkSense System, Rear 147, 149	Rear Wiper/Washer	Lap/Shoulder Belt Operation
Pets	Recreational Towing	Lap/Shoulder Belts
Phone, Hands-Free (Uconnect)	Release, Hood	Pregnant Women
Phone (Pairing)	Reminder, Seat Belt	Seat Belt Pretensioner
Phone (Uconnect)	Remote Control	Seat Belt Reminder
Power	Starting System	Seat Belt Maintenance
Glass Sunroof	Remote Keyless Entry	Seat Belt Reminder
Inverter	Arm The Alarm	Seat Belts
Outlet (Auxiliary Electrical Outlet)49	Disarm The Alarm	Adjustable Shoulder Belt
Windows	Remote Starting System	Adjustable Upper Shoulder
Power Shade	Replacement Keys	Anchorage
Open	Replacement Tires	Front Seat
Pregnant Women And Seat Belts 93	Restraint, Head	Front Seat























Inspection .117 Lap/Shoulder Belt Untwisting .92 Operating Instructions .91 Pregnant Women .93 Pretensioners .93 Rear Seat .89 Reminder .56 Untwisting Procedure .92 Seats .23, 24 Head Restraints .25 Heated .24	Siri .276, 277 Snow Chains (Tire Chains) .223 Snow Tires .221 Sound Systems (Radio) .257, 258 Spare Tire .221 Spare Tires .221, 222 Spark Plugs .238 Specifications .238 Fuel (Gasoline) .238 Oil .238 Speed Control	Steering Wheel Mounted Sound System .246 Controls .246 Storage, Vehicle .43 Stuck, Freeing .189 Sunroof .46 Opening .46 Venting .46 Sun Roof .45 Supplemental Restraint System .96
Memory .23 Vented .25 Ventilated .25	Accel/Decel	Sway Control, Trailer
Security Alarm .18, 57 Arm The System .18 Disarm The System .18	Distance Setting (ACC Only)142, 145 Mode Setting (ACC Only)146 Set	Telescoping Steering Column
Selec-Terrain.135Selection Of Coolant (Antifreeze).238Sentry Key Replacement.15Service Assistance.280Shifting.129Matuomatic Transmission.129Manual Transmission.126Shift Lever Override.189Shoulder Belts.89Signals, Turn.32, 64, 118	Speed Control (Cruise Control) .141 Starting .17, 121 Cold Weather .121 Remote .17 Starting Procedures .121 Steering .11t Column .28 Wheel, Heated .28 Wheel Lock .17 Wheel, Tilt .28	Tilt Steering Column .28 Time Delay, Headlight .31 Tires .118, 216, 221 Aging (Life Of Tires) .219 Air Pressure .216 Chains .223 Changing .173, 216 Compact Spare .221 General Information .216 General Information .221

General Information	Trailer Sway Control (TSC)	Vehicle Security Alarm (Security Alarm)18	
High Speed	Trailer Towing	Vehicle Storage	
Inflation Pressure	Trailer Towing Guide	Ventilated	
Jacking	Trailer Weight	Voice Command	
Life Of Tires	Transaxle	Voice Recognition System	
Pressure Monitoring System (TPMS)60	Automatic	(VR)	-8
Pressure Monitor System (TPMS)82	Operation		
Radial	Transmission	Warning Flasher, Hazard	
Replacement	Automatic	Warning Lights (Instrument Cluster	N/A
Rotation	Automatic	Descriptions)	
Safety	Fluid240	Warning, Roll Over	
Snow Tires	Maintenance	Warnings And Cautions	
Spare Tire	Manual	Washer	
Spare Tires	Transporting Pets	Rear	
Spinning	Tread Wear Indicators	Washers, Windshield	
Tread Wear Indicators	Turn Signals	Washing Vehicle	
Wheel Nut Torque		Wheel And Wheel Tire Care	
Tire Service	Uconnect (Hands-Free Phone)	Wheel And Wheel Tire Trim	
Kit180, 181, 182, 183, 184, 185	Making A Phone Call261, 267	Wind Buffeting	
To Open Hood	Receiving A Call	Window Fogging	
Towing	Uconnect	Windows	
Disabled Vehicle	Phone261, 266, 267, 268, 272	Close	"(G)°
Guide	Uconnect Voice Command 266, 271	Down	
Recreational	Untwisting Procedure, Seat Belt 92	Open44	
Weight	USB Port	Power44	
Towing Behind A Motorhome		Up	7 es E
Traction Control	Vehicle Modifications/Alterations 3	Windshield Defroster	B Q A
		7.05	ICT D

























Windshield	Washers	33, 209
Fluid .		209
Windshield	Wiper Blades	211
Windshield	Wipers	33
Wiper Blade	e Replacement	211
Wiper, Rear		34

_		
-		



Jeep



©2018 FCA US LLC. All Rights Reserved. Jeep is a registered trademark of FCA US LLC.