
Ambient Weather WS-1280 Advanced Weather Station User Manual



Table of Contents

1.	Introduction	2
2.	Getting Started	2
2.1	Parts List	2
2.2	Recommend Tools.....	2
2.3	Remote Thermometer Sensor Set Up.....	2
2.4	Display Console Set Up	3
2.4.1	Radio Controlled Clock (RCC).....	3
2.4.2	Display Console Layout.....	4
2.5	Sensor Operation Verification	4
3.	Remote Sensor Installation	4
4.	Console Operation.....	5
4.1	Time Modes	5
4.1.1	Set Time, Date, Units and Storm Threshold.....	5
4.1.2	Set Alarm Time	7
4.1.3	Turning On and Off the Time Alarm.....	7
4.1.4	Displaying the Date and Alarm Time	7
4.2	Indoor Temperature and Humidity Mode	7
4.2.1	Displaying and Resetting the Indoor Temperature and Humidity Min and Max Values....	7
4.3	Outdoor Temperature Mode	8
4.3.1	Displaying and Resetting the Outdoor Temperature Min and Max Values	8
4.4	Other Console Features	8
4.4.1	Weather Forecasting and Tendency	8
4.4.2	Weather Icons.....	8
4.4.3	Pressure threshold setting.....	9
4.5	Multi-Channel Operation	9
4.5.1	Sensor Initialization	9
4.5.2	Sensor Accuracy Note	9
4.5.3	Viewing the 3 Sensor Channels.....	9
5.	Glossary of Terms	9
6.	Specifications.....	10
6.1	Wireless Specifications	10
6.2	Measurement Specifications	10
6.3	Power Consumption.....	10
7.	Troubleshooting Guide.....	10
8.	Accessories	11
9.	Liability Disclaimer	12
10.	FCC Statement.....	12
11.	Warranty Information	13

1. Introduction

Thank you for your purchase of the Ambient Weather WS-1280 Weather Station with time, indoor temperature and humidity, outdoor temperature, and weather forecasting. The following user guide provides step by step instructions for installation, operation and troubleshooting. To download the latest manual and additional troubleshooting tips, please visit:

<http://ambientweather.wikispaces.com/ws1280>

2. Getting Started

The WS-1280 weather station consists of a display console (receiver), and a wireless thermometer (remote transmitter).

2.1 Parts List

QTY	Item
1	Display Console Frame Dimensions (LxWxH): 5.5 x 3.0 x 1.0 in LCD Dimensions (LxW): 3.5 x 2.0"
1	Thermometer transmitter (WH3C) with mounting bracket Dimensions (LxWxH): 3.5" x 2.5" x 0.9"

2.2 Recommend Tools

- Philips screwdriver (precision)
- Drill for mounting bracket

2.3 Remote Thermometer Sensor Set Up

 **Note:** To avoid permanent damage, please take note of the battery polarity before inserting the batteries.

Remove the battery door on the back of the sensor with a Philips screwdriver (there is only one screw, at the bottom of the unit). Insert two AAA batteries as shown in Figure 1 (we recommend lithium batteries for cold weather climates, but alkaline batteries are sufficient for most climates).

Replace the battery door and set screw. Note that the temperature will be displayed on the LCD display. Looking at the back of the unit from left to right, the polarity is (-) (+) for the top battery and (+) (-) for the bottom battery.



Figure 1

2.4 Display Console Set Up

 **Note:** To avoid permanent damage, please take note of the battery polarity before inserting the batteries.

Move the remote thermometer at least 10' away from the display console (if the sensor is too close, it may not be received by the display console).

Remove the battery door on the back of the display. Insert two AA (alkaline or lithium, avoid rechargeable) batteries in the back of the display console.

All of the LCD segments will light up for a few seconds to verify all segments are operating properly.

Replace the battery door, and fold out the desk stand and place the console in the upright position.

The console will instantly display indoor temperature, date and time. The outdoor temperature and humidity will display --, then update on the display within a few minutes. **Do not touch any buttons** until the remote sensor reports in, otherwise the remote sensor search mode will be terminated, and you must power down and power up the console again. When the remote sensor data has been received, the console will automatically switch to the normal mode, and all further settings can be performed.

If the remote does not update, please reference the troubleshooting guide in Section 7.

2.4.1 Radio Controlled Clock (RCC)

After the remote sensor is powered up, the sensor will transmit weather data for 30 seconds, and then the sensor will begin radio controlled clock (RCC) reception. During the RCC time reception period (maximum 10 minutes), no weather data will be transmitted to avoid interference.

If the signal reception is not successful within 1 minute, the signal search will be cancelled and will automatically resume every two hours until the signal is successfully captured. The regular RF link will resume once RCC reception routine is finished. In some locations, RCC reception may take a couple of days to receive the signal.

2.4.2 Display Console Layout

 **Note:** The following illustration shows the full segments of the LCD for description purposes only and will not appear like this during normal operation.




Figure 2

- | | |
|---|---------------------------------------|
| 1. Weather tendency arrow | 8. Indoor temperature display |
| 2. Weather forecast icon | 9. Indoor Humidity display |
| 3. Time alarm icon | 10. MIN/MAX icon |
| 4. WWVB tower icon for time reception
(will briefly flash when received) | 11. Transmitter low battery indicator |
| 5. Time / Date | 12. Outdoor temperature display |
| 6. MIN/MAX icon | 13. Number showing sensor unit |
| 7. Receiver low battery indicator | 14. Outdoor reception signal |

2.5 Sensor Operation Verification

Verify the indoor and outdoor temperature match closely with the console and sensor array in the same location (about 10' apart). The sensors should be within 4°F (the accuracy is $\pm 2^\circ\text{F}$). Allow about 30 minutes for both sensors to stabilize.

3. Remote Sensor Installation

It is recommended you mount the remote sensor on a north facing wall, in a shaded area. Direct sunlight and radiant heat sources will result in inaccurate temperature readings. Although the sensor is water resistant, it is best to mount in a well protected area, such as an eave.

Use 3 screws to affix the mounting bracket to the wall. Connect the remote sensor to the wall bracket with a precision screwdriver.




Figure 3

4. Console Operation

 **Note:** After 30 seconds of inactivity, the display will automatically revert to the normal display mode (automatic time out).

 **Note:** The **SET** and **MODE** functions use the same button and are used interchangeably. The **MIN/MAX/-** functions use the same button and are used interchangeably. The **CH/+** functions use the same button and are used interchangeably.

 **Note:** There are two modes of operation (1) normal mode, and (2) set mode, where settings are programmed.

4.1 Time Modes

Press the **MODE** button until the arrow (➔) is pointing at the date and time field.

4.1.1 Set Time, Date, Units and Storm Threshold

Press the **SET** key for 3 seconds to enter the SET Mode and the DST (daylight savings time) will flash. Press the **CH/+** key to switch between ON and OFF. Press the **SET** key to confirm the selection.

The time zone will flash. Press the **CH/+** key to advance the time zone (or **MIN/MAX/-** to decrement the time zone). Reference the table below to determine your time zone setting. Press the **SET** key to confirm the selection.

The 12H will flash. Press the **CH/+** key to switch between the 24 hour (24H) and 12 hour (12H) time display mode. Press the **SET** key to confirm the selection.

The hour will begin flashing. Press the **CH/+** key to advance the hour (or **MIN/MAX/-** to decrement the hour). Note that the PM icon will be displayed for afternoon hours. Press and hold the **CH/+** key

to advance rapidly. Press the **SET** key to confirm the hour selection.

The minute will begin flashing. Press the **CH/+** key to advance the minute. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the minute selection.

The year will begin flashing. Press the **CH/+** key to advance the year. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the year selection.

The year will begin flashing. Press the **CH/+** key to advance the year. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the year selection.

The month will begin flashing. Press the **CH/+** key to advance the month. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the month selection.

The day will begin flashing. Press the **CH/+** key to advance the day. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the month selection.

The temperature units will begin flashing. Press the **CH/+** key to switch between °F and °C. Press the **SET** key to confirm the units selection.

The pressure threshold will begin flashing. Press the **CH/+** key to increase the threshold setpoint (hpa/hr). Press the **SET** key to confirm the pressure threshold selection.


The following table provides times zones throughout the world. Locations in the eastern hemisphere are positive, and locations in the western hemisphere are negative.

Hours from GMT	Time Zone	Cities
-12	IDLW: International Date Line West	---
-11	NT: Nome	Nome, AK
-10	AHST: Alaska-Hawaii Standard CAT: Central Alaska HST: Hawaii Standard	Honolulu, HI
-9	YST: Yukon Standard	Yukon Territory
-8	PST: Pacific Standard	Los Angeles, CA, USA
-7	MST: Mountain Standard	Denver, CO, USA
-6	CST: Central Standard	Chicago, IL, USA
-5	EST: Eastern Standard	New York, NY, USA
-4	AST: Atlantic Standard	Caracas
-3	---	São Paulo, Brazil
-2	AT: Azores	Azores, Cape Verde Islands
-1	WAT: West Africa	---
0	GMT: Greenwich Mean WET: Western European	London, England
1	CET: Central European	Paris, France
2	EET: Eastern European	Athens, Greece
3	BT: Baghdad	Moscow, Russia
4	---	Abu Dhabi, UAE
5	---	Tashkent
6	---	Astana
7	---	Bangkok
8	CCT: China Coast	Beijing
9	JST: Japan Standard	Tokyo

Hours from GMT	Time Zone	Cities
10	GST: Guam Standard	Sydney
11	---	Magadan
12	IDLE: International Date Line East NZST: New Zealand Standard	Wellington, New Zealand

4.1.2 Set Alarm Time

Press the **MODE** button until the arrow (→) is pointing at the date and time field. Press the **CH/+** until the alarm time is displayed, as shown in the figure below.



Press the **SET** key for 3 seconds to enter the SET Mode and the alarm hour will flash. Press the **CH/+** key to advance the alarm hour (or **MIN/MAX/-** to decrement the alarm hour). Note that the PM icon will be displayed for afternoon hours. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the alarm hour selection.

The alarm minute will begin flashing. Press the **CH/+** key to advance the alarm minute. Press and hold the **CH/+** key to advance rapidly. Press the **SET** key to confirm the alarm minute selection.

The time alarm will now be active and alarm symbol (⏰) will be displayed.

4.1.3 Turning On and Off the Time Alarm

While in Normal Mode, select the **MIN/MAX/-** key to turn on (⏰) and off the alarm.

4.1.4 Displaying the Date and Alarm Time

While in Normal Mode, select the **CH/+** key to view the date. Select the **CH/+** key again to view the alarm time.

4.2 Indoor Temperature and Humidity Mode



Press the **MODE** button until the arrow (→) is pointing at the indoor temperature and humidity field.

4.2.1 Displaying and Resetting the Indoor Temperature and Humidity Min and Max Values

Press the **MIN/MAX** key to display the maximum indoor temperature. Press and hold the **MIN/MAX** key for three seconds to reset the maximum indoor temperature to the current value.

Press the **MIN/MAX** key again to display the minimum indoor temperature. Press and hold the **MIN/MAX** key for three seconds to reset the minimum indoor temperature to the current value.

Press the **MIN/MAX** key again to display the maximum indoor humidity. Press and hold the **MIN/MAX** key for three seconds to reset the maximum indoor humidity to the current value.

Press the **MIN/MAX** key again to display the minimum indoor humidity. Press and hold the **MIN/MAX** key for three seconds to reset the minimum indoor humidity to the current value.

4.3 Outdoor Temperature Mode



Press the **MODE** button until the arrow (→) is pointing at the outdoor temperature field.

4.3.1 Displaying and Resetting the Outdoor Temperature Min and Max Values

Press the **MIN/MAX** key to display the maximum outdoor temperature. Press and hold the **MIN/MAX** key for three seconds to reset the maximum outdoor temperature to the current value.

Press the **MIN/MAX** key again to display the minimum outdoor temperature. Press and hold the **MIN/MAX** key for three seconds to reset the minimum outdoor temperature to the current value.

 **Note:** This weather station supports up to three remote temperature sensors. Repeat this procedure for Channels 2 and 3 if these sensors are installed.

4.4 Other Console Features

The following section describes additional console features.


4.4.1 Weather Forecasting and Tendency

 **Note:** The weather forecast or pressure tendency is based on the rate of change of barometric pressure. In general, when the pressure increases, the weather improves (sunny to partly cloudy) and when the pressure decreases, the weather degrades (cloudy to rain).

The weather forecast is an estimation or generalization of weather changes in the next 24 to 48 hours, and varies from location to location. The tendency is simply a tool for projecting weather conditions and is never to be relied upon as an accurate method to predict the weather.

The weather tendency arrow shows positive (↑) and negative (↓) trends in barometric pressure.

4.4.2 Weather Icons



The four weather icons are Sunny, Partly Cloudy, Cloudy and Rainy. There are also two weather tendency indicators to show the air pressure tendency between the weather icons.

4.4.3 Pressure threshold setting

The pressure threshold (the negative or positive rate of change of pressure signifying a change in the weather) can be adjusted by the user from level 2 to level 4 (default level 2 mbar/hour).

The lower the level pressure threshold setting, the higher sensitivity for weather forecast changes. Locations that experience frequent changes in air pressure require a higher setting compared to locations where the air pressure is typically stagnant.

4.5 Multi-Channel Operation

The WS-1280 supports up to three WH-3C remote thermometers (one is included). The optional sensors can be purchased at AmbientWeather.com.

4.5.1 Sensor Initialization

Power up the sensors and console in the following order:

1. Power up the console. Do not touch any of the buttons, as described in Section 2.4.
2. Power up the first remote thermometer as described in Section 2.5. Wait until the sensor reports into the console.
3. Power up the second remote thermometer as described in Section 2.5. Wait until the sensor reports to the console. The first sensor will be designated as Channel 1 and the second sensor will be designated as Channel 2.
4. Power up the third remote thermometer as described in Section 2.5. Wait until the sensor reports to the console. The third sensor will be designated as Channel 3. The display will switch between each sensor until you exit the initialization state by pressing any button.

4.5.2 Sensor Accuracy Note

Verify the temperature values match closely with the console and sensor array in the same location (about 10' apart). The sensors should be within 4°F (the accuracy is $\pm 2^\circ\text{F}$).

Allow about 30 minutes for both sensors to stabilize.

4.5.3 Viewing the 3 Sensor Channels

To view the 3 sensor channels, select the **CH/+** button. The minimum and maximum can be viewed for each channel as specified in Section 4.3.

5. Glossary of Terms

Term	Definition
Accuracy	Accuracy is defined as the ability of a measurement to match the actual value of the quantity being measured.
Hygrometer	A hygrometer is a device that measures relative humidity. Relative humidity is a term used to describe the amount or percentage of water vapor that exists in air.
Range	Range is defined as the amount or extent a value can be measured.

6. Specifications

6.1 Wireless Specifications

- Line of sight wireless transmission (in open air): 300 feet
- Frequency: 433 MHz
- Update Rate: 48 seconds

6.2 Measurement Specifications

The following table provides specifications for the measured parameters.

Measurement	Range	Accuracy	Resolution
Indoor Temperature	32 to 140 °F	± 2 °F	0.1 °F
Outdoor Temperature	-40 to 149 °F	± 2 °F	0.1 °F
Indoor Humidity	20 to 95%	± 5%	1 %

6.3 Power Consumption

- Base station : 2 x AA 1.5V Alkaline batteries
- Remote sensor : 2 x AAA 1.5V Alkaline batteries
- Battery life: Minimum 24 months for base station
Minimum 24 months for remote thermometer sensor (use lithium batteries in cold weather climates)

7. Troubleshooting Guide

If your question is not answered here, you can contact us as follows:

1. Email Support: support@ambientweather.com
2. Live Chat Support: www.ambientweather.com/chat.html (M-F 8am to 4pm Arizona Time)
3. Technical Support: 480-283-1644 (M-F 8am to 4pm Arizona Time)

Problem	Solution
Wireless remote (thermometer) not reporting in to console. There are dashes on the display console.	The maximum line of sight communication range is 300'. Move the sensor assembly closer to the display console. If the sensor assembly is too close (less than 10'), move the sensor assembly away from the display console. Cycle power on the console by removing the batteries, waiting 5 seconds, and reinserting the batteries. The console may have exited the search mode. Install a fresh set of batteries in the remote thermometer. For cold weather environments, install lithium batteries. Make sure the remote sensors are not transmitting through solid metal (acts as an RF shield), or earth barrier (down a hill).

Problem	Solution
	Move the display console around electrical noise generating devices, such as computers, TVs and other wireless transmitters or receivers. Move the remote sensor to a higher location. Move the remote sensor to a closer location. Radio Frequency (RF) Sensors cannot transmit through metal barriers (example, aluminum siding) or multiple, thick walls.
Temperature sensor reads too high in the day time.	Make sure the thermometer is mounted in a shaded area on the north facing wall. Consider the following radiation shield if this is not possible: http://www.ambientweather.com/amwesrpatean.html
Indoor and Outdoor Temperature do not agree	Allow up to 30 minutes for the sensors to stabilize due to signal filtering. The indoor and outdoor temperature sensors should agree within 4 °F (the sensor accuracy is ± 2 °F)
Humidity is reading 20% at low humidity or 95% at high humidity	The humidity sensor is out of range (20 to 95%)
Display console contrast is weak	Replace console batteries with a fresh set of batteries.

8. Accessories

The following software and hardware accessories are available for this weather station at www.AmbientWeather.com.

Accessory	Image	Description
Energizer AA Lithium Battery (2-pack) - Batteries for Long Life and Cold Climates		AA lithium batteries for cold weather climates.
SRS100LX Temperature and Humidity Solar Radiation Shield		Solar Radiation Shield improves temperature accuracy for hot weather climates. Remove the rain guard and install over thermometer.
Ambient Weather WH3C WH-3C Wireless Thermometer		Add two additional remote wireless thermometers for a total of three remote sensors.
Ambient Weather WS-1280-C Wireless Weather Forecaster with Indoor Temperature, Humidity and Outdoor Temperature (console only)		Add multiple consoles throughout your house or business. Each console can read up to three remote sensors.

9. Liability Disclaimer

Please help in the preservation of the environment and return used batteries to an authorized depot. The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.

Reading the “User manual” is highly recommended. The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.

This product is designed for use in the home only as indication of weather conditions. This product is not to be used for medical purposes or for public information.

The specifications of this product may change without prior notice.

This product is not a toy. Keep out of the reach of children.

No part of this manual may be reproduced without written authorization of the manufacturer.

Ambient, LLC WILL NOT ASSUME LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT.

10. FCC Statement

Statement according to FCC part 15.19:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Statement according to FCC part 15.21:

Modifications not expressly approved by this company could void the user's authority to operate the equipment.

Statement according to FCC part 15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

11. Warranty Information

Ambient, LLC provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

This limited warranty begins on the original date of purchase, is valid only on products purchased and only to the original purchaser of this product. To receive warranty service, the purchaser must contact Ambient, LLC for problem determination and service procedures.

Warranty service can only be performed by a Ambient, LLC. The original dated bill of sale must be presented upon request as proof of purchase to Ambient, LLC.

Your Ambient, LLC warranty covers all defects in material and workmanship with the following specified exceptions: (1) damage caused by accident, unreasonable use or neglect (lack of reasonable and necessary maintenance); (2) damage resulting from failure to follow instructions contained in your owner's manual; (3) damage resulting from the performance of repairs or alterations by someone other than an authorized Ambient, LLC authorized service center; (4) units used for other than home use (5) applications and uses that this product was not intended (6) the products inability to receive a signal due to any source of interference or metal obstructions and (7) extreme acts of nature, such as lightning strikes or floods.

This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

