DASHCAM

NORDVÄL DC103





English



NORDVĀL



HELLO,

Thank you for purchasing the Nordväl DC103 dashcam. Let's get started!

TABLE OF CONTENTS

Declaration of Conformity	3
What's in the box	4
Get to know your dashcam	4
Installation of your dashcam	6
Play recordings	7
Apps to connect your dashcam to	7
WiFi connection to your smartphone	8
GPS player software instructions	9
Frequently asked questions	10
Specifications DC103	12

<u>Δ</u> <u>2</u>

DECLARATION OF CONFORMITY

Product information

For the following

Product: radio equipment/dashcam

Type: DC103



Declaration and applicable standards

Hereby, TJM Supplies B.V. declares that the type of radio equipment/dashcam DC103 series conforms to:

Directive EMC 2014/53/EU and the RoHS directive (2011/65/EU) and its amendment directives 2015/863/EU on the restriction of the use of certain hazardous substances in electronic and electronic equipment.

The full text of the EU declaration of conformity can be found at the following internet address: www.nordval.eu/declaration-of-conformity/

Importer

Company: TJM Supplies B.V.

Address: Zompstraat 8

8102 HX Raalte

The Netherlands

Email: info@tjmsupplies.nl

Phone number: +31 85-0402973

Business license number: 72016981

VAT number: NL858946439B01

Manufactured in China

3 **Ā**


WHAT'S IN THE BOX


Please check the box for each of the following items before installing your dashcam:

- ▶ Nordväl DC103 dashcam
- **▶** Rear camera
- ▶ 32GB microSD card
- ▶ 12V power cable (cigarette lighter)
- ▶ AV cable for rear camera

- **▶** USB cable
- **▶** 5x cable clips
- **▶** 3M tape front camera
- **▶** 3M tape rear camera
- **▶** Manual

GET TO KNOW YOUR DASHCAM





Button explained

Button	Function	Instruction
Power	Turn on WiFi and access menu	Press the on/off button on WiFi. Press it again to access the menu.

5

INSTALLATION OF YOUR DASHCAM

Install the front camera behind the rear view mirror. Clean and dry the windshield before installation.

Warning: Do not install the product in a location where it can obstruct the driver's field of vision.

- 1. Turn off the engine. Gently push the card into the slot until it locks into place.
- 2. Peel off the plastic film from the front camera and the rear camera. Peel off the protective film from the double-sided tape and attach the front camera to the windshield behind the rear-viewer mirror.
- 3. Adjust the angle of the lens by rotating the body of the front camera. We recommend pointing the lens slightly downwards (\approx 10° below horizontal), so as to record video with a 6:4 road to background ratio.
- 4. Plug the power cord into the cigarette lighter socket and the front camera.
- 5. Peel off the protective film from the rear camera mount, and attach the rear camera to the rear windshield where there is no defrost grid wire and where the camera can record the entire rear view. Connect the front camera (AV-IN) and the rear camera using the rear camera AV cable.
- 6. Turn on the engine. The dashcam will power up and start recording. Video files are stored on the microSD card. When the microSD card is full, the newest video files will start to replace the oldest video files (called loop recording) so you will always have the most recent video files.

PLAY RECORDINGS

You can play recordings on the screen, on a computer, or through the app (WiFi).

Screen

Access the menu, and choose playback to access the library of video files, and simply choose the video you wish to watch.

Computer

- 1. Remove the microSD card from the dashcam.
- 2. Use a USB microSD or SD card adapter and connect the card to a computer.
- 3. Download GPS player software (see page 9) and install it on your computer.
- 4. Run GPS player software (for instructions, view full manual).

APPS TO CONNECT YOUR DASHCAM TO

Android

Open the Google Play Store and search "Kacam" to download and install the app. You can also scan the QR code down below to go straight to the right application.



ios

Open the Apple store search "Kacam" to download and install the app. You can also scan the QR code down below to go straight to the right application.



Δ

WIFI CONNECTION TO YOUR SMARTPHONE

Open your smartphone WiFi settings and select network: LS03.....; Use default password 12345678 to connect.

Once connected, launch the Kacam app to see live video track your journey, change camera settings or download captured videos and photos. For detailed instructions, view the full manual.

Forgot your WiFi password?

Press the on/off button on your dashcam to activate WiFi. Your WiFi name and password will now show in the top left corner of your dashcam screen.



Ā 8

GPS PLAYER SOFTWARE INSTRUCTIONS

If you need to check the GPS information, the GPS player needs to be installed.

1. Download the GPS player software from the following link: www.nordval.eu/downloads/dashcams



2. Copy the download file to your computer, and run the installation.

Using the player software

- 1. Open the installed GPS player software.
- 2. Click File–Choose the file which you need play, and open it to start playing the video in the software.



9

Ā

FREQUENTLY ASKED QUESTIONS

My dashcam gives an SD card error.

Format the SD card through the settings of your dashcam. For detailed information, please see our full manual.

The dashcam sometimes automatically stops while recording.

There could be an issue with your SD card. Due to the huge amount of HD video data, please use high-speed Class 10 microSD cards.

I cannot find the dashcam in my WiFi settings.

Please turn on the dashcam WiFi by pressing the on/off button. The camera will show a green WiFi icon on your screen to confirm it has turned on WiFi. Also your WiFi information will show in the top left corner of your dashcam.

I cannot connect to the dashcam Wifi.

Switch of your smart network switch on your smartphone.

WiFi automatically disconnects.

When you are connected to the dashcam WiFi it will automatically disconnect after a while (when there is no activity).

Horizontal stripes in the recording.

This is due to the wrong setting of light frequency.

Please set the frequency 60HZ or 50HZ according to your power supply.

The dashcam does not do anything anymore.

Please reset the dashcam and format the SD card and try again. If the screen stays black, please check the power supply.

<u>Δ</u> 1<u>1</u>0

How long is my dashcam covered under warranty?

We provide a 24-month warranty on all our products after purchase (with some exceptions).

Unfortunately, we cannot treat products that have become defective due to incorrect use, fall damage, water damage, etc.

Your question not answered?

The frequently asked questions, solutions and tips are answered above. Is your question not listed? Then go to www.nordval.eu/dashcams/dc103/faq

1<u>1</u>1

SPECIFICATIONS DC103

Product name	Nordväl DC103
Color/Size/Weight	Front: black / 12x6x3 cm / 115 g Rear: black / 5,7x3x3 cm / 32 g
Memory	MicroSD card, class 10 or higher. maxium of 128GB
Recording modes	Normal recording, event recording and parking mode * (when motion is detected) * Use the optional Nordväl hardwired cable for parking mode.
Viewing Angle	Front: 140° wide angle lens Rear: 135° wide angle lens
Menu language	English, French, German, Italian, Spanish, Portuguese, Polish
Resolution/Frame Rate	Full HD 1080p (1920 x 1080P) @ 30FPS
Video Codec	H.264
Video Compression Mode	MP4
Image Compression Mode	JPG
GPS	Built-in
Screen	3" OLED LCD screen
G-sensor	Built-in
Microphone/Speaker	Yes/Yes
USB-port	Built-in
Time and date setting	Yes
Loop recording	Yes
Input	5V 2.5A
Battery	Super capacitor
Operation Temperature	-10°C till 60°C
Warranty	2 years

Nordväl® is the registered trademark of TJM Zwerink Holding B.V. Specifications are subject to change without notice. Copyright©2020 TJM Supplies B.V. All rights reserved Manufactured in China



