




# Use and Care Guide

## 9 ft Sparkling Amelia Pine LED Pre-Lit Tree

Item #1001539382  
Model #TG90M4JA1L01

### HARDWARE INCLUDED



### Safety Information

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed, including the following:

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS


1. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
2. This seasonal product is not intended for permanent installation or use.
3. Do not mount or place the product near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
4. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
5. Do not let lamps rest on the supply cord or on any wire.
6. Unplug the product when leaving the house, when retiring for the night, or if left unattended.
7. This is an electric product and not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
8. Do not use this product for other than its intended use.
9. Do not hang ornaments or other objects from cord, wire, or light string.
10. Do not close doors or windows on the product or extensions cords as this may damage the wire insulation.
11. Do not cover the product with cloth, paper, or any material that is not a part of the product when in use.
12. The lamps of this product are not replaceable. Do not attempt to change or modify the lamps.
13. Read and follow all instructions that are on the product or provide with the product.

## SAVE THESE INSTRUCTIONS

### Installation & Operation


## 1 ASSEMBLING THE TREE STAND

- Step 1. Choose a location near a wall outlet.
- Step 2. Unfold the legs of the tree stand and lay the stand on the floor.
- Step 3. Slide the locking disk of the tree stand down until it snaps into place.




## 2 ASSEMBLING THE TREE

- This tree comes with Quick Set® feature --- Set up and light up your tree in minutes!
- Step 1. Remove the protective caps from the tree bottom and insert the pole into the tree stand.
- Note: Do not step on the tree stand legs during the setup. This may deform the tree stand and may result in an unbalanced tree.
- Step 2. Continue by inserting the upper tree section(s) to the lower section(s) until inserting the tree top.
- Step 3. Shape the branches to your preference by working from the bottom to the top. When adjusting the branches, ensure that no wires are tangled around them.
- Step 4. Shape the tree from the bottom to the top. Start with the branches farthest from the pole – fan out in a star shape, and continue until the entire tree is shaped.



- Step 5. When finished shaping the branches, slightly upsweep all branch tips for a uniform look.



# 3 TURNING ON THE TREE

- Step 1. Connect the light strings of the tree together and plug the adapter into a wall outlet.
- Step 2. Check for loose connection between light string plugs and the power cord.
- Step 3. If the tree comes with a foot pedal, step on the On/Off button.
- NOTE: If some bulbs do not light up or flicker, search for any loose plugs. Connecting the plugs promptly in order to maintain the performance and life expectancy of your pre-lit tree.

## Troubleshooting

| Problem                 | Solution                                                                                                                                                              |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The tree does not light | Ensure that all tree sections are plugged into each other and that the tree is plugged into the wall. If your tree came with a foot pedal, step on the On/Off button. |

## Maintenance

### Spare Parts


This tree package includes hinge pins, washers for any replacement or repair that you need to perform on your tree. If extra parts are needed, contact the Customer Service Team at 1-855-HDHoliday (1-855-434-6543) from 8am to 7pm EST, Monday through Friday, and 9am to 6pm EST, Saturday.

### Repairing Loose Hinges

- Step 1. Place the branch into the slot of the bracket.
- Step 2. Insert a new hinge pin through the holes of the bracket and secure with a washer.

## Care and Cleaning

1. Before using or reusing, inspect product carefully. Discard any products that have cut, damaged or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
2. Before disassembling the tree, unplug the tree and remove all ornaments and decorations.
3. Gently lift the tree top straight up to remove from the center section and fold all branches towards the pole.
4. Repeat this step for the center and bottom tree sections.
5. When storing the product, carefully remove the product from wherever it is placed, including tree, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires. Cover the protective cap on the poles to avoid damaging the internal parts.
6. When not in use, store neatly in a cool, dry location protected from sunlight.



### CAUTION:

1. To reduce the risk of fire and electric shock:

a. Use only the power supply that was provided with this product. Using a different adapter will damage the lights and may cause fire, or electrical shock hazards.

b. Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal.

c. Do not mount or support strings in a manner that can cut or damage wire insulation.
2. The controller and remote controller (if included) can only be used with this product.
3. Ensure the ladder is securely fixed and is not slippery. Be cautious when climbing up and down the ladder.




 Be cautious when using ladder to set up tall trees

# User Servicing Instructions

## HOW TO USE THE LIGHT CONTROLLER:

This tree is preset to Demo mode.  
Before selecting other light functions, the Demo mode has to be deactivated.  
Follow the steps "To deactivate the Demo mode" under Demo Mode Instructions to do so.  
On the Light Control, press the selector button to browse among:

- 1. SLOW FADING
- 2. TWINKLING
- 3. FAST FADING
- 4. COMBINATION
- 5. STEADY
- 6. OFF



# Demo Mode Instructions


This tree is preset to Demo Mode.

## To deactivate the DEMO Mode:

- 1. With the tree plugged in and in DEMO mode, press and hold the FUNCTION button of the in-line light controller for **5 seconds**.
- 2. Press & hold button until warm white lights blink 5 times. You can now choose the light function for your tree.
- 3. The tree is now in normal mode. Flashing pattern can be set to desired function and tree will remember the last setting until new setting is selected.

## To activate the DEMO Mode:

- 1. With the tree plugged in, press and hold the FUNCTION button of the in-line light controller for **5 seconds**.
- 2. Press & hold button until warm white lights blink 3 times. Then, tree lights will display all three modes in sequence, i.e. Slow Fading, Twinkling and Fast Fading.
- 3. Within DEMO mode, the tree will display the Combination pattern at all times unless the function button is pressed to change the flashing pattern. The tree will return to Combination pattern whenever the controller is idle for 30 seconds.



# Warranty

Contact the Customer Service Team at 1-855-HDHOLIDAY (1-855-434-6543) or visit [www.HomeDepot.com](http://www.HomeDepot.com).  
Questions, problems, missing parts? Before returning to the store,  
call [HOME ACCENTS HOLIDAY] Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday