



**Model: HW0009**

**2D Area-imaging Barcode Scanner  
with Display and Charging Cradle**

**User Manual**

Ver.01.1.01

## About This Manual

An asterisk (\*) next to an option indicates the default setting.

Scanners are factory programmed for the most common terminal and communication settings.

If settings need to be changed, you can reprogram by scanning the barcodes in this manual.

### Note:

For the correct use of the product, please read this manual carefully and do not scan configuration bar codes at random. Otherwise, some settings will be temporarily unavailable.

The scanner's keyboard layout default is a US keyboard.

**Please do not hesitate to contact us if you have any questions.**

**Important Notice:**

Please include your Order Number and Product Model Number in the email.

## **Official Customer Service**

**Email Address:** [info@tera-digital.com](mailto:info@tera-digital.com)

**Cell:** +1 (909)-242-8669

**Whatsapp:** +1 (626)-438-1404

## **Follow us:**

Instagram: [tera\\_digital](#)

Youtube: [Tera Digital](#)

Twitter: [Tera Digital](#)

Facebook: [Tera](#)

User manuals are available in Spanish, French, Italian and German, and can be downloaded from our website. You may visit our official website via the link below or by scanning the given QR code:

<https://www.tera-digital.com>



# Contents

<b>Chapter 1 Wireless Settings.....</b>	<b>01</b>
Wireless Factory Default.....	01
Wireless Version.....	01
Beeper Volume.....	01
Vibration.....	01
Battery Level.....	01
Encoding Format.....	02
Operation Modes.....	02
Power Timeout Timer.....	02
Communications & Pairing.....	03
USB-COM/Virtual Serial Port.....	03
2.4GHz Wireless Pairing.....	03
Bluetooth HID Pairing.....	04
Bluetooth Settings.....	05
Keyboard Country Layout.....	07
Keyboard Conversion.....	08
Replacement of Group Separator.....	08
Prefix and Suffix.....	09
Removal of Characters.....	10
Terminators.....	10
Timestamp.....	11
Escape Character Sets.....	11
Appendix - Enter/Exit Configuration Mode.....	11
Appendix - Control Character Chart.....	12
Appendix - ASCII Character Chart.....	13

**Chapter 2 General Settings..... 28**

Factory Default..... 28


Firmware Version..... 28

Illumination Lights..... 28

**Chapter 3 Scan Modes..... 29**

**Chapter 4 Symbolologies..... 30**

# Display Layout



**Hold the “Up” button or the “Down” button for 3s to clear the Total counter.**  
**Hold the “Up” and “Down” at the same time to go to the Home Screen**

# Chapter 1 Wireless Settings

## Wireless Factory Default



Reset to Wireless Factory Defaults

## Wireless Version



Show Wireless Version

## Beeper Volume



High\*



Medium



Low



Off

## Vibration



On



Off

## Battery Level



Show Battery Level

# Encoding Format



GBK (MS Notepad, Excel)\*



Unicode (MS Word)

# Operation Modes

## Real Time Mode



Real Time Mode\*

## Storage Mode



Storage Mode



Upload All  
Stored Codes



Upload Total  
Records



Clear All  
Stored Codes

# Power Timeout Timer



1 min



5 mins



10 mins



30 mins



Never



Immediately



# Communications & Pairing

## USB-COM/Virtual Serial Port



USB-COM

## 2.4Ghz Wireless Pairing

When connected successfully, the scanner is able to scan barcodes into text fields.

Step 1: Scan the “2.4G Mode” barcode.

Note: The scanner will connect to the previously paired USB receiver in preference.



2.4G Mode

Step 2: Scan the “Pairing” barcode to get the scanner ready for pairing, with the display flashing rapidly.



Pairing

Step 3: Plug in the USB receiver and wait till the scanner emits a beep and the display stops flashing, indicating successful pairing.

Note: A double press on the trigger or not detecting any pairing requests within 1 min will cause the scanner to exit pairing mode.

## Bluetooth HID Pairing

Step 1: Scan the “Bluetooth HID” symbol.

Note: The scanner will connect to the previously paired Bluetooth device in preference.



Bluetooth HID

Step 2: Scan the “Pairing” symbol, with the display flashing rapidly.



Pairing

Step 3: Enable Bluetooth on your device and locate a device named “Bar-Code Scanner HID”

Step 4: Tap/Click “BarCode Scanner HID” to pair it with your device.

Step 5: The scanner beeps once and the display stops flashing, indicating successful pairing.

Note: A double trigger press or not detecting any pairing requests within 1 min will cause the scanner to exit pairing mode.

## Bluetooth SPP Pairing

This connection mode only works with applications designed for SPP purpose. If you are not familiar with Bluetooth SPP, please use Bluetooth HID.

Step 1: Scan the “Bluetooth SPP” symbol.

To continue pairing the scanner with your device, launch a specifically designed application (can be downloaded from application store).



Bluetooth SPP

Step 2: Locate a device named “BarCode Scanner SPP” in the application.

Step 3: Tap/click “BarCode Scanner SPP” to pair it with your device.

Step 4: The scanner beeps once and the the red SPP text on the status bar turns green, indicating successful pairing.

## Bluetooth BLE Pairing

This connection mode only works with applications designed for BLE purpose. If you are not familiar with Bluetooth BLE, please use Bluetooth HID.

Step 1: Scan the “Bluetooth BLE” barcode.

To continue pairing the scanner with your device, launch a specifically designed application (can be downloaded from application store).



Bluetooth BLE

Step 2: Locate a device named “BarCode Scanner BLE” in the application.

Step 3: Tap/click “BarCode Scanner BLE” to pair it with your device.

Step 4: The scanner beeps once and the the red BLE text on the status bar turns green, indicating successful pairing.

## Bluetooth Settings

**Hold the trigger for 8s to get the scanner ready for Bluetooth HID pairing**



Long press to enter  
Bluetooth HID Pairing On



Long press to enter  
Bluetooth HID Pairing Off

## Virtual HID Keyboard Settings

(For iOS Bluetooth HID only)



Show/hide Keyboard



Double press trigger  
to show/hide keyboard On



Double press  
trigger to show/hide  
keyboard Off

## Bluetooth HID Transfer Rate

If the transmitted data gets lost or garbled, try to reduce the transfer rate.



Fast



Medium\*



Slow



Ultra-slow

## Change Bluetooth Name

How to Change Bluetooth Name

Step 1: Scan the “Customize Bluetooth Name” symbol.



Customize Bluetooth Name

Step 2: Scan the barcode that contains characters desired. (Users need to generate a barcode that contains characters desired.)

Note: The default name is BarCode Scanner. The target characters selected will be the new Bluetooth Name when the setting is done.

a) The maximum configuration of Bluetooth Name is 16 characters. If inputted characters are more than 16 characters, the scanner picks up the first 16 characters as the new Bluetooth name.

# Keyboard Country Layout

By default, the keyboard layout is a US keyboard. To change this layout, scan the appropriate country code below to program the keyboard for your country or language.



United States



Germany



France



Spain



Italy



Japan



Belgium  
(French)



Portugal



United  
Kingdom



German iOS  
Keyboard



Brazil  
(Portuguese)



Russia



Czech



Italy 142



Turkey Q



Turkey F



Sweden/  
Finland



Mexico  
(Spanish)



Denmark



Norway  
(Written)



Croatia/Serbia



Switzerland  
(German)



Switzerland  
(French)



Dutch  
(Netherlands)



Hungary



Poland



Canada  
(French)



Argentina  
(Latin)



Slovakia



International  
keyboard

## Keyboard Conversion



Conversion Off \*



Convert All  
Characters  
to Upper Case



Convert All  
Characters  
to Lower Case



Invert Case of  
All Characters

## Replace Group Separators

Step 1: Scan the “Replacement On” barcode below.



Replacement On

Step 2: Refer to the “Appendix ASCII Chart” and scan the appropriate barcode.

### For example:

Replace GS character with a printable character |

Step 1: Scan the “Replacement On” barcode.

Step 2: Locate the character | in the ASCII chart and scan the rightmost barcode in the same row.

## Don't Transmit Group Separators

When this option is selected, the scanner will ignore GS characters in the barcodes to be read.



Don't Transmit

# Prefix/Suffix Selections

The maximum size of a prefix/suffix configuration is 16 characters.

## Add a prefix

Step 1: Scan the “Add Prefix” barcode.



Add Prefix

Step 2: Refer to the ASCII chart, locate and scan the barcodes representing desired characters.

For example, add 3 numbers, 7, 8, 9, at the beginning of a barcode ABC123, and get the reading of 789ABC123.

Step 1: Scan the “Add Prefix” barcode.

Step 2: Locate the barcodes representing 7, 8, 9, respectively in the appendix chart and scan the three barcodes in the order in which you want them to output.

## Clear Prefixes

Step 1: Scan the “Add Prefix” symbol.

Step 2: Scan the “Exit Configuration Mode” symbol in the Appendix

Note: Resetting to wireless factory defaults will remove prefixes and suffixes as well.

## Add a suffix

Step 1: Scan the “Add Suffix” barcode.



Add Suffix

Step 2: Refer to the ASCII chart, locate and scan the barcodes representing desired characters.

For example, add 3 characters, X, Y, Z, at the end of a barcode ABC123, and get the reading of ABC123XYZ.

Step 1: Scan the “Add Suffix” barcode.

Step 2: Locate the barcodes representing X, Y, Z, respectively in the appendix chart and scan the three barcodes in the order in which you want them to output.

**Clear Suffixes**

Step 1: Scan the “Add Suffix” symbol.

Step 2: Scan the “Exit Configuration Mode” symbol in the Appendix

Note: Resetting to wireless factory defaults will remove prefixes and suffixes as well.

**Removal of Characters**

The maximum size of this configuration is 16 characters.

Step 1: Scan either the “Remove characters from the start” or the “ Remove characters from the end” barcode.



Remove characters from the start



Remove characters from the end

Step 2: Scan the appropriate digit code from the “Appendix – ASCII Chart” depending on your needs.

(For more digit codes, refer to the first 16 codes of the ASCII Character Chart)



1 digit



2 digits



3 digits



4 digits

**Don’t Remove Characters**

Step 1: Scan either the “Remove characters from the start” or the “Remove characters from the end” barcode.

Step 2: Scan the “Exit Configuration Mode” from the Appendix – Enter/Exit Configuration Mode.

Resetting to wireless factory defaults will remove these settings as well.

**Terminators**



Add Carriage  
Return<CR>  
(0x0D)\*



Add Line  
Feed<LF>  
(0x0A)



Add <CR> &  
<LF>  
(0x0D,0x0A)



Add Horizontal  
Tab<HT>  
(0x09)



None



# Timestamp

If you want to record the time and date for every scan, scan either Time & Date Prefix or Time & Date Suffix. If the time and date stamp doesn't match your computer's, contact Tera customer service for Time Sync Tool.



Show Current  
Time



Timestamp  
Prefix



Timestamp  
Suffix



Clear Timestamp

# Escape Character Sets

This feature is designed to be used in conjunction with the prefix and suffix function. If you need to add control characters (1-31 characters in the ASCII chart) as prefix and/or suffix, you should select an escape character set first. With different character sets, the added characters may vary. By default, the scanner uses escape character set 0. If you simply need to add a printable character (32-127 characters in the ASCII chart) as prefix and/or suffix, just scan the “Add Prefix” or “Add Suffix”, and then scan the barcode representing the character needed from the ASCII chart.



Escape  
Character  
Set 0\*



Escape  
Character  
Set 1



Escape  
Character  
Set 2



Escape  
Character  
Set 3



Escape  
Character  
Set 4

# Appendix–Enter/Exit Configuration Mode



Enter Configuration  
Mode










Exit Configuration  
Mode


# Appendix – Control Character Chart










HEX	DEC	ASCII	Set 0	Set 1	Set 2	Set 3	Set 4
01	01	SOH	NULL	Home	Ctrl+A	Alt+001	Numpad Enter
02	02	STX	Ctrl+B	End	Ctrl+B	Alt+002	Cap Lock
03	03	ETX	Ctrl+C	Up Arrow	Ctrl+C	Alt+003	Right Arrow
04	04	EOT	Custom 1*	Down Arrow	Ctrl+D	Alt+004	Up Arrow
05	05	ENQ	Custom 2*	Left Arrow	Ctrl+E	Alt+005	NULL
06	06	ACK	Custom 3*	Right Arrow	Ctrl+F	Alt+006	NULL
07	07	BEL	Custom 4*	Shift+Tab	Ctrl+G	Alt+007	Enter
08	08	BS	Back Space	Back Space	Back Space	Alt+008	Left Arrow
09	09	HT	Tab	Tab	Tab	Alt+009	Tab
0A	10	LF	Enter	Enter	Ctrl+J	Alt+010	Down Arrow
0B	11	VT	NULL	NULL	Ctrl+K	Alt+011	Tab
0C	12	FF	NULL	NULL	Ctrl+L	Alt+012	delete
0D	13	CR	Enter	Enter	Enter	Alt+013	Enter
0E	14	S0	F1	Page Up	Ctrl+N	Alt+014	Insert
0F	15	S1	F2	Page Down	Ctrl+O	Alt+015	Esc
10	16	DLE	F3	F11	Ctrl+P	Alt+016	F11
11	17	DC1	F4	NULL	Ctrl+Q	Ctrl+Q	Home
12	18	DC2	F5	NULL	Ctrl+R	Alt+018	Print Screen
13	19	DC3	F6	NULL	Ctrl+S	Alt+019	Back Space
14	20	DC4	F7	NULL	Ctrl+T	Alt+020	Shift tab
15	21	NAK	F8	F12	Ctrl+U	Alt+021	F12
16	22	SYN	F9	F1	Ctrl+V	Alt+022	F1
17	23	TB	F10	F2	Ctrl+W	Alt+023	F2
18	24	CAN	F11	F3	Ctrl+X	Alt+024	F3
19	25	EM	F12	F4	Ctrl+Y	Alt+025	F4
1A	26	SUB	NULL	F5	Ctrl+Z	Alt+026	F5
1B	27	Esc	Esc	F6	Ctrl+[	Alt+027	F6
1C	28	FS	ALT+028	F7	Ctrl+\	Alt+028	F7










1D	29	GS	ALT+029	F8	Ctrl+]	Alt+029	F8
1E	30	RS	NULL	F9	Ctrl+^	Alt+030	F9
1F	31	US	NULL	F10	Ctrl+_	Alt+031	F10

**Appendix –ASCII Character Chart**










HEX	ASCII(DEC)	Char	Symbol
01	01	SOH	
02	02	STX	
03	03	ETX	
04	04	EOT	
05	05	ENQ	
06	06	ACK	
07	07	BEL	

08	08	BS	
09	09	HT	
0A	10	LF	
0B	11	VT	
0C	12	FF	
0D	13	CR	
0E	14	S0	
0F	15	S1	
10	16	DLE	










11	17	DC1	
12	18	DC2	
13	19	DC3	
14	20	DC4	
15	21	NAK	
16	22	SYN	
17	23	TB	
18	24	CAN	
19	25	EM	










1A	26	SUB	
1B	27	Esc	
1C	28	FS	
1D	29	GS	
1E	30	RS	
1F	31	US	
20	32	SP	
21	33	!	
22	34	"	









23	35	#	
24	36	\$	
25	37	%	
26	38	&	
27	39	`	
28	40	(	
29	41	)	
2A	42	*	
2B	43	+	










2C	44	,	
2D	45	-	
2E	46	.	
2F	47	/	
30	48	0	
31	49	1	
32	50	2	
33	51	3	
34	52	4	





















35	53	5	
36	54	6	
37	55	7	
38	56	8	
39	57	9	
3A	58	:	
3B	59	;	
3C	60	<	
3D	61	=	










3E	62	>	
3F	63	?	
40	64	@	
41	65	A	
42	66	B	
43	67	C	
44	68	D	
45	69	E	
46	70	F	









47	71	G	
48	72	H	
49	73	I	
4A	74	J	
4B	75	K	
4C	76	L	
4D	77	M	
4E	78	N	
4F	79	O	

50	80	P	
51	81	Q	
52	82	R	
53	83	S	
54	84	T	
55	85	U	
56	86	V	
57	87	W	
58	88	X	

59	89	Y	
5A	90	Z	
5B	91	[	
5C	92	\	
5D	93	]	
5E	94	^	
5F	95	_	
60	96	'	
61	97	a	

62	98	b	
63	99	c	
64	100	d	
65	101	e	
66	102	f	
67	103	g	
68	104	h	
69	105	i	
6A	106	j	

6B	107	k	
6C	108	l	
6D	109	m	
6E	110	n	
6F	111	o	
70	112	p	
71	113	q	
72	114	r	
73	115	s	

74	116	t	
75	117	u	
76	118	v	
77	119	w	
78	120	x	
79	121	y	
7A	122	z	
7B	123	{	
7C	124		



7D	125	}	
7E	126	~	
7F	127	DEL	
C7	199	Ç	
E7	231	ç	

## How to enable the scanner to input special characters


1. Scan the following three configuration codes from left to right.



2. Scan the appropriate keyboard layout code from the Keyboard Country Layout section (page 7).

# Chapter 2 General Settings

## Factory Default



Reset to Factory Defaults

## Check Firmware Version



Show Firmware Version

## Illumination Lights

The white illumination lights are designed to improve scanner performance in dim ambient condition.



Lights On \*



Lights Off

# Chapter 3 Scan Modes

## Manual Trigger Mode

A scan mode for reading barcodes by pulling the trigger.



Manual Trigger Mode\*

## Continuous Scan Mode

A scan mode that continuously keeps scanning barcodes.



Continuous Scan Mode

## Sensor-activated Mode

For sensor-activated mode, when the scanner is idle it has no illumination, and uses predominantly ambient light to detect if an object is moving in front of the scanner. The scanner is expected to reside in a fixed position. Whenever it detects activity in the field of view it will turn on the illumination and attempt to read a barcode. After reading the barcode the illumination will be default remain on for defined period, before it returns to idle state again.



Sensor-activated Mode

# Chapter 4 Symbolologies

## Description

If you want to decode all the symbolologies allowable for your scanner, scan the All Symbolologies On code. If on the other hand, you want to decode only a particular symbology, scan All Symbolologies Off followed by the On symbol for that particular symbology.

Note: Scanner performance may reduce by scanning All Symbolologies On. Only scan All Symbolologies On when needed.

## Overall Settings



All Symbolologies On



All Symbolologies Off



All 1D Symbolologies On



All 1D Symbolologies Off



All 2D Symbolologies On



All 2D Symbolologies Off

## UPC-A



On\*



Off

## UPC-A Check Digit

This selection allows you to specify whether the check digit should be transmitted at the end of the scanned data or not.



On\*



Off

**UPC-A Addenda**

This selection adds 2 or 5 digits to the end of all scanned UPC-A data.



2-digit Addenda On



2-digit Addenda Off\*



5-digit Addenda On



5-digit Addenda Off\*

**UPC-A Addenda Required**

When Required is scanned, the scanner will only read UPC-A barcodes with addenda. You must then turn on a 2 or 5 digit addenda listed above.



Required



Not Required\*

**UPC-A Addenda Separator**

When this feature is on, there is a space between the data from the bar code and the data from the addenda. When turned off, there is no space.



On\*



Off

**UPC-A Number System**

The numeric system digit of a U.P.C symbol is normally transmitted at the beginning of the scanned data, but the unit can be programmed so it will not transmit it.



On\*



Off

**UPC-A converted to EAN-13**

When On is selected, UPC-A barcodes are converted to 13-digit EAN-13 codes by adding a zero to the front. When Off is scanned, UPC-A codes are read as UPC-A.



On



Off\*

**UPC-E0**



On\*



Off

**UPC-E1**



On



Off\*

**UPC-E Check Digit**

This selection allows you to specify whether the check digit should be transmitted at the end of the scanned data or not.



On\*



Off

**UPC-E Addenda**

This selection adds 2 or 5 digits to the end of all scanned UPC-A data.



2-digit Addenda On



2-digit Addenda Off\*



5-digit Addenda On



5-digit Addenda Off\*

**UPC-E Addenda Required**

When Required is scanned, the scanner will only read UPC-E barcodes with addenda. You must then turn on a 2 or 5 digit addenda listed above.



Required



Not Required\*

**UPC-E Addenda Separator**

When this feature is on, there is a space between the data from the bar code and the data from the addenda. When turned off, there is no space.



On\*



Off

**UPC-E0 Leading Zero**

This feature allows the transmission of a leading zero at the beginning of scanned data. To prevent transmission, scan Off.



On\*



Off

**UPC-E0 Expand**

UPC-E0 Expand expands the UPC-E code to the 12-digit, UPC-A format.



On



Off\*

**EAN-8**

**EAN-8 On/Off**



On\*



Off

**EAN-8 Check Digit**



Transmit Check Digit\*



Don't Transmit Check Digit

**EAN-8 Addenda**



2-digit Addenda On



2-digit Addenda Off\*



5-digit Addenda On



5-digit Addenda Off\*

**EAN-8 Addenda Required**



Required



Not Required\*

**EAN-8 Addenda Separator**

When this feature is on, there is a space between the data from the bar code and the data from the addenda. When turned off, there is no space.



On\*



Off

**EAN-8 Converted to EAN-13**

This selection expands EAN-8 to the 13-digit, EAN-13 format.



On



Off\*



# EAN-13

## EAN-13 On/Off



On\*



Off

## EAN-13 Check Digit



Transmit Check Digit\*



Don't Transmit Check Digit

## EAN-13 Addenda



2-digit Addenda On



2-digit Addenda Off\*



5-digit Addenda On



5-digit Addenda Off\*

## EAN-13 Addenda Required



Required



Not Required\*

## EAN-13 Addenda Separator

When this feature is on, there is a space between the data from the bar code and the data from the addenda. When turned off, there is no space.



On\*



Off

**ISBN Translate**

When On is scanned, EAN-13 symbols are translated into their equivalent ISBN number format.



On



Off\*

**ISBN Check Digit**



Transmit Check Digit



Don't Transmit  
Check Digit\*

**ISSN Translate**



On



Off\*

**ISSN On/Off**



On



Off\*

**ISSN Check Digit**



Transmit Check Digit



Don't Transmit  
Check Digit\*

**Code 128**



On\*



Off

# GS1-128(UCC/EAN 128)



On\*



Off

## Code 39

### Code 39 On/Off



On\*



Off

### Code 39 Check Character

No Check Character indicates that the scanner reads and transmits barcode with or without a check character. When Check Character is set to Validate and Transmit, the scanner will only read barcodes with a check character, and will transmit this character at the end of the scanned data.



Mod 43, Validate



No Check Character\*



Transmit Check Digit



Don't Transmit  
Check Digit\*

### Code 39 Start/Stop Characters

Start/Stop characters identify the leading and trailing ends of the barcode. You may either transmit, or not transmit Start/Stop characters.



Transmit



Don't Transmit\*

### Code 39 Full ASCII

If Full ASCII Code 39 decoding is enabled, certain character pairs within the barcode symbol will be interpreted as a single character.



Full ASCII On



Full ASCII Off\*

# Code 32 Pharmaceutical (PARAF)

## Code 32 Pharmaceutical On/Off

Code 32 Pharmaceutical is a form of the Code 39 symbology used by Italian pharmacies. This symbology is also known as PARAF.



On



Off\*

## Check Digit



Transmit Check Digit\*



Don't Transmit  
Check Digit

## Add Prefix A to Code 32



On



Off\*

## Code 32 Not Good Read



On\*



Off

Note: Being a variant of Code 39, Code 32 may be recognized as Code 39 when Code 32 is disabled and Code 39 is enabled. In this case, the output may be incorrect. If you turn on Code 32 Not Good Read, the scanner will still input the data even if it is wrong; if you disable the feature, the scanner will not scan Code 32 barcodes as well as Code 39 barcodes.

## Code 93



On\*



Off

**Code 11**

**Code 11 On/Off**



On



Off\*

**Code 11 Check Digits**



1 check digit\*



2 check digits

**Transmit Check Digit**



On\*



Off

**Codabar (NW-7)**

**Codabar On/Off**



On\*



Off

**Codabar Check Character**



No Check Character\*



Mod 16, Validate

**Transmit Check Digit**



On



Off\*

## Codabar Start/Stop Characters

Start/Stop characters identify the leading and trailing ends of the barcode. You may either transmit, or not transmit Start/Stop characters.



On



Off\*

## Interleaved 2 of 5

### Interleaved 2 of 5 On/Off



On\*



Off

## Interleaved 2 of 5 Check Character

No Check Character indicates that the scanner reads and transmits barcode with or without a check character. When Check Character is set to Validate and Transmit, the scanner will only read barcodes with a check character, and will transmit this character at the end of the scanned data.



No Check Character\*



Mod 10, Validate



Transmit Check Digit



Don't Transmit  
Check Digit\*

## Matrix 2 of 5

### Matrix 2 of 5 On/Off



On\*



Off

**Matrix 2 of 5 Check Character**



Validate, and Transmit



No Check Character\*



Validate, but Don't  
Transmit

**Industrial 2 of 5**



On\*



Off

**Standard 2 of 5(IATA 2 of 5)**



On



Off\*

**MSI Plessey**

**MSI Plessey On/Off**



On



Off\*

**MSI Plessey Check Character**

No Check Character indicates that the scanner reads and transmits barcode with or without a check character. When Check Character is set to Validate and Transmit, the scanner will only read barcodes with a check character, and will transmit this character at the end of the scanned data.



No Check Character\*



1 digit Mod 10



2-digit Mod 10



1 digit Mod 10,  
1 digit Mod 11



Transmit Check Digit



Don't Transmit Check  
Digit\*

# Telepen

## Telepen On/Off



On



Off\*

## Telepen Output



Numeric



Alphanumeric\*

# Febraban

## Febraban On/Off (ITF25)



On



Off\*

## Febraban On/Off (Code 128)



On



Off\*

## Check Character

No Check Character indicates that the scanner reads and transmits barcode with or without a check character. When Check Character is set to Validate and Transmit, the scanner will only read barcodes with a check character, and will transmit this character at the end of the scanned data.



Validate, and Transmit



No Check Character\*

# GS1 DataBar 14 (RSS-14)



On\*



Off

Note: GS1 DataBar 14 is also known as GS1 Databar Omnidirectional, RSS-14



**GS1 DataBar Limited (RSS-Limited)**



On\*



Off

Note: GS1 DataBar Limited is also known RSS-Limited

**GS1 DataBar Expanded (RSS-Expanded)**



On\*



Off

Note: GS1 DataBar Expanded is also known as RSS-Expanded

**QR Code**

**QR Code On/Off**



On\*



Off

**QR Code - Inverse**



Regular Only\*



Both Regular and Inverse

**URL QR Code**



URL QR Code On\*



URL QR Code Off

**Data Matrix**

**Data Matrix On/Off**



On\*



Off

**Data Matrix - Rectangular**



On



Off\*

**Data Matrix - Inverse**



Regular Only\*



Both Regular and Inverse

**PDF 417**



On\*



Off

**MicroPDF417**



On



Off\*

**MaxiCode**



On



Off\*

**Aztec Code**

**Aztec Code On/Off**



On



Off\*

**Aztec Code - Inverse**



Regular Only\*



Both Regular and Inverse

**GS1 Composite Code**



On



Off\*