

# QUICK START GUIDE<sup>®</sup>

Please read these instructions completely before operating this product.

**Important!**  
  
Use bag to lift TV.  
Do not touch screen.



To download your copy of the complete Owner’s Manual:

<http://consumersservicerefurbish.com>

Click on: Download Owners Manual  
On Manufacturer or Brand, select: VIZIO  
On Product Type, select: TV  
On Model Number, select: D24FM-K01\_D32FM-K01\_ D40FM-K09\_D43FM-K04


**What’s Inside the Box • Smart TV | Power Cable | Voice Remote | TV Feet with Screws**  
**What You Need Not Included • Phillips Head Screwdriver | Broadband Internet Connection | WiFi Password**

Accessory type and quantity may vary depending on the model.

## 1 Stand Setup


Lift the TV out of the box using the plastic bag\* covering the TV. Support the TV evenly on both sides while laying it on a padded, flat surface that is larger than the TV.

Install the stand feet\*\* or a wall mount\*\* (not included) according to the image below. When the stand legs are properly connected, the legs will not shift or move.



## 2 Remote Control

Once you are ready to start the on-screen setup, insert two AAA batteries into your remote control.



## 3 Connect

Plug the TV power cord into a wall outlet.

If you have a sound bar, connect it to your TV’s HDMI ARC port (HDMI 1) now.



**HDMI ARC/eARC**

**HDMI 1 (ARC)**

**Integrated Sound Bar Control:**  
When connected to select VIZIO sound bars using the dedicated HDMI ARC/eARC port, audio settings can be adjusted easily via an on-screen menu.

The actual number of ports may have a different name or location.

## 4 On-screen Setup

Follow the easy on-screen instructions to complete the setup of your TV.

See the User Manual for a full walk-through.

The image shown here is for illustrative purposes only and may be subject to change.

The remote control vary depend of model! The buttons on the remote control may have a different name or location than the remote control shows in this manual.

The cables mentioned in this guide is not supplied with your unit.



Safety & Certification
IMPORTANT SAFETY INSTRUCTIONS

Your TV is designed and manufactured to operate within defined design limits. Misuse may result in electric shock or fire. To prevent your TV from being damaged, the following instructions should be observed for the installation, use, and maintenance of your TV. Read the following safety instructions before operating your TV. Keep these instructions in a safe place for future reference.

- To reduce the risk of electric shock or component damage, switch off the power before connecting other components to your TV.
- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly where it exits, crosses over receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cord, store, rated, product, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when making the cord/appliance combination to avoid injury from tip over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled on objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Unplug the power cord before cleaning your TV.
- When moving your TV from an area of low temperature to an area of high temperature, condensation may form in the housing. Wait before turning on your TV to avoid causing fire, electric shock, or component damage.
- A distance of at least three feet should be maintained between your TV and any heat source, such as smoking, heater, lamp, an pillar, etc. Do not install your TV close to smoke. Operating your TV close to smoke or moisture may cause fire or electric shock.
- Slots and openings in the back and bottom of the cabinet are provided for ventilation. To ensure reliable operation of your TV and to protect it from overheating, be sure these openings are not blocked or covered. Do not place your TV in a location in which airflow is restricted.
- Never push any object into the slots and openings on your TV cabinet. Do not place any objects in the front of your TV. Doing so could short-circuit parts causing a fire or electric shock. Never spill liquids on your TV.
- Your TV should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
- Do not apply pressure or throw objects at your TV. This may compromise the integrity of the TV. The manufacturer's warranty does not cover user abuse or improper installation.
- The power cord must be replaced when using different voltage than the voltage specified. For more information, contact a service center.
- When connected to a power outlet, power is always flowing into your TV. To safely disconnect power, unplug the power cord.
- The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of an isolated, dangerous voltage within the interior of your TV that may be of sufficient magnitude to constitute a risk of electric shock to persons.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- The wall socket should be installed near your TV and easily accessible.
- Only power of the marked voltage can be used for your TV. Any other voltage than the specified voltage may cause fire or electric shock.
- Do not touch the power cord during lightning. To avoid electric shock, avoid touching the power cord during electrical storms.
- Unplug your TV during a lightning storm or when it will not be used for long period of time. This will protect your TV from damage due to power surges.
- Do not attempt to repair or service your TV yourself. Opening or removing the back cover may expose you to high voltages, electric shock, and other hazards. If repair is required, contact your dealer and refer all servicing to qualified service personnel.
- WARNING: Keep your TV away from moisture. Do not expose your TV to rain or moisture. If water penetrates into your TV, unplug the power cord and contact your dealer. Continued use in this case may result in fire or electric shock.
- Do not use your TV if any abnormality occurs. If any smoke or odor becomes apparent, unplug the power cord and contact your dealer immediately. Do not try to repair your TV yourself.
- Avoid using dropped or damaged appliances. If your TV is dropped and the housing is damaged, the internal components may function abnormally. Unplug the power cord immediately and contact your dealer for repair. Continued use of your TV may cause fire or electric shock.
- Do not use old your TV in areas with heavy dust or high humidity. Operating your TV in environments with heavy dust or high humidity may cause fire or electric shock.
- Follow instructions for moving your TV. Ensure that the power cord and any other wires are unplugged before moving your TV.
- To prevent injury, this apparatus must be securely attached to the floorwall in accordance with the installation's cautions.
- When unplugging your TV, grab the head of the power plug, not the cord. Pulling on the power cord may damage the wires inside the cord and cause fire or electric shock. When your TV will not be used for an extended period of time, unplug the power cord.
- To reduce risk of electric shock, do not touch the connector with wet hands.
- Insert batteries in accordance with instructions. Incorrect polarities may cause the batteries to leak which can damage the remote control or cause the operation. Do not expose batteries to excessive heat, such as sunshine, fire or the like.

- If any of the following occurs, contact a service center:
  - The power cord falls or frays.
  - Liquid sprays or any object drops into your TV.
  - Your TV is exposed to rain or other moisture.
  - Your TV is dropped or damaged in any way.
  - The performance of your TV changes substantially.
- This apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The main plug or appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.
- The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated DANGEROUS VOLTAGE within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
- WARNING: Exposure to loud sounds can damage your hearing causing hearing loss and tinnitus (ringing or buzzing in the ears). With continued exposure to loud noises, ears may become accustomed to the sound level, which may result in permanent damage to hearing without any noticeable discomfort.
- Insert the TV where it cannot be pulled, pushed or knocked over.
- Do not allow children to hang onto the product.
- Store the accessories (remote, batteries, etc.) in a location safely out of the reach of children.
- The American Academy of Pediatrics discourages television viewing for children younger than two years of age.
- WARNING: Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death.
- Many injuries, particularly to children, can be avoided by taking simple precautions, such as:
  - Using cabinets or stands recommended by the manufacturer of the television set.
  - Only using furniture that can safely support the television set.
  - Ensuring the television set is not overhanging the edge of the supporting furniture.
  - Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring fast to the furniture and the television set to a suitable support.
  - Not placing the television set on chairs or other materials that may be placed between the television set and the supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the television set or its controls.
- If your existing television set is being retained and replaced with this same model or a later version, the same considerations as above should be applied.
- WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.



Regulatory Information

FCC Class B Radio Interference Statement
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice
The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This doc Interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibility of the user to correct such interference.

FCC Warning
Changes or modifications not expressly approved by the party responsible for compliance with the FCC Rules could void the user's authority to operate this equipment.

Caution
Always use a power outlet that is properly grounded.

Canada Notice for License-Exempt Radio Apparatus
This device complies with Industry Canada's Low-Serious-RPT RSS-616. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device operates on a non-protected non-interference basis. Should the user seek to obtain protection from other radio services operating in the same TV band, a radio license is required. Please consult Industry Canada's document CPC-21-28, Optional Licensing for Low-Power Radio Apparatus or the TV bands, for details.

This Class B digital apparatus complies with Canadian ICES-003.

Legal Information

Software Licenses
All software is provided subject to a software license agreement(s), and you agree that you will be bound by such license agreement(s) in addition to these terms. Your use of this product is subject to Vizio's privacy policy, which may be updated from time to time, and is available to view at: http://www.vizio.com/privacy.

Export Regulations
Customer acknowledges that the VIZIO products, which include technology and software, are subject to customs and export control laws in the United States ("US"). The products may also be subject to the customs and export control laws and regulations of the country in which the products are manufactured and/or serviced.

Internet Connectivity
Network conditions, environmental and other factors may negatively affect connectivity and the resulting video quality, if any. The applications and content of the applications pictured herein or described in accompanying documentation may only be available in certain countries or languages, may require additional fees or subscription charges, and may be subject to future updates, modifications or discontinuation without notice. VIZIO has no control over third-party applications or content, and assumes no responsibility for the availability or interruption of such applications or content. Additional third-party terms, conditions and restrictions apply.

© 2018 VIZIO, Inc. All Rights Reserved.

This User Manual may not be copied in whole or in part without the written permission of VIZIO, Inc. VIZIO, Inc. has made reasonable efforts to ensure the accuracy of the information provided herein. All product specifications, functionality, features, configurations, and firmware, design and other product information described herein are subject to change without notice. VIZIO, Inc. is not responsible for typographical, technical, or descriptive errors.

VIZIO, the VIZIO logo, the V logo, and other terms and phrases are trademarks or registered trademarks of VIZIO, Inc.

The terms HDMI, HDMI High Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

For DTS patents, see http://patents.dts.com/. Manufactured under license from DTS, Inc. DTS, the Symbol, DTS and the Symbol together, and DTS Studio Sound are registered trademarks and/or trademarks of DTS, Inc. in the United States and/or other countries. © DTS, Inc. All Rights Reserved.

Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories. Manufactured under license from Dolby Laboratories. Confidential/unpublished work. Copyright © 2018 2019 Dolby Laboratories. All rights reserved.

© 2018 Google Inc. All rights reserved. Google Goo is a trademark of Google Inc.

Other names of companies, products, and services used in this User Manual may be trademarks, trade names or service marks of others and VIZIO, Inc. disclaims any interest in such names, trademarks or service marks other than its own. Mention of other VIZIO products is for informational purposes only.

Battery Disposal



Caution: This product may be shipped with batteries. Do not dispose of batteries in a fire or with your household waste. Batteries may explode and can cause damage. Replace batteries only with the same or equivalent type of battery recommended by VIZIO. The disposal of batteries may be regulated by your state. For more information on recycling or properly disposing of your batteries, please check with your state or go to www.vizio.com/environment.

Product Recycling

The disposal and recycling of consumer electronic products may be regulated by your state. Always properly dispose of your VIZIO products in accordance with local laws and regulations. VIZIO supports the proper recycling of our products. For information on how to properly recycle your VIZIO products and to learn more about consumer electronics recycling laws, please go to www.vizio.com/environment.



Packaging Disposal
VIZIO encourages the recycling of the packaging used for this product. Please break-down all boxes and recycle eligible materials according to local laws and regulations. For more information please go to: www.vizio.com/environment.