



Mcombo®

| Mobility Issue Series
Power Lift Recliner

Owner's Manual

Mcombo.com
Amazon.com/mcombo

6160 - 7507



Mcombo.com



Amazon.com/mcombo

Newacme LLC, 2808 Vail Ave, Commerce, CA, 90040
sales@mcombo.com
1-323-597-1109

All rights reserved



CONTENTS

I. SAFETY GUIDELINES - - - - - 02

II. ASSEMBLY INSTRUCTIONS - - - - - 05

III. DISASSEMBLY INSTRUCTIONS - - - - - 11

IV. OPERATING INSTRUCTIONS - - - - - 13

V. TROUBLESHOOTING - - - - - 15

VI. WARRANTY - - - - - 21

VII. RETURN/REPLACEMENT POLICY - - - - - 22

VIII. CARE AND MAINTENANCE - - - - - 22

IX. MCOMBO CUSTOMER SUPPORT - - - - - 24

X. FEEDBACK - - - - - 25

DISCLAIMER

We ask that you read this manual completely before assembling and operating your new Mcombo Power Lift Recliner. We are not and cannot be held responsible for any damage or injury incurred due to improper or unsafe use of the Mcombo Power Lift Recliner. We specifically disclaim responsibility for any bodily injury or property damage that may occur during any use that does not comply with applicable federal, state, or local laws or ordinances.

I. SAFETY GUIDELINES

MANDATORY!

Read the safety and other instructions before using your Mcombo® Recliner. Failure to follow the guidelines, warnings in this manual and those located on your product can result in personal injury or product damage and will void the product warranty.

DANGER

- To prevent suffocation, keep plastic bags away from children.
- Do not allow children play on or near the chair when in use. Serious injury or death could occur if a child is under the chair when the chair is in motion.
- Keep cord out of reach of small children, and do not use where it may be a trip hazard.
- Plug directly into a wall outlet. Do not use an extension cord or adapter.
- Avoid exposing upholstered chair to burning cigarettes or cigars, open flames, and high temperatures.
- Do not use this product if it is wet, in water, around water or any liquid.
- Always leave in an upright and closed position. Keep hands and feet clear of mechanism and all moving parts. Footrest must be completely closed before getting in or out of the chair. Only the occupant should operate the chair.
- Before moving the product, disconnect the electrical plug from the wall outlet and secure the mechanism to prevent unexpected lifting and movement of the chair.

WARNING

- Weight Capacity: 320 lbs.
- Do not use outdoors. INDOOR USE ONLY.
- To avoid tip over, do not put your weight against the back of the chair.
- Do not stand, sit, or place extra weight on the arms, back or open footrest.
- Do not use this product if it is damaged. Do not use attachments or substitute parts.

- Do not use this product if you have poor circulation, are mobility-impaired, or cannot sense heat, except as directed by your health care provider.
- Do not operate the unit until the back is installed and locked.
- Do not attempt to disassemble or repair the actuator or pump; no serviceable parts are inside.
- Do not allow electrical cord to be pinched between moving parts or between the frame and the floor. Do not place cord under carpet or in a location where it could become worn.
- Do not use pillow, blanket, or other cover between occupant and chair surface when heat is engaged.
- Do not attempt to disconnect the power plug by pulling the power cord. Always hold the power plug and pull it out.
- Closely supervise children and disabled persons using this product.
- To reduce the risk of head entrapment and other injuries, keep children and pets away from openings and moving parts in and around furniture.
- Unplug power cords from outlet before relocating or troubleshooting.
- This product has many moving parts, serious injury can occur if not used properly. Keep hands, fingers, and body parts away from the mechanism.
- To exit the unit safely and prevent a tripping hazard, bring the back upright and close the footrest.
- Place tables and area rugs at a distance to allow the footrest to fully extend without rubbing or interference.
- Check the condition of the power supplies, electrical cords, plugs, and connectors often. Keep the power supplies and electrical cords away from heat sources. Never operate the unit with a damaged power supply, electrical cord, plug or connector.
- This product is not intended for use as a health care device. Some medications and physical limitations may impair your ability to operate this product in a safe manner. Consult your physician if you are taking prescribed or over the counter medication, or if you have physical limitations.
- Do not charge your device into the USB charge ports over 24hours.
- Do not charge any devices over 5V/2A with the USB charge ports.
- Do not overlay the USB charge ports with other heat-dissipating electronic products. This may prevent heat dissipation and cause overheating or melting.
- Users of medical devices should contact their health care provider before using this product.
- Unplug the power cord immediately if you detect strange odors or fumes coming from the chair. Contact your Mcombo Customer Support.
- Burns may result from improper use and care of internal heating parts. To avoid risk of burns, do not use pins, do not allow heating pad area to become wet, and do not remove upholstery cover.
- The chair is intended for a single occupant, not exceeding 320 pounds. Do not operate the chair with more than one occupant in or on any part of the chair.
- If you give this product to someone else, must include this owner's manual.

⚠ SYMBOLS INFORMATION

The symbols below represent labels used on the product to identify warnings, mandatory actions, and prohibited actions. It is especially important for you to read and understand these symbols completely. Do not remove these labels from your product. Please note that not all the symbols may be used on your chair.



Read and follow the information in the owner's manual



Weight capacity: 320 lbs



Do not connect an extension cord to the AC/DC converter or the battery charger



Do not place objects under the footrest when lift chair is in fully reclined position



Do not cover or place the external transformer and other objects under lift chair



Pinch/Crush Points Hazard



Electrical Hazard



Class II Equipment



Indoor Use Only

PURCHASER'S AGREEMENT

By accepting delivery of this product, you promise that you will not change, alter, or modify this product or remove or render inoperable or unsafe any guards, shields or other safety features of this product. You will not refuse or neglect any retrofit kits that Mcombo may provide to enhance and preserve the safe use of this product.

II. ASSEMBLY INSTRUCTIONS

Notice

1. Please read these instructions thoroughly before using.
2. Do not plug the power supply in until assembly complete.
3. Choose a location for the lift chair that is close to an electrical outlet (1 power outlet required).

Shipping and Delivery





This chair comes with 2 boxes and the carrier may deliver them on different days, please make sure your delivery is complete. Please contact us (See "Mcombo Customer Support" on Page) immediately if anything is missing or damaged.

Unpacking

Carefully unpack all items and lay out contents for inspection. Remove any packaging tape or supplies.

Parts List


NOTE: Use Mcombo parts only for all replacements.

Box 1 of 2	A  Seat x1	C  Right armrest x1
	B  Backrest x1	C  Left Armrest x1
Box 2 of 2		
D  Lift Remote x1	E  Angle Power Cord x1	F  Anti-back-tipping x2
		G  Rack circular gasket x2 (Spare parts)

Assembly Steps

Step1 Armrest Assembly

1. Ensure the armrest which has USB charge port is located on right of seat.
2. Slide the left and right armrest into the brackets of the seat.
3. Press each armrest down as far as it will go (Figure).




NOTE: Ensure the two connections on each armrest are both inserted onto the seat tightly.

ATTENTION

Ensure the two connections on each armrest are all inserted onto the seat tightly.

Step2 Backrest Assembly

1. Align the brackets of backrest at the clips of seat-back (Figure).
2. Push firmly the brackets into the seat-back. Listen for a “click” on each side to ensure the backrest is locked in properly.




NOTE: Pull up the backrest to check if it is locked in place.

ATTENTION

Remove the plastic cap before assembling backrest.


Step3 Lift Connections

1. Connect the chairs according to the following wiring diagram (Figure).
2. Attach the chair-back to the velcro on the bottom of the chair base.




Step4 Anti-back-tipping Part Assembly

1. Place the Anti-back-tipping parts (F) near the bottom of base.
2. Align the screws with the holes then tighten the wing screws (Figure).



Step5 Final Check

1. Make sure both metal brackets on each armrest are mounted on the base.
(There are two metal brackets on each side of the base, it looks like assembly finished when you insert armrest into only one bracket instead of two, however all pressure will apply to one bracket, that is one likely reason that the armrest fall apart from the seat.)
2. Make sure the backrest inserts are locked to the base.
(Pull up the backrest to check if it is locked in place.)
3. Make sure all wires are connected tightly.
4. Make sure all wires not placed the bottom of the rack and will not be pressed by frame.
(If the wire is pressed by the frame, the wire will be broken by the frame and the chair will stop working.)
5. Make sure the anti-tilt fitting screws are tightened.






III. DISASSEMBLY INSTRUCTIONS

Notice

1. Ensure the chair is in seated position and its footrest return to original position.
2. Please unplug the power cord before disassembling.
3. Please refer to the installation steps from back to front and disassemble the chair in reverse order.

Step1 Disassemble Backrest

1. Pushing the metal ears of the backrest inserts outward (Refer to arrow direction).
2. After unlocking the metal lugs on both sides of the backrest, hold the bottom part of the backrest marked in the picture below and pull it vertically upward.




Step2 Disassemble Armrest


NOTE:

1. Need to remove the backrest first.
2. It is best to remove armrest by two people.
3. When lifting the armrest, be sure to hold the bottom of the armrest to avoid damaging the handrail bag and cup holder.

1. Use your knees to find a support point on the seat and press on the base with your own strength.
2. Hold the two marked positions at the bottom of the armrest and lift the armrest vertically upward.(Refer to arrow direction and the circular marking area.)



ATTENTION



Shake the armrest slightly to loosen the brackets, make it easier to detach from the base.

IV. OPERATING INSTRUCTIONS

Operation Precautions

1. Do not use an extension cord.
2. Do not exceed recommended weight limit.
3. Do not use attachments not recommended by the manufacturer.
4. Do not use outdoors. INDOOR USE ONLY.
5. Stay away the backrest from wall at least **15.7** inches before using.
6. Use this lift only for its intended use as described in the operating.
7. Keep dry. Do not operate in a wet or moist environment.
8. Keep all cords away from heated surfaces and pinch points.
9. Ensure the hand control is out of the way before sitting in the chair.
10. Always leave the lift chair in an upright and closed position when not in use.
11. Periodically check the hand control and all power cords for visible damage.
12. Do not use the footrest as a seat, or for purposes outside its intended use.
13. Do not lean or apply downward force to the chair-back while in recline position.

NOTE: If you discover a problem at any point during the setup and positioning of your lift chair, stop and contact the Mcombo Customer Support immediately. To avoid personal injury and/or product damage, do not plug the unit into the electrical outlet until the problem is corrected and do not attempt to fix electrical problems by yourself.


Lift Operation Instruction

^ LIFT (UP)

Press and hold the UP button to raise the chair to the full-lift position.
Press and hold the UP button to return to the seated position from the reclined position.

∨ LIFT (DOWN)

Press and hold the DOWN button to lower the chair to the seated position.
Press and hold the DOWN button to raise the footrest and recline the chair back.



V. TROUBLESHOOTING


The following troubleshooting FAQs should summarize what you need to know about your lift chair. If at any time you do not feel comfortable performing the troubleshooting steps listed in this manual, please contact Mcombo Customer Support for service.

Questions	Answers
What if my lift chair does not operate at all?	• Make sure all the connections at the bottom of the chair are secured; refer to the Assembly Instructions. • Check all the electrical cords are not crimped or pinched. Make sure the light of the lift remote goes on. • Check if the light of the RED button at the back of the base is on. • Turn the chair over and check the GREEN light on the power box at the bottom is on.
What if the USB charge ports do not work?	• Turn the chair over and check the GREEN light on the power box at the bottom is on. • Make sure the USB cable coming out of the right armrest is properly connected to the connecting box behind the bottom of the chair; refer to the Step 3 lift connection in the "Assembly Instructions".
What if my lift chair is wobbly?	• Check the base of chair to make sure all the rubber seat retainers are not broken. • Make sure the armrests are installed tightly; refer to the Assembly Instructions.

Questions	Answers
What if the armrest falls apart from seat?	• Ensure the two connections on each armrest are all inserted onto the seat tightly. • Check the brackets of armrest and base to ensure there is no defects.
What if my lift chair makes a clicking noise?	• Check the lift motor and make sure the end of lift motor at the center of pivot point. • Make sure the weight capacity of 320 lbs has not been exceeded.
What if my lift chair tilted to one side?	• Check the brackets of backrest are installed into seat tightly. • Make sure the rack of lift chair is in a good condition without any distortion. • Use lift chair on the flat carpet, not smooth floor.
What if the remote is very hot?	• Check all wiring harnesses to make sure they are not damaged or frayed. • If all cords are in a good condition, please unplug the remote and cool it for a while before using it. • If there is a burning smell, unplug the remote and contact Mcombo support to replacement.
Can I add a battery backup for my lift chair?	• For safety, we do not recommend adding any battery backup for Mcombo lift chair.
IMPORTANT: If the lift recliner still does not operate properly, please contact the Mcombo® Customer Support for help and never attempt to make any repairs or adjustments yourself.	


Lift Motor Replacement:

NOTE:




- 1. Take an original bottom picture for reference before disassembling.
- 2. The disassembled small parts need to be put away to prevent falling into the rack.

Step1 Turn the Chair to the Left




First turn the chair to the left, the right armrest is upward, be careful not to break the wire of USB charge ports.


Step2 Remove Bolts




(1) The original position of the paper clip




(2) Twist the paper clip





(3) Pull out the paper clip



(4) Pull out the bolt





Step3 Remove Old Lift Motor



Repeat "Step 2" with the other end of the lift motor.


Step4 Replace the New Lift Motor




Replace the new lift motor.

NOTE: Please note that the motor of the lift motor is facing ground, be careful not to install it backwards, otherwise the lift motor will break.


Step5 Install Bolts



Insert bolts and paper clips at both ends of the lift motor.




(1) Insert the bolt



(2) Insert the paperclip

Step6 Final Check



Check & Confirm

- (1) Make sure bolts and paper clips are fully inserted.
- (2) Make sure the lift motor is installed in the correct direction.
- (3) Make sure the wires are not crushed by the seat frame.

VI. WARRANTY

Lift/Reclining Mechanism	1 Year
Upholstery Material	1 Year
Metal/ Wood Chair Frame	1 Year
Electronic Parts	1 Year

LIMITATIONS APPLICABLE TO ALL WARRANTIES

All warranties begin on the date of delivery.

All warranties are to the original purchaser from EXACME/MCOMBO® ONLY.

- EXACME/MCOMBO® will replace the defective parts or send replacement chair provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.

- Exclusions also include components with damage caused by:
 - Contamination
 - Abuse, misuse, accident, or negligence
 - Commercial use, or use other than normal
 - Improper operation, maintenance, or storage

EXACME/MCOMBO® will pay standard shipping rates on all warranted parts for the first year. We can also sell you replacement part for a discount price when your chair is out of warranty policy.

NOTE: For lift chair beyond the limited manufacturer warranty period and scope, Mcombo can also provide replacement service, but a basic charge will be charged according to the circumstances.

VII. RETURN/REPLACEMENT POLICY

EXACME/MCOMBO®

All of lift recliners come with a 30-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged chair, through providing pre-paid return label or pick-up service for customer convenience.

NOTE:

- (1) Please disassemble the chair before you return it, otherwise there will be a huge cost as oversized and it could even exceed your order amount.
- (2) Please do not purchase return label for a damaged/defective chair by yourself.
- (3) If you have any problem to return the chair, please contact us immediately, we will do our best to help you with a reasonable solution.

EXACME/MCOMBO® is not responsible for the returns that customer bought by mistake, changed their mind or other non-quality issues.

NOTE:

The customer is responsible for freight costs unless the chair is defective. Chairs returned due to being refused delivery by the customer or deemed undeliverable by freight carrier are subject to fees for a 20% restocking fee.

Why don't we recommend returning the item by yourself?

- Huge cost
- Need you to take the box to UPS facility

VIII. CARE AND MAINTENANCE

Your Mcombo® power lift chair will provide years of superior performance and satisfaction with regular care and maintenance. To maintain the finish quality of your “assistant”, please follow the guidelines and cleaning procedures provided below.

NOTE:

- Do not place your chair in direct sunlight, as sunlight causes fading.
- Do not smoke cigarettes while seated in or using your chair.
- Avoid extreme changes in temperature by arranging chair away from radiators, heat and air vents.

- Do not use solvent-type cleaners to spot clean.
- Do not saturate fabric.
- Please be careful that pet scratch may cause fabric or leather break.

Fabric Care

- Inspect the fabric on a regular basis for any pulls, tears, or gaps.
- Frequent vacuuming or light brushing with a nonmetallic, stiff bristle brush to remove dust and grime is recommended.
- When liquid spills onto the fabric, please immediately wipe off liquid spills with a dry or lightly dampened clean white cloth, sponge, or paper towel.

Faux Leather Care

- Wipe leather down regularly with a clean, dry microfiber cloth.
- For more stubborn dust, dampen the cloth with distilled water. Make sure that the cloth is not soaking wet. Never let water soak into leather.
- Always be sure to use a soft cloth and never use an abrasive brush or scrubber as this can scratch and damage the leather.

Electronics Care

- Inspect all wiring harnesses to make sure they are not damaged or stuck under chair.
- Keep all the electronics free from moisture and temperature extremes.
- Check electrical components frequently for signs of corrosion and replace as necessary.
- Contact Mcombo Customer Support if damage is present, do not fix it by yourself.

Disposal & Recycling

Your lift chair must be disposed of according to applicable local and national statutory disposal regulations. Contact your local waste disposal agency for information on proper disposal of lift chair packaging, metal/wood frame components, fabric, electronic components.

IX. MCOMBO CUSTOMER SUPPORT

If for any reason, we have fallen short of your expectations, or if you have any questions and suggests, please refer to the following contact information, we will do our best to work with you to make sure you are entirely satisfied.

	1-323-597-1109 1-877-608-0775
	sales@mcombo.com (Respond within 24 hours)
	2411 Bear Corbitt Rd STE 1 New Castle, DE, 19720
	2808 Vail Ave Commerce, CA, 90040

CUSTOM-MADE SERVICE

Do you have any specified requirements for chair size, color, style, material or some more?
Do not hesitate to contact us if any questions. We would be glad to provide you personalized service and products to meet all your needs.

X. FEEDBACK

Mcombo is dedicated to providing premium products for customers, we believe listening to customers is the way to create great products.
We'd love to hear your feedback regarding our products.

Purchase from: Amazon ☐ Wayfair ☐ Walmart ☐ other _____

Your Name: _____ **E-mail:** _____

Item Model: _____ **Order ID:** _____

Date of installation: _____-_____-_____

Easy to assemble					
Comfort					
Support					
Value for money					

LET US KNOW...

Date: _____-_____-_____

TIP: Take a picture of this page and send to us via email (sales@mcombo.com). We will reply to you within 24 hours.