

Shark
ROTATOR[®]
POWERED LIFT-AWAY

NV650/750
Series

INSTRUCTIONS

INSTRUCCIONES

PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.
This Owner's Guide is designed to help you get a complete understanding of your new Shark Rotator Powered Lift-Away Upright Vacuum.

SharkNinja Operating LLC
US: Newton, MA 02459
CAN: Ville St-Laurent, QC H4S 1A7
Illustrations may differ from actual product.
Shark, Rotator and Lift-Away are registered trademarks of SharkNinja Operating LLC.
For SharkNinja U.S. Patent information, visit sharkninja.com/USPatents.



IMPORTANT SAFETY INSTRUCTIONS
FOR HOUSEHOLD USE ONLY

⚠ WARNING

To reduce the risk of injury, fire, electric shock, and property damage resulting from improper use of the appliance, carefully observe the following instructions. This unit contains electrical connections and moving parts that potentially present risk to the user.

THE MOTORIZED FLOOR NOZZLE, WAND, AND HANDLE CONTAIN ELECTRICAL CONNECTIONS:

- These are not serviceable parts.
- Do not use to vacuum any liquids.
- Do not immerse in water.
- If handle/wand is damaged, discontinue use.

1. Inspect power cord or plug for any damage before use. DO NOT use vacuum cleaner with a damaged cord or plug. Turn off all controls before plugging or unplugging the vacuum cleaner. Store your vacuum cleaner with the power cord secured around the two cord hooks.
2. DO NOT use outdoors or on wet surfaces. Use only on dry surfaces.
3. Unplug from electrical outlet when not in use and before servicing.
4. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, call a service center.
5. The hose contains electric wires. DO NOT use when damaged, cut, or punctured.
6. DO NOT pull or carry vacuum cleaner by the cord or use the cord as a handle.
7. DO NOT unplug by pulling on cord. Grasp the plug, not the cord.
8. DO NOT handle plug or vacuum cleaner with wet hands.

9. DO NOT run the vacuum cleaner over the power cord, close a door on the cord, or pull cord around sharp corners.
10. The use of an extension cord is NOT recommended.
11. DO NOT leave vacuum cleaner unattended when plugged in.
12. Keep cord away from heated surfaces.
13. Always turn off the vacuum cleaner before connecting or disconnecting motorized nozzle.

GENERAL USE

14. Use only as described in this manual.
15. Keep your work area well lit.
16. Keep the vacuum cleaner moving over the carpet surface at all times to avoid damaging the carpet fibers.
17. DO NOT place vacuum cleaner on unstable surfaces such as chairs or tables.
18. DO NOT put any objects into openings. DO NOT use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
19. DO NOT allow the appliance to be used by children. Close attention is necessary when used near children. This is not a toy.
20. DO NOT use without dust cup and/or filters in place.

DUST CUP/FILTERS/ACCESORIES

Before turning on the vacuum:

21. Make sure that all filters are thoroughly dry after routine cleaning.
22. Make sure that dust cup and all filters are in place after routine maintenance.
23. Make sure accessories are free of blockages.
24. Only use Shark-brand filters and accessories (failure to do so will void the warranty).

HOSE ATTACHMENTS

25. DO NOT use if airflow is restricted; if the air paths or the motorized floor nozzle become blocked, turn the vacuum cleaner off and unplug from electrical outlet. Remove all obstructions before you turn on the unit again.
26. Keep the end of the hose and accessory openings away from face and body.
27. Keep cleaning tools and hose suction openings away from hair, face, fingers, uncovered feet, or loose clothing.
28. Only use manufacturer's recommended attachments.

GENERAL CLEANING

29. DO NOT pick up large-sized objects.
30. DO NOT pick up hard or sharp objects such as glass, nails, screws, or coins that could damage the vacuum cleaner.

31. DO NOT use to pick up drywall dust, fireplace ash, or embers. Do not use as an attachment to power tools for dust collection.
32. DO NOT pick up smoking or burning objects such as hot coals, cigarette butts, or matches.
33. DO NOT pick up flammable or combustible materials (e.g., lighter fluid, gasoline, or kerosene) or use vacuum in areas where they may be present.
34. DO NOT pick up toxic solutions (e.g., chlorine bleach, ammonia, or drain cleaner).
35. DO NOT use in an enclosed space where vapors are present from paint, paint thinner, moth-proofing substances, flammable dust, or other explosive or toxic materials.
36. DO NOT vacuum up any liquids.
37. DO NOT immerse vacuum cleaner in water or other liquids.
38. Use extra care when cleaning on stairs.

POLARIZED PLUG

To reduce the risk of electric shock, this vacuum cleaner has a polarized plug (one blade is wider than the other). As a safety feature, the plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT force into outlet or try to modify to fit.


GETTING TO KNOW YOUR SHARK[®] ROTATOR[®] POWERED LIFT-AWAY[™] UPRIGHT VACUUM

WELCOME!

Congratulations on your purchase. Use this instruction manual to learn about your new vacuum's great features. From assembly to use to maintenance, you will find it all in here.

MAIN UNIT

- A. Suction Selector
- B. Power Button
- C. Hose
- D. Handle Release Button
- E. Hose Clip
- F. Upper Cord Hook
- G. Lift-Away Button
- H. Wand Release Lifter
- I. Lift-Away Pod
- J. Wand
- K. Lower Cord Hook
- L. Motorized Floor Nozzle
- M. Brushroll Indicator Light
- N. Headlight



ASSEMBLING YOUR VACUUM

TIP: Slide hose clip into back of wand for convenience.



TIP: For quick cord access, rotate upper hook down and remove cord.



TIP: To store your vacuum, wrap cord around cord hooks.



STEP 1



1. Place selected floor nozzle on floor and insert wand.

STEP 2



2. Insert handle into wand.

STEP 3



3. Place pod onto wand and slide down to connect.

STEP 4



4. Connect hose into back of pod until you hear a click.

STEP 5



5. Place tools on their accessory posts.

USING YOUR VACUUM IN UPRIGHT MODE

⚠ WARNING: DO NOT use to pick up drywall dust, fireplace ash, or embers. DO NOT use as an attachment to power tools for dust collection.

WHAT DOES THE BRUSHROLL INDICATOR LIGHT MEAN?

Solid Green

The brushroll is on and working as it should.

Solid Red

There is a jam in the brushroll area. Turn your vacuum off and remove the blockage.

Flashing Red*

The motorized floor nozzle is overheating. Turn your vacuum off and wait for it to cool down. Next time you are vacuuming that surface, try opening the Suction Control.

No Light

The brushroll is off because the vacuum is in Hard Floor mode.



*See Troubleshooting section for further instructions.

STEP 1



1. Plug power cord into outlet. Place foot on floor nozzle and tilt handle back.

STEP 2



2. Choose the appropriate setting.
Thick Carpet & Area Rug Cleaning
Set floor selector to Carpet.
Carpet & Low Pile Cleaning
Set floor selector to Carpet/Low Pile.
Hard Floor Cleaning
Set floor selector to Hard Floor.
NOTE: For deep cleaning pet odors, set floor selector to Carpet/Low Pile.


STEP 3



3. Press power button to turn vacuum on to start cleaning. The brushroll will not spin unless the wand is locked.


USING YOUR VACUUM IN ABOVE-FLOOR MODE

STEP 1



1. Press the Handle button when you need to clean within short reach. **OR** Press the Wand Release button when you need to clean with a longer reach.

STEP 2



2. Insert desired tool directly into wand or handle.

Note: Accessories may vary depending on model.

The Quick Start guide shows the select accessories that are included with your model.

CHANGING YOUR FLOOR NOZZLES

If your vacuum comes with a Dust-Away[™] Hard Floor Attachment, use these instructions.



Motorized Floor Nozzle

Use the motorized floor nozzle for deep-cleaning carpets and picking up large debris on hard floors.



Dust-Away Hard Floor Attachment

Use the Dust-Away Hard Floor Attachment to pick up debris and wipe away fine dust on hard floors.

★ IMPORTANT: Do not use the Dust-Away Hard Floor Attachment without the microfiber pad attached.

STEP 1



1. Press Lift-Away[®] button to lift pod off motorized floor nozzle.

STEP 2



2. Press Wand Release button to remove wand from motorized floor nozzle.


STEP 3



3. Insert wand into the Dust-Away[™] Hard Floor Attachment. Hold pod in hand to clean in Lift-Away[®] mode. You cannot use the Dust-Away Hard Floor Attachment in regular upright mode.

USING YOUR VACUUM IN LIFT-AWAY® MODE

WARNING: Ensure solid footing when using in Lift-Away mode. Using for an application where you lack stability may result in personal injury.



LIFT-AWAY CLEANING

- 1 Press Lift-Away button to lift pod off motorized floor nozzle. You are now ready to clean those hard-to-reach places.



- 2 Attach desired accessory directly into handle. You can also attach the accessory to the wand for extended reach.

TROUBLESHOOTING GUIDE

WARNING: To reduce the risk of shock and unintended operation, turn power off and unplug unit before servicing.

Vacuum is not picking up debris. No suction or light suction.
(Refer to Maintenance section for more information.)

- Check filters to see if they need cleaning. Follow instructions for rinsing and drying the filters before reinserting in the vacuum.
- Dust cup may be full; empty dust cup.
- Check hose, hose connections, nozzles, and accessories for blockages; clear blockages if required.
- Remove any string, carpet fibers, or hair that may be wrapped around the brushroll.

Vacuum lifts area rugs.

- Turn off unit to disengage the brushroll. Move switch to Hard Floor setting for suction-only cleaning, and turn unit back on.
- Suction is powerful. Take care when vacuuming area rugs or rugs with delicately sewn edges.

Brushroll does not spin.

- If Brushroll Indicator Light on the motorized floor nozzle turns red, the brushroll has stopped spinning. Immediately turn off and unplug vacuum, disconnect the nozzle, and remove blockage before reconnecting and turning vacuum back on.
- With the power on, recline the handle, which will automatically turn on the brushroll.
- Make sure the carpet height selector is not set to Hard Floor.

Vacuum turns off on its own or indicator light flashes red.

- This vacuum is equipped with a motor-protective thermostat. If your vacuum overheats, the thermostat will automatically turn the suction motor off. Perform the following steps to restart the thermostat:
 - 1. Turn vacuum off and unplug it.
 - 2. Empty dust cup and clean filters (see Maintenance section).
 - 3. Check for blockages in hose, accessories, and inlet openings.
 - 4. Allow unit to cool for a minimum of 45 minutes.
 - 5. Plug in vacuum and turn it on.
- If hose is not fully connected to the pod, it can cause a poor electrical connection and the hose can come loose, turning the vacuum off.
 - 1. Turn vacuum off and unplug it.
 - 2. Empty dust cup and clean filters.
 - 3. Check for blockages in hose, accessories, and inlet openings.
 - 4. Remove cord from cord hook so hose latch can be seen and engaged.
 - 5. Ensure you hear an audible click at all connection points:
 - a. Where hose meets back of pod (may require additional force; pull on hose to ensure latch is fully engaged)
 - b. Where wand plugs into floor nozzle
 - c. Where handle plugs into wand
 - 6. Plug in vacuum and turn it on.

TECHNICAL SPECIFICATIONS

Voltage: 120V, 60Hz

MAINTENANCE

To keep your vacuum safe for power, unplug it from the power outlet. Follow these instructions. Make sure unit is off and cord is unplugged.

WARNING: To reduce the risk of shock and unintended operation, turn power off and unplug unit before servicing.

Hand wash filters with water only to prevent damage from cleaning chemicals. Allow ALL filters to dry completely before replacing in the vacuum to prevent liquid from being drawn into electric parts.

IMPORTANT: Do not use soap or detergent on the HEPA filter.

RECOMMENDED FILTER CLEANING SCHEDULE:

Pre-Motor Filter Kit
Foam & HEPA
Wash with water
Clean every 3 months

Post-Motor Filter
(HEPA)
Wash with water
Clean every 6 months

STEP 1



EMPTYING THE DUST CUP

- 1 Pull up on dust cup release latch and the dust cup will pop out.
- 2 Flick dust cup over a lower surface and use the empty release latch on the bottom.

STEP 2



STEP 3



CLEANING THE FILTERS

- 1 **Pre-Motor (foam and felt)** With the dust cup removed, take out and rinse the foam and felt filter with water. Do a deep clean of the felt between washes as needed.
- 2 **Post-Motor (HEPA)** To clean the HEPA filter, remove the filter and pull the Filter-Away release latch on the side. Remove and rinse the filter.



WARNING: To reduce the risk of shock and unintended operation, turn power off and unplug unit before servicing.

TIP: You do not need any tools to open the motorized floor nozzle. Just a coin.

STEP 1



CHECKING FOR BLOCKAGES & MAINTAINING BRUSHROLL

- 1 Push down on brushroll release latch on the bottom of the floor nozzle.

STEP 2



STEP 3



STEP 4



- 2 A portion of the base is lifted for better access to the brushroll and approach to the entry. Shine a flashlight from the bottom of the base to check for blockages.
- 3 Remove any hair, fibers, or debris that are wrapped around the brushroll. There is a groove that allows a pair of pliers to grab and pull out debris.
- 4 If reasonable, rotate base by lifting it up along the front of the motorized floor nozzle. Rotate closed and look the 3 locks.

