



5713248141_01_0620

ECAM35075

FULLY AUTOMATIC ESPRESSO AND COFFEE MACHINE

Instructions for use. Keep these instructions
Visit www.delonghi.com for a list of service
centers near you.
ELECTRIC CHARACTERISTICS
120 V~ 60 Hz 1250 W

MACHINE À CAFÉ


Mode d'emploi . Conservez cette notice Visitez www.delonghi.com pour y voir une liste des centres de réparation proches de chez vous. CARACTÉRISTIQUES ÉLECTRIQUES 120 V~ 60 HZ 1250 W


CAFETERA

Repase y guarde estas instrucciones.
Lea cuidadosamente este instructivo antes de
usar su aparato.
Visite www.delonghi.com para ver la lista de
centros de servicios cercanos a usted.
CARACTERISTICAS ELECTRICAS:
120 V~ 60 HZ 1250 W









| 1.1 1.2 1.3 INTR 2.1 2.2 DESC 3.1 3.2 3.3 3.4 BEFC 4.1 4.2 4.3 4.4 TURN TURN TURN 7.1 7.2 7.3 7.4 7.5 | Letters in brackets |
|---|--|
| 1.2 1.3 INTR 2.1 2.2 DESC 3.1 3.2 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Designated use |
| 1.3 INTR 2.1 2.2 DESC 3.1 3.2 3.3 3.4 BEFC 4.1 4.2 4.3 4.4 TURN TURN TURN 7.1 7.2 7.3 7.4 7.5 | User manual |
| INTR 2.1 2.2 DESC 3.1 3.2 3.3 3.4 BEFC 4.1 4.2 4.3 4.4 TURN TURN MEN 7.1 7.2 7.3 7.4 7.5 | ODUCTION |
| 2.1 2.2 DESC 3.1 3.2 3.3 3.4 BEFC 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Letters in brackets |
| 2.2 DESC 3.1 3.2 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Troubleshooting and repairs |
| DESC 3.1 3.2 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | RIPTION |
| 3.1 3.2 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Description of the appliance |
| 3.2 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Description of the touch screen |
| 3.3 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Description of the accessories7 Description of the milk container7 PRE USE7 |
| 3.4 BEFO 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | Description of the milk container7 |
| 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | PRE USE |
| 4.1 4.2 4.3 4.4 TURN TURN 7.1 7.2 7.3 7.4 7.5 | |
| 4.2 4.3 4.4 TURN TURN MEN 7.1 7.2 7.3 7.4 7.5 | |
| 4.3 4.4 TURN TURN MEN 7.1 7.2 7.3 7.4 7.5 | Checking the appliance7 |
| 4.4 TURN TURN MEN 7.1 7.2 7.3 7.4 7.5 | Installing the appliance7 |
| TURN TURN MEN 7.1 7.2 7.3 7.4 7.5 | Connecting the appliance7 |
| TURN MEN 7.1 7.2 7.3 7.4 7.5 | Setting up the appliance7 |
| MEN 7.1 7.2 7.3 7.4 7.5 | NING THE MACHINE ON |
| 7.1 7.2 7.3 7.4 7.5 | NING THE APPLIANCE OFF |
| 7.1 7.2 7.3 7.4 7.5 | U SETTINGS |
| 7.2 7.3 7.4 7.5 | Language9 |
| 7.4 7.5 | Maintenance9 |
| 7.5 | Program beverages9 |
| | Program My beverages9 |
| 7.6 | General9 |
| | Statistics10 |
| RINS | ING 1 |
| MΔK | ING COFFEE 1 |
| | Adjusting the coffee grinder11 |
| | Tips for a hotter coffee11 |
| | Making automatic recipes using coffee beans . |
| | 11 |
| 9.4 | Temporarily varying the coffee aroma12 |
| | Making coffee using pre-ground coffee12 |
| TRUE | BREW OVER ICE™ COFFEE |
| | ING MILK-BASED RECIPES |
| | Filling and attaching the milk container13 |
| | Adjusting the amount of froth14 |
| | Making cappuccino and milk-based coffees |
| | automatically14 |
| | Cleaning the milk container after use14 |
| | MENU" PROGRAMMING AND SELECTING |
| \sim | INITIAL LUCALININININA WIND SELECTING |
| DELI | |

| 14. | CLE | ANING | 15 |
|-----|-------|--|----|
| | 14.1 | Cleaning the machine15 | |
| | 14.2 | Cleaning the machine's internal circuit15 | |
| | 14.3 | Cleaning the coffee grounds container16 | |
| | 14.4 | Cleaning the drip tray and condensate tray .16 | |
| | 14.5 | Cleaning the inside of the coffee machine16 | |
| | 14.6 | Cleaning the water tank16 | |
| | 14.7 | Cleaning the coffee spouts17 | |
| | 14.8 | Cleaning the pre-ground coffee funnel17 | |
| | 14.9 | Cleaning the infuser17 | |
| | 14.10 | OCleaning the milk container17 | |
| | 14.1 | I Cleaning the hot water nozzle18 | |
| 15. | DES | CALING | 18 |
| 16. | SET1 | TING WATER HARDNESS | 19 |
| | 16.1 | Measuring water hardness19 | |
| | | Setting water hardness19 | |
| 17. | WAT | ER SOFTENER FILTER | 19 |
| | 17.1 | Installing the filter19 | |
| | 17.2 | Replacing the filter20 | |
| | 17.3 | Removing the filter20 | |
| 18. | DISF | PLAYED MESSAGES | 21 |
| 19 | TRO | UBLESHOOTING | 23 |
| | 1110 | VPENIIVVIIII | 23 |
| | | | |

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following.

- Read all instructions carefully.
- Make sure the voltage of your electrical system corresponds to the voltage shown on the bottom of the machine.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electrical shock and personal injury, do not immerse cord, plug or appliance in water or other liquid.
- Keep the appliance out of the reach of children and do not leave appliance unattended while in operation.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by the manufacturer may result in fire, electrical shock, or personal injury.
- Do not use outdoors.
- Make sure the power cord does not hang over the edge of the table or counter-top to avoid getting accidentally caught or entangled.
- Do not place the appliance or its electrical parts on or near electric stoves, cooking surfaces, or gas burners.
- Plug cord into the wall outlet. To disconnect, first turn machine "off", then remove plug from wall outlet.
- Do not use the appliance for other than the intended use. This appliance is to be utilized for domestic use only. The manufacturer declines all responsibility for any damage caused by improper, incorrect, or irresponsible use.

WARNING: To reduce the risk of fire or electric shock, do not remove the cover or the exterior of the unit. Don't attempt to repair or modify the machine, doing so will void the warranty. Repair should be done by authorized service personnel only!

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

SHORT CORD INSTRUCTIONS

- A short power cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer, detachable power supply cords or extension cords are available and may be used if care is exercised in their use.
- If an extension cord is used, the marked electrical rating should be at least as great as the electrical rating of the appliance. If the appliance is provided with 3- wire, grounding type cord, the extension should be a GROUNDING TYPE 3 WIRE CORD. The longer cord should be arranged so that it will not drape over the counter-top or table top where it can be pulled on by children or tripped over.
- Your product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

SAFETY WARNINGS

Symbols used in these instructions 1.1

Important warnings are identified by these symbols. It is vital to respect these warnings.



Failure to observe the warning may result in life threatening injury by electric shock.



Important!

Failure to observe the warning could result in injury or damage to the appliance.



Failure to observe the warning could result in scalds or burns.



i Please note:

This symbol identifies important advice or information for the user.



This is an electrical appliance and may cause electric shock. You should therefore follow these safety warnings:

- Never touch the appliance with damp hands or feet.
- Never touch the plug with damp hands.
- Make sure the socket used is freely accessible at all times, enabling the appliance to be unplugged when necessary.
- Unplug directly from the plug only. Never pull the cord as you could damage it.
- To disconnect the appliance completely you must unplug it from the mains socket.
- If the appliance is faulty, do not attempt to repair. Turn it off, unplug from the mains socket and contact Customer Services.
- Before cleaning the appliance, turn it off, unplug from the mains socket and allow to cool.



\ Important:

Keep all packaging (plastic bags, polystyrene foam) away from children.



____ Danger of burns!

This appliance produces hot water and steam may form while it is in operation.

Avoid contact with splashes of water or hot steam.

When the appliance is in operation, the cup shelf could become very hot.

1.2 Designated use

This appliance is designed and made to prepare coffee and heat beverages.

Any other use is considered improper and thus dangerous. The manufacturer is not liable for damage deriving from improper use of the appliance.

1.3 **User manual**

Read this Instruction for Use carefully before using the appliance. Failure to follow this Instruction for Use may result in burns or damage to the appliance.

The manufacturer is not liable for damage deriving from failure to respect this Instruction for Use.



Please note:

Keep this Instruction for Use.

INTRODUCTION

Thank you for choosing this fully automatic espresso machine. We hope you enjoy using your new appliance. Take a few minutes to read this Instruction for Use. This will avoid all risks and damage to the appliance.

2.1 Letters in brackets

The letters in brackets refer to the legend in the description of the appliance on pages 2-3.

2.2 Troubleshooting and repairs

In the event of problems, first try and resolve them by reading the information given in sections "18. Displayed messages" and "19. Troubleshooting".

If this does not resolve the problem or you require further information, you should consult Customer Services by calling the number given on the warranty card.

DESCRIPTION

Description of the appliance 3.1

(page 2 - A)

- Beans container lid A1.
- A2. Pre-ground coffee funnel lid
- A3. Beans container
- A4. Pre-ground coffee funnel
- Grinding adjustment dial A5.
- A6. Cup shelf
- (1) button: to turn the appliance on and off (standby) A7.
- A8. Hot water and steam connection nozzle
- Coffee spouts (adjustable height)
- A10. Condensate tray
- A11. Coffee grounds container
- A12. Cup tray
- A13. Drip tray water level indicator
- A14. Drip tray grille
- A15. Drip tray
- A16. Water tank lid
- A17. Water tank
- A18. Water softener filter housing

- A19. Infuser door
- A20. Infuser
- A21. Power cord
- A22. Main switch

Description of the touch screen 3.2

(page 3 - B)

A number of buttons on the panel have a dual function. This is indicated in brackets in the description.

- B1. Display: guides the user in using the appliance. The current selection is at the center between two dotted lines.
- B2. \(\neg \) Selection arrow("ESC": when programming beverages, *press to exit without saving the change)*
- B3. **OK**: to confirm the selection(*During the first few seconds of* "espresso", "ristretto" or "Lungo" delivery, press for 2 cups)
- B4. A Selection arrow("STOP" When delivering/programming beverages, press to interrupt/programme)
- B5. **3**/ESC: to perform a rinse cycle. (When in the settings menu, it acts as the "ESC" button to exit from the selected function and go back to the main menu)
- B6. appliance settings menu
- B7. **1** aroma selection

Directly selected beverages:

- B8. ☐: Espresso
- B9. TrueBrew Over Ice (TM) Coffee
- B10. : Long
- B11. 🗇 : Cappuccino
- B12. 🖃: Latte
- B13. The Hot Milk
- B14. DRINK: Select additional beverages available from the Drink Menu: Lungo, Ristretto, Double Espresso+, Cappuccino+, Cappuccino Mix, Latte Macchiato, Flat White, Espresso Macchiato, 2 Espresso, 2 Ristretto, 2 Lungo, Hot Water
- B15. (my) MENU: Customize and select recipes from the My Menu. Beverages on the My Menu are automatically set to default settings, until customized.

3.3 **Description of the accessories**

(page 3 - C)

- C1. Water hardness indicator paper
- C2. Pre-ground coffee measure
- C3. Descaler
- C4. Water softener filter (certain models only)
- C5. Cleaning brush
- C6. Hot water spout

3.4 Description of the milk container

(page 3 - D)

- D1. Froth adjustment and CLEAN dial
- D2. Milk container lid

- D3. Milk container
- D4. Milk intake tube
- D5. Frothed milk spout (adjustable)

BEFORE USE

Checking the appliance

After removing the packaging, make sure the product is complete and undamaged and that all accessories (C) are present. Do not use the appliance if it is visibly damaged. Contact De'Longhi Customer Services.

4.2 Installing the appliance



\ Important!

When you install the appliance, you should respect the following safety warnings:

- The machine gives off heat. After positioning the machine on the worktop, leave a space of at least 1.18 in / 3 cm between the surfaces of the machine and the side and rear walls and at least 5.6 in / 15 cm above the coffee maker.
- Water penetrating the machine could cause damage. Do not place the appliance near taps or sinks.
- The appliance could be damaged if the water it contains freezes.
 - Do not install the appliance in a room where the temperature could drop below freezing point.
- Arrange the cord (C7) in such a way that it cannot be damaged by sharp edges or come with contact with hot surfaces (e.g. electric hot plates).

Connecting the appliance



/!\ Important!

Check that the mains power supply voltage corresponds to that indicated on the rating plate on the bottom of the appliance. Connect the appliance to an efficiently earthed and correctly installed socket with a minimum current rating of 10A only. If the power socket does not match the plug on the appliance, have the socket replaced with a suitable type by a qualified professional.


4.4 Setting up the appliance



Please note:


- Coffee has been used to factory test the appliance and it is therefore completely normal for there to be traces of coffee in the grinder. The machine is, however, guaranteed to be new.
- You should customise water hardness as soon as possible following the instructions in section "16.2 Setting water hardness".


1. Plug the machine into the mains socket and press the main switch (fig. 1). Make sure the main switch (A22) at the back of the appliance is pressed (fig. 2);



The following messages will show on the display (B1):

- "Language": press the selection arrow (B2) until the required language is displayed between the two dotted lines, then press **OK** (B3) to confirm.
- "Fill tank": remove the water tank (A17), fill to the MAX line with fresh water (fig. 3A), then place back in machine (fig. 3B);





- "Insert water spout": Check that the hot water spout (C6) is inserted on the connection nozzle (A8) (fig. 4) and place a container holding a minimum of 3.38 floz/100 ml underneath (fig. 5);
- "Water circuit empty, Fill water circuit, Hot water, Confirm?";
 - Press the **OK** button to confirm. The appli-

ance delivers hot water from the spout then goes off automatically.

The coffee machine is now ready for normal use.



i Please note:

- The first time you use the machine, you need to make 4-5 cappuccinos before it starts to give optimal results.
- To enjoy your coffee even more and improve the performance of your appliance, we recommend installing a water softener filter (C4) as described in section "17. Water softener filter".

TURNING THE MACHINE ON



Please note:

Before turning the appliance on, make sure the main switch (A22) on the back of the appliance is pressed (fig. 2).

Each time the appliance is turned on, it performs an automatic preheat and rinse cycle which cannot be interrupted. The appliance is ready for use only after completion of this cycle.

\angle Danger of burns!

During rinsing, hot water comes out of the coffee spouts (A9) and is collected in the drip tray (A15) underneath. Avoid contact with splashes of water.



To turn the appliance on, press the button (A7) (fig. 6). The message "Heating Please wait" appears on the display (B1).

After heating, the message "Rinsing" is displayed, together with a progress bar which gradually fills as preparation proceeds. As well as heating the boiler, the appliance also

heats the internal circuits by circulating hot water.

The appliance is ready when the message "Select your beverage" is displayed.

TURNING THE APPLIANCE OFF

Whenever the machine is turned off after being used to make espresso or coffee, it performs an automatic rinse cycle.



$\angle^{\underline{w}}$ Danger of burns!

During rinsing, hot water flows from the coffee spouts (A9). Avoid contact with splashes of water.

To turn the appliance off, press the () button (A7) (fig.

• The message "Turning off underway Please wait" appears on the display (B1), then the appliance performs a rinse cycle and goes off (standby).

Please note!

If you will not be using the appliance for some time, unplug from the mains socket:

- first turn the appliance off by pressing the **U** button (fig. 6);
- press the main switch (A22) (fig. 2).

! Important!

Never press the main switch while the appliance is on.

7. MENU SETTINGS

This menu has the following options, each explained in detail in this section.

- Language;
- Maintenance:
 - Descale,
 - Install filter,
 - (if a filter has been installed): Replace filter,
 - (if a filter has been installed): Remove filter;
- Prg. beverages;
- Prg. my beverages;
- General:
 - Set temperature,
 - Water hardness,
 - Auto-off,
 - Energy saving,
 - Beep,
 - Default beverages,
 - Default values;
- · Statistics.

7.1 Language

To modify the language of the display (B1), proceed as follows:

- 1. Press (B6) to enter the "Settings" menu;
- Press **OK** (B3) to select "Language". The available languages are displayed;
- 3. Press the selection arrows (B2 and B4) until the required language is displayed between the two lines;
- 4. Press **OK** to confirm;
- 5. The appliance goes back to the "Settings" menu;
- 6. Press ��/**ESC** (B5) to exit the menu.

7.2 Maintenance

Here you can find all the maintenance operations required by the appliance over time:

- Descale: For instructions on descaling, see section "15. Descaling".
- Install filter: For instructions on how to install the filter (C4), see section "17.1 Installing the filter".

To select the operation you require, proceed as follows:

- 1. Press (B6) to enter the "Settings" menu;
- 2. Press the selection arrows (B2 and B4) until "Maintenance" is displayed between the two lines;
- 3. Press **OK** (B3) to confirm;
- 4. Press the selection arrows to display the operation to be performed;
- Press **OK** to confirm and perform the operations as described in the corresponding sections.

7.3 Program beverages

The appliance is set by default to automatically deliver standard quantities. To change these quantities and customise the directly selected beverages and the PAINK (B14), proceed as follows:

- 1. Press (B6) to enter the "Settings" menu;
- Press the selection arrows (B2 and B4) until "Prg. beverages" is displayed between the two lines;
- 3. Press **OK** (B3) to confirm: the appliance lists the beverages you can customise;
- 4. Press the selection arrows until the beverage you want to customise is displayed, then press **OK** to confirm;
- 5. **Beverages with coffee:** "Program aroma" appears on the display: press the selection arrows (B2 and B4) or (B7) until the required aroma is selected (see section "9.4 Temporarily varying the coffee aroma"), then press **OK**. "Program coffee" appears on the display together with a bar which gradually fills as delivery progresses. When the required quantity is reached, press **OK**;

Cappuccinos and milk-based recipes: after selecting the aroma, "Program milk" appears on the display together with a bar which gradually fills as milk delivery progresses. When the required quantity is reached, press **OK**. The appliance then makes the coffee. Press **OK** to interrupt delivery when the required quantity of coffee is reached.

Hot water: press **OK**. Delivery begins: press **OK** when the required quantity is reached.

"Save parameters?": to save the settings, press **OK** (otherwise press **③/ESC** - B2 or B5).

7.4 Program My beverages

To customize recipes under the My Menu, follow the procedures described in previous section "7.3 Program beverages" by selecting "Prg. my beverages" OR by programing directly under the My Menu by following instructions described in section "12. Programming and selecting".

7.5 General

Here you can find the settings to customise the basic functions of the appliance:

1. Press 💝 (B6) to enter the "Settings" menu;

- 2. Press the selection arrows (B2 and B4) until "General" is displayed between the two lines;
- 3. Press **OK** (B3) to confirm and select the required item with the selection arrows. Then follow the instructions for each setting.

• Set temperature:

To modify the temperature of the water used to make the coffee, proceed as follows:

- 4. Press **OK** (B3). The current value appears on the display (B1) and the "New" value flashes;
- Select the new value you want to set using the selection arrows (B2 or B4);
- 6. When the required value (low, medium, high, maximum) has been selected, press **OK**.

The display goes back to the previous screen.

Water hardness:

For instructions on identifying and setting water hardness, see section "16. Setting water hardness".

Auto-off (standby):

Auto-off can be set so that the appliance goes off after 15 or 30 minutes, or 1, 2 or 3 hours

- 4. Press **OK**. The current value appears on the display (B1) and the "New" value flashes;
- Select the new value you want to set using the selection arrows (B2 or B4);
- 6. When the required value (low, medium, high, maximum) has been selected, press **OK**.

The display goes back to the previous screen.

Energy saving:

Use this function to enable or disable energy saving. When enabled, the function reduces energy consumption.

To disable or enable "Energy Saving", proceed as follows:

- Press **OK**. The current state ("Enabled" or "Disabled") and the operation to be performed ("Disable?" or "Enable?") is displayed. Press **OK** to confirm;
- 5. Press **OK** to disable or enable the function.

The display goes back to the previous screen.

Please note!

- when the function is enabled, the symbol "ECO" appears on the display.
- When in energy saving mode, a few seconds elapse before the first coffee, cappuccino or milk-based coffee is delivered as the appliance must heat up again.
- If the milk container (D) is inserted, "Energy Saving" cannot be activated.

• Beep:

Use this function to enable or disable the beep. Proceed as follows:

- Press **OK**. The current state ("Enabled" or "Disabled") and the operation to be performed ("Disable?" or "Enable?") is displayed. Press **OK** to confirm;
- 5. Press **OK** to disable or enable the function.

The display goes back to the previous screen.

Default beverages:

Use this function to reset the default values for all the beverages, or the individual beverages programmed previously. Select the beverage, then proceed as follows:

- 4. Select "All" to reset the aroma and quantity settings to the default values, or select the required beverage, then press **OK**;
- 5. The machine will display "Reset?". To confirm, press **OK**;
- 6. The machine will now display "Reset complete" and goes back to previous screen.

To reset another beverage, repeat from point 4 or to exit, press <a>®/ESC (B5).

Default values:

Use this function to reset all settings of the machine to factory values, keeping only the language option in use.

To proceed with the reset, select Default values from the General menu (section "7.5 General"):

- 4. The "Reset" message will display". Press **OK**;
- 5. The machine will confirm displaying "Reset complete" and it goes back to previous screen.

To exit, press ��/**ESC** (B5).

7.6 Statistics

This displays statistics relating to the machine. To display the statistics, proceed as follows:

- 1. Press **©** (B6) to enter the "Settings" menu;
- 2. Press the selection arrows (B2 and B4) until "Statistics" is displayed between the two lines;
- 3. Press **OK** (B3): statistics on the appliance are displayed, use the selection arrows to scroll through the items;
- 4. Press @/**ESC** (B5) to exit.

To go back to the main screen, press **49/ESC**.

8. RINSING

Use this function to deliver hot water from the coffee spouts (A9) and hot water spout (C6), if inserted, to clean and heat the appliance's internal circuit.

Place a container with a minimum capacity of 3.38 floz/100ml under the coffee and hot water spouts.



Important! Danger of burns.

Do not leave the appliance unattended while hot water is being delivered.

1) To enable this function, press @ (B5). "RINSING" appears on the display (B1);


- After a few seconds, hot water is delivered first from the coffee spouts, then from the hot water spout (if inserted).
 A progress bar is displayed and fills gradually as rinsing proceeds;
- 3) To interrupt, press the arrow corresponding to "STOP" (B4).

i Please note!

- If the appliance is not used for more than 3-4 days, when switched on again, we strongly recommend performing 2/3 rinses before use;
- After cleaning, it is normal for the coffee grounds container (A11) to contain water.

9. MAKING COFFEE

9.1 Adjusting the coffee grinder



The coffee grinder is set by default to prepare coffee correctly and should not require regulating initially.

However, if after making the first few coffees you find that the coffee is either too weak and not creamy enough or delivery is too slow (a drop at a time), this can be corrected by adjusting the grinding dial (A5) (fig. 7).

Please note:

The grinding adjustment dial must only be turned when the coffee grinder is in operation.



If the coffee is delivered too slowly or not at all, turn one click clockwise.

For fuller bodied creamier coffee, turn one click anticlockwise (do not turn more than one click at a time).

These adjustments will only be evident

after at least 2 cups of coffee have been delivered. If this adjustment does not obtain the desired result, turn the dial another click.

9.2 Tips for a hotter coffee

For hotter coffee, you should:

- rinse the machine prior to brewing, press @/ESC (B5) (see section "8. RINSING");
- warm the cups with hot water using the hot water function (see section "13. Delivering hot water");
- increase the coffee temperature in the "Settings" menu (see section "7.5 General").


9.3 Making automatic recipes using coffee beans

\bigwedge

/!\ Important!

Do not use green, flavoured, caramelised or candied coffee beans as they could stick to the coffee grinder and make it unusable.

Fill the container (A3) (fig. 8) with coffee beans;





- . Place under the coffee spouts (A9):
 - 1 cup, if you want to make 1 coffee (fig. 9);
 - 2 cups if you want 2 coffees.
- Lower the spouts as near as possible to the cup. This makes a creamier coffee (fig. 10);
- 4. Then select the desired recipe coffee:

| recipe conee: | | | | |
|--|-----------------------------|---|------------------|--|
| Directly selec | Directly selected beverages | | | |
| Recipe | Quantity | Program- mable quantity | Default aroma | |
| Espresso (B8) | ≃ 40 ml | from ≈ 30 to $\approx 80 \text{ml}$ | 00000 | |
| Long (B10) | ≃ 160 ml | from ≃115 to ≃250ml | | |
| Beverages with coffee selectable from the Prink MENU (B14) | | | | |
| Lungo | ≃ 120 ml | from ≃80 to ≃180ml | 00000 | |
| Ristretto | ≃ 30 ml | from ≃20 to ≃40ml | 00000 | |

| Double Espresso+ | ≃ 120 ml | from ≃80 to ≃180ml | 00000+ |
|---------------------|---------------------------------|------------------------|--------|
| Coffee | ≃ 180 ml | from ≃100 to ≃240ml | 00000 |
| 2 Espresso | $\simeq 40 \text{ml x}$ 2 cups | | 00000 |
| 2 Lungo | ≃ 120 ml x 2 cups | | 00000 |
| 2 Ristretto | $\simeq 30 \text{ml x}$ 2 cups | | 00000 |

5. Preparation begins. A progress bar appears on the display (B1) and gradually fills as preparation proceeds.

Please note:

- You can prepare 2 cups of RISTRETTO, ESPRESSO or LUNGO coffee at the same time by pressing "2X" (B3) during preparation of single beverages (the 2X image is displayed for a few seconds at the start of preparation).
- While the machine is making coffee, delivery can be interrupted at any time by pressing the selection arrow corresponding to "STOP" (B4).
- At the end of delivery, to increase the quantity of coffee in the cup, just press and hold (within 3 seconds) one of the coffee buttons (B8 or B10).

Once the coffee has been made, the appliance is ready to make the next beverage.

Please note:

- Various alarm messages could be displayed while using the appliance (fill tank, empty grounds container, etc.). Their meaning is explained in section "18. Displayed messages".
- For hotter coffee, see section "9.2 Tips for a hotter coffee".
- If the coffee is delivered a drop at a time, too weak and not creamy enough or too cold, read the tips in section "19. Troubleshooting".
- To customise the beverages according to personal taste, see sections "7.3 Program beverages" and "7.4 Program My beverages".

9.4 Temporarily varying the coffee aroma

To temporarily vary the aroma of the coffee in the automatic recipes, press (B7):

| () AUTO | Custom (if programmed) / Standard |
|---------|--------------------------------------|
| •••••• | EXTRA LIGHT |
| 00000 | LIGHT |

| 00000 | MEDIUM |
|-------|---|
| 00000 | STRONG |
| 00000 | X-STRONG |
| - | (see "9.5 Making coffee using pre-ground coffee") |

Please note:


- The variation in aroma is not saved and the next time a beverage is delivered automatically, the appliance selects the default value (AUTO).
- If a few seconds elapse between temporary customising of the aroma and delivery of the beverage, the aroma returns to the default value (AUTO).

9.5 Making coffee using pre-ground coffee

! Important!

- Never add pre-ground coffee when the machine is off or it could spread through the inside of the machine and damage it. This could damage the appliance.
- Never use more than 1 level measure (C2) or it could damage the inside of the coffee machine or block the funnel (A4).

Please note:



- If you use pre-ground coffee, you can only make one cup of coffee at a time.
- 2. Make sure the funnel is clean, then add one level measure of pre-ground coffee (fig. 11).
- 3. Place a cup under the coffee spouts (A9) (fig. 9).
- 4. Then select your required coffee:

| Directly selected beverages | | |
|-----------------------------|----------|--|
| Recipe Quantity | | |
| ➡ Espresso (B8) | ≃ 40 ml | |
| Long (B10) | ≃ 160 ml | |

| Beverages with coffee selectable from the PDRINK MENU (B14) | | |
|---|--|--|
| Lungo \simeq 120 ml | | |
| Ristretto $\simeq 30 \text{ ml}$ | | |
| Coffee $\simeq 180 \text{ml}$ | | |

Preparation begins. The beverage selected appears on the display together with a progress bar which gradually fills as preparation proceeds.

Important! Making LONG coffee ::


Halfway through preparation, the message "Add pre-ground coffee" appears on the display (B1). Add one level measure of pre-ground coffee and press **OK** (B3).

i Please note:

If "Energy Saving" mode is active, you may have to wait a few seconds before the first coffee is delivered.

10. TRUEBREW OVER ICE™ COFFEE

1. Add ice to a large glass about half way full (fig. 12), press the strength selector (B8) to choose a strength (strong or extra strong recommended), and place the glass under the brewing unit;



- 2. Then, press the TrueBrew Over Ice™ (B9) button to brew the coffee (fig. 13);
- 3. Add additional ice to the glass/coffee plus any syrup, sweetener or milk desired and enjoy

Important!

Always use glasses resistant to thermal shock.

| Recipe | Quantity | Programmable quantity |
|--------------------------------|-------------------------|--|
| TrueBrew Over Ice coffee™ (B9) | ≃ 3.38 floz / 100 ml | from $\simeq 1.35$ floz/ 40 ml to $\simeq 8.11$ floz / 240ml |

11. MAKING MILK-BASED RECIPES


0

Please note:

 To avoid milk with poor froth or large bubbles, always clean the milk container lid (D2) and hot water connection nozzle (A8) as described in sections "11.4 Cleaning the milk container after use", "14.10 Cleaning the milk container" and "14.11 Cleaning the hot water nozzle".

11.1 Filling and attaching the milk container


1. Remove the lid (D2) (fig. 14);



 Fill the milk container (D3) with a sufficient quantity of milk, not exceeding the MAX level marked on the handle (fig. 15). Each mark on the side of the container corresponds to 3.38 fl oz/ 100 ml of milk;


Please note:

- For a denser more even froth, you must use skimmed or partially skimmed milk at refrigerator temperature (about 41°F/4°C).
- If "Energy Saving" mode is enabled, you may have to wait a few seconds before the first cappuccino is delivered.
- 3. Make sure the milk intake tube (D4) is correctly inserted in the bottom of the milk container lid (fig. 16);




4. Place the lid back on the milk container;

- Remove the hot water spout (C6) from the connection nozzle (A8) (fig. 17);
- Attach the container to the connection nozzle and push as far as it will go (fig. 18). The machine emits a beep (if enabled);



- Place a sufficiently large cup under the coffee spouts (A9) and frothed milk spout (D5). Adjust the length of the milk spout. To move it nearer the cup, simply pull it downwards (fig. 19);
- 8. Follow the instructions below for each function.

11.2 Adjusting the amount of froth



Turn the froth adjustment dial (D1) (fig. 20) to adjust the amount of froth on the milk delivered while making cappuccinos and milk-based coffees.

| Dial position | Description | Recommended for |
|------------------|-------------|---|
| | No froth | HOT MILK (not frothed) / LATTE |
| | Min. froth | LATTE MACCHIATO/ FLAT WHITE |
| | Max. froth | CAPPUCCINO/ CAPPUCCI- NO+ / ESPRESSO MACCHIA- TO / HOT MILK (frothed) |

11.3 Making cappuccino and milk-based coffees automatically

- 1. Fill the milk container (D) and attach it as described above;
- 2. Select the desired beverage:

Directly selected beverages:

• <u></u>: CAPPUCCINO (B11)

• 📳: Latte (B12)

• **I**: Hot Milk (B13)

Select by pressing Prink (B14):

- Cappuccino+
- · Latte macchiato
- Flat white
- · Espresso macchiato;
- After a few seconds, preparation begins automatically, a progress bar appears on the display and gradually fills as preparation proceeds;
- 4. After delivering the milk, the machine automatically makes the coffee (if required by the recipe).

i Please note:

- If you want to interrupt preparation during delivery, press the arrow corresponding to "STOP" (B4).
- Do not leave the milk container out of the refrigerator for long periods. The warmer the milk (41°F / 5°C is ideal), the poorer the quality of froth produced.
- The beverages can be customised (see sections "7.3 Program beverages" and "7.4 Program My beverages").


11.4 Cleaning the milk container after use

/ss.\ Important! Danger of burns

 When cleaning the internal tubes of the milk container (D), a little hot water and steam may leak out out of the milk spout (D5). Avoid contact with splashes of water.

"Set dial to CLEAN, ESC to cancel" appears on the display (B1) each time you use a milk function. Clean as described to eliminate all milk residues (or press " * [ESC" (B5) to clean later):

- 1. Leave the milk container (D) in the machine (you do not need to empty it);
- 2. Place a cup or other recipient under the frothed milk spout;



- 3. Turn the froth adjustment dial (D1) to "CLEAN" (fig. 21). "Cleaning underway" appears on the display, together with a progress bar which gradually fills as the operation proceeds. Cleaning stops automatically;
- 4. Turn the dial back to one of the froth selections;
- 5. Remove the milk container and always clean the steam connection nozzle (A8) with a sponge (fig. 22).

(i] Please note!

- To prepare a number of cappuccinos or milk-based coffees, clean the milk container after you have prepared the last beverage only. In this case, press **@/ESC** (B5) to go back to the main menu.
- The milk container can be kept in the refrigerator.
- In some cases, before cleaning you must wait for the appliance to heat up.

12. "(my) MENU" PROGRAMMING AND SELECTING

In (my) MENU you can select beverages customised to your personal tastes. If the beverages have not yet been programmed, the appliance will request the customisation procedure before proceeding with delivery:

- 1. Press (my) MENU (B15);
- 2. Press the selection arrows (B2 and B4) until the required beverage is displayed between the two lines;

Unprogrammed beverages:

- 3. Press **OK** (B3) to select;
- 4. **Beverages with coffee:** "Program aroma" appears on the display. Press the selection arrows (B2 and B4) or **1** (B7) until the required aroma is selected. Press **OK**. "Program coffee" appears on the display together with a bar which gradually fills as delivery progresses. When the required quantity is reached, press **OK**.
- Cappuccinos and milk-based coffees: After selecting the aroma, "Program milk" appears on the display together with a bar which gradually fills as milk delivery progresses. When the required quantity is reached, press OK.
- 6. The appliance then makes the coffee. Press **OK** to interrupt delivery when the required quantity of coffee is reached.
- "Save parameters?": to save the settings, press **OK** (otherwise press **ESC** - B2 or B5).
- "Parameters saved" (or "Parameters not saved"). The appliance is ready for use again.

Programmed beverages:

- 3. Press **OK** (B3) to select;
- 4. Preparation begins according to the previously programmed settings.

(i) Please note:

Two cups of a beverage can only be selected when the corresponding single beverages have been programmed.

13. DELIVERING HOT WATER



/ Important! Danger of burns.

Never leave the machine unattended while delivering hot water.

- Make sure the hot water spout (C6) is attached correctly;
- Place a container under the water spout (as close as possi-2. ble to avoid splashes) (fig. 5);
- Press Press Press (B14) and scroll through the beverages in the menu by pressing the selection arrows (B2 or B4) until "Hot water" is selected;
- Press **OK** (B3). A progress bar appears and gradually fills as preparation proceeds;
- The machine delivers about 8.45 fl oz / 250 ml of hot water, then delivery stops automatically. To interrupt hot water delivery manually, press the selection arrow corresponding to "STOP" (B4) again.

Please note:

- If "Energy Saving" mode is active, you may have to wait a few seconds before hot water is delivered.
- The quantity of water delivered can be customised (see section "7.3 Program beverages").

14. CLEANING

14.1 Cleaning the machine

The following parts of the machine must be cleaned regularly:

- the appliance's internal circuit;
- coffee grounds container (A11);
- drip tray (A15) and condensate tray (A10);
- water tank (A17);
- coffee spouts (A9);
- pre-ground coffee funnel (A4);
- infuser (A20), accessible after opening the infuser door (A19);
- milk container (D);
- hot water/steam connection nozzle (A8);



\ Important!

- Do not use solvents, abrasive detergents or alcohol to clean the coffee machine.
- None of the components of the appliance can be washed in a dishwasher with the exception of the drip tray grille (A14) and milk container (D).
- Do not use metal objects to remove coffee deposits as they could scratch metal or plastic surfaces.

14.2 Cleaning the machine's internal circuit

If the appliance is not used for more than 3/4 days, before using it again, we strongly recommend switching it on and:

- performing 2-3 rinse cycles by pressing @ (B5);
- delivering hot water for a few seconds (section "13. Delivering hot water").

i Please note:

After cleaning, it is normal for the coffee grounds container (A11) to contain water.


14.3 Cleaning the coffee grounds container

When "Empty grounds container" appears on the display (B1), the grounds container must be emptied and cleaned. The appliance cannot be used to make coffee until you have cleaned the grounds container (A11). Even if not full, the empty grounds container message appears on the display 72 hours after the first coffee has been prepared. For the 72 hours to be calculated correctly, the machine must never be turned off with the main switch (A22).

/ssi Important! Danger of burns

If you make a number of cappuccinos one after the other, the metal cup tray (A12) becomes hot. Wait for it to cool down before touching it and handle it from the front only.

To clean (with the machine on):




- Remove the drip tray (A15) (fig. 23), empty and clean.
- Empty the grounds container (A11) and clean thoroughly to remove all residues left on the bottom. This can be done with the spatula on the brush (C5) provided.
- Check the condensate tray (A10) (red) and empty if necessary.



∕!∖ Important!

When removing the drip tray, the grounds container must be emptied, even if it contains few grounds.

If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine.



14.4 Cleaning the drip tray and condensate tray

| Important!

The drip tray (A15) is fitted with a level indicator (A13) (red) showing the level of water it contains (fig. 24). Before the indicator protrudes from the cup tray (A12), the drip tray must be emptied

and cleaned otherwise the water may overflow the edge and damage the appliance, the surface it rests on or the surrounding area.


To remove the drip tray:

- Remove the drip tray and the coffee grounds container (A11) (fig. 23);
- 2. Remove the cup tray (A12) and drip tray grille (A14), then empty the drip tray and grounds container and wash all components;
- Check the red condensate tray (A10) and empty if necessary;
- Replace the drip tray complete with grille and grounds

14.5 Cleaning the inside of the coffee machine

\angle Danger of electric shock!

Before cleaning internal parts, the machine must be turned off (see section "6. Turning the appliance off") and unplugged from the mains power supply. Never immerse the coffee machine in water.



- Check regularly (about once a month) that the inside of the appliance (accessible after removing the drip tray, A15) is not dirty. If necessary, remove coffee deposits with the brush (C5) supplied and a sponge;
- 2. Remove all the residues with a vacuum cleaner (fig. 25).

14.6 Cleaning the water tank

- Clean the water tank (A17) regularly (about once a month) and whenever you replace the water softener filter (C4) (if provided) with a damp cloth and a little mild washing up
 - liquid;
 - Remove the filter (C4) (if present) and rinse with running water;
 - Replace the filter (if provided), fill the tank with fresh water and replace the tank;
 - (Models with water softener filter only) Deliver about 3.38 fl oz / 100ml of water.



14.7 Cleaning the coffee spouts

- 1. Clean the coffee spouts (A9) regularly with a sponge or cloth (fig. 26A);
- 2. Check that the holes in the coffee spouts are not blocked. If necessary, remove coffee deposits with a toothpick (fig. 26B).

14.8 Cleaning the pre-ground coffee funnel

Check regularly (about once a month) that the pre-ground coffee funnel (A4) is not blocked. If necessary, remove coffee deposits with the brush (C5) supplied.


14.9 Cleaning the infuser

The infuser (A20) must be cleaned at least once a month.



The infuser may not be extracted when the machine is on.

- 1. Make sure the machine is correctly turned off (see "6. Turning the appliance off");
- 2. Remove the water tank (A17);
- 3. Open the infuser door (A19) (fig. 27) on the right side of the appliance;




- 4. Press the two coloured release buttons inwards and at the same time pull the infuser outwards (fig. 28);
- 5. Soak the infuser in water for about 5 minutes, then rinse under the tap;

Important!

RINSE WITH WATER ONLY
NO WASHING UP LIQUID - NO DISH WASHER
Clean the infuser without using soap as it could damage
the infuser.

- 6. Use the brush (C5) to remove any coffee residues left in the infuser housing, visible through the infuser door;
- After cleaning, put back in place the infuser by sliding it onto the internal support, then push the PUSH symbol fully in until it clicks into place;

i Please note:




If the infuser is difficult to insert, before insertion, adapt it to the right size by pressing the two levers (fig. 29).

- Once inserted, make sure the two coloured buttons have snapped out;
- 9. Close the infuser door;
- 10. Put the water tank back.

14.10 Cleaning the milk container


Clean the milk container (D) frequently as described below:

- 1. Remove the lid (D2);
- 2. Remove the milk spout (D5) and intake tube (D4) (fig. 30);



- Turn the froth adjustment dial (D1) counterclockwise to the "INSERT" position (fig. 31) and pull off upwards;
- 4. Wash all the components thoroughly with hot water and mild soap. All components are dishwasher safe, placing them in the top basket of the dishwasher.

Make sure there are no milk residues on the hollow and groove under the dial (fig. 32). If necessary, scrape the groove with a toothpick;



- 5. Rinse inside the froth adjustment dial housing with running water (fig. 33);
- 6. Check that the intake tube and milk spout are not clogged with milk residues;
- 7. Put back in place the dial (in correspondence to the word "INSERT"), spout and milk intake tube;
- 8. Place the lid back on the milk container (D3).

14.11 Cleaning the hot water nozzle

Each time you prepare milk, clean the connection nozzle (A8) with a sponge to remove milk residues from the gaskets (fig. 22).

15. DESCALING


\Important!

- Before use descaler, read the instructions and the labelling on the descaler pack.
- You should use De'Longhi descaler only. Using unsuitable descaler and/or performing descaling incorrectly may result in faults not covered by the manufacturer's warranty.

Descale the machine when the message "Descale, ESC to cancel, OK to descale (~45 minutes)" appears on the display (B1). To descale immediately, press **OK** (B3) and follow the instructions from point 6. To descale the appliance later, press **ESC** (B5). The 以 symbol on the display reminds you that the appliance needs descaling.

To access the descaling menu:

- 1. Turn the appliance on and wait until it is ready for use;
- 2. Press (B6) to enter the "Settings" menu;
- Press the selection arrows (B2 and B4) until "Maintenance" is displayed between the two lines. Press OK (B3);
- 4. Press OK to select "Descale";
- 5. Confirm? (~45 minutes)". Press OK to confirm;
- "Remove filter": extract the water tank (A17), remove the water softener filter (C4) (if present) and empty the water tank. Press OK;



"Pour descaler and water into tank": Pour the descaler into the tank up to level A (corresponding to a 61 fl oz /100 ml

- pack) marked on the inner surface of the tank, then add water (1 litre) up to level B (fig. 34) and put the water tank back. Press OK;
- "Empty drip tray": Remove, empty and replace the drip tray (A15) and grounds container (A11). Press **OK**;
- "Place 1.8L container empty under spouts": Place an empty container with a minimum capacity of 1.8 litres / 61 fl oz under the hot water spout (C6) and coffee spouts (A9) (fig. 35). Press **OK**;

∠ Important! Danger of burns

Hot water containing acid flows out of the coffee spouts and hot water spout. Take care to avoid contact with splashes of this solution.

10. "Descaling underway": The descale programme starts and the descaler liquid comes out of the hot water and coffee spouts. A series of rinses and pauses is performed automatically to remove all the scale residues inside the coffee machine;

After about 25 minutes, descaling stops. The following messages will appear on the screen:

- 11. "Rinse tank and fill with water": the appliance is now ready to rinse with fresh water. Empty the container used to collect the descaler solution. Extract the water tank, empty, rinse under running water, fill with fresh water up to the MAX level and put back in the appliance. Press **OK**;
- 12. "Place 61 fl oz / 1.8L container empty under spouts": place the container used to collect the descaler solution empty under the coffee spouts and hot water spout (fig. 35) and press OK";
- 13. "Rinsing Confirm?": press **OK**;
- 14. "Rinsing underway": hot water is delivered first from the coffee spouts, then from the hot water spout;
- 15. When the water in the tank has run out, empty the container used to collect the rinsing water;
- 16. "Rinse tank and fill with water": extract the water tank and fill with fresh water up to the MAX level. Press **OK**;
- 17. "Insert filter": put the water softener filter (if removed) back in its housing in the water tank, and replace the tank in the appliance. Press **OK**;
- 18. "Place 1.8L container empty under spouts": place the container used to collect the descaler solution empty under the hot water spout. Press **OK**;
- 19. "Rinsing Confirm?": press **OK**.
- 20. "Rinsing underway". Hot water comes out of the hot water
- 21. "Empty drip tray": At the end of the second rinse, remove, empty and replace the drip tray (A15) and grounds container (A11). Press OK;

- 22. "Descale complete": press **OK**;
- 23. "Fill tank": empty the container used to collect the rinse water, remove the water tank and fill with fresh water up to the MAX level, then put back in the appliance.

Descaling is complete.



- If the descaling cycle is not completed correctly (e.g. no electricity) we recommend repeating the cycle;
- After descaling, it is normal for the grounds container (A11) to contain water;
- If the water tank has not been filled to the MAX level, at the end of descaling, the appliance requests a third rinse to guarantee that the descaler solution has been completely eliminated from the machine's internal circuits.
- The appliance may request descaling cycles at very short intervals. This is normal and due to the appliance's advanced control system.


16. SETTING WATER HARDNESS

The descale message is displayed after a period of time established according to water hardness level.

The machine is set by default for a hardness level of 4. The machine can also be programmed according to the hardness of the mains water in the various regions so that the machine needs to be descaled less often.

16.1 Measuring water hardness

- 1. Remove the "TOTAL HARDNESS TEST" indicator paper (C1) from its pack (attached to the English instructions);
- Immerse the paper completely in a glass of water for one second;
- Remove the paper from the water and shake lightly. After about a minute, 1, 2, 3, or 4 red squares form, depending on the hardness of the water. Each square corresponds to one level;



16.2 Setting water hardness

- 1. Press (B6) to enter the "Settings" menu;
- Press the selection arrows (B2 and B4) until "General" is displayed between the two lines. Press **OK**;

- Press the selection arrows until "Water hardness" is displayed, then press **OK**;
- 4. The current selection appears on the display and the new selection flashes. Press the selection arrows until the required new selection is displayed. Press **OK**.

The new level is saved and the appliance goes back to the "General" menu.


Press ��/**ESC** (B5) twice to go back to the main screen.

17. WATER SOFTENER FILTER

Certain models are fitted with a water softener filter (C4). If this is not the case with your model, you are recommended to purchase one from De'Longhi Customer Services.

To use the filter correctly, follow the instructions below.

17.1 Installing the filter




- Remove the filter (C4) from the packaging. The date indicator disk varies according to the filter provided.
- Turn the date indicator disk (fig. 36) until the next 2 months of use are displayed.

i Please note


The filter lasts about two months if the appliance is used normally. If the coffee machine is left unused with the filter installed, it will last a maximum of three weeks.

3. To activate the filter, run tap water through the hole in the filter as shown in fig. 37 until water comes out of the openings at the side for more than a minute.;



Extract the tank (A17) from the appliance and fill with water;

- 5. Insert the filter in the water tank and immerse it completely for about ten seconds, sloping it and pressing it lightly to enable the air bubbles to escape (fig. 38).
- 6. Insert the filter in the filter housing (A18) and press as far as it will go (fig. 39);
- 7. Close the tank with the lid (A16) (fig. 40), then replace the tank in the machine;



When you install the filter, you must notify the appliance of its presence.

- 8. Press (B6) to enter the "Settings" menu;
- 9. Press the selection arrows (B2 and B4) until "Maintenance" is displayed between the two lines. Press **OK**;
- 10. Press the selection arrows until "Install filter" is displayed, then press **OK**;
- 11. Confirm?": press OK;
- 12. "Hot water, Confirm?": Position a container under the hot water spout (C6) (min. capacity: 500 ml), then press **OK**;
- 13. The appliance begins hot water delivery and the message "Please wait" is displayed;
- 14. After the flow of hot water stops, the appliance automatically resets to "Ready for coffee" status.

The filter is now active and you can use the coffee machine.

17.2 Replacing the filter

Replace the filter (C4) when "Replace filter, ESC to cancel, OK to replace" appears on the display (B1). To replace immediately, press **OK** (B3) and follow the instructions from point 8. To replace later, press ESC (B5). The \square symbol on the display reminds you that the filter needs replacing.

To replace the filter, proceed as follows:

- 1. Extract the tank (A17) and exhausted filter;
- 2. Take the new filter out of its packet and proceed as illustrated in points 2, 3, 4, 5, 6 and 7 in the previous section;
- 3. Press (B6) to enter the "Settings" menu;
- 4. Press the selection arrows (B2 and B4) until "Maintenance" is displayed between the two lines. Press **OK**;

- Press the selection arrows until "Replace filter" is displayed, then press **OK**;
- 6. Confirm?": press **OK**;
- 7. "Hot water, Confirm?": Position a container under the hot water spout (C6) (min. capacity: 500 ml), then press **OK**;
- 8. The appliance begins hot water delivery and the message "Please wait" is displayed;
- After the flow of hot water stops, the appliance automatically resets to "Ready for coffee" status.

The new filter is now active and you can use the coffee machine.

Please note!

After two months (see date indicator) or when the appliance has not been used for 3 weeks, you should replace the filter even if the message has not yet been displayed.

17.3 Removing the filter

If you want to use the appliance without the filter (C4), you must remove it and notify the appliance of its removal. Proceed as follows:

- 1. Extract the tank (A17) and exhausted filter;
- 2. Press (B6) to enter the "Settings" menu;
- Press the selection arrows (B2 and B4) until "Maintenance" is displayed between the two lines. Press **OK**;
- 4. Press the selection arrows until "Remove filter" is displayed, then press **OK**;
- 5. "Confirm?": press **OK** to confirm removal. The appliance goes back to the "Maintenance" menu;

Press ��/**ESC** (B5) to exit the menu.

i Please note!

After two months (see date indicator) or when the appliance has not been used for 3 weeks, you should replace the filter even if the message has not yet been displayed.

18. DISPLAYED MESSAGES

| DISPLAYED MESSAGE | POSSIBLE CAUSE | REMEDY |
|-----------------------------------|--|---|
| Fill tank | Insufficient water in the tank (A17). | Fill the tank with water and/or insert it correctly, pushing it as far as it will go until it clicks into place (fig. 3B). |
| Insert tank | The tank (A17) is not correctly in place. | Insert the tank correctly and press as far as it will go (page 3B). |
| Empty grounds container | The grounds container (A11) is full. | Empty the grounds container and drip tray (A15), clean and replace. Important: when removing the drip tray, the grounds container MUST be emptied, even if it contains few grounds. If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine. |
| Insert grounds container | After cleaning, the grounds container (A11) has not been replaced. | Remove the drip tray (A15) and insert the grounds container. |
| Add pre-ground coffee | The "pre-ground coffee" function has been selected without placing any pre-ground coffee in the funnel (A4). | Place pre-ground coffee in the funnel (fig. 11) or deselect the "pre-ground" function. |
| | A LONG coffee with pre-ground coffee has been requested | Put one level measure of pre-ground coffee into the pre-ground coffee funnel (A4) and press OK (B3) to continue and complete preparation. |
| Fill beans container | The coffee beans have run out. | Fill the beans container (A3) (fig. 8). |
| | The pre-ground coffee funnel (A4) is clogged. | Empty the funnel with the help of the brush (C5) as described in section "14.8 Cleaning the pre-ground coffee funnel". |
| Ground too fine Adjust grinder | The grinding is too fine and the coffee is delivered too slowly or not at all. | Repeat coffee delivery and turn the grinding adjustment dial (A5) (fig. 7) one click clockwise towards 7 while the coffee grinder is in operation. If after making at least 2 coffees delivery is still too slow, repeat the correction procedure, turning the grinding adjustment dial another click until delivery is correct (see section "9.1 Adjusting the coffee grinder"r". If the problem persists, make sure the water tank (A17) is fully inserted. |
| | If the water softener filter (C4) is present, an air bubble may have been released inside the circuit, obstructing delivery. | Insert the hot water spout (C6) in the appliance and deliver a little water until the flow becomes regular. |
| Less coffee | Too much coffee has been used. | Select a lighter taste by pressing 10 (B7) or reduce the quantity of pre-ground coffee. |
| Insert water spout | The hot water spout (C6) is not inserted or is inserted incorrectly. | Fully insert the hot water spout (fig. 4). |

| DISPLAYED MESSAGE | POSSIBLE CAUSE | REMEDY |
|--|---|--|
| Insert milk container | The milk container (D) is not inserted correctly. | Insert the milk container as far as it will go (fig. 18). |
| Insert infuser assembly | The infuser (A20) has not been replaced after cleaning. | Insert the infuser as described in section "14.9 Cleaning the infuser". |
| Water circuit empty Fill water circuit Hot water Confirm? | The water circuit is empty. | Press OK (B3) to deliver water from the spout (C6) until it flows out normally. If the problem persists, make sure the water tank (A17) is fully inserted. |
| Press OK to CLEAN | The milk container (D) has been inserted with the froth adjustment dial (D1) in the "CLEAN" position. | To proceed with the CLEAN function press OK or turn the froth adjustment dial to another position. |
| Set dial to CLEAN ESC to cancel | Milk has been delivered recently and the tubes inside the milk container (D) must be cleaned. | Turn the froth adjustment dial (D1) to CLEAN (fig. 19). |
| Turn froth adjustment dial | The milk container (D) has been inserted with the froth adjustment dial (D1) in the "CLEAN" position. | Turn the froth adjustment dial to one of the milk froth positions. |
| Descale ESC to cancel OK to descale (~45 minutes) | The machine must be descaled. | The descaling procedure described in section "15. Descaling" needs to be performed. |
| Replace filter ESC to cancel OK to replace | The water softener filter (C4) is exhausted. | Replace the filter or remove it as described in section "17. Water softener filter". |
| General alarm | The inside of the appliance is very dirty. | Clean the inside of the appliance thoroughly, as described in section "14. Cleaning". If the message is still displayed after cleaning, contact a service centre. |
| 3 | The tubes inside the milk container (D) must be cleaned. | Turn the froth adjustment dial (D1) to CLEAN (fig. 21). |
| | The water softener filter (C4) is exhausted and must be replaced or removed. | Replace the filter or remove it as described in section "17. Water softener filter". |
| ************************************** | The machine must be descaled. | The descaling procedure described in section "15. Descaling" needs to be performed. The appliance may request descaling cycles at very short intervals. This is normal and due to the appliance's advanced control system. |
| ECO | Energy saving is enabled. | To disable energy saving, proceed as described in section "7.5 General" - "• Energy saving:" |

19. TROUBLESHOOTING

Below is a list of some of the possible malfunctions.

If the problem cannot be resolved as described, contact Customer Services.

| POSSIBLE CAUSE | REMEDY |
|--|--|
| The cups were not preheated. | Warm the cups by rinsing them with hot water (Please note: you can use the hot water function). |
| The internal circuits of the appliance have cooled down because 2/3 minutes have elapsed since the last coffee was made. A low coffee temperature is set. | Before making coffee, rinse the internal circuits by pressing the 🚳 button (B5). |
| | Set a higher coffee temperature in the menu. |
| The coffee is weak or not creamy enough. The coffee is ground too coarsely. | Turn the grinding adjustment dial (A5) one click anticlockwise towards 1 while the coffee grinder is in operation (fig. 7). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering 2 coffees (see section "9.1 Adjusting the coffee grinder"). |
| The coffee is unsuitable. | Use coffee beans for espresso machines. |
| The coffee is ground too finely. | Turn the grinding adjustment dial (A5) one click clockwise towards 7 while the coffee grinder is in operation (fig. 7). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering 2 coffees (see section "9.1 Adjusting the coffee grinder"). |
| The appliance has detected impurities in its internal circuits. "Please wait" is displayed. | Wait for the appliance to be ready for use again and reselect the required beverage. Contact Customer Services if the problem persists. |
| The coffee spouts (A9) are blocked. | Clean the spouts with a toothpick (fig. 26B). |
| It is not plugged into the mains socket. | Plug into the mains socket (fig. 1). |
| The main switch (A22) is not turned on. | Place the main switch in the I position (fig. 2). |
| The power cord (C7) connector is not inserted correctly. | Insert the connector as far as it will go in the socket at the back of the appliance (fig. 1). |
| The appliance has not been turned off correctly | Turn the appliance off by pressing the button (A7) (fig. 6) (see section "6. Turning the appliance off"). |
| | The cups were not preheated. The internal circuits of the appliance have cooled down because 2/3 minutes have elapsed since the last coffee was made. A low coffee temperature is set. The coffee is ground too coarsely. The coffee is unsuitable. The coffee is ground too finely. The appliance has detected impurities in its internal circuits. "Please wait" is displayed. The coffee spouts (A9) are blocked. It is not plugged into the mains socket. The main switch (A22) is not turned on. The power cord (C7) connector is not inserted correctly. |