

Read this manual carefully before installing and operating!

For any problems or issues, please contact support@ibestten.com or 1-800-358-6160. Our technical team will help you sort it out.

BESTTEN® Hardware


Digital Lever with Keypad

Not Waterproof

BESTTEN electronic door locks are not waterproof and should not be installed where they will be exposed to rain or other wet conditions.



Installation Overview



Package Includes:

A Exterior Assembly	-1	E Keys	-2	I 1 1/8" Screw	-1
B Interior Assembly	-1	F Latch	-1	J 1" Screw	-2
C Mounting Plate	-1	G Strike Plate	-1	K 5/16" Screw	-2
D AA Alkaline Batteries	-4	H User Guide	-1	L 3/4" Screw	-4
		M Optional Set Screw	-1		

Exterior Assembly

Interior Assembly

Mounting Plate

AA Alkaline Batteries

Keys

Latch

Strike Plate

User Guide

1 1/8" Screw

1" Screw

5/16" Screw

3/4" Screw


Optional Set Screw

Please carefully check the above list to confirm all items have been received. If any items are missing, please contact BESTTEN Customer Care.


1. Prepare Door

Refer to Template for Door Prep Instructions Included in Packaging.


NOTE: Skip this step if your door comes with pre-drilled holes.



2. Install Latch and Strike Plate



To convert between 2-3/8" (60mm) and 2-3/4" (70mm) backset
1. Pull or push the extension plate to the required size.




3. Determine Door "Handing" and Install Lock Handle


View from the front of the lock

Right Handed Door

Left Handed Door




Reminder: Tail piece must be in the horizontal position only when removing or installing handles.




4. Change Lever Handing (Optional)


Reminder: Tail piece must be in the horizontal position only when removing or installing handles.



5. Install Exterior Assembly





Check that the rubber gasket is secured on the exterior assembly. Place the exterior assembly onto the door with the tail piece going through the latch assembly. Route the control wire through the door over the latch assembly.



6. Install Wiring Connector

⚠ Work with the Door Open





⚠ Control Wire

Make sure that all the pins on the control wire connector are straight and that the connector is fully installed and firmly connected.


7. Install Interior Assembly

NOTE: Make sure the tail piece and knob are both set in the VERTICAL position. Be careful not to pinch the control wire when assembling.




8. Test the Lock

Test the Lock



Check the Lock/Unlock function and that the Lever fully retracts the Latch.





NOTE: Do not touch the keypad until the light turns off. Do not use rechargeable batteries or non-alkaline batteries.

This electronic lock requires (4) High Quality AA alkaline batteries. When all 4 batteries are installed in the correct position, you should hear 2 beeps and the keypad will illuminate.

9. Test Operation

Test that all buttons on the keypad are working.




Default Administrator Code:123456
Default User Code:1234

Both Administrator Code and User Code can open the door

⚠ Before Opening Door, Let Motor Complete Cycle.

BESTTEN® Hardware
Programming Instructions

Test the keypad to ensure all the buttons work.



5 Seconds

During programming, if there are no inputs for 5 seconds, the programming will exit and fail to complete.

Please change the Administrator Code and User Code as soon as possible after installation to insure security.

AC Administrator Code
Default:123456

UC User Code (4-8 digits)
Default:1234

ID User ID (01-50, 2 digits)
Each User Code is linked to a User ID

- Green Light

 - Indicates Successful Programming Step
 - Indicates Unlocking is Successful
- Red light

 - Indicates Failed Programming Step
 - Indicates Locking is Successful




- Lock Button

Lock
Used to lock door
- Unlock Button

Unlock
Used to unlock door




Programming
Used in programming steps

1. Change Administrator Code




2. Add a User Code




When a NEW User Code is set, the default User Code (1234) is deleted for safety.






3. Unlock Door with User Code



4. Delete a User Code



5. Delete All User Codes



6. Additional Programming Functions

Programming Symbols

- ⏻ Lock / Clear
- 🔓 Unlock / Programming
- Ⓜ Administrator Code

Automatic Lock Function

SET OR CANCEL AUTO LOCK
You can set the lock to automatically lock after each time the lock is unlocked. Time value range = 20 - 900 seconds, enter the following:
Set Auto Lock: Ⓜ → 🔓 → 5 → 🔓 → Time Value → 🔓
1 beep and green light confirms successful programming.
Cancel Time Value Auto Lock: Ⓜ → 🔓 → 5 → 🔓 → 00 → 🔓

TEMPORARILY DISABLE:
While in Auto-Lock mode, unlock door using Ⓜ, within 5 seconds you must turn the locking knob by hand to the locked position, and then turn the locking knob back to the unlock position. The Auto-Lock mode is now disabled.

RESTORE:
To restore the Auto-Lock function, turn the locking knob by hand to the locked position, wait more than 2 seconds or press the ⏻ Lock button on the keypad.

Vacation Mode

With Vacation Mode enabled, the system enters into low-power consumption mode. During this mode, all buttons and functions will be disabled until they are re-enabled.

ENABLE:
Ⓜ → 🔓 → 10 → 🔓 → 1 → 🔓 → 🔓

Once the door is locked then vacation mode will be engaged and all buttons and functions will be disabled

DISABLE:
To disable the Vacation Mode, you must press and hold 🔓 for more than 3 seconds, then input Ⓜ followed by 🔓 to unlock the door. Vacation Mode is now disabled.

NOTE: If you only press the 🔓 for more than 3 seconds but do not input Ⓜ, the system will remain in Vacation Mode.

Secure Lock-out Period

Warning sounds and LED flashes red after 4 incorrect code attempts: Keypad shuts down for 60 seconds.

7. Additional Programming Functions

SOUND ON AND OFF

You can "mute" or turn the "sound on" on your lock by entering the following. (Factory setting is sound on).

Ⓜ → 🔓 → 6 → 🔓 → 1 or 2 → 🔓
1= Sound Off
2= Sound On

Sound Off (1) - Light Indicator illuminates green.
Sound On (2) - Hear 1 beep and Light Indicator illuminates green.

Restore Factory Settings

To reset the lock to the original factory settings including the Admin Code and all User Codes follow these steps:

1. Remove one battery for 10 seconds.
2. Reinsert the battery and wait for a long and short beep.
3. Quickly Press 🔓 3 times within 3 seconds (before the blue light turns off).
4. The lock will beep and the light indicator will turn green.

Low Battery Warning

Beeps and LED flashes red 7 times. Replace with high quality alkaline batteries.
Note: Removing batteries does not erase active Administrator or User Codes.

Function Guide

Unlock / Valid programming:	1 long beep and LED illuminates green
Lock:	2 short beeps and LED illuminates red
Invalid programming:	2 short beeps and LED flashes red twice
Low voltage:	Short beeps and LED flashes red seven times
Super low voltage:	4 short beeps and LED flashes red four times
4 Incorrect code entry attempts:	2 short beeps and LED illuminates red each attempt
Power on:	1 long beep and 1 short beep and LED illuminates green
Lock error:	3 long beeps and LED flashes red three times

Troubleshooting

Issue	Solution
Interior Knob will not turn	Knob or vertical tailpiece is installed in incorrect position. • Remove Interior Assembly and verify that the locking knob and tailpiece are vertical.
Lock will not function electronically	• Check that all batteries are high quality Alkaline Batteries. • Check for proper polarity (+-)of all batteries. • Check that the Control Wire is attached to the Interior Assembly and not damaged. • Check each wire for loose or disconnected wires. • Disconnect the wiring harness and reconnect the wiring harness. • Restore to factory settings
Keypad not working	• Wait 60 seconds, keypad may be locked out due to incorrect code. • Replace with 4 high quality alkaline batteries. • Ensure Wiring connector is fully engaged and secure.
Keypad beeps and LED flashes	• Replace with 4 high quality alkaline batteries.

Contact Us First! Do Not Return to Store

WARRANTY

BESTTEN warrants to the original customer that this product is free of defects in materials and workmanship for 3 years from the purchase date. Within this period, simply contact BESTTEN CARE with proof of purchase and reason of claim. We will replace the product for free.

Any product which is subject to misuse or accidental damage is excluded from this warranty.

BESTTEN CARE
support@ibestten.com
1-800-358-6160 (Mon-Fri 9AM-5PM PST)

For more products from BESTTEN, please visit our website www.ibestten.com.



Installation and Operation Guide