



F

VFD-F

User Manual

Fan and Pump Applications



Power Range :

1-phase 230V series: 0.75kW~37kW (1~50 HP)

3-phase 460V series: 0.75kW~220kW (1~300HP)



DELTA ELECTRONICS, INC.

www.delta.com.tw/industrialautomation**ASIA****Delta Electronics, Inc.****Taoyuan1**

31-1, Xingbang Road, Guishan Industrial Zone,
Taoyuan County 33370, Taiwan, R.O.C.
TEL: 886-3-362-6301 / FAX: 886-3-362-7267

Delta Electronics (Jiang Su) Ltd.**Wujiang Plant3**

1688 Jiangxing East Road,
Wujiang Economy Development Zone,
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-512-6340-7290

Delta Electronics (Japan), Inc.**Tokyo Office**

Delta Shibadaimon Building, 2-1-14 Shibadaimon,
Minato-Ku, Tokyo, 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

234-9, Duck Soo BD 7F, Nonhyun-dong,
Kangnam-ku, Seoul, Korea
Post code : 135-010
TEL: 82-2-515-5303/5 / FAX: 82-2-515-5302

Delta Electronics (Singapore) Pte. Ltd.

8 Kaki Bukit Road 2, #04-18 Ruby Warehouse Complex,
Singapore 417841
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Energy Systems (India) Pvt. Ltd.

Plot No. 27 & 31, Sector-34, EHTP,
Gurgaon-122001 Haryana, India
TEL: 91-124-4169040 / FAX: 91-124-4036045

AMERICA**Delta Products Corporation (USA)****Raleigh Office**

P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

EUROPE**Deltronics (Netherlands) B.V.****Eindhoven Office**

De Witbogt 15, 5652 AG Eindhoven, The Netherlands
TEL: 31-40-259-28-50 / FAX: 31-40-259-28-51

5011613009
2011-04-18



*We reserve the right to change the information in this manual without prior notice



VFD-F

User Manual

Fan and Pump Applications



Preface

Thank you for choosing DELTA's high-performance VFD-F Series. VFD-F Series are manufactured by adopting high-quality components, material and incorporating the latest microprocessor technology available.

Getting Started

This manual will be helpful in the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drives. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC drives. Keep this operating manual handy and distribute to all users for reference.



WARNING

-  Always read this manual thoroughly before using VFD-F series AC Motor Drives.
-  Ensure that VFD-F is grounded in a correct way before putting it into use.
-  **DANGER!** AC input power must be disconnected before any maintenance. Do not connect or disconnect wires and connectors while power is applied to the circuit. Maintenance must be performed by qualified technicians.
-  **CAUTION!** There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To avoid damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.
-  **DANGER!** A charge may still remain in the DC-link capacitor with hazardous voltages even if the power has been turned off. To avoid personal injury, do not remove the cover of the AC drive until all "DISPLAY LED" lights on the digital keypad are off. Please note that there are live components exposed within the AC drive. Do not touch these live parts.
-  **CAUTION!** Ground the VFD-F using the ground terminal. The grounding method must comply with the laws of the country where the AC drive is to be installed. Refer to Basic Wiring Diagram.
-  **DANGER!** The AC drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC drive output terminals U/T1, V/T2, and W/T3 directly to the AC main circuit power supply.
-  **CAUTION!** The final enclosures of the AC drive must comply with EN50178. (Live parts shall be arranged in enclosures or located behind barriers that meet at least the requirements of the Protective Type IP20. The top surface of the enclosures or barrier that is easily accessible shall meet at least the requirements of the Protective Type IP40). (VFD-F series corresponds with this regulation.)
-  **CAUTION!** The rated voltage for the AC motor drive must be $\leq 240\text{V}$ for 230V models ($\leq 480\text{V}$ for 460V models) and the mains supply current capacity must be $\leq 5000\text{A RMS}$ ($\leq 10000\text{A RMS}$ for the $\geq 40\text{hp}$ (30kW) models)
-  **CAUTION!** Heat sink may heat up over 70°C (158°F), during the operation. Do not touch the heat sink.



TABLE OF CONTENTS

CHAPTER 1 RECEIVING AND INSPECTIONS

1.1 Nameplate Information	1 - 1
1.2 Model Explanation	1 - 1
1.3 Serial Number Explanation	1 - 2

CHAPTER 2 STORAGE AND INSTALLATION

2.1 Storage.....	2 - 1
2.2 Installation.....	2 - 2

CHAPTER 3 WIRING

3.1 Basic Wiring Diagram	3 - 2
3.2 External Wiring	3 - 5
3.3 Main Circuit Connection	3 - 6
3.4 Control Terminals	3 - 9
3.5 Specifications for Power Terminals and Control Terminals	3-11
3.6 Wiring Notes	3-14
3.7 Motor Operation Precautions	3-16

CHAPTER 4 DIGITAL KEYPAD OPERATION

4.1 VFD-PU01	4 - 2
4.1.1 Description of the Digital Keypad VFD-PU01	4 - 2
4.1.2 Explanation of Display Message.....	4 - 2
4.1.3 Operation Steps of the Digital Keypad VFD-PU01	4 - 4



4.2 KPF-CC01	4 - 5
4.2.1 Description of the Digital Keypad KPF-CC01	4 - 5
4.2.2 Explanation of Display Message.....	4 - 5
4.2.3 KPF-CC01 Operation Flow Chart	4 - 6

CHAPTER 5 DESCRIPTION OF PARAMETER SETTINGS

5.1 Group 0: AC Drive Status Parameters.....	5 - 1
5.2 Group 1: Basic Parameters	5 - 4
5.3 Group 2: Operation Method Parameters	5 - 9
5.4 Group 3: Output Function Parameters	5-15
5.5 Group 4: Input Function Parameters	5-19
5.6 Group 5: Multi-step Speed Frequency Parameters.....	5-24
5.7 Group 6: Protection Parameters.....	5-30
5.8 Group 7: AC Drive and Motor Parameters	5-36
5.9 Group 8: Special Parameters	5-39
5.10 Group 9: Communication Parameters.....	5-45
5.11 Group 10: PID Control Parameters	5-60
5.12 Group 11: Fan and Pump Control Parameters.....	5-63

CHAPTER 6 MAINTENANCE AND INSPECTIONS

6.1 Periodic Inspection	6 - 1
6.2 Periodic Maintenance	6 - 1

CHAPTER 7 TROUBLESHOOTING AND FAULT INFORMATION..... 7 - 1



CHAPTER 8 SUMMARY OF PARAMETER SETTINGS 8 - 1

APPENDIX A SPECIFICATIONS A - 1

APPENDIX B ACCESSORIES

B.1 All Brake Resistors & Brake Units Used in AC Motor Drives	B - 1
B.1.1 Dimensions and Weights for Brake Resistors	B - 3
B.1.2 Specifications for Brake Unit	B - 5
B.1.3 Dimensions for Brake Unit.....	B - 6
B.2 AMD-EMI Filter Cross Reference.....	B - 8
B.3 AC Reactor	B-10
B.3.1 AC Input Reactor Recommended Value	B-10
B.3.2 AC Output Reactor Recommended Value.....	B-11
B.4 Non-fuse Circuit Breaker Chart.....	B-12
B.5 Fuse Specification Chart	B-13
B.6 PU06.....	B-14
B.6.1 Description of the Digital Keypad VFD-PU06.....	B-14
B.6.2 Explanation of Display Message	B-14
B.6.3 PU06 Operation Flow Chart	B-15
B.7 Relay Card	B-16
B.8 Zero Phase Reactor	B-18

APPENDIX C DIMENSIONS..... C - 1



CHAPTER 1 RECEIVING AND INSPECTION


1

This VFD-F AC drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC drive, please check for the following:

Receiving

- ✓ Check to make sure that the package includes an AC drive, the User Manual, dust covers and rubber bushings.
- ✓ Inspect the unit to insure it was not damaged during shipment.
- ✓ Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

1.1 Nameplate Information: Example for 7.5HP/5.5kW 3-phase 460V AC drive




1.2 Model Explanation

VFD	055	F	43	A	
					Version Type
					Input Voltage
					23: Three phase 230V
					43: Three phase 460V
					VFD-F Series
					Applicable motor capacity
007: 1.0HP(0.75kW)	150: 20HP(15kW)	750: 100HP(75kW)			
015: 2.0HP(1.5kW)	185: 25 HP(18.5kW)	900: 120HP(90kW)			
022: 3.0HP(2.2kW)	220: 30 HP(22kW)	1100: 150HP(110kW)			
037: 5.0HP(3.7kW)	300: 40HP(30kW)	1320: 175HP(130kW)			
055: 7.5HP(5.5kW)	370: 50HP(37kW)	1600: 215HP(160kW)			
075: 10 HP(7.5kW)	450: 60HP(45kW)	1850: 250HP(185kW)			
110: 15 HP(11kW)	550: 75HP(55kW)	2200: 300HP(220kW)			



1.3 Series Number Explanation



If there is any nameplate information not corresponding to your purchase order or any problem, please contact your distributor.



CHAPTER 2 STORAGE AND INSTALLATION

2.1 Storage

The AC drive should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time.

Ambient Conditions:

Operation	Air Temperature: -10°C to +40°C (14°F to 104°F) +50°C (122°F) without dust cover. Atmosphere pressure: 86 to 106 kPa Installation Site Altitude: below 1000m Vibration: Maximum 9.80 m/s ² (1G) at less than 20Hz Maximum 5.88 m/s ² (0.6G) at 20Hz to 50Hz
Storage	Temperature: -20°C to +60°C (-4°F to 140°F) Relative Humidity: Less than 90%, no condensation allowed Atmosphere pressure: 86 to 106 kPa
Transportation	Temperature: -20°C to +60°C (-4°F to 140°F) Relative Humidity: Less than 90%, no condensation allowed Atmosphere pressure: 86 to 106 kPa Vibration: Maximum 9.86 m/s ² (1G) at less than 20Hz, Maximum 5.88 m/s ² (0.6G) at 20Hz to 50Hz
Pollution Degree	2: good for a factory type environment.



2.2 Installation



CAUTION


The control, power supply and motor leads must be laid separately. They must not be fed through the same cable conduit / trunking.

High voltage insulation test equipment must not be used on cables connected to the drive.

Improper installation of the AC drive will greatly reduce its life. Be sure to observe the following precautions when selecting a mounting location.

Failure to observe these precautions may void the warranty!

- Do not mount the AC drive near heat-radiating elements or in direct sunlight.
- Do not install the AC drive in a place subjected to high temperature, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- Mount the AC drive vertically and do not restrict the air flow to the heat sink fins.
- The AC drive generates heat. Allow sufficient space around the unit for heat dissipation.





CHAPTER 3 WIRING



DANGER

Hazardous Voltage

Before accessing the AC drive:

- ◆ Disconnect all power to the AC drive.
- ◆ Wait five minutes for DC bus capacitors discharge.

3

Any electrical or mechanical modification to this equipment without prior written consent of Delta Electronics, Inc. will void all warranties and may result in a safety hazard in addition to voiding the UL listing.


Short Circuit Withstand:

The rated voltage for the AC motor drive must be $\leq 240V$ for 230V models ($\leq 480V$ for 460V models) and the mains supply current capacity must be $\leq 5000A$ RMS ($\leq 10000A$ RMS for the $\geq 40hp$ (30kW) models)




3.1 Basic Wiring Diagram

Users must connect wires according to the following circuit diagram shown below. Do not plug a Modem or telephone line to the RS-485 communication port, permanent damage may result. Pins 1 & 2 are the power sources for the optional copy keypad and should not be used while using RS-485 communication.







For 230V series, 20HP and above models
460V series, 25HP and above models






Wiring for SINK mode and SOURCE mode





3.2 External Wiring



Items	Explanations
Power supply	Please follow the specific power supply requirements shown in Appendix A.
Fuse/NFB (Optional)	There may be an inrush current during power up. Please check the chart of Appendix B and select the correct fuse with rated current. Use of an NFB is optional.
Magnetic contactor (Optional)	Please do not use a Magnetic contactor as the I/O switch of the AC motor drive, as it will reduce the operating life cycle of the AC drive.
Input AC Line Reactor (Optional)	Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more or advanced capacity is activated. The wiring distance should be $\leq 10m$. Refer to appendix B for details.
Zero-phase Reactor (Ferrite Core Common Choke) (Optional)	Zero-phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. Attenuation quality is good for a wide range from AM band to 10MHz. Appendix B specifies the zero-phase reactor. (RF220X00A)
EMI filter (Optional)	To reduce electromagnetic interference, please refer to Appendix B for more details.
Brake Resistor (Optional)	Used to reduce the deceleration time of the motor. Please refer to the chart in Appendix B for specific Brake Resistors.
Output AC Line Reactor (Optional)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable ($>20m$), it is necessary to install a reactor at the inverter output side.



3.3 Main Circuit Connection

Figure 1 for the main circuit terminals





Figure 2 for the main circuit terminals



Terminal Explanations

Terminal Symbol	Explanation of Terminal Function
R/L1, S/L2, T/L3	AC line input terminals
U/T1, V/T2, W/T3	AC drive output terminals motor connections
+1,+2	Connections for DC Link Reactor (optional)
+2/B1~B2	Connections for Brake Resistor (optional)
+2~ -,+2/B1~ -	Connections for External Brake Unit (VFDB series)
⊕	Earth Ground




Mains power terminals (R/L1, S/L2, T/L3)

- Connect these terminals (R/L1, S/L2, T/L3) via a non-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of AC motor drives. Both ends of the MC should have an R-C surge absorber.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- Please use voltage and current within the regulation shown in Appendix A.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above, and not less than 0.1-second detection time to avoid nuisance tripping. For the specific GFCI of the AC motor drive, please select a current sensor with sensitivity of 30mA or above.
- Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC drives by turning power ON/OFF, it is recommended to do so only ONCE per hour.
- Do NOT connect 3-phase models to a 1-phase power source.

Output terminals for main circuit (U, V, W)

- If the AC drive is installed in the place where a load reactor is needed, install the filter close to U/T1, V/T2, W/T3 side of AC drive. Do not use a Capacitor or L-C Filter (Inductance-Capacitance) or R-C Filter (Resistance-Capacitance), unless approved by Delta.
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- Use well-insulated motor, suitable for inverter operation.


Terminals [+1, +2] for connecting DC reactor



- To improve power factor and reduce harmonics, connect a DC reactor between terminals [+1, +2]. Please remove the jumper before connecting the DC reactor.



Terminals [+2/B1, B2] for connecting brake resistor and terminals [+2/B1, -] for connecting external brake unit



- Connect a brake resistor or brake unit in applications with frequent deceleration ramps, short deceleration time, too low brake torque or requiring increased brake torque.
- If the AC motor drive has a built-in brake chopper, connect the external brake resistor to the terminals [+2/B1, B2].
- Some models of VFD-F series don't have a built-in brake chopper, please connect an external optional brake unit and brake resistor.
- When not used, please leave the terminals [+2(+2/B1), -] open.





WARNING!

Short-circuiting [B2] or [-] to [+2/B1] can damage the AC motor drive.



3.4 Control Terminals



3

Terminal symbols and functions

Terminal Symbols	Terminal Functions	Factory Settings
FWD	Forward-Stop command	
REV	Reverse-Stop command	
EF	External fault	
MI1	Multi-function Input 1	Factory setting: Multi-step speed command 1
MI2	Multi-function Input 2	Factory setting: Multi-step speed command 2
MI3	Multi-function Input 3	Factory setting: Multi-step speed command 3
MI4	Multi-function Input 4	Factory setting: Multi-step speed command 4
MI5	Multi-function Input 5	Factory setting: RESET
MI6	Multi-function Input 6	Factory setting: JOG
MI7	Multi-function Input 7	Factory setting: Accel/Decel prohibit
MI8	Multi-function Input 8	Factory setting: Accel/Decel time switch 1
+24V	DC Voltage Source	(+24V, 20mA), used for source mode.
DCM	Digital Signal Common	Used as common for digital inputs and used for sink mode.
RA 1	Multi-function Relay1 output (N.O.) a	1.5A(N.O.)/1A(N.C.) 240VAC 1.5A(N.O.)/1A(N.C.) 24VDC Refer to Pr.03-00 to Pr.03-01
RB 1	Multi-function Relay1 output (N.C.) b	
RC 1	Multi-function Relay1 common	
RA 2	Multi-function Relay2 output (N.O.) a	
RB 2	Multi-function Relay2 output (N.C.) b	
RC 2	Multi-function Relay2 common	




Terminal Symbols	Terminal Functions	Factory Settings
+10V	Potentiometer power source	+10V 20mA
AVI	Analog voltage Input	0 to +10V correspond to Max. operation frequency
ACI 1/2	Analog current Input	4 to 20mA correspond to Max. operation frequency
AFM 1	Analog frequency /current meter 1	0 to 10V correspond to Max. operation frequency
AFM 2	Analog frequency /current meter 2	4 to 20mA correspond to 2 times of output current
ACM	Analog control signal (common)	

* Control signal wiring size: 18 AWG (0.75 mm²).

Analog input terminals (ACI1, ACI2, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor and ferrite core as indicated in the following diagrams:



wind each wire 3 times or more around the core


Digital inputs (FWD, REV, MI1~MI8, DCM)

- When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.



3.5 Specifications for Power Terminals and Control Terminals

Frame B



Power Terminals:


R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2/B1, -, B2

Models	Wire Gauge	Torque	Wire Type
VFD007F23A	12-24 AWG, (3.3-0.2mm ²)	18kgf-cm (15.6in-lbf)	Stranded Copper only, 75°C
VFD007F43A			
VFD007F43H			
VFD015F23A			
VFD015F43A			
VFD015F43H			
VFD022F23A			
VFD022F43A			
VFD022F43H			
VFD037F23A			
VFD037F43A			
VFD037F43H			

Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)

Frame C



Power Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2/B1, -, B2

Models	Wire Gauge	Torque	Wire Type
VFD055F23A	12-8 AWG, (3.3-8.4mm ²)	30kgf-cm (26in-lbf)	Stranded Copper only, 75°C
VFD055F43B			
VFD055F43H			
VFD075F23A			
VFD075F43B			
VFD075F43H			
VFD110F23A			
VFD110F43A			
VFD110F43H			
VFD150F43A			
VFD150F43H			

NOTE


If wiring of the terminal utilizes the wire with a diameter of 6AWG.(13.3mm²), it is thus necessary to use the Recognized Ring Terminal to conduct a proper wiring.

Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)



Frame D



Power Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2, -,

Models	Wire Gauge	Torque	Wire Type
VFD150F23A	8-2 AWG. (8.4-33.6mm ²)	30kgf-cm (26in-lbf)	Stranded Copper only, 75°C
VFD185F23A			
VFD185F43A			
VFD185F43H			
VFD220F23A			
VFD220F43A			
VFD220F43H			
VFD300F43A			
VFD300F43H			


NOTE

If wiring of the terminal utilizes the wire with a diameter of 1AWG.(42.4mm²), it is thus necessary to use the Recognized Ring Terminal to conduct a proper wiring.

Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)

Frame E



Power Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2, -,


Models	Wire Gauge	Torque	Wire Type
VFD300F23A	1/0-4/0 AWG. (53.5-107.2mm ²)	200kgf-cm (173in-lbf)	Stranded Copper only, 75℃
VFD370F23A	3/0-4/0 AWG. (85-107.2mm ²)		
VFD750F43A			
VFD750F43H			
VFD900F43C			
VFD900F43H	4/0 AWG. (107.2mm ²)	57kgf-cm (49.5in-lbf)	
VFD370F43A	3 AWG. (26.7mm ²)		
VFD370F43H			
VFD450F43A			
VFD450F43H			
VFD550F43A	2 AWG. (33.6mm ²)	200kgf-cm (173in-lbf)	
VFD550F43H	1/0-4/0 AWG. (53.5-107.2mm ²)		
VFD550F43H			
VFD550F43H			

Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)



Frame G




Power Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, +2, -

Models	Wire Gauge	Torque	Wire Type
VFD1100F43C VFD1100F43H VFD1320F43A VFD1320F43H VFD1600F43A VFD1600F43H	4/0 AWG - 300MCM (107.2-152mm ²)	300kgf-cm (260in-lbf)	Stranded Copper only, 75°C

NOTE


It needs following additional terminal when wiring, and add insulation sheath on position where following figure shows.



Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)

Frame H




Power Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, $\oplus$, +1, -

Models	Wire Gauge	Torque	Wire Type
VFD1850F43A VFD1850F43H VFD2200F43A VFD2200F43H	500 MCM (max)	408kgf-cm (354 in-lbf)	Stranded copper only, 75°C

NOTE

It needs following additional terminal when wiring, and add insulation sheath on position where following figure shows.




Control Terminals:

Wire Gauge	Torque
12-24AWG. (3.3-0.2mm ²)	4kgf-cm (3in-lbf)




3.6 Wiring Notes: PLEASE READ PRIOR TO INSTALLATION.

1. **CAUTION:** Do not connect the AC power to the U/T1, V/T2, W/T3 terminals, as it will damage the AC drive.
2. **WARNING:** Ensure all screws are tightened to the proper torque rating.
3. During installation, follow all local electrical, construction, and safety codes for the country the drive is to be installed in.
4. Ensure that the appropriate protective devices (circuit breaker or fuses) are connected between the power supply and AC drive.
5. Make sure that the leads are connected correctly and the AC drive is properly grounded. (Ground resistance should not exceed 0.1Ω .)
6. Use ground leads that comply with AWG/MCM standards and keep them as short as possible.
7. Multiple VFD-F units can be installed in one location. All the units should be grounded directly to a common ground terminal. The VFD-F ground terminals may also be connected in parallel, as shown in the figure below. **Ensure there are no ground loops.**



8. When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U, V, and W, respectively, the motor will rotate counterclockwise (as viewed from the shaft ends of the motor) when a forward operation command is received. To reverse the direction of motor rotation, switch over any of the two motor leads.
9. Make sure that the power source is capable of supplying the correct voltage and required current to the AC drive.
10. Do not attach or remove wiring when power is applied to the AC drive.
11. Do not inspect components unless inside "CHARGE" lamp is turned off.
12. Do not monitor the signals on the circuit board while the AC drive is in operation.

13. For the single-phase rated AC drives, the AC power can be connected to any two of the three input terminals R/L1, S/L2, T/L3. **Note: This drive is not intended for the use with single-phase motors.**
14. Route the power and control wires separately, or at 90° angle to each other.
15. If a filter is required for reducing EMI (Electro Magnetic Interference), install it as close as possible to AC drive. EMI can also be reduced by lowering the Carrier Frequency.
16. If the AC drive is installed in the place where a load reactor is needed, install the filter close to U/T1, V/T2, W/T3, side of AC drive. Do not use a Capacitor or L-C Filter (Inductance-Capacitance) or R-C Filter (Resistance-Capacitance), unless approved by Delta.
17. When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above, and not less than 0.1-second detection time to avoid nuisance tripping. For the specific GFCI of the AC motor drive, please select a current sensor with sensitivity of 30mA or above.
18. To improve the input power factor, to reduce harmonics and provide protection from AC line disturbances (surges, switching spikes, short interruptions, etc.), AC line reactor should be installed when the power supply capacity is 500kVA or more.
19. There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To prevent damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.





3.7 Motor Operation Precautions

1. When using the AC drive to operate a standard 3-phase induction motor, notice that the energy loss is greater than for an inverter duty motor.
2. Avoid running a standard induction motor at low speed. Under these conditions, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan.
3. When the standard motor operates at low speed, the output load must be decreased.
4. If 100% output torque is desired at low speed, it may be necessary to use a special "inverter-duty" rated motor.



CHAPTER 4 DIGITAL KEYPAD OPERATION


This chapter describes the various controls and indicators found on the digital keypad. The information in this chapter should be read and understood before performing the start-up procedures described in the chapter of parameter settings.

- ↳ Description of the Keypad
- ↳ Description of Display
- ↳ Keypad Operation Modes & Programming Steps



4.1 VFD-PU01

4.1.1 Description of the Digital Keypad VFD-PU01



4.1.2 Explanation of Display Message

Display Message	Descriptions
	Display the AC drive Master Frequency.
	Display the actual operation frequency present at terminals U/T1, V/T2, and W/T3.
	Display voltage (V), Current (A), power factor and feedback signal (P)
	Display the output current present at terminals U/T1, V/T2, and W/T3.



Display Message	Descriptions
	Display the AC drive forward run status.
	The AC drive reverse run status.
	Display the specified parameter setting.
	Display the actual value stored within the specified parameter.
	External Fault.
	Display "End" for approximately 1 second if input has been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the or keys.
	Display "Err", if the input is invalid.



4.1.3 Operation steps of the Digital Keypad VFD-PU01


Selecting mode

START



Note : In the selection mode, press **PROG DATA** to set the parameters.

Setting parameters



NOTE :In the parameter setting mode, you can press **MODE** to return the selecting mode.

To shift data

START



To modify data

START



Setting direction





4.2 KPF-CC01

For models of VFD-F (HVAC) series


VFD007F43H; VFD015F43H; VFD022F43H; VFD037F43H; VFD055F43H; VFD075F43H;
VFD110F43H; VFD150F43H; VFD185F43H; VFD220F43H; VFD300F43H; VFD370F43H;
VFD450F43H; VFD550F43H; VFD750F43H; VFD900F43H; VFD1100F43H; VFD1320F43H;
VFD1600F43H; VFD1850F43H; VFD2200F43H

NOTE

When KPF-CC01 is connected on AC motor drive, the communication protocol is forced to be 9600, 8, N, 2. After KPF-CC01 is disconnected, and AC motor drive immediately gets connection with other controller by RS-485, 1st communication fault may occur due to different communication protocol. AC motor drive will automatically reset communication protocol as previous parameter setting from 2nd communication.

4.2.1 Description of the Digital Keypad KPF-CC01

4



4.2.2 Explanation of Display Message


Display Message	Description
Setpoint 60.00 Hz	The AC motor drive Master Frequency Command.
Output Frequency 0.00 Hz	The Actual Operation Frequency present at terminals U, V, W.



Display Message	Description
Load current 0.0 Amp	The output current present at terminals U, V, W.
Basic P01.00=	The specified group description.
Max Voltage Freq P01.01= 60.00Hz	The specified parameter description and setting
Read Block 1 - Empty Address -	Copy Mode: Press MODE key for about 2~3 seconds in main page. Use UP/DOWN key to select copy function (Read, Write, Delete) and LEFT/RIGHT key to select memory address. Total two blocks are available.
Copy to KeyPad? <Block 1> No	Use UP/DOWN key to confirm copy function. Press PROG/DATA key to execute.
External Fault	External Fault.
Value Accepted	Input data is accepted.
Invalid Data	Input data is invalid.

4.2.3 KPF-CC01 Operation Flow Chart

KPF-CC01 Operation Flow Chart





CHAPTER 5 DESCRIPTION OF PARAMETER SETTINGS

✎: This parameter can be set during operation.

5.1 Group 0: AC Drive Status Parameters

📖 Group 0 is read-only.

00 - 00	Software Version	Factory setting: Read Only
----------------	------------------	----------------------------

📖 This parameter displays the software version of AC drive.

00 - 01	AC Drive Status Indication 1	Factory setting: Read Only
----------------	------------------------------	----------------------------

📖 This parameter displays the AC drive status.

Code	AC Drive Status	Explanation
00	No fault occurred	
01	oc	over current
02	ov	over voltage
03	oH	over temperature
04	oL	overload
05	oL1	electronic thermal relay
06	EF (external fault)	EF-DCM is closed
07	occ (AC drive IGBT fault)	IGBT short circuit protection
08	cF3 (CPU failure)	Abnormal A/D reading during self-check
09	HPF (hardware protection failure)	Hardware protection function activated during self-check.
10	ocA (over current during acceleration)	Output current exceeds protection level during acceleration
11	ocd (over current during deceleration)	Output current exceeds protection level during deceleration
12	ocn (over current during steady state operation)	Output current exceeds protection level during steady state operation.
13	GFF (ground fault)	Ground fault protection feature activated
14	Lv (under voltage)	Low input voltage
15	cF1	EEPROM input data is abnormal
16	cF2	EEPROM output data is abnormal
17	bb (base block)	BB is set and activated
18	oL2 (motor over load 2)	Output current exceeds rated motor current
19	Reserved	
20	codE	software or password protection
21	EF1 (external emergency stop)	EF1 (a multifunction-DCM is enabled)
22	PHL (phase loss)	Input power lacks phase. 3-phase input power is unbalance and exceeds specification.
23	Lc (Low Current)	Low current detection during operation.
24	FbL(Feedback Loss)	Feedback signal is abnormal.
25	Reserved	



Code	AC Drive Status	Explanation
26	FAnP	Fan Power Fault
27	FF1	Fan 1 Fault
28	FF2	Fan 2 Fault
29	FF3	Fan 3 Fault
30	FF123	Fan 1, 2, 3 Fault
31	FF12	Fan 1, 2 Fault
32	FF13	Fan 1, 3 Fault
33	FF23	Fan 2, 3 Fault
34	Fv	Gate Drive Low Voltage Protect

00 - 02	AC Drive Status Indication 2	Factory setting: Read Only
Display	Bit 0~1: 00: Run LED is off and STOP led is on. (AC Drive stopping) 01: Run LED is blink and STOP led is on. (AC Drive deceleration to stop) 10: Run LED is on and STOP led is blink. (AC Drive standby) 11: Run LED is on and STOP led is off. (AC Drive running) Bit 2: 1: Jog on. Bit 3~4: 00: Rev LED is off and FWD led is on. (Forward) 01: Rev LED is blink and FWD led is on. (Reverse to Forward) 10: Rev LED is on and FWD led is blink. (Forward to Reverse) 11: Rev LED is on and FWD led is off. (Reverse) Bit 5-7: Reserved Bit 8: Master frequency source via communication interface Bit 9: Master frequency source via analog Bit10: Running command via communication interface Bit11: Parameter locked Bit12~15: Reserved	

00 - 03	Frequency Setting	Factory setting: Read Only
	This parameter displays the frequency command set by the user.	

00 - 04	Output Frequency	Factory setting: Read Only
	This parameter displays actual output frequency of the AC drive.	

00 - 05	Output Current	Factory setting: Read Only
	This parameter displays actual output current of the AC drive.	

00 - 06	DC-BUS Voltage	Factory setting: Read Only
	This parameter displays DC-BUS voltage of the AC drive.	

00 - 07	Output Voltage	Factory setting: Read Only
	This parameter displays output voltage of the AC drive.	



00 - 08	Output Power Factor	Factory setting: Read Only
	This parameter displays output power factor.	
00 - 09	Output Power (kW)	Factory setting: Read Only
	This parameter displays output power of the AC drive.	
00 - 10	Feedback Signal Actual Value	Factory setting: Read Only
	This parameter displays feedback signal value.	
00 - 11	Feedback Signal (%)	Factory setting: Read Only
	This parameter displays feedback signal value (%).	
00 - 12	User Target Value (Low bit) uL 0-99.99	Factory setting: Read Only
00 - 13	User Target Value (High bit) uH 0-9999	Factory setting: Read Only
	User Target Value = Actual output frequency (0-04) × User Defined Multiplier (02-10).	
	Maximum summed display of both parameters is 999999.99.	
	When User Target Value <=99.99, 00-13=0.	
00 - 14	PLC time	Factory setting: Read Only
	This parameter displays remaining time of PLC each phase.	
00-15	Stall torque output(N.M.)	
	This parameter shows stall torque output in Newton meter.	



5.2 Group 1: Basic Parameters

01 - 00 Maximum Output Frequency Factory Setting: 60.00

Settings 50.00~120.00Hz

- This parameter determines the AC drives maximum output frequency. All master frequency commands set by the keypad or analog inputs are limited by this parameter. The analog commands (AVI, ACI1 and ACI2) may be scaled to correspond to the output frequency range. (Please refer to 04-09~04-20.)

01 - 01 Maximum Voltage Frequency (Base Frequency) Factory Setting: 60.00

Settings 0.10~120.00 Hz

- This parameter sets the frequency, where the maximum output voltage (Pr. 01-02) will be reached. The output frequency may exceed this setting, but the output voltage doesn't increase beyond this point. This parameter should be set according to the rated frequency of the motor as indicated on the motor nameplate.
- If this parameter setting is smaller than the rated frequency of the motor, nuisance over current faults or damage to the AC drive may occur.
- If this parameter setting is greater than the rated frequency of the motor, the motor will encounter torque loss.

01 - 02 Maximum Output Voltage Factory Setting: 220.0/440.0

Settings 230V series: 0.1 ~ 255.0V
 460V series: 0.2 ~ 510.0V

- This parameter determines the Maximum Output Voltage of the AC drive. This parameter setting should be set according to rated voltage of the motor as indicated on the motor nameplate. If rated voltage of the motor is 440V, this parameter must be set to 440V. If rated voltage of the motor is 380V, this parameter must be set to 380V.
- If this setting is greater than the rated voltage of the motor, nuisance over current faults or damage to the AC drive may occur.

01 - 03 Mid-point Frequency Factory Setting: 1.50

Settings 0.10~120.00 Hz

- This parameter sets the Mid-point Frequency of the V/f curve.
- This parameter must meet the following argument. Pr.1-01 >= Pr.1-03 >= Pr.1-05.



01 - 04 Mid-point Voltage

Factory Setting: 5.5/11.0

Settings 230V series: 0.1 ~ 255.0V

460V series: 0.2 ~ 510.0V

This parameter sets the Mid-point Voltage of the V/f curve.

This parameter must meet the following argument. Pr.1-02 >= Pr.1-04 >= Pr.1-06.

01 - 05 Minimum Output Frequency

Factory Setting: 1.50

Settings 0.10~20.00 Hz

This parameter sets the Minimum Output Frequency of the AC drive. This parameter must be lower than or equal to the Mid-point frequency

01 - 06 Minimum Output Voltage

Factory Setting: 5.5/11.0

Settings 230V series: 0.1 ~ 50.0V

460V series: 0.2 ~100.0V

This parameter sets the Minimum Output Voltage of the AC Drive. The parameter must be lower than or equal to the Mid-point Voltage.

01 - 07 Upper Bound Frequency

Factory Setting: 60.00

Settings 0.00~120.00 Hz

This parameter will limit the maximum output frequency of AC drive. If slip compensation (Pr.07-02~07-05) or feedback control (Pr.10-00~10-09) are enabled, the output frequency of AC drive may exceed the Master Frequency Command, but it will continue to be limited by this parameter setting.

01 - 08 Lower Bound Frequency


Factory Setting: 0.00

Settings 0.00~120.00 Hz

This parameter will limit the minimum output frequency. Any Master Frequency Command below Pr.1-08 will result in an output equal to Pr.1-08.

Upon a start command, the drive will accelerate from Pr.1-05 Minimum Output Frequency to the Master Frequency Command point.

The Lower Bound Frequency setting must be smaller than the Dwell Frequency (Pr.11-08>=01-08). If lower bound frequency setting is greater than the Dwell Frequency, the AC drive will equalize the two settings to the Lower Bound point.



01 - 09	Acceleration Time 1	⚡	Factory Setting: 10.0/60.0
01 - 10	Deceleration Time 1	⚡	Factory Setting: 10.0/60.0
01 - 11	Acceleration Time 2	⚡	Factory Setting: 10.0/60.0
01 - 12	Deceleration Time 2	⚡	Factory Setting: 10.0/60.0
01 - 13	Acceleration Time 3	⚡	Factory Setting: 10.0/60.0
01 - 14	Deceleration Time 3	⚡	Factory Setting: 10.0/60.0
01 - 15	Acceleration Time 4	⚡	Factory Setting: 10.0/60.0
01 - 16	Deceleration Time 4	⚡	Factory Setting: 10.0/60.0
01 - 17	JOG Acceleration Time	⚡	Factory Setting: 10.0/60.0
01 - 18	JOG Deceleration Time	⚡	Factory Setting: 10.0/60.0

Settings

0.1~3600.0 Sec

Unit: 0.1sec

- Acceleration time is the time required for the AC drive to ramp from 0 Hz to its Maximum Output Frequency (Pr.1-00). Deceleration time is the time required for the AC drive to decelerate from Maximum Output Frequency (Pr.1-00) down to 0 Hz.
- An Acceleration or Deceleration time that is too quick, may cause the AC drives protection features to enable (over-current stall prevention during Accel 06-01 or over-voltage stall prevention 06-00). If this occurs, the actual Accel/Decel time will be longer than this setting.
- Warning: An acceleration or deceleration that is too quick, may cause excess loads on the AC drive and may permanently damage the drive.
- If you want to decelerate the AC drive in short time period, we recommend to add an external brake module and brake resistor.
- You can set 1st to 4th Accel/Decel time via multi-function input terminals 04-00 to 04-07.



01 - 19	JOG Frequency		Factory Setting: 6.00
----------------	----------------------	--	------------------------------

Settings 0.0 Hz~120.00 Hz

Unit: 0.1sec

- When the JOG function is to be utilized, users need to use the multi-function input terminals (Pr. 04-00 to 04-07 set to 07) or the JOG key on keypad. Once a JOG command is initiated, the AC drive will accelerate from the Minimum Output Frequency (Pr.01-05) to the JOG frequency (Pr.01-19).
- The accel/decel time of the JOG operation is determined by the JOG accel/decel speed (Pr.01-17 and 01-18).
- When the drive is in operation, the JOG command is disabled.

01 - 20	S Curve Delay Time in Accel	Factory Setting: 0.00
----------------	------------------------------------	------------------------------

01 - 21	S Curve Delay Time in Decel
----------------	------------------------------------

Settings 0.00~2.50sec

- These parameters enable the S curve. The longer the S curve time period the smoother the transition between speeds.

01 - 22	Modulation Index		Factory Setting: 1.00
----------------	-------------------------	--	------------------------------

Settings 0.90~1.20

Unit: 0.1

- This parameter sets the ratio of the Maximum Output Voltage to the input voltage.
- The Maximum Output Voltage (Pr.01-02) is normally limited to the input voltage. With the Modulation Index parameter, the user is able to increase the output voltage beyond the incoming line voltage.
- A Modulation Index of 1, defines the Maximum Output Voltage (Pr. 1-02) is equal to the input voltage.
- A Modulation index of 1.2, defines the Maximum Output Voltage (Pr. 1-02) is 20% higher than in the input voltage. Please note, the output voltage wave form will be distorted due to harmonics and may increase torque ripple and noise in the motor.



01 - 23

Accel/Decel Time Unit

Factory Setting: 01

- Settings
- 00: Unit is 1 Sec
- 01: Unit is 0.1 Sec
- 02: Unit is 0.01 Sec

This parameter sets the resolution of accel/decel time (Pr.01-09 to 01-18).

A high resolution decreases the accel/decel time range as shown in the following chart.

01-23	Accel/Decel time unit	Accel/Decel time range
00	1 Sec	1~36000 Sec
01	0.1 Sec	0.1~3600.0 Sec
02	0.01 Sec	0.01~360.00 Sec



5.3 Group 2: Operation Method Parameters

02 - 00	Source of Frequency Command		Factory Setting: 00
Settings	00: via keypad 01: via analog input AVI 02: via analog input ACI1 03: via analog input ACI2 04: via RS485 serial communication 05: via External Reference		

Settings:

- 00: Frequency command source is the keypad. User may use UP/DOWN keys to adjust the frequency command. Also if the Multi-Function Input terminals (Pr.04-00 to 04-07) are set to 13 or 14, their function will be the same as the UP/DOWN keys.
- 01: Frequency command source is the analog input terminal AVI.
- 02: Frequency command source is the analog input terminal ACI1.
- 03: Frequency command source is the analog input terminal ACI2.
- 04: Frequency command source is the RS485 serial communication.
- 05: Frequency command source depends on the setting of Pr. 04-24.

You may use SW2 on the control board to choose between a 0~10V or 0~5V input range. When AVI is set to 0~5V, the voltage input is limited to 5V maximum. The relationship to frequency is 0V = 0 Hz and 5V = Pr1-00.

02 - 01	Source of Operation Command		Factory Setting: 00
Settings	00: Controlled by the digital keypad 01: Controlled by the external terminals, keypad STOP enabled. 02: Controlled by the external terminals, keypad STOP disabled. 03: Controlled by the RS-485 communication interface, keypad STOP enabled. 04: Controlled by the RS-485 communication interface, keypad STOP disabled.		

This parameter sets the operation command source of the AC drive.

When the AC drive is controlled by an external source, you may select 2-wire or 3-wire operation. Please refer to Pr.02-05.




02 - 02

Stop Method

Factory Setting: 00

- Settings
- 00:Stop = ramp to stop, E.F. (External Fault) = coast to stop
- 01:Stop = coast to stop, E.F. = coast to stop
- 02:Stop = ramp to stop, E.F. = ramp to stop
- 03:Stop = coast to stop, E.F. = ramp to stop

- Ramp: The AC drive decelerates the motor to minimum output frequency according to the deceleration time setting.
- Coast: The AC drive output instantly stops upon command and the motor free spins until it comes to a complete stop.
- External Fault may be enabled by the EF terminal or a Multi-Function terminal. Please refer to Pr.04-00 to 04-07.
- Loss of an ACI signal may cause an E.F condition. Please refer to 02-07.



02 - 03

PWM Carrier Frequency Selections

⚡

Unit: 1

- Settings
- 1~10HP 4000~10000Hz
- 15~30HP 3000~9000Hz
- ≥40HP 2000~6000Hz
- Factory Setting: 9000Hz
- Factory Setting: 6000Hz
- Factory Setting: 4000Hz

- This parameter sets the carrier frequency of PWM output. The factory setting and setting range depend on the model type.
- When the temperature of the heat sink is greater than its limit, the AC drive will automatic lower the carrier frequency to avoid over heating the AC drive.

📖 The Carrier frequency of the PWM output has a signification influence on the electromagnetic noise, heat dissipation of the AC drive, and the acoustic noise to the motor as shown in the following chart.

Carrier frequency	Acoustic Noise	Electromagnetic Noise	Leakage Current	Heat Dissipation
Signification	Minimal	Signification	Signification	Signification
↓	↓	↓	↓	↓
Minimal	Signification	Minimal	Minimal	Minimal

📖 When the carrier frequency is low, current ripple of the AC drive is large. This may result in a current display value greater than the actual value.

02 - 04

Forward/Reverse Enable

Factory Setting: 00

- Settings
- 00: Forward/Reverse enabled
- 01: Reverse disabled
- 02: Forward disabled

📖 This parameter enables the direction of the AC drive.

02 - 05

2-wire/3-wire Operation Control Modes

Factory Setting: 00

- Settings
- 00: 2-wire (#1), FWD/STOP, REV/STOP
- 01: 2-wire (#2), RUN/STOP, REV/FWD
- 02: 3-wire

📖 This parameter sets the operation mode when operating by external terminals.

📖 Please refer to 02-01.

02-05	External Terminal
00 (2-wire #1) FWD / STOP REV / STOP	FWD/STOP REV/STOP ○ ○ ○ ○ FWD: ("OPEN":STOP) ("CLOSE":FWD) REV: ("OPEN":STOP) ("CLOSE":REV) DCM VFD-F
01 (2-wire #2) RUN / STOP REV / FWD	RUN/STOP FWD/REV ○ ○ ○ ○ FWD: ("OPEN":STOP) ("CLOSE":RUN) REV : ("OPEN":FWD) ("CLOSE":REV) DCM VFD-F
02 3-wire	STOP FWD/REV ○ ○ ○ ○ RUN FWD ("CLOSE":RUN) EF ("OPEN":STOP) REV ("OPEN":FWD) ("CLOSE":REV) DCM VFD-F




02 - 06		Line Start Lockout	Factory Setting: 01	
Settings		00: Enabled		
		01: Disabled		
		02: If the command to run still remains after resetting, the inverter will continue to run.		
When enabled, the AC drive will not start when powered up with a run command applied. The AC drive must see the run command transition from stop to run after power up. When Line Start Lockout is disabled (also known as Auto-Start), the AC drive will start when powered-up with run commands applied.				
Pr02-06=2 : This determines the following matter. The VFD (Variable-Frequency Drive) detects an error message and eliminates the error. If the command terminal remains running in the external function terminals, you can simply press the RESET button to make the VFD running again.				
02 - 07		ACI (4~20mA) Loss of ACI Signal	Factory Setting: 01	
Settings		00: Decelerate to 0Hz		
		01: E.F.		
		02: Continue operation by the last frequency command		
		03: Use loss of ACI Signal Frequency of Pr02-16		
This parameter determines the AC drives response to a loss of the ACI input.				
02 - 08		Start-up Display Selection		Factory Setting: 00
Settings		Bit0~1: 00 = F LED		
		01 = H LED		
		10 = U LED (special display)		
		11 = Fwd / Rev		
		Bit2: 0 = Fwd LED / 1 = Rev LED		
		Bit3~5: 000 = 1st 7-step		
		001 = 2nd 7-step		
		010 = 3rd 7-step		
		011 = 4th 7-step		
		100 = 5th 7-step		
		Bit6~7: Reserved		
This parameter determines the display on keypad after each power up.				

-  To program this parameter the user must first generate a Hex value with the information above. Then using the Hex to Decimal conversion to find the corresponding Decimal value and enter it into this parameter.
-  For example, a setting of 21 (decimal 21= hex 010101) will display the “H” and “REV” LEDs and the cursor will stay at the 3rd 7-step display upon power up.
-  When setting to U LED, please refer to 02-09.

02 - 09	Special Display		Factory Setting: 00
---------	-----------------	---	---------------------

- Settings
- 00: A displays output current of AC drive
- 01: U displays DC-Bus voltage of AC drive
- 02: E displays RMS of output voltage
- 03: P displays feedback signal
- 04: PLC display auto procedure state
- 05: T displays heat sink’s temperature
- 06: The keypad’s screen displays both target value and feedback value controlled by PID (**Proportional–Integral–Derivative controller (PID controller)**)).

-  This parameter chooses the display on the keypad immediately following the “U” user defined setting.
-  “MODE” key will scroll from “F”, “H”, “U”, (Pr. 02-09), FWD, and back to “F”.
-  Users may also use the “LEFT” key on the digital keypad to switch display content.
-  When Pr02-09 is set to be 6, the keypad’s screen displays both target value and feedback value controlled by PID as shown below.





02 - 10	User Defined Coefficient	⚡	Factory Setting: 1.00
----------------	---------------------------------	---	-----------------------

Settings 0.01~160.00

Unit: 0.01

📖 When this parameter is set, the “H” display value = actual output frequency of AC drive x 02-10.

📖 If output frequency of AC drive is 90Hz, set 02-10 to 2.5. When H LED lights, the value on the display is 225.00.

02 - 11	Flying Start	⚡	Factory Setting: 00
----------------	---------------------	---	---------------------

Settings 00: Disable

01: Enable (DC brake disabled)

📖 When the AC drive starts into a running motor (Flying Start), it may cause an over current on the drive and may damage the motor. Using speed search upon start-up will allow the drive to slowly find the motor speed, smoothly take control of the motor, and bring it to command speed.

📖 If the Flying Start feature is enabled upon start-up, the DC brake 08-01 will be disabled.

02 - 12	Flying Start Frequency	⚡	Factory Setting: 00
----------------	-------------------------------	---	---------------------

Settings 00: Begin search from Master Frequency Command

01: Begin search from Maximum Frequency (Pr.01-00)

02 - 13	Master Frequency Memory Setting	⚡	Factory Setting: 01
----------------	--	---	---------------------

Settings 00: Do not remember the last known frequency

01: Remember the last known frequency

📖 If this parameter is set to 00: The AC drive will not store the last known master frequency command, after power is removed.

📖 If this parameter is set to 01: The AC drive will memorize the last known master frequency command after power off. Upon power up the last known frequency is displayed.

📖 After a fault, the AC drive will always remember the last known master frequency command.

📖 This feature is only enabled when Pr. 02-00 is set for 0 or 4.



02-14	Source of Second Frequency Command		⚡	Factory Setting	00
	Setting Range	00	Master Frequency Setting is controlled by PID controller.		
		01	Master frequency is controlled by an external terminal via analog input AVI: DC 0~+10V.		
		02	Master frequency is controlled by an external terminal via analog input ACI1: DC 4~ 20mA.		
		03	Master frequency is controlled by an external terminal via analog input ACI2: DC 4~ 20mA		
		04	Master frequency is handled via RS485 serial communication (RJ-11).		
		05	External Reference Master frequency via External Reference.		

📖 This parameter sets the source of inverter's second frequency.

5

02-15	Source of Second Operation Command		⚡	Factory Setting	00
	Setting Range	00	Controlled by the digital keypad		
		01	Controlled by the external terminals, keypad STOP enabled.		
		02	Controlled by the external terminals, keypad STOP disabled		
		03	Controlled by the RS-485 communication interface keypad STOP enabled.		
		04	Controlled by the RS-485 communication interface keypad STOP disabled.		

📖 This parameter sets the source of inverter's second operation command.

02-16	Loss of ACI Signal		⚡	Factory Setting	0.00
	Setting Range	0.00-Highest operational frequency			

📖 This parameter sets the loss of ACI signal



5.4 Group 3: Output Function Parameters

03 - 00	Multi-function Output terminal 1 (Relay 1)	Factory Setting: 00
03 - 01	Multi-function Output terminal 2 (Relay 2)	Factory Setting: 00
03 - 02	Multi-function Output terminal 3 (Relay 3)	Factory Setting: 00
03 - 03	Multi-function Output terminal 4 (Relay 4)	Factory Setting: 00
03 - 04	Multi-function Output terminal 5 (Relay 5)	Factory Setting: 00
03 - 05	Multi-function Output terminal 6 (Relay 6)	Factory Setting: 00
03 - 06	Multi-function Output terminal 7 (Relay 7)	Factory Setting: 00
03 - 07	Multi-function Output terminal 8 (Relay 8)	Factory Setting: 00

Setting Range 00-43

Setting	Functions	Descriptions
00	No function	All unused terminals should be set to 00, to assure they have no effect on derive operation.
01	Motor No. 1	When starting circulative control, AC drive will automatic set this parameter by 11-01 ~ 11-03. If there is only one motor available to operate while running circulative control, the circulative control will stop. That means the motor will not be switched.
02	Motor No. 2	
03	Motor No. 3	
04	Motor No. 4	
05	Motor No. 5	
06	Motor No. 6	
07	Motor No. 7	
08	Motor No. 8	
09	Auxiliary 1 output	Parameter value 20 to 26 program Multi-Function Input Terminals (Pr.04-00~Pr.04-07) to correspond with the AC drive multi-function output terminals Pr.03-00 to 03-07 (settings 09-15).
10	Auxiliary 2 output	
11	Auxiliary 3 output	
12	Auxiliary 4 output	
13	Auxiliary 5 output	
14	Auxiliary 6 output	
15	Auxiliary 7 output	
16	Indication during operation	The corresponding output will be closed during operation (including DC brake time).
17	Master frequency attained	The corresponding output will be closed when output frequency reaches master frequency command.
18	Zero Speed (including shutdown)	The corresponding output will be closed when the AC drive has no output voltage signal.
19	Over-torque	The corresponding output relay will be closed when the AC drives output current exceeds the over-torque detection level 06-04.
20	External Fault	The corresponding output will be closed when the EF is enabled. (Pr. 4-00 to 4-07)



Setting	Functions	Descriptions
21	Low voltage detection	The corresponding output will be closed when the DC Bus voltage drops below our threshold. The keypad will display “Lu”.
22	Operation Mode indication	The corresponding output will be closed when the AC drives “Operation Command” is controlled by the external terminals.
23	Fault Indication	The corresponding output will be closed when AC drive has experienced a fault.
24	Master Frequency Attained 1	The corresponding output will be closed when the AC drives output frequency exceeds (Pr.03-08) Master Frequency Attained 1.
25	Master Frequency Attained 2	The corresponding output will be closed when the AC drives output frequency exceeds (Pr.03-09) Master Frequency Attained 2.
26	Over Temperature indication	The corresponding output will be closed when the AC drive temperature exceeds its rating.
27	Drive Ready	The corresponding output will be closed the when the AC drive is ready and has no faults.
28	External Emergency Stop (EF1)	The corresponding output will be closed when multi-function input terminals (Pr.04-00 to 04-07) are set to emergency stop and then activated.
29	Software brake output	The corresponding output will be closed when the AC drives DC bus voltage exceeds (Pr.08-19) the brake level.
30	OL or OL1 overload warning	The corresponding output will be closed upon an overload (OL or OL1) fault.
31	Dwell indication (sleep)	The corresponding output will be closed when the AC drive is in a Dwell status (Pr.11-07).
32	Low current indication	The corresponding output will be closed when the AC drives output current is lower than the Low Current setting (Pr.06-08).
33	PID feedback error indication	The corresponding output will be closed when the PID feedback signal has an error.
34	PLC Program Running	The Output will be activated when PLC Program is running.
35	PLC Program Step Completed	The Output will be activated for 0.5 sec when each multi-step speed is attained.
36	PLC Program Completed	The output will be activated for 0.5 sec when the PLC program cycle has completed
37	PLC Operation Paused	The output will be activated when PLC operation is paused.
38	Loss of an ACI signal Indication	When there is a loss of an ACI signal indication, the corresponding relay output will be closed.
39	HOA-Hand mode indication	Under the Hand mode indication of HOA mode, the corresponding relay output will be closed.



Setting	Functions	Descriptions
40	HOA-Off mode indication	Under the Off mode indication of HOA mode, the corresponding relay output will be closed.
41	HOA-Auto mode indication	Under the Automatic mode indication of HOA mode, the corresponding relay output will be closed.
42	Fire mode indication	When Fire mode indication is activated, the corresponding relay output will be closed.
43	Bypass fire mode indication	Under the Bypass fire mode indication, the corresponding relay output will be closed.

The VFD-F has two form C relays (multi-function output 1 and 2). There is an optional External Relay Card with 6 NO contact relays (multi-function outputs 3-8).


External relay specifications = 8A/250VAC or 5A/30VDC.

Relay delay time is 5~10 msec.

03 - 08	Master Frequency Attained 1	Factory Setting: 0.00
03 - 09	Master Frequency Attained 2	
Settings		0.00~120.00 Hz
		Unit: 0.01

An output relay may be programmed to activate when the output frequency exceeds the desired attained frequency setting of these two parameters.

There is a $\pm 2\text{Hz}$ window of operation. If the master frequency attained is 20Hz and the output frequency exceeds 20Hz, the corresponding output relay will be “closed”. When the output frequency is less than 18Hz, the corresponding output relay will be “opened” as the following diagram shows.





03 - 10	Analog Output 1, (AFM1) 0~10Vdc	Factory Setting: 00
03 - 11	Analog Output 2, (AFM2) 0/4~ 20mA	Factory Setting: 01

Settings 00: Output frequency
 01: Output current
 02: Output voltage
 03: Frequency command
 04: Power factor loading

These parameters select the content of the analog output signals AFM1 and AFM2.

Setting 00: 0-10V = 0 - (Pr.01-00)

Setting 01: 0-10V = 0 - (2.52.0 x rated current)

Setting 02: 0-10V = 0 - (Pr.01-02)

Setting 03: 0-10V = 0 - Master Freq. command

Setting 04: 0-10V = 0.0 - output power factor 1.0

When using 0-20mA output, please refer to Pr. 3-14.

Maximum impedance loading of analog output 2 (AFM2) can't be greater than 500 ohms.

03 - 12	Analog Output Gain 1		Factory Setting: 100
03 - 13	Analog Output Gain 2		Factory Setting: 100
	Settings 01~200%		

This parameter is to determine analog output gain.

The analog output is limited to 10V and 20mA. The gain is designed to offer a normally small output signal to be enlarged for easier viewing on a meter.

03 - 14	Analog Output 2 Selection	Factory Setting: 01
	Settings 00: 0~20mA 01: 4~20mA	

This parameter selects the output range of Analog Output 2 (AFM2).



03 - 15

DC Fan Control

Factory Setting: 00

- Settings
- 00: Fan runs on power up.

01: Fan begins upon a RUN command. Fan stops 1 minute after a STOP command.

02: Fan begins upon a RUN command. Fan stops after a STOP command

03: Fan is controlled by temperature. Approximately a 60°C temperature will start the fan.

04: Unusual Fan status warning, inverter continues to run.
- (This setting is only available in the existing firmware v.3.104,

the new released version v.1.302 and the versions above v.1.302)

 This parameter determines DC fan control method.



5.5 Group 4: Input Function Parameters

04 - 00	Multi-function Input terminal 1	Factory Setting: 01
04 - 01	Multi-function Input terminal 2	Factory Setting: 02
04 - 02	Multi-function Input terminal 3	Factory Setting: 03
04 - 03	Multi-function Input terminal 4	Factory Setting: 04
04 - 04	Multi-function Input terminal 5	Factory Setting: 05
04 - 05	Multi-function Input terminal 6	Factory Setting: 07
04 - 06	Multi-function Input terminal 7	Factory Setting: 08
04 - 07	Multi-function Input terminal 8	Factory Setting: 09

Settings 00~43

Setting	Functions	Descriptions
00	No function	All unused terminals should be set to 00, to assure they have no effect on drive operation.
01	Multi-Speed terminal 1	Allows selection of the 15 multi-step speeds. Please refer to 05-00 to 05-14 to program the 15 step speeds.
02	Multi-Speed terminal 2	
03	Multi-Speed terminal 3	
04	Multi-Speed terminal 4	
05	Reset (NO)	- Clears (Reset) a fault and returns the AC drive to normal operation. - When the AC Drive doesn't work properly, this terminal and the Stop/Reset key on the keypad share the same function.
06	Reset (NC)	
07	Jog operation (JOG)	- This terminal and the JOG key on the keypad share the same function. - When the AC Drive is functioning, this terminal is disabled.
08	Accel/Decel disable	It stops the acceleration or deceleration of the AC drive. AC drive then maintains a constant speed.
09	Accel/Decel 2 selection	- You can combine these two terminals and choose between Accel/Decel time 1 to 4 in Pr01-09 to Pr01-16. - Don't do Accel/Decel time selection, but the AC drive choose automatically Accel/Decel time 1 as the Accel/Decel time
10	Accel/Decel 3 selection	
11	B.B. (NO) input	Enables the base block (pause) function. Please refer to Pr.08-08, for base block functions.
12	B.B. (NC) input	
13	Increase Frequency	This terminal shares the same function as the Up/Down key on the keypad to adjust the master



Setting	Functions	Descriptions
14	Decrease Frequency	frequency command. ● This terminal is only available when the AC drive is functioning. This terminal is disabled while the AC drive is not functioning ● When this terminal is working, master frequency can be adjusted Up/Down at the real output frequency. The adjusting rate of master frequency command is related to the Accel/Decel time.
15	Emergency stop (NO)	Generates an external fault (EF1). The function is identical to the external terminal (EF).
16	Emergency stop (NC)	
17	AVI(open), ACI1(close)	External selection of the Master Frequency command. (Analog input AVI = terminal open) or (ACI1 = terminal closed). This setting over-rides Pr.02-00.
18	KEYPAD(open), EXT(close)	● External selection of the Operation Command Source. (Keypad = terminal open) or (External terminals = terminal closed). This setting is valid when Pr.02-01 is set to 00. Otherwise, the Operation Command Source will follow the setting in Pr.02-01. ● When this terminal is set, the master frequency command from Pr02-01 is automatically disabled.
19	PID disable	Disable PID feedback control and operate via Master Frequency Command source Pr.02-00.
20	Auxiliary 1 input	Parameter value 20 to 26 program Multi-Function Input Terminals (Pr.04-00~Pr.04-07) to correspond with the AC drive multi-function output terminals Pr.03-00 to 03-07 (settings 09-15).
21	Auxiliary 2 input	
22	Auxiliary 3 input	
23	Auxiliary 4 input	
24	Auxiliary 5 input	
25	Auxiliary 6 input	
26	Auxiliary 7 input	
27	Motor No.1 output disable	When multiple motors are controlled by an AC drive, these settings will allow the corresponding motor to disable and ignore this motor. AC drive will not accept a "Motor Output Disabled" signal when it is running.
28	Motor No.2 output disable	
29	Motor No.3 output disable	
30	Motor No.4 output disable	
31	All motor outputs disable	When multiplex motors are in circulative control mode, this terminal can stop the motor that power supply is not from AC drive and set the circulative control mode disable. Now only the motor in running keeps running.



Setting	Functions	Descriptions									
32	Run PLC Program	Parameter value 32 programs Multi-Function Input Terminal to enable the AC drive internal PLC program. Parameter value 33 programs an input terminal to pause the PLC program. Note: Pr.05-00 to Pr.05-16 defines the PLC program.									
33	Pause PLC Program										
34	Enable source of the second frequency	This terminal allows you to choose the master frequency or the second one.									
35	Enable the source of second operation command	This terminal allows you to choose the master operation command or the second one.									
36	Motor No.5 output disabled	When multiple motors are controlled by an AC drive, these settings will allow the corresponding motor to disable and ignore this motor. AC drive will not accept the “Motor Output Disabled signal” when it is running.									
37	Motor No.6 output disabled										
38	Motor No.7 output disabled										
39	Motor No.8 output disabled										
40	HOA-Hand mode indication	This terminal enables HOA function. <table border="1"> <tr> <td></td><td>MI40 ON</td><td>MI40 OFF</td></tr> <tr> <td>MI41 ON</td><td>Off mode</td><td>Auto mode</td></tr> <tr> <td>MI41 OFF</td><td>Hand mode</td><td>Off mode</td></tr> </table>		MI40 ON	MI40 OFF	MI41 ON	Off mode	Auto mode	MI41 OFF	Hand mode	Off mode
	MI40 ON	MI40 OFF									
MI41 ON	Off mode	Auto mode									
MI41 OFF	Hand mode	Off mode									
41	HOA-Auto mode indication	Pr02-00 Refer to Pr02-00 for the source of frequency Auto mode : Pr02-14 Refer to Pr02-14 for the source of frequency. Pr02-15 Refer to Pr02-15 for source of operation command Off mode: AC Drive is permanently off.									
42	(NO) Fire mode (NO)	In accordance with Pr11-15[Fire Mode], this terminal can start the Fire Mode									
43	Fire mode (NC)										



04 - 08 Digital Input Terminal Response Time

Factory Setting: 01

Settings 01~20

- This parameter selects the response time of digital input terminals MI1 to MI8, EF, REV and FWD.
- AC drive will scan the digital input terminals once every 2msec. During each scan the drive will check the status of each terminal (open or closed).
- In noisy environments, it would be advantageous to verify the terminal status several times before executing a new command, nearly eliminating false signals.
- Example: If Pr.04-08 is set to 4, the AC drive will confirm the terminal status ($4+1 = 5$) 5 times before a change is made. This correlates to an 8~10msec time response from input command to execution.
- It is not recommended to set this parameter to 00, since interference may cause improper operation of the AC drive.

04 - 09 AVI Minimum Voltage

Factory Setting: 0.0

04 - 10 AVI Maximum Voltage

Factory Setting: 10.0

Settings 0.0 ~ 10.0V

Unit: 0.1

04 - 11 AVI Minimum Frequency (percentage of Pr.1-00)

Factory Setting: 0.00

04 - 12 AVI Maximum Frequency (percentage of Pr.1-00)

Factory Setting: 100.00

Settings 0.00~100.00%

Unit: 0.01

04 - 13 ACI1 Minimum Current

Factory Setting: 4.0

04 - 14 ACI1 Maximum Current

Factory Setting: 20.0

Settings 0.0 ~ 20.0mA

Unit: 0.1

04 - 15 ACI1 Minimum Frequency (percentage of Pr.1-00)

Factory Setting: 0.00

04 - 16 ACI1 Maximum Frequency (percentage of Pr.1-00)

Factory Setting: 100.00

Settings 0.0~100.0%

Unit: 0.01

04 - 17 ACI2 Minimum Current

Factory Setting: 4.0

04 - 18 ACI2 Maximum Current

Factory Setting: 20.0


Settings 0.0 ~ 20.0mA

Unit: 0.1


04 - 19	ACI2 Minimum frequency (percentage of Pr.1-00)	Factory Setting: 0.00
04 - 20	ACI2 Maximum frequency (percentage of Pr.1-00)	Factory Setting: 100.00
Settings		0.00~100.00%
		Unit: 0.01

 The above parameters are used to set the analog input reference values. The min and max frequencies are based on Pr.01-00 (during open-loop control) or the PID reference value Pr.10-01 (during PID close-loop control).

Please refer to the following diagram for more details:



 Example: Using the AVI (0~10V) as the target source and ACI1 (4~20mA corresponds to 0~5Pa) and ACI2 (0~10mA corresponds to 0~4Pa) as the feedback location for a pressure sensor connected. If your target value is between 3~7Pa (Set Pr.10-01 to 10, other parameters settings refer Pr.10-01 to set as shown in the following diagram and then setting the PID feedback relative parameters.) If setting AVI to 7.5V, pressure sum of ACI1 and ACI2 could be controlled at 6Pa.



When analog input current of ACI1/ACI2 is lower than Pr.04-13/Pr.04-17, EF warning will pup-up.

04 - 21	Analog Input Delay AVI	Factory Setting: 0.50
04 - 22	Analog Input Delay ACI1	Factory Setting: 0.50
04 - 23	Analog Input Delay ACI2	Factory Setting: 0.50
Settings 0.00 ~ 10.00 Sec		Unit: 0.01

This parameter selects the time constant for the analog input signal filter. A properly adjusted time constant may help filter noise on the analog input terminals.

If the input delay is set too long, the system may experience oscillation. Be careful setting these parameters.



04 - 24		Summation of External Frequency Sources	Factory Setting: 00
Settings	00: No functions 01: AVI+ACI1 02: ACI1+ACI2 03: ACI2+AVI 04: Communication master frequency +AVI 05: Communication master frequency +ACI1 06: Communication master frequency +ACI2 07: First frequency + Second Frequency 08: First frequency - Second Frequency		

This parameter selects the terminals used for summation of the External Frequency Sources.

04-25		Summation of First External Frequency Source		Factory Setting	00
	Setting Range	00	Digital Keypad		
		01	AVI External Terminal AVI		
		02	External Terminal ACI1		
		03	External Terminal ACI2		
		04	RS-485 communication interface		

04-26		Summation of Second External Frequency Source		Factory Setting	00
	Setting Range	00	Digital Keypad		
		01	External Terminal AVI		
		02	External Terminal ACI1		
		03	External Terminal ACI2		
		04	RS-485 Communication Interface		



5.6 Group 5: Multi-step Speed Frequency Parameters

05 - 00	1 st Step Speed Frequency	↗	Factory Setting: 0.00
05 - 01	2nd Step Speed Frequency	↗	Factory Setting: 0.00
05 - 02	3rd Step Speed Frequency	↗	Factory Setting: 0.00
05 - 03	4th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 04	5th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 05	6th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 06	7th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 07	8th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 08	9th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 09	10th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 10	11th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 11	12th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 12	13th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 13	14th Step Speed Frequency	↗	Factory Setting: 0.00
05 - 14	15th Step Speed Frequency	↗	Factory Setting: 0.00

Settings 0.00~120.00 Hz

Unit: 0.01

The Multi-Function Input Terminals (refer to Pr.04-00 to 04-07) are used to select one of the AC drive Multi-Step speeds. The speeds (frequencies) are determined by Pr.05-00 to 05-14 shown above.


05 - 15	PLC Mode	Factory Setting: 00
Settings	00	Disable PLC operation
	01	Execute one program cycle
	02	Continuously execute program cycles
	03	Execute one program cycle step by step
	04	Continuously execute program cycles step by step

This parameter selects the mode of PLC operation for the AC drive. The AC drive will change speeds and directions according to the user's desired programming.



Example 1 (Pr.05-15 = 1): Execute one cycle of the PLC program. Its relative parameter settings are:

- Pr.05-00 to 05-14: 1st to 15th step speed (sets the frequency of each step speed)
- Pr.04-00 to 04-07: Multi-Function Input Terminals (set one multi-function terminal as 32 - PLC auto-operation).
- Pr.03-00 to 03-07: Multi-Function Output Terminals (set a Multi-Function Terminal as 34-PLC running indication, 35-PLC step completed or 36-PLC program completed).
- Pr.05-16: Direction of operation for the 1st to 15th step speed.
- Pr.05-17 to 05-31: Operation time setting of the 1st to 15th step speed.



Note: The above diagram shows one complete PLC cycle. To restart the cycle, turn the PLC program off and on again.


Example 2 (Pr.05-15 = 2): Continuously executes program cycles:

The diagram above shows the PLC program stepping through each speed. Set Pr.05-15 to 2 continuously executes the program. To stop the PLC program, one must either pause the program or turn it off. (Refer to Pr.04-00 to 04-07 values 32 and 33).

Example 3 (Pr.05-15 = 3) Execute one cycle step by step:



The example below shows how the PLC can perform one cycle at a time, within in a complete cycle. Each step will use the accel/decel times in Pr.01-09 to Pr.01-16. It should be noticed that the time each step spends at its intended frequency is diminished, due to the time spent during accel/decel.




05 - 16	PLC Forward/Reverse Motion	Factory Setting: 00
	Settings 00 to 32767	


This parameter controls the direction of motion for the Multi-Step Speeds Pr.05-00 to Pr.05-14 during PLC mode. All other direction commands are invalid during the PLC mode.

Note:

The equivalent 15-bit number is used to program the forward/reverse motion for each of the 15 speed steps. The binary notation for the 15-bit number must be translated into decimal notation and then entered.



5



The setting value = $\text{bit}14 \times 2^{14} + \text{bit}13 \times 2^{13} + \dots + \text{bit}2 \times 2^2 + \text{bit}1 \times 2^1 + \text{bit}0 \times 2^0$
= $1 \times 2^{14} + 1 \times 2^{11} + 1 \times 2^{10} + 1 \times 2^6 + 1 \times 2^5 + 1 \times 2^4 + 1 \times 2^1$
= $16384 + 2048 + 1024 + 64 + 32 + 16 + 2$
= 19570
Setting 05-16 = 19570

NOTE:				
$2^{14}=16384$	$2^{13}=8192$	$2^{12}=4096$	$2^{11}=2048$	$2^{10}=1024$
$2^9=512$	$2^8=256$	$2^7=128$	$2^6=64$	$2^5=32$
$2^4=16$	$2^3=8$	$2^2=4$	$2^1=2$	$2^0=1$




05 - 17	Time Duration of 1st Step Speed	Factory Setting: 0.0
05 - 18	Time Duration of 2nd Step Speed	Factory Setting: 0.0
05 - 19	Time Duration of 3rd Step Speed	Factory Setting: 0.0
05 - 10	Time Duration of 4th Step Speed	Factory Setting: 0.0
05 - 21	Time Duration of 5th Step Speed	Factory Setting: 0.0
05 - 22	Time Duration of 6th Step Speed	Factory Setting: 0.0
05 - 23	Time Duration of 7th Step Speed	Factory Setting: 0.0
05 - 24	Time Duration of 8th Step Speed	Factory Setting: 0.0
05 - 25	Time Duration of 9th Step Speed	Factory Setting: 0.0
05 - 26	Time Duration of 10th Step Speed	Factory Setting: 0.0
05 - 27	Time Duration of 11th Step Speed	Factory Setting: 0.0
05 - 28	Time Duration of 12th Step Speed	Factory Setting: 0.0
05 - 29	Time Duration of 13th Step Speed	Factory Setting: 0.0
05 - 30	Time Duration of 14th Step Speed	Factory Setting: 0.0
05 - 31	Time Duration of 15th Step Speed	Factory Setting: 0.0

Settings 0.0 to 65500

Unit: 1 / 0.1sec

From Pr.05-17 to Pr.05-31 correspond to operation time of each step speed defined by Pr.05-00 to Pr.05-14. The maximum setting 65500 seconds will be displayed as t6550. If it shows t6550, that means 6550 seconds.

Note: If a parameter is set to “00” (0 sec), the corresponding step will be skipped. This is commonly used to reduce the number of program steps.



5

05 - 32	Time Unit Settings			Factory Setting: 00
	Settings	00	1 Sec	
		01	0.1 Sec	

 This parameter determines the time unit for Pr.05-17~Pr.05-31.



5.7 Group 6: Protection Function Parameters


06 - 00

Over-voltage Stall Prevention

Factory Setting: 390.0/780.0

Settings 230V series: 330.0 ~ 410.0VDC
 460V series: 660.0 ~820.0VDC
 00: Disable

- This parameter selects the voltage level for the Over-Voltage Stall Prevention function.
- During decelerations, the DC bus voltage may exceed its maximum allowable value due to motor regeneration. When this function is enabled, the AC drive will stop decelerating and maintain a constant output frequency. The AC drive will only resume deceleration when the voltage drops below the preset value.
- With moderate inertial loads, the over-voltage stall prevention will not occur and the deceleration time should be equal to Pr.1-10. With high inertial loads, the AC drive will automatically extend the deceleration time due to the step function shown below. If the deceleration time is critical for the application, then dynamic brake resistors should be used.




06 - 01

Over-current Stall Prevention during Acceleration

Factory Setting: 120

Settings 20~150% Unit: 1

- This parameter selects the percentage of allowable over-current during acceleration before the stall prevention is enabled.
- During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06-01 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and maintain a constant output frequency. The AC drive will only resume acceleration when the current drops below the value set in Pr.06-01 (please see the graph below).
- When the over-current stall prevention is activated, the acceleration time of the AC drive will be longer than the time set in Pr. 01-09.



Over-current Stall Prevention during Acceleration

06 - 02

Over-current Stall Prevention during operation

Factory Setting: 120


Settings

20~150%

Unit: 1

5

-  This parameter selects the percentage of allowable over-current during operation before the stall prevention function is enabled.
-  If the output current exceeds the value specified in Pr.06-02 when the drive is operating at steady state speed, the drive will decrease its output frequency to prevent the drive from faulting with an OC. Once the current falls below the value specified in Pr.06-02, the drive will then accelerate to catch up with the command frequency.




Over-current Stall Prevention during Operation



06 - 03	Over-torque Detection Selection	Factory Setting: 00
Settings	00: Over-torque detection disabled. 01: Over-torque detection enabled during constant speed operation (OL2), and operation continues. 02: Over-torque detection enabled during constant speed operation (OL2), and operation halted. 03: Over-torque detection enabled during operation (OL2), and operation continues. 04: Over-torque detection enabled during constant speed operation (OL2), and operation halted.	
	This parameter selects the Over-torque Detection operation.	
	If this parameter is set to 01 or 02, over-torque detection will not occur during acceleration.	
06 - 04	Over-torque Detection Level	Factory Setting: 110
Settings	30~150%	Unit: 1
	This parameter sets the Over-torque Detection level based on the AC drive rated current.	
06 - 05	Over-torque Detection Time	Factory Setting: 0.1
Settings	0.1~60.0 Sec	Unit: 0.1
	This parameter selects the allowable time of Over-torque Detection before the AC drive faults with an OL2.	
	When the output current exceeds Pr.06-04 for the time set in Pr06-05, AC drive will fault and display “OL2” on the keypad.	
06 - 06	Electronic Thermal Relay Selection	Factory Setting: 02
Settings	00: Operation disabled. 01: Operation with a standard motor (shaft mounted fan cooled). 02: Operation with a vector motor (non-fan cooled or self powered fan)	
	This parameter provides electronic thermal protection for the motor. When the output current exceeds Pr.07-02 for the time set in Pr.06-07, the drive will fault with an OL1.	
06 - 07	Electronic Thermal Characteristic	Factory Setting: 60
Settings	30~600 Sec	Unit: 1
	This parameter selects the time required for the electronic thermal protection function to activate.	
	When Pr.6-06 is set for 1 or 2 and the output current exceeds Pr.7-02 for the time set in Pr.6-07, the drive will fault with an OL1.	
	The common electronic thermal reaction time (150% output current for 1 minute) is shown in the	



chart below. The actual reaction time will vary depending on output current.



5

06 - 08	Low Current Detection Level	Factory Setting: 00
	Settings 00~100% (00 disabled)	Unit: 1
06 - 09	Low Current Detection Time	Factory Setting: 10.0
	Settings 0.1~ 3600.0 Sec	Unit: 0.1
06 - 10	Low Current Detection Treatment	Factory Setting: 01
	Settings 00: Warn and Ramp to stop 01: Warn and Coast to stop 02: Warn and keep operating	

📖 These parameters set the low current detection mode, time, and operation.

06 - 11	Present Fault Record	Factory Setting: 00
06 - 12	Second Most Recent Fault Record	Factory Setting: 00
06 - 13	Third Most Recent Fault Record	Factory Setting: 00
06 - 14	Fourth Recent Fault Record	Factory Setting: 00
Settings		
	00	No fault occurred
	01	Over-current (oc)
	02	Over-voltage (ov)
	03	Overheat (oH)
	04	Overload (oL)
	05	Electronic thermal relay (oL1)
	06	External fault (EF)
	07	AC drive IGBT fault (occ)



-
- 08 CPU failure (cF3)
 - 09 Hardware protection failure (HPF)
 - 10 Over current during acceleration (ocA)
 - 11 Over current during deceleration (ocd)
 - 12 Over current during steady state operation (ocn)
 - 13 Ground fault (GFF)
 - 14 Under voltage (Lv)
 - 15 EEPROM WRITE failure (cF1)
 - 16 EEPROM READ failure (cF2)
 - 17 Base Block (bb)
 - 18 Motor over load (oL2)
 - 19 Reserved
 - 20 Software/password protection (codE)
 - 21 External emergency stop (EF1)
 - 22 Phase-Loss (PHL)
 - 23 Low-current (Lc)
 - 24 FbL (Feedback Loss)
 - 25 Reserved
 - 26 Fan Power Fault (FAnP)
 - 27 Fan 1 Fault (FF1)
 - 28 Fan 2 Fault (FF2)
 - 29 Fan 3 Fault (FF3)
 - 30 Fan 1, 2, 3 Fault (FF123)
 - 31 Fan 1, 2 Fault (FF12)
 - 32 Fan 1, 3 Fault (FF13)
 - 33 Fan 2, 3 Fault (FF23)
 - 34 Gate Drive Low Voltage Protect (Fv)

06 - 15 Parameter Reset

Factory Setting: 00

- Settings 00~65535
- 09: Reset parameters (50Hz, 220/380)
- 10: Reset parameters (60Hz, 220/440)

This parameter resets all parameters to the factory setting.

06 - 16 Parameter Protection Password Input

Factory Setting: 00



Settings

00~65535

- This parameter allows the user to enter their password to unlock the Parameter Protection feature. The password entered must match the value entered into Pr.6-17. After three invalid password attempts, the drive will no longer allow any operation. The drive must then be powered off and back on again.
- After successfully entering the password, the user may change parameters as they wish. Once the drive is powered off, the drive has locked the parameters again. To clear the password, the user must enter the correct password in Pr.6-16 and then set Pr.6-17 to 00.

06 - 17

Parameter Protection Password Setting

Factory Setting: 00

Settings

00~65535

00: No password protection

- This parameter allows the user to set a password for parameter protection. After entering a password, Pr.6-17 will display 1.
- Be sure to keep the password in a safe place. If the password is lost, please return the drive to DELTA.

06-18	Recording Mid/Low Voltage while running the AC Drive			
	Setting Range		Factory Setting	00
	00	None Recorded Low Voltage, Parameter Reset Automatically		
	01	None Recorded Low Voltage, Parameter Reset Manually		
	02	Recorded Low Voltage, Parameter Reset Manually		



5.8 Group 7: AC Drive and Motor Parameters

07 - 00 Identity Code of AC Drive

Factory Setting: ##

Settings Display by model type

This parameter displays the AC drive model code.

This parameter is read-only.

07 - 01 Rated Current of AC Drive

Factory Setting: ##

Settings Display by model type

This parameter displays rated output current of the AC drive. The following chart may be used to look up the identity code, current, and hp of your drive.

230V series

KW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
HP	1	2	3	5	7.5	10	15	20	25	30	40	50
Pr.07-00	4	6	8	10	12	14	16	18	20	22	24	26
Rated current (A)	5	7	11	17	25	33	49	65	75	90	120	145
Max. Carried Freq.	10KHz						9KHz			6KHz		
Min. Carried Freq.	4KHz						3KHz			2KHz		
Factory Setting	9KHz						6KHz			4KHz		

460V series

KW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	130	160	185	220
HP	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50	60	75	100	125	150	175	215	250	300
Pr.07-00	05	07	09	11	13	15	17	19	21	23	25	27	29	31	33	35	37	39	41	43	45
Rated Current (A)	2.7	4.2	5.5	8.5	13	18	24	32	38	45	60	73	91	110	150	180	220	260	310	370	460
Max. Carried Freq.	10KHz						9KHz			6KHz											
Min. Carried Freq.	4KHz						3KHz			2KHz											
Factory Setting	9KHz						6KHz			4KHz											

This parameter is read-only.

07 - 02 Full-load Current of Motor



Factory Setting: 100%

Settings 30~120%

Unit: 1

This parameter selects the full load current of the motor.

Pr7-02 = (full load motor current / drive rated current)

Example: If the rated current of AC drive is 150A, full-load current of motor is 120A, and then Pr.7-02 should be set to 80%.

-  This parameter is used with slip compensation Pr.7-04 to Pr.7-05 and electronic thermal relay Pr.6-06 to Pr.6-07. An incorrect setting will cause these functions to not work incorrectly and may damage the motor and drive.
-  The full-load current of the motor must be equal to or less than (but not less than 50%) the rated current of the AC drive.

07 - 03	No-load Current of Motor		Factory Setting: 30%
	Settings 1~99%		Unit: 1

-  This parameter sets the no-load current of the motor.
Pr.7-03 = (no load current / drive rated current)

Example: If the rated current of the AC drive is 150A and no-load current of the motor is 40A, then Pr.7-03 should be set to 27%.
-  This parameter is used with slip compensation Pr.7-04 and Pr.7-05. An incorrect setting will cause the function to work incorrectly and may damage the motor and drive.
-  If the no-load current of the motor is unavailable, it may be found by running the motor with no load and reading the current on the keypad display.

07 - 04	Auto Slip Compensation Gain		Factory Setting: 0.0
	Settings 0.0~3.0		Unit: 0.1

-  This parameter is set to auto slip compensation gain.
-  Rotor speed of the motor (output frequency of AC drive) can't synchronize due to induction motor characteristic. The difference between synchronization speed and rotor speed is called slip frequency. Slip frequency is in direct proportion with output torque and output current. Therefore, slip compensation could make rotor speed and master frequency command the same according output current (Io).
-  The equation of slip compensation is (07-05) X (07-04) X (Io-(07-03)) / ((07-02)-(07-03)). If rated current of AC drive is 150A, full-load current of the motor is 120A, no-load current is 40A, rated slip frequency is 5Hz and output current of AC drive is 100A. At this time, slip compensation is (07-04) X 5 X (100-40) / (120-40) = 3.75 X (07-04). If 07-04 is set to 1.0 and the compensation is 3.75. If master frequency command is set to 50Hz and output frequency is 53.75.
-  Output frequency after compensation is limited by 01-07 upper bound frequency. When using slip compensation, 01-07 should be set to the suitable value.
-  When PID feedback control, slip compensation function will be disabled.
-  Unsuitable setting value may cause over compensation.



07 - 05	Rated Slip Frequency of Motor		Factory Setting: 0.00
	Settings	0.00~20.00Hz	Unit: 0.01
	This parameter is to set rated slip of loaded motor. Users need to input rated rotation speed according to nameplate of loaded motor. If rated frequency of motor is 60Hz, number of motor poles is 4 and rated rotation speed of motor is 1650rpm. The rated slip frequency of motor is $60\text{Hz} - (1650\text{rpm} \times 4/120) = 5\text{Hz}$.		
	This parameter has relation with 07-04 slip compensation. To have the best slip compensation, this parameter must be set correctly. Incorrect setting may cause above functions disable and even damage the motor and AC drive.		
07 - 06	Auto Torque Compensation Gain		Factory Setting: 0.0
	Settings	0.0~10.0	Unit: 0.1
	This parameter is to set auto torque compensation gain.		
	When motor loading is high, a part of output frequency of AC drive will be absorbed by impedance of stator winding to make voltage of exciting inductance of motor is not enough. Therefore, the short of gap magnet field will make a high output current but low output torque. Auto torque compensation gain could adjust output voltage automatically according to loading to maintain in a fixed gap magnet of the motor to get the best running situation.		
	If the setting of compensation gain is too great, over-exciting magnet will cause the following situation: output current of AC drive is too great, motor is over-heating or protection function occurs.		
07 - 07	Torque Compensation Gain by Manual Operation		Factory Setting: 0.0
	Settings	0.0~10.0	Unit: 1.0
	This parameter determines torque compensation gain by manual operation.		
	Torque compensation gain by manual operation won't refer to the loading situation and adds compensation voltage on the setting V/f curve. Basically, it just changes V/f curve. It could be reached by adjusting V/f curve.		
07 - 08	Calculate Total Running Time of the Motor (Min)		Factory Setting: 00
	Settings	00 to 1439 Min	Unit: 1
07 - 09	Calculate Total Running Time of the Motor (Day)		Factory Setting: 00
	Settings	00 to 65535 Day	Unit: 1
	This parameter could display running time of the motor.		
07-10	Poles of Motor		Factory setting
	Setting Range	2~10	4



07-11	Reserved	↗	Factory setting	
	Setting Range			



5.9 Group 8: Special Parameters

08 - 00	DC Brake Current Level	Factory Setting: 00
----------------	------------------------	---------------------

Settings	00~100%	Unit: 1
----------	---------	---------

This parameter determines the level of DC brake current output.

08 - 01	DC Brake Time during Start-up	Factory Setting: 0.0
----------------	-------------------------------	----------------------

Settings	0.0~60.0 Sec	Unit: 0.1
----------	--------------	-----------

This parameter determines the duration of time that the DC brake current will be applied to the motor during the AC drive start-up.

The motor may rotate by external force or inertia itself before operating. It may damage the motor or start the AC drive protection function by an over current if the AC drive added at this time. This parameter enable the AC drive to output a direct current before running the motor that will produce a torque to forced motor stop and get a steady start-up characteristic.

08 - 02	DC Brake Time during Stopping	Factory Setting: 0.0
----------------	-------------------------------	----------------------

Settings	0.00~60.00 Sec	Unit: 0.01
----------	----------------	------------

This parameter determines the duration of time that the DC brake current will be applied to the motor during stopping.


Motor may be in rotation status after AC drive stops output and can't in stop status accuracy when motor is running with external force or itself inertia. After AC drive stops output, this parameter could output a DC current to produce torque force motor to stop and make sure the motor has stopped accuracy.

08 - 03	Start-point for DC Brake	Factory Setting: 0.00
----------------	--------------------------	-----------------------

Settings	0.00~120.00 Hz	Unit: 0.01
----------	----------------	------------

This parameter determines the frequency when DC brake will begin during deceleration.

If this parameter is set greater than 01-05 minimum frequency setting, it won't decelerate to 01-05 and enter DC brake status when AC drive brakes. Suitable DC brake start-up frequency setting will get better brake characteristic.



08 - 04

Momentary Power Loss Operation Selection

Factory Setting: 00

- Settings
- 00: Disable

01: Trace from top downward

02: Trace from bottom upward

- This parameter determines the start-up mode after momentary power loss operation.
- The power system connects to AC drive may occurred momentary power loss by any probably reason. This function can make AC drive output voltage continuously after power loss and AC drive won't stop by power loss.
- If this parameter is set to 01, AC drive will trace from the last frequency before power loss downward. After output frequency of AC drive and running speed of the motor is synchronization, it will accelerate to master frequency command. It is recommended to use this setting if the motor loading has the characteristics of high inertial and low resistance.
- If this parameter is set to 02, AC drive will trace from the Min. frequency upward. After output frequency of AC drive and running speed of the motor is synchronization, it will accelerate to master frequency command. It is recommended to use this setting if the motor loading has the characteristics of low inertial and high resistance.

08 - 05

Maximum Allowable Power Loss Time

Factory Setting: 2.0

- Settings
- 0.1~5.0 Sec

Unit: 0.1

- This parameter determines the maximum allowable power loss time. If the power loss time is less than the time defined by this parameter, the AC drive will execute 08-04 momentary power loss operation.
- The allowable power loss time is beginning to count time after AC drive displays Lu. Therefore, actual allowable power loss time will change with loading.
- The allowable power loss time must in the condition that AC drive auxiliary power is working normally. If auxiliary power is turned off in the allowable power loss time, the actual allowable power loss time will be shorter than the parameter setting.



08 - 06

Speed Search Time

Factory Setting: 0.5

Settings

0.1~5.0 Sec

Unit: 0.1

This parameter determines the delay time from fault (power loss, OV, OC or BB) recovery to start to execute the function of speed search time.

08 - 07

Maximum Speed Search Current


Factory Setting: 110


Settings

30~150%

Unit: 1

- This parameter determines maximum current of speed search.
- Maximum speed search current will have influence with synchronization attained time. The greater this parameter is set, the faster it will be synchronization. But if the parameter setting value is too great, it may cause over-loaded protection.
- If 08-04 is set to 01: when speed search is from top downward, output frequency is searched from master frequency command downward. Now output voltage and output current will be added from zero. When output current is equal to 08-07 setting value, AC drive output current will retain in a fixed value and output frequency will keep on searching from top downward. When output frequency and output voltage is overlapped with V/f setting frequency, AC drive will judge that is synchronization attained and accelerates from V/f curve to master frequency command.
- If 08-04 is set to 02: AC drive will accelerate according to V/f curve and won't do any special treatment.





5

08 - 08

BB Speed Search Method

Factory Setting: 00

- Settings
- 00: Trace from top downward
01: Trace from bottom upward

- This parameter determines BB speed search method when multi-function input terminal 04-00 to 04-07 is set to BB External interrupt (11 or 12) and activates.
- BB speed search method is the same with restart speed search after momentary loss power.

08 - 09

Auto Restart Times After Fault

Factory Setting: 00

- Settings
- 00 ~10

- This parameter determines the times of auto restart after fault.
- When AC drive has fault (OV, OC or OCC) and fault disappeared automatically, this parameter allows AC drive reset and runs with the parameter that is set before fault occurred.
- If fault occurred times exceed 08-09 setting, AC drive will reject to restart and need to reset by users to keep on running.

08 - 10

Auto Restart Time after Fault

Factory Setting: 600

- Settings
- 00 to 60000 sec
- Unit:



This parameter determines auto restart time after fault. After fault occurs and restart, there is no fault occurs during 08-10 setting time, AC drive will reset fault occurred record to zero.

08 - 11	Operation Frequency Inhibition 1 UP	Factory Setting: 0.00
08 - 12	Operation Frequency Inhibition 1 DOWN	Factory Setting: 0.00
08 - 13	Operation Frequency Inhibition 2 UP	Factory Setting: 0.00
08 - 14	Operation Frequency Inhibition 2 DOWN	Factory Setting: 0.00
08 - 15	Operation Frequency Inhibition 3 UP	Factory Setting: 0.00
08 - 16	Operation Frequency Inhibition 3 DOWN	Factory Setting: 0.00
Settings 0.00~120.00 Hz		Unit: 0.01

This parameter determines the inhibition operation frequency range. This function will let AC drive not run continuous in the resonance frequency of the motor or loading system, or inhibition operation frequency.


The settings of this parameter should follow as $08-11 \geq 08-12 \geq 08-13 \geq 08-14 \geq 08-15 \geq 08-16$.

Master frequency command can be set in inhibition operation frequency range. Now the output frequency will be limited in the lower bound of inhibition operation frequency.

When AC drive accelerates or decelerates, output frequency will pass through inhibition operation frequency range.

08 - 17	Automatic Energy-saving	Factory Setting: 00
Settings 00: Energy-saving operation disabled 01: Energy-saving operation enabled		

This parameter determines automatic energy-saving function.



08 - 18	Automatic Voltage Regulation (AVR)	Factory Setting: 00
----------------	------------------------------------	---------------------



- Settings
- 00: AVR function enabled
01: AVR function disabled
02: AVR function disabled for deceleration

- This parameter determines the function of Automatic Voltage Regulation is enabled or disabled.
- This parameter is set to 01: when AVR function is disabled, AC drive will calculate input voltage by DC Bus value (620VDC). Output voltage will vary by DC Bus varying and may cause output current insufficiently, over current or oscillation.
- This parameter is set to 00: when AVR function is enabled, AC drive will calculate output voltage by actual voltage value of DC Bus. Output voltage won't vary by DC Bus varying.
- This parameter is set to 02: AC drive will disable AVR function during decelerate to stop. It can speed up braking in some degree.

08 - 19	Software Setting of the Brake Level (the action level of the brake resistor)		Factory Setting: 380.0/ 760.0
	Settings	230V series: 370.0 ~ 410.0VDC 460V series: 740.0 ~ 820.0VDC 00: Disable	Unit: 0.1

- This parameter determines software setting of the brake level.
- The model VFD007~150F43A has brake chip, user could select suitable brake resistor to have the best deceleration characteristics.
- The action level of the brake resistor could be set by this parameter.

08 - 20	Vibration Compensation Factor		Factory Setting: 00
	Settings	00~1000	Unit: 1

- This parameter will minimize vibration at low speed during vector control. The value of the parameter is a GAIN. The higher the value, the more vibration dampening that will occur.



5.10 Group 9: Communication Parameters

09 - 00	Communication Address	⚡	Factory Setting: 01
Settings	When Pr09-09=0, Setting range is 01~254		
	When Pr09-09=1, Setting range is 01~127		
	When Pr09-09=2, Setting Range is 01~254		

If the AC drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter.

09 - 01	Transmission Speed (Baud Rate)	⚡	Factory Setting: 01
Settings	00: Baud rate 4800		
	01: Baud rate 9600		
	02: Baud rate 19200		
	03: Baud rate 38400		

This parameter determines transmission speed of AC drive communication.

09 - 02	Transmission Fault Treatment	⚡	Factory Setting: 03
Settings	00: Warn and keep operating		
	01: Warn and RAMP to stop		
	02: Warn and COAST to stop		
	03: No warning and no display		

This parameter is set to detect if an error occurs and take actions.

09 - 03	Time-out Detection during Transmission		Factory Setting: 00
Settings	00: Disable		
	01: Enable		

This parameter is used for ASCII mode. When this parameter is set to 01, indicates that the over time detection is enable, the time slot between each character can't exceed 500 ms.

09 - 04	Communication Format		Factory Setting: 00
Settings	00: 7-bit for ASCII		
	01: 8-bit for ASCII		
	02: 8-bit for RTU		

			
09 - 05	Even/Odd Parity and Stopping Parity Setting	Factory Setting: 00	
Settings	00: None parity + 2 stop bit 01: Even parity + 2 stop bit 02: Odd parity + 2 stop bit 03: None parity + 1 stop bit 04: Even parity + 1 stop bit 05: Odd parity + 1 stop bit		
	This parameter determines the communication format of serial communication.		
09 - 06	Communication Operation Command 1		Factory Setting: 00
Settings	Bit0~1: 00: Disable 01: Stop 10: Start-up 11: JOG start-up Bit2~3: Reserved Bit4~5: 00: No function 01: FWD command 10: REV command 11: Direction change command Bit6~7: 00: 1 st step acce/decel speed 01: 2 nd step acce/decel speed 10: 3 rd step acce/decel speed 11: 4 th step acce/decel speed Bit8~11: 0000: Master speed 0001: 1 st step speed 0010: 2 nd step speed 0011: 3 rd step speed 0100: 4 th step speed 0101: 5 th step speed 0110: 6 th step speed 0111: 7 th step speed 1000: 8 th step speed 1001: 9 th step speed 1010: 10 th step speed 1011: 11 th step speed 1100: 12 th step speed 1101: 13 th step speed 1110: 14 th step speed 1111: 15 th step speed Bit12: Select Bit6~11 function Bit13~15: Reserved		
	This parameter can be set by communication settings. It can't be set by keypad.		



09 - 07	Communication Frequency Setting	⚡	Factory Setting: 60.00
Settings	0~120.00Hz		Unit: 0.01


📖 This parameter can be set by communication settings. It can't be set by keypad.

09 - 08	Communication Operation Command 2	⚡	Factory Setting: 00
Settings	Bit0: 1: EF ON Bit1: 1: Reset Bit2: 0: BB OFF, 1: BB ON Bit3~15: Reserved		

📖 This parameter can be set by communication settings. It can't be set by keypad.

📖 If you set BB action by this parameter and you also need to disable BB action by this parameter.

There is a built-in RS-485 serial interface, marked (RJ-11 jack) on the control terminal block. The pins are defined below:



Each AC drive has a pre-assigned communication address specified by 9-00. The computer then controls each AC drive according to its communication address.

AC drive can be setup to communicate on Modbus networks using one of the following modes: ASCII (American Standard Code for Information interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in 09-04 and 09-05.

09-09	Switching between Modbus & BACnet	⚡	Factory Setting	00
	Setting Range			
	00		Modbus Mode	
	01		BACnet Master Mode	
	02		BACnet Slaver Mode	

📖 This parameter determines the switch between Modbus and BACnet.



09-10	BACnet DNET	⚡	Factory Setting	01
	Setting Range	01~65535		

📖 This parameter determines the final IP address of the BACnet.

09-11	BACnet Device Instance	⚡	Factory Setting	00
	Setting Range	00~65535		

📖 This parameter determines the serial number of the BACnet.

09-12	DCC password	⚡	Factory Setting	0
	Setting Range	0~65535		

📖 This parameter determines the DCC password of the BACnet.

The proprietary objects, properties and data type are supported by the BACnet.

Property Type	Object Type supported		
	Device supported	Analog Value supported	Binary Value supported
Object Identifier	X	X	X
Object Name	X	X	X
Object Type	X	X	X
System Status	X		
Vendor Name	X		
Vendor Identifier	X		
Model Name	X		
Firmware Revision	X		
Appl Software revision	X		
Protocol Version	X		
Protocol Revision	X		
Services Supported	X		
Object Types supported	X		
Object List	X		
Max APDU Length	X		
Segmentation Support	X		
APDU Timeout	X		
Number ADPU Retires	X		
Max_Master	X		
Max_Info_Frames	X		
Device Address Binding	X		
Database Revision	X		



Present Value		X	X
Status Flag		X	X
Event State		X	X
Out-of-Service		X	X
Units		X	
Priority Array		X*	X*
Relinquish Default		X*	X*
Active Text			X
Inactive Text			X

- Only with commendable values

VFDF-Analog Values Description :

ID	Object Name	Description	Unit	
0	AV00:RESERVED	software version(.xx)	NO UNITS	R
1	AV01:ERROP	Error Code(xx.)	NO UNITS	R
2	AV02:LEDOP	VFDF status(xx.)	NO UNITS	R
3	AV03:FSET	Frequency Command(xx.xx)	HERZ	R
4	AV04:FOUT	Output Frequency(xx.xx)	HERZ	R
5	AV05:OUTAMP	Output Current(xx.x)	AMPERES	R
6	AV06:DCBUS	DC Bus Voltage(xxx.x)	VOLTS	R
7	AV07:OUTACV	Output Voltage(xxx.x)	VOLTS	R
8	AV08:PFANGLE	PF angle(xx.xx)	DEGREE ANGULAR	R
9	AV09:POUT	Output Power(xx.xx)	KILPWATTS	R
10	AV10:PVFB	PID feedback physical signal (x.x)	NO UNITS	R
11	AV11:SENSOR	PID feedback (xx.xx)	PERCENT	R
12	AV12:USERDL	Low part of user define (xx.xx)	NO UNITS	R
13	AV13:USERDH	High part of user define(xxxx)	NO UNITS	R
14	AV14:PLC TIME	PLC time (xxxx)	UNIT SECOND	R
15	AV15:TQ_RATIO	Torque(xx.x)	UNIT NEWTON METER	R
16	AV16:CMD_REM	(RUN/STOP/JOG/FWD/REV)	NO UNITS(resolution 1.0)	C
17	AV17:FCMAIN	Frequency command	HERTZ	C
18	AV18:SCMD_REM	(EF/Reset/BB)	NO UNITS(resolution 1.0)	C
19	AV19:PARAMETERID	Parameter ID set	0.0~65535.0 (resolution 1.0)	R/W
20	AV20:PARAMETERVALUE	Parameter value set	0.0~65535.0	R/W

📖 To set up object AV16 from the BACnet Communication Protocol, Pr02-01 has to be set as 3 or 4.

📖 To set up object AV17 from the BACnet Communication Protocol, Pr02-00 has to be set as 4.

📖 To set up communication parameter from BACnet, please set up the object AV19 then set up object AV20.

📖 Please refer to the description of Group 00 to set up objects AV00 to AV15.

📖 Please refer to Pr09-06 for the description of object AV16.

📖 Please refer to Pr09-07 for the description of the object AV17.

📖 Please refer to Pr09-08 for the description of the object AV18.

VFDF-Binary Values:

ID	Object Name	Description	Inactive/Active	
0	BV00:Ready or Not-Ready	Ready State	Not Ready/ Ready	R

For current Value Access Types, R = Read-only, R/W = Writable, C = Commandable.

Commandable values support priority arrays and relinquish defaults.



Code Description:

ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data: 64 Hex, shown as ‘64’ in ASCII, consists of ‘6’ (36Hex) and ‘4’ (34Hex).

Character	‘0’	‘1’	‘2’	‘3’	‘4’	‘5’	‘6’	‘7’
ASCII Code	30H	31H	32H	33H	34H	35H	36H	37H

Character	‘8’	‘9’	‘A’	‘B’	‘C’	‘D’	‘E’	‘F’
ASCII Code	38H	39H	41H	42H	43H	44H	45H	46H


RTU mode:

Each 8-bit is the combination of two 4-bit hexadecimal characters. For example, 64 Hex.


2. Data format

2.1 10-bit character frame (for 7-bit):


❖ (7, N, 2: 9-04=0, 9-05=0)



❖ (7, E, 1: 9-04=0, 9-05=04)




❖ (7, O, 1: 9-04=0, 9-05=05)






2.2 11-bit character frame (for 8-bit):


❖ (8, N, 2: 9-04=1 or 2, 9-05=00)



❖ (8, E, 1: 9-04=1 or 2, 9-05=04)



❖ (8, O, 1: 9-04=1 or 2, 9-05=05)



3. Communication Protocol

3.1 Communication Data Frame:

ASCII mode:

STX	Start character ':' (3AH)
ADR 1	Communication address:
ADR 0	8-bit address consists of 2 ASCII codes
CMD 1	Command code:
CMD 0	8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
.....	N X 8-bit data consists of 2n ASCII codes.
DATA 0	n<=25, maximum of 50 ASCII codes
LRC CHK 1	LRC check sum:
LRC CHK 0	8-bit check sum consists of 2 ASCII codes
END 1	End characters:
END 0	END1= CR (0DH), END0= LF(0AH)

RTU mode:

START	A silent interval of more than 10 ms
ADR	Communication address: 8-bit address
CMD	Command code: 8-bit command
DATA (n-1)	Contents of data:
.....	N X 8-bit data, n<=25
DATA 0	
CRC CHK Low	CRC check sum:
CRC CHK High	16-bit check sum consists of 2 8-bit characters
END	A silent interval of more than 10 ms

3.2 ADR (communication address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

For example, communications to AMD with address 16 decimal:

ASCII mode: (ADR 1, ADR 0) = '1','0' => '1'=31H, '0'=30H

RTU mode: (ADR) = 10H



3.3 CMD (command code) and DATA (data character)

The format of data characters depends on the command code. The available command codes are described as followed:

- Command code: 03H, read N words. The maximum value of N is 10. For example, reading parameters 01-01 and 01-02 from address 01H.

ASCII mode:

Command message:		Response message:		Error response message	
STX	‘.’	STX	‘.’	STX	‘.’
ADR 1	‘0’	ADR 1	‘0’	ADR 1	‘0’
ADR 0	‘1’	ADR 0	‘1’	ADR 0	‘1’
CMD 1	‘0’	CMD 1	‘0’	CMD 1	‘8’
CMD 0	‘3’	CMD 0	‘3’	CMD 0	‘3’
Starting data address	‘0’	Number of data(Word)	‘0’	Error code	‘0’
	‘1’		‘4’		‘2’
	‘0’	Data of 0101H	‘1’	LRC CHK 0	‘6’
	‘1’		‘7’	LRC CHK 1	‘D’
Number of data (Word)	‘0’		‘7’	END 1	CR
	‘0’		‘0’	END 0	LF
	‘0’	Data of 0102H	‘0’		
	‘2’		‘8’		
LRC CHK 1	‘D’		‘9’		
LRC CHK 0	‘7’		‘8’		
END 1	CR	LRC CHK 1	‘D’		
END 0	LF	LRC CHK 0	‘1’		
		END 1	CR		
		END 0	LF		



RTU mode:

Command message:		Response message:		Error response message	
ADR	01H	ADR	01H	ADR	01H
CMD	03H	CMD	03H	CMD	90H
Starting data address	01H	Number of data	04H	Error code	02H
	01H	data 0101H content	17H 70H	CRC CHK LOW	CDH
Number of data (Word)	00H'	0102H content	08H 98H	CRC CHK HIGH	C1H
	02H	CRC CHK LOW	F8H		
CRC CHK Low	94H	CRC CHK HIGH	36H		
CRC CHK High	37H				

- Command code: 06H, write a word

For example, writing 6000(1770H) to address 0100H of AMD with address 01H.

ASCII mode:

Command message:		Response message:		Error response message	
STX	‘.’	STX	‘.’	STX	‘.’
ADR 1	‘0’	ADR 1	‘0’	ADR 1	‘0’
ADR 0	‘1’	ADR 0	‘1’	ADR 0	‘1’
CMD 1	‘0’	CMD 1	‘0’	CMD 1	‘8’
CMD 0	‘6’	CMD 0	‘6’	CMD 0	‘6’
data starting address	‘0’	data starting address	‘0’	Error code	‘0’
	‘1’		‘1’		‘2’
	‘0’		‘0’	LRC CHK 0	‘6’
	‘0’		‘0’	LRC CHK 1	‘D’
data	‘1’	data	‘1’	END 1	CR
	‘7’		‘7’	END 0	LF
	‘7’		‘7’		
	‘0’		‘0’		
LRC CHK 1	‘7’	LRC CHK 1	‘7’		
LRC CHK 0	‘1’	LRC CHK 0	‘1’		
END 1	CR	END 1	CR		
END 0	LF	END 0	LF		



RTU mode:

Command message:

ADR	01H
CMD	06H
data	01H
Starting address	00H
data	17H
	00H
CRC CHK LOW	87H
CRC CHK HIGH	C6H

Response message:

ADR	01H
CMD 1	06H
data	01H
Starting address	00H
data	17H
	70H
CRC CHK LOW	87H
CRC CHK HIGH	C6H

Error response message

ADR	01H
CMD 1	86H
Error code	02
CRC CHK LOW	C3H
CRC CHK HIGH	A1H

- Command code: 08H, loop detection

This command is used to test the communication condition between master control equipment (usually is PC or PLC) and AC drive. AC drive will deliver the data that received from AC drive to master control equipment.

For example:

ASCII mode:

Command message:

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘0’
CMD 0	‘8’
data	‘0’
Starting address	‘0’
	‘0’
	‘0’
data	‘1’
	‘7’
	‘7’
	‘0’
LRC CHK 1	‘7’
LRC CHK 0	‘0’
END 1	CR
END 0	LF

Response message:

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘0’
CMD 0	‘8’
data	‘0’
Starting	‘0’
	‘0’
	‘0’
data	‘1’
	‘7’
	‘7’
	‘0’
LRC CHK 1	‘7’
LRC CHK 0	‘0’
END 1	CR
END 0	LF

Error response message

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘8’
CMD 0	‘8’
Error code	‘0’
	‘2’
LRC CHK 0	‘6’
LRC CHK 1	‘D’
END 1	CR
END 0	LF



RTU mode:

Command message:		Response message:		Error response message	
ADR	01H	ADR	01H	ADR	01H
CMD	08H	CMD 1	08H	CMD 1	88H
data	00H	data	00H	Error code	02
Starting address	00H	Starting address	00H	CRC CHK LOW	E0H
data	17H	data	17H	CRC CHK HIGH	6DH
	70H		70H		
CRC CHK LOW	EEH	CRC CHK LOW	EEH		
CRC CHK HIGH	1FH	CRC CHK HIGH	1FH		

- Command code: 10H, write continuous words

For example, modify multi-step speed setting of AC drive (address 01H)

05-00=50.00(1388H) , 05-01=40.00(0FA0H)

5

ASCII mode:

Command message:		Response message:		Error response message	
STX	‘.’	STX	‘.’	STX	‘.’
ADR 1	‘0’	ADR 1	‘0’	ADR 1	‘0’
ADR 0	‘1’	ADR 0	‘1’	ADR 0	‘1’
CMD 1	‘1’	CMD 1	‘1’	CMD 1	‘9’
CMD 0	‘0’	CMD 0	‘0’	CMD 0	‘0’
Data	‘0’	Data	‘0’	Error	‘0’
Starting	‘5’	address	‘5’	code	‘2’
address	‘0’		‘0’	LRC CHK 0	‘6’
	‘0’		‘0’	LRC CHK 1	‘D’
Number	‘0’	Number	‘0’	END 1	CR
Of	‘0’	Of	‘0’	END 0	LF
data	‘0’	data	‘0’		
(Word)	‘2’	(Word)	‘2’		
Number of	‘0’	LRC CHK 1	‘E’		
data (Byte)	‘4’	LRC CHK 0	‘8’		
The first	‘1’	END 1	CR		
data	‘3’	END 0	LF		
	‘8’				
	‘8’				
The second	‘0’				
data	‘F’				
	‘A’				
	‘0’				
LRC CHK 1	‘9’				
LRC CHK 0	‘A’				
END 1	CR				
END 0	LF				

**RTU mode:**

Command message:

ADR	01H
CMD	10H
Data starting address	05H 00H
Number of data (Word)	00H 02H
Number of data (Byte)	04
The first data	13H 88H
The second data	0FH A0H
CRC CHK LOW	4DH
CRC CHK HIGH	D9H

Response message:

ADR	01H
CMD 1	10H
Data starting address	05H 00H
Number of data (Word)	00H 02H
CRC CHK LOW	41H
CRC CHK HIGH	04H

Error response message

ADR	01H
CMD 1	90H
Error	02H
CRC CHK LOW	CDH
CRC CHK HIGH	C1H

3.4 CHK (check sum)

ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, and the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘0’
CMD 0	‘3’
Data starting address	‘0’ ‘4’ ‘0’ ‘1’
Number of data	‘0’ ‘0’ ‘0’ ‘1’
LRC CHK 1	‘F’
LRC CHK 0	‘6’
END 1	CR
END 0	LF

$01H+03H+04H+01H+00H+01H=0AH$, 2's complement of 0AH is **F6H**.

RTU mode:

RTU mode uses CRC (Cyclical Redundancy Check) detect value. CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

For example, read 2 words from the address 2102H of AMD with address 01H. The CRC register content of last byte from ADR to number of data is F76FH. The command message is as following. 6FH will transmit before F7H.

Command message:

ADR	01H
CMD	03H
Data starting address	02H
	02H
Number of data (word)	00H
	02H
CRC CHK Low	6FH
CRC CHK High	F7H

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer



The function returns the CRC values as a type of unsigned integer.

```
unsigned int crc_chk(unsigned char* data, unsigned char length){
    int j;
    unsigned int reg_crc=0xFFFF;
    while(length--){
        reg_crc ^= *data++;
        for(j=0;j<8;j++){
            if(reg_crc & 0x01){ /* LSB(b0)=1 */
                reg_crc=(reg_crc>>1) ^ 0xA001;
            }else{
                reg_crc=reg_crc >>1;
            }
        }
    }
    return reg_crc;
}
```



3.5 Address List

The contents of available addresses are shown as below:

Content	Address	Function	
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 04-01 is 0401H. Referencing to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can be read at one time.	
Command Write only	2000H	Bit 0-1	00B: No function 01B: Stop 10B: Run 11B: Jog + Run
		Bit 2-3	Reserved
		Bit 4-5	00B: No function 01B: FWD 10B: REV 11B: Change direction
		Bit 6-7	00B: Comm. forced 1st accel/decel 01B: Comm. forced 2nd accel/decel 10B: Comm. forced 3rd accel/decel 11B: Comm. forced 4th accel/decel
		Bit 8-11	Represented 16 step speeds.
		Bit 12	0: No comm. multi step speed or accel/decel time 1: Comm. multi step speed or accel/decel time
		Bit 13-15	Reserved
	2001H	Frequency command	
	2002H	Bit 0	1: EF (external fault) on
		Bit 1	1: Reset
		Bit 2	1: External Base Block (B.B) on 0: External Base Block (B.B) off
Status monitor Read only	2100H	Error code:	
		00: No fault occurred	
		01: Over-current (oc)	
		02: Over-voltage (ov)	
		03: Overheat (oH)	
		04: Overload (oL)	
		05: Electronic thermal relay (oL1)	
		06: EF (external fault)	
		07: AC drive IGBT fault (occ)	
		08: CPU failure (cF3)	
		09: Hardware protection failure (HPF)	
		10: Over current during acceleration (ocA)	
		11: Over current during deceleration (ocd)	
		12: Over current during steady state operation (ocn)	
		13: Ground Fault (GFF)	
		14: Under voltage (Lv)	



Content	Address	Function	
		15: EEPROM WRITE failure (cF1)	
		16: EEPROM READ failure (cF2)	
		17: Base Block (bb)	
		18: Motor over load (oL2)	
		19: Reserved	
		20: Software or password protection (codE)	
		21: External emergency stop (EF1)	
		22: Phase-Loss (PHL)	
		23: Low current (Lc)	
		24: Feedback loss (FbL)	
		25: Reserved	
		26: FAnP (Fan Power Fault)	
		27: FF1 (Fan 1 Fault)	
		28: FF2 (Fan 2 Fault)	
		29: FF3 (Fan 3 Fault)	
		30: FF123 (Fan 1, 2, 3 Fault)	
		31: FF1, 2 (Fan 1, 2 Fault)	
		32: FF1, 3 (Fan 1, 3 Fault)	
		33: FF2, 3 (Fan 2, 3 Fault)	
		34: Gate Drive Low Voltage Protect (Fv)	
	2101H	Status of AC drive	
		Bit 0-1	00: Run LED is off and STOP led is on. (AC Drive stopping)
			01: RUN LED is blink and STOP led is on. (AC Drive deceleration to stop)
			10: RUN LED is on and STOP led is blink. (AC Drive standby)
			11: RUN LED is on and STOP led is off. (AC Drive running)
		Bit 2	Jog on
		Bit 3~4	00: REV LED is off and FWD led is on. (Forward)
			01: REV LED is blink and FWD led is on. (Reverse to Forward)
			10: REV LED is on and FWD led is blink. (Forward to Reverse)
			11: REV LED is on and FWD led is off. (Reverse)
		Bit 5~7	Reserved
		Bit 8	1: Master frequency source via communication interface
		Bit 9	1: Master frequency source via analog signal
		Bit 10	1: Running command via communication interface
		Bit 11	1: Parameter locked
		Bit 12	Reserved
		Bit 13	Reserved
		Bit 14-15	Reserved
	2102H	Frequency command (F)	
	2103H	Output frequency (H)	



Content	Address	Function
	2104H	Output current (Axxx.X)
	2105H	DC-BUS Voltage (Uxxx.X)
	2106H	Output voltage (Exxx.X)
	2107H	Output power factor (n)
	2108H	Output power (XX. XXKW)
	2109H	Feedback signal actual value
	210AH	Feedback signal (XXX.XX %)
	210BH	Estimated torque ratio (XXX.X)
	210CH	User Target Value (Low bit) uL 0-99.99
	210DH	User Target Value (High bit) uH 0-9999
	210EH	PLC time
	220FH	Reserved

3.6 Exception response

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message “CExx” will be displayed on the keypad of AC motor drive. The xx of “CExx” is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

Example of an exception response of command code 06H and exception code 02H:

ASCII mode	
STX	‘.’
Address	‘0’
	‘1’
Function	‘8’
	‘6’
Exception code	‘0’
	‘2’
LRC CHK	‘7’
	‘7’
END	CR
	LF

RTU mode	
Address	01H
Function	86H
Exception code	02H
CRC CHK Low	C3H
CRC CHK High	A1H



The explanation of exception codes:

Exception code	Explanation
01	Illegal function code: The function code received in the command message is not available for the AC motor drive.
02	Illegal data address: The data address received in the command message is not available for the AC motor drive.
03	Illegal data value: The data value received in the command message is not available for the AC drive.
04	Slave device failure: The AC motor drive is unable to perform the requested action.
10	Communication time-out: If Pr.09-03 is not equal to 0.0, Pr.09-02=00~02, and there is no communication on the bus during the Time-out detection period (set by Pr.09-03), “cE10” will be shown on the keypad.



5.11 Group 10: PID Control Parameters

10 - 00


Input Terminal for PID Feedback

Factory Setting: 00

- Settings
- 00: No function
01: Input via AVI
02: Input via ACI1
03: Input via ACI2
04: Input via External Reference

- This parameter is to set the source of PID control feedback signal. The source could be AVI, ACI1, ACI2 or external reference that defined by 04-24.
- When this parameter is set to 00, PID feedback control function is disabled.
- When this parameter is set to 02/03 and analog input current of ACI1/ACI2 is lower than Pr.04-13/Pr.04-17, EF warning will pup-up.
- If this parameter isn't set to 00, AC drive will automatically start-up PID feedback control. Output frequency is calculated by master frequency and PID feedback signal.

5



10 - 01

PID Control Detection Signal Reference

Factory Setting: 1000.0

- Settings
- 0.0-6550.0
- Unit: 0.1

- Please refer to 04-09 to 04-20 if this parameter is set to PID feedback control.

10 - 02

PID Feedback Control Method

Factory Setting: 00

- Settings
- 00: Negative feedback control
01: Positive feedback control

- This parameter could set the calculation method of deviation signal during PID feedback control circuit.
- When this parameter is set to 00: when negative feedback control, the deviation equation is deviation = target value – detection signal. When increasing output frequency will increase detection value, this setting should be chose.



When this parameter is set to 01: when positive control, the deviation equation is deviation = detection signal – target value. When increasing output frequency will decrease detection value, this setting should be chose.

10 - 03	Proportional Gain (P)	Factory Setting: 1.0
Settings	0.0~10.0	Unit: 0.1

This parameter is to set proportional gain (P). This gain determines the response degree of P controller to feedback deviation. If gain value is large, the response is fast. But if the gain value is too great, oscillation will occur. If gain value is small, the response is slow.

10 - 04	Integral Time (I)	Factory Setting: 1.00
Settings	0.00~100.00 Sec	Unit: 0.01

This parameter is set to integral gain of I controller. When much integral time is to be set, the gain of I controller is small and the response is slow. The control ability to external is poor. When less integral time is to be set, the gain of I controller is large and the response is fast. The control ability to external is fast.

If the setting of integral time is too small, output frequency and system may occur oscillation.

If integral time is set to 0.00, I controller is closed.

10 - 05	Differential Time (D)	Factory Setting: 0.00
Settings	0.00~1.00 Sec	Unit: 0.01

This parameter is set to D controller gain. This gain determines D controller to the response of change of deviation. Suitable differential time could decrease overshoot of P and I controller. The oscillation will be attenuation and steady quickly. But if much differential time is to be set, it may cause system oscillation.

Interference immunity ability is poor due to differential controller activates to change of deviation. It's not recommended to use, especially during interferences.

10 - 06	Upper Bound for Integral Control	Factory Setting: 100
Settings	00~200%	Unit: 1

This parameter could set the upper bound of I controller. In other words, upper bound for integral control = (01-00) X (10-04) %

10 - 07	Primary Low Pass Filter Time	Factory Setting: 0.0
----------------	-------------------------------------	----------------------



Settings 0.0~2.5 Sec

Unit: 0.1

This parameter determines primary Low Pass filter time.

Output frequency of PID controller will filter by primary low pass function. This function could decrease change of output frequency. A long primary low pass time means filter degree is high and vice versa.

Unsuitable primary low pass filter time setting may cause system oscillation.

10 - 08 PID Feedback Signal Range

Factory Setting: 600.0

Settings 0.0~6550.0

Unit: 0.1

This parameter setting could allow the maximum of PID deviation.

If PID function is normal, it should control the detective value to target value accurately in the certain time. If AC drive can't control deviation in the 10-08 setting range during 10-09 setting time, FbL warning will pup-up and it means PID feedback control is abnormal. The treatment is set as 10-10.

10 - 09 PID Feedback Signal Fault Treatment Time

Factory Setting: 0.0

Settings 0.0~3600.0 Sec

Unit: 0.1

This parameter is to set the detection time of abnormal PID derivative. If PID deviation detection time is set to 0.0, the function is disabled.

10 - 10 PID Feedback Signal Fault Treatment



Factory Setting: 01

Settings 00: Warn and RAMP stop

01: Warn and COAST stop

02: Warn and keep operating

This parameter is to set treatment of the abnormal PID deviation.

10 - 11 PID Minimum Output Frequency



Factory Setting: 01

Settings 0: By PID controller

1: By AC drive

This parameter can decide the source of PID output minimum frequency when AC drive enters PID sleep process. If it is set to 0, minimum output frequency should be set by PID. If it is set to 1 and 01-08 is 0, the output frequency is equal to the value of 01-05 setting. If it is set to 1 and 01-08 is not 0, the output frequency is equal to the value of 01-08 setting.



10-12	PID Mode Selection			Factory setting	00
	Setting Range	00	Manual gain control mode		
		01	Automatic gain control		

- This parameter allows you to choose PID control by hand or automatic PID control.
- When the set up is Automatic PID Control, you can adjust Kp from Pr10-03[Propotional Gain], adjust TI from Pr10-04[Integral Time] and adjust Td from Pr10-05[Differential Time].




5.12 Group 11: Fan and Pump Control Parameters

11 - 00	V/f Curve Selection	Factory Setting: 00
---------	---------------------	---------------------

- Settings
- 00: Determined by group 1
01: 1.5 power curve
02: 1.7 power curve
03: 2 power curve
04: cube curve

- This parameter is to set V/f curve. If this parameter isn't set to 00, parameter 01-03 and 01-04 will disable.
- Input current of the motor could divide into two orthogonal vectors: magnetic vector and torque vector. Gap flux, which is produced by Magnetic vector, is in direct proportion with output voltage of motor. Torque vector produces torque. Torque is in direct proportion with the result of magnetic vector multiply by torque vector. In theory, if the value of magnet vector is the same with torque vector (in unsaturated flux condition), the input current is minimum. If motor loading is unsteady torque loading (loading torque is in direct proportion with speed. For example, the loading of fan or pump), loading torque is low during low speed, suitable lower input voltage will decrease input current of magnetic field to lower flux loss and iron loss of the motor and promote whole efficiency.
- When this parameter is set to high power V/f curve and low frequency torque is lower, it is not suitable for AC drive to accel/decel quickly. If it needs to accel/decel quickly, it is not recommended to use this parameter.

5






11 - 01 Circulative Control


Factory Setting: 00

- Settings
- 00: No function
 - 01: Time circulation (by time)
 - 02: Fixed amount circulation (by PID)
 - 03: Fixed amount control (an AC drive runs with 4 motors)
 - 04: Fixed Time Switch + Fixed Amount Circulation
 - 05: Fixed Time Switch + Fixed Amount Control

This parameter is to set an AC drive runs with multiple motors in circulation control mode.

When Pr. 11-01 is set to 01 Time Circulation. Starts a motor, runs it for a fixed amount of time Pr. 11-03 stops it (this motor will coast to stop), wait for delay time on Pr. 11-04, then starts the next motor, runs it for fixed amount of time, etc. Operates like an alternator (also notice that the Pr.11-03 time includes both the acceleration time and the running time).






 When Pr. 11-01 is set to 02 “Fixed Amount Circulation” and adding relay card “RY-00”, VFD-F is able to drive 4 motors under PID control mode by turns.

System powers up, VFD-F drives 1st motor as PID control mode. If VFD-F output frequency continually surpasses 11-06 frequency setting and 11-05 time period, after time lag of 11-04, VFD-F will switch 1st motor power supply to commercial power and energize 2nd motor. At this time, 1st motor is full power running and 2nd motor is running PID control mode by VFD-F.

Previous routine repeats to 2nd motor→3rd motor→4th motor till VFD-F reaches proper PID values. VFD-F only runs PID control mode to last motor, others run full power.




When Pr. 11-01 is set to 03 “Fixed Amount Control” and adding relay card “RY-00”, VFD-F is able to drive 1 motor under PID control mode and another 4 motors as full power running.

System powers up, VFD-F drives 1st motor as PID control mode. If VFD-F output frequency continually surpasses 11-06 frequency setting and 11-05 time period, after time lag of 11-04, VFD-F will energize 2nd motor as full power running and 1st motor is still running PID control mode by VFD-F.

When 1st and 2nd motors are running, if VFD-F output frequency continually surpasses 11-06 frequency setting and 11-05 time period, after time lag of 11-04, VFD-F will energize 3rd motor as full power running and 1st motor is still running PID control mode by VFD-F. At this time, 2nd and 3rd motors are full power running.

Previous routine repeats to 3rd motor→4th motor→5th motor till VFD-F reaches proper PID values. VFD-F only runs PID control mode to 1st motor, others run full power.



When this parameter isn't set to 00, 03-00 to 03-07 multi-function terminals will automatically set the corresponding output motor.

When the AC drive is set to be Pr11-01 <Fixed Time Circulation (by time)>, the AC drive is able to run with 1 to 8 motors (the number of motor can be set by Pr11-02) while the order of running of those motors can be set by Pr11-03. To set the delay time of running of motors, use PR 11-04.



When the setting is <<03 Fixed amount control (one AC drive runs with 8 motors)>>, and if the output frequency reaches the setting of <<Pr 11-06 Motor Switch Frequency during the Fixed Amount Circulation>> and surpasses (or is equal to) the setting of <<Pr 11-05 Motor Switch Delay Time during the Fixed Amount Circulation>>, the AC drive will start to run a second motor. The AC drive is able to run up to 8 motors in order and simultaneously (the number of motors can be set by <<Pr11-02>>). When output frequency is lower than the output frequency of <<Pr 11-11>>, the motors will stop running one by one.

When the setting is <04 Fixed Time Switch and Fixed Amount Circulation>, its function is the same as fixed amount circulation. But since the Fixed Time Switch is also added, the current motor run by the AC drive will stop and start to run another idling motor. This function reduces efficiently the idling time of motors.

When the setting is <<05 Fixed Time Switch + Fixed Amount Control>>,

its function is the same as Fixed Amount Control. But by adding a Fixed Switch Device

will activate the auxiliary which is not in use and deactivate the one which is running.

This function can prevent an auxiliary from being too long time at an idle mode.

11 - 02 Multiple Motors Control

Factory Setting: 01

Settings 01~08
Range

When this parameter is set to multiple motors control, multi-function terminals 03-00 to 03-07 will automatically set to suitable value. Users need to connect output terminal correctly to circulative control as shown in following chart.

11-01 Circulative Control	01 Time Circulation				02 Fixed Amount Circulation			
11-02 motors	01	02	03	04	01	02	03	04
03-00	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.	01 Motor 1 runs by AC drive.
03-01	N/A	02 Motor 2 runs by AC drive.	02 Motor 2 runs by AC drive.	02 Motor 2 runs by AC drive.	02 Motor 1 runs by commercial power.	02 Motor 1 runs by commercial power.	02 Motor 1 runs by commercial power.	02 Motor 1 runs by commercial power.
03-02	N/A	N/A	03 Motor 3 runs by AC drive.	03 Motor 3 runs by AC drive.	N/A	03 Motor 2 runs by AC drive.	03 Motor 2 runs by AC drive.	03 Motor 2 runs by AC drive.



03-03	N/A	N/A	N/A	04 Motor 4 runs by AC drive.	N/A	04 Motor 2 runs by commercial power.	04 Motor 2 runs by commercial power.	04 Motor 2 runs by commercial power.
03-04	N/A	N/A	N/A	N/A	N/A	N/A	05 Motor 3 runs by AC drive.	05 Motor 3 runs by AC drive.
03-05	N/A	N/A	N/A	N/A	N/A	N/A	06 Motor 3 runs by commercial power.	06 Motor 3 runs by commercial power.
03-06	N/A	N/A	N/A	N/A	N/A	N/A	N/A	07 Motor 4 runs by AC drive.
03-07	N/A	N/A	N/A	N/A	N/A	N/A	N/A	08 Motor 4 runs by commercial power.

5


11 - 03 Time Circulation Time Setting

Factory Setting: 00

Settings 00~65500 Min

Unit: 1 Min

- This parameter is to set running time of each motor (including acceleration time) when multiple motors are in time circulation mode (11-01=1). If this parameter is set to 00, time setting is disabled and run with a motor.
- If multi-function input terminals (04-00 to 04-07) are set to 27 to 31, the corresponding output terminals will skip and not activate. The following diagram is the action schedule of time circulation when motor 3 is disabled.
- The motor, which is running with AC drive doesn't accept any disable command of motor.
- When switching time circulation, AC drive won't provide this selection when running motor is coast to stop.





11 - 04

Motor Switch Delay Time

Factory Setting: 1.0

Settings

0.0~3600.0 sec

Unit: 0.1

- This parameter determines time interval of two motors during circulative control (11-01=01). Users need to set suitable time delay to avoid water hammer effect damaging AC drive, motor or system.
- This parameter determines time interval between power supply changes from AC drive to commercial power during fixed circulative control (11-01=02). Users need to set the suitable time delay to make no shock to motor and runs by commercial power.

11 - 05

Motor Switch Delay Time during Fixed Amount Circulation


Factory Setting: 10.0

Settings

0.0~3600.0 sec

Unit: 0.1

- This parameter determines time interval between motor switch frequency and power supply of motor is not from AC drive during fixed amount circulation (11-01=02)/fixed amount control (11-01=03) and output frequency of AC drive attained.
- As the diagram shown below, after output frequency attains 11-06 motor switch frequency, motor doesn't switch at once. It will do motor switch action of circulation control after waiting the delay time that is set by 11-05. Suitable delay time setting will decrease motor switch times.
- After power supply of motor is not from AC drive, the motor will coast to stop according to loading characteristics. Users need to set 11-06 motor switch frequency and 11-04 delay time of circulation control according to actual situation to make rotor speed equals to commercial frequency.



11 - 06 Motor Switch Frequency during Fixed Amount Circulation

Factory Setting: 60.00 Hz

Settings 0.00 to 120.00 Hz

Unit: 0.01Hz

 This parameter determines frequency that motor runs by commercial power during fixed amount circulation (11-01=02)/fixed amount control (11-01=03). This parameter should be greater than commercial frequency. If output frequency of AC drive attains to motor switch frequency, it means that even motor runs in full speed it can't make detection value of PID control attains to target value. Therefore, the power supply of the motor needs to be changed from AC drive to commercial power. AC drive runs with the next motor and makes the detection value close to target.


 In the following chart


T1: enter sleep process time (Pr.11-07)

T2: motor switch delay time during fixed amount circulation (Pr.11-05)

T3: motor switch delay time (Pr.11-04)

N: motor 1





11 - 07

Enter Sleep Process Time

Factory Setting: 0.0

Settings

0.0~3600.0sec

Unit: 0.1 Sec

-  This parameter is to set output frequency of AC drive being smaller than the time interval between sleep frequency and enter sleep process.
-  When AC drive starts running, frequency command calculated by PID is smaller than sleep frequency. AC drive will enter sleep status and won't be limited by this parameter.
-  When AC motor drive is in sleep process, SLEEP will be displayed on the digital keypad till frequency command attains to wake up frequency.

11 - 08

Sleep Frequency of Sleep Process (hz) / Wake Up Feedback
Frequency of Sleep Process (%)

Factory Setting: 0.00

Settings

0.00~11-09 (wake up frequency)

Unit: 0.01

-  This parameter determines frequency after AC drive enters sleep process.
-  After AC drive enters sleep status, it will stop to output signal but PID controller will keep working.
-  When Pr11-12 = 1, this parameter is a certain percentage of PID rate.

11 - 09

Wake Up Frequency of Sleep Process


Factory Setting: 0.00

Settings

0.00 to 120.00Hz

Unit: 0.01

-  This parameter determines wake up frequency after AC drive enters sleep process.
-  PID control function will keep calculating frequency command (F) when AC drive is in sleep process. When frequency command attains to wake up frequency, AC drive will accelerate from 01-05 minimum frequency setting according to V/f curve.
-  The setting of wake up frequency needs to be greater than sleep frequency.
-  The Sleep feedback rate of Sleep Process has to be bigger than Wake up feedback rate of Sleep Process.
-  When Pr11-12 =1, this parameter is a certain percentage of PID rate.





11 - 10

Treatment of Fixed Amount Circulation Malfunction

Factory Setting: 00

- Settings
- 00: Turn off all motors
- 01: Turn off AC drive

- This parameter determines treatment of AC drive malfunction during fixed amount circulation.
- When AC drive occurs power circuit malfunction to make auxiliary power disable and microprocessor can't work, all output will close automatically.

**11 - 11 Stop Frequency of Auxiliary Motor**

Factory Setting: 0.00

Settings 0.00~120.00Hz

Unit: 0.01Hz

📖 If output frequency of AC drive is less than or equal to this parameter when AC drive is fixed amount circulation (11-01=02) or fixed amount (11-01=03), AC drive will make motor stop in sequence.

11-12	Setting of Sleep Mode Function		Factory Setting	00
	Setting Range	01-08		
	00	Refer to PID Output Command		
	01	Refer to Feedback signal		

📖 When the setting is 00: the Pr11-08 is the <Sleep Frequency of Sleep Process.> while Pr11-09 is the <Wake Up Frequency of Sleep Process>

📖 When the setting is 01: the Pr11-08 is the Wake Up Feedback Frequency of Sleep Process, while Pr11-09 is the Sleep Feedback of Sleep Process.>

11-13	Reserved		Factory Setting	
	Setting Range	Reserved		

11-14	Delay Time when Switching Circulating Motors (2)		Factory Setting	1.0
	Setting Range	0.0-3600.0 Sec		

📖 This parameter determines the delay time of switching circulating motors from mains electricity while doing fixed amount control (Pr11-01=2)



Fire Mode :

By choosing the fire mode and ignoring most of errors to make the AC drive to work non-stop could cause damages or mal function to the AC Drive and the system itself. It could even incur a fire accident. If any errors occurred by using the fire mode then lead to damages of personnel or properties, Delta Electronics Co. Ltd will not be responsible. If an AC drive is set to be at fire mode and is running under this mode, then any direct, indirect, specific or afterward damages happen to the end users or others, Delta Electronics will not be responsible for that.

Note:

Only under certain circumstance, the fire mode may be used to keep the motors running. For example: To keep the ventilation system running in the stair ways and tunnels, ventilation systems cannot be shut down to help the evacuation. Some errors occurred while running the fire mode will be ignored to keep the motors running

Action time

When Pr-11-15 is not equal to zero and when external terminal MI=42 or MI=43.

The error code of AC drive under normal usage and fire mode

Code	Error Name	Normal Usage	Fire Mode
1	OC	X	X
2	OV	X	X
3	OH	X	X
4	OL	X	
5	OL1	X	
6	EF	X	
7	OCC	X	X
8	CF3	X	X
9	HPF	X	X
10	OCA	X	X
11	OCN	X	X
12	OCD	X	X
13	GFF	X	X
14	LV	X	
15	CF1	X	
16	CF2	X	X
17	BB	X	
18	OL2	X	
20	Code	X	
21	EF1	X	



22	PHL	X	
23	Lc	X	
24	FbL	X	
26	FANP	X	
27	Fan1 Abnormal	X	
28	Fan2 Abnormal	X	
29	Fan3 Abnormal	X	
30	Fan1,2,3 Abnormal	X	
31	Fan1,2 Abnormal	X	
32	Fan1,3 Abnormal	X	
33	Fan2,3 Abnormal	X	
34	FV	X	X
41	HPF1	X	X
42	HPF2	X	X
43	HPF3	X	X
44	HPF4	X	X
45	CF33	X	X
46	CF34	X	X
47	CF35	X	X
48	CF36	X	X
49	CF37	X	X
50	CF38	X	X

11-15	Fire Mode Function		⚡ Factory Setting	0
	Setting Range			
	00	Turn off Fire Mode Function		
	01	To turn at Clock-wise direction		
	02	To turn at counter clock-wise direction		

📖 This parameter determines to turn on or off the Fire mode function and the direction of fire mode.

11-16	Operation Frequency at Fire Mode		⚡ Factory Setting	60.00
	Setting Range	0~FMAX		

📖 This parameter determines the operation frequency at fire mode.

11-17	Number of Times to Re-activate while Abnormal Fire Mode		Factory Setting	0
	Setting Range	0~10		

📖 This parameter determines the number of times to re-activate the system while abnormal fire mode.

📖 Able to re-activate while abnormal fire mode: OC、OV、OH、OCC、OCA、OCN、OCD、GFF、FV。

📖 This parameter is only effective when bypass mode is already set up. If bypass mode is not set up, then the AC drive will always be reset.




11-18	Bypass Function		Factory Setting	00
	Setting Range			
	00	Turn Off		
	01	Turn On		

- This parameter determines to turn on or turn off the bypass function. AC drive can switch to operate under this function.
- The abnormal codes are to activate bypass function under the fire mode. OC 、OV 、OH 、OCC 、CF3 、HPF 、OCA 、OCN 、OCD 、GFF 、PHL 、FV 。




11-19	Bypass Delay time under Fire Mode		Factory Setting	0.0
	Setting Range	0.0~6550.0 Second		

- This parameter determines the bypass delay time.
- When the external bypass actuation timing starts, the inverter stops any output.
- External bypass actuation timing

When error codes such as CF3, HPF are shown on the inverter, wait for command of Pr11-19<Bypass delay time under fire mode> then the bypass will actuate.





- External bypass actuation timing
- When error codes are not eliminated (i.e. OC, OV, OH, OCC, OCA, OCD, OCN, GFF and FV) and when Pr11-19<Bypass delay time under fire mode> arrives.



5

External bypass Actuation Timing

Under the fire mode, the number of time of auto-rest is ZERO for the following error code: OC, OV, OH, OCC, OCA, OCD, OCN, and GFF.





Additional information on Circulative Control

Pr11-01=01 : Fixed Time Circulation

After Motor#1 follows Pr11-03 <Fixed Time Circulation Setting> to run for some time, it will park freely. Then Motor # 2 will wait for the Pr11-04<Motor Switch Delay Time> and start to run. The order to run of fixed time circulation is Motor1-Motor2-Motor3-Motor4-Motor1-Motor2-Motor3-Motor4 repeatedly.

● Setting of Related Parameters :

Pr11-01=01 Select <Fixed Time Circulation>


Pr11-02=X Set quantity of motors, maximum 8 motors.

Pr11-03=X Set time for fixed time circulation.

Pr11-04=X Set time for motor switch delay time.

Multi-function output terminal will follow Pr11-02 for setting.


Pr11-02=	01	02	03	04	05	06	07	08
Pr03-00=	1	1	1	1	1	1	1	1
Pr03-01=	-	2	2	2	2	2	2	2
Pr03-02=	-	-	3	3	3	3	3	3
Pr03-03=	-	-	-	4	4	4	4	4
Pr03-04=	-	-	-	-	5	5	5	5
Pr03-05=	-	-	-	-	-	6	6	6
Pr03-06=	-	-	-	-	-	-	7	7
Pr03-07=	-	-	-	-	-	-	-	8



Description of Fixed Time Circulation



● Example of Fixed Time Circulation: Connecting 4 Motors





Pr11-01=02 : Fixed Amount Circulation

When Motor#1 of the inverter accelerate from 0Hz to the highest frequency, it will follow Pr11-05<Motor switch delay time during Fixed Amount Circulation> to decelerate. After the time set by Pr11-04<Motor Switch Delay Time>, Motor01 will not be powered by the inverter but by the mains. Then after the same length of time set by Pr11-04<Motor Switch Delay Time>, Motor#2 will be powered by the inverter, so on and so forth. Please refer to the Increasing Demand graph.

When Motor#4 which is powered by the inverter decreases from the largest frequency to 0Hz and after it runs for the length of time set by Pr11-16, it will make one of the motor not to be powered by the mains electricity. Then after it runs again for the same length of time set by Pr11-16, it will stop another motor being powered by the mains electricity, so on and so forth. Please refer to the Decreasing demand graph. No matter it is the acceleration or the deceleration, the 4 motors will be running at this order repeatedly: 1-2-3-4-1-2-3-4

- Setting of Related Parameters

Pr11-01=02 Select <Fixed Amount Circulation>.

Pr11-02=X Set quantity of motors, maximum 4.

Pr11-05=X Set motor switch delay time


Pr11-06=X Activation Frequency of an Auxiliary

Pr11-04=X Command from the AC drive to increase the motor switch delay time (Please refer to Increasing demand graph)


Pr11-14=X Command from the AC drive to decrease the motor switch delay time (Please refer to the Decreasing demand graph).

Multi-function output terminal will follow Pr11-02 for setting.



Pr11-02=	01	02	03	04	
Pr03-00=	1	1	1	1	Motor #1 by VFD-F
Pr03-01=	2	2	2	2	Motor #1 on Mains
Pr03-02=	-	3	3	3	Motor #2 by VFD-F
Pr03-03=	-	4	4	4	Motor #2 on Mains
Pr03-04=	-	-	5	5	Motor #3 by VFD-F
Pr03-05=	-	-	6	6	Motor #3 on Mains
Pr03-06=	-	-	-	7	Motor #4 by VFD-F
Pr03-07=	-	-	-	8	Motor #4 on Mains



5




Increasing demand 圖示



Decreasing demand 圖示

● Example of Fixed Amount Circulation: Connecting to 4 motors





Pr11-01=03 : Fixed Amount Control

The motor powered by the inverter accelerates from 0Hz to exceed the frequency value set at Pr11-06. Then after the inverter runs for the length of time set at Pr11-05, it will pass Auxiliary#1 to be powered by the mains electricity. Then it will pass other auxiliaries to be powered by the main electricity in the same way. (Please refer to Increasing Demand graph)

The motor powered by the inverter decelerates from its largest frequency to 0Hz. Then when it passes the length of time set at Pr11-05, it will stop Auxiliary#1 being powered by the mains electricity. It will continue to stop repeatedly other auxiliaries being powered by the mains electricity one by one in the following order: 1-2-3-4-1-2-3-4.

- Setting of related Parameters

Pr11-01=01 Select fixed time circulation



Pr11-02=X Set quantity of motors, maximum 8 motors.

Pr11-05=X Delay time to activate auxiliaries.


Pr11-06=X Activation frequency of auxiliaries

Multi-function output terminals follow automatically the settings of Pr11-02

Pr11-02=	01	02	03	04	05	06	07	08	
Pr03-00=	1	1	1	1	1	1	1	1	Motor#1 on Mains
Pr03-01=	-	2	2	2	2	2	2	2	Motor#2 on Mains
Pr03-02=	-	-	3	3	3	3	3	3	Motor#3 on Mains
Pr03-03=	-	-	-	4	4	4	4	4	Motor#4 on Mains
Pr03-04=	-	-	-	-	5	5	5	5	Motor#5 on Mains
Pr03-05=	-	-	-	-	-	6	6	6	Motor#6 on Mains
Pr03-06=	-	-	-	-	-	-	7	7	Motor#7 on Mains
Pr03-07=	-	-	-	-	-	-	-	8	Motor#8 on Mains




Graph: Increasing Demand



Graph: Increasing Demand

● Example of Fixed Amount Control: Connecting to 4 motors





CHAPTER 6 MAINTENANCE AND INSPECTIONS

Modern AC drives are based on solid state electronics technology, preventive maintenance is required to operate this AC drive in its optimal condition, and to ensure a long life. It is recommended to perform a monthly check up of the AC drive by a qualified technician. Before the check up, always turn off the AC Input Power to the unit. ***Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between B1 and Ground using a multimeter set to measure DC.***

6.1 Periodic Inspection

Basic check up items to detect if there were any abnormality during the operation:

1. Whether the motors are operating as expected.
2. Whether the installation environment is abnormal.
3. Whether the cooling system is operating as expected.
4. Whether any irregular vibration or sound occurred during the operation.
5. Whether the motors are overheated during the operation.
6. Always check the input voltage of the AC drive with Voltmeter.

6.2 Periodic Maintenance

 **WARNING!** Disconnecting AC power before processing!

1. Tighten and reinforce the screws of the AC drive if necessary, cause it may loose due to the vibration or changing of temperatures.
2. Whether the conductors or insulators were corroded and damaged.
3. Check the resistance of the insulation with Meg-ohmmeter.
4. Often check and change the capacitors and relays.
5. If use of the AC drive is discontinued for a long period of time, turn the power on at least once every two years and confirm that it still functions properly. To confirm functionality, disconnect the motor and energize the AC drive for 5 hours or more before attempting to run a motor with it.
6. Clean off any dust and dirt with a vacuum cleaner. Place special emphasis on cleaning the ventilation ports and PCBs. Always keep these areas clean, as accumulation of dust and dirt can cause unforeseen failures.



This page intentionally left blank.



CHAPTER 7 Troubleshooting and Fault Information

The AC drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC drive digital keypad display. The four most recent faults can be read on the digital keypad display.

NOTE: Faults can be cleared by a reset from the keypad or Input Terminal.

Common Problems and Solutions:

Fault Name	Fault Descriptions	Corrective Actions
OC	The AC drive detects an abnormal increase in current.	1. Check whether the motors horsepower corresponds to the AC drive output power. 2. Check the wiring connections between the AC drive and motor for possible short circuits. 3. Increase the Acceleration time. 4. Check for possible excessive loading conditions at the motor. 5. If there are any abnormal conditions when operating the AC drive after short-circuit being removed, it should be sent back to manufacturer.
OU	The AC drive detects that the DC bus voltage has exceeded its maximum allowable value.	1. Check whether the input voltage falls within the rated AC drive input voltage. 2. Check for possible voltage transients. 3. Bus over-voltage may also be caused by motor regeneration. Either increase the decel time or add an optional brake resistor. 4. Check whether the required brake power is within the specified limits.



Fault Name	Fault Descriptions	Corrective Actions
OH	The AC drive temperature sensor detects excessive heat.	1. Ensure that the ambient temperature falls within the specified temperature range. 2. Make sure that the ventilation holes are not obstructed. 3. Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins. 4. Provide enough spacing for adequate ventilation.
LU	The AC drive detects that the DC bus voltage has fallen below its minimum value.	Check whether the input voltage falls within the rated AC drive's input voltage.
OL	The AC drive detects excessive drive output current. Note: The AC drive can withstand up to 150% of the rated current for a maximum of 60 seconds.	1. Check whether the motor is overloaded. 2. Reduce torque compensation setting as set in Pr.7-02. 3. Increase the AC drive's output capacity.
OL1	Internal electronic overload trip	1. Check for possible motor overload. 2. Check electronic thermal overload setting. 3. Increase motor capacity. 4. Reduce the current level so that the drive output current does not exceed the value set by the Motor Rated Current Pr.7-00.
OL2	Motor overload. Check the parameter settings (Pr.6-03 to Pr.6-05)	1. Reduce the motor load. 2. Adjust the over-torque detection setting to an appropriate setting (Pr.06-03 to Pr.06-05).
HPF1	GFF hardware error	Return to the factory.
HPF2	CC (Current Clamp)	Return to the factory.



Fault Name	Fault Descriptions	Corrective Actions
HPF3	OC hardware error	Return to the factory.
HPF4	OV hardware error	Return to the factory.
HPF5	OH hardware error	Return to the factory.
CE--	Communication Error	1. Check the connection between the AC drive and computer for loose wires. 2. Check if the communication protocol is properly set.
ocA	Over-current during acceleration: 1. Short-circuit at motor output. 2. Torque boost too high. 3. Acceleration time too short. 4. AC drive output capacity is too small.	1. Check for possible poor insulation at the output line. 2. Decrease the torque boost setting in Pr.7-02. 3. Increase the acceleration time. 4. Replace with the AC drive with one that has a higher output capacity (next HP size).
ocd	Over-current during deceleration: 1. Short-circuit at motor output. 2. Deceleration time too short. 3. AC drive output capacity is too small.	1. Check for possible poor insulation at the output line. 2. Increase the deceleration time. 3. Replace with the AC drive with one that has a higher output capacity (next HP size).
ocn	Over-current during steady state operation: 1. Short-circuit at motor output. 2. Sudden increase in motor loading. 3. AC drive output capacity is too small.	1. Check for possible poor insulation at the output line. 2. Check for possible motor stall. 3. Replace with the AC drive with one that has a higher output capacity (next HP size).



Fault Name	Fault Descriptions	Corrective Actions
EF	Analog Signal Error	1. Check ACI wiring. 2. Check whether the input current of ACI is lower than Pr.04-13/04-17 setting.
EF1	Emergency stop. When the multi-function input terminals (MI1 to MI8) stop, AC drive stops any output.	Press RESET after fault has been cleared.
CF1	Internal memory IC cannot be programmed.	1. Return to the factory. 2. Check the EEPROM on the control board.
CF2	Internal memory IC cannot be read.	1. Return to the factory. 2. Reset drive to factory defaults.
CF33	U-phase error	Return to the factory.
CF34	V-phase error	Return to the factory.
CF35	W-phase error	Return to the factory.
CF36	OV or LV	Return to the factory.
CF37	Isum error	Return to the factory.
CF38	OH error	Return to the factory.
codeE	Software protection failure	Return to the factory.
CFR	Auto accel/decel failure	Don't use the function of auto acceleration /deceleration.



Fault Name	Fault Descriptions	Corrective Actions
OFF	Ground fault: The AC drive output is abnormal. When the output terminal is grounded (short circuit current is 50% more than the AC drive rated current), the AC drive power module may be damaged. The short circuit protection is provided for AC drive protection, not user protection.	Ground fault: 1. Check whether the IGBT power module is damaged. 2. Check for possible poor insulation at the output line.
bb	External Base Block. AC drive output is turned off.	1. When the external input terminal (B.B) is active, the AC drive output will be turned off. 2. Disable this connection and the AC drive will begin to work again.
FbL	PID Feedback Signal Error	1. Check parameter settings (Pr.10-00) and AVI/ACI1/ACI2 wiring. 2. Check for possible fault between system reaction time and the feedback signal detection time (Pr.10-08/Pr.10-09).
FAnP	Fan Power Fault (150~300HP)	Return to the factory.
FF1	Fan 1 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
FF2	Fan 2 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
FF3	Fan 3 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.



Fault Name	Fault Descriptions	Corrective Actions
FF 123	Fan 1, 2, 3 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
FF 12	Fan 1, 2 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
FF 13	Fan 1, 3 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
FF23	Fan 2, 3 fault (150~300HP)	Remove any foreign objects on the heatsinks and check for possible dirty heat sink fins.
F_U	Gate Drive Low Voltage Protect	Return to the factory.



CHAPTER 8 PARAMETER SUMMARY

Group 0 AC Drive Status Parameter

	Parameters	Functions	Settings	Factory Setting	Customer
	00-00	Software Version	Read only		
	00-01	AC Drive Status Indication 1	00: No Fault occurred 01: oc (over current) 02: ov (over voltage) 03: oH (over temperature) 04: oL (overload) 05: oL1 (electronic thermal relay) 06: EF (External Fault) 07: occ (AC drive IGBT fault) 08: cF3 (CPU failure) 09: HPF (Hardware Protection Failure) 10: ocA (current exceed during Acceleration) 11: ocd (current exceed during Deceleration) 12: ocn (current exceed during Steady State) 13: GFF (Ground Fault) 14: Lv (Low voltage) 15: cF1 (input data abnormal) 16: cF2 (output data abnormal) 17: bb (base block) 18: oL2 (over load2) 19: Reserved 20: codE (software or password protection) 21: EF1 (external emergency stop) 22: PHL (phase loss) 23: Lc (Low current) 24: FbL (Feedback loss) 25: Reserved 26: FAnP (Fan Power Fault) 27: FF1 (Fan 1 fault) 28: FF2 (Fan 2 fault) 29: FF3 (Fan 3 fault) 30: FF123 (Fan 1, 2, 3 fault) 31: FF12 (Fan 1, 2 fault) 32: FF13 (Fan 1, 3 fault) 33: FF23 (Fan 2, 3 fault) 34: Fv (Gate Drive Low Voltage Protect)	Read	



Parameters	Functions	Settings	Factory Setting	Customer
00-02	AC Drive Status Indication 2	Bit 0~1: 00: Run led is off and stop led is on. 01: Run led is blink and stop led is on. 10: Run led is on and stop led is blink. 11: Run led is on and stop led is off. Bit 2: 1: Jog on. Bit 3~4: 00: Rev led is off and FWD led is on. 01: Rev led is blink and FWD led is on. 10: Rev led is on and FWD led is blink. 11: Rev led is on and FWD led is off. Bit 5-7: Reserved Bit 8: Master frequency source via communication interface Bit 9: Master frequency source via analog Bit10: Running command via communication interface Bit11: Parameter locked Bit12~15: Reserved	Read	
00-03	Frequency Setting	Read only	Read	
00-04	Output Frequency	Read only	Read	
00-05	Output Current	Read only	Read	
00-06	DC-BUS Voltage	Read only	Read	
00-07	Output Voltage	Read only	Read	
00-08	Output Power Factor	Read only	Read	
00-09	Output Power (kW)	Read only	Read	
00-10	Feedback Signal Actual Value	Read only	Read	
00-11	Feedback Signal (%)	Read only	Read	
00-12	User Target Value (Low bit) uL 0-99.99	Read only	Read	
00-13	User Target Value (High bit) uH 0-9999	Read only	Read	
00-14	PLC time	Read only	Read	
00-15	Stall Torque Output	Read only	Read	


Group 1 Basic Parameter (Twice the value for 460V class)

	Parameters	Functions	Settings	Factory Setting	Customer
	01-00	Maximum Output Frequency	50.00~120.00Hz	60.00	
	01-01	Maximum Voltage Frequency (Base Frequency)	0.10~120.00 Hz	60.00	
	01-02	Maximum Output Voltage	230V series: 0.1~255.0V 460V series: 0.2~510.0V	220.0 440.0	
	01-03	Mid-point Frequency	0.10~120 Hz	1.50	
	01-04	Mid-point Voltage	230V series: 0.1~255.0V 460V series: 0.2~510.0V	5.5 11.0	
	01-05	Minimum Output Frequency	0.10~20.00 Hz	1.50	
	01-06	Minimum Output Voltage	230V series: 0.1~50.0V 460V series: 0.2V~100.0V	5.5 11.0	
	01-07	Upper Bound Frequency	0.00~120.00 Hz	60.00	
	01-08	Lower Bound Frequency	0.00~120.00 Hz	0.00	
⚡	01-09	Acceleration Time 1	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-10	Deceleration Time 1	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-11	Acceleration Time 2	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-12	Deceleration Time 2	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-13	Acceleration Time 3	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-14	Deceleration Time 3	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-15	Acceleration Time 4	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-16	Deceleration Time 4	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-17	JOG Acceleration Time	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-18	JOG Deceleration Time	0.1~3600.0 Sec	10.0/ 60.0	
⚡	01-19	JOG frequency	0.0 Hz~120.00 Hz	6.00	
	01-20	S Curve Delay Time in Accel	0.00~2.50sec	0.00	
	01-21	S Curve Delay Time in Decel	0.00~2.50sec	0.00	
⚡	01-22	Modulation Index	0.90~1.20	1.00	
	01-23	Accel/Decel Time Unit	00: Unit is 1 Sec 01: Unit is 0.1 Sec 02: Unit is 0.01 Sec	01	



Group 2 Digital Output/Input Parameter

	Parameters	Functions	Settings	Factory Setting	Customer
⚡	02-00	Source of Frequency Command	00: via keypad 01: via analog input AVI 02: via analog input ACI1 03: via analog input ACI2 04: via RS485 serial communication 05: via External Reference	00	
⚡	02-01	Source of Operation Command	00: Controlled by the digital keypad 01: Controlled by the external terminals, keypad STOP enabled. 02: Controlled by external terminals, keypad STOP disabled. 03: Controlled by the RS-485 communication interface, keypad STOP enabled. 04: Controlled by the RS-485 communication interface, keypad STOP disabled.	00	
	02-02	Stop Method	00: Stop = ramp to stop, E.F. (External Fault) = coast to stop 01: Stop = coast to stop, E.F. = coast to stop 02: Stop = ramp to stop, E.F. = ramp to stop 03: Stop = coast to stop, E.F. = ramp to stop	00	
⚡	02-03	PWM Carrier Frequency Selections	1~10HP: 4000~10000Hz 15~30HP: 3000~9000Hz ≥ 40HP: 2000~6000Hz	9000Hz 6000Hz 4000Hz	
	02-04	Forward/Reverse Enable	00: Forward enabled 01: Reverse disabled 02: Forward disabled	00	
	02-05	2-wire/3-wire Operation Control Modes	00: 2-wire (#1), FWD/STOP, REV/STOP 01: 2-wire (#2), RUN/STOP, REV/FWD 02: 3-wire	00	
	02-06	Line Start Lockout	00: Enabled 01: Disabled 02: If the command to run still remains after resetting, the inverter will continue to run.	01	



Parameters	Functions	Settings	Factory Setting	Customer
02-07	Loss of ACI Signal	00: Decelerate to 0Hz 01: E.F. 02: Continue operation by the last frequency command 03: Use loss of ACI Signal Frequency of Pr02-16	01	
⚡ 02-08	Start-up Display Selection	Bit0~1: 00 = F LED 01 = H LED 10 = U LED (special display) 11 = Fwd / Rev Bit2: 0 = Fwd LED / 1 = Rev LED Bit3~5: 000 = 1st 7-step 001 = 2nd 7-step 010 = 3rd 7-step 011 = 4th 7-step 100 = 5th 7-step Bit6~7: Reserved	00	
⚡ 02-09	Special Display	00: A displays output current of AC drive 01: U displays DC-Bus voltage of AC drive 02: E displays RMS of output voltage 03: P displays feedback Signal 04: PLC display auto procedure state 05: T displays heat sink's temperature 06: The keypad's screen displays both target value and feedback value controlled by PID (proportional-integral-derivative controller (PID controller)).	00	
⚡ 02-10	User Defined Coefficient	0.01~160.00	1.00	
⚡ 02-11	Flying Start	00: Disable 01: Enable (Dc brake disabled)	00	
⚡ 02-12	Flying Start Frequency	00: Trace from master frequency command 01: Trace from maximum setting frequency 01-00	00	



	Parameters	Functions	Settings	Factory Setting	Customer
⚡	02-13	Master Frequency Memory Setting	00: Do not remember the last known frequency 01: Remember the last known frequency	01	
⚡	02-14	Source of Second Frequency Command	00: Master Frequency Setting is controlled by PID controller. 01: Master frequency is controlled by an external terminal via analog input AVI: DC 0~+10V. 02: Master frequency is controlled by an external terminal via analog input ACI1: DC 4~20mA. 03: Master frequency is controlled by an external terminal via analog input ACI2: DC 4~20mA 04: Master frequency is handled via RS485 serial communication (RJ-11). 05: External Reference Master frequency via External Reference.	00	
⚡	02-15	Source of Second Operation Command	00: Controlled by the digital keypad 01: Controlled by the external terminals, keypad STOP enabled. 02: Controlled by the external terminals, keypad STOP disabled 03: Controlled by the RS-485 communication interface keypad STOP enabled. 04: Controlled by the RS-485 communication interface keypad STOP disabled.	00	
⚡	02-16	Loss of ACI Signal	00-Highest operational frequency	00	



Group 3 Output Function Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	03-00	Multi-function Output terminal 1	00: No function	00	
	03-01	Multi-function Output terminal 2	01: Motor No.1	00	
	03-02	Multi-function Output terminal 3	02: Motor No.2	00	
	03-03	Multi-function Output terminal 4	03: Motor No.3	00	
	03-04	Multi-function Output terminal 5	04: Motor No.4	00	
	03-05	Multi-function Output terminal 6	05: Motor No.5	00	
	03-06	Multi-function Output terminal 7	06: Motor No.6	00	
	03-07	Multi-function Output terminal 8	07: Motor No.7	00	
			08: Motor No.8		
			09: Auxiliary 1 output		
			10: Auxiliary 2 output		
			11: Auxiliary 3 output		
			12: Auxiliary 4 output		
			13: Auxiliary 5 output		
			14: Auxiliary 6 output		
			15: Auxiliary 7 output		
			16: Indication during operation		
			17: Master frequency attained		
			18: Zero speed (including shutdown)		
			19: Over-torque		
			20: External fault		
			21: Low voltage detection		
			22: Operation mode indication		
			23: Fault indication		
			24: Master frequency attained 1		
			25: Master frequency attained 2		
			26: Over temperature indication		
			27: Drive ready		
			28: External emergency stop (EF1)		
			29: Software brake output		
			30: OL or OL1 overload warning		
			31: Dwell indication (sleep)		
			32: Low current indication		
			33: PID feedback error indication		
			34: PLC program running		
			35: PLC program step completed		
			36: PLC program completed		



	Parameters	Functions	Settings	Factory Setting	Customer
			37: PLC program operation Paused 38: Loss of an ACI signal indication 39: HOA-Hand mode indication 40: HOA-Off mode indication 41: HOA-Auto mode indication 42: Fire mode indication 43: Bypass fire mode indication		
	03-08	Master Frequency Attained 1	0.00~120.00 Hz	0.00	
	03-09	Master Frequency Attained 2	0.00~120.00 Hz	0.00	
	03-10	Analog Output 1, (AFM1) 0~10Vdc	00: Output frequency 01: Output current	00	
	03-11	Analog Output 2, (AFM2) 0/4~ 20mA	02: Output voltage 03: Frequency command 04: Power factor loading	01	
⚡	03-12	Analog Output Gain 1	01~200%	100	
⚡	03-13	Analog Output Gain 2	01~200%	100	
	03-14	Analog Output 2 Selection (AFM2 Definition)	00: 0~20mA 01: 4~20mA	01	
	03-15	DC Fan Control	00: Fan runs on power up. 01: Fan begins upon a RUN command. Fan stops 1 minute after a STOP command. 02: Fan begins upon a RUN command. Fan stops after a STOP command 03: Fan is controlled by temperature. Approximately a 60°C temperature will start the fan. 04: Unusual fan status warning, inverter continues to run. (Setting 04 is only available in the existing firmware v.3.104, the new released version v.1.302 and the versions above v.1.302)	00	



Group 4 Input Function Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	04-00	Multi-function Input terminal 1	00: No function	01	
	04-01	Multi-function Input terminal 2	01: Multi-Speed terminal 1	02	
	04-02	Multi-function Input terminal 3	02: Multi-Speed terminal 2	03	
	04-03	Multi-function Input terminal 4	03: Multi-Speed terminal 3	04	
	04-04	Multi-function Input terminal 5	04: Multi-Speed terminal 4	05	
	04-05	Multi-function Input terminal 6	05: Reset (NO)	07	
	04-06	Multi-function Input terminal 7	06: Reset (NC)	08	



Parameters	Functions	Settings	Factory Setting	Customer
04-07	Multi-function Input terminal 8	07: Jog operation (JOG) 08: Accel/Decel disable 09: Accel/Decel 2 selection 10: Accel/Decel 3 selection 11: B.B. (NO) input 12: B.B. (NC) input 13: Increase frequency 14: Decrease frequency 15: Emergency stop (NO) 16: Emergency stop (NC) 17: AVI(open), ACI1(close) 18: KEYPAD(open), EXT(close) 19: PID disable 20: Auxiliary 1 input 21: Auxiliary 2 input 22: Auxiliary 3 input 23: Auxiliary 4 input 24: Auxiliary 5 input 25: Auxiliary 6 input 26: Auxiliary 7 input 27: Motor No.1 output disable 28: Motor No.2 output disable 29: Motor No.3 output disable 30: Motor No.4 output disable 31: All motor output disable 32: Run PLC program 33: Pause PLC program 34: Enable the source of the second frequency 35: Enable the second operation command 36: Motor No.5 output disabled 37: Motor No.6 output disabled 38: Motor No.7 output disabled 39: Motor No.8 output disabled 40: HOA-Hand mode indication 41: HOA-Auto mode indication 42: (NO)Fire mode (NO) 43: Fire mode(NC)	09	
04-08	Digital Input Terminal Response Time	01~20	01	
04-09	AVI Minimum voltage	0.0~10.0V	0.0	
04-10	AVI Maximum voltage	0.0~10.0V	10.0	
04-11	AVI Minimum frequency (percentage of Pr.1-00)	0.00~100.00%	0.00	



	Parameters	Functions	Settings	Factory Setting	Customer
	04-12	AVI Maximum frequency (percentage of Pr.1-00)	0.00~100.00%	100.00	
	04-13	ACI1 Minimum current	0.0~20.0mA	4.0	
	04-14	ACI1 Maximum current	0.0~20.0mA	20.0	
	04-15	ACI1 Minimum frequency (percentage of Pr.1-00)	0.0~100.0%	0.00	
	04-16	ACI1 Maximum frequency (percentage of Pr.1-00)	0.0~100.0%	100.00	
	04-17	ACI2 Minimum current	0.0~20.0mA	4.0	
	04-18	ACI2 Maximum current	0.0~20.0mA	20.0	
	04-19	ACI2 Minimum frequency (percentage of Pr.1-00)	0.00~100.00%	0.00	
	04-20	ACI2 Maximum frequency (percentage of Pr.1-00)	0.00~100.00%	100.00	
	04-21	Analog Input Delay AVI	0.00~10.00 Sec	0.50	
	04-22	Analog Input Delay ACI1	0.00~10.00 Sec	0.50	
	04-23	Analog Input Delay ACI2	0.00~10.00 Sec	0.50	
	04-24	Summation of External Frequency Sources	00: No functions 01: AVI+ACI1 02: ACI1+ACI2 03: ACI2+AVI 04: Communication master frequency +AVI 05: Communication master frequency +ACI1 06: Communication master frequency +ACI2 07: First frequency + Second frequency 08: First frequency – Second frequency	00	
✓	04-25	Summation of First External Frequency Source	00: Digital keypad 01: External Terminal AVI 02: External Terminal ACI1 03: External Terminal ACI2 04: RS-485 Communication Interface	00	
✓	04-26	Summation of Second External Frequency Source	00: Digital Keypad 01: External Terminal AVI 02: External Terminal ACI1 03: External Terminal ACI2 04: RS-485 Communication Interface		



Group 5 Multi-step Speed Frequency Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
↗	05-00	1 st Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-01	2 nd Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-02	3 rd Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-03	4 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-04	5 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-05	6 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-06	7 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-07	8 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-08	9 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-09	10 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-10	11 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-11	12 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-12	13 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-13	14 th Step Speed Frequency	0.00~120.00 Hz	0.00	
↗	05-14	15 th Step Speed Frequency	0.00~120.00 Hz	0.00	
	05-15	PLC Mode	00: Disable PLC operation 01: Execute one program cycle 02: Continuously execute program cycles 03: Execute one program cycle step by step 04: Continuously execute program cycles step by step	00	
	05-16	PLC Forward/ Reverse Motion	00 to 32767 (00: FWD 01: REV)	00	
	05-17	Time Duration Step 1	0.0 to 65500 sec	0.0	
	05-18	Time Duration Step 2	0.0 to 65500 sec	0.0	
	05-19	Time Duration Step 3	0.0 to 65500 sec	0.0	
	05-20	Time Duration Step 4	0.0 to 65500 sec	0.0	
	05-21	Time Duration Step 5	0.0 to 65500 sec	0.0	
	05-22	Time Duration Step 6	0.0 to 65500 sec	0.0	
	05-23	Time Duration Step 7	0.0 to 65500 sec	0.0	
	05-24	Time Duration Step 8	0.0 to 65500 Sec	0.0	
	05-25	Time Duration Step 9	0.0 to 65500 Sec	0.0	
	05-26	Time Duration Step 10	0.0 to 65500 Sec	0.0	
	05-27	Time Duration Step 11	0.0 to 65500 Sec	0.0	
	05-28	Time Duration Step 12	0.0 to 65500 Sec	0.0	
	05-29	Time Duration Step 13	0.0 to 65500 Sec	0.0	



	Parameters	Functions	Settings	Factory Setting	Customer
	05-30	Time Duration Step 14	0.0 to 65500 Sec	0.0	
	05-31	Time Duration Step 15	0.0 to 65500 Sec	0.0	
	05-32	Time Unit Settings	00: 1 Sec 01: 0.1 Sec	00	



Group 6 Protection Function Parameters (Twice the value for 460V class)

	Parameters	Functions	Settings	Factory Setting	Customer
	06-00	Over-voltage Stall Prevention	230V: 330.0~410.0VDC 460V: 660.0~820.0VDC 00: Disable	390.0 780.0	
	06-01	Over-current Stall Prevention during Acceleration	20~150% 00: Disable	120	
	06-02	Over-current Stall Prevention during operation	20~150% 00: Disable	120	
	06-03	Over-torque Detection Selection	00: Over-torque detection disabled. 01: Over-torque detection enabled during constant speed operation (OL2), and operation continues. 02: Over-torque detection enabled during constant speed operation (OL2), and operation halted. 03: Over-torque detection enabled during operation (OL2), and operation continues. 04: Over-torque detection enabled during operation (OL2), and operation halted.	00	
	06-04	Over-torque Detection Level	30~150%	110	
	06-05	Over-torque Detection Time	0.1~60.0 Sec	0.1	
	06-06	Electronic Thermal Relay Selection	00: Operate disabled. 01: Operate with a standard motor. 02: Operate with a special motor.	02	
	06-07	Electronic Thermal Characteristic	30~600 Sec	60	
	06-08	Low Current Detection Level	00~100% (00 disabled)	00	
	06-09	Low Current Detection Time	0.1~ 3600.0 Sec	10.0	
	06-10	Low Current Detection Treatment	00: Warn and ramp to stop 01: Warn and coast to stop 02: Warn and keep operating	01	
	06-11	Present Fault Record	00: No fault	00	
	06-12	Second Most Recent Fault Record	01: Oc (over-current) 02: Ov (over-voltage)	00	
	06-13	Third Most Recent Fault Record	03: OH (over temperature) 04: OL (over load)	00	



	Parameters	Functions	Settings	Factory Setting	Customer
	06-14	Fourth Recent Fault Record	05: oL1 (over load 1) 06: EF (External Fault) 07: Occ (IGBT module is abnormal) 08: cF3 (driver's internal circuitry is abnormal) 09: HPF (Hardware Protection Failure) 10: OcA (over-current during acceleration) 11: Ocd (over-current during deceleration) 12: Ocn (over-current during steady state operation) 13: GFF (Ground Fault) 14: Lv (Low voltage) 15: cF1 (EEPROM WRITE failure) 16: cF2 (EEPROM READ failure) 17: bb (Base block) 18: OL2 (over load2) 19: Reserved 20: Code (software/password protection) 21: EF1 (Emergency stop) 22: PHL (phase-loss) 23: Lc (Low Current) 24: FbL (Feedback Loss) 25: Reserved 26: FAnP (Fan Power Fault) 27: FF1 (Fan 1 fault) 28: FF2 (Fan 2 fault) 29: FF3 (Fan 3 fault) 30: FF123 (Fan 1, 2, 3 fault) 31: FF12 (Fan 1, 2 fault) 32: FF13 (Fan 1, 3 fault) 33: FF23 (Fan 2, 3 fault) 34: Fv (Gate Drive Low Voltage Protect)	00	
	06-15	Parameter Reset	00~65535 09: Reset parameters (50Hz, 220/380) 10: Reset parameters (60Hz, 220/440)	00	
	06-16	Parameter Protection Password Input	00~65535	00	
	06-17	Parameter Protection Password Setting	00~65535 00: No password protection	00	



	Parameters	Functions	Settings	Factory Setting	Customer
	06-18	Recording Mid/Low Voltage while running the AC Drive	00: None recorded low voltage, parameter reset automatically 01: None recorded low voltage, parameter reset manually 02: Recorded low voltage, parameter reset manually	00	

Group 7 AC Drive and Motor Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	07-00	Identity Code of AC Drive	Display by model type	##	
	07-01	Rated Current of AC Drive	Display by model type	##	
⚡	07-02	Full-load Current of Motor	30~120%	100%	
⚡	07-03	No-load Current of Motor	1~99%	30%	
⚡	07-04	Auto Slip Compensation Gain	0.0~3.0	0.0	
	07-05	Rated Slip Frequency of Motor	0.00~20.00Hz	0.00	
⚡	07-06	Auto Torque Compensation Gain	0.0~10.0	0.0	
⚡	07-07	Torque Compensation Gain by Manually	0.0~10.0	0.0	
	07-08	Calculate Total Running Time of the Motor (Min)	00 to 1439 Min	00	
	07-09	Calculate Total Running Time of the Motor (Day)	00 to 65535 Day	00	
⚡	07-10	Poles of Motors	2~10	4	
⚡	07-11	Reserved			


Group 8 Special Parameters (Twice the value for 460V class)

	Parameters	Functions	Settings	Factory Setting	Customer
	08-00	DC Brake Current Level	00~100%	00	
	08-01	DC Brake Time during Start-up	0.0~60.0 Sec	0.0	
	08-02	DC Brake Time during Stopping	0.00~60.00 Sec	0.0	
	08-03	Start-point for DC Brake	0.00~120.00 Hz	0.00	
	08-04	Momentary Power Loss Operation Selection	00: Disable 01: Trace from top downward 02: Trace from bottom upward	00	
	08-05	Maximum Allowable Power Loss Time	0.1~5.0 Sec	2.0	
	08-06	Speed Search Time	0.1~5.0 Sec	0.5	
	08-07	Maximum Speed Search Current	30~150%	110	
	08-08	BB speed search method	00: Trace from top downward 01: Trace from bottom upward	00	
	08-09	Auto Restart Times after Fault	00~10	00	
	08-10	Auto Restart Time after Fault	00 to 60000 sec	600	
	08-11	Operation Frequency Inhibition 1 UP	0.00~120.00 Hz	0.00	
	08-12	Operation Frequency Inhibition 1 DOWN	0.00~120.00 Hz	0.00	
	08-13	Operation Frequency Inhibition 2 UP	0.00~120.00 Hz	0.00	
	08-14	Operation Frequency Inhibition 2 DOWN	0.00~120.00 Hz	0.00	
	08-15	Operation Frequency Inhibition 3 UP	0.00~120.00 Hz	0.00	
	08-16	Operation Frequency Inhibition 3 DOWN	0.00~120.00 Hz	0.00	
	08-17	Automatic Energy-saving	00: Energy-saving operation disabled 01: Energy-saving operation enabled	00	
	08-18	Automatic Voltage Regulation (AVR)	00: AVR function enabled 01: AVR function disabled 02: AVR function disabled for deceleration	00	
⚡	08-19	Software Setting of the Brake Level (the action level of the brake resistor)	230V: 370~410VDC 460V: 740~820VDC 00: Disable	380.0 760.0	
⚡	08-20	Vibration Compensation Factor	00~1000	00	



Group 9 Communication Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
↗	09-00	Communication Address	•When Pr09-09=0, Setting range is 01~254 •When Pr09-09=1, Setting range is 01~127 •When Pr09-09=2, Setting Range is 01~254	01	
↗	09-01	Transmission Speed (Baud Rate)	00: Baud rate 4800 01: Baud rate 9600 02: Baud rate 19200 03: Baud rate 38400	01	
↗	09-02	Transmission Fault Treatment	00: Warn and keep operating 01: Warn and RAMP to stop 02: Warn and COAST to stop 03: No warning and no display	03	
	09-03	Over Time Detection during Transmission	00: Disable 01: Enable	00	
	09-04	Communication Format	00: 7-bit for ASCII 01: 8-bit for ASCII 02: 8-bit for RTU	00	
	09-05	Even/Odd Parity and Stopping Parity Setting	00: None parity + 2 stop bit 01: Even parity + 2 stop bit 02: Odd parity + 2 stop bit 03: None parity + 1 stop bit 04: Even parity + 1 stop bit 05: Odd parity + 1 stop bit	00	
↗	09-06	Communication Operation Command 1	Bit0~1: 00: Disable 01: Stop 10: Start-up 11: JOG start-up Bit2~3: Reserved Bit4~5: 00: No function 01: FWD command 10: REV command 11: Change direction command Bit6~7: 00: 1 st step accel/decel speed 01: 2 nd step accel/decel speed 10: 3 rd step accel/decel speed 11: 4 th step accel/decel speed	00	



	Parameters	Functions	Settings	Factory Setting	Customer
⚡	09-06	Communication Operation Command 1	Bit8~11: 0000: Master speed 0001: 1 st step speed 0010: 2 nd step speed 0011: 3 rd step speed 0100: 4 th step speed 0101: 5 th step speed 0110: 6 th step speed 0111: 7 th step speed 1000: 8 th step speed 1001: 9 th step speed 1010: 10 th step speed 1011: 11 th step speed 1100: 12 th step speed 1101: 13 th step speed 1110: 14 th step speed 1111: 15 th step speed Bit12: Select Bit6~11 function Bit13~15 Reserved	00	
⚡	09-07	Communication Frequency Setting	0~120.00Hz	60.00	
⚡	09-08	Communication Operation Command 2	Bit0: 1: EF ON Bit1: 1: Reset Bit2: 0: BB OFF, 1: BB ON Bit3~15: Reserved	00	
⚡	09-09	Switching between Modbus & BAC net	00: Modbus mode 01: BACnet Master Mode 02: BACnet Slaver Mode	00	
⚡	09-10	BACnet DNET	01~65535	01	
⚡	09-11	BACnet Device Instance	00~65535	00	
⚡	09-12	DCC password	0 ~65535	0	



Group 10 PID Controls

	Parameters	Functions	Settings	Factory Setting	Customer
	10-00	Input Terminal for PID Feedback	00: No function 01: Input via AVI 02: Input via ACI1 03: Input via ACI2 04: Input via External Reference	00	
	10-01	PID Control Detection Signal Reference	0.0~6550.0	1000.0	
	10-02	PID Feedback Control Method	00: Negative feedback control 01: Positive feedback control	00	
	10-03	Proportional Gain (P)	0.0~10.0	1.0	
	10-04	Integral Time (I)	0.00~100.00 Sec	1.00	
	10-05	Differential Time (D)	0.00~1.00 Sec	0.00	
	10-06	Upper Bound for Integral Control	00~200%	100	
	10-07	Primary Low Pass Filter Time	0.0~2.5 Sec	0.0	
	10-08	PID Feedback Signal Range	0.0~6550.0	600.0	
	10-09	PID Feedback Signal Fault Treatment Time	0. 0~3600.0 Sec 0.0: Disable	0.0	
⚡	10-10	PID Feedback Signal Fault Treatment	00: Warn and RAMP stop 01: Warn and COAST stop 02: Warn and keep operating	01	
⚡	10-11	PID Minimum Output Frequency	0: By PID controller 1: By AC drive	01	
⚡	10-12	PID Mode	00: Default PID control 01: Smart PID Control	00	



Group 11 Fan and Pump Control Parameters

	Parameters	Functions	Settings	Factory Setting	Customer
	11-00	V/F Curve Selection	00: Determined by group 01 01: 1.5 power curve 02: 1.7 power curve 03: 2 power curve 04: 3 power curve	00	
	11-01	Circulative Control	00: No function 01: Time circulation (by time) 02: Fixed amount circulation (by PID) 03: Fixed amount control (an AC drive runs with 4 motors) 04: Fixed Time Switch + Fixed Amount Circulation 05: Fixed Time Switch+ Fixed Amount Control	00	
	11-02	Multiple Motors Control	01~08	01	
	11-03	Time Circulation Time Setting	00~65500 Min	00	
	11-04	Motor Switch Delay Time	0.0~3600.0 sec	1.0	
	11-05	Motor Switch Delay Time during Fixed Amount Circulation	0.0~3600.0 sec	10.0	
	11-06	Motor Switch Frequency during Fixed Amount Circulation	0.00 to 120.00 Hz	60.00	
	11-07	Enter Sleep Process Time	0.0~3600.0sec 0.0: Sleep function disable	0.00	
	11-08	Sleep Frequency of Sleep Process	0.00 ~ 11-09 (Wake up Frequency)	0.0	
	11-09	Wake Up Frequency of Sleep Process	0.00 to 120.0Hz	0.0	
	11-10	Treatment of Fixed Amount Circulation Malfunction	00: Turn off all motors 01: Turn off AC drive	00	
	11-11	Stop Frequency of Auxiliary Motor	0.00~120.00Hz	0.00	
	11-12	Setting of Sleep Mode Function	00: Refer to PID Output Command 01: Refer feedback signal	00	
	11-13	Reserved	Reserved	00	
	11-14	Delay Time when Switching Circulating Motors (2)	0.0 ~ 3600.0 sec	1.0	



This page intentionally left blank.



Specifications

Voltage Class		230V Class											
Model Number VFD-__F23_		007	015	022	037	055	075	110	150	185	220	300	370
Max. Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
Max. Applicable Motor Output (HP)		1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50
Output Rating	Rated Output Capacity (KVA)	1.9	2.5	4.2	6.5	9.5	12.5	18.3	24.7	28.6	34.3	45.7	55
	Rated Output Current (A)	5.0	7.0	11	17	25	33	49	65	75	90	120	145
	Maximum Output Voltage (V)	Proportional to Input Voltage											
	Rated Frequency (Hz)	0.10-120.00Hz											
Input Rating	Carrier Frequency (kHz)	4-10						3-9			2-6		
	Rated Input Current (A)	5.7	7.6	15.5	20.6	26	34	50	60	75	90	110	142
	Rated Voltage	3-phase 180-264 V											
	Frequency Tolerance	47 – 63 Hz											

Voltage Class		460V Class																					
Model Number VFD-__F43__		007	015	022	037	055	075	110	150	185	220	300	370	450	550	750	900	1100	1320	1600	1850	2200	
Max. Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	160	185	220	
Max. Applicable Motor Output (HP)		1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40	50	60	75	100	125	150	175	215	250	300	
Output Rating	Rated Output Capacity (KVA)	2.3	3.2	4.2	6.5	10	14	18	25	29	34	46	56	69	84	114	137	168	198	236	281	350	
	Rated Output Current (A)	2.7	4.2	5.5	8.5	13	18	24	32	38	45	60	73	91	110	150	180	220	260	310	370	460	
	Maximum Output Voltage (V)	Proportional to Input Voltage																					
	Rated Frequency (Hz)	0.10-120.00Hz																					
Input Rating	Carrier Frequency (kHz)	4-10						3-9						2-6									
	Rated Input Current (A)	3.2	4.3	5.9	11.2	14	19	25	32	39	49	60	73	91	120	160	160	200	240	300	380	400	
	Rated Voltage	3-phase 342-528 V																					
	Frequency Tolerance	47 – 63 Hz																					

General Specifications

Control Characteristics	Control System	SPWM (Sinusoidal Pulse Width Modulation, carrier frequency 2-10kHz)	
	Output Frequency Resolution	0.01Hz	
	Torque Characteristics	Including the auto-torque, auto-slip compensation; starting torque can be 150% at 1.0Hz	
	Overload Endurance	120% of rated current for 1 minute	
	Accel/Decel Time	1-36000/0.1-3600.0/0.01-360.00 seconds (3 Independent settings for Accel/Decel Time)	
Operating Characteristics	V/f Pattern	Adjustable V/f pattern	
	Stall Prevention Level	20 to 150%, Setting of Rated Current	
	Frequency Setting	Keypad	Setting by  
		External Signal	1 set of AVI analog voltage DC0-+10V/0-+5V; 2 sets of ACI analog current 0/4-20mA, 15 Multi-Function Inputs, RS-485 interface (MODBUS), External terminals UP/DOWN Key
	Operation Setting Signal	Keypad	Set by RUN, STOP and JOG
		External Signal	Operation by FWD, REV, JOG and communication operation
	Multi-Function Input Signal	Multi-step selection 0 to 15, Jog, accel/decel inhibit, first to forth accel/decel switches, counter, external Base Block (NC, NO), JOG, auxiliary motor start/maintenance	
	Multi-Function Output Indication	AC Drive Operating, Frequency Attained, Desired Frequency Attained, Zero speed, Base Block, Fault Indication, Local/Remote indication, and Auxiliary Motor Output	
	Analog Output Signal	2 sets of Analog frequency/current signal output	



Other Functions		AVR, 2 kinds of S-Curve, Over-Voltage, Over-Current Stall Prevention, Fault Records, Reverse inhibition, DC Brake, Momentary Power Loss restart, Auto torque and slip compensation, PID Control, Parameter Lock/Reset, Frequency Limits, Adjustable Carrier Frequency, 4 sets of Fan & Pump Control,
Protection		Self-testing, Over Voltage, Over Current, Under Voltage, Overload, Overheating, External Fault, Electronic thermal, Ground Fault, Phase-loss
Built-in Reactor		DC Reactor: 25~215HP AC Reactor: 250~300HP
Built-in Brake Chopper		1~20HP
Cooling Methods		Forced Fan-cooled
Environment	Installation Location	Altitude 1,000 m or lower, keep from corrosive gasses, liquid and dust
	Pollution Degree	2
	Ambient Temperature	-10°C to 40°C Non-Condensing and not frozen
	Storage/ Transportation Temperature	-20°C to 60°C
	Ambient Humidity	Below 90% RH (non-condensing)
Vibration		9.80665m/s ² (1G) less than 20Hz, 5.88m/s ² (0.6G) at 20 to 50Hz



ACCESSORIES

B.1 All Brake Resistors & Brake Units Used in AC Motor Drives

Note: Please only use DELTA resistors and recommended values. Other resistors and values will void Delta's warranty. Please contact your nearest Delta representative for use of special resistors. For instance, in 460 V series, 100 HP, AC drive has 2 brake units with total of 16 brake resistors, so each brake unit uses 8 brake resistors. There should be at least 10 cm away from AC drive to avoid possible noise. Refer to the "Brake Unit Module User Manual" for further detail.

Voltage	Applicable Motor		★ Full Load Torque KG-M	Equivalent Resistors Specification for Each AC Drive	Brake Unit Model VFDB No. of Unit Used		Brake Resistors Model No. of Units Used		Brake Torque 10%ED%	Equivalent Minimum Resistor Value for Each AC Drive
	HP	KW								
230V series	1	0.75	0.427	80W 200 Ω			BR080W200	1	125	80 Ω
	2	1.5	0.849	300W 100 Ω			BR300W100	1	125	55 Ω
	3	2.2	1.262	300W 70 Ω			BR300W070	1	125	35 Ω
	5	3.7	2.080	400W 40 Ω			BR400W040	1	125	25 Ω
	7.5	5.5	3.111	500W 30 Ω			BR500W030	1	125	16 Ω
	10	7.5	4.148	1000W 20 Ω			BR1K0W020	1	125	12 Ω
	15	11	6.186	2400W 13.6 Ω			BR1K2W6P8	2	125	13.6 Ω
	20	15	8.248	3000W 10 Ω	2015	1	BR1K5W005	2	125	10 Ω
	25	18.5	10.281	4800W 8 Ω	2022	1	BR1K2W008	4	125	8 Ω
	30	22	12.338	4800W 6.8 Ω	2022	1	BR1K2W6P8	4	125	6.8 Ω
	40	30	16.497	6000W 5 Ω	2015	2	BR1K5W005	4	125	5 Ω
	50	37	20.6	9600W 4 Ω	2015	2	BR1K2W008	8	125	4 Ω
460V Series	1	0.75	0.427	80W 750 Ω			BR080W750	1	125	160 Ω
	2	1.5	0.849	300W 400 Ω			BR300W400	1	125	160 Ω
	3	2.2	1.262	300W 250 Ω			BR300W250	1	125	160 Ω
	5	3.7	2.080	400W 150 Ω			BR400W150	1	125	130 Ω
	7.5	5.5	3.111	500W 100 Ω			BR500W100	1	125	60 Ω
	10	7.5	4.148	1000W 75 Ω			BR1K0W075	1	125	45 Ω
	15	11	6.186	1000W 50 Ω			BR1K0W050	1	125	50 Ω
	20	15	8.248	1500W 40 Ω			BR1K5W040	1	125	40 Ω
	25	18.5	10.281	4800W 32 Ω	4030	1	BR1K2W008	4	125	32 Ω
	30	22	12.338	4800W 27.2 Ω	4030	1	BR1K2W6P8	4	125	27.2 Ω
	40	30	16.497	6000W 20 Ω	4030	1	BR1K5W005	4	125	20 Ω
	50	37	20.6	9600W 16 Ω	4045	1	BR1K2W008	8	125	16 Ω
	60	45	24.745	9600W 13.6 Ω	4045	1	BR1K2W6P8	8	125	13.6 Ω
	75	55	31.11	12000W 10 Ω	4030	2	BR1K5W005	8	125	10 Ω
	100	75	42.7	19200W 6.8 Ω	4045	2	BR1K2W6P8	16	125	6.8 Ω
	120	90	52.5	13500W 5 Ω	4132	1	BR1K5W005	9	120	5 Ω
	150	110	61	21600W 4 Ω	4132	1	BR1K2W008	18	120	4 Ω
	175	132	73.5	21600W 4 Ω	4132	1	BR1K2W008	18	100	4 Ω
	215	160	89	21600W 3.4 Ω	4132	1	BR1K2W6P8	18	97	3.4 Ω
	250	185	103	27000W 2.5 Ω	4132	2	BR1K5W005	18	115	2.5 Ω
	300	220	122.5	27000W 2.5 Ω	4132	2	BR1K5W005	18	96	2.5 Ω

★: Standard 4-pole motor




NOTE

1. Please select the brake unit and/or brake resistor according to the table. "-" means no Delta product. Please use the brake unit according to the Equivalent Resistor Value.
2. If damage to the drive or other equipment is due to the fact that the brake resistors and the brake modules in use are not provided by Delta, the warranty will be void.
3. Take into consideration the safety of the environment when installing the brake resistors.
4. If the minimum resistance value is to be utilized, consult local dealers for the calculation of the power in Watt.
5. Please select thermal relay trip contact to prevent resistor over load. Use the contact to switch power off to the AC motor drive!
6. When using more than 2 brake units, equivalent resistor value of parallel brake unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the right-most column in the table).
7. Please read the wiring information in the user manual of the brake unit thoroughly prior to installation and operation.
8. In applications with brake resistor or brake unit, Pr.06-00 (Over-voltage stall prevention) must be disabled. And Pr.08-18 (AVR function) shall not be used.


9. Definition for Brake Usage ED%

Explanation: The definition of the brake usage ED(%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Suggest cycle time is one minute.



10. For safety reasons, install a thermal overload relay between brake unit and brake resistor.

Together with the magnetic contactor (MC) in the mains supply circuit to the drive it offers protection in case of any malfunctioning. The purpose of installing the thermal overload relay is to protect the brake resistor against damage due to frequent braking or in case the brake unit is continuously on due to unusual high input voltage. Under these circumstances the thermal overload relay switches off the power to the drive. Never let the thermal overload relay switch off only the brake resistor as this will cause serious damage to the AC Motor Drive.



Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of brake unit.


Note2: **Do NOT** wire terminal -(N) to the neutral point of power system.



B.1.1 Dimensions and Weights for Brake Resistors

(Dimensions are in millimeter)

Order P/N: BR080W200, BR080W750, BR300W070, BR300W100, BR300W250, BR300W400, BR400W150, BR400W040




TYPE	L1	L2	H	D	W	MAX. WEIGHT(g)
BR080W200	140	125	20	5.3	60	160
BR080W750	140	125	20	5.3	60	160
BR300W070	215	200	30	5.3	60	750
BR300W100	215	200	30	5.3	60	750
BR300W250	215	200	30	5.3	60	750
BR300W400	215	200	30	5.3	60	750
BR400W150	265	250	30	5.3	60	930
BR400W040	265	250	30	5.3	60	930

B




Order P/N: BR500W030, BR500W100, BR1K0W020, BR1K0W075



TYPE	L1	L2	H	D	W	MAX. WEIGHT(g)
BR500W030	335	320	30	5.3	60	1100
BR500W100	335	320	30	5.3	60	1100
BR1K0W020	400	385	50	5.3	100	2800
BR1K0W075	400	385	50	5.3	100	2800

Order P/N: BR1K0W050, BR1K2W008, BR1K2W6P8, BR1K5W005, BR1K5W040





B.1.2 Specifications for Brake Unit

Voltage Class		230V Series		460V Series		
Model Number VFDB-□□□□		2015	2022	4030	4045	4132
Max. Motor Power (kW)		15	22	30	45	132
Output Rating	Max. Peak Discharge Current (A) 10%ED	40	60	40	60	240
	Continuous Discharge Current (A)	15	20	15	18	75
	Brake Start-up Voltage (DC)	330/345/360/380/400/415 ±3V		660/690/720/760/800/830 ±6V		618/642/667/690/725/750±6V
Input Rating	DC Voltage	200~400VDC		400~800VDC		480~750VDC
Protection	Heat Sink Overheat	Temperature over +95℃ (203 °F)				
	Alarm Output	RELAY contact 5A120Vac/28Vdc(RA, RB, RC)				
	Power Charge Display	Blackout until bus (+~-) voltage is below 50VDC				
Environment	Installation Location	Indoor (no corrosive gases, metallic dust)				
	Operating Temperature	-10℃ ~ +50℃				
	Storage Temperature	-20℃ ~ +60℃				
	Humidity	90% Non-condensing				
	Vibration	9.8m/S²(1G) under 20Hz 2m/S²(0.2G) at 20 ~ 50Hz				
Wall-mounted Enclosed Type		IP50				IP10



B.1.3 Dimensions for Brake Unit

(Dimensions are in millimeter[inch])

Figure 1: VFDB2015, VFDB2022, VFDB4030, VFDB4045





**Figure 2: VFDB4132****B**



B.2 AMD-EMI Filter Cross Reference

AC Drives	EMI Model Number
VFD007F23A/H, VFD015F23A/H, VFD022F23A/H, VFD037F23A/H	26TDT1W4C
VFD110F23A/H, VFD055F23A/H, VFD075F23A/H, VFD185F43A/H	50TDS4W4C
VFD150F23A/H, VFD220F43A/H, VFD300F43A/H, VFD370F43A/H	100TDS84C
VFD220F23A/H, VFD185F23A/H, VFD300F23A/H, VFD450F43A/H	150TDS84C
VFD370F23A/H, VFD550F43A/H	180TDS84C
VFD750F43A/H	200TDDS84C

Installation

All electrical equipment, including AC motor drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when AC motor drive and EMI filter are installed and wired according to user manual:

- EN61000-6-4
- EN61800-3: 1996 + A11: 2000
- EN55011 (1991) Class A Group 1 (1st Environment, restricted distribution)

General precaution



1. EMI filter and AC motor drive should be installed on the same metal plate.
2. Please install AC motor drive on footprint EMI filter or install EMI filter as close as possible to the AC motor drive.
3. Please wire as short as possible.
4. Metal plate should be grounded.
5. The cover of EMI filter and AC motor drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

Choose suitable motor cable and precautions


Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.

1. Use the cable with shielding (double shielding is the best).
2. The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
3. Remove any paint on metal saddle for good ground contact with the plate and shielding.

Remove any paint on metal saddle for good ground contact with the plate and shielding.



Saddle on both ends



Saddle on one end



B.3 AC Reactor

AC Input Reactor Recommended Value

460V, 50/60Hz, 3-Phase

KW	HP	Fundamental Amps	Max. Continuous Amps	Inductance (mh)	
				3% impedance	5% impedance
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
3.7	5	8	12	3	5
5.5	7.5	12	18	2.5	4.2
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	35	52.5	0.8	1.2
22	30	45	67.5	0.7	1.2
30	40	55	82.5	0.5	0.85
37	50	80	120	0.4	0.7
45	60	80	120	0.4	0.7
55	75	100	150	0.3	0.45
75	100	130	195	0.2	0.3
90	125	160	240	0.15	0.23
110	150	200	300	0.11	0.185
132	175	250	375	0.09	0.15
160	215	320	480	0.075	0.125
185	250	400	560	0.06	0.105
220	300	500	700	0.05	0.085

460V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
	0.75	1	4	25.00
	1.5	2	9	11.50
	2.2	3	9	11.50
	3.7	5	12	6.00
	5.5	7.5	18	3.75
	7.5	10	25	4.00
	11	15	32	2.68
	15	20	50	2.00



NOTE

18.5kW~132kW models: built-in DC choke

160kW~220kW models: built-in AC reactor



AC Output Reactor Recommended Value

230V, 50/60Hz, 3-Phase

kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
0.75	1	8	12	3	5
1.5	2	8	12	1.5	3
2.2	3	12	18	1.25	2.5
3.7	5	18	27	0.8	1.5
5.5	7.5	25	37.5	0.5	1.2
7.5	10	35	52.5	0.4	0.8
11	15	55	82.5	0.25	0.5
15	20	80	120	0.2	0.4
18.5	25	80	120	0.2	0.4
22	30	100	150	0.15	0.3
30	40	130	195	0.1	0.2
37	50	160	240	0.075	0.15

460V, 50/60Hz, 3-Phase

kW	HP	Fundamental Amps	Max. continuous Amps	Inductance (mH)	
				3% impedance	5% impedance
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
3.7	5	12	18	2.5	4.2
5.5	7.5	18	27	1.5	2.5
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	45	67.5	0.7	1.2
22	30	45	67.5	0.7	1.2
30	40	80	120	0.4	0.7
37	50	80	120	0.4	0.7
45	60	100	150	0.3	0.45
55	75	130	195	0.2	0.3
75	100	160	240	0.15	0.23
90	125	160	240	0.15	0.23
110	150	200	300	0.11	0.185
185	250	320	480	0.075	0.125
220	300	400	600	0.06	0.105

B



B.4 Non-fuse Circuit Breaker Chart

The fuse should comply with UL248 and the breaker should comply with UL489.

The current rating of the breaker shall be within 2~4 times maximum input current rating.

Model	3-phase
	Recommended non-fuse breaker (A)
VFD007F23A	10
VFD007F43A/H	5
VFD015F23A	15
VFD015F43A/H	10
VFD022F23A	30
VFD022F43A/H	15
VFD037F23A	40
VFD037F43A/H	20
VFD055F23A	50
VFD055F43B/H	30
VFD075F23A	60
VFD075F43B/H	40
VFD110F23A	100
VFD110F43A/H	50
VFD150F23A	125
VFD150F43A/H	60
VFD185F23A	150
VFD185F43A/H	75
VFD220F23A	175
VFD220F43A/H	100
VFD300F23A	225
VFD300F43A/H	125
VFD370F23A	250
VFD370F43A/H	150
VFD450F43A/H	175
VFD550F43A/H	250
VFD750F43A/H	300
VFD900F43C/H	300
VFD1100F43C/H	400
VFD1320F43A/H	500
VFD1600F43A/H	600
VFD1850F43A/H	600
VFD2200F43A/H	800



B.5 Fuse Specification Chart

Smaller fuses than those shown in the table are permitted.


Model	I (A) Input	I (A) Output	Line Fuse	
			I (A)	Bussmann P/N
VFD007F23A	5.7	5.0	10	JJN-10
VFD007F43A/H	3.2	2.7	5	JJS-6
VFD015F23A	7.6	7.0	15	JJN-15
VFD015F43A/H	4.3	4.2	10	JJS-10
VFD022F23A	15.5	11	30	JJN-30
VFD022F43A/H	5.9	5.5	15	JJS-15
VFD037F23A	20.6	17	40	JJN-40
VFD037F43A/H	11.2	8.5	20	JJS-20
VFD055F23A	26	25	50	JJN-50
VFD055F43B/H	14	13	30	JJS-30
VFD075F23A	34	33	60	JJN-60
VFD075F43B/H	19	18	40	JJS-40
VFD110F23A	50	49	100	JJN-100
VFD110F43A/H	25	24	50	JJS-50
VFD150F23A	60	65	125	JJN-125
VFD150F43A/H	32	32	60	JJS-60
VFD185F23A	75	75	150	JJN-150
VFD185F43A/H	39	38	75	JJS-70
VFD220F23A	90	90	175	JJN-175
VFD220F43A/H	49	45	100	JJS-100
VFD300F23A	110	120	225	JJN-225
VFD300F43A/H	60	60	125	JJS-125
VFD370F23A	142	145	250	JJN-250
VFD370F43A/H	63	73	150	JJS-150
VFD450F43A/H	90	91	175	JJS-175
VFD550F43A/H	130	110	250	JJS-250
VFD750F43A/H	160	150	300	JJS-300
VFD900F43C/H	160	180	300	JJS-300
VFD1100F43C/H	200	220	400	JJS-400
VFD1320F43A/H	240	260	500	JJS-500
VFD1600F43A/H	300	310	600	JJS-600
VFD1850F43A/H	380	370	600	JJS-600
VFD2200F43A/H	400	460	800	JJS-800

B



B.6 PU06

B.6.1 Description of the Digital Keypad VFD-PU06




B.6.2 Explanation of Display Message

Display Message	Descriptions
	The AC motor drive Master Frequency Command.
	The Actual Operation Frequency present at terminals U, V, and W.
	The custom unit (u)
	The output current present at terminals U, V, and W.
	Press to change the mode to READ. Press PROG/DATA for about 2 sec or until it's flashing, read the parameters of AC drive to the digital keypad PU06. It can read 4 groups of parameters to PU06. (read 0 – read 3)
	Press to change the mode to SAVE. Press PROG/DATA for about 2 sec or until it's flashing, then write the parameters from the digital keypad PU06 to AC drive. If it has saved, it will show the type of AC motor drive.



Display Message	Descriptions
	The specified parameter setting.
	The actual value stored in the specified parameter.
	External Fault
	"End" displays for approximately 1 second if the entered input data have been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the or keys.
	"Err" displays if the input is invalid.
	Communication Error. Please check the AC motor drive user manual (Chapter 5, Group 9 Communication Parameter) for more details.

B.6.3 PU06 Operation Flow Chart








B.7 Relay Card

Specifications:

1. Screw Length (between RELAY CARD and Control Board): 8mm or less.
2. Torque Rating: 3~4 kgf-cm or less.
3. Wire Gauge: 16~26 AWG.
4. Maximum Voltage/Current of each contact: Max. 250VAC/2A
5. Maximum Momentary Voltage/Current of each contact:
Max. 350VAC/8A, transient time is 10m sec
6. Close/Restoring Time of each contact: Typical 5/1 ms
7. Ambient Temperature: -10°C to 40°C (non-condensing and not frozen)
8. Ambient Humidity: less than 90%RH (not frozen)
9. Environment:
 - Installation Altitude: below 1000m
 - Always use this product in a clean indoor location free from dust, corrosive gases and liquid.
10. Vibration:
 - Maximum 9.80665 m/s² (1G) at less than 20 Hz
 - Maximum 5.88 m/s² (0.6G) at 20Hz to 50Hz

Notes:


1. Please put RC network or Varistor on the side of coil to prevent sparks when connect the inductance loading device, i.e. relay, magnetic contactor, motor...etc.
2. It is recommended to put the fuses into the circuit if having safety concern when using this product. (The specification of used fuses must be within the limit of contact.)
3. Please use the isolated wires as much as possible to avoid interferences. (The isolated layer must be grounded to the earth.)
4. The ends of wires must be plated with tin or connected with terminals.
5. For the safety concern, route the Relay Card wires separately and far away from other control wires, motor wires and power wires...etc. at least 15cm. Where these wires must cross to each other please make sure they are at a 90 degree angle.
6. Always use and operate this product within the limit of its specifications.
7. For other operation notes, please refer to the user's manuals of AC motor drive.

**B**



B.8 Zero Phase Reactor (RF220X00A)

Dimensions are in millimeter and (inch)



Cable type (Note)	Recommended Wire Size (mm ²)			Qty.	Wiring Method
	AWG	mm ²	Nominal (mm ²)		
Single-core	≤ 10	≤ 5.3	≤ 5.5	1	Diagram A
	≤ 2	≤ 33.6	≤ 38	4	Diagram B
Three-core	≤ 12	≤ 3.3	≤ 3.5	1	Diagram A
	≤ 1	≤ 42.4	≤ 50	4	Diagram B

Note: 600V Insulated unshielded Cable.

Diagram A

Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.





Diagram B

Please put all wires through 4 cores in series without winding.



Note 1: The table above gives approximate wire size for the zero phase reactors, but the selection is ultimately governed by the type and diameter of cable fitted, i.e. the cable must fit through the center hole of zero phase reactors.


Note 2: Only the phase conductors should pass through, not the earth core or screen.

Note 3: When long motor output cables are used, an output zero phase reactor may be required to reduce radiated emissions from the cable.



DIMENSIONS

Frame B



UNIT: mm [inch]


Frame	W	W1	H	H1	D	D1	S1	S2
B1	150.0 [5.91]	135.0 [5.32]	260.0 [10.24]	244.3 [9.63]	160.2 [6.31]	4.0 [0.16]	8.0 [0.32]	6.5 [0.26]



Frame B(B1): VFD007F23A; VFD007F43A; VFD007F43H; VFD015F23A; VFD015F43A; VFD015F43H; VFD022F23A;
VFD022F43A; VFD022F43H; VFD037F23A; VFD037F43A; VFD037F43H



Frame C




UNIT: mm [inch]

Frame	W	W1	H	H1	D	D1	D2	S1	S2
C1	200.0 [7.88]	185.6 [7.31]	323.0 [12.72]	303.0 [11.96]	183.2 [7.22]	76.5 [3.01]	3.0 [0.12]	7.0 [0.28]	7.0 [0.28]



Frame C(C1): VFD055F23A; VFD055F43B; VFD055F43H; VFD075F23A; VFD075F43B; VFD075F43H; VFD110F23A;
VFD110F43A; VFD110F43H; VFD150F43A; VFD150F43H

**Frame D**

UNIT: mm [inch]


Frame	W	W1	H	H1	D	D1	D2	S1
D1	250.0 [9.84]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	205.4 [8.08]	110.0 [4.33]	8.0 [0.31]	10.0 [0.39]



Frame D(D1): VFD150F23A; VFD185F23A; VFD185F43A; VFD185F43H; VFD220F23A; VFD220F43A; VFD220F43H;
VFD300F43A; VFD300F43H



Frame E



UNIT: mm [inch]


Frame	W	W1	H	H1	H2	D	D1	D2	S1	S2	S3
E1	370.0 [14.57]	335.0 [13.19]	-	589.0 [23.19]	560.0 [22.05]	260.0 [10.24]	132.5 [5.22]	18.0 [0.71]	13.0 [0.51]	13.0 [0.51]	18.0 [0.71]
E2	370.0 [14.57]	335.0 [13.19]	595.0 [23.43]	589.0 [23.19]	560.0 [22.05]	260.0 [10.24]	132.5 [5.22]	18.0 [0.71]	13.0 [0.51]	13.0 [0.51]	18.0 [0.71]



NOTE

Frame E(E1): VFD300F23A; VFD370F23A; VFD750F43A; VFD750F43H; VFD900F43C; VFD900F43H

Frame E(E2): VFD370F43A; VFD370F43H; VFD450F43A; VFD450F43H; VFD550F43A; VFD550F43H

**Frame G**

UNIT: mm [inch]


Frame	W	W1	H	H1	H2	D	D1	D2	S1	S2	S3	S4
G1	425.0 [16.73]	381.0 [15.00]	850.0 [33.46]	819.5 [32.26]	746.0 [30.08]	264.0 [10.39]	19.0 [0.75]	18.0 [0.71]	13.0 [0.51]	13.0 [0.51]	20.00 [0.79]	18.0 [0.71]



Frame G(G1): VFD1100F43C; VFD1100F43H; VFD1320F43A; VFD1320F43H; VFD1600F43A; VFD1600F43H



Frame H




UNIT: mm [inch]

Frame	W	W1	H	H1	H2	H3	D	D1	S1	S2	S3
H1	547.0 [21.54]	480.0 [18.90]	1357.6 [53.45]	1150.0 [45.28]	1119.0 [44.06]	1072.6 [42.23]	360.0 [14.17]	20.00 [0.79]	13.0 [0.51]	13.0 [0.51]	20.00 [0.79]



Frame H(H1): VFD1850F43A; VFD1850F43H; VFD2200F43A; VFD2200F43H

**VFD-PU01****Unit: mm (inches)****C**

**KPF-CC01****Unit: mm (inches)**