



Military & Professional

Survival Egress Air (SEA MK / LV2)



TECHNICAL MANUAL

COPYRIGHT NOTICE

This manual is copyrighted, all rights reserved. It may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable format without prior consent in writing from Aqua Lung America. It may not be distributed through the internet or computer bulletin board systems without prior consent in writing from Aqua Lung America.

**©2017 AQUA LUNG AMERICA.
SEA MK / LV2 TECHNICAL MANUAL, PN 108348**

You can contact a Technical Adviser via e-mail at:

sreilly@aqualung.com
jbutner@aqualung.com
grubin@aqualung.com

Trademark Notice

Aqua Lung® is a registered trademark of Aqua Lung America, Inc.

Warnings, Cautions, & Notes

Pay special attention to information provided in warnings, cautions and notes that are accompanied by one of these symbols:



A **WARNING** indicates a procedure or situation that, if not avoided, could result in serious injury or death to the user.



A **CAUTION** indicates any situation or technique that could cause damage to the product and could subsequently result in injury to the user.



A **NOTE** is used to emphasize important points, tips and reminders.

CONTENTS

Introduction	4
Disassembly Procedure.....	5
First Stage Disassembly.....	5
Second Stage (MK) Disassembly.....	8
Second Stage (LV2) Disassembly	9
Valve Body Disassembly	10
Reassembly Procedure.....	10
First Stage Reassembly	10
First Stage Testing	14
Valve Body Reassembly.....	15
Second Stage (MK) Reassembly	16
Second Stage (LV2) Reassembly.....	17
Final Testing.....	19
Table 1: Troubleshooting Guide First Stage.....	20
Table 2: Troubleshooting Guide Second Stage	21
Table 3: List of Tools and Service Kits	22
Table 4: Torque Specifications	25
Table 5: Test Bench Specifications	25
Table 6: Recommended Cleaners and Lubricants	25
Procedure A: Cleaning and Lubricating.....	26
SEA First Stage Exploded View	27
MK Second Stage Exploded View.....	28
LV2 Second Stage Exploded View	29
Maintenance Notes	30

Introduction

This manual provides factory prescribed procedures for the correct service and repair of this Aqua Lung product. It is not intended to be used as an instructional manual for untrained personnel. The procedures outlined in this manual are to be performed only by personnel who have received Factory Authorized training through an Aqua Lung Service & Repair Seminar. If you do not completely understand all of the procedures outlined in this manual, contact Aqua Lung to speak directly with a Technical Advisor before proceeding any further.

Scheduled Service

This product should be given the same care and maintenance as life support equipment. It is therefore important to perform scheduled overhaul service for the complete unit, according to the procedures outlined in this manual on a regularly scheduled basis; **once every two years** with normal use.

General Guidelines

1. In order to correctly perform the procedures outlined in this manual, it is important to follow each step exactly in the order given. Read over the entire manual to become familiar with all procedures before attempting to disassemble the product in this manual and to learn which specialty tools and replacement parts will be required. Keep the manual open beside you for reference while performing each procedure. Do not rely on memory.

2. All service and repair should be carried out in a work area specifically set up and equipped for the task. Adequate lighting, cleanliness and easy access to all required tools are essential for an efficient repair facility.

3. As each unit is disassembled, reusable components should be segregated and not allowed to intermix with non-reusable parts or parts from other units. Delicate parts, including inlet fittings and crowns which contain critical seating surfaces, must be protected and isolated from other parts to prevent damage during the cleaning procedure.

4. Use only genuine Aqua Lung ® parts provided in the overhaul parts kit for this product. DO NOT attempt to substitute an Aqua Lung ® part with another manufacturer's, regardless of any similarity in shape or size.

5. Do not attempt to reuse mandatory replacement parts under any circumstances, regardless of the amount of use the product has received since it was manufactured or last serviced.

6. When reassembling, it is important to follow every torque specification prescribed in this manual, using a calibrated torque wrench. Most parts are made of aluminum, marine brass or plastic and can be permanently damaged by excessive stress.

General Conventions

Unless otherwise instructed, the following terminology and techniques are assumed:

1. When instructed to **remove**, **unscrew** or **loosen** a threaded part, turn the part counter-clockwise.

When instructed to **install**, **screw** or **tighten** a threaded part, turn the part clockwise.

2. When instructed to **"OPEN"** the handwheel, turn the handwheel counter-clockwise. The **red indicator ring will not be visible** in the handwheel window, this indicates the unit is in the **"ON"** position.

When instructed to **"CLOSE"** the handwheel, turn the handwheel clockwise. The **red indicator ring will be visible** in the handwheel window, this indicates the unit is in the **"OFF"** position.

3. The method used to depressurize your system will depend on its configuration:

- SEA w/ handwheel: Depress second stage purge button for 5 seconds and release for 5 seconds. Repeat this procedure until the system is depressurize.
- SEA w/o handwheel: Breathe the unit down by taking 5 breaths from the second stage and pause for 5 seconds. Repeat this procedure until the system is depressurized.

4. When instructed to fill or refill the cylinder, 3000 PSI (207 BAR) will be the standard fill pressure used for testing purposes in this manual. Upon completion of all testing, fill the cylinder to its full capacity as marked. (**Reference the Filling Procedures section of the User's Manual**).


5. The following acronyms are used throughout the manual: **LP** is Low Pressure; **MP** is Medium Pressure; and **HP** is High Pressure.

6. Numbers in parentheses reference the key numbers on the exploded parts schematics. **For example**, in the statement, "... remove the o-ring (7) from the crown (8) "...the number 7 is the key number to the crown o-ring.

7. When instructed to remove an o-ring, use the pinch method (see illustration below) or use a brass or plastic o-ring removal tool. Avoid using hardened steel picks (unless directed), as they may damage the o-ring sealing surface. All o-rings that are removed are discarded and replaced with brand new o-rings.

Pinch Method

Press upwards on sides of o-ring to create a protrusion. Grab o-ring or insert o-ring tool at protrusion.



DISASSEMBLY PROCEDURE



NOTE: Before performing any disassembly, refer to the exploded parts drawing, which references all mandatory replacement parts. These parts should be replaced with new service kit parts. Old parts should not be reused under any circumstances, regardless of the regulator age or how much use it has received since it was last used.



CAUTION: Use only brass o-ring removal tools (PN 944022) when removing o-rings to prevent damaging critical sealing surfaces. Even a small scratch across an o-ring sealing surface could result in leakage. Once an o-ring sealing surface has been damaged, the part must be replaced with new. **DO NOT** use a dental pick or any other steel instrument, except where instructed.



NOTE: Certain components are available in a black or chrome finish. Components in either finish are interchangeable.



Black



Chrome

First Stage Disassembly

1. Open the handwheel (18) and depressurize the system. Ensure the cylinder (43) is completely empty and it contains no air.



2. Hold the second stage inlet fitting (51) with a 3/4" thin wrench and use a 11/16" crow foot and flex wrench to unscrew the hose (11) from the inlet fitting.



3. Remove o-ring (25) from the hose swivel on the MP hose (11) using the stainless steel o-ring tool (PN 10-102-400).



4. Using a 3/16" hex bit socket and flex wrench, unscrew the swivel port plug (14) from the first stage body (8). Separate the swivel port plug, MP hose (11) and spacer (10). Remove o-rings (12 & 13) from the swivel port plug.



5. Remove the safety plug (9) from the first stage body (8) using a 3/8" socket and flex wrench.



Disassembly of Blank Plug




NOTE: SEA units will either have a blank plug or On / Off handwheel assembly. Identify which type the SEA being serviced utilizes and follow the instructions accordingly.

6. Use a 3/16" hex bit socket and flex wrench to remove the blank plug (22) from the first stage body (8). Remove o-ring (23) from the blank plug.



Disassembly of Handwheel

7. Unscrew the handwheel retainer (15) using the modified screwdriver. Remove the handwheel washer (16), spring (17) handwheel (18), nylon washer (19) and indicator ring (20) from the stem (28).




8. Using the 3/4" socket and flex wrench, unscrew the bonnet (21) from the first stage body (8). Pull the stem assembly out of the bonnet.



9. Remove the back-up ring (24), o-ring (25), brass washer (26) and Teflon washer (27) from the stem (28).

NOTE: It is possible that some or all of these parts have remained in the bonnet (21).




10. Remove the o-ring (23) from the bonnet (21).



11. Insert the squared end of the stem (28) into the seat & disc retainer (29) and unscrew it from the first stage body (8).



12. Using a magnifier, inspect the condition of the seat & disc retainer crown inside the first stage body (8). There should be no scratches, nicks or dents on the crown seating surface.



Disassembly of Dial Pressure Gauge

NOTE: SEA units will either have a dial pressure gauge (36) or pin style pressure gauge (37). Identify which type the SEA being serviced utilizes and follow the instructions accordingly.

13. Remove the pressure gauge (36) using a 7/8" crowfoot and flex wrench. Remove o-ring (32) from the pressure gauge.

CAUTION: Be careful not to damage the fill port (33) with the wrench while removing the pressure gauge (36).



Disassembly of Pin Style Pressure Gauge


14. Use the valve handle retainer tool to remove the pin pressure indicator (37) from the first stage body (8). Remove o-ring (32) from the pressure indicator body (38).



15. Using a 1/8" hex bit socket and flex wrench, unscrew the retainer (42) from the pressure indicator body (38). Remove the plunger (41) and spring (40) from the pressure indicator body.



CAUTION: The pin indicator parts are under spring tension. Use caution during disassembly.



16. Turn the pressure indicator body (38) over to remove the o-ring (34) and washer (39). Use the o-ring tool to extract the components if they remain inside the pressure indicator body.



17. Using your fingers, unscrew the fill port cap (31) from the fill port (33). Remove the o-ring (32) from the fill port cap.




18. Using a 9/16" socket and flex wrench, unscrew the fill port (33) from the first stage body (8). Remove the fill port pin (35) from the fill port.



NOTE: Take care not to lose the fill port pin (35) when removing the fill port (33). It is possible that the fill port pin may have remained inside the fill port during removal.



19. Remove the o-ring (32) from the fill port (33) and o-ring (34) from the fill port pin (35).



20. Using your fingers, peel the retainer cover (1) off the retainer cap (2).




21. Insert the pins on the adjustable spanner wrench into the two holes on top of the retainer cap (2). Unscrew the retainer cap from the first stage body (8).




22. Separate the piston (4) from the retainer cap (2). Remove the spring (7) from the first stage body (8).



23. Using a magnifier, inspect the condition of the HP crown inside the first stage body (8). There should be no scratches, nicks or dents on the crown seating surface.



24. Remove o-rings (3 & 5) from the piston (4). Insert the seat extraction tool into the open end of the piston and push out the HP seat (6).



CAUTION: Ensure that the crowfoot is aligned with the wrench flats on the first stage body (8). Do not position the crowfoot over the bonnet opening as this will cause damage, resulting in replacement of the first stage body.



NOTE: Another option is to use vise jaw inserts (PN 100398) in conjunction with a bench vise to remove the first stage body (8) from the cylinder (43).

25. Secure the strap wrench to the cylinder (43). Using a 1 3/16" crowfoot and flex wrench, unscrew the first stage body (8) from the cylinder. Remove o-ring (30) from the first stage body.



NOTE: Before beginning reassembly, perform parts cleaning and lubrication in accordance with Procedure A: Cleaning and Lubricating.

Second Stage (MK) Disassembly

1. Use diagonal pliers to cut the strap clamp (50) and remove the mouthpiece (49) from the box bottom (54). Inspect the mouthpiece to ensure it is free of any tears or cuts that may cause water leakage into the second stage or discomfort during use. Discard the mouthpiece if damage is found or set it aside for reuse if the condition is acceptable.



2. Using your fingers, unscrew the hard cover (45) or retaining ring and front cover (46 & 44) from the box bottom (54).



3. Lift out the ring cover support (47) and diaphragm (48). Inspect the diaphragm for any tears or pin holes by holding it up to a light and gently stretching around the perimeter. If the condition is acceptable, set it aside for reuse.




4. Using a 3/4" thin wrench, remove the inlet fitting (51) from the box bottom (54).



5. Grasp the lever (60) and remove the valve body assembly from the box bottom (54). It may be necessary to push the valve body assembly through the inlet hole into the box bottom.



 **NOTE:** Set the valve body assembly to the side, disassembly will continue during the **Valve Body Disassembly** section of this manual.

6. The exhaust valve cover (52) is held in place by four tabs: Two short tabs on the top side and two long tabs on the bottom side. To remove the exhaust valve cover press downward on the center rib using your index and middle fingers while simultaneously pulling out on the exhaust valve cover.



7. Remove the exhaust valve (53) by grasping the valve flap and pulling straight out. Remove both valves.



Second Stage (LV2) Disassembly

1. Use diagonal pliers to cut the strap clamp (50) and remove the mouthpiece (70) from the box bottom (69). Inspect the mouthpiece to ensure it is free of any tears or cuts that may cause water leakage into the second stage or discomfort during use. Discard the mouthpiece if damage is found or set it aside for reuse if the condition is acceptable.



2. Using your fingers, unscrew the hard cover (64) from the box bottom (69). Use the retaining ring wrench to unscrew the retaining ring (65) from the box bottom.



3. Lift out the front cover (66) and diaphragm (48). Inspect the diaphragm for any tears or pin holes by holding it up to a light and gently stretching around the perimeter. If the condition is acceptable, set it aside for reuse.




4. Using a 3/4" thin wrench, remove the inlet fitting (51) from the box bottom (69).



5. Grasp the lever (60) and remove the valve body assembly from the box bottom (69). It may be necessary to push the valve body assembly through the inlet hole into the box bottom.



 **NOTE:** Set the valve body assembly to the side, disassembly will continue during the **Valve Body Disassembly** section of this manual.

6. Using your fingers, unscrew the exhaust valve cap (67). Remove the exhaust valve (68) by grasping the valve flap and pulling straight out.



Valve Body Disassembly

1. Remove the o-ring (23) from the inlet fitting (51).



2. Using a 1/4" nut driver, remove the locknut (62) from the poppet (56). Remove the washer (61), lever (60), spring (57) and poppet (56) from the valve body (59).



CAUTION: The valve body assembly is under spring tension, use caution during disassembly.



3. Place the threaded end of the poppet (56) directly over the poppet bearing (58) and press down to dislodge it from the valve body (59).



NOTE: DO NOT discard used MP seat (55), it will be used to aid in the reassembly process.

4. Using the SS o-ring tool (PN 10-102-400) pierce the middle of the MP seat (55) and remove it from the poppet (56).



NOTE: Before beginning reassembly, perform parts cleaning and lubrication in accordance with Procedure A: Cleaning and Lubricating.

REASSEMBLY PROCEDURE



NOTE: Before performing any reassembly, it is important to inspect all parts, both new and those that are being reused, to ensure that every part and component is perfectly clean and free of any dust, corrosion or blemishes. Before dressing each o-ring with Christo-Lube®, check to ensure it is clean, supple and free of any blemishes.



WARNING: Use only genuine Aqua Lung® parts, sub-assemblies and components when ever assembling any Aqua Lung® product. DO NOT attempt to substitute an Aqua Lung® part with another manufacturer's, regardless of any similarity in shape, size or appearance. Doing so may render the product unsafe and could result in serious injury or death.



CAUTION: Before proceeding, visually inspect the cylinder according to Compressed Gas Association (CGA) standards pamphlet (CGA C 6.1: 2013, STANDARD FOR VISUAL INSPECTION OF HIGH PRESSURE ALUMINUM ALLOY COMPRESSED GAS CYLINDERS). This inspection requires a visual inspection light. If the cylinder does not pass the visual inspection, it must be serviced or replaced with a new cylinder before it can be assembled and filled.

First Stage Reassembly

1. Install o-ring (30) over the threads on the first stage body (8). Lubricate the first 4 to 5 threads on the first stage body with Christo-lube®.



CAUTION: Ensure that the crowfoot is aligned with the wrench flats on the first stage body (8). Do not position the crowfoot over the bonnet opening as this will cause damage, resulting in replacement of the first stage body.



NOTE: Another option is to use vise jaw inserts (PN 100398) in conjunction with a bench vise to install the first stage body (8) onto the cylinder (43).

2. Thread the first stage body (8) into the cylinder (43) until hand-tight. Secure the strap wrench to the cylinder. Use a 1 3/16" crowfoot and foot pound torque wrench to apply 25 ft lb (33.9 Nm) of torque to the first stage body.




3. Install o-ring (3) and o-ring (5) onto the piston (4). Closely inspect the edges of new HP seat (6). One edge is sharp and one edge has a bevel. Using your fingers, press the HP seat into the piston with the beveled edge facing out. The HP seat should be flush with the end of the piston. If you are unable to press the HP seat into the piston, place the HP seat on a flat, clean surface (beveled side down) and press the piston shaft down over it.




4. Place the spring (7) into the first stage body (8). Lightly lubricate the threads on the first stage body. Press the piston (4) into the retainer cap (2) so that the piston head is seated flat against the cap.



5. Insert the shaft of the piston (4) into the spring (7). Press down on the retainer cap (2) and tighten the cap onto the first stage body (8) until hand tight. Insert the pins on the adjustable spanner wrench into the two holes on top of the retainer cap and tighten until snug. The retainer cover (1) will be installed after final testing.



6. Install o-ring (34) onto the shaft of the fill port pin (35) and o-ring (32) onto the fill port cap (31). Set the fill port cap to the side, it will be installed after final testing.



7. Install o-ring (32) onto the fill port (33). Insert the fill port pin (35), o-ring side first, into the male-threaded end of the fill port.



8. Install the fill port (33) into the lower HP port on the first stage body (8). Use a 9/16" socket and inch pound torque wrench to apply 90 in lb (10.2 Nm) of torque to the fill port.



CAUTION: To avoid damaging the fill port (33), do not over torque.



Reassembly of Dial Pressure Gauge



NOTE: SEA units will either have a dial pressure gauge (36) or pin style pressure gauge (37). Identify which type the SEA being serviced utilizes and follow the instructions accordingly.

9. Install o-ring (32) onto the pressure gauge (36). Screw the pressure gauge into the upper HP port on the first stage body (8) until hand tight. Use a 7/8" crowfoot and inch pound torque wrench to apply 45 in lb (5 Nm) of torque to the pressure gauge.



CAUTION: Be careful not to damage the fill port (33) with the crowfoot while torquing the pressure gauge (36).



Reassembly of Pin Style Pressure Gauge

10. Insert o-ring (34) into the pressure indicator body (38), making sure it is properly seated in the small recess at the end. Place the washer (39) on top of the o-ring, inside the pressure indicator body.



11. Install the spring (40) into the pressure indicator body (38). Insert the plunger (41) through the center of the spring. Place the retainer (42) on top of the plunger, press down on the retainer and screw it into the pressure indicator body.




12. Using a 1/8" hex bit socket and flex wrench, tighten the retainer (42) into the pressure indicator body (38) until hand tight. Install o-ring (32) onto the threaded end of the pressure indicator body.



13. Screw the pin pressure indicator (37) into the upper HP port on the first stage body (8). Use the valve handle retainer tool to tighten the pin pressure indicator until hand tight.





14. Thread the safety plug (9) into the lower HP port (opposite the fill port) on the first stage body (8). Use a 3/8" socket and inch pound torque wrench to apply 90 in lb (10.2 Nm) of torque to the safety plug.

 **NOTE:** DO NOT apply any type of lubricant to the safety plug assembly (9). This will result in over-torquing of the safety plug.



Reassembly of Blank Plug

 **NOTE:** SEA units will either have a blank plug or On / Off handwheel assembly. Identify which type the SEA being serviced utilizes and follow the instructions accordingly.

 **NOTE:** SEA systems utilizing a blank plug (22) can be converted to use a handwheel by installing the On / Off Valve Conversion Kit (PN 108441).

15. Install o-ring (23) onto the blank plug (22) and thread it into the first stage body (8). Use a 3/16" hex bit socket and inch pound torque wrench to apply 90 in lb (10.2 Nm) of torque to the blank plug.




Reassembly of Handwheel

16. In the following order, place a new Teflon washer (27), brass washer (26), o-ring (25) and back-up ring (24) onto the stem (28).



NOTE: Before continuing, closely examine the back-up ring (24). You will note that it has a flat side and a concave side. For correct assembly, the concave side should be against the o-ring (25), as shown in the picture.



17. Using the squared end of the stem (28), screw the seat disc & retainer (29) into the port on the first stage body (8). Leave the stem in position, place the handwheel (18) over the stem and tighten the seat disc & retainer until finger tight. Remove the handwheel from the stem.

NOTE: DO NOT apply any type of lubricant to the seat & disc retainer (29) prior to installation.



18. Install o-ring (23) onto the bonnet (21) so that the o-ring fits into the groove located above the threads. Lubricate the bonnet threads, then pass the bonnet over the stem and thread it into the first stage body (8) until hand-tight.




19. Use a 3/4" socket and inch pound torque wrench to apply 90 in lb (10.2 Nm) of torque to the bonnet (21).



20. Place the nylon washer (19) over the stem (28), so it sits on top of the bonnet (21). Face the round edge on the indicator ring (20) outward and thread the indicator ring onto the bonnet until it bottoms out.



21. When the indicator ring (20) bottoms out, turn it slightly counter-clockwise so the square corners on the stem (28) shaft are aligned with the square cutouts on the indicator ring. Turn an additional 90° counter-clockwise.



22. Place the handwheel (18) over the indicator ring (20). Place the spring (17) into the handwheel, followed by the washer (16). Using the modified screwdriver, screw the handwheel retainer (15) onto the end of the stem (28) until it will not turn any further.



CAUTION: If resistance is felt while screwing the handwheel retainer (15) onto the stem (28), stop and start over to avoid cross threading.




23. Install o-ring (12) onto the threaded end and o-rings (13) into the grooves on the swivel port plug (14).




24. Pass the threaded end of the swivel port plug (14) through the hose swivel on the MP hose (11) making sure both o-rings (13) are covered by the hose swivel. Insert the spacer (10) onto the swivel port plug and screw it into the upper MP port (opposite the pressure gauge) on the first stage body (8). Use a 3/16" hex bit socket and inch pound torque wrench to apply 60 in lb (6.8 Nm) of torque to the swivel port plug.



 **NOTE:** O-ring (25) for the second stage swivel end of the MP hose (11) is in the second stage overhaul kit PN108343.

25. Install o-ring (25) into the groove on the MP hose (11).



First Stage Testing



WARNING: Compressed air can be highly explosive and is dangerous if misused. Ensure the cylinder valve is opened slowly. Use eye and ear personal protective equipment when performing any tests involving compressed air.

1. Cycle the handwheel (18) several times to ensure the proper function of the indicator ring (20) and seat & disc retainer (29). Close the handwheel when finished.

2. Attach the SCUBA fill adapter to the fill port (33) and **slowly** fill the SEA to 3000 PSI (207 BAR).

3. During the fill process, check for any air leaking from the open end of the MP hose (11). If an air leak is detected, immediately stop the filling process and refer to **Table 1 : Troubleshooting Guide** section of this manual to determine its possible cause. If no leak is detected, finish filling the cylinder and remove the SCUBA fill adapter from the fill port (33).

4. Screw the test gauge onto the MP hose (11) until hand-tight. Open the bleed valve on the test gauge and **slowly** open the handwheel (18). While watching the test gauge, slowly close the bleed valve.



NOTE: Correct MP for the SEA is 135 ± 20 PSI (9.3 ± 1.4 BAR), with an inlet pressure of 3000 PSI (207 BAR).

- If a stable MP has been achieved, note the pressure indicated on the test gauge. Cycle the bleed valve several times and closely monitor the test gauge for several minutes, making sure the MP has remained stable.
- If the MP exceeds 155 PSI (10.7 BAR), quickly open the bleed valve and close the handwheel (18). Refer to **Table 1 : Troubleshooting Guide** section of this manual to determine its possible cause.
- If the MP rises more than 5 PSI (0.35 BAR) in 5-15 seconds after cycling the bleed valve or "creeps", this indicates a HP leak. Refer to **Table 1 : Troubleshooting Guide** section of this manual to determine its possible cause.

5. Close the handwheel (18) and open the bleed valve to depressurize the system. Remove the test gauge from the MP hose (11).

6. Since there is nothing attached to the end of the MP hose (11) and the cylinder (43) is fully charged, set the system in a secure place so that the valve cannot be accidentally opened.

Valve Body Reassembly

1. Install o-ring (23) onto the inlet fitting (51).



2. Place the poppet bearing (58) over the threaded end of the poppet (56) with the square feature facing up. Guide the threaded end of the poppet into the open end of the valve body (59) and out through the square hole in its center. While sighting through the top of the valve body, rotate the poppet as needed to align the square feature of the poppet bearing with the square hole in the valve body. Press the poppet upward to seat the poppet bearing securely in place. When finished, check to ensure that the top of the poppet bearing is flush with the top of the valve body.



3. Stand the inlet fitting (51) vertical on a flat surface with the crown side facing up. Place the previously used MP seat (55) on top of the crown, inside the inlet fitting. Press a new MP seat into the poppet (56) with the smooth side facing out.



4. Stand the poppet (56) on its head inside the inlet fitting (51), on top of the old MP seat (55). Place the spring (57) over the poppet shaft.



NOTE: The LV2 second stage uses a spring (57) that is red in color. The MK second stage uses a spring that is silver in color.



CAUTION: If resistance is felt, immediately stop and unscrew the valve body (59) from the inlet fitting (51) to check the alignment of the poppet shaft (56) and poppet bearing (58). Excessive force and misalignment will result in damage to the poppet bearing, requiring replacement.

5. Hold the inlet fitting (51) secure and lower the valve body (59) down over the poppet shaft (56). Press down on the valve body to compress the spring (57) while threading it onto the inlet fitting. Continue tightening the valve body onto the inlet fitting until it stops.




6. Place the arms of the lever (60) inside the grooves on the valve body (59), straddling the poppet shaft (56). Ensure the curved portion of the lever faces away from the air outlet hole on the valve body. Place the washer (61) onto the poppet shaft.



7. Place the locknut (62), with the flat side facing down onto the poppet shaft (56). Being careful to avoid disturbing the lever (60), tighten the locknut by hand to engage the threads on the poppet. Apply a 1/4" nut driver to the locknut and tighten it until only two threads of the poppet shaft are visible above the top of the locknut.



8. Hold the valve body (59) with the lever (60) facing up and slowly unscrew the inlet fitting (51) to remove the used MP seat (55). Depress the lever with your finger and thread the inlet fitting back into the valve body.





9. Screw the valve assembly onto the MP hose (11) until hand tight. Slowly open the handwheel (18) to pressurize the system. If a leak is detected from the valve assembly, immediately close the handwheel and depressurize the system. Adjust the lever height as follows:


- a. Using a 1/4" nut driver, loosen the locknut (62) a 1/4 to 1/2 turn and slowly open the handwheel to pressurize the system. Repeat this process until no leak is detected.



- b. Tighten the locknut using a 1/4" nut driver to initiate a slight leak. Once a slight leak has been established, loosen the locknut until the leak stops, then loosen another 1/4 to 1/2 turn. Depress the lever 2-3 times, pausing after each purge to ensure no leak is present.


 **NOTE:** There should be approximately 1/8" of play in the lever action of the second stage regulator when adjusted and checked in a pressurized condition. All adjustments and checks should be conducted at ambient temperature (i.e. normal room) temperature.

 **NOTE:** The 1/4 to 1/2 turn provides a visual reference when using a 1/4" nut driver and provides an allowance in order to obtain the correct amount of lever play.

 **CAUTION:** Units that have no play in the lever at ambient (room) temperature will most likely leak when exposed to colder temperatures.

10. Close the handwheel (18) and depressurize the system. Remove the valve body assembly from the MP hose (11). Using your finger, press down on the lever (60) and unscrew the valve body (59) from the inlet fitting (51).




 **NOTE:** Set the valve body assembly to the side, reassembly will continue during the **Second Stage Reassembly** section of this manual.

Second Stage (MK) Reassembly

1. Install the exhaust valve (53) into the box bottom (54) by inserting the stem through the center hole of the exhaust port. Pull the stem through until the barb is on the opposite side of the hole in the exhaust port. Examine the flap of the exhaust valve to make sure it is laying flat and is not distorted or folded under. Use a pair of small diagonal pliers to trim the stem so it is only about 1/4" long. Repeat process for other exhaust valve.



2. Insert the long tabs on the exhaust valve cover (52) into the bottom slots of the box bottom (54). Press down on the exhaust valve cover center rib using your index and middle fingers while simultaneously pressing the short tabs into the top slots. Check that the exhaust valve cover is locked into place.



3. Insert the valve body assembly into the box bottom (54) with the lever (60) facing upward. Ensure the valve body assembly is seated between the molded slots in the box bottom.



4. Press down on the lever (60) and thread the inlet fitting (51) into the valve body (59) until hand tight. It may be necessary to press in on the valve body to prevent it from rotating inside the box bottom (54). Use a 3/4" socket and inch pound torque wrench to apply 50 in lb (5.6 Nm) of torque to the inlet fitting.



5. Place the diaphragm (48) on top of the lever (60) inside the box bottom (54). Make sure the edges of the diaphragm are seated below the threads inside the box bottom. Lay the flat side of the ring cover support (47) on top of the diaphragm.



6. Place the front cover (44) on top of the ring cover support (47). Screw the retaining ring (46) or hard cover (45) onto the box bottom (54) until hand tight.



7. Install the mouthpiece (49) onto the box bottom (54). Loosely fasten the clamp strap (50) over the groove at the base of the mouthpiece. Position the clamp strap tab on the MP hose side of the mouthpiece. Pull the clamp strap tight and trim the excess strap using diagonal pliers. Ensure the excess strap has been cut so it is flush with the tab on the clamp strap.



8. Thread the MP hose (11) onto the inlet fitting (51). Hold the inlet fitting with a 3/4" thin wrench and use a 11/16" crowfoot and inch pound torque wrench to apply 45 in lb (5 Nm) of torque to the MP hose fitting.



Second Stage (LV2) Reassembly

1. Install the exhaust valve (68) into the box bottom (69) by inserting the stem through the center hole of the exhaust port. Pull the stem through until the barb is on the opposite side of the hole in the exhaust port. Examine the flap of the exhaust valve to make sure it is laying flat and is not distorted or folded under. Use a pair of small diagonal pliers to trim the stem so it is only about 1/4" long.



2. Using your fingers, screw the exhaust valve cap (67) onto the box bottom (69) until finger tight.



3. Insert the valve body assembly into the box bottom (69) with the lever (60) facing upward.




4. Press down on the lever (60) and thread the inlet fitting (51) into the valve body (59) until hand tight. It may be necessary to press in on the valve body to hold it in place while attaching the inlet fitting. Use a 3/4" socket and inch pound torque wrench to apply 50 in lb (5.6 Nm) of torque to the inlet fitting.




5. Place the diaphragm (48) on top of the lever (60) inside the box bottom (69). Make sure the edges of the diaphragm are seated below the threads inside the box bottom. Lay the front cover (66) on top of the diaphragm.



6. Use the retaining ring wrench to screw the retaining ring (65) into the box bottom (69) hand tight. Place the hard cover (64) over the front cover (66) and screw down until hand tight.



 **NOTE:** The LV2 mouthpiece can be adjusted to several different user preferred positions. (*Reference the User's Manual for more information*).

7. Install mouthpiece (70) onto the box bottom (69). Loosely fasten the clamp strap (50) over the groove at the base of the mouthpiece. Position the clamp strap tab on the MP hose side of the mouthpiece. Pull the clamp strap tight and trim the excess strap using diagonal pliers. Ensure the excess strap has been cut so it is flush with the tab on the clamp strap.



8. Thread the MP hose (11) onto the inlet fitting (51). Hold the inlet fitting with a 3/4" thin wrench and use a 11/16" crowfoot and inch pound torque wrench to apply 45 in lb (5 Nm) of torque to the MP hose fitting.



FINAL TESTING



WARNING: Compressed air can be highly explosive and is dangerous if misused. Ensure the cylinder valve is opened slowly. Use eye and ear personal protective equipment when performing any tests involving compressed air.



WARNING: The SEA is designed to assist helicopter air crew members and passengers in emergency egress situations from submerged aircraft. It is very critical to ensure that no leakage is present and the SEA has met all requirements in the Final Testing section of this manual. DO NOT issue to a crew member or passenger any SEA which exhibits any signs of leakage or unsatisfactory performance until the problem has been thoroughly diagnosed and repairs have been made as needed, including the possible replacement of a damaged component or subassembly.

Subjective Test

1. Slowly open the handwheel (18) to pressurize the system. Check the pressure gauge (36) reads 3000 PSI (207 BAR) or the plunger (41) is "Popped Up" on the pin style gauge (37) indicating a full cylinder (43).
2. Press the front cover two times for about five seconds each, with a five second pause between each purge. Ensure no leaks can be heard coming from the second stage. If a leak is detected, refer to **Table 2: Troubleshooting Guide** section of this manual to determine its possible cause.
3. Perform a subjective breathing test to ensure the second stage is operating properly using the following procedure:
 - a. Fully depress the purge cover (44 or 66) to ensure an adequate volume of air passes through the second stage to clear out any water.
 - b. Inhale slowly but deeply from the mouthpiece (49 or 70). A properly serviced and adjusted regulator should deliver air upon deep inhalation without excessive inhalation effort, free-flow or fluttering of the second stage diaphragm (48). When exhaling, there should be no fluttering or sticking of the exhalation valve (53 or 68). If any of these problems occur, refer to **Table 1 & 2: Troubleshooting Guides** section of this manual to determine its possible cause.

Immersion Test

1. Ensure the handwheel (18) is in the open position and the system is pressurized. Check the pressure gauge (36) reads 3000 PSI (207 BAR) or the plunger (41) is "Popped Up" on the pin style gauge (37) indicating a full cylinder (43).

2. Submerge the entire system in a test tank of clean water. Shake the unit to remove trapped bubbles. Observe any bubbles rising from the submerged system over a **five minute** period. The recommended time is necessary due to slower bubble formation that occurs in smaller leaks. Bubbles indicate a leak, which requires the system to be disassembled at the source to check sealing surfaces, assembly sequence and component positioning in order to correct the problem.



NOTE: Do not confuse bubbles from trapped air with a true leak. If there is an air leak, bubbles will come out in a constant stream.

Pressure Drop Test

1. Ensure the unit is pressurized with the handwheel (18) in the open position. Check the pressure gauge (36) reads 3000 PSI (207 BAR) or the plunger (41) is "Popped Up" on the pin style gauge (37) indicating a full cylinder (43). Set the SEA in a stable temperature environment for a minimum of **twelve hours**. After the time has elapsed, check the following:

- Dial pressure gauge: Ensure gauge reads "3000 PSI".
- Pin pressure gauge: Ensure plunger (41) is "Popped Up".



WARNING: If the pressure gauge (36) does not read "3000 PSI" or the plunger (41) on the pin gauge (37) is not "Popped Up" after **12 hours**, refer to **Table 1 & 2: Troubleshooting Guides** section of this manual to determine its possible cause.

2. Upon completion of the pressure drop test, ensure all water is removed from the unit. Blow clean LP air through the cap (2) holes and fill port (33) to remove excess water. After the unit is dry, refill the unit to 3000 PSI (207 BAR). Close the handwheel (18) when filling is complete and depressurize the unit.
3. Once completely dry, install retainer cover (1) and fill port cap (31).



NOTE: The SEA must be cleaned and sanitized as per local instructions before issue.



4. Providing the unit has passed all testing and the cylinder has been filled to its full capacity as marked, the SEA is now ready for use.

TABLE 1: TROUBLESHOOTING GUIDE FIRST STAGE

SYMPTOM	POSSIBLE CAUSE	TREATMENT
System will not remain depressurized after handwheel is closed and second stage is purged.	1. The seat & disc retainer (29) is worn or damaged.	1. Replace seat & disc retainer (29).
	2. The seat & disc retainer crown in first stage body (8) is worn or damaged.	2. Replace body (8).
High or Unstable MP “Creep”	1. The seat & disc retainer (29) is worn or damaged.	1. Replace seat & disc retainer (29).
	2. The seat & disc retainer crown in first stage body (8) is worn or damaged.	2. Replace first stage body (8).
	3. The spring (7) is weakened or damaged.	3. Replace spring (7).
	4. The HP seat (6) is worn or damaged.	4. Replace HP seat (6).
	5. The HP crown seating surface in first stage body (8) is worn or damaged.	5. Replace first stage body (8).
Low MP	1. The spring (7) is weakened or damaged.	1. Replace spring (7).
External Air Leak	1. The piston head o-ring (3) or shaft o-ring (5) is worn or damaged.	1. Replace o-rings (3 & 5).
	2. The o-ring grooves on the piston (4) are worn or damaged.	2. Replace piston (4) and o-rings (3 & 5).
	3. The piston head o-ring sealing surface in the retainer cap (2) is worn or damaged.	3. Replace retainer cap (2).
	4. The piston shaft o-ring sealing surface in the first stage body (8) is worn or damaged.	4. Replace first stage body (8).
	5. Safety plug (9) not seated correctly.	5. Check for damage and re-torque safety plug (9).

TABLE 2: TROUBLESHOOTING GUIDE SECOND STAGE

SYMPTOM	POSSIBLE CAUSE	TREATMENT
Leakage or free-flow from the second stage	1. High first stage MP, should be 135 (±20) PSI / 9.3 (± 1.4) BAR.	1. Refer to <u>Table 1: Troubleshooting Guide</u>.
	2. The MP seat (55) is dirty, worn or damaged.	2. Clean or replace MP seat (55).
	3. The lever (60) is set too high.	3. Readjust locknut (62).
	4. The lever (60) is bent.	4. Replace the lever (60).
	5. The crown seating surface on the inlet fitting (51) is worn or damaged.	5. Replace the inlet fitting (51).
	6. The spring (57) is worn or damaged.	6. Replace the spring (57).
	7. The poppet (56) is worn or damaged.	7. Replace the poppet (56).
Low purge or labored breathing (full cylinder)	1. Low first stage MP, should be 135 (±20) PSI / 9.3 (± 1.4) BAR.	1. Refer to <u>Table 1: Troubleshooting Guide</u>.
	2. The lever (60) is set too low.	2. Readjust locknut (62).
	3. The lever (60) is bent.	3. Replace the lever (60).
	4. The MP hose (11) is clogged or obstructed.	4. Clean or replace the MP hose (11).
	5. The spring (57) is worn or damaged.	5. Replace the spring (57).
External Air Leak (Immersion Test)	1. The MP hose (11) is loose or damaged.	1. Re-torque MP hose (11) at second stage fitting or replace hose.
	2. The MP hose o-ring (25) is damaged.	2. Replace the o-ring (25).
Water entering second stage	1. The mouthpiece (49 or 70) is incorrectly fitted or damaged.	1. Refit or replace mouthpiece (49 or 70).
	2. The diaphragm (48) is damaged.	2. Replace the diaphragm (48).
	3. The exhaust valve (53 or 68) is damaged or improperly seated.	3. Re-seat or replace the exhaust valve (53 or 68).
	4. The diaphragm (48) is improperly seated in the box bottom (54 or 69).	4. Disassemble and properly reassemble (check for distortion).
	5. The box bottom (54 or 69) is damaged.	5. Check exhaust valve seating surface or replace box bottom (54 or 69).
	6. The inlet fitting o-ring (23) is damaged.	6. Disassemble and replace o-ring (23).



NOTE: This is a partial list of problems and recommended treatments. For more information contact your Aqua Lung Technical Service Department for assistance with problems not described in the **Table 1 & 2: Troubleshooting Guides**.



CAUTION: Recommended treatments which require disassembly of the SEA must be performed during a complete overhaul, according to the prescribed procedures for scheduled service. Do not attempt to perform partial service.

TABLE 3: LIST OF TOOLS AND SERVICE KITS











PART #	DESCRIPTION	APPLICATION
108342	SEA MK Tool Kit (Tools in addition to those listed below are included in the tool kit. Additional tools are for MRS III portable refill station service).	Tools Kit for servicing SEA MK / LV2
108361	Tool Pouch SEA MK 	Carrying tools
111610	MP Test Gauge 0-400 psi 	Checking medium pressure
108357	Repair Mat 	Service and maintenance
108362	Soft Cases MP Test Gauge 	Cover for MP Test Gauge
108325	SCUBA Fill Adapter 	Filling Cylinder (43)
944022	O-ring Tool (Brass) 	Removal / Installation of O-rings
10-102-400	O-ring Tool SS 	Removal of MP Hose O-ring (25) & MP Seat (55)
109437	Seat Extractor Tool 	Removal of HP Seat (6)
9-47709	Cylinder Light 	Inspection of Cylinder (43)
100188	Retaining Ring Wrench 	Removal / Installation of Retaining Ring (65)

TABLE 3: LIST OF TOOLS AND SERVICE KITS (CONTINUED)

















PART #	DESCRIPTION	APPLICATION
9-BA819008	Magnifier w/Illumination 	Inspection of parts
820466	Christo-Lube MCG 111 2 oz. 	Parts lubrication
947448	Screwdriver Medium Blade (Modified) 	Removal / Installation of Handwheel Retainer (15)
54325A22	Strap Wrench 	Removal / Installation of First Stage Body (8) from Cylinder (43)
103045	Flex Wrench 3/8" Drive 	Removal / Installation of parts
FC38A 9-43625 9-43628	1 3/16" Crowfoot 11/16" Crowfoot 7/8" Crowfoot 	Removal / Installation of First Stage Body (8) Removal / Installation of MP Hose (11) Removal / Installation of Pressure Gauge (36)
9-43226 103006 9-43001	3/4" Socket 9/16" Socket 3/8" Socket 	Removal / Installation of Bonnet (21) & Inlet Fitting (51) Removal / Installation of Fill Port (33) Removal / Installation of Safety Plug (9)
107394	Adjustable Spanner Wrench 	Removal / Installation of Retainer Cap (2)
9-44584	3/4" & 7/8" Thin Wrench 	Hold Inlet Fitting (51) while tightening MP Hose (11)
9-AM11708 9-46661	1/8" Hex Bit Socket 3/16" Hex Bit Socket 	Removal / Installation of Retainer (42) Removal / Installation of Swivel Port Plug (14)
9-41971	1/4" Nut Driver 	Removal / Installation of Locknut (62)

TABLE 3: LIST OF TOOLS AND SERVICE KITS (CONTINUED)

PART #	DESCRIPTION	APPLICATION
9-45171	Diagonal Pliers Small 	Removal / Installation of Clamp Strap (50)
053035	Valve Handle Retainer Tool 	Removal / Installation of Pin Style Pressure Indicator (37)
100398	Insert, Tool Vise Jaws 	Removal / Installation of First Stage Body (8) from Cylinder (43) (1.5 ft³ & 2 ft³ cylinders only) (Not included in Tool Kit)
N/A	Torque Wrench in lb 	Apply torque to parts listed in Table 4: Torque Specifications (Not included in Tool Kit)
N/A	Torque Wrench ft lb 	Apply torque to parts listed in Table 4: Torque Specifications (Not included in Tool Kit)
108343 108344	Service Kit, SEA First Stage Service Kit, MK & LV2 Second Stage	Replacement Service Kit Parts



NOTE: Photos of tools contained in the SEA tool kit are representative. Tool manufacturers and part numbers are subject to change without notice.



TABLE 4: TORQUE SPECIFICATIONS

PART #	DESCRIPTION / KEY ITEM #	TORQUE
108312	First Stage Body (8)	25 ft lb (33.9 Nm)
108305 / 108333	Swivel Port Plug (14)	60 in lb (6.8 Nm)
054201	Safety Plug (9)	90 in lb (10.2 Nm)
108318	Bonnet (21)	90 in lb (10.2 Nm)
108308	Fill Port (33)	90 in lb (10.2 Nm)
102810	Pressure Gauge (36)	45 in lb (5 Nm)
108625 / 102835 108392 / 108391	MP Hose (11) Swivel Fitting	45 in lb (5 Nm)
108438	Inlet Fitting (51)	50 in lb (5.6 Nm)
108367	Blank Plug (22)	90 in lb (10.2 Nm)

TABLE 5: TEST BENCH SPECIFICATIONS

TEST	CONDITION	SPECIFICATION
Leak Test	Inlet 3000 PSI (207 BAR)	No leaks allowed
MP	Inlet 3000 PSI (207 BAR)	135 ±20 PSI (9.3± 1.4 BAR)
MP Creep	Inlet 3000 PSI (207 BAR)	5 psi (0.34 BAR) max between 5 to 15 seconds after cycling regulator (purge)
Opening Effort	Inlet 3000 PSI (207 BAR)	+1.4 to +3.0 inch H ₂ O (3.5 - 7.5 mbar)
Flow Effort	MP 135 ±20 PSI (9.3± 1.4 BAR)	+5 inches H ₂ O (12.5 mbar) (maximum) at 6 SCFM (170 LPM)
Purge Flow	MP 135 ±20 PSI (9.3± 1.4 BAR)	5 SCFM (142 LPM) flow rate (minimum)

TABLE 6: RECOMMENDED CLEANERS AND LUBRICANTS

LUBRICANT/CLEANER	APPLICATION	SOURCE
Christo-Lube MCG 111	All o-rings	Aqua Lung, PN 820466, or Lubrication Technologies 310 Morton Street Jackson, OH 45640 (800) 477-8704
 CAUTION: Silicone rubber requires no lubrication or preservative treatment. DO NOT apply grease or spray to silicone rubber parts. Doing so may cause a chemical breakdown and premature deterioration of the material.		
Oakite #31	Acid bath for reusable stainless steel and brass parts.	Oakite Products, Inc. 50 Valley Road Berkeley Heights, NJ 07922
 CAUTION: Do not use muriatic acid for the cleaning of any parts. Even if strongly diluted, muriatic acid can harm chrome plating and may leave a residue that is harmful to o-ring seals and other parts.		
White distilled vinegar	Acid bath for reusable stainless steel and brass parts.	"Household" grade
Liquid dish washing detergent (diluted with warm water)	Degreaser for brass and stainless steel parts; general cleaning solution for plastic and rubber	"Household" grade

PROCEDURE A: CLEANING AND LUBRICATING

Cleaning Brass & Stainless Steel Parts

1. Pre-clean in warm, soapy water* using a nylon bristle tooth brush.
2. Thoroughly clean parts in an ultrasonic cleaner filled with soapy water. If there are stubborn deposits, household white distilled vinegar (acetic acid) in an ultrasonic cleaner will work well. DO NOT place plastic, rubber, silicone or anodized aluminum parts in vinegar.
3. Remove parts from the ultrasonic cleaner and rinse with fresh water. If tap water is extremely “hard,” place the parts in a bath of distilled water to prevent any mineral residue. Agitate lightly and allow to soak for 5-10 minutes. Remove and blow dry with clean, low pressure filtered air and inspect closely to ensure proper cleaning and like-new condition.

Cleaning Anodized Aluminum, Plastic & Rubber Parts

Anodized aluminum parts and parts made of plastic, rubber or silicone such as box bottoms, box tops, dust caps, diaphragms, etc., may be soaked and cleaned in a solution of warm water mixed with mild dish soap. Use only a soft nylon toothbrush to scrub away any deposits. Rinse in fresh water and thoroughly blow dry, using low pressure filtered air.



CAUTION: Do not place plastic, rubber, silicone or anodized aluminum parts in acid solutions. Doing so may alter the physical properties of the component, causing it to prematurely degrade and/or break.

Cleaning Hoses

1. Hose fittings: Ultrasonically clean with soapy water*; vinegar OK on tough corrosion – (**only hose ends**).
2. Run soapy water through hose if needed.
3. Thoroughly rinse with fresh water– (**hang with hose ends down**).
4. Blow out hose before installing.

Lubrication and Dressing


All o-rings should be lubricated with Christo-Lube® MCG 111. Dress the o-rings with a very light film of lubricant and remove any visible excess by running the o-ring between thumb and forefinger. Avoid applying excessive amounts of Christo-Lube® MCG 111, as this will attract particulate matter that may cause damage to the o-ring.

*Soapy water is defined as “household” grade liquid dishwashing detergent diluted in warm water.



CAUTION: Silicone grease and sprays must be strictly avoided, since silicone does not provide adequate lubricity in extreme weather conditions.

SEA FIRST STAGE EXPLODED VIEW



Key # Part # Description

.....108343	Overhaul Service Kit, SEA First Stage
.....108311	First Stage, Spare SEA
.....108469	First Stage Spare, SEA USCG / CBP


1108302	Cover, Retainer
2108303	Cap, Retainer
3 820062P	O-ring (10 pk)
4106769	Piston
5 820007P	O-ring (20 pk)
6 106726	HP Seat
7106771	Spring
8108312	Body, First Stage
9 054201	Safety Plug
10108306	Spacer, Black
.....108334	Spacer, Chrome
11100625	Hose Assy. MK, 27" Black
.....102835	Hose Assy. MK, 20" Black
.....108392	Hose Assy. LV2, 27" Black
.....108391	Hose Assy. LV2, 20" Black
12 820311P	O-ring (10 pk)
13 820312P	O-ring (10 pk)
14108305	Port Plug, Swivel, Black
.....108333	Port Plug, Swivel, Chrome
15108304	Retainer, Handwheel, Black
.....108314	Retainer, Handwheel, Silver
16108329	Washer, Handwheel
17108316	Spring, Handwheel
18108313	Handwheel

Key # Part # Description

19108326	Washer, Nylon
20108317	Ring, On / Off Indicator
21108318	Bonnet
22108367	Plug, Blank, 5/8" Black (USCG Only)
23 820015P	O-ring (10 pk)
24 828009	Ring, Back-up
25 820010P	O-ring (25 pk)
26108328	Washer, Brass
27 108327	Washer, Teflon
28108319	Stem, On / Off
29 108322	Seat & Disc Retainer Assy
30 820316P	O-ring (10 pk)
31108307	Cap, Fill Port
32 820319P	O-ring (10 pk)
33108308	Port, Fill
34 820304P	O-ring (10 pk)
35108309	Pin, Fill Port
36102810	Pressure Gauge 3000 psi, Black
37108346	Pressure Indicator, Pin Style
38108347	Body, Pressure Indicator
39 820304P	O-ring (10 pk)
40845034	Washer
41100688	Spring, Pressure Gauge
42100613	Plunger
43100607	Retainer
.....079105	Cylinder, 1.5 ft³, 3000 PSI Black, Aluminum
.....079120	Cylinder, 2.0 ft³, 3000 PSI Black, Aluminum

Part numbers in **BOLD ITALICS** indicate standard overhaul replacement part.

MK SECOND STAGE EXPLODED VIEW




Key #	Part #	Description
.....	108344	Overhaul Service Kit, SEA MK Second Stage
.....	108315	Second Stage, MK, Spare
.....	108468	Second Stage, MK, Spare USCG/CBP
44	100904	Front Cover
45	108414	Hard Cover (USCG only)
46	100906	Ring, Retaining Threaded
47	100909	Ring Cover Support
48	100181	Diaphragm
49	105831	Mouthpiece, Black
50	104913	Clamp Strap, Black
23	820015P	O-ring (10 pk)
51	108438	Inlet Fitting, Black
25	820010P	O-ring (25 pk)

Key #	Part #	Description
52	100907	Cover, Exhaust Valve
53	100922	Exhaust Valve
54	100905	Box Bottom, MK, Black
55	106738	MP Seat
56	104122	Poppet
57	104127	Spring
58	104134	Poppet Bearing
59	100945	Valve Body
60	100923	Lever
61	104129	Washer
62	102510	Locknut
63	100653	Cover Mouthpiece, MK

Part numbers in **BOLD ITALICS** indicate standard overhaul replacement part.

LV-2 SECOND STAGE EXPLODED VIEW



Key #	Part #	Description
-------	--------	-------------

.....	108344	Overhaul Parts Kit
.....	108402	Second Stage, LV2, Spare
64	100652	Hard Cover, Purge
.....	100652Y	Hard Cover, Purge Yellow
65	100119	Retaining Ring
66	100104	Cover, Front
48	100181	Diaphragm
55	106738	MP Seat
56	104122	Poppet
57	104127R	Spring (Red)
58	104134	Poppet Bearing
59	100945	Valve Body

Key #	Part #	Description
-------	--------	-------------

60	100923	Lever
61	104129	Washer
62	102510	Locknut
67	108371	Cap Exhaust Valve
.....	108371Y	Cap Exhaust Valve Yellow
68	100122	Exhaust Valve
69	108374	Box Bottom, LV2, Black
23	820015P	O-ring (10 pk)
51	108438	Inlet Fitting, Black
25	820010P	O-ring (25 pk)
50	104913	Clamp Strap, Black
70	108373	Mouthpiece, LV2
71	108453	Cover Mouthpiece, LV2

Part numbers in **BOLD ITALICS** indicate standard overhaul replacement part.

MAINTENANCE NOTES

[illegible]

[illegible]

Survival Egress Air

(SEA MK / LV2)

Technical Manual



2340 Cousteau Court • Vista, CA 92081
Phone (760) 597-5000 • Fax (760) 597-4900
www.aqualung.com/militaryandprofessional