

Egg Cocker

MICROWAVE Pasta Cooker



IMPORTANT SAFETY INSTRUCTIONS, READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT. IMPROPER USE CAN RESULT IN INJURY. SAVE THESE INSTRUCTIONS.

WARNING

 **Keep this product out of the reach of children.**

IMPORTANT SAFETY INSTRUCTIONS

- Thoroughly wash microwave pasta cooker before first use and after each use.
- If washing by hand, only use warm soapy water and do not use steel wool cleaners or abrasive materials.
- Microwave pasta cooker can be washed in a top-loading dishwasher.
- Before putting it into the microwave oven, when the water level is too full, you can open the lid and put it in the microwave oven (if the water level is about half the height of the noodle pot, you can cover it and put it in the microwave oven).
- **BURN HAZARD:** Microwave pasta cooker get very hot and produce steam after microwaving. Allow to cool for 2 minutes before removing the pasta cooker from the microwave oven and use caution before opening the steam lid to reduce the risk of burns.
- **BURN HAZARD:** Do not pick up or carry pasta cooker by steam lid after heating in microwave. Use oven gloves and lift and carry by safety locking handles to reduce the risk of burns.
- - **BURN HAZARD:** Avoid placing hands or fingers near the steam valve after heating in the microwave oven.
- Remove the cookware from the microwave oven and place on a heat safe surface away from the heat source before opening.
- **WARNING:** To avoid damage to the product, do not overcook food and/or exceed the maximum cooking time specified in the cooking schedule.
- **WARNING:** Use only in the microwave oven. Do not use in convection mode in conventional ovens or microwaves.
- Use to cook a variety of spaghetti.

PACKAGE INCLUDES

1 Microwave Pasta Cooker

1 Instruction Manual

PRODUCT SPECIFICATIONS

Product weight: 7.2 oz

Product material: Plastic

Product size: 12.01×5.71×3.82 inches

INSTRUCTIONS FOR USE

Step 1

Portion your pasta with the attached measuring tool and put in the cooker
(Note: no more than 4 servings).



Step 2

Add water to corresponding water level on the measuring card. Take out the card.



Step 3

Take lid off and put the cooker into microwave. Cook on high (100%) and corresponding time based on attached time chart.



Step 4

Cover lid on, take it out with both side handles.



Step 5

Pour the water out, shake it to strain more thoroughly.
Rinse with cold water and strain again, if needed.



6. Place in the microwave oven for the required cooking time. See cooking schedule.
7. Cool for 2 minutes, then remove the pasta cooker from the microwave. Use oven mitts to lift and carry by the safety lock handle.
8. Place on a surface that will not be damaged by heat or steam.
9. Be careful when pouring water and before opening the lid to avoid steam hurting your hands.
10. Use a spoon or fork to take out the pasta and put it on the plate, pour your favorite sauce and enjoy your delicious pasta

COOKING TIME CHART

The Microwave Pasta Cooker is specially designed for cooking pasta in the microwave. The cooking times below are for reference only. Actual cooking times will vary based on many factors, including brand of microwave, type of pasta, and more. Adjust the cooking time in 1-minute intervals to cook the pasta to your liking.

TYPE OF PASTA	PACKAGE INSTRUCTION TIM	900W	1200W
Angel Hai	6-10 mins	10 mins	10 mins
Spaghetti	10-11 mins	13 mins	12 mins
Fettuccine	14 mins	15 mins	14 mins
Linguine	8-9 mins	15 mins	14 mins
Farfalle	14 mins	16 mins	15 mins
Rotini	10-12 mins	17 mins	16 mins
Fusilli	10-13 mins	17 mins	16 mins
Orzo	9 mins	10 mins	8 mins
Penne	11 mins	15 mins	14 mins
Shaped pasta	8-12 mins	17 mins	16 mins



SCAN NOW

or go to

pato_serviceteam@163.com