





OCULAR



LTE PLUS USER MANUAL & INSTALLATION GUIDE

OC20-BC-7.2KW-Plus-A
OC20-BC-22KW-Plus-A

Version 2.2

 ocularcharging.com.au
 sales@ocularcharging.com.au
 1300 912 650



CONTENTS

- Welcome to Your LTE Plus 3
- EVSE Master app 4
- User Manual 5
 - How to Charge - LTE Plus 5
 - Schedule and Delayed Charging 7
 - Reports and Statistics 8
 - Troubleshooting 9
 - Warranty 9
- Installation Guide..... 10
 - Specifications 10
 - Accessories of Tethered Model..... 11
 - Product Overview 11
 - Installation Guide..... 12
 - Illustration of Screen and LED..... 13
 - Safety Warning 14
 - Maintenance..... 14

IMPORTANT!

Read this entire document before installing or using the charger. Failure to do so or to follow any of the instructions and warnings in this document can result in fire, electrical shock, serious injury, or death.

The charger must be installed by a qualified electrician.

The entire installation must comply with the latest
“AS/NZS 3000:2018 & AS/NZS 3008 standards”

Welcome to your Ocular LTE Plus!



[Resource Library](#)



[FAQs](#)

Follow the links or scan to QR codes to access all our user manuals and technical documents. You will also find answers to the most common questions we receive.

Download the EVSE Master app



[Click here to download](#)



[Click here to download](#)

USER MANUAL

SECTION 1

HOW TO CHARGE - LTE PLUS



Scan for a video overview of the EVSE Master app and how to start charging


1. CONNECT YOUR CHARGER AND APP

After installation, launch the EVSE Master app. You will see a home screen with a Connect button. Click it to connect to your charger. You may be prompted by your phone to turn on Bluetooth if it isn't already. A list will appear of available nearby chargers. Select the one you want to control to connect to it.

2. START A CHARGING SESSION


Plug the cable into your car, then you can either start charging on the app or from the button on the charger.

App

- Open the app and navigate to general settings via the  button in the bottom right-hand corner of the screen
- Ensure the toggle “start charging by button” is switched OFF
- Navigate back to the home charging page
- Plug the charging cable into the car
- Press the start charging session button

***As this is a Bluetooth charger, you must be in the vicinity of the charger to start/stop the charging session via the app.**


Charger Button

- Open the app and navigate to general settings via the  button in the bottom right-hand corner of the screen
- Ensure the toggle “start charging by button” is switched ON
- Plug the charging cable into the car
- Press the silver button on the side of the charger

If your charger is not providing max charging speed, your current limit may be set too low.

You need to change the current limit by adjusting the slider up to 32A or by pressing the button on the side of the charger, while not plugged into a vehicle, to cycle through the available settings.

If there has been a hard limit set by the electrician, your max current limit may be less than 32 Amps.



3. STOP A CHARGING SESSION

App

If you started the charging session with the app, you must stop charging with the app. Press the stop charging button on the home charging page.

***As this is a Bluetooth charger, you must be in the vicinity of the charger to start/stop the charging session via the app.**

Charger Button

If you started the charging session with the silver button on the side of the charger, you must stop charging by pressing the button again.

SECTION 2

SCHEDULE AND DELAYED CHARGING

DELAY CHARGING


1. Press custom charge on the home page.
2. Press the single charging tab.
3. The first slider will delay the start time based on your choice-up to 24 hours.
4. The second slider determines the duration by choosing the stop time.
5. The last slider allows you to choose a set amount of kWh, and the charger will stop once the car has received this much power.



SCHEDULE CHARGING

1. Press the repeated charging tab under the custom charge menu.
2. Choose your start and stop time, and you will be able to see the total charging duration during these times.
3. Choose the days you want to repeat this schedule.
4. The charging session will start and stop depending on this schedule.


*You must be plugged in before the start of the schedule.



SECTION 3

REPORTS AND STATISTICS

1. Records and Statistics page
2. My records tab: records of all charging sessions that were started on your phone.
3. All records tab: all charging records that were stored in the charger.
4. Refresh button: synchronise all charging records to your phone.
5. Statistics tab: graphs of Charging duration and Carbon emissions.



SECTION 4

TROUBLESHOOTING

PROBLEMS	SOLUTIONS
The charger will not charge the car	<ol style="list-style-type: none">1. Unplug the charger from the car and then plug back in, making sure that the plug is pushed all the way into the socket.2. Check if your car is fully charged or if there's a charging limit set on your car.3. Check that the desired charging mode has been selected in the App. (See Section 1 for more information).4. Check if there is a schedule set on the App.
The car charges slower than expected	<ol style="list-style-type: none">1. The maximum charging current may be set lower than is desired. To change it, navigate to the charging page and adjust the max current slider (See Section 1 for more information).2. There may have been a hard limit set by the electrician according to the power available at your house. Please consult your installer if you believe this value is incorrect. They will need to assess the available power at your house.3. Double check if there's a charging current limit on your car.
I can't connect the app to the charger	Reboot your charger by turning off at the isolator switch next to the charger and then turn the switch back on.

WARRANTY

This charging station is subject to stringent quality inspections. Warranty is available within 2 years of purchase of your accessory.

Any incorrect handling, fair wear and tear, misuse, misrepair or neglect caused by the user resulting in direct damage and failure to the product cannot be covered by warranty.

This product is warranted for 2 years by Ocular. For all faults or warranty related questions or claims, please contact Ocular at **help@ocularcharging.com.au** or **1300 912 650**.


INSTALLATION GUIDE

SPECIFICATIONS		
Model Number	OC20-BC-7.2KW-Plus	OC20-BC-22KW-Plus
Power Output	7.2kW (1- Phase)	22kW (3- Phase)
Charging Connector	Tethered 6m Type-2 Cable	
Display	3.5" LCD Screen + LED indication lights	
Frequency (Hz)	50Hz	
Input and Output Voltage	230V \pm 20% per phase	
Input and Output Current	32A MAX per phase	
Operating Temperature	-30 to +55 in operation	
Storage Temperature	-40 to +75 in storage	
Working Humidity	95% relative humidity, non-condensing	
IP Performance	IP66	
Internal RCD	Type A + 6mA DC	
Electrical Protection	Over current, Short circuit, Over voltage, Under voltage, Ground fault, Lightning surge, Over temperature, Earth leakage	
Meter	Integrated Energy Meter	
Standby Power Consumption	<8W	
Mounting	Wall mountable	
Dimension (H x W x D, mm)	295 x 195 x 65 mm	
Net Weight	7.7 kg	
Recommended Cable Size (50m run)	40A single phase type A RCBO	40A three phase type A RCBO
Recommended Circuit Breaker	10mm ² 2C+E	10mm ² 4C+E
Certification	CE, TUV, FCC, CSA, RoHS, RCM	
Warranty	2 years	

OCULAR LTE PLUS OVERVIEW

ACCESSORIES OF TETHERED MODEL

It is the installer’s responsibility to provide and install a suitable RCBO, cabling and isolator switch to complete the installation.



PRODUCT OVERVIEW




INSTALLATION GUIDE

1

Place **reference paper** on wall

Wall


Drill the holes according to the **reference paper**



2


Hammer the **30mm plastic bolts** into the holes

Take down the **reference paper** from the wall




3

Fix the **plate** with **30mm screws** on the wall



4

Embed **station** into **plate** on the wall. Use Connector Clip to connect base plate to charger



5

Isolation switch

This is what the charger, holder and isolator should look like after installation.

Install the **hook and holder** nearby the charger



6

Peel off the plastic protector





ILLUSTRATION OF SCREEN AND LED




Start-up screen
(the version no. is for reference only)




The charger is ready to be connected to the car



Start charging from App or Button




Charging process is starting




Data displayed during the charging process








Charging has stopped and car can be unplugged



1. Real-time power
2. Three Live Wire data
3. Charging Time
4. Power Consumption
5. Charging Icon
6. PCB Temperature



1. Emergency stop
2. Over Current
3. Over Temperature
4. Leakage protection
5. Short Current

Instruction of LED status	Idle	Connected	Charging	Finished	Error
	 <p>Off</p>	 <p>Continuous light</p>	 <p>Rolling</p>	 <p>Continuous light</p>	 <p>Red flashing</p>

Note: The Ocular LTE Plus will automatically restart when minor problems occur.

For serious failures, the system cannot automatically recover. In order to remind user of this failure, the system will automatically countdown 10 seconds to restart.

SAFETY WARNING

Failure to follow instructions may result in danger!

- Regularly check whether the charging station has visible damage.
- Make sure that all safety facilities are available at all times and are tested regularly to ensure they can operate normally.
- If a ground fault occurs, it must be assumed that the cable carries voltage. Please isolate the charger from power, via circuit breaker or isolator, before inspecting the charging station.
- Persons who install and use charging stations must obey the principles and regulations mentioned to ensure personal and equipment safety.
- Before powering on the device, please confirm that the device is properly grounded to avoid unnecessary accidents.
- All tools' unnecessarily exposed metal parts should be insulated to prevent them from touching the metal frame to avoid short circuits.
- Do not modify, retrofit, or change any part by yourself under any circumstances.
- To ensure the service life and stable operation of the charging station, the operating environment should be kept clean as possible with a relatively stable temperature and humidity. The charging station must not be used in a flammable environment or environments with volatile gas.
- Be sure to confirm that the input voltage, frequency, circuit breakers and other conditions of the device meet the specifications before the device is powered on.

MAINTENANCE

Ocular LTE Plus is only recommended for use in residential applications and use outside of this area (i.e. for commercial application) is outside of warranty.

The product should be placed at an ambient temperature of $-25^{\circ}\text{C}\sim+55^{\circ}\text{C}$ in relative humidity of no more than 95%. The air should not contain acids, alkalis, or other corrosive and explosive gases.

Ocular Charging Stations are subject to stringent quality inspections. From the day of purchase, any problem quality can be reflected to the dealer within two years.

Any direct damage or malfunction caused by neglect, incorrect use, installation, usage, repair by the users or natural damage are not covered by the warranty.

OCULAR

LTE PLUS

ocularcharging.com.au
sales@ocularcharging.com.au
1300 912 650