


EVK-VERA-P174

Evaluation kit for VERA-P1 host-based V2X transceiver modules

User guide



Abstract

This document describes how to set up the EVK-VERA-P174 evaluation kit to evaluate the VERA-P1 series host-based 802.11p V2X transceiver modules.

Document information

Title	EVK-VERA-P174		
Subtitle	Evaluation kit for VERA-P1 host-based V2X transceiver modules		
Document type	User guide		
Document number	UBX-17048707		
Revision and date	R08	6-Nov-2020	
Disclosure Restriction	C1 Public		

This document applies to the following products:

Product name	Type number	Firmware version	PCN reference
EVK-VERA-P174	EVK-VERA-P174-00A-00		N/A

u-blox or third parties may hold intellectual property rights in the products, names, logos and designs included in this document. Copying, reproduction, modification or disclosure to third parties of this document or any part thereof is only permitted with the express written permission of u-blox.

The information contained herein is provided "as is" and u-blox assumes no liability for its use. No warranty, either express or implied, is given, including but not limited to, with respect to the accuracy, correctness, reliability and fitness for a particular purpose of the information. This document may be revised by u-blox at any time without notice. For the most recent documents, visit www.u-blox.com.

Copyright © u-blox AG.

Contents

Document information	2
Contents	3
1 Evaluation kit description	5
1.1 Overview	5
1.2 Kit includes	6
1.3 Software and documentation.....	6
1.4 System requirements	6
1.5 Specifications	7
2 Getting started	8
3 Board description	9
3.1 Block diagram	9
3.2 Overview	9
3.2.1 Main board	10
3.2.2 USB and power supply board.....	11
3.3 Connectors	12
3.3.1 Power supply and configuration	12
3.3.2 USB interface.....	12
3.3.3 Bootstrapping.....	12
3.3.4 SPI interface	12
3.3.5 SPI chip select	13
3.3.6 1PPS interface.....	13
3.3.7 GNSS interface.....	13
3.3.8 SMA connectors	14
3.3.9 Host interface connector	14
3.4 LEDs.....	14
3.5 Buttons.....	14
3.6 Design files	15
4 Software	20
4.1 Quick start instructions.....	20
4.2 Module calibration	22
4.3 Usage examples	22
4.3.1 Transmit and receive counters	23
4.3.2 Channel configuration	24
4.3.3 Transmitter test	24
4.3.4 Receiver test	25
4.3.5 LLC native IPv6 functionality	26
4.4 Building the software for a different target platform	27
Appendix	28
A Glossary	28
Related documents	29

Revision history	30
Contact.....	31

1 Evaluation kit description

1.1 Overview

VERA-P1 is a compact, embedded transceiver module that enables development of electronics for Vehicle-to-Everything (V2X) communication systems. The module includes an integrated MAC/LLC/Baseband processor and the required RF front-end components. It connects to a host processor through USB or SPI interface.

The EVK-VERA-P174 evaluation kit provides a simple way to evaluate the VERA-P1 series host-based V2X transceiver modules. The evaluation kit serves as an evaluation and development platform providing full access to the interfaces of the VERA-P1 radio module, and allows integration of the VERA-P1 module with an external PC or host processor development platform.

The main features of the EVK-VERA-P174 evaluation kit are:

- Enables host communication via Micro USB connector or SPI pin header
- Provides two SMA antenna connectors for the VERA-P1 module
- Has an integrated u-blox NEO-M8U GNSS module with SMA antenna connector
- Has an on-board SPI flash for evaluating different boot options
- Provides an integrated USB 2.0 hub to access VERA-P1, GNSS, and SPI flash via a single connector
- Has 9 – 28 V DC power supply input with the option to provide external supplies separately and measure current consumption

Table 1 lists the available versions of the evaluation kit:

Evaluation kit	Description	Suitable for evaluation of
EVK-VERA-P174	Evaluation kit for the VERA-P1 module	VERA-P173 (with single radio firmware) VERA-P174 (with dual radio firmware)

Table 1: EVK-VERA-P174 evaluation kit



For further information about the features supported by VERA-P1 series V2X modules, see the VERA-P1 series data sheet [1] and VERA-P1 series system integration manual [2].

The EVK-VERA-P174 consists of two boards, which are connected by a board-to-board connector. The upper main board contains the VERA-P174 and the NEO-M8U GNSS module. The USB interface and main power supply are included on the lower power supply board. The board-to-board connector allows the main board to be directly connected to a compatible host board.




Figure 1: EVK-VERA-P174 main board

1.2 Kit includes

The EVK-VERA-P174 evaluation kit includes the following:

- Evaluation board with the VERA-P174 module (main and power supply boards)
- Two 5.9 GHz DSRC antennas (Triton TD.10 5 dBi)
- Micro USB cable
- Quick Start card

1.3 Software and documentation

The Linux drivers, firmware, and basic evaluation tools for the VERA-P1 series modules are available via u-blox support. Distribution of the software requires signing of the u-blox Limited Use License Agreement (LULA-N).



Contact u-blox support for your area as listed in the Contact section to obtain the software package.

1.4 System requirements

- Host PC with a USB 2.0 interface
- Native Linux OS or virtual machine for building and running the software (for example, Ubuntu 18.04)

1.5 Specifications

Table 2 and Table 3 list the absolute maximum ratings and operating conditions for the EVK-VERA-P174:

Symbol	Description	Min.	Max.	Unit
V _{Sys}	Main power supply 9 – 28 V	-0.3	28.0	V
5V0_A1, 5V0_A2	Power supply voltage 5 V	-0.3	6.0	V
3V3	Power supply voltage 3.3 V	-0.3	3.9	V
VIO	I/O supply voltage 1.8 V/3.3 V	-0.3	3.9	V
T _{STORAGE}	Storage temperature	-40	+95	°C

Table 2: Absolute maximum ratings

Symbol	Description	Min.	Typ	Max.	Unit
V _{Sys}	Main power supply voltage	9	12	28	V
5V0_A1, 5V0_A2	Power supply voltage 5.0 V	4.5	5.0	5.5	V
3V3	Power supply voltage 3.3 V	3.0	3.3	3.6	V
VIO	I/O supply voltage 1.8 V/3.3 V	1.65	1.8	1.95	V
		3.0	3.3	3.6	V
T _A	Ambient operating temperature	- 40	-	+ 95	°C
Ripple Noise	Peak-to-peak voltage ripple on 3V3 supply lines	-	-	175	mV
	Peak-to-peak voltage ripple on 5V0 supply lines.			125	mV

Table 3: Operating conditions

Symbol	Description	Conditions	Typ	Max.	Unit
V _{IH}	Input high voltage		0.7*VIO ¹	VIO ¹	V
V _{IL}	Input low voltage		-0.3	0.6 ²	V
V _{HYS}	Input hysteresis		0.18	-	V
V _{OH}	Output high voltage	I _O max = 5 mA	VIO - 0.4	-	V
V _{OL}	Output low voltage	I _O max = -5 mA	-	0.4	V

Table 4: Digital pad ratings

¹ 1PPS pad always uses 1.8 V internally generated IO supply regardless of the VIO pad voltage.

² RSTn pad is internally pulled high to VIO voltage by 100k. During reset, it should be below 0.2 V.

2 Getting started

The basic steps to evaluate the VERA-P1 series modules using the EVK-VERA-P174 evaluation kit are provided below:

1. Make sure that jumpers are placed on the current measurement pin headers on the main board as shown in Figure 2. The jumpers for 5 V, 3.3 V, and 1.8 V supply must be placed on the power supply board to use the on-board voltage regulators. The jumper for VIO voltage selection on the power supply board is set to 3.3 V by default. See the description on the back of the board for the jumper locations.





Figure 2: Jumper locations on the main board

2. Place jumpers on Boot_0 and Boot_1 to select the USB DFU boot mode.
3. Connect two external 5.9 GHz antennas to the SMA antenna connectors of the VERA-P1 series module.

 Always make sure that the RF ports are properly terminated to a 50 Ω load such as an antenna, spectrum analyzer or 802.11p receiver. If you directly connect the RF ports of the two EVK-VERA-P174 evaluation kits, include a minimum attenuation of 50 dB, to avoid damage to the modules.

4. Connect a 9 – 28 V, 12 W power adapter to the 2.5 x 5.5 mm barrel power connector (\ominus — \oplus) on the power supply board. The power and reset LEDs will be on.
5. Connect the micro USB connector on the power supply board to a host processor or a PC. The USB LED will be on.
6. Follow the quick start instructions in section 4.1 to build the Linux driver and applications for the VERA-P1 series modules and download the firmware to the VERA-P1 series module.

3 Board description

This section describes the EVK-VERA-P174 evaluation board, the available connectors, and configuration settings.

3.1 Block diagram

Figure 3 shows a general block diagram of the evaluation board.




Figure 3: Block diagram of the EVK-VERA-P174 evaluation board

3.2 Overview

Table 5 lists the available connectors on the upper main board of the EVK-VERA-P174 and their functions. Table 6 lists the available connectors on the lower power supply board of the EVK-VERA-P174 and their functions.

3.2.1 Main board




Figure 4: EVK-VERA-P1 Main board assembly overview

Designator	Connector	Description
J112	Bootstrapping	Jumpers to select the VERA-P1 boot mode
J105	SPI	SPI interface connector
J108	1PPS	Jumper and connector for the internal or external 1PPS signal
J109	3V3 current measure	Pin header to measure current on 3V3 rail
J110	VIO current measure	Pin header to measure current on VIO rail
J111	5V current measure	Pin header to measure current on 5V rail
J102	ANT1	SMA connector for antenna 1 of VERA-P1
J103	ANT2	SMA connector for antenna 2 of VERA-P1
J113	SPI CS	Jumper to configure SPI chip select routing between VERA-P1, SPI flash, and host
J104	GNSS antenna	SMA connector for the GNSS antenna
J106	GNSS connector	Connector for GNSS UART/1PPS signals
J101	Host interface connector	Board-to-board connector to the power supply board

Table 5: EVK-VERA-P174 Main board connector description

3.2.2 USB and power supply board




Figure 5: USB Power supply board assembly overview

Designator	Connector	Description
J1	Main supply	2.5 x 5.5 mm barrel connector for 9 – 28 V power supply Connect jumpers J7, J8, J9 and J10 before using
J8	Jumper for 5 V supply	Disconnect to use external 5 V supply on J5
J7	Jumper for 3.3 V supply	Disconnect to use external 3.3 V supply on J4
J5	External 5 V supply	Connector for external 5 V supply
J4	External 3.3 V supply	Connector for external 3.3 V supply
J10	VIO select	Jumper to select VIO voltage 1.8 V or 3.3 V
J9	Jumper for 1.8 V supply	Disconnect to use external 1.8 V supply on J6
J6	External 1.8 V supply	Connector for external 1.8 V supply
J2	Micro USB	USB interface connector
J3	Host interface connector	Board-to-board connector to the main board

Table 6: EVK-VERA-P174 Power supply board connector description

3.3 Connectors

3.3.1 Power supply and configuration

The VERA-P1 module is supplied with 3.3 V, 5 V, and a VIO that can be either 3.3 V or 1.8 V. Power supply for the evaluation board is provided through a DC power jack connector (J1) with an input voltage of 9-28 V.

All supply voltages can be generated from the on-board DC-DC converters and LDO regulators or supplied externally via the connectors J5 (5 V), J4 (3.3 V) and J6 (1.8 V) of the power supply board. Disconnect the jumpers J8, J7 or J9 on the power supply board to use the external power supply connectors. The VIO voltage for the VERA-P1 module can be selected with jumper J10 on the power supply board between 1.8 V and 3.3 V.

Individual current consumption on the 3.3 V, 5 V, and VIO rails of the VERA-P1 module can be measured with the respective pin headers J109, J111, and J110 on the main board.

3.3.2 USB interface

The USB host communication for the VERA-P1 module is provided through the micro USB connector J2 on the power supply board. The connector J2 is connected to a USB 2.0 hub on the power supply board, which connects the USB port to the following downstream devices:

- The USB interface of the VERA-P1 module on the main board
- The u-blox NEO-M8U GNSS module on the main board via a USB-to-UART bridge (FT234XD-T)
- The SPI interface of the VERA-P1 module or on-board SPI flash on the main board via a USB-to-SPI bridge (FT2232H port A)

3.3.3 Bootstrapping

The bootstrapping jumper J112 on the main board is used to select the boot mode of the VERA-P1 module. The valid bootstrap options are listed in Table 7. To set a logic level 0, connect the boot pin with a jumper to GND. Leave the pin open for logic level 1.

Boot mode	Boot 2	Boot 1	Boot 0	Description
SPI master	1	1	0	VERA-P1 acts as an SPI master and automatically downloads a bootloader or firmware from an SPI flash.
SPI slave	1	0	1	Firmware download is under the control of an external SPI master. VERA-P1 acts as SPI slave.
USB-DFU	1	0	0	USB Device Firmware Upgrade (DFU) boot mode. The VERA-P1 module presents itself on the USB bus as a DFU device for downloading the SDR firmware.

Table 7: Boot mode configuration

The EVK-VERA-P174 contains an on-board SPI flash to support the SPI master boot option. See section 3.3.5 for further configuration of the SPI chip select routing options.

3.3.4 SPI interface

The SPI interface connector J105 on the main board can be used to connect to the SPI interface of the VERA-P1 module or the on-board SPI flash. The SPI chip select jumpers are used to select either the VERA-P1 module or the SPI flash.

Pin No.	Assignment
1	SPI data MISO
2	VIO
3	SPI clock
4	SPI data MOSI
5	SPI chip select
6	GND

3.3.5 SPI chip select

The EVK-VERA-P174 contains an 8 Mbit SPI flash (SST25VF080B), which can be used to store the radio firmware or a different bootloader for the VERA-P1 module. The SPI chip select pin header (J113) on the main board is used to configure the routing of the SPI chip select signal between the VERA-P1, host, and SPI flash. Table 8 shows the possible configurations:

SPI CS routing	Jumper settings ³ (J113)	Description
Host to flash via USB	2 (1-3)	Used to program the flash from the host over USB. The SPI flash is accessible via the USB interface on the power supply board. A USB-to-SPI bridge (FT2232H) connects the SPI flash to the USB.
Host to flash via J105	2 (1-3), 4 (5-6)	Used to program the flash from the host directly over SPI. The SPI flash is accessible via the SPI interface connector or the host interface connector. Jumper on 5-6 is used to disable the USB-to-SPI bridge.
VERA-P1 to flash	1 (1-2), 4 (5-6)	Used to connect VERA-P1 to the SPI flash for firmware or bootloader download, when boot mode “SPI master” is selected (see 3.3.3).
Host to VERA-P1 via J105	3 (2-4), 4 (5-6)	Used to connect VERA-P1 to the host over SPI, when boot mode “SPI slave” is selected (see 3.3.3). The VERA-P1 SPI interface is accessible via the SPI interface connector or the host interface connector.

Table 8: SPI Chip select configuration

3.3.6 1PPS interface

A 1PPS UTC reference signal is required by the IEEE1609.4 MAC inside the module to align transmissions during channel switching and timekeeping. The 1PPS pin header J108 on the main board can be used to connect the 1PPS signal from the on-board NEO-M8U GNSS receiver to the 1PPS signal input of the VERA-P1 module.

Place a jumper on pins 1 and 2 of the 1PPS pin header to connect the 1PPS signal from the NEO-M8U GNSS module to the VERA-P1 module. The Pin 2 (VERA-P1 1PPS) and 3 (GND) can be used to connect a 1PPS signal from an external GNSS to the VERA-P1 module. The signal level for the external 1PPS can be in the range from 1.8 – 5 V and is converted to 1.8 V via a level shifter.

3.3.7 GNSS interface

The signals of the GNSS UART and 1PPS signal are available on the connector J106.

³ Italic number is the designation as printed on the EVK


Pin No.	Pin name	Type	Level	Description
5	VIO2	Power	VIO	VIO voltage
7	GND	Ground		
10	1PPS	I/O	I: 1.8 - 5.5 V O: 3.3 V	1PPS signal output from GNSS (J108 1-2) or input to VERA-P1 (J108 2-3)
11	NEO_UART_RX	I	0 - 3.3 V	GNSS UART RX
12	NEO_UART_TX	O	3.3 V	GNSS UART TX
13	GND	Ground		

3.3.8 SMA connectors

The EVK-VERA-P174 includes two SMA connectors, ANT1 (J102) and ANT2 (J103), which are used to connect external antennas or measurement instruments to the antenna pins of the VERA-P1 module.

A third SMA connector (J104) is included to connect an active antenna to the on-board NEO-M8U GNSS module.

The SMA connectors on the EVK are specified for RF signals up to 18 GHz.

 Always ensure that the RF ports of the VERA-P1 module are properly terminated to a 50 Ω load such as an antenna, spectrum analyzer, or 802.11p receiver. If you directly connect the RF ports of two EVK-VERA-P174 evaluation kits, include a minimum attenuation of 50 dB, to avoid damage to the modules.

3.3.9 Host interface connector

The host interface connector is used in the EVK to connect the VERA-P1 main board to the power supply and USB interface board. Additionally, it can be used to connect the VERA-P1 main board directly to a compatible host board. The connector on the main board is a QMS-052-0675-L-D-PC4 and the counterpart on the power supply board is a QFS-052-0675-L-D-PC4.

3.4 LEDs

Table 9 lists the available LEDs on the EVK-VERA-P174:

Name	Designator	Location	Function
Power	LED1	Power supply board	Indicates 3.3 V supply (LED on)
USB	LED2	Power supply board	Indicates USB connection to the host (LED on)
Reset	LED103	Main board, near pin 1 of VERA-P1	Indicates VERA-P1 module in reset (LED off)
1PPS	LED102	Main board	Indicates 1PPS signal (LED blinking)
Firmware	LED101	Main board	Indicates firmware loaded (LED on) through current measurement


Table 9: LED Description

3.5 Buttons

The reset button on the main board (S101) resets the VERA-P1 module. The button on the power supply board (S1) is used to reset the on-board power supply for the EVK.

3.6 Design files

The schematics for the EVK-VERA-P174 are shown in Figure 6 and Figure 7. Full design files are also available via u-blox support. To obtain these documents, send an email to the support team email address for your area, as listed in the Contact section.






Figure 7: Schematic of the VERA-P1 main board, page 2/2




Figure 8: Schematic of the power supply board, page 1/2




Figure 9: Schematic of the power supply board, page 2/2

4 Software

A standalone software package for the VERA-P1 modules called “LLC Remote” is available through u-blox support. The “LLC Remote” software package contains the following:

- A firmware image that has to be downloaded to the module on system start
- A driver, which is placed between the bus driver and network layer of the V2X stack
- Various test tools and example applications
- Precompiled executables to run on a Linux x86 PC

The LLC driver and part of the tools are provided as source code. The SDR firmware and LLC driver is developed by Cohda Wireless Pty, as a subcontractor of NXP Semiconductors N.V. The release process of the firmware binary and the associated LLC Remote driver implementation is combined with the major release of the Cohda MKx Software Development Kit⁴ and the version numbering of the LLC Remote package follows the numbering of the Cohda SDK.

A release notes document with quick start instructions for compiling the software is available with each software package. Recipes for integrating the software package into Yocto-based projects can be provided by u-blox on request.

To evaluate the VERA-P1 series module, the EVK-VERA-P174 can be connected via USB to a native Linux PC or a virtual machine running Linux. For this user guide, a virtual machine running Ubuntu 18.04 LTS with Linux kernel 4.15.0-23-generic (x86_64) has been used.

4.1 Quick start instructions

Copy the LLC Remote package archive into the target Linux development environment. Extract the package content and change to the extracted directory.

```
$ tar -xzf V2X_LLC_Remote_V15.0.0.tar.gz
$ cd llc-remote
```


Run the *install.sh* script once in a new development environment to automatically install the package dependencies. The script requires system privileges and an active Internet connection for downloading the packages. The main dependencies of the LLC Remote package are:

- dfu-util, for downloading the radio firmware to the module in USB DFU boot mode
- linux-headers, for building the LLC remote driver
- bison, flex, for building the included libpcap library used by the LLC user-space library

```
$ sudo ./install.sh
```

The next step is to run *make* to build the whole software package:

```
$ make
```

 If the make process fails because of a missing *pcap* library, run the following command to create the missing symbolic link to the library and then run *make* again:

```
$ ln -sr bsp/app/libpcap/${uname -m}/libpcap.a cohda/app/llc/lib/
```

This will compile and install the following parts:

- cw-llc driver for the active running Linux kernel
- LLC user-space library libLLC.so

⁴ A full SDK supporting IEEE 1609 and ETSI ITS software stacks is available from Cohda Wireless.

- LLC user-space tool and plugins⁵

The LLC user-space tool, plugins and library will be installed to the `./bin` subdirectory and the `cw-llc` driver will be copied to the `./drivers/<kernel_version>` subdirectory.

Connect the EVK-VERA-P174 evaluation kit to the PC and connect the USB device to the virtual machine, if required. The VERA-P1 module enumerates itself on the USB as “NXP SAF510x DFU” device with the USB device ID 1fc9:0102, which can be checked using the `lsusb` command:

```
$ lsusb
Bus 001 Device 002: ID 1fc9:0102 NXP Semiconductors
```

Run the `load` script to detect the VERA-P1 module and download the radio firmware through USB via the Device Firmware Update (DFU) protocol, if required. If prompted for a firmware, select option 2 to download the `SDRMK5Dual.bin` for evaluation of VERA-P174 or option 4 to select `SDRMK5Single.bin` for evaluation of VERA-P173.

```
$ ./load
Load SAF5X00 firmware via DFU-util
** NOTE: dfu-util may fail under VMWare; you may need to unplug your board after
download and restart ./load **
1] DFUBootLoader.bin
2] SDRMK5Dual.bin
3] SDRMK5DualSPI.bin
4] SDRMK5Single.bin
Select file to download (1-4): 2
Using firmware file images/SDRMK5Dual.bin
[sudo] password for user:
dfu-util 0.9
```

```
Copyright 2005-2009 Weston Schmidt, Harald Welte and OpenMoko Inc.
Copyright 2010-2016 Tormod Volden and Stefan Schmidt
This program is Free Software and has ABSOLUTELY NO WARRANTY
Please report bugs to http://sourceforge.net/p/dfu-util/tickets/
```

```
dfu-util: Invalid DFU suffix signature
dfu-util: A valid DFU suffix will be required in a future dfu-util release!!!
Deducing device DFU version from functional descriptor length
Opening DFU capable USB device...
ID 1fc9:0102
Run-time device DFU version 0100
[...]
DFU mode device DFU version 0100
Device returned transfer size 4096
Copying data from PC to DFU device
Download [=====] 100% 436316 bytes
Download done.
state(8) = dfuMANIFEST-WAIT-RESET, status(0) = No error condition is present
Done!
dfu-util: can't detach
Resetting USB to switch back to runtime mode
```

In case of a virtual machine environment, repeat to run the `load` script until the `cw-llc` driver module is loaded. As the USB device changes roles after firmware download, ensure that the new 802.11p radio device with the USB device ID 1fc9:0103 is automatically connected to the virtual machine.

Once the device is properly detected, the `load` script will display an output as shown below:

```
$ ./load
0
```

⁵ LLC plugins for channel configuration, sending, and receiving packets are provided as source code. Other plugins are provided as binary only.

```
Echo loading cw-llc module for kernel 4.15.0-23-generic_x86_64
cw_llc          143360  0
1
LLC 4
```



Kernel crashes have been observed in some cases when loading the driver on systems where NetworkManager is running. In such a case, either stop the NetworkManager before loading the driver via

```
sudo systemctl stop NetworkManager.service
```

or configure it to ignore the LLC IPv6 interfaces by adding the following lines to

```
/etc/NetworkManager/NetworkManager.conf:
```

```
[keyfile]
```

```
unmanaged-devices=interface-name:llc-*
```

Then, restart the NetworkManager service via

```
sudo systemctl restart NetworkManager.service
```

Execute the “llc version” command to check the connection to the module and to verify the firmware version:

```
$ ./bin/llc version
WISPA Variant      : TEF5200
WISPA Version      : 0x0
PCB Version        : 2
PCB Load           : 1
Boot Pins          : 0xc
SDR Firmware       : 69189
SDR Revision Date  : 2018-01-22 12:14
SDR Build Date     : 2018-01-22 12:15
Security Accel.    : No
Antenna Mask       : 3
Radio B Present    : 1
Last Reset Source  : External (36, 1024)
Last Reset Source  : External (53, 1024)
Last Reset Source  : External (54, 1024)
```



The llc tool and plugins require the shared library - *libLLC* so that it can be located by the run-time linker. This is set up during the make process by calling *ldconfig* with the library path and could be overwritten during system startup. In this case, *ldconfig* must be called manually again:

```
$ sudo ldconfig $(realpath ./bin)
```

4.2 Module calibration

The EVK-VERA-P174 modules do not contain valid calibration settings. The calibration must be performed manually, by executing llc commands after each power cycle and loading of the firmware.

The instruction for loading the calibration parameters and calibration files for the EVK-VERA-P174 modules are provided in the VERA-P1 series system integration manual [2].

4.3 Usage examples


After loading the firmware and the LLC driver, basic tests can be performed using the LLC tool and the provided plugins. The LLC tool and plugins are installed in the *./bin* subdirectory. A list of the available commands or plugins can be obtained by running the following command:

```
$ ./llc -c
```

Some basic plugins and their purpose are described in Table 10.

Plugin	Description
count	Displays the transmit and receive counters for both radios
config	Displays the configuration (mode/antenna/freq) of both radios
txqueue	Displays the state of the Tx MAC, together with the counts of all of the queues
status	Displays the instantaneous status of the radio, including the number of packets that are queued and also the state of the medium
cfg	Command to read or write the current RadioConfig data, as stored in the baseband
version	Reports the version details of the SDR firmware image
dmesg	Displays the debug print messages of the ARM/VDSP1/VDSP2 processor
rxphylast	Displays details of the last received frames by the PHY
txphylast	Displays details of the last transmitted frames by the PHY
chconfig	Sets the channel configuration for both radios
test-tx	Generates and transmits test packets
test-rx	Receives test packets

Table 10: Description of LLC plugins


 The source code for the chconfig, test-rx and test-tx plugins is provided in the *cohda/app/llc/plugin/simtdapi* subdirectory.

Instructions on how to use the individual commands are printed with the “--help” option.

```
$ ./llc <command-name> --help
```

4.3.1 Transmit and receive counters

Use the command “llc count” to print out transmit and receive counters for both the radios as shown below.

 This command can be used to easily verify the access to the module.

```
$ ./llc count
```

	RadA	Ch0	RadA	Ch1	RadB	Ch0	RadB	Ch1
Tx MAC Unconfigured Frames		0		0		282		0
Tx MAC Failed Enqueue		0		0		0		0
Tx MAC Broadcast Enqueued Frames	5331		0		3		0	
Tx MAC Broadcast Success Frames	5331		0		2		0	
Tx MAC Broadcast Failed TTL	0		0		0		0	
Tx MAC Broadcast Retired Frames	5331		0		2		0	
Tx MAC Unicast Enqueued Frames	0		0		0		0	
Tx MAC Unicast RTS/CTS Enq Frame	0		0		0		0	
Tx MAC Unicast Success Frames	0		0		0		0	
Tx MAC Unicast Failed Retry	0		0		0		0	
Tx MAC Unicast Failed TTL	0		0		0		0	
Tx MAC Unicast Retired Frames	0		0		0		0	
Tx MAC Unicast Retry Frames	0		0		0		0	
Tx MAC Unicast Ack Frames	0		0		0		0	
Tx MAC Unicast RTS Frames	0		0		0		0	
Tx MAC Unicast CTS Frames	0		0		0		0	
Tx PHY Frames	5332		0		3		0	
Tx PHY Aborted Frames	2		0		0		0	
Tx PHY Aborted Resp (Ack/CTS/..)	0		0		0		0	
Rx PHY AGC Firings	0		0		0		0	
Rx PHY Acquisitions	0		2765		0		0	
Rx PHY Failed SF	0		2		0		0	
Rx PHY Valid SF Frames	0		2763		0		0	
Rx MAC Failed FCS	0		0		0		0	
Rx MAC Valid Matched RTS Frames	0		0		0		0	
Rx MAC Valid Unmatched RTS Frame	0		0		0		0	

Rx MAC Valid Matched CTS Frames	0	0	0	0
Rx MAC Valid Unmatched CTS Frame	0	0	0	0
Rx MAC Valid Data Frames	0	2763	0	0
Rx MAC Valid Matched Ack Frames	0	0	0	0
Rx MAC Valid Unmatched Ack Frame	0	0	0	0
Rx MAC Valid Matched Late Ack Fr	0	0	0	0
Rx MAC Broadcast Frames	0	2763	0	0
Rx MAC Address Matched Frames	0	0	0	0
Rx MAC Address Dropped Frames	0	0	0	0
Rx MAC Buffer Overflow Frames	0	0	0	0
Rx MAC Duplicate Frames	0	0	0	0
Rx MAC USB Transferred Frames	0	2763	0	0
Rx MAC USB Callbacks	2763	0	0	0
CS Active Firings	2	2751	0	0
CS Idle Firings	2	40	0	0
CCA Active Firings	0	51	0	0
CCA Idle Firings	0	2765	0	0
Rx Frame Firings	0	2765	0	0

4.3.2 Channel configuration

Two different channel configurations are available per radio on the VERA-P1, which can be configured by using the *chconfig* LLC plugin via the Control Channel (CCH) or Service Channel (SCH). The plugin uses the LLC Remote API to set up, start, stop, or get the CCH/SCH configurations.

The following example configures and starts the control channel (radio channel configuration 0) on radio A, channel 184, using both the antennas:

```
$ ./llc chconfig -s -w CCH -c 184 -r a -a 3
Interface:          wave-raw
Channel: CCH
Radio: A
ChannelNumber:  184
DefaultMCS:     10
DefaultTxPower: 40
DefaultTRC:     0
DefaultTPC:     0
Bandwidth:      10
DualTxControl:  0
ChannelUtilisationPeriod: 49
TxAntenna:      3
RxAntenna:      3
MACAddr: 04:e5:48:00:10:00
Filter:         0x88b5
MAC Address: 04:e5:48:00:10:00
```

4.3.3 Transmitter test

The *test-tx* LLC plugin is used to transmit a burst of packets. The CCH or SCH must be configured prior to transmitting a burst and their settings define the default configuration for the packets.

The following example transmits 100 test packets of 200 bytes length on channel 184 and both antennas, with the output power set to 40 and modulation set to ½ QPSK:

```
$ ./llc test-tx -c 184 -p 40 -a 3 -m MK2MCS_R12QPSK -n 100 -l 200
Mode:          CREATE
Number Of Packets: 100
Target Packet Rate: 10.00
Priority: 4
Service: 1
MCS[0]: 10
NMCS: 1
```


```

TxPwrCtrl: 0
TxPower: 40
TxAntenna[0]: 3
NTxAnt: 1
Expiry: 0
PayloadLength[0]: 200
Destination MAC Address: ff:ff:ff:ff:ff:ff
EtherType: 0x88b5
ChannelNumber:      184
PayloadMode:        increment
Source MAC Address: 04:e5:48:00:10:00
Packet Log File:
DumpPayload:        0
DumpToStdout:        0
Interface:           wave-raw
Tx: Last SeqNum:      10 [/100]. Packet rate: Current      9.6, Target      10.0
Tx: Last SeqNum:      20 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      30 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      40 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      50 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      60 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      70 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      80 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:      90 [/100]. Packet rate: Current      10.0, Target      10.0
Tx: Last SeqNum:     100 [/100]. Packet rate: Current      9.8, Target      10.0

```

4.3.4 Receiver test

The *test-rx* command is used to receive test packets sent by another module via the *test-tx* command. The receiving application periodically informs about the number of received packets, the calculated packet error rate and also dumps per packet and statistics logs. The receive test should be running before starting the transmission to receive all the packets.

 The LLC driver supports only one VERA-P1 module connected to the host system. In order to test packet transmission with two modules, two host PCs or virtual machines must be used in parallel.

The following example sets the channel configuration and starts to receive and transmit test packets between two different VERA-P1 modules:

On the receiving side:

```

$ ./llc chconfig -s -w CCH -c 184
$ ./llc test-rx -c 184

```

On the transmitting side, sends 1000 packets at a rate of 100 packets per second:

```

$ ./llc chconfig -s -w CCH -c 184
$ ./llc test-tx -c 184 -a1 -p30 -n1000 -r100

```

The output on the receiver will look like the following:

```

Packet Log File:
Report File:      RxReport.txt
LogUnMatched:     0
DumpPayload:      0
DumpToStdout:      0
ReportPeriod:     100
Filter SA: None
Interface:        wave-raw
ChannelNumber:    184
Rx: Report [Last SeqNum: -1 (0xffffffff)]
Rx:   Approx PER: -nan% [Missed: 0, Payload Error: 0 / Tx: 0] (264.6% [-67108864, -
1975612572 / -772014096)
Rx:   Un/Matched Frames: 0/0

```

```

      Total      0      0
Rx: Report [Last SeqNum: 100 (0x00000064)]
Rx:  Approx PER: 0.0% [Missed: 0, Payload Error: 0 / Tx: 101] (0.0% [0, 0 / 100])
Rx:  Un/Matched Frames: 0/101
Rx:  Channel 184: 00000101 Matched Packets.
# MCS  Len    Matched Payload Err
   11  104      101          0
   Total    101          0

[...]

Rx: Report [Last SeqNum: 999 (0x000003e7)]
Rx:  Approx PER: 0.0% [Missed: 0, Payload Error: 0 / Tx: 1000] (0.0% [0, 0 / 99])
Rx:  Un/Matched Frames: 0/1000
Rx:  Channel 184: 00001000 Matched Packets.
# MCS  Len    Matched Payload Err
   11  104     1000          0
   Total    1000          0


```

4.3.5 LLC native IPv6 functionality

Native IPv6 functionality using the Linux IPv6 stack is supported in the LLC driver since release 15. The driver creates two network interfaces - `llc-cch-ipv6` and `llc-sch-ipv6`, which can be used for IPv6 communication between two or more VERA-P1 modules. The network interfaces, `llc-cch-ipv6` and `llc-sch-ipv6` map to the channel configuration 0 of radio A and radio B respectively. All communicating VERA-P1 modules must be configured to use the same DSRC channel.

The module option `IPv6Enabled=1` must be provided when the driver module is loaded to enable IPv6 support. The optional argument, `IPv6MCS` can be used to set the rate for transmitted IPv6 packets. The module options can be passed to the `load` script in the `./drivers` subdirectory, after using the top level load script to download the radio firmware:

```
$ cd drivers; ./load IPv6Enabled=1; cd -
```

 The Network Manager in the Linux host system should be deactivated, or the IPv6 configuration of the LLC IPv6 network interfaces should be set to Link-Local only and IPv4 should be disabled, in order to not interfere with the interface configuration.

The `chconfig` plugin is used to configure the DSRC channel on all VERA-P1 modules, for example to set the channel configuration 0 of radio A to channel 180 for communication using the `llc-cch-ipv6` network interface:

```
$ llc chconfig -s -w CCH -r a -c 180
```

The following commands are used to enable the `llc-cch-ipv6` network interface and to get the automatically assigned link-local IPv6 address:

```

$ ip link set llc-cch-ipv6 up
$ ip addr show llc-cch-ipv6
39: llc-cch-ipv6: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc noqueue state
UNKNOWN group default qlen 1000
    link/ether fa:8b:7f:64:0e:eb brd ff:ff:ff:ff:ff:ff
    inet6 fe80::8a8c:22ae:976d:cdde/64 scope link noprefixroute
        valid_lft forever preferred_lft forever

```

The IPv6 address can then be used to send an IPv6 ping request from another VERA-P1 module over the `llc-cch-ipv6` interface:

```
$ ping6 -I llc-cch-ipv6 fe80::8a8c:22ae:976d:cdde
```

The throughput over IPv6 between two VERA-P1 modules can be tested using the `iperf3` tool for example. To do this, start the `iperf3` server on one side:


```
$ iperf3 -s -D
```

Then start the throughput test on the client side and connect to the IPv6 address of the server:

```
$ iperf3 -6 -c fe80::8a8c:22ae:976d:cdde%llc-cch-ipv6
```

4.4 Building the software for a different target platform

Building the LLC Remote package for a different target system requires a toolchain and configured kernel sources for the target platform. The following example shows how to manually cross-compile the LLC driver and tools for an Arm® architecture using the *gcc-arm-linux-gnueabi* toolchain. The configured kernel sources should be available in the */home/duser/work/linux-3.10.107/* directory.

 Recipes for integrating the software package into Yocto-based projects can be provided by u-blox on request.

To cross-compile the LLC driver:

```
$ cd cohda/kernel/drivers/cohda/llc
$ make BOARD=mk5 ARCH=arm CROSS_COMPILE=arm-linux-gnueabi-
  KERNELDIR=/home/duser/work/linux-3.10.107/
```

To cross-compile the LLC tool, library, and plugins⁶:

```
$ cd cohda/app/llc
$ make BOARD=mk5 ARCH=arm CROSS_COMPILE=arm-linux-gnueabi- CC=arm-linux-gnueabi-gcc
  LD=arm-linux-gnueabi-ld
```

After successful compilation, the following files must be deployed on the target system:

- cohda/app/llc/llc – LLC tool
- cohda/app/llc/lib/libLLC.so* – LLC library
- cohda/app/llc/plugin/*.so – LLC plugins (to plugin subdirectory)
- cohda/kernel/drivers/cohda/llc/cw-llc.ko – LLC kernel module
- cohda/kernel/drivers/cohda/llc/SDRMK5*.bin – SDR firmware images

The *dfu-util* tool is required on the target system to download the SDR firmware to the VERA-P1 module.

⁶ Not all plugins are provided as source code. The Binary plugins are available only for i686, x86-64 and mk5 (Arm) architectures.

Appendix


A Glossary

Abbreviation	Definition
1PPS	1 Pulse Per Second
API	Application Programming Interface
CMOS	Complementary Metal-Oxide-Semiconductor
DFU	Device Firmware Upgrade
DSRC	Dedicated Short Range Communication
ETSI	European Telecommunications Standards Institute
EVB	Evaluation Board
EVK	Evaluation Kit
IEEE	Institute of Electrical and Electronics Engineers
ITS	Intelligent Transport Systems
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
MAC	Medium Access Control
LLC	Logical Link Control
OS	Operating System
PC	Personal Computer
PHY	Physical Layer
QPSK	Quadrature Phase-Shift Keying
RF	Radio Frequency
SDK	Software Development Kit
SDR	Software Defined Radio
USB	Universal Serial Bus
UTC	Coordinated Universal Time
V2X	Vehicle-to-Everything

Table 11: Explanation of the abbreviations and terms used

Related documents

- [1] VERA-P1 series data sheet, UBX-17004377
- [2] VERA-P1 series system integration manual, UBX-17006502
- [3] CohdaMobility MKx Radio LLCremote API Specification, CWD-MKx-0208

 For regular updates to u-blox documentation and to receive product change notifications, register on our homepage (www.u-blox.com).

Revision history

Revision	Date	Name	Comments
R01	24-Aug-2017	mzes, shoe, kgom	Initial release.
R02	20-Oct-2017	mzes, kgom	Removed references to VERA-P175.
R03	25-Apr-2018	shoe	Fixed a typo in the calibration command in section 4.2.
R04	22-Jun-2018	mzes, kgom	Updated for Rev B of the evaluation board. Removed references to VERA-P171.
R05	20-Jul-2018	mzes	Updated calibration sequence in section 4.2. Added iperf3 instructions in section 4.3.5.
R06	17-Apr-2019	mzes	Included a note with respect to Kernel crashes and workaround in section 4.1. Removed references to Hardware Security Module (HSM) from NXP.
R07	9-Jul-2019	mzes	Modified the size of the barrel connector in section 2 (step 4) and section 3.2.2 (first row in Table 6).
R08	6-Nov-2020	mzes	Replaced calibration instructions in section 4.2 with a reference to the SIM.

Contact

For complete contact information, visit us at www.u-blox.com.

u-blox Offices

North, Central and South America

u-blox America, Inc.

Phone: +1 703 483 3180

E-mail: info_us@u-blox.com

Regional Office West Coast:

Phone: +1 408 573 3640

E-mail: info_us@u-blox.com

Technical Support:

Phone: +1 703 483 3185

E-mail: support@u-blox.com

Headquarters

Europe, Middle East, Africa

u-blox AG

Phone: +41 44 722 74 44

E-mail: info@u-blox.com

Support: support@u-blox.com

Asia, Australia, Pacific

u-blox Singapore Pte. Ltd.

Phone: +65 6734 3811

E-mail: info_ap@u-blox.com

Support: support_ap@u-blox.com

Regional Office Australia:

Phone: +61 2 8448 2016

E-mail: info_au@u-blox.com

Support: support_ap@u-blox.com

Regional Office China (Beijing):

Phone: +86 10 68 133 545

E-mail: info_cn@u-blox.com

Support: support_cn@u-blox.com

Regional Office China (Chongqing):

Phone: +86 23 6815 1588

E-mail: info_cn@u-blox.com

Support: support_cn@u-blox.com

Regional Office China (Shanghai):

Phone: +86 21 6090 4832

E-mail: info_cn@u-blox.com

Support: support_cn@u-blox.com

Regional Office China (Shenzhen):

Phone: +86 755 8627 1083

E-mail: info_cn@u-blox.com

Support: support_cn@u-blox.com

Regional Office India:

Phone: +91 80 405 092 00

E-mail: info_in@u-blox.com

Support: support_in@u-blox.com

Regional Office Japan (Osaka):

Phone: +81 6 6941 3660

E-mail: info_jp@u-blox.com

Support: support_jp@u-blox.com

Regional Office Japan (Tokyo):

Phone: +81 3 5775 3850

E-mail: info_jp@u-blox.com

Support: support_jp@u-blox.com

Regional Office Korea:

Phone: +82 2 542 0861

E-mail: info_kr@u-blox.com

Support: support_kr@u-blox.com

Regional Office Taiwan:

Phone: +886 2 2657 1090

E-mail: info_tw@u-blox.com

Support: support_tw@u-blox.com