

MGate 5121 Series User Manual

Version 1.1, January 2025

www.moxa.com/products



© 2025 Moxa Inc. All rights reserved.

MGate 5121 Series User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2025 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Table of Contents

1. Introduction	4
2. Getting Started	5
Connecting the Power	5
Connecting CAN Devices	5
Connecting to a Network	5
Installing DSU Software.....	5
Log In to the Web Console.....	6
microSD	6
3. Web Console Configuration and Troubleshooting	8
System Dashboard.....	8
System Settings	9
System Settings—General Settings.....	9
System Settings—Network Settings	11
System Settings—SNMP Settings.....	12
Protocol Settings	15
Protocol Settings—Protocol Conversion	15
Protocol Settings—CANopen Master Settings.....	16
Protocol Settings—J1939 Settings	24
Protocol Settings—CAN Proprietary Settings	27
Protocol Settings—Modbus TCP Server Settings.....	37
Protocol Settings—SNMP Mapping Settings	39
Diagnostics	40
Diagnostics—Protocol Diagnostics.....	40
Diagnostics—Protocol Traffic	44
Diagnostics—Event Log	45
Diagnostics—Tag View	50
Diagnostics—Network Connections	51
Diagnostics—Ping	51
Diagnostics—LLDP	52
Security.....	53
Security—Account Management	53
Security—Service	56
Security—Allowlist	57
Security—DoS Defense	57
Security—Login Policy	58
Security—Certificate Management	59
Maintenance	60
Maintenance—Configuration Import/Export.....	60
Maintenance—Firmware Upgrade.....	61
Maintenance—Load Factory Default	61
Restart.....	62
Status Monitoring	62
4. Network Management Tool (MXstudio).....	64
A. SNMP Agents with MIB II	65
RFC1213 MIB-II Supported SNMP Variables	65

1. Introduction

The MGate 5121 is an industrial Ethernet gateway for converting CANopen, J1939 or CAN proprietary (CAN 2.0A/B) to Modbus TCP and SNMP network communications. To integrate existing CAN-based devices into a Modbus TCP or SNMP network, use the MGate 5121 as a CAN master to collect data and exchange data with the Modbus TCP host or SNMP client. All models are protected by a rugged and compact metal housing and are DIN-rail mountable. The rugged design is suitable for industrial applications such as factory automation and other process automation industries.



NOTE

CAN proprietary (CAN 2.0 A/B) is supported in firmware version V2.0 and later.

2. Getting Started

Connecting the Power

The unit can be powered by connecting a power source to the terminal block:

1. Connect the 12 to 48 VDC power line or DIN-rail power supply to the MGate's power terminal block.
2. Tighten the screws on both sides of the terminal block.
3. Turn on the power source.

Note that the unit does not have an on/off switch. It automatically turns on when it receives power. The PWR LED on the top panel will glow to show that the unit is receiving power. For power terminal block pin assignments, refer to the *Quick Installation Guide*, **Power Input and Relay Output Pinout** section.

Connecting CAN Devices

The MGate supports CAN devices. Before connecting or removing the serial connection, first make sure the power is turned off. For the CAN port pin assignments, refer to the *Quick Installation Guide*, **Pin Assignments** section.

Connecting to a Network

Connect one end of the Ethernet cable to the MGate's 10/100M Ethernet port and the other end of the cable to the Ethernet network. The MGate will show a valid connection to the Ethernet in the following ways:

- The Ethernet LED maintains a solid green color when connected to a 100 Mbps Ethernet network.
- The Ethernet LED maintains a solid orange color when connected to a 10 Mbps Ethernet network.
- The Ethernet LED will flash when Ethernet packets are being transmitted or received.

Installing DSU Software

If you do not know the MGate gateway's IP address when setting it up for the first time (default IP is 192.168.127.254); use an Ethernet cable to connect the host PC and MGate gateway directly. If you connect the gateway and host PC through the same Ethernet switch, make sure there is no router between them. You can then use the **Device Search Utility (DSU)** to detect the MGate gateways on your network. You can download DSU (Device Search Utility) from Moxa's website: www.moxa.com.


The following instructions explain how to install the DSU, a utility to search for MGate units on a network.

1. Locate and run the following setup program to begin the installation process:

This version might be named **dsu_setup_Ver2.x_Build_xxxxxxx.exe**

2. The Welcome window will greet you. Click **Next** to continue.
3. When the **Select Destination Location** window appears, click **Next** to continue. You may change the destination directory by first clicking on **Browse....**
4. When the **Select Additional Tasks** window appears, click **Next** to continue. You may select **Create a desktop icon** if you would like a shortcut to the DSU on your desktop.
5. Click **Install** to copy the software files.
6. A progress bar will appear. The procedure should take only a few seconds to complete.
7. A message will show the DSU has been successfully installed. You may choose to run it immediately by selecting **Launch DSU**.
8. You may also open the DSU through **Start > Programs > MOXA > DSU**.

The DSU window should appear as shown below. Click **Search** and a new Search window will pop up.



Log In to the Web Console

Use the Web console to configure the MGate through Ethernet or verify the MGate's status. Use a web browser, such as Google Chrome to connect to the MGate, using the HTTPS protocol.

When the MGate gateway appears on the DSU device list, select the gateway and right-click the mouse button to open a web console to configure the gateway.

On the login page, create an account name and set a password that is at least eight characters long when you log in for the first time. Or if you have already an account, log in with your account name and password. If you change the MGate's IP and other related network settings, click **SAVE**, and the MGate will reboot.



microSD

The MGate provides users with an easy way to back up, copy, replace, or deploy. The MGate is equipped with a microSD card slot. Users can plug in a microSD card to back up data, including the system configuration settings.

First time use of a new microSD card with the MGate gateway

1. Format the microSD card as FAT file system through a PC.
2. Power off the MGate and insert the microSD card (ensure that the microSD card is empty).
3. Power on the MGate. The default settings will be copied to the microSD card.
4. Manually configure the MGate via web console, and all the stored changes will copy to the microSD card for synchronization.

First time use of a microSD card containing a configuration file with the MGate gateway

1. Power off the MGate and insert the microSD card.
2. Power on the MGate.
3. The configuration file stored in the microSD card will automatically copy to the MGate.

Duplicating current configurations to another MGate gateway

1. Power off the MGate and insert a new microSD card.
2. Power on the MGate.
3. The configuration will be copied from the MGate to the microSD card.
4. Power off the MGate and insert the microSD card into the other MGate.
5. Power on the second MGate.
6. The configuration file stored in the microSD card will automatically copy to the MGate.

Malfunctioning MGate replacement



1. Replace the malfunctioning MGate with a new MGate.
2. Insert the microSD card into the new MGate.
3. Power on the MGate.
4. The configuration file stored on the microSD card will automatically copy to the MGate.

microSD card writing failure

The following circumstances may cause the microSD card to experience a writing failure:

1. The microSD card has less than 256 Mbytes of free space remaining.
2. The microSD card is write-protected.
3. The file system is corrupted.
4. The microSD card is damaged.


In case of the above events, the MGate will flash Ready LED in red color. When you replace the MGate gateway's microSD card, the microSD card will synchronize the configurations stored on the MGate gateway. Note that the replacement microSD card should not contain any configuration files on it; otherwise, the out-of-date configuration will be copied to the MGate device.



System Settings

System Settings—General Settings

On this page, you can change the name of the device and time settings.



System Settings

Parameter	Value	Description
Host Name	Alphanumeric string	Enter a name that can help you uniquely identify the device. For example, you can include the name and function of the device.
Description	Alphanumeric string	(optional) You can include additional description about the device such as function and location.

Time Settings

The MGate has a built-in real-time clock for time-calibration functions. Functions such as logs use the real-time clock to add the timestamp to messages.



ATTENTION

First-time users should select the time zone first. The console will display the actual time in your time zone relative to the GMT. If you would like to change the real-time clock, select Local time. MGate's firmware will change the GMT time according to the Time Zone setting.

General Setting

[Home](#) > General Setting

System Time

Current date and time: July 4, 2022 at 18:29:23

Timezone
(GMT+08:00)Taipei

Daylight saving time
☒ Enable ☐ Disabled

Start

Month: 3 Week: 5 Day: 0 Hour: 1

End

Month: 10 Week: 5 Day: 0 Hour: 1

Offset
+00:00

Sync Mode
☒ Manual ☐ Auto

sync with browser

Date
2022/07/04

Hour: 18 Minute: 28 Second: 19

SAVE

Parameter	Value	Description
Time zone	User-selectable time zone	Shows the current time zone selected and allows change to a different time zone.
Daylight saving time	Enable Disable	Enables daylight saving time to automatically adjust the time according to the region.
Sync Mode	Manual	Use this setting to manually adjust the time (1900/1/1-2037/12/31) or sync with the browser time
	Auto	Specify the IP or domain of the time server to sync with (E.g., 192.168.1.1 or time.stdtime.gov.tw). This optional field specifies the IP address or domain name of the time server on your network. The module supports SNTP (RFC-1769) for automatic time calibration. The MGate will request the time information from the specified time server per the set configured time.

System Settings—Network Settings

Change the IP Configuration, IP Address, Netmask, Default Gateway, and DNS settings on the **Network Settings** page.

Network Setting

[Home](#) > [Network Setting](#)

LAN Mode

Switch ☒

LAN 1 IP Configuration

☐ DHCP ☒ Static

IP Address

10.128.4.44

Netmask

255.255.255.0

Gateway

10.128.4.1

DNS Servers

Preferred DNS Server

10.168.1.25

Alternative DNS Server

10.168.1.24

SAVE

Parameter	Value	Description
LAN Mode	Switch, Dual IP, Redundant LAN	The Switch mode allows users to install the device with daisy-chain topology. The Dual IP mode allows the gateway to have two different IP addresses, each with distinct netmask and gateway settings. The IP addresses can have the same MAC address. The Redundant LAN mode allows users to use the same IP address on both Ethernet ports. The default active LAN port is ETH1 after bootup. If the active LAN link is down, the device will automatically switch to the backup LAN ETH2.
IP Configuration	DHCP, Static IP	Select Static IP if you are using a fixed IP address. Select the DHCP option if you want the IP address to be dynamically assigned.
IP Address	192.168.127.254 (or other 32-bit number)	The IP Address identifies the server on the TCP/IP network.

Parameter	Value	Description
Netmask	255.255.255.0 (or other 32-bit number)	Identifies the server as belonging to a Class A, B, or C network.
Gateway	0.0.0.0 (or other 32-bit number)	The IP address of the router that provides network access outside the server's LAN.
Preferred DNS Server	0.0.0.0 (or other 32-bit number)	The IP address of the primary domain name server.
Alternative DNS Server	0.0.0.0 (or other 32-bit number)	The IP address of the secondary domain name server.


System Settings—SNMP Settings

System Settings—SNMP Settings—SNMP Agent

Parameters	Description
Version	The SNMP version; the MGate supports SNMP v1, v2c, and v3.
Contact	The optional contact information; it usually includes an emergency contact name and telephone number.
Location	The location information. This string is usually set to the street address where the MGate is physically located.
Read-only Community	A text password mechanism that is used to weakly authenticate queries to agents of managed network devices. Default is empty. Type in the community string when selecting v1 v2c or v1 v2c v3 version.
Read/Write Community	A text password mechanism that is used to weakly authenticate changes to agents of managed network devices. Default is empty. Type in the community string when selecting v1 v2c or v1 v2c v3 version.
Minimum Authentication/Privacy Password Length	Minimum Authentication/Privacy Password Length must be between 8 and 64.

Read-only and Read/Write Access Control

You can define usernames, passwords, and authentication parameters in SNMP for two levels of access control: read-only and read/write. The access level is shown in the value of the Authority field. For example, Read-only authentication mode allows you to configure the authentication mode for read-only access, whereas Read/Write authentication mode allows you to configure the authentication mode for read/write access. For each level of access, you may configure the following:



Create SNMPv3 Account

Account Name

Authority
Read Only

Authentication type
Disable

CANCEL SAVE

Parameters	Value	Description
Account Name		The username for which the access level is being defined.
Authority	Read Only Read/Write	The level of access allowed
Authentication Type	Disable MD5 SHA1 SHA-224 SHA-256 SHA-384 SHA-512	Use this field to select MD5 or SHA as the method of password encryption for the specified level of access, or to disable authentication.
Privacy Type	Disable (Default) DES-CBC AES-128	Use this field to enable or disable data encryption for the specified level of access. If you enable a privacy type, also configure the privacy password.

If you need to change the SNMP Account settings created previously, click on the button on the right of the configured SNMP item to change settings, such as Authentication Type or Privacy Type.

Home > SNMP Agent

SNMP Agent

General SNMPv3 Account SNMPv3 Account Protection

☒ Disable SNMPv3 account if authentication failed

Min. Authentication Failures

5

☒ Enable timeout for authentication failure

Each Authentication Failure Timeout (min)

10

Account Disabled Time Interval (min)

10

SAVE

Parameters	Value	Description
Max Authentication Failure	1 to 10 (default 5)	Specifies the maximum number of authentication failures. The MGate will disable SNMPv3 if this number is exceeded.
Each Authentication Failure Timeout (min.)	1 to 1440 (default 10)	Specifies a timeout period when enabling the Timeout for authentication failure function
Account Disabled Time Interval (min.)	1 to 60 (default 10)	When the number of authentication failures exceeds the value set in Max Authentication Failure Times , the MGate will disable the SNMPv3 for Account Disabled Time Interval.

System Settings—SNMP Settings—SNMP Trap

Home > SNMP Trap

SNMP Trap

General SNMP Trap Server

Trap Service

☒ Active ☐ Inactive

SAVE

Set up the SNMP trap server to send the trap events, such as warning messages.

Home > SNMP Trap


SNMP Trap

General SNMP Trap Server

+ CREATE

maximum number of trap server is 2

Server IP	Port	Trap Version	Community	Account Name	Authentication Type	Privacy Type
192.168.3.4	4442	Disable	-	-	-	-



The 'Create Trap Server' window is divided into two sections. The 'General Setting' section contains two text input fields: 'Server IP' and 'Port'. The 'Trap Method' section contains a dropdown menu for 'Trap Version' with 'Disable' selected. At the bottom right are 'CANCEL' and 'SAVE' buttons.

Parameters	Description
Server IP	SNMP server IP address or domain name; the maximum number of trap servers is 2
Port	SNMP server IP Port.
Trap Version	Disable SNMPv1 SNMPv2c SNMPv3

Protocol Settings

Protocol Settings—Protocol Conversion

You can select CANopen, J1939, or CAN proprietary on this page.




The 'Protocol Conversion' window shows a central diagram of a device with various ports. Above the device, there are two tabs: 'Modbus TCP Client' and 'SNMP Client'. Below the device, there is a 'Modbus TCP Server' tab. At the bottom, there is a 'Page Setting' section with a 'Modbus Slave' tab and a 'Save' button.

Click **Edit** at the “Edge Device” right-hand side and select your device protocol roles.



The dialog box is titled "Edit Protocol Conversion". It contains two dropdown menus. The first dropdown, labeled "Role of MGate 5121_5122222", has "CANopen Master" selected. The second dropdown, labeled "Edge Device", has "CANopen Slave" selected. At the bottom right, there are two buttons: "CANCEL" and "SAVE".


Click **SAVE** then **APPLY** on the warning pop-up window.



The dialog box is titled "Apply Protocol Conversion". It contains the following text: "Applying configuration will override current settings and restart the application in a few seconds. Are you sure you want to apply?". At the bottom right, there are two buttons: "CANCEL" and "APPLY".

Protocol Settings—CANopen Master Settings

Manage CANopen devices on this page.




The screenshot shows the "CANopen Master" settings page. On the left is a sidebar menu with options: "System Dashboard", "SYSTEM SETTINGS", "General Settings", "Network Settings", "SNMP Settings", "PROTOCOL SETTINGS", "Protocol Conversion", "Ethernet/IP Adapter", "CANopen Master" (highlighted), "SNMP Mapping", and "SWATCHES". The main content area is titled "CANopen Master" and contains three sections: "CANopen Master" with a "CANopen Master" button, "CANopen" with a "Master" dropdown set to "T-plant", and "EDS Management" with an "EDS Repository" dropdown set to "T-Rep".

Manage CANopen slave device EDS files in “EDS Management-EDS Repository”. The MGate can store up to 64 different EDS files. Click Import to add the EDS file. Tick the item and delete it.



Parameter	Description
Vendor	Vendor name
Product Name	Product name
Vendor ID	Vendor ID registered in CiA organization
Revision	EDS file revision
EDS file	EDS file name
RxPDOs	Supports number of RxPDO
TxPDOs	Supports number of TxPDO

Click CANopen-Master to config CANopen master and slave settings.




Master Settings

Parameter	Value	Default	Description
Node ID	1 to 127	1	Master CANopen Node ID
Baudrate	10 kbit/s 20 kbit/s 50 kbit/s 125 kbit/s 250 kbit/s 500 kbit/s 800 kbit/s 1 Mbit/s	125 kbit/s	Set CANopen network baudrate
Initial Delay (ms)	0 to 120000	0	For those CAN devices that need longer time to boot up, the MGate needs to wait until the device is ready for communication. Set the initial delay time to wait for the device to boot up.

Parameter	Value	Default	Description
CAN Bus-OFF Reset	Disable Enable	Disable	When the MGate detects that the error count exceeds the CAN threshold, the CAN bus will switch to Bus Off mode according to the CAN definition. Enable will auto reset the error count and restart the bus. Disable will stay in the Bus Off mode and only recover by re-powering the MGate.
CAN bus Termination Resistor 120 ohms	Disable Enable	Disable	
SYNC- SYNC Producer	Disable Enable	Enable	Enable the MGate to send out the SYNC signal based on the interval time.
SYNC-Counter	Disable Enable	Enable	Enable to include SYNC counter information in the SYNC message. Counter is a 2 bytes value from 0 to 65535 with rolling over behavior.
SYNC-COB ID	0x0000 to 0xFFFF	0x0080	Standard SYNC COB ID is 0x0080
SYNC-Interval(ms)	0 to 65535	1000	Interval time for the SYNC message.
Time-Time Producer	Disable Enable	Enable	Enable the MGate to send out the TIME stamp message. TIME is a 6 bytes value with UAT format.
Time-COB ID	0x0000 to 0xFFFF	0x0100	Standard TIME COB ID is 0x0100
Time-Interval (ms)	0 to 65535	1000	Interval time for the TIME message.

MGate CANopen master supports up to 256 TPDO and up to 256 RPDO. Click ADD to edit PDO with slave PDO COB ID. For example, if you want to mapping slave ID 2's RPDO4 to MGate TPDO1, type in COB ID 0x0502 in the CANopen master TPDO1. If you want to mapping slave ID2's TPDO1 to CANopen master RPDO2, type in COB ID 0x0182 in RPDO2.



Parameter	Value	Default	Description
Transmission Type	Sync, RTR, Event	Sync	<p>For TPDO:</p> <p>Sync. The MGate will send out TPDO following by the number of SYNC reached, which is set in the No. of SYNCs.</p> <p>RTR. The MGate will send out TPDO when received RTR bit ON in the slave RPDO, which COB ID is set in the previous setting.</p> <p>Event. The MGate will send out TPDO cyclic according to the Event Timer(ms). If the Event time is 0, then TPDO will send out when data changed. To use CAN bus loading efficiently, set the Inhibit Time(ms) to avoid sending TPDO too frequently.</p> <p>For RPDO:</p> <p>Sync. The MGate will update the slave TPDO data into internal memory only when the SYNC message occurred.</p> <p>Event. The MGate updates the slave TPDO data into internal memory when received from the slave TPDO.</p>
No. of SYNCs (for Sync Type)	0 to 240	0	No. of SYNC messages. Value from 0 to 240.
Inhibit Time (ms) (for Event Type))	0 to 65535	0	This can be used to set a time that must wait after the sending of a PDO
Event Timer (ms)	0 to 65535	0	This time can be used to trigger an event, which handles the sending of the PDO.
Fault Protection	Pause Proceed-Clear data to zero Proceed – Set to User Defined Value	Pause	<p>Pause: The gateway will write the same data to the slave device.</p> <p>Proceed—Clear data to zero: The gateway will write zero values to the slave device.</p> <p>Proceed—Set to User Defined Value: A user-defined value will be written to the slave device.</p>
Fault Timeout (ms)	100 to 65535	60000	Defines the communication timeout for the opposite side.
Bit Position	Automatic generated		Bit offset in the PDO data frame
Object index	Customer Object index/sub-index		User can Add customer object or add quickly with index/sub-index from slave EDS parameter.
Data Type	1 to 7 Bit 1 to 8 Byte	1 Bit	Tag data type
Tag Name	Alphanumeric string		Create Tag names. User can select tags in the northbound protocol setting.
Endian Swap	None Byte swap Reverse Reverse with byte swap	None	<p>Swapping the data. The item may change with different tag type or length for raw data type.</p> <p>None: No swap</p> <p>Byte swap: Switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x22 11 44 33 66 55 88 77</p> <p>Reverse: Reverse the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x88 77 66 55 44 33 22 11</p> <p>Reverse with byte swap: Reverse the order of bytes first, then switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x77 88 55 66 33 44 11 22</p>

CANopen COB ID table

Communication Object	Function Code (4 bit, binary)	Node ID (dec)	COB ID (hex)
NMT	0000	0	0x000
SYNC	0001	0	0x080
EMCY	0001	1 to 127	0x081 to 0x0FF
TIME	0010	0	0x100
T_PDO 1	0011	1 to 127	0x181 to 1FF
R_PDO 1	0100	1 to 127	0x201 to 27F
T_PDO 2	0101	1 to 127	0x281 to 2FF
R_PDO 2	0110	1 to 127	0x301 to 37F
T_PDO 3	0111	1 to 127	0x381 to 3FF
R_PDO 3	1000	1 to 127	0x401 to 47F
T_PDO 4	1001	1 to 127	0x481 to 4FF
R_PDO 4	1010	1 to 127	0x501 to 57F
T_SDO	1011	1 to 127	0x581 to 5FF
R_SDO	1100	1 to 127	0x601 to 67F
Heartbeat	1110	1 to 127	0x701 to 77F

Add CANopen slave device into Slave Setting.



You can ADD the slave device manually or SCAN the devices on the CAN bus. Import slave EDS files before adding or scanning the slave devices.

Click the ADD button and select the slave device from the EDS repository.



Or click the SCAN button to scan the device on the CAN bus. Only the slave device that matches the EDS file in the EDS Repository will be added to the table.

Scan Slave Setting

STOP

1 (1/1)

Radio Switch

<input checked="" type="checkbox"/> Disabled	Heartbeat	Node ID	Device Name	Device ID	Device
--	-----------	---------	-------------	-----------	--------

C

CANCEL

ADD

Click the pen icon to edit the slave Node ID and Device Name. Enable the **Enable device parameters initialization** setting. The MGate will send SDO requests to set the slave’s communication parameters when CANopen bus is ready. Select **Heartbeat** to retrieve the slave’s status and set **Master Heartbeat Consuming Timeout** time for the CANopen slave parameter.

Edit Slave Setting

Node ID

1

Device Name

1

State Retrieval

Disabled

Disabled

Heartbeat

CANCEL

SAVE

Edit Slave Settings

Node ID

1

Device Name

1

☒ Enable device parameters initialization ⓘ

State Retrieval

Heartbeat

Master Heartbeat Consuming Timeout (ms)

1000

CANCEL

SAVE

Heartbeat tag view status

Home > Tag View

Tag View

🔍 Type to search...


REFRESH

Provider ⓘ	Source ⓘ	Name ⓘ	Type	Value	Timestamp	
canopen_master	1	status	int32	Invalid (0x00000000)	2023-04-21T08:54:01.385+08:00	
canopen_master	NMT	state	uint8	0x0000	2023-04-21T08:54:01.385+08:00	
canopen_master	RPDO1	RPDO1	uint64	0x000000000000400F	2023-04-20T18:15:58.295+08:00	
canopen_master	TPDO1	TPDO1	uint64	0x000000000000400F	2023-04-20T18:15:28.717+08:00	

If you would like to initialize or change parameters default value of slave device when CAN bus ID is ready to send SDOs. Click the Edit device parameters.



In the following window, you can see the default value from the EDS file, and you may type in the new value in the value column, and then click the SAVE button.




Protocol Settings—J1939 Settings

You can manage the J1939 protocol on this page.



Config J1939 settings in the **Device Settings** tab.



Parameter	Value	Default	Description
Network address	Numerical number	128 to 253	The MGate's network address in the J1939 bus
Device name	The parameters regarding to J1939.	FFFFFFFFFFFFFFF	A set of J1939 parameter combinations represented in hex value
Start output transmission by	Data update, startup	Data update	To determine the way the transmission starts

Parameter	Value	Default	Description
Endian swap	None Byte swap Reverse Reverse with byte swap	None	Swapping the data. The item may change with different tag type or length for raw data type. None: Don't need to swap Byte swap: Switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x22 11 44 33 66 55 88 77 Reverse: Reverse the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x88 77 66 55 44 33 22 11 Reverse with byte swap: Reverse the order of bytes first, then switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x77 88 55 66 33 44 11 22
CAN bus-off reset	Disable, Enable	Disable	When a J1939 bus error happens, the MGate will automatically stop communication with the J1939 bus. You may choose Enable to have the MGate rejoin the bus.
CAN bus termination resistor 120 ohms	Disable, Enable	Disable	To enable 120 ohms termination resistor on CAN bus.
Baudrate	250 kbps, 500 kbps, 1Mbps	250 kbps	The baudrate used in J1939

In the **I/O Table** tab, change the input/output commands of J1939. Click **ADD** to add the J1939 commands into the MGate, according to the J1939 device it is attached to.

Add I/O

Type
☒ Input ☐ Output

Name

Parameter Address(es)

CAN

Message offset

Data length

Tag

Input/output

CANCEL DONE

Home > J1939 > J1939 Settings

J1939 Settings

Device Settings IO Table

CLONE DELETE SEARCH ADD

Index	Type	Name	Network Address	PGN	Offset	Length	Priority	Trigger	Update Interval (ms)	
1	Input	Input256	128	256	0 (0, 0)	64 (0, 0)	-	Cyclic	0	
2	Output	Output256	128	256	0 (0, 0)	64 (0, 0)	6	Cyclic	10	
3	Input	Input512	128	512	0 (0, 0)	64 (0, 0)	-	Cyclic	0	
4	Output	Output512	128	512	0 (0, 0)	64 (0, 0)	6	Cyclic	10	
5	Input	Input768	128	768	0 (0, 0)	64 (0, 0)	-	Cyclic	0	
6	Output	Output768	128	768	0 (0, 0)	64 (0, 0)	6	Cyclic	10	
7	Input	Input1024	128	1024	0 (0, 0)	64 (0, 0)	-	Cyclic	0	
8	Output	Output1024	128	1024	0 (0, 0)	64 (0, 0)	6	Cyclic	10	

Parameter	Value	Default	Description
Type	Input, Output	Input	Data type
Name	(An alphanumeric string)	Command1	Max. 32 characters
Source Address	0 to 253, 255	0	Data from which J1939 device. Also listed as Network Address in the IO table.
Destination Address (for output)	0 to 253, 255	0	Data sent to which J1939 device. Also listed as Network Address in the IO table.
PGN	0 to 131071	0	Parameter Group Number
Message Offset	0 to 14279 bits	0 (0, 0)	The location where the data associated with the data point begins. The offset not only can be shown in bits but can be displayed as corresponding bytes and bits (byte, bit).
Data Length	0 to 14280 bits	0 (0, 0)	The length of the data to be transferred between the J1939 devices. The length not only can be shown in bits but also can be displayed as corresponding bytes and bits (byte, bit).
Trigger	Disable, Cyclic, Data Change	Cyclic	Disable: The command has never been sent Cyclic: The command is sent cyclically at the interval specified in the Poll Interval parameter. Data change: The data area is polled for changes at the time interval defined by Poll Interval. A command is issued when a change in data is detected.
Update interval	0 to 65535 ms	0	The desired update interval for the data in milliseconds.
Priority (for output)	0 to 7		Output PGN priority
Fault Protection (for output)	Pause Proceed—Clear data to zero Proceed—Set to User-defined Value	Keep Latest Data	Configure the criteria used to determine what to do when the write command is no longer received from the master side. For example, when a cable comes loose accidentally, the most up-to-date write command from the master side will not be received by the gateway. Pause: The gateway will write the same data to the slave device. Proceed—Clear data to zero: The gateway will write zero values to the slave device. Proceed—Set to User Defined Value: A user-defined value will be written to the slave device.


AutoScan:

For users' convenience, the MGate is designed with an innovative command auto-learning function. It can learn all the output commands from the J1939 devices in the same CAN bus. Users don't need to key in the commands one by one. All you have to do is click on the **SCAN** button, and a window will pop up. Click the Start button to learn. Click the pen icon at the right-hand side of the command to edit the command.

Whenever the commands are set, remember to click the APPLY button to save it.

Protocol Settings—CAN Proprietary Settings

Import or export offline excel CAN data frame configuration by clicking the IMPORT or EXPORT button on the right-hand side. Or, click CAN Port 1 to configure manually.



Click the EDIT button to set the CAN proprietary settings.



Select the CAN settings for CAN port 1. Click SAVE AS DRAFT button.

CAN Port 1 Settings

Frame Format:
☒ CAN 2.0A (11 bits CAN ID) ☐ CAN 2.0B (29 bits CAN ID)

Baudrate(kbit/s):
 125 kbit/s

Initial Delay(ms):
 0

☐ Enable CAN Bus-off Reset
☐ Enable CAN bus termination resistor (120 Ohms)

CANCEL SAVE AS DRAFT

CAN Port 1 Settings

Parameter	Value	Default	Description
Frame Format	CAN 2.0A CAN 2.0B	CAN 2.0A	According to your CAN proprietary device, select either CAN 2.0A or 2.0B CAN data frame format.
Baudrate(kbits/s)	10 kbit/s 20 kbit/s 50 kbit/s 125 kbit/s 250 kbit/s 500 kbit/s 800 kbit/s 1 Mbit/s	125 kbit/s	Set CANopen network baudrate
Initial Delay(ms)	0 to 120000	0	For some CAN devices which need longer boot up time, the MGate needs to wait until the device is ready for communication. Set the initial delay time to wait the device boot-up.
CAN Bus-OFF Reset	Disable Enable	Disable	When the MGate detects the error count exceeding the CAN threshold, the CAN bus will switch to Bus Off mode, according to the CAN definition. Enable will auto reset the error count and restart the bus. Disable will stay in the Bus Off mode and only recovers when re-powering the MGate.
CAN bus termination resistor 120 ohms	Disable Enable	Disable	Software configurable CAN bus termination resistor.

Click ADD DEVICE to add the CAN devices, type in a 1- to 64-character device name. Click SAVE AS DRAFT to save the configuration temporarily.

Add Device

Device Name
 Sensor

CANCEL SAVE AS DRAFT

Click ADD TRANSACTION button to select the CAN data frame type Produce, Consume, or Request/Response.



Follow a 3-step configuration for Produce Transaction, which the MGate will send CAN data to slave devices.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Produce Transaction

← Add Produce Transaction

1 Produce Settings 2 Frame Settings 3 Confirm

☒ Enable transaction

Transaction Name
produce!!

Trigger Mode
Cyclic

Cycle Interval(ms)
1000

Fault Protection
Proceed - Set to User-Defined Value

Info
Set the user-defined value in the data block under the frame settings in the next step.

Fault Timeout(ms)
60000

☐ Trigger by RTR
When receiving a remote transmission request (RTR) for a specific CAN-ID, it triggers the produce transaction.

← BACK CANCEL NEXT >

Parameter	Value	Default	Description
Transaction Name	(An alphanumeric string)		1 to 64 characters.
Trigger Mode	Cyclic Data Change Boot-up	Cyclic	Cyclic: The transaction is sent cyclically at the interval specified in the Cyclic Interval parameter. Data change: The transaction is sent when a change in data is detected. Boot-up: The transaction is sent once the CAN bus boots up
Cyclic Interval(ms)	10 to 65535	1000	The desired cyclic interval in milliseconds.
Fault Protection	Pause Proceed—Clear data to zero Proceed—Set to User Defined Value	Pause	Pause: The gateway will write the same data to the slave device. Proceed—Clear data to zero: The gateway will write zero values to the slave device. Proceed—Set to User Defined Value: A user-defined value will be written to the slave device.
Fault Timeout(ms)	100 to 65535	60000	Defines the communication timeout for the opposite side.
Tigger by RTR	Disable Enable	Disable	When receiving a remote transmission request (RTR) for a specific CAN-ID, it triggers the produce transaction.

In the Frame Settings, type the CAN-ID according to the CAN device user manual first. Then click ADD FUNCTION BLOCK to add Data blocks or Constant blocks.

Parameter	Value	Default	Description
Name	(An alphanumeric string)		1 to 64 characters
Tag Type	raw, int 8, int 16, int 32, int 64, uint 8, uint 16, uint 32, uint 64, float, double	raw	Tag data type
Length(byte)	1 to 8	1	The default length for raw type is 1. The value is fixed for other data type except raw type.
User-defined Value for Fault Protection (Hex)		00	Set the user-defined value in the data block when you activate Fault Protection in the Produce Settings step and select "Proceed—Set to User-defined Value"

Parameter	Value	Default	Description
Endian Swap	None Byte swap Reverse Reverse with byte swap	None	Swapping the data. The item may change with different tag type or length for raw data type. None: Don't need to swap Byte swap: Switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x22 11 44 33 66 55 88 77 Reverse: Reverse the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x88 77 66 55 44 33 22 11 Reverse with byte swap: Reverse the order of bytes first, then switch the order of bytes. 0x11 22 33 44 55 66 77 88 → 0x77 88 55 66 33 44 11 22

Add Constant Block

Name
Constant

Length(byte)
1

Value (0)
0x 00

CANCER
SAVE AS DRAFT

Parameter	Value	Default	Description
Name	(An alphanumeric string)		1 to 32 characters.
Length(byte)	1 to 8	1	Data length of constant value.
Value	0x0000000000000000 to 0xFFFFFFFFFFFFFFFF	0x0000000000000000	Set the constant value in Hex.

The configuration will be displayed below Frame Settings.

Add Produce Transaction

1 Produce Settings
2 Frame Settings
3 Confirm

Data ID
0x 0123

Data Field

ADD FUNCTION BLOCK

Byte Offset	Name	Function Block	Length(Byte)
0-1	data1	Data	2
2-5	data2	Data	4
6-7	Constant	Constant	2

BACK
CANCER
NEXT

Finally, confirm the transaction settings. Then, click SAVE AS DRAFT.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Produce Transaction

← Add Produce Transaction

1 Produce Settings — 2 Frame Settings — 3 Confirm

Produce Settings

Transaction Name: produce1
 Enable transaction: Enable
 Trigger Mode: Cyclic
 Cycle Interval(ms): 1000
 Fault Protection: Proceed - Set to User-Defined Value
 Fault Timeout(ms): 60000
 Trigger by RTR: Disable

Frame Settings

CAN-ID: 0x0123
 Frame Length(byte): 8

← BACK CANCEL **SAVE AS DRAFT**

Follow 3 steps configuration for Consume Transaction which MGate will receive data from CAN slave devices.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Consume Transaction

← Add Consume Transaction

1 Consume Settings — 2 Frame Settings — 3 Confirm

☒ Enable transaction

Transaction Name
consume1

☒ Consume Timeout
 If the consume transaction is not received within the timeout time, the device will be considered offline.

Timeout Time(ms)
10000

← BACK CANCEL **NEXT >**

Parameter	Value	Default	Description
Transaction Name	(An alphanumeric string)		1 to 64 characters.
Consume Timeout (ms)	10 to 65535	10000	The timeout value in milliseconds. If the consume transaction is not received within the timeout time, the device will be considered offline.

Type in the CAN-ID, according to the CAN device user manual. Click the ADD FUNCTION BLOCK button to add Data blocks or Constant blocks. The block setting is the same as the producer. Refer to the Produce Frame Settings' description.

The screenshot shows the 'Add Consume Transaction' screen with a breadcrumb trail: Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Consume Transaction. The title is 'Add Consume Transaction'. A progress bar at the top shows three steps: 1. Consume Settings (active), 2. Frame Settings, and 3. Confirm. Below the progress bar, the 'CAN-ID' is set to '0x0123'. A 'Data Field' section contains a table with columns: 'Byte Offset', 'Name', 'Function Block', and 'Length(byte)'. The table is empty, with a message below it: 'No data to display. Click "ADD FUNCTION BLOCK" to add one.' To the right of the table is a button 'ADD FUNCTION BLOCK' with a dropdown menu showing 'Data block' and 'Constant block'. At the bottom, there are three buttons: '< BACK', 'CANCEL', and 'NEXT >'.

Confirm the transaction settings. Click SAVE AS DRAFT.

The screenshot shows the 'Add Consume Transaction' screen with a breadcrumb trail: Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Consume Transaction. The title is 'Add Consume Transaction'. A progress bar at the top shows three steps: 1. Consume Settings, 2. Frame Settings (active), and 3. Confirm. Below the progress bar, the 'Consume Settings' section shows: Transaction Name: consume1, Enable transaction: Enable, Consume Timeout: Enable, and Timeout Time(ms): 10000. The 'Frame Settings' section shows: CAN-ID: 0x0123 and Frame Length(byte): 8. At the bottom, there are three buttons: '< BACK', 'CANCEL', and 'SAVE AS DRAFT'.

Regarding Request/Response Transaction, the MGate will send a request to the CAN device to query a data, and then wait for its response.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Request/response Transaction

← Add Request/Response Transaction

1 Request/Response Settings 2 Frame Settings 3 Confirm

☒ Enable transaction

Transaction Name
ReadData

Request Response

Trigger Mode
Cyclic

Cycle Interval(ms)
1000

Fault Protection
Proceed - Set to User-Defined Value

Info:
Set the user-defined value in the data block under the frame settings in the next step.

Fault Timeout(ms)
60000

Maximum retry(count) @
3

< BACK CANCEL NEXT >

Parameter	Value	Default	Description
Transaction Name	(An alphanumeric string)		1 to 64 characters.
Trigger Mode	Cyclic Data Change Boot-up	Cyclic	Cyclic: The transaction is sent cyclically at the interval specified in the Cyclic Interval parameter. Data change: The transaction is sent when a change in data is detected. Boot-up: The transaction is sent once the CAN bus boots up
Cyclic Interval (ms)	10 to 65535	1000	The desired cyclic interval in milliseconds.
Fault Protection	Pause Proceed—Clear data to zero Proceed—Set to User Defined Value	Pause	Pause: The gateway will write the same data to the slave device. Proceed—Clear data to zero: The gateway will write zero values to the slave device. Proceed—Set to User Defined Value: A user-defined value will be written to the slave device.
Fault Timeout (ms)	100 to 65535	60000	Defines the communication timeout on the opposite side.
Maximum retry (count)	0 to 5	0	The request retries counts when a timeout occurred without receiving a response. The response timeout value is set in Response tab.

Parameter	Value	Default	Description
Response Timeout (ms)	100 to 65535	1000	The desired response timeout value.

Here set the request and response frame settings according to the CAN device user manual, including the CAN-ID, Data blocks or Constant blocks. The block setting is the same as the producer. Refer to Produce Frame Settings' description.

Confirm the transaction settings. Then click **SAVE AS DRAFT**.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1 > Add Request/response Transaction

← Add Request/Response Transaction

1 Request/Response Settings 2 Frame Settings 3 Confirm

Request/Response Settings

Transaction Name: ReadData
Enable transaction: Enable

Request

Trigger Mode: Cyclic
Cycle interval(ms): 1000
Fault Protection: Proceed - Set to User-Defined Value
Fault Timeout(ms): 60000
Maximum retry(count): 5

Response

Response Timeout(ms): 1000

Frame Settings

Request

CAN-ID: 0x0123
Frame Length(byte): 8

Response

CAN-ID: 0x0001
Frame Length(byte): 8

← BACK CANCEL **SAVE AS DRAFT**

After all settings have been created, click the icon on the right-hand side of each transaction to edit, delete or clone it. Finally, click **APPLY** to activate all settings.

Home > CAN Proprietary > CAN Port Settings > CAN Port 1

← CAN Port 1

CAN Port 1
Name Format: CAN ID&PT&St&DA&CC
Reserve: 1/15 empty
More Information

ADD DEVICE Sensor **ADD TRANSACTION**

No.	Transaction Name	Status	Transaction Type	CAN-ID	Frame Length(byte)	
1	produce1	Enable	Produce	0x0123	8	
2	consume1	Enable	Consume	0x0123	8	
3	ReadData	Enable	Request Response	0x0123 0x0001	8	Edit produce settings Edit frame settings Clone Delete

Items per page: 10 1 - 3 of 3

DISCARD **APPLY**

Protocol Settings—Modbus TCP Server Settings

Configure the Modbus TCP server setting on this page. Click on the TCP button to edit the setting.



Click **EDIT** to adjust the Modbus TCP basic settings.



Edit TCP Settings

Server ID
1

Server Port
502

TCP Alive Check Time (min)
1

CANCEL SAVE

Parameter	Value	Default	Description
Server ID	1 to 255		The Modbus server ID that this slave module will accept.
Server Port	1 to 65535	502	The TCP port number.
TCP Alive Check Time (min)	0 to 99	1	The time to check TCP alive.

Add Tags for Modbus TCP. Notice that the tags must be created in CANopen master or J1939. Click **DONE** after selection. The selection sequence will also decide the sequence in the Modbus TCP register/coil address.

Add tags

Info

Select one or more tag providers to get their tags, and select tags to map data.

Providers

Search

SELECT ALL

CLEAR

☒ canopen_master

Total: 1

Selected: 1

DONE

Add Tags

Info

Select one or more tag providers to get their tags, and select tags to map data.

Providers

canopen_master

0 Tags

Search

SELECT ALL

CLEAR

☒ state

Total: 1

Selected: 1

DONE

The selected tags will display in the data mapping column by default with register/coil address. You may adjust it manually.

Data Mapping | 1 tag

Module Only (1)

Unit Only (0)

Unit Provider (0)

Modbus Register (0)


Modbus Coil (0)

15

ID	Provider	Item Type	Item Name	Item Address	Item Size	Item
1	canopen_master	coil	state	100000	1	100000 - 100000

Protocol Settings—SNMP Mapping Settings

You can manage CAN to SNMP mapping data on this page; for detailed SNMP protocol settings, go to the SNMP Trap Server page.



Home > SNMP Mapping > SNMP Setting

SNMP Setting

Data Mapping DELETE + ADD TAGS
The maximum number of tags is 1024

<input type="checkbox"/>	#	SNMP OID	Provider	Source	Name	
<input type="checkbox"/>	1	1.3.6.1.4.1.8881.21.3122.3.1.1.1	canopen_master	RPDO1	RPDO1	← →
<input type="checkbox"/>	2	1.3.6.1.4.1.8881.21.3122.3.1.1.2	canopen_master	TPDO1	TPDO1	← →
<input type="checkbox"/>	3	1.3.6.1.4.1.8881.21.3122.3.1.1.3	canopen_master	1	status	← →
<input type="checkbox"/>	4	1.3.6.1.4.1.8881.21.3122.3.1.1.4	canopen_master	100T	state	← →

Click **ADD TAGS** to add tags in the CAN settings.

Add tag

Info:
Select one or more tag providers to get their tags, and select tags to map data.

Providers
canopen_master ▼

1 Tags

Selected Tags
state ▼

CANCEL SAVE

The OID is defined as below:

OID	String	OID (string type)	Description
1.3.6.1.4.1.8691	moxa	1.3.6.1.4.1.8691	
1.3.6.1.4.1.8691.21	mgate	{moxa}.21	MGate Series
1.3.6.1.4.1.8691.21.5121	mgate5121	{mgate}.5121	Model name
1.3.6.1.4.1.8691.21.5121.1	swMgmt	{mgate5121}.1	SNMP management Information
1.3.6.1.4.1.8691.21.5121.2	trap	{mgate5121}.2	SNMP trap
1.3.6.1.4.1.8691.21.5121.3	mapping	{mgate5121}.3	SNMP mapping
1.3.6.1.4.1.8691.21.5121.3.1	tags	{mapping}.1	Tag mapping
1.3.6.1.4.1.8691.21.5121.3.1.1	array of values	{tags}.1	Tag value
1.3.6.1.4.1.8691.21.5121.3.1.2	array of names	{tags}.2	Tag name
1.3.6.1.4.1.8691.21.5121.3.1.1.x	value of array[x]	{array of values}.x	Index of tag value
1.3.6.1.4.1.8691.21.5121.3.1.2.x	name of array[x]	{array of names}.x	Index of tag name

Diagnostics

Diagnostics—Protocol Diagnostics

Diagnostics—Protocol Diagnostics—CANopen Diagnostics

Home > CANopen Diagnostics

CANopen Diagnostics

☒ Autorefresh

Overview
Slave Status

CAN Status

CLEAR

State : Error active
RX Count : 0
TX Count : 0
CRC Error : 0
Bit Error : 0
Stuff Error : 0
Bus-off Count : 0

CANopen Status


CLEAR

State : Operational
PDO RX Count : 0
PDO TX Count : 7/7
Hiro pkt Count : 0
SYNC pkt Count : 0
EMCY pkt Count : 0
Heart/State pkt Count : 0


In the Slave Status tab, check the detailed information regarding the slave status and change CANopen state machine at the right-hand side.




You can open the Object Parameter tab to check and change the slave device's CANopen object value.



Diagnostics—Protocol Diagnostics—J1939 Diagnostics



The Live List function allows you to check how many live devices are on the same network.



Diagnostics—Protocol Diagnostics—CAN Proprietary Diagnostics

Home > CAN Proprietary Diagnostics

CAN Proprietary Diagnostics

☒ Auto Refresh

CAN Port 1

CAN Status

State	Error active
RX Count	0
TX Count	11
CRC Error	0
Bit Error	0
Stuff Error	0
Bus-off Count	0
Bus Loading	0%

Transaction Status

Device List
Sensor

Transaction List

Transaction Name	State	Failed Count
produce1	Failed	670095
consume1	Timeout	2
ReadData	Failed	670097

Diagnostics—Protocol Diagnostics—Modbus TCP Diagnostics

Home > Modbus TCP Diagnostics

Modbus TCP Diagnostics

☒ Auto Refresh

Modbus

Mode	Server
Number of connections	0
Valid requests received	0
Invalid requests received	0
Sent responses	0
Sent exceptions	0

Connections

No data

Diagnostics—Protocol Traffic

Diagnostics—Protocol Traffic—CANopen Traffic

Click **START** to start traffic log.

Home > CANopen Traffic

CANopen Traffic

STOP Capturing...

Auto Scroll

Type ALL

Node ID

EXPORT TEST

No.	Time	Tx/Rx	Node ID	Type	COB ID	Description	Data
1	0.752	Tx	2	RPDO1	0x0202	Receive PDO 1	00 00 00 00 00 00 00 00
2	0.762	Rx	2	TPDO1	0x0182	Transmit PDO 1	00 00 00 00 00 00 00 00
3	1.753	Tx	2	RPDO1	0x0202	Receive PDO 1	00 00 00 00 00 00 00 00
4	1.763	Rx	2	TPDO1	0x0182	Transmit PDO 1	00 00 00 00 00 00 00 00
5	2.758	Tx	2	RPDO1	0x0202	Receive PDO 1	00 00 00 00 00 00 00 00
6	2.769	Rx	2	TPDO1	0x0182	Transmit PDO 1	00 00 00 00 00 00 00 00
7	3.752	Tx	2	RPDO1	0x0202	Receive PDO 1	00 00 00 00 00 00 00 00
8	3.762	Rx	2	TPDO1	0x0182	Transmit PDO 1	00 00 00 00 00 00 00 00
9	4.755	Tx	2	RPDO1	0x0202	Receive PDO 1	00 00 00 00 00 00 00 00
10	4.765	Rx	2	TPDO1	0x0182	Transmit PDO 1	00 00 00 00 00 00 00 00

You can also read/write CAN data manually by clicking the **TEST** button and type in the CAN data frame.

test

COB ID

0x 010

Data

0x01

0 for separate (e.g., 0x12,0x34,1N55)

Diagnostics—Protocol Traffic—J1939 Traffic

Click **START** to start J1939 traffic log.

Home > J1939 Traffic

J1939 Traffic

START Pausing capture

Auto Scroll

EXPORT

No.	Time	Card Identifier	Destination Address	Source Address	Priority	State	Value
No data to display							

Diagnostics—Protocol Traffic—CAN Proprietary Traffic

Home > Diagnostics > CAN Proprietary Traffic Log

CAN Proprietary Traffic Log

Start Stop Refresh

Auto Scroll

ID	Timestamp	Direction	Sub-ID	Size	Data Length/Byte	Hex Data
1	0:000	Reception	0x0100	8	8	00 00 00 00 00 00 00 00
2	0:000	Send	0x0200	8	8	00 00 01 00 01 00 01 00
3	0:000	Send	0x03 10	8	8	01 00 01 00 01 00 01 00
4	0:001	Send	0x03 00	8	8	01 00 01 00 01 00 01 00
5	0:001	Send	0x03 00	8	8	01 00 01 00 01 00 01 00
6	0:000	Send	0x02 00	8	8	01 00 01 00 01 00 01 00
7	0:000	Send	0x02 00	8	8	01 00 01 00 01 00 01 00
8	0:000	Send	0x02 00	8	8	01 00 01 00 01 00 01 00
9	0:001	Send	0x02 00	8	8	01 00 01 00 01 00 01 00

Diagnostics—Protocol Traffic—Modbus TCP Traffic

Click START to start Modbus TCP traffic log.

Home > Diagnostics > Modbus TCP Traffic Log

Modbus TCP Traffic Log

Start Stop Refresh

Auto Scroll

ID	Time	Size	Modbus Address	Modbus ID	Operation	Response ID	Response Length	Code
The table is empty.								

Diagnostics—Event Log

Diagnostics—Event Log—Log View

Review and export all event information in the event log.

Home > Event Log

Event Log

EXPORT CLEAR REFRESH

ID	Severity	Category	Event Name	Source	Message	Timestamp
1	Information	Security	Login success	admin 10.122.0.171	Account 'admin' login successfully	2022-07-08T09:00:52.627+08:00
2	Warning	Security	Clear event log	admin 10.122.0.171	Clear event log	2022-07-08T09:00:55.067+08:00


Items per page: 10 1-2 of 2 1 2 / 1 2

Diagnostics—Event Log—Policy Settings

The event policy settings enable the MGate to record important events, which can be recorded in the Remote Log to Syslog server and Local Log, which will be stored with up to 10,000 events in the MGate.


The MGate can also send email alerts, SNMP Trap messages, or open/close the circuit of the relay output when a selected event was triggered.

You can filter events for easy reading or expand by clicking the category, such as System. Tick or untick the events if you want to log it and select which channels you want to use by clicking the channel name. After changing the settings, remember to SAVE it.



Event Group	Description
System	Start system, User trigger reboot, Power input failure, NTP update failure
Network	IP conflict, DHCP get IP/renew, IP changed, Ethernet link down
Security	Clear event log, Login success, Login failure, Account/group changed, Password reached lifetime, SSL certificate import, Syslog certificate import
Maintenance	Firmware upgrade success, Firmware upgrade failure, Configuration import success, Configuration import failure, Configuration export, Configuration changed, Load factory default
Modbus client	Server connected, Server disconnected, Command recovered, Command fail
Modbus server	Client connected; Client disconnected; Exception function
EtherNet/IP	Adapter connected; Adapter disconnected
PROFINET	I/O Device is connected, I/O Device is disconnected, I/O Controller is running, I/O Controller has stopped
CANopen	Device status changed; CAN bus-off; slave initialization failed
J1939	CAN bus-off
CAN proprietary	CAN Error Passive, CAN bus-off, Transaction Success, Transaction Failed, Transaction Timeout

Local Log Settings



Local Log Setting

Event Log Overwrite Policy

☒ Overwrite the Oldest Event Log

☐ Stop Recording Event Log

☒ Log Capacity Warning

Capacity Threshold (%)

80


Warning By

☐ SNMP Trap ☐ Email

CANCEL SAVE

Local Log Settings	Description
Event Log Overwrite Policy	Overwrites the oldest event log Stops recording event log
Capacity Threshold (%)	When the log amount exceeds the warning
Warning By	SNMP Trap Email

Remote Log Settings



Remote Log Settings

Syslog Server 1

☒ Enable

TLS Authentication

☒ Enable

Upload TLS files to the bottom section

IP Address

Port

514

Syslog Server 2

☐ Enable

TLS Authentication

☐ Enable

IP Address

Port

514

TLS Authentication

Common Name	Start Time	Expiration Time
No data to display.		

Client Certificate

Choose File

No file chosen

Client Key

Choose File

No file chosen

CA Certificate

Choose File

No file chosen

UPLOAD

Remote Log Settings	Description
Syslog Server IP	IP address of a server that will record the log data
Syslog Server port	514
TLS Authentication	Enable TLS authentication. Notice TLS files must be uploaded for a successful connection.

SNMP Trap Settings

SNMP Trap Server

Trap Service

☒ Active

☐ Inactive

For advanced settings, please go to [SNMP Trap Server](#) page

CANCEL

SAVE

Email Settings

Email Setting

SMTP Service
Active

Primary Service

Mail Server (SMTP)	Port
10.123.7.18	25

Security Connection
None

☒ Require Authentication

Username

Password

From (Email address)
test1@10.123.7.18

To (Email addresses, separated by semicolon)
test1@10.123.7.18

CANCEL SAVE

Parameters	Description
Mail Server (SMTP)	The mail server's domain name or IP address.
Port	The mail server's IP port.
Security Connection	TLS STARTTLS STARTTLS-None None
Username	This field is for your mail server's username, if required.
Password	This field is for your mail server's password, if required.
From (Email address)	Email address from which automatic email warnings will be sent.
To (Email address, separated by semicolon)	Email addresses to which automatic email warnings will be sent.

Diagnostics—Tag View

This page displays the tag live value generated by field devices and updates the values periodically. It is an easy and useful tool if you want to check whether the MGate receives the correct data from field devices. The gateway timestamp shows the time data was updated to the tag. For example, when the CANopen_master NMT state showing the master current state, 0 means the master is in operational mode, 1 it is in preoperational mode, and 2 it is stop mode.

Tag View					
Provider	Source	Name	Type	Value	Timestamp
canopen_master	NMT	000	uint16	00000	2020-05-20T14:47:59.489+08:00
canopen_slave	RPDO1	02_1PDO1	uint32	0000000000000000	2020-05-20T14:48:04.000+08:00
canopen_slave	RPDO1	02_2PDO1	uint32	0000000000000000	2020-05-20T14:48:04.000+08:00

Write a value to the CAN device via Write value directly to test the communication with the CAN device.

Write value directly

Provider

canopen_master

Source

RPDO1

Name

02_1PDO1

Type

uint32

Value


0x 0000000000000000

CANCEL

SAVE

Diagnostics—Network Connections

You can see network-related information, including protocol, address, and state.




The screenshot shows the 'Network Connections' web console. At the top, there is a title 'Network Connections' and a breadcrumb 'Home > Network Connections'. Below the breadcrumb is a checkbox labeled 'Auto refresh' which is checked. The main content is a table with the following columns: Protocol,Recv Q,Send Q,Local Address,Foreign Address, and State. The table contains eight rows of data representing various network connections.

Protocol	Recv Q	Send Q	Local Address	Foreign Address	State
TCP	0	0	*.80	*.0	LISTEN
TCP	0	0	*.64818	*.0	LISTEN
TCP	0	0	*.22	*.0	LISTEN
TCP	0	0	*.443	*.0	LISTEN
TCP	34	0	10.125.0.64.55032	10.125.0.18.25	CLOSE_WAIT
TCP	0	0	10.123.0.44.443	10.123.0.171.50076	TIME_WAIT
TCP	0	255	10.125.0.64.443	10.122.0.171.55890	ESTABLISHED

Diagnostics—Ping

This network testing function is available only in the web console. The MGate gateway will send an ICMP packet through the network to a specified host, and the result can be viewed on the web console immediately.



The screenshot shows the 'Ping' web console. It has a title 'Ping' and a breadcrumb 'Home > Ping'. Below the breadcrumb is a label 'Ping Destination' followed by the text '192.168.1.27'. At the bottom of the form is a green button labeled 'ACTIVATE'.


Diagnostics—LLDP

You can see LLDP related information, including Port, Neighbor ID, Neighbor Port, Neigh Port Description, and Neighbor System. Also, you can adjust the transmit interval for LLDP by clicking the **EDIT** button.



The screenshot shows the 'LLDP' configuration page. At the top, there's a breadcrumb 'Home > LLDP'. Below it, the 'LLDP Configuration' section shows 'LLDP Service Disabled' with a 'Message Transmit Interval: 30 seconds' and an 'EDIT' button. The 'LLDP Table' section below it has a 'REFRESH' button and a table with columns: Interface, Neighbor ID, Neighbor Port, Neighbor Port Description, and Neighbor System. The table currently shows 'No Data'.

After clicking EDIT, if you need to enable or disable LLDP service. Click on the “Service” hyperlink or navigate to Security > Service page to enable or disable it.




The screenshot shows the 'LLDP Configuration' modal dialog. It has a title 'LLDP Configuration'. Under 'LLDP Service', there are two radio buttons: 'Enable' (unselected) and 'Disabled' (selected). Below this, a note says 'Note: enable/disable this service through [Service Enablement](#)'. There is a 'Message Transmit Interval (sec)' field with the value '30'. At the bottom, there are 'CANCEL' and 'SAVE' buttons.

Security


To secure your MGate, refer to the following security functions and configure it according to your requirements. We also provide a guideline of recommended steps as best practices for secure configurations in most applications. For this, refer to the Security Hardening Guide for the MGate 5000 Series.

Security—Account Management

Security—Account Management—Accounts



Only the Administrator group can create or edit accounts for user management. Click **CREATE** to add new accounts. Click the dot icon to edit the account.



Parameters	Value	Description
Group	Administrator, Operator, Guest	Users can change the password for different accounts. The MGate provides three built-in account groups: administrator, operator and guest. Administrator account can access all settings. Operator accounts can access most settings, except security categories. Guest account can only view the overview page. Create your own group for account management.

Security—Account Management—Groups



Three MGate built-in types of groups are shown; you can also create your own group by clicking **CREATE**.

The 'Create New Group' form contains the following sections and fields:

- Basic Information**
 - Name: [Text input field]
 - Description (optional): [Text area]
- Access Permissions**
 - System Configuration: [Read, Write, Execute, etc.]
 - Protocol setting: [Read, Write, Execute, etc.]
 - Diagnostic: [Read, Write, Execute, etc.]
 - Security: [No display, etc.]
 - Maintenance: [Read, Write, Execute, etc.]
 - Restart: [Read, Write, Execute, etc.]
- Buttons**
 - CANCEL
 - SAVE

Parameters	Value	Description
Basic Information		Includes Name and Description for the new Group.
Access Permissions	No display	Corresponding to the configuration menu on the left-hand side of the web console, you can select different permissions for a new group. Displays will not show the page on the right-hand side menu.
	Read only	
	Read write	

Security—Account Management—Password Policy

Password Policy

Home > Password Policy

Password Strength Setting

Password Minimum Length

8

Password Complexity Strength Check

☐ Select all password strength requirements

☐ At least one digit (0-9)

☐ Mixed upper and lower case letters (A-Z, a-z)

☐ At least one special character (~!@#\$%^&*_-+=\|'(){};:"'<>.,/?/)

Password Lifetime Setting

The password lifetime determines how long the password is effective. If password has expired, a popup message and event will notify user to change the password for security reasons.

☐ Enable password lifetime check


Password Lifetime (day)

90

SAVE

Parameter	Value	Description
Password Minimum Length	8 to 128	The minimum password length
Password Complexity Strength Check		Select how the MGate checks the password's strength
Password lifetime Setting	90 to 180 days	Set the password's lifetime period.

Security—Service



Parameter	Value	Description
HTTP Service	Enable/Disable	To enhance security, all HTTP requests will redirect to HTTPS when the HTTP service is enabled. You can also disable the HTTP service.
HTTPS Service	Enable/Disable	Disabling this service will disable the web console and search utility connections, thus cutting off access to the configuration settings. To re-enable the HTTPS communication, reset to the factory default settings via the hardware Reset button.
Ping Service	Enable/Disable	Disabling this service will block ping requests from other devices.
SD Card	Enable/Disable	Disabling this service will deactivate the SD card function for backup and restore configuration files.
SNMP Agent Service	Enable/Disable	Enable or disable SNMP agent function.
LLDP Service	Enable/Disable	Enable or disable LLDP function.
Reset button disable after 60 sec	Always enable and disable after 60 sec.	The MGate provides a Reset button to load factory default settings. For enhanced security, users can disable this function. In the disabled mode, the MGate will still enable the Reset button for 60 seconds after booting up, just in case you really need to reset the device.

Security—Allowlist

These settings are used to restrict access to the MGate by the IP address. Only IP addresses on the list will be allowed to access the device. Notice the restriction includes configuration and protocol conversion.

Allow List

Home > Allow List

☐ Activate the accessible IP list (All communications are NOT allowed for the IPs NOT on the list.)

No.	Active	IP	Netmask
1	<input type="checkbox"/>		
2	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>		
4	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>		

Security—DoS Defense

Users can select from several options to enable DoS Defense to fend off cybersecurity attacks. A denial-of-service (DoS) attack is an attempt to make a machine or a network resource unavailable. Users can select from the following options to counter DoS attacks.

DoS Defense

Home > DoS Defense

Configuration

☐ Null Scan

☐ NMAP-Xmas Scan

☐ SYN/TIN Scan

☐ FIN Scan

☐ NMAP-ID Scan

SYN-Flood

☐ Enable

Limit pkt/s

ICMP Flood

☐ Enable

Limit pkt/s

Security—Login Policy

Login Message

You can input a message for Login or for Login authentication failure messages.

The screenshot shows the 'Login Policy' configuration page with the 'Login Message' tab selected. It contains two text input fields. The first field is labeled 'Login Message - optional' and contains the text 'Hello'. The second field is labeled 'Login Authentication Failure Message' and contains the text 'The account or password you entered is incorrect.(Your account will be temporarily locked if excessive tried.)'. Both fields have a character count at the bottom right (5 / 256 and 110 / 256 respectively). A 'SAVE' button is at the bottom left.

Login Lockout

The screenshot shows the 'Login Policy' configuration page with the 'Login Lockout' tab selected. It features several settings: a checkbox for 'Enable Login Failure Lockout' which is unchecked; a 'Max Failure Retry Times' input field with the value '5'; another unchecked checkbox for 'Reset the Login Failure Counter' with a subtext explaining its function; a 'Reset Period (min)' input field with the value '10'; and a 'Lockout Time (min)' input field with the value '10'. A 'SAVE' button is located at the bottom left.

Parameter	Value	Description
Max Failure Retry Times	1 to 10 (default 5)	Specify the maximum number of failures retries, if exceed the retry times, MGate will lock out for that account login
Reset Period (min)	1 to 1440 (default 10)	Specify the reset period time when enabling the "reset the login failure counter" function
Lockout Time(min)	1 to 60 (default 10)	When the number of login failures exceeds the threshold, the MGate will lock out for a period.

Login Session

Login Policy
Home > Login Policy

Login Message Login Lockout Login Session

Maximum login user for HTTP+HTTPS
1

Auto logout setting (min)
1440

SAVE

Parameter	Value	Description
Maximum login users for HTTP+HTTPS	1 to 10 (default 5)	The number of users that can access the MGate simultaneously.
Auto logout setting (min)	1 to 1440 (default 1440)	Sets the auto logout period.

Security—Certificate Management

Use this function to load the Ethernet SSL certificate. Import or delete SSL certificate/key files. This function is only available for the web console.

Certificate Management
Home > Certificate Management

Configuration

Issue to 10.123.144
Issue by Moxa Inc.
Valid from 2022-6-2 to 2027-6-1

SSL

Select SSL Certificate **IMPORT**

Delete SSL Certificate **DELETE**

Maintenance

Maintenance—Configuration Import/Export

There are three main reasons for using the Import and Export functions:

- Applying the same configuration to multiple units. The Import/Export configuration function is a convenient way to apply the same settings to units in different sites. Export the configuration as a file and then import the configuration file onto other units.
- Backing up configurations for system recovery. The export function allows you to export configuration files that can be imported onto other gateways to restore malfunctioning systems within minutes.

Troubleshooting. Exported configuration files help administrators to identify system problems that provide useful information for Moxa's Technical Service Team when maintenance visits are requested.

For cybersecurity reasons, you can export configuration file with an authentication key, length from 8 to 16 characters. If the key to the imported configuration file differs from the key to the exported file, the import process will fail.

Home > Config. Import/Export

Config. Import/Export

Configuration File Authentication

Export configuration **EXPORT**

Import configuration ☐ Update network settings

Choose File No file chosen

IMPORT

Home > Config. Import/Export

Config. Import/Export

Configuration **File Authentication**

File authentication

☒ Enable ☐ Disable

File authentication key

SAVE

Maintenance—Firmware Upgrade

Firmware updates for the MGate are available on the Moxa website. After you have downloaded the new firmware onto your PC, you can use the web console to write it onto your MGate. Select the desired unit from the list in the web console and click **Submit** to begin the process.



ATTENTION

DO NOT turn off the MGate power before the firmware upgrade process is completed. The MGate will erase the old firmware to make room for the new firmware to flash memory. If you power off the MGate and end the progress, the flash memory will contain corrupted firmware, and the MGate cannot boot. If this happens, contact Moxa RMA services.

The screenshot shows the 'Firmware Upgrade' page in a web console. At the top, there is a breadcrumb 'Home > Firmware Upgrade'. The title 'Firmware Upgrade' is prominently displayed. Below the title, a warning message states: 'Upgrading firmware may cause device to reset to factory default. Back up the configuration of device.' There is a file selection area with a 'Choose File' button and the text 'No file chosen'. At the bottom of this area is a large green 'UPLOAD' button.

Maintenance—Load Factory Default

To clear all the settings on the unit, use the Load Factory Default to reset the unit to its initial factory default values.

The screenshot shows the 'Load Factory Default' page in a web console. At the top, there is a breadcrumb 'Home > Load Factory Default'. The title 'Load Factory Default' is prominently displayed. Below the title, there is a warning message: 'Click on Reset Button to reset all settings, including the console password, to the factory default values. The setting will remain after rebooting.' There is a checkbox labeled 'Keep Current IP Setting' which is currently unchecked. Below this, a blue information box contains the text: 'Info: To keep the IP address, netmask, and gateway settings unchanged, make sure that Keep IP settings is enabled.' At the bottom of the page is a large green 'RESET' button.



ATTENTION

Load Default will completely reset the configuration of the unit, and all the parameters you have saved will be discarded. Do not use this function unless you are sure you want to completely reset your unit.


Restart

Reboot the MGate by clicking the RESTART button.



ATTENTION

Unsaved configuration files will be discarded during a reboot.



Status Monitoring

The Status Monitoring function provides status information of field devices when the MGate is being used as a CAN client. If a CAN device fails or a cable comes loose, the gateway will not be able to receive up-to-date data from the CAN device. The out-of-date data will be stored in the gateway's memory and will be retrieved by the client (e.g., PLC), which is not aware that the slave device is not providing up-to-date data. To handle this situation, the MGate provides a warning mechanism to report the list of slave devices that are still "alive" through the Status Monitoring function.

The MGate automatically creates a status tag when a CAN-based server device is created. This tag is used to show the connection status (valid or invalid) of the CAN-based server device. To monitor the status of the status tag, you can convert this tag to the northbound protocol and read for the northbound SCADA/device. Or, you can check the tag status on the MGate's web, the Tag View page.

To perform the status tag monitoring from your northbound protocol, go to the northbound protocol's page (for example, the Modbus TCP Server page). Click ADD TAGS and select canopen_master as the tag provider and select the "status" tag. The MGate will automatically add a mapping from this CAN-based tag to the Modbus TCP.



The highest significant bit shows the status. 1 is invalid, 0 is valid.

Further details on the status codes:

1. Valid (0x00000000) - Indicates the status is connected.
2. Invalid (0x80000000) - Indicates the status is unknown.
3. Invalid (0x80000001) - Indicates the status is offline.

Device	Status	Reason	Type	Value	Description
Computer_00000000	000	000000	0000	Invalid (0x80000000)	2020-06-10 10:10:10 AM (UTC)

4. Network Management Tool (MXstudio)

Moxa's MXstudio industrial network management suite includes tools such as MXconfig and MXview. MXconfig is for industrial network mass configuration; MXview is for industrial management software. For the software and related detailed information regarding MXview and MXconfig, as well as the supported product firmware versions, refer to the Moxa website at <https://www.moxa.com/en/products/industrial-network-infrastructure/network-management-software>.

When you discover a Moxa product that has not been integrated into the MXview or MXconfig, you may not be able to retrieve the product information from MXview or MXconfig. To solve this, you can download the plugin file from the Moxa MGate product website and then import/install the plugin into MXview or MXconfig.

After importing/installing the plugin files, the MGate products can be supported by MXview/MXconfig. Refer to the Moxa MGate product website to download plugin files: <http://www.moxa.com>. For more detailed functions such as supported functions on MXview/MXconfig, refer to the Tech Note: Configuring and Monitoring with MXview One/MXview and MXconfig.

A. SNMP Agents with MIB II

The MGate has built-in Simple Network Management Protocol (SNMP) agent software that supports SNMP Trap, and RFC 1213 MIB-II.

RFC1213 MIB-II Supported SNMP Variables

System MIB	Interfaces MIB	IP MIB	ICMP MIB
sysDescr	ifNumber	ipForwarding	icmpInMsgs
sysObjectID	ifIndex	ipDefaultTTL	icmpInErrors
sysUpTime	ifDescr	ipInReceives	icmpInDestUnreachs
sysContact	ifType	ipInHdrErrors	icmpInTimeExcds
sysName	ifMtu	ipInAddrErrors	icmpInParmProbs
sysLocation	ifSpeed	ipForwDatagrams	icmpInSrcQuenchs
sysServices	ifPhysAddress	ipInUnknownProtos	icmpInRedirects
	ifAdminStatus	ipInDiscards	icmpInEchos
	ifOperStatus	ipInDelivers	icmpInEchoReps
	ifLastChange	ipOutRequests	icmpInTimestamps
	ifInOctets	ipOutDiscards	icmpTimestampReps
	ifInUcastPkts	ipOutNoRoutes	icmpInAddrMasks
	ifInNUcastPkts	ipReasmTimeout	icmpInAddrMaskReps
	ifInDiscards	ipReasmReqds	icmpOutMsgs
	ifInErrors	ipReasmOKs	icmpOutErrors
	ifInUnknownProtos	ipReasmFails	icmpOutDestUnreachs
	ifOutOctets	ipFragOKs	icmpOutTimeExcds
	ifOutUcastPkts	ipFragFails	icmpOutParmProbs
	ifOutNUcastPkts	ipFragCreates	icmpOutSrcQuenchs
	ifOutDiscards	ipAdEntAddr	icmpOutRedirects
	ifOutErrors	ipAdEntIfIndex	icmpOutEchos
	ifOutQLen	ipAdEntNetMask	icmpOutEchoReps
	ifSpecific	ipAdEntBcastAddr	icmpOutTimestamps
		ipAdEntReasmMaxSize	icmpOutTimestampReps
		ipRouteDest	icmpOutAddrMasks
		ipRouteIfIndex	icmpOutAddrMaskReps
		ipRouteMetric1	
		ipRouteMetric2	
		ipRouteMetric3	
		ipRouteMetric4	
		ipRouteNextHop	
		ipRouteType	
		ipRouteProto	
		ipRouteAge	
		ipRouteMask	
		ipRouteMetric5	
		ipRouteInfo	
		ipNetToMediaIfIndex	
		ipNetToMediaPhysAddress	
		ipNetToMediaNetAddress	
		ipNetToMediaType	
		ipRoutingDiscards	

Address Translation MIB	TCP MIB	UDP MIB	SNMP MIB
atIfIndex	tcpRtoAlgorithm	udpInDatagrams	snmpInPkts
atPhysAddress	tcpRtoMin	udpNoPorts	snmpOutPkts
atNetAddress	tcpRtoMax	udpInErrors	snmpInBadVersions
	tcpMaxConn	udpOutDatagrams	snmpInBadCommunityNames
	tcpActiveOpens	udpLocalAddress	snmpInBadCommunityUses
	tcpPassiveOpens	udpLocalPort	snmpInASNParseErrs
	tcpAttemptFails		snmpInTooBigs
	tcpEstabResets		snmpInNoSuchNames
	tcpCurrEstab		snmpInBadValues
	tcpInSegs		snmpInReadOnlyls
	tcpOutSegs		snmpInGenErrs
	tcpRetransSegs		snmpInTotalReqVars
	tcpConnState		snmpInTotalSetVars
	tcpConnLocalAddress		snmpInGetRequests
	tcpConnLocalPort		snmpInGetNexts
	tcpConnRemAddress		snmpInSetRequests
	tcpConnRemPort		snmpInGetResponses
	tcpInErrs		snmpInTraps
	tcpOutRsts		snmpOutTooBigs
			snmpOutNoSuchNames
			snmpOutBadValues
			snmpOutGenErrs
			snmpOutGetRequests
			snmpOutGetNexts
			snmpOutSetRequests
			snmpOutGetResponses
			snmpOutTraps
			snmpEnableAuthenTraps
			snmpSilentDrops
			snmpProxyDrops