



Thank you for your purchase. Questions, comments or feedback? We'd love to hear from you. Visit feit.com/help for support.

SMART VIDEO DOORBELL

IMPORTANT SAFETY INSTRUCTIONS AND INSTALLATION GUIDE



Works with

Feit Electric app

 **WiFi**
Only supports
2.4GHz Wi-Fi
Networks

**READ BEFORE INSTALLATION.
SAVE THESE INSTRUCTIONS.**

Questions, problems, missing parts?
Before returning to store, visit feit.com/help for further assistance.

FEIT.COM

REV007

We appreciate the trust and confidence you have placed in Feit Electric through the purchase of this product. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Feit Electric.

Table of Contents

Safety Information	2	Double-sided Tape Installation	7
FCC Statement	2	Power Kit Installation	8-9
Limited Warranty	2	App Setup	9
Pre-Installation	3	Need Help?	9
Description	4	Troubleshooting Tips	10
Battery Installation	5		
AC Power Supply Installation (Optional)	6-7		

Safety Information

PLEASE READ BEFORE INSTALLING!

IMPORTANT SAFEGUARDS:

ALWAYS FOLLOW BASIC SAFETY PRECAUTIONS WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT.



CAUTION: Your transformer should be able to supply power to both the Chime and Smart Video Doorbell. Do not use a Direct Current power supply. Not all chimes are compatible with the Smart Video Doorbell.

Mechanical Chime – For 12-24VAC normal operation, the Power Kit must be installed to give consistent power to your Smart Video Doorbell. In the Feit Electric app, choose “Mechanical Chime” in the Bell setting after pairing the device to function properly. Check your installation if the Power Kit is buzzing or hot to touch. Your wiring may be wrong. Consult a certified electrician for further assistance.

Electronic Chime – For 12-24VAC normal operation, **DO NOT** install the Power Kit. In the Feit Electric app, choose “Mechanical Chime” or “None” in the Bell setting after pairing the device to function properly.

Intercom System – Not compatible with the Smart Video Doorbell.



CAUTION: Use 5VDC 1A power adapter (included) for charging. To hardwire unit, requires a transformer (not included):

12-24VAC 60Hz. This product is not user-serviceable. Do not attempt to open the product enclosure for any reason. Before installing your Smart Video Doorbell, thoroughly review enclosed installation guide. If you do not have sufficient electrical wiring experience, please refer to a do-it-yourself wiring handbook or have your Smart Video Doorbell installed by a certified electrician. Reliable operating temperature is -4°F to 122°F (-20°C to 50°C). This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and hazards involved. Min. 90°C supply conductors.



CAUTION: Intended for outdoor use. May be used indoors.



CAUTION: CONTAINS NON-REPLACEABLE LITHIUM-ION BATTERY(IES).



CAUTION: If you are unfamiliar or inexperienced with your home’s electrical systems, contact a certified electrician for assistance.



WARNING: This product may represent a possible shock or fire hazard if improperly installed or attached in any way. Product should be installed in accordance with the owner’s manual, current electrical codes and/or the current National Electric Code (NEC).

RISK OF ELECTRIC SHOCK: Turn off the main power at the circuit breaker before installing.

Supplier’s Declaration of Conformity: 47 CFR § 2.1077 Compliance Information
Responsible Party: Feit Electric Company, 4901 Gregg Road, Pico Rivera, CA 90660, USA 562-463-2852
Unique Identifier: CAM/DOOR/WIFI/BATG2


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment. CAN ICES-005 (B).

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.
The device can be used in mobile (min 7.87 in.) exposure condition without restriction.

Limited Warranty


This product is warranted to be free from defects in workmanship and materials for up to 1 year from date of purchase. If the product fails within the warranty period, please visit [feit.com/help](https://www.feit.com/help) for instructions on replacement/refund or call 866.326.BULB. REPLACEMENT OR REFUND IS YOUR SOLE REMEDY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED. Some states and provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

TOOLS REQUIRED TO MOUNT THE DOORBELL




HARDWARE INCLUDED

NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	Smart Video Doorbell	1
BB	Micro USB Cord	1
CC	Power Adapter	1
DD	Double-sided Tape	2
EE	Mounting Screws	3
FF	Mounting Anchors	3
GG	Star-shaped Screw	1
HH	Star-shaped Screwdriver	1
II	Mounting Bracket	1
JJ	Power Kit	1
KK	Reset Pin	1
LL	Wire Terminal Block	1
MM	Wire Terminal Extenders	2
NN	Power Kit Double-sided Tape	1

Description




 **NOTE:** Stores up to 10 days of continuous recording based on 128 GB MicroSD card (sold separately). Results will vary based on file size, resolution, compression, bit rate, content, audio and other factors.

 **NOTE:** To access the MicroSD card slot, remove the back cover. Set the battery pack aside but **DO NOT** detach it.


 **NOTE:** Before installing, fully charge the battery pack using the supplied Micro USB Cord (BB) and Power Adapter (CC).

Item	Description
External Power Port	12-24VAC 10VA transformer (not included) for a single doorbell application. For two doorbells ringing the same mechanical chime box, there needs to be 20 or 30 VA transformer.
Doorbell Button	Press to activate the doorbell.
Status Light	• Blinking RED = Pairing Mode • Solid RED = Rebooting • Blinking BLUE = No Wi-Fi Connection • Solid BLUE = Connected to Wi-Fi
SD Card Slot	Add 128GB or less MicroSD card to enable recording (sold separately). Only supports MicroSD card with FAT32 format.
Reset Button	Use the Reset Pin (KK) to press and hold for 5 seconds or until you hear an audible tone to reset the Smart Video Doorbell.
Micro USB Power	5VDC, Max. 1A
Charging LED Indicator	• Solid Red: Battery is charging. • Solid Blue: Charging is complete.
Battery Capacity	6700mAh (contains two 18650 non-replaceable lithium-ion batteries).


- 1 Removing the Mounting Bracket**
Remove the Mounting Bracket (II) from the Smart Video Doorbell (AA).




- 2 Marking screw positions**
Mark screw positions using the Mounting Bracket (II) on your wall.




- 3 Installing the Mounting Bracket**
Drill holes at the marked points if installing on a hard surface such as concrete or brick. Insert Mounting Anchors (FF) into holes. You can skip this step if installing on wood, siding or attaching with tape.




- 4 Attaching the Mounting Bracket**
Use the Mounting Screws (EE) to attach the Mounting Bracket (II) to the wall.



- 5 Placing the Doorbell into the Mounting Bracket**
Insert the Smart Video Doorbell (AA) into the Mounting Bracket (II).




- 6 Securing the Doorbell to the Mounting Bracket**
Use the supplied Star-shaped Screwdriver (HH) and Star-shaped Screw (GG) to secure the Smart Video Doorbell (AA) to the Mounting Bracket (II).




1 Shut Off the Power

Shut Off the power to your doorbell at the circuit or fuse breaker before installing.




2 Removing the Mounting Bracket

Remove the Mounting Bracket (II) from the Smart Video Doorbell (AA).




3 Marking screw positions

Mark screw positions using the Mounting Bracket (II) on your wall.




4 Installing the Mounting Bracket

Drill holes at the marked points if installing on a hard surface such as concrete or brick. Insert Mounting Anchors (FF) into holes. You can skip this step if installing on wood, siding or attaching with tape.



5 Connecting the Power


Attach your doorbell wires to the terminal screws on the back of the Mounting Bracket (II). Use the provided Wire Extenders (MM) and Wire Terminal Block (LL) if your existing doorbell wires are too short. Tighten the terminal screws with the screwdriver.



NOTE: Your existing doorbell wires can go to any terminal screws.


6 Attaching the Mounting Bracket

Use the Mounting Screws (EE) to attach the Mounting Bracket (II) to the wall.




7 Placing the Doorbell into the Mounting Bracket

Insert the Smart Video Doorbell (AA) into the Mounting Bracket (II).



8 Securing the Doorbell to the Mounting Bracket

Using the supplied Star-shaped Screwdriver (HH), secure the Smart Video Doorbell (AA) to the Mounting Bracket (II) using the Star-shaped Screw (GG).




Double-Sided Tape Installation

Attaching the Mounting Bracket with tape

As an alternative, mount the Mounting Bracket (II) using the provided Double-sided Tape (DD).

- Clean the mounting area thoroughly (surface must be free of dust, dirt or grease).
- Stick Double-Sided Tape (DD) at the back of the Mounting Bracket (II). Peel the Double-Sided Tape (DD) and place your Smart Video Doorbell (AA) on a flat surface.



1 Turn Off Power

Shut Off power to your doorbell and mechanical chime at the circuit or fuse breaker before installing. Ring your doorbell again to confirm the power is Off. You will not be able to hear any sound.




NOTE: Your transformer should be able to supply power to both the Chime and Smart Video Doorbell. Do not use a Direct Current power supply. Not all chimes are compatible with the Smart Video Doorbell.

Mechanical Chime – For 12-24VAC normal operation, the Power Kit must be installed to give consistent power to your Smart Video Doorbell. In the Feit Electric app, choose “Mechanical Chime” in the Bell setting after pairing the device to function properly. Check your installation if the Power Kit is buzzing or hot to touch. Your wiring may be wrong. Consult a certified electrician for further assistance.


Electronic Chime – For 12-24VAC normal operation, **DO NOT** install the Power Kit. In the Feit Electric app, choose “Mechanical Chime” or “None” in the Bell setting after pairing the device to function properly.

Intercom System – Not compatible with the Smart Video Doorbell.



2 Locate Existing Mechanical Chime


Locate your existing mechanical chime. It is a box that produces the sound when your doorbell is pressed. Remove the cover (here is an example of a mechanical chime).




3 Install Power Kit

Slightly unscrew the “FRONT” terminal and “TRANS” terminal. Connect each wire of the Power Kit (JJ) to each screw. It does not matter which wire connects to which screw. Leave the existing doorbell wires and tighten both screws.


Locate the Power Kit (JJ) included in the packaging. The transformer terminal on the mechanical chime is usually labeled TRANS, T, AC, or O. The front terminal on the mechanical chime is usually labeled FRONT, F, 1, or C1.





4 Turn On Power and Test the Doorbell

Use the included Power Kit Double-sided Tape (NN) to stick on the back of the Power Kit (JJ). Position the Power Kit (JJ) where space is available. It is important that the wires DO NOT interfere with any moving mechanical parts of the chime. Turn On power at the circuit or fuse breaker. If the Smart Video Doorbell (AA) works properly, you can place the cover back over the chime.



APP Setup

Download and install the Feit Electric app

- Search for the Feit Electric app in the App Store or Google Play Store.
- Download and install the Feit Electric app on your smart device.





Feit Electric App



Set up the Smart Video Doorbell using the Feit Electric app

- Check to be sure the Smart Video Doorbell is in pairing mode. The RED status light must be blinking rapidly to connect. If the light is not blinking, press and hold the Reset Button for 5 seconds or until you hear an audible tone. Use the Feit Electric app to complete the set up.
- Tap Add Device or the + sign. Tap Security & Camera and then select Doorbell. You will be prompted to enter your Wi-Fi network and password.
- Follow the directions in the Feit Electric app to pair your device using the QR code.
- You can find more pairing methods in the drop down menu on the device set-up page.

Be sure to connect to a 2.4 GHz Wi-Fi network that covers your installation location.



Hold the phone approximately 6-12 inches from the doorbell and wait for the tone.



Need Help?

Thank you for your purchase.

Questions, comments or feedback?

We'd love to hear from you.

Visit feit.com/help for support

or connect with us:



@FeitElectric



@FeitElectricInc



feitelctrclighting

PROBLEM	CORRECTIVE ACTION
Doorbell will not power up	After completing installation, make sure your circuit breaker is in the On position. If the doorbell does not power on, consult a certified electrician to ensure the transformer is properly installed for mechanical chimes.
Doorbell will not connect to my Wi-Fi network	- Make sure the LED is blinking red. If the LED is not blinking red, press and hold Reset Button for 5 seconds or until you hear an audible tone, located at the bottom of the doorbell. - Make sure the Wi-Fi network is a 2.4GHz network. Device will not connect to a 5GHz network. - Test your Wi-Fi network with other devices such as your phone or computer to make sure it is operating properly. - The Wi-Fi connection may be out of range during pairing. Use your phone to check the Wi-Fi signal strength, it is recommended to have at least 2 signal bars showing for proper connection. - Your Wi-Fi network password is case sensitive, make sure you are entering it correctly.
The doorbell is offline	- There could be a temporary issue with your internet connection (e.g., service disruption). Please try again in a few minutes. - Make sure your Wi-Fi router is turned On. - The doorbell may not have power to it, make sure the wall switch and breaker is in the On position. - Make sure the doorbell is getting a good signal from your Wi-Fi router. Use your phone to check the Wi-Fi signal strength, it is recommended to have at least 2 signal bars showing for proper connection. - The doorbell may have been disconnected from your Wi-Fi network. Press and hold the Reset Button until you see a blinking red LED and hear an audible tone. Follow directions in the App Setup section of the manual to re-connect the doorbell to your Wi-Fi network.
What do the blinking LEDs mean?	- Blinking RED = Pairing Mode - Solid RED = Rebooting - Blinking BLUE = No Wi-Fi Connection - Solid BLUE = Connected to Wi-Fi
Live video stream is slow to load	Doorbell streaming issues may be caused by any of the following: - Your phone's cellular connection, which relies on mobile coverage. - Limited internet bandwidth at home. For example, other video streaming services running at the same time on your network can cause congestion slowing down the internet upload and download speeds. - Wi-Fi reception may not be stable or work reliably if the doorbell's Wi-Fi signal strength is less than 2 signal bars. You may need to install a Wi-Fi repeater or extender to boost the Wi-Fi signal.
How do I reset the doorbell to reenter pairing mode?	Press and hold the Reset Button located at the bottom of the doorbell until you see a blinking red LED and hear an audible tone.
The doorbell is not recording	- Under the SD Card and Record Settings in the Feit App, make sure the Record Switch is turned On. - Make sure that the MicroSD Card is installed correctly. To confirm that the doorbell is recognizing the MicroSD Card, go to the Settings menu in the Feit Electric app. Then, go to the SD Card and Record Settings menu and make sure the MicroSD Card capacity menu shows total, used, and free space. If this does not appear, consider reformatting the MicroSD Card. WARNING: Reformatting MicroSD Card will delete all videos stored on card. Please go through the troubleshooting section before doing so or contact our Customer Support Team.
How do I set the doorbell to Event or Continuous Recording?	In the Settings menu under SD Card and Record Settings make sure Record Switch is turned On, and then select Event Recording or Continuous Recording.
How can I check the available space on the MicroSD Card?	In the Settings menu under SD Card and Record Settings, you will see Used Space and Free Space. Note: Doorbell only supports 128GB or less MicroSD Cards with FAT32 format. (MicroSD Card NOT INCLUDED.)
What happens when the MicroSD card reaches full capacity?	Once the MicroSD Card reaches full capacity, new videos will start rewriting (deleting) over the oldest videos.
Can I use a new MicroSD card if I do not want to record over existing videos?	Yes, you can use a new MicroSD Card if you do not want to record over existing videos. Remove the existing MicroSD Card from the back of the doorbell and replace a new one not exceeding 128GB capacity. Once this is completed, format the new MicroSD Card by going to the SD Card and Record Settings and pressing Format SD Card, then Confirm. WARNING: Reformatting MicroSD Card will delete all videos stored on card. Please go through the troubleshooting section before doing so or contact our Customer Support Team.

SD™, MicroSD™, and SDHC™ are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries, or both.