

# Nios® V Embedded Processor Design Handbook

Updated for Quartus® Prime Design Suite: **25.1**

## Contents

<b>1. About the Nios® V Embedded Processor.....</b>	<b>6</b>
1.1. Altera® FPGA and Embedded Processors Overview.....	6
1.2. Quartus® Prime Software Support.....	7
1.3. Nios V Processor Licensing.....	7
1.4. Embedded System Design.....	8
<b>2. Nios V Processor Hardware System Design with Quartus Prime Software and Platform Designer.....</b>	<b>10</b>
2.1. Creating Nios V Processor System Design with Platform Designer .....	10
2.1.1. Instantiating Nios V Processor Altera FPGA IP.....	11
2.1.2. Defining System Component Design.....	23
2.1.3. Specifying Base Addresses and Interrupt Request Priorities .....	24
2.2. Integrating Platform Designer System into the Quartus Prime Project.....	25
2.2.1. Instantiating the Nios V Processor System Module in the Quartus Prime Project.....	25
2.2.2. Connecting Signals and Assigning Physical Pin Locations.....	25
2.2.3. Constraining the Altera FPGA Design.....	25
2.3. Designing a Nios V Processor Memory System .....	26
2.3.1. Volatile Memory.....	26
2.3.2. Non-Volatile Memory.....	35
2.4. Clocks and Resets Best Practices.....	35
2.4.1. System JTAG Clock.....	35
2.4.2. Reset Request Interface.....	36
2.4.3. Reset Release IP.....	37
2.5. Assigning a Default Agent.....	37
2.6. Assigning a UART Agent for Printing.....	38
2.6.1. Preventing Stalls by the JTAG UART.....	38
2.7. JTAG Signals.....	39
2.8. Optimizing Platform Designer System Performance.....	39
<b>3. Nios V Processor Software System Design.....</b>	<b>42</b>
3.1. Nios V Processor Software Development Flow.....	43
3.1.1. Board Support Package Project.....	43
3.1.2. Application Project.....	43
3.2. Altera FPGA Embedded Development Tools.....	43
3.2.1. Nios V Processor Board Support Package Editor.....	44
3.2.2. RiscFree IDE for Altera FPGAs.....	45
3.2.3. Nios V Utilities Tools.....	45
3.2.4. File Format Conversion Tools.....	46
3.2.5. Other Utilities Tools.....	46
<b>4. Nios V Processor Configuration and Booting Solutions.....</b>	<b>47</b>
4.1. Introduction.....	47
4.2. Linking Applications.....	47
4.2.1. Linking Behavior.....	48
4.3. Nios V Processor Booting Methods.....	49
4.4. Introduction to Nios V Processor Booting Methods.....	51
4.4.1. Nios V Processor Application Execute-In-Place from Boot Flash.....	51

4.4.2. Nios V Processor Application Copied from Boot Flash to RAM Using Boot Copier.....	52
4.4.3. Nios V Processor Application Execute-In-Place from OCRAM.....	54
4.4.4. Nios V Processor Application Execute-In-Place from TCM.....	55
4.5. Nios V Processor Booting from On-Chip Flash (UFM).....	55
4.5.1. MAX 10 FPGA On-Chip Flash Description.....	56
4.5.2. Nios V Processor Application Execute-In-Place from UFM.....	58
4.5.3. Nios V Processor Application Copied from UFM to RAM using Boot Copier.....	67
4.6. Nios V Processor Booting from General Purpose QSPI Flash.....	76
4.6.1. Nios V Processor Application Executes-In-Place from General Purpose QSPI Flash.....	77
4.6.2. Nios V Processor Application Copied from General Purpose QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI).....	86
4.7. Nios V Processor Booting from Configuration QSPI Flash.....	94
4.7.1. Nios V Processor Application Executes-In-Place from Configuration QSPI Flash.....	95
4.7.2. Nios V Processor Design, Configuration and Boot Flow (Control Block-based Device).....	106
4.7.3. Nios V Processor Design, Configuration and Boot Flow (SDM-based Devices)..	119
4.8. Nios V Processor Booting from On-Chip Memory (OCRAM).....	140
4.8.1. Nios V Processor Application Executes in-place from OCRAM.....	140
4.9. Nios V Processor Booting from Tightly Coupled Memory (TCM).....	147
4.9.1. Nios V Processor Application Executes in-place from TCM.....	147
4.10. Summary of Nios V Processor Vector Configuration and BSP Settings.....	154
4.11. Reducing Nios V Processor Booting Time.....	156
4.11.1. Boot Methods.....	156
4.11.2. Boot devices.....	156
4.11.3. Peripheral Initialization.....	156
4.11.4. Caches.....	156
4.11.5. System Speed.....	157
<b>5. Nios V Processor - Using the MicroC/TCP-IP Stack.....</b>	<b>158</b>
5.1. Introduction.....	158
5.2. Software Architecture.....	158
5.3. Support and Licensing.....	159
5.4. MicroC/TCP-IP Example Designs.....	159
5.4.1. Hardware and Software Requirements.....	159
5.4.2. Overview.....	160
5.4.3. Acquiring the Example Design Files.....	162
5.4.4. Hardware Design Files.....	163
5.4.5. Software Design Files.....	164
5.5. Development Flow.....	165
5.5.1. Hardware Development Flow.....	165
5.5.2. Software Development Flow.....	167
5.5.3. Device Programming.....	170
5.6. Operating the Example Designs.....	171
5.6.1. Operating the MicroC/TCP-IP IPPerf.....	171
5.6.2. Operating the MicroC/TCP-IP Simple Socket Server.....	173
5.7. Optional Configuration.....	176
5.7.1. Configuring Hardware Name.....	176
5.7.2. Configuring MAC and IP Addresses.....	177
5.7.3. Configuring MicroC/TCP-IP Initialization.....	177

5.7.4. Configuring iPerf Server Auto-Initialization.....	180
5.8. MicroC/TCP-IP Simple Socket Server Concepts.....	181
5.8.1. MicroC/OS-II Resources .....	181
5.8.2. Error Handling.....	182
5.8.3. MicroC/TCP-IP Stack Default Configuration.....	182
<b>6. Nios V Processor Debugging, Verifying, and Simulating.....</b>	<b>183</b>
6.1. Debugging Nios V/c Processor .....	183
6.1.1. Pilot System with Non-pipelined Nios V/m Processor.....	183
6.1.2. printf() Debugging.....	185
6.2. Debugging Nios V Processor Hardware Designs.....	186
6.2.1. JTAG Server.....	186
6.2.2. System Console.....	187
6.2.3. Signal Tap Logic Analyzer.....	189
6.2.4. In-System Sources and Probes.....	198
6.3. Debugging Nios V Processor Software Designs.....	199
6.3.1. Ashling RiscFree IDE for Altera FPGAs.....	199
6.3.2. Ashling Visual Studio Code Extension for Altera FPGAs.....	200
6.3.3. OpenOCD.....	200
6.3.4. Objdump File.....	200
6.3.5. Show Make Commands.....	200
6.4. Debugging Tools.....	201
6.5. Additional Embedded Design Considerations.....	201
6.5.1. JTAG Signal Integrity.....	201
6.5.2. Additional Memory Space for System Prototyping.....	201
6.6. Simulating Nios V Processor Designs.....	201
6.6.1. Prerequisites.....	202
6.6.2. Setting Up and Generating Your Simulation Environment in Platform Designer.....	202
6.6.3. Creating Nios V Processor Software.....	203
6.6.4. Generating Memory Initialization File.....	204
6.6.5. Generating System Simulation Files.....	204
6.6.6. Running Simulation in the QuestaSim Simulator Using Command Line.....	205
<b>7. Nios V Processor — Remote System Update.....</b>	<b>207</b>
7.1. Overview.....	207
7.2. Quartus Prime Pro Edition Software and Tool Support.....	208
7.2.1. Quartus Prime Pro Edition Software.....	208
7.2.2. Programming File Generator.....	210
7.3. Nios V Processor RSU Quick Start Guide in SDM-based Devices.....	212
7.3.1. Individual Factory, Application, and Update Images.....	213
7.3.2. Hardware Design Flow.....	213
7.3.3. Software Design Flow.....	216
7.3.4. Individual Images Generation.....	221
7.3.5. Remote System Update Image Files Generation.....	221
7.3.6. QSPI Flash Programming.....	228
7.3.7. Operating the RSU Client API.....	230
<b>8. Nios V Processor — Using Custom Instruction.....</b>	<b>234</b>
8.1. Introduction.....	234
8.2. Unimplemented Instruction Example Design.....	234
8.2.1. Hardware and Software Requirements.....	234
8.2.2. Overview.....	235

8.2.3. Acquiring the Example Design File.....	235
8.2.4. Hardware Design Files.....	235
8.2.5. Software Design Files.....	237
8.2.6. Development Flow.....	237
8.2.7. Operating the Example Design.....	238
8.3. Hardware Acceleration Example Design.....	240
8.3.1. Hardware and Software Requirements.....	241
8.3.2. Overview.....	241
8.3.3. Acquiring the Example Design File.....	241
8.3.4. Hardware Design Files.....	242
8.3.5. Software Design Files.....	242
8.3.6. Development Flow.....	243
8.3.7. Operating the Example Design.....	244
<b>9. Nios V Embedded Processor Design Handbook Archives.....</b>	<b>246</b>
<b>10. Document Revision History for the Nios V Embedded Processor Design Handbook...</b>	<b>247</b>



## 1. About the Nios® V Embedded Processor

---

### 1.1. Altera® FPGA and Embedded Processors Overview

Altera FPGA devices can implement logic that functions as a complete microprocessor while providing many options.

An important difference between discrete microprocessors and Altera FPGA is that Altera FPGA fabric contains no logic when it powers up. The Nios® V processor is a soft intellectual property (IP) processor based on the RISC-V specification. Before you run software on a Nios V processor based system, you must configure the Altera FPGA device with a hardware design that contains a Nios V processor. You can place the Nios V processor anywhere on the Altera FPGA, depending on the requirements of the design.

To enable your Altera® FPGA IP-based embedded system to behave as a discrete microprocessor-based system, your system should include the following:

- A JTAG interface to support Altera FPGA configuration, hardware and software debugging
- A power-up Altera FPGA configuration mechanism

If your system has these capabilities, you can begin refining your design from a pretested hardware design loaded in the Altera FPGA. Using an Altera FPGA also allows you to modify your design quickly to address problems or to add new functionality. You can test these new hardware designs easily by reconfiguring the Altera FPGA using your system's JTAG interface.

The JTAG interface supports hardware and software development. You can perform the following tasks using the JTAG interface:

- Configure the Altera FPGA
- Download and debug software
- Communicate with the Altera FPGA through a UART-like interface (JTAG UART terminal)
- Debug hardware (with the Signal Tap embedded logic analyzer)
- Program flash memory

After you configure the Altera FPGA with a Nios V processor-based design, the software development flow is similar to the flow for discrete microcontroller designs.

#### Related Information

- [AN 985: Nios V Processor Tutorial](#)  
A quick start guide about creating a simple Nios V processor system and running the Hello World application.

- [Nios V Processor Reference Manual](#)  
Provides information about the Nios V processor performance benchmarks, processor architecture, the programming model, and the core implementation.
- [Embedded Peripherals IP User Guide](#)
- [Nios V Processor Software Developer Handbook](#)  
Describes the Nios V processor software development environment, the tools that are available, and the process to build software to run on Nios V processor.
- [Ashling\\* RiscFree\\* Integrated Development Environment \(IDE\) for Altera FPGAs User Guide](#)  
Describes the RiscFree\* integrated development environment (IDE) for Altera FPGAs Arm\*-based HPS and Nios V core processor.
- [Nios V Processor Altera FPGA IP Release Notes](#)

## 1.2. Quartus® Prime Software Support

Nios V processor build flow is different for Quartus® Prime Pro Edition software and Quartus Prime Standard Edition software. Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for more information about the differences.

### Related Information

[AN 980: Nios V Processor Quartus Prime Software Support](#)

## 1.3. Nios V Processor Licensing

Each Nios V processor variant has its license key. Once you acquire the license key, you can use the same license key for all Nios V processor projects until the expiration date. You can acquire the Nios V Processor Altera FPGA IP licenses at zero cost.

The Nios V processor license key list is available in the Altera FPGA Self-Service Licensing Center. Click the **Sign up for Evaluation or Free License** tab, and select the corresponding options to make the request.

**Figure 1. Altera FPGA Self-Service Licensing Center**



With the license keys, you can:

- Implement a Nios V processor within your system.
- Simulate the behavior of a Nios V processor system.
- Verify the functionality of the design, such as size and speed.
- Generate device programming files.
- Program a device and verify the design in hardware.

You do not need a license to develop software in the Ashling\* RiscFree\* IDE for Altera FPGAs.

#### **Related Information**


- [Altera FPGA Self-Service Licensing Center](#)  
For more information about obtaining the Nios V Processor Altera FPGA IP license keys.
- [Altera FPGA Software Installation and Licensing](#)  
For more information about licensing the Altera FPGA software and setting up a fixed license and network license server.

## **1.4. Embedded System Design**

The following figure illustrates a simplified Nios V processor based system design flow, including both hardware and software development.




Figure 2. Nios V Processor System Design Flow



## 2. Nios V Processor Hardware System Design with Quartus Prime Software and Platform Designer

The following diagram illustrates a typical Nios V processor hardware design.

**Figure 3. Nios V Processor System Hardware Design Flow**



### 2.1. Creating Nios V Processor System Design with Platform Designer

The Quartus Prime software includes the Platform Designer system integration tool that simplifies the task of defining and integrating Nios V processor IP core and other IPs into an Altera FPGA system design. The Platform Designer automatically creates interconnect logic from the specified high-level connectivity. The interconnect automation eliminates the time-consuming task of specifying system-level HDL connections.

After analyzing the system hardware requirements, you use Quartus Prime to specify the Nios V processor core, memory, and other components your system requires. The Platform Designer automatically generates the interconnect logic to integrate the components in the hardware system.

### 2.1.1.1. Instantiating Nios V Processor Altera FPGA IP

You can instantiate any of the processor IP cores in **Platform Designer** ► **IP Catalog** ► **Processors and Peripherals** ► **Embedded Processors**.

The IP core of each processor supports different configuration options based on its unique architecture. You can define these configurations to better suit your design needs.

**Table 1. Configuration Options Across Core Variants**

Configuration Options	Nios V/c Processor	Nios V/m Processor	Nios V/g Processor
Debug	—	✓	✓
Use Reset Request	✓	✓	✓
Traps, Exceptions, and Interrupts	✓	✓	✓
CPU Architecture	✓	✓	✓
ECC	✓	✓	✓
Caches, Peripheral Regions and TCMs	—	—	✓
Custom Instructions	—	—	✓
Lockstep	—	—	✓

#### 2.1.1.1.1. Instantiating Nios V/c Compact Microcontroller Altera FPGA IP

**Figure 4. Nios V/c Compact Microcontroller Altera FPGA IP**



### 2.1.1.1.1. CPU Architecture Tab

**Table 2. CPU Architecture Tab**

Feature	Description
Enable Avalon® Interface	Enables Avalon Interface for instruction manager and data manager. If disabled, the system uses AXI4-Lite interface.
mhartid CSR value	<ul style="list-style-type: none"> <li>Invalid IP option.</li> <li>Do not use mhartid CSR value in Nios V/c processor.</li> </ul>

### 2.1.1.1.2. Use Reset Request Tab

**Table 3. Use Reset Request Tab Parameter**

Use Reset Request Tab	Description
Add Reset Request Interface	<ul style="list-style-type: none"> <li>Enable this option to expose local reset ports where a local master can use it to trigger the Nios V processor to reset without affecting other components in a Nios V processor system.</li> <li>The reset interface consists of an input <code>resetreq</code> signal and an output <code>ack</code> signal.</li> <li>You can request a reset to the Nios V processor core by asserting the <code>resetreq</code> signal.</li> <li>The <code>resetreq</code> signal must remain asserted until the processor asserts <code>ack</code> signal. Failure for the signal to remain asserted can cause the processor to be in a non-deterministic state.</li> <li>The Nios V processor responds that the reset is successful by asserting the <code>ack</code> signal.</li> <li>After the processor is successfully reset, the assertion of the <code>ack</code> signal can happen multiple times periodically until the de-assertion of the <code>resetreq</code> signal.</li> </ul>

### 2.1.1.1.3. Traps, Exceptions, and Interrupts Tab

**Table 4. Traps, Exceptions, and Interrupts Tab Parameters**

Traps, Exceptions, and Interrupts	Description
Reset Agent	<ul style="list-style-type: none"> <li>The memory hosting the reset vector (the Nios V processor reset address) where the reset code resides.</li> <li>You can select any memory module connected to the Nios V processor instruction master and supported by a Nios V processor boot flow as the reset agent.</li> </ul>
Reset Offset	<ul style="list-style-type: none"> <li>Specifies the offset of the reset vector relative to the chosen reset agent's base address.</li> <li>Platform Designer automatically provides a default value for the reset offset.</li> </ul>

**Note:** Platform Designer provides an **Absolute** option, which allows you to specify an absolute address in Reset Offset. Use this option when the memory storing the reset vector is located outside the processor system and subsystems.

#### 2.1.1.1.4. ECC Tab

**Table 5. ECC Tab**

ECC	Description
Enable Error Detection and Status Reporting	<ul style="list-style-type: none"> <li>Enable this option to apply ECC feature for Nios V processor internal RAM blocks.</li> <li>ECC features detect up to 2-bits errors and react based on the following behavior: <ul style="list-style-type: none"> <li>If it is a correctable error 1-bit, the processor continues to operate after correcting the error in the processor pipeline. However, the correction is not reflected in the source memories.</li> <li>If the error is uncorrectable, the processor continues to operate without correcting it in the processor pipeline and source memories, which might cause the processor to enter a nondeterministic state.</li> </ul> </li> </ul>

#### 2.1.1.2. Instantiating Nios V/m Microcontroller Altera FPGA IP

**Figure 5. Nios V/m Microcontroller Altera FPGA IP**



Nios V/m Microcontroller Altera FPGA IP

and, please go to: [Nios V/m Microcontroller Altera FPGA IP](#)

**Example Designs**

For available Nios V/m Example Designs, please go to: [Quartus > File Menu > Open Example Project...](#)

**Debug**

☒ Enable Debug

☐ Enable Reset from Debug Module

**Nios Reset Request**

☐ Add Reset Request Interface

**Trap, Exceptions, and Interrupts**

Reset Agent:

Reset Vector Offset:

Interrupt Model:

**CPU Architecture**

When pipelining is enabled, you benefit from higher instructions per cycle (IPC), but at the cost of higher area and lower frequency. When pipelining is disabled, you benefit from lower area and higher frequency, but at the cost of lower IPC.

☒ Enable Pipelining in CPU

☐ Enable Asynchronous Interface

Initial CPU value:

**ECC**

☐ Enable Error Detection & ECC Status Reporting

### 2.1.1.2.1. Debug Tab

**Table 6. Debug Tab Parameters**

Debug Tab	Description
Enable Debug	<ul style="list-style-type: none"> <li>Enable this option to add the JTAG target connection module to the Nios V processor.</li> <li>The JTAG target connection module allows connecting to the Nios V processor through the JTAG interface pins of the FPGA.</li> <li>The connection provides the following basic capabilities: <ul style="list-style-type: none"> <li>Start and stop the Nios V processor</li> <li>Examine and edit registers and memory.</li> <li>Download the Nios V application .elf file to the processor memory at runtime via niosv-download.</li> <li>Debug the application running on the Nios V processor</li> </ul> </li> <li>Connect dm_agent port to the processor instruction and data bus. Ensure the base address between both buses are the same.</li> </ul>
Enable Reset from Debug Module	<ul style="list-style-type: none"> <li>Enable this option to expose dbg_reset_out and ndm_reset_in ports.</li> <li>JTAG debugger or niosv-download -r command trigger the dbg_reset_out, which allows the Nios V processor to reset system peripherals connecting to this port.</li> <li>You must connect the dbg_reset_out interface to ndm_reset_in instead of reset interface to trigger reset to processor core and timer module. You must not connect dbg_reset_out interface to reset interface to prevent indeterminate behavior.</li> </ul>

### 2.1.1.2.2. Use Reset Request Tab

**Table 7. Use Reset Request Tab Parameter**

Use Reset Request Tab	Description
Add Reset Request Interface	<ul style="list-style-type: none"> <li>Enable this option to expose local reset ports where a local master can use it to trigger the Nios V processor to reset without affecting other components in a Nios V processor system.</li> <li>The reset interface consists of an input resetreq signal and an output ack signal.</li> <li>You can request a reset to the Nios V processor core by asserting the resetreq signal.</li> <li>The resetreq signal must remain asserted until the processor asserts ack signal. Failure for the signal to remain asserted can cause the processor to be in a non-deterministic state.</li> <li>Assertion of the resetreq signal in debug mode has no effect on the processor's state.</li> <li>The Nios V processor responds that the reset is successful by asserting the ack signal.</li> <li>After the processor is successfully reset, the assertion of the ack signal can happen multiple times periodically until the de-assertion of the resetreq signal.</li> </ul>

### 2.1.1.2.3. Traps, Exceptions, and Interrupts Tab

**Table 8. Traps, Exceptions, and Interrupts Tab**

Traps, Exceptions, and Interrupts Tab	Description
Reset Agent	<ul style="list-style-type: none"> <li>The memory hosting the reset vector (the Nios V processor reset address) where the reset code resides.</li> <li>You can select any memory module connected to the Nios V processor instruction master and supported by a Nios V processor boot flow as the reset agent.</li> </ul>
Reset Offset	<ul style="list-style-type: none"> <li>Specifies the offset of the reset vector relative to the chosen reset agent's base address.</li> <li>Platform Designer automatically provides a default value for the reset offset.</li> </ul>
Interrupt Mode	<p>Specific the type of interrupt controller either Direct or Vectored.</p> <p><i>Note:</i> The Nios V/m non-pipelined processor does not support Vectored interrupts. Therefore, avoid using the Vectored interrupt mode when the processor is in Non-pipelined mode.</p>

**Note:** Platform Designer provides an **Absolute** option, which allows you to specify an absolute address in Reset Offset. Use this option when the memory storing the reset vector is located outside the processor system and subsystems.

#### 2.1.1.2.4. CPU Architecture

**Table 9. CPU Architecture Tab Parameters**

CPU Architecture	Description
Enable Pipelining in CPU	<ul style="list-style-type: none"> <li>Enable this option to instantiate pipelined Nios V/m processor. <ul style="list-style-type: none"> <li>IPC is higher at the cost of higher logic area and lower Fmax frequency.</li> </ul> </li> <li>Disable this option to instantiate non-pipelined Nios V/m processor. <ul style="list-style-type: none"> <li>Has similar core performance as the Nios V/c processor.</li> <li>Supports debugging and interrupt capability</li> <li>Lower logic area and higher Fmax frequency at the cost of lower IPC.</li> </ul> </li> </ul>
Enable Avalon Interface	Enables Avalon Interface for instruction manager and data manager. If disabled, the system uses AXI4-Lite interface.
mhartid CSR value	<ul style="list-style-type: none"> <li>Hart ID register (mhartid) value is 0 at default.</li> <li>Assign a value between 0 and 4094.</li> <li>Compatible with Altera FPGA Avalon Mutex Core HAL API.</li> </ul>

#### Related Information

[Embedded Peripheral IP User Guide - Intel FPGA Avalon® Mutex Core](#)


#### 2.1.1.2.5. ECC Tab

**Table 10. ECC Tab**

ECC	Description
Enable Error Detection and Status Reporting	<ul style="list-style-type: none"> <li>Enable this option to apply ECC feature for Nios V processor internal RAM blocks.</li> <li>ECC features detect up to 2-bits errors and react based on the following behavior: <ul style="list-style-type: none"> <li>If it is a correctable error 1-bit, the processor continues to operate after correcting the error in the processor pipeline. However, the correction is not reflected in the source memories.</li> <li>If the error is uncorrectable, the processor continues to operate without correcting it in the processor pipeline and source memories, which might cause the processor to enter a nondeterministic state.</li> </ul> </li> </ul>

### 2.1.1.3. Instantiating Nios V/g General Purpose Processor Altera FPGA IP

Figure 6. Nios V/g General Purpose Processor Altera FPGA IP - Part 1



Nios V/g General Purpose Processor Intel FPGA IP  
intel\_niosv\_g

Example Designs

CPU Architecture

- ☐ Enable Floating Point Unit
- ☒ Enable Branch Prediction
- ☐ Disable FSQRT & FDEV instructions for FPU

mhartid CSR value:

Debug

- ☒ Enable Debug
- ☐ Enable Reset from Debug Module

Lockstep

- ☐ Enable Lockstep

Blind Window Period:


Default Timeout Period:

- ☐ Enable Extended Reset Interface

Use Reset Request

- ☐ Add Reset Request Interface

Figure 7. Nios V/g General Purpose Processor Altera FPGA IP - Part 2 (Turn Off Enable Core Level Interrupt Controller)



Traps, Exceptions, and Interrupts

Reset Agent:

Reset Vector Offset:


- ☐ Enable Core Level Interrupt Controller

Interrupt Mode:

Shadow Register Files:



**Figure 8. Nios V/g General Purpose Processor Altera FPGA IP - Part 2 (Turn On Enable Core Level Interrupt Controller)**



**Traps, Exceptions, and Interrupts**

Reset Agent: intel\_onchip\_memory\_0.s1

Reset Vector Offset: 0x00000000

☒ Enable Core Level Interrupt Controller

Interrupt Mode: Direct

Shadow Register Files: Number of CLIC interrupt levels

Number of Platform interrupt sources: 16

CLIC Vector Table Alignment: 128 bytes


Number of Interrupt Levels: 2

Number of Interrupt Priorities per level: 8

☐ Configurable interrupt polarity

☐ Support edge triggered interrupts

**Figure 9. Nios V/g General Purpose Processor Altera FPGA IP - Part 3**



**Memory Configurations**

**Caches**

Data Cache Size: 4 KBytes

Instruction Cache Size: 4 KBytes

**Peripheral Regions**

Peripheral Region A Peripheral Region B

Peripheral Region A Size: 0

Peripheral Region A Base Address: 0x00000000

**Tightly Coupled Memories**


Instruction TCM1 Instruction TCM2 Data TCM1 Data TCM2

Instruction TCM1 Size: 0

Instruction TCM1 Base Address: 0x00000000

Instruction TCM1 Initialization File:

**Figure 10. Nios V/g General Purpose Processor Altera FPGA IP - Part 4**



### 2.1.1.3.1. CPU Architecture

**Table 11. CPU Architecture Parameters**

CPU Architecture Tab	Description
Enable Floating Point Unit	Enable this option to add the floating-point unit ("F" extension) in the processor core.
Enable Branch Prediction	Enable static branch prediction (Backward Taken and Forward Not Taken) for branch instructions.
mhartid CSR value	<ul style="list-style-type: none"> <li>Hart ID register (mhartid) value is 0 at default.</li> <li>Assign a value between 0 and 4094.</li> <li>Compatible with Altera FPGA Avalon Mutex Core HAL API.</li> </ul>
Disable FSQRT & FDIV instructions for FPU	<ul style="list-style-type: none"> <li>Remove floating-point square root (FSQRT) and floating-point division (FDIV) operations in FPU.</li> <li>Apply software emulation on both instructions during runtime.</li> </ul>

### Related Information

[Embedded Peripheral IP User Guide - Intel FPGA Avalon® Mutex Core](#)

### 2.1.1.3.2. Debug Tab

**Table 12. Debug Tab Parameters**

Debug Tab	Description
Enable Debug	<ul style="list-style-type: none"> <li>Enable this option to add the JTAG target connection module to the Nios V processor.</li> <li>The JTAG target connection module allows connecting to the Nios V processor through the JTAG interface pins of the FPGA.</li> <li>The connection provides the following basic capabilities: <ul style="list-style-type: none"> <li>Start and stop the Nios V processor</li> <li>Examine and edit registers and memory.</li> <li>Download the Nios V application <code>.elf</code> file to the processor memory at runtime via <code>niosv-download</code>.</li> <li>Debug the application running on the Nios V processor</li> </ul> </li> <li>Connect <code>dm_agent</code> port to the processor instruction and data bus. Ensure the base address between both buses are the same.</li> </ul>
Enable Reset from Debug Module	<ul style="list-style-type: none"> <li>Enable this option to expose <code>dbg_reset_out</code> and <code>ndm_reset_in</code> ports.</li> <li>JTAG debugger or <code>niosv-download -r</code> command trigger the <code>dbg_reset_out</code>, which allows the Nios V processor to reset system peripherals connecting to this port.</li> <li>You must connect the <code>dbg_reset_out</code> interface to <code>ndm_reset_in</code> instead of <code>reset</code> interface to trigger reset to processor core and timer module. You must not connect <code>dbg_reset_out</code> interface to <code>reset</code> interface to prevent indeterminate behavior.</li> </ul>

### 2.1.1.3.3. Lockstep Tab

**Table 13. Lockstep Tab**

Parameters	Description
Enable Lockstep	<ul style="list-style-type: none"> <li>Enable the dual core Lockstep system.</li> </ul>
Default Timeout Period	<ul style="list-style-type: none"> <li>Default value of programmable timeout on reset exit (between 0 and 255).</li> </ul>
Enable Extended Reset Interface	<ul style="list-style-type: none"> <li>Enable the optional Extended Reset Interface for Extended Reset Control.</li> <li>When disabled, the <code>fRSmartComp</code> implements Basic Reset Control.</li> </ul>

### 2.1.1.3.4. Use Reset Request Tab

**Table 14. Use Reset Request Tab Parameter**

Use Reset Request Tab	Description
Add Reset Request Interface	<ul style="list-style-type: none"> <li>Enable this option to expose local reset ports where a local master can use it to trigger the Nios V processor to reset without affecting other components in a Nios V processor system.</li> <li>The reset interface consists of an input <code>resetreq</code> signal and an output <code>ack</code> signal.</li> <li>You can request a reset to the Nios V processor core by asserting the <code>resetreq</code> signal.</li> <li>The <code>resetreq</code> signal must remain asserted until the processor asserts <code>ack</code> signal. Failure for the signal to remain asserted can cause the processor to be in a non-deterministic state.</li> <li>Assertion of the <code>resetreq</code> signal in debug mode has no effect on the processor's state.</li> <li>The Nios V processor responds that the reset is successful by asserting the <code>ack</code> signal.</li> <li>After the processor is successfully reset, the assertion of the <code>ack</code> signal can happen multiple times periodically until the de-assertion of the <code>resetreq</code> signal.</li> </ul>

### 2.1.1.3.5. Traps, Exceptions, and Interrupts Tab

**Table 15. Traps, Exceptions, and Interrupts Tab when Enable Core Level Interrupt Controller is Turned Off**

Traps, Exceptions, and Interrupts Tab	Description
Reset Agent	<ul style="list-style-type: none"> <li>The memory hosting the reset vector (the Nios V processor reset address) where the reset code resides.</li> <li>You can select any memory module connected to the Nios V processor instruction master and supported by a Nios V processor boot flow as the reset agent.</li> </ul>
Reset Offset	<ul style="list-style-type: none"> <li>Specifies the offset of the reset vector relative to the chosen reset agent's base address.</li> <li>Platform Designer automatically provides a default value for the reset offset.</li> </ul>
Enable Core Level Interrupt Controller (CLIC)	<ul style="list-style-type: none"> <li>Enable CLIC to support pre-emptive interrupts and configurable interrupt trigger condition.</li> <li>When enabled, you can configure the number of platform interrupts, set trigger conditions, and designate some of the interrupts as pre-emptive.</li> </ul>
Interrupt Mode	Specify the interrupt types as Direct, or Vectored
Shadow Register Files	Enable shadow register to reduce context switching upon interrupt.

**Table 16. Traps, Exceptions and Interrupts when Enable Core Level Interrupt Controller is Turned On**

Traps, Exceptions, and Interrupts	Descriptions
Reset Agent	<ul style="list-style-type: none"> <li>The memory hosting the reset vector (the Nios V processor reset address) where the reset code resides.</li> <li>You can select any memory module connected to the Nios V processor instruction master and supported by a Nios V processor boot flow as the reset agent.</li> </ul>
Reset Offset	<ul style="list-style-type: none"> <li>Specifies the offset of the reset vector relative to the chosen reset agent's base address.</li> <li>Platform Designer automatically provides a default value for the reset offset.</li> </ul>
Enable Core Level Interrupt Controller (CLIC)	<ul style="list-style-type: none"> <li>Enable CLIC to support pre-emptive interrupts and configurable interrupt trigger condition.</li> <li>When enabled, you can configure the number of platform interrupts, set trigger conditions, and designate some of the interrupts as pre-emptive.</li> </ul>
Interrupt Mode	<ul style="list-style-type: none"> <li>Specify the interrupt types as Direct, Vectored, or CLIC.</li> </ul>
Shadow Register Files	<ul style="list-style-type: none"> <li>Enable shadow register to reduce context switching upon interrupt.</li> <li>Offers two approaches: <ul style="list-style-type: none"> <li><b>Number of CLIC interrupt levels</b></li> <li><b>Number of CLIC interrupt levels - 1:</b> This option is useful when you want the number of register file copies to fit in an exact number of M20K or M9K blocks.</li> </ul> </li> <li>Enable the Nios V processor to use shadow register files which reduce context switching overhead upon interrupt.</li> </ul> <p>For more information about shadow register files, refer to the <i>Nios V Processor Reference Manual</i>.</p>
Number of Platform interrupt sources	<ul style="list-style-type: none"> <li>Specifies the number of platform interrupt between 16 to 2048.</li> </ul> <p><i>Note:</i> CLIC supports up to 2064 interrupt inputs, and the first 16 interrupt inputs are also connected to the basic interrupt controller.</p>
CLIC Vector Table Alignment	<ul style="list-style-type: none"> <li>Automatically determined based on the number of platform interrupt sources.</li> <li>If you use an alignment that is below the recommended value, the CLIC increases logic complexity by adding an extra adder to perform vectoring calculations.</li> <li>If you use an alignment that is below the recommended value, this results in increased logic complexity in the CLIC.</li> </ul>

*continued...*

Traps, Exceptions, and Interrupts	Descriptions
Number of Interrupt Levels	<ul style="list-style-type: none"> <li>Specifies the number of interrupt levels with an additional level 0 for application code. Interrupts of a higher level can interrupt (pre-empt) a running handler for a lower-level interrupt.</li> <li>With non-zero interrupt levels as the only options for interrupts, the application code is always at the lowest level 0.</li> </ul> <p><i>Note:</i> Run-time configuration of an interrupt's level and priority is done in a single 8-bit register. If the number of interrupt levels is 256, it is not possible to configure the interrupt priority at run-time. Otherwise, the maximum number of configurable priorities is 256 / (number of interrupt levels - 1).</p>
Number of Interrupt Priorities per level	<ul style="list-style-type: none"> <li>Specifies the number of interrupt priorities, which the CLIC uses to determine the order in which non pre-empting interrupt handlers are called.</li> </ul> <p><i>Note:</i> Concatenation of binary values of the selected interrupt level and selected interrupt priority must be less than 8 bits.</p>
Configurable interrupt polarity	<ul style="list-style-type: none"> <li>Allows you to configure interrupt polarity during runtime.</li> <li>Default polarity is positive polarity.</li> </ul>
Support edge triggered interrupts	<ul style="list-style-type: none"> <li>Allows you to configure interrupt trigger condition during runtime, i.e. high-level triggered or positive-edge triggered (when interrupt polarity is positive in <b>Configurable interrupt polarity</b>).</li> <li>Default trigger condition is level triggered interrupt.</li> </ul>

**Note:** Platform Designer provides an **Absolute** option, which allows you to specify an absolute address in Reset Offset. Use this option when the memory storing the reset vector is located outside the processor system and subsystems.

### Related Information

Nios® V Processor Reference Manual

#### 2.1.1.3.6. Memory Configurations Tab

**Table 17. Memory Configuration Tab Parameters**

Category	Memory Configuration Tab	Description
Caches	Data Cache Size	<ul style="list-style-type: none"> <li>Specifies the size of the data cache.</li> <li>Valid sizes are from 0 kilobytes (KB) to 16 KB.</li> <li>Turn off data cache when size is 0 KB.</li> </ul>
	Instruction Cache Size	<ul style="list-style-type: none"> <li>Specifies the size of the instruction cache.</li> <li>Valid sizes are from 0 KB to 16 KB.</li> <li>Turn off instruction cache when size is 0 KB.</li> </ul>
Peripheral Region A and B	Size	<ul style="list-style-type: none"> <li>Specifies the size of the peripheral region.</li> <li>Valid sizes are from 64 KB to 2 gigabytes (GB), or None. Choosing None disables the peripheral region.</li> </ul>
	Base Address	<ul style="list-style-type: none"> <li>Specifies the base address of peripheral region after you select the size.</li> <li>All addresses in the peripheral region produce uncachable data accesses.</li> <li>Peripheral region base address must be aligned to the peripheral region size.</li> </ul>
Tightly Coupled Memories	Size	<ul style="list-style-type: none"> <li>Specifies the size of the tightly-coupled memory.</li> <li>— Valid sizes are from 0 MB to 512 MB.</li> </ul>
	Base Address	<ul style="list-style-type: none"> <li>Specifies the base address of tightly-coupled memory.</li> </ul>
	Initialization File	<ul style="list-style-type: none"> <li>Specifies the initialization file for tightly-coupled memory.</li> </ul>

**Note:** In a Nios V processor system with cache enabled, you must place system peripherals within a peripheral region. You can use peripheral regions to define a non-cacheable transaction for peripherals such as UART, PIO, DMA, and others.

### 2.1.1.3.7. ECC Tab

**Table 18. ECC Tab**

ECC	Description
Enable Error Detection and Status Reporting	<ul style="list-style-type: none"> <li>Enable this option to apply ECC feature for Nios V processor internal RAM blocks.</li> <li>ECC features detect up to 2-bits errors and react based on the following behavior: <ul style="list-style-type: none"> <li>If it is a correctable single bit error and <b>Enable Single Bit Correction</b> is turned off, the processor continues to operate after correcting the error in the processor pipeline. However, the correction is not reflected in the source memories.</li> <li>If it is a correctable single bit error and <b>Enable Single Bit Correction</b> is turned on, the processor continues to operate after correcting the error in the processor pipeline and the source memories.</li> <li>If it is an uncorrectable error, the processor halts its operation.</li> </ul> </li> </ul>
Enable Single Bit Correction	Enable single bit correction on embedded memory blocks in the core.

### 2.1.1.3.8. Custom Instruction Tab

**Note:** This tab is only available for the Nios V/g processor core.

Custom Instruction	Description
Nios V Custom Instruction Hardware Interface Table	<ul style="list-style-type: none"> <li>Nios V processor uses this table to define its custom instruction manager interfaces.</li> <li>Defined custom instruction manager interfaces are uniquely encoded by an Opcode (CUSTOM0-3) and 3 bits of <code>funct7[6:4]</code>.</li> <li>You can define up to a total of 32 individual custom instruction manager interfaces.</li> </ul>
Nios V Custom Instruction Software Macro Table	<ul style="list-style-type: none"> <li>Nios V processor uses this table is used to define custom instruction software encodings for defined custom instruction manager interfaces.</li> <li>For each defined custom instruction software encoding, the Opcode (CUSTOM0-3) and 3 bits of <code>funct7[6:4]</code> encoding must correlate to a defined custom instruction manager interface encoding in the Custom Instruction Hardware Interface Table.</li> <li>You can use <code>funct7[6:4]</code>, <code>funct7[3:0]</code>, and <code>funct3[2:0]</code> to define additional encoding for a given custom instruction, or specified as Xs to be passed in as additional instruction arguments.</li> <li>Nios V processor provides defined custom instruction software encodings as generated C-macros in <code>system.h</code>, and follow the R-type RISC-V instruction format.</li> <li>Mnemonics may be used to define custom names for: <ul style="list-style-type: none"> <li>The generated C-Macros in <code>system.h</code>.</li> <li>The generated GDB debug mnemonics in <code>custom_instruction_debug.xml</code>.</li> </ul> </li> </ul>

### Related Information

#### AN 977: Nios V Processor Custom Instruction

For more information about custom instructions that allow you to customize the Nios® V processor to meet the needs of a particular application.


## 2.1.2. Defining System Component Design

Use the Platform Designer to define the hardware characteristics of the Nios V processor system and add in the desired components. The following diagram demonstrates a basic Nios V processor system design with the following components:

- Nios V processor core
- On-Chip Memory
- JTAG UART
- Interval Timer (optional)<sup>(1)</sup>

When a new On-Chip Memory is added to a Platform Designer system, perform **Sync System Infos** to reflect the added memory components in reset. Alternatively, you can enable **Auto Sync** in Platform Designer to automatically reflect the latest component changes

**Figure 11. Example connection of Nios V processor with other peripherals in Platform Designer**



<sup>(1)</sup> You have the option to use the Nios V Internal Timer features to replace the external Interval Timer in Platform Designer.

You must also define operation pins to export as conduit in your Platform Designer system. For example, a proper FPGA system operation pin list is defined as below but not limited to:

- Clock
- Reset
- I/O signals

### 2.1.3. Specifying Base Addresses and Interrupt Request Priorities

To specify how the components added in the design interact to form a system, you need to assign base addresses for each agent component and assign interrupt request (IRQ) priorities for the JTAG UART and the interval timer. The Platform Designer provides a command - `Assign Base Addresses` - which automatically assigns proper base addresses to all components in a system. However, you can adjust the base addresses based on your needs.

The following are some guidelines for assigning base addresses:

- Nios V processor core has a 32-bit address span. To access agent components, their base address must range between 0x00000000 and 0xFFFFFFFF.
- Nios V programs use symbolic constants to refer to addresses. You do not have to choose address values that are easy to remember.
- Address values that differentiate components with only a one-bit address difference produce more efficient hardware. You do not have to compact all base addresses into the smallest possible address range because compacting can create less efficient hardware.
- Platform Designer does not attempt to align separate memory components in a contiguous memory range. For example, if you want multiple On-Chip Memory components addressable as one contiguous memory range, you must explicitly assign base addresses.

Platform Designer also provides an automation command - `Assign Interrupt Numbers` which connects IRQ signals to produce valid hardware results. However, assigning IRQs effectively requires an understanding of the overall system response behavior. Platform Designer cannot make educated guesses about the best IRQ assignment.

The lowest IRQ value has the highest priority. In an ideal system, Altera recommends that the timer component to have the highest priority IRQ, i.e., the lowest value, to maintain the accuracy of the system clock tick.

In some cases, you might assign a higher priority to real time peripherals (such as video controllers), which demands a higher interrupt rate than timer components.

#### Related Information

[Quartus Prime Pro Edition User Guide:](#)

More information about creating a System with Platform Designer.



## 2.2. Integrating Platform Designer System into the Quartus Prime Project

After generating the Nios V system design in Platform Designer, perform the following tasks to integrate the Nios V system module into the Quartus Prime FPGA design project.

- Instantiate the Nios V system module in the Quartus Prime project
- Connect signals from Nios V system module to other signals in the FPGA logic
- Assign physical pins location
- Constrain the FPGA design

### 2.2.1. Instantiating the Nios V Processor System Module in the Quartus Prime Project

Platform Designer generates a system module design entity which you can instantiate in Quartus Prime. How you instantiate the system module depends on the design entry method for the overall Quartus Prime project. For example, if you were using Verilog HDL for design entry, instantiate the Verilog based system module. If you prefer to use the block diagram method for design entry, instantiate a system module symbol .bdf file.

### 2.2.2. Connecting Signals and Assigning Physical Pin Locations

To connect your Altera FPGA design to your board-level design, perform the following tasks:

- Identify the top-level file for your design and signals to connect to external Altera FPGA device pins.
- Understand which pins to connect through your board-level design user guide or schematics.
- Assign signals in the top-level design to ports on your Altera FPGA device with pin assignment tools.

Your Platform Designer system can be the top level design. However, the Altera FPGA can also include additional logic based on your needs and thus introduces a custom top-level file. The top-level file connects the Nios V processor system module signals to other Altera FPGA design logic.

#### Related Information

[Quartus Prime Pro Edition User Guide: Design Constraints](#)

### 2.2.3. Constraining the Altera FPGA Design

A proper Altera FPGA system design includes design constraints to ensure the design meets timing closure and other logic constraint requirements. You must constrain your Altera FPGA design to meet these requirements explicitly using tools provided in the Quartus Prime software or third-party EDA providers. The Quartus Prime software uses the provided constraints during the compilation phase to get the optimum placement results.

### Related Information

- [Quartus Prime Pro Edition User Guide: Design Constraints](#)
- [Third-party EDA Partners](#)
- [Quartus Prime Pro Edition User Guide: Timing Analyzer](#)

## 2.3. Designing a Nios V Processor Memory System

This section describes the best practices for selecting memory devices in a Platform Designer embedded system with a Nios V processor and achieving optimum performance. Memory devices play a critical role in improving the overall performance of an embedded system. Embedded system memory stores the program instructions and data.

### 2.3.1. Volatile Memory

A primary distinction in a memory type is volatility. Volatile memory only holds its contents while you supply power to the memory device. As soon as you remove the power, the memory loses its contents.

Examples of volatile memory are RAM, cache, and registers. These are fast memory types that increase running performance. Altera recommends you load and execute Nios V processor instructions in RAM and pair Nios V IP core with On-Chip Memory IP or External Memory Interface IP for optimum performance.

To improve performance, you can eliminate additional Platform Designer adaptation components by matching Nios V processor data manager interface type or width with boot RAM. For example, you can configure On-Chip Memory II with a 32-bits AXI-4 interface, which matches the Nios V data manager interface.

### Related Information

- [External Memory Interfaces IP Support Center](#)
- [On-Chip Memory \(RAM or ROM\) Altera FPGA IP](#)
- [On-Chip Memory II \(RAM or ROM\) Altera FPGA IP](#)
- [Nios V Processor Application Execute-In-Place from OCRAM on page 54](#)

#### 2.3.1.1. On-Chip Memory Configuration – RAM or ROM

You can configure Altera FPGA On-Chip Memory IPs as RAM or ROM.

- RAM provides read and write capability and has a volatile nature. If you are booting the Nios V processor from an On-Chip RAM, you must make sure boot content is preserved and not corrupted in the event of a reset during run time.
- If a Nios V processor is booting from ROM, any software bug on the Nios V processor cannot erroneously overwrite the contents of On-Chip Memory. Thus, reducing the risk of boot software corruption.

### Related Information

- [On-Chip Memory \(RAM or ROM\) Altera FPGA IP](#)
- [On-Chip Memory II \(RAM or ROM\) Altera FPGA IP](#)
- [Nios V Processor Application Execute-In-Place from OCRAM on page 54](#)

### 2.3.1.2. Caches

On-chip memories are commonly used to implement the cache functionality because of their low latency. The Nios V processor uses on-chip memory for its instruction and data caches. The limited capacity of on-chip memory is usually not an issue for caches because they are typically small.

Caches are commonly used under the following conditions:

- Regular memory is located off-chip and has a longer access time than on-chip memory.
- The performance-critical sections of the software code can fit in the instruction cache, improving system performance.
- The performance-critical, most frequently used section of the data can fit in the data cache, improving system performance.

Enabling caches in Nios V processor creates a memory hierarchy, which minimize the memory access time.


#### 2.3.1.2.1. Peripheral region

Any embedded peripherals IP, such as UART, I2C, and SPI must not be cached. Cache is highly recommended for external memories which are affected by long access time, while internal on-chip memories may be excluded due to their short access time. You must not cache any embedded peripheral IPs, such as UART, I2C, and SPI, except for memories. This is important because events from external devices, such as agent devices updating the soft IPs, are not captured by the processor cache, in turn not received by the processor. As a result, these events can go unnoticed until you flush the cache, which can lead to unintended behavior in your system. In summary, the memory-mapped region of embedded peripheral IPs is uncacheable and must reside within the processor's peripheral regions.

To set a peripheral region, follow these steps:

1. Open the system's **Address Map** in the Platform Designer.
2. Navigate to the address map of the processor's Instruction Manager and Data Manager.
3. Identify the peripherals and memories in your system.

**Figure 12. Example of Address Map**



Subordinate	cpu.instruction_manager	cpu.data_manager
✓ bootcopier_ram.s1	0x0005_2000 - 0x0005_3fff	0x0005_2000 - 0x0005_3fff
✓ bootcopier_rom.s1	0x0005_0000 - 0x0005_1fff	0x0005_0000 - 0x0005_1fff
✓ cpu.timer_sw_agent		0x0005_4000 - 0x0005_403f
✓ cpu.dm_agent	0x0004_0000 - 0x0004_ffff	0x0004_0000 - 0x0004_ffff
✓ mailbox_axiwen		0x0005_4040 - 0x0005_407f
✓ sysid_qsys_0.control_slave		0x0005_4080 - 0x0005_40bf
✓ uart_avalon_jtag_slave		0x0005_40c0 - 0x0005_40bf
✓ user_application_mem.s1	0x0006_0000 - 0x0003_ffff	0x0006_0000 - 0x0003_ffff

*Note:* The blue arrows are pointing to memories.

4. Group the peripherals:
  - a. Memory as cacheable
  - b. Peripherals as uncacheable

Table 19. Cacheable and Uncacheable Region

Subordinate	Address Map	Status	Peripheral Region	
			Size	Base Address
user_application_mem.s1	0x0 ~ 0x3ffff	Cacheable	N/A	N/A
cpu.dm_agent	0x40000 ~ 0x4ffff	Uncacheable	65536 bytes	0x40000
bootcopier_rom.s1	0x50000 ~ 0x517ff	Cacheable	144 bytes (min size is 65536 bytes)	0x54000
bootcopier_ram.s1	0x52000 ~ 0x537ff	Cacheable		
cpu.timer_sw_agent	0x54000 ~ 0x5403f	Uncacheable		
mailbox.avmm	0x54040 ~ 0x5407f	Uncacheable		
sysid_qsys_0.control_slave	0x54080 ~ 0x54087	Uncacheable		
uart.avalon_jtag_slave	0x54088 ~ 0x5408f	Uncacheable		

5. Align the peripheral regions with their specific sizes:

- For example, if the size is 65536 bytes, it corresponds to 0x10000 bytes. Therefore, the allowed base address must be a multiple of 0x10000.
- The CPU.dm\_agent uses a base address of 0x40000, which is a multiple of 0x10000. As a result, Peripheral Region A, with a size of 65536 bytes and a base address of 0x40000, meets the requirements.
- The base address of the collection of uncacheable regions at 0x54000 is not a multiple of 0x10000. You must reassign them to 0x60000 or other multiple of 0x10000. Thus, Peripheral Region B, which has a size of 65536 bytes and a base address of 0x60000, satisfies the criteria.

Table 20. Cacheable and Uncacheable Region with Reassignment

Subordinate	Address Map	Status	Peripheral Region	
			Size	Base Address
user_application_mem.s1	0x0 ~ 0x3ffff	Cacheable	N/A	N/A
cpu.dm_agent	0x40000 ~ 0x4ffff	Uncacheable	65536 bytes	0x40000
bootcopier_rom.s1	0x50000 ~ 0x517ff	Cacheable	144 bytes (min size is 65536 bytes)	0x60000
bootcopier_ram.s1	0x52000 ~ 0x537ff	Cacheable		
cpu.timer_sw_agent	<b>0x60000</b> ~ 0x6003f	Uncacheable		
mailbox.avmm	<b>0x60040</b> ~ 0x6007f	Uncacheable		
sysid_qsys_0.control_slave	<b>0x60080</b> ~ 0x60087	Uncacheable		
uart.avalon_jtag_slave	<b>0x60088</b> ~ 0x6008f	Uncacheable		

### 2.3.1.3. Tightly Coupled Memory

Tightly coupled memories (TCMs) are implemented using on-chip memory as their low latency makes them well suited to the task. TCMs are memories mapped in the typical address space but have a dedicated interface to the microprocessor and possess the high-performance, low-latency properties of cache memory. TCM also provides a subordinate interface for the external host. The processor and external host have the same permission level to handle the TCM.

**Note:** When the TCM subordinate port is connected to an external host, it may be displayed with a different base address than the base address assigned in the processor core. Altera recommends to align both addresses to the same value.

#### 2.3.1.4. External Memory Interface (EMIF)

EMIF (External Memory Interface) functions similarly to SRAM (Static Random Access Memory), but it is dynamic and requires periodic refreshing to maintain its content. The dynamic memory cells in EMIF are much smaller than the static memory cells in SRAM, which results in higher capacity and lower-cost memory devices.

In addition to the refresh requirement, EMIF has specific interface requirements that often necessitate specialized controller hardware. Unlike SRAM, which has a fixed set of address lines, EMIF organizes its memory space into banks, rows, and columns. Switching between banks and rows introduces some overhead, so you must carefully order memory accesses to use EMIF efficiently. EMIF also multiplexes row and column addresses over the same address lines, reducing the number of pins required for a given EMIF size.

Higher-speed versions of EMIF, such as DDR, DDR2, DDR3, DDR4, and DDR5, impose strict signal integrity requirements that PCB designers must consider.

EMIF devices rank among the most cost-effective and high-capacity RAM types available, making them a popular option. A key component of an EMIF interface is the EMIF IP, which manages tasks related to address multiplexing, refreshing, and switching between rows and banks. This design allows the rest of the system to access EMIF without needing to understand its internal architecture.

##### Related Information


[External Memory Interfaces IP Support Center](#)

##### 2.3.1.4.1. Address Span Extender IP

The Address Span Extender Altera FPGA IP allows memory-mapped host interfaces to access a larger or smaller address map than the width of their address signals allows. The Address Span Extender IP splits the addressable space into multiple separate windows so that the host can access the appropriate part of the memory through the window.

The Address Span Extender does not limit host and agent widths to a 32-bit and 64-bit configuration. You can use the Address Span Extender with 1-64 bit address windows.

**Figure 13. Address Span Extender Altera FPGA IP**



### Related Information

Quartus® Prime Pro Edition User Guide: Platform Designer

Refer to the topic Address Span Extender Intel® FPGA IP for more information.

#### 2.3.1.4.2. Using Address Span Extender IP with Nios V Processor

The 32-bit Nios V processor can address up to 4 GB of an address span. If the EMIF contains more than 4GB of memory, it exceeds the maximum supported address span, rendering the Platform Designer system as erroneous. An Address Span Extender IP is required to resolve this issue by dividing a single EMIF address space into multiple smaller windows.

Altera recommends that you consider the following parameters.

**Table 21. Address Span Extender Parameters**

Parameter	Recommended Settings
Datapath Width	Select 32-bits, which correlates to the 32-bit processor.
Expanded Master Byte Address Width	Depends on the EMIF memory size.
Slave Word Address Width	Select 2 GB or less. Remaining address span of Nios V processor is reserved for other embedded soft IPs.
Burstcount Width	Start with 1 and gradually increase this value to improve performance.
Number of sub-windows	Select 1 sub-window if you are connecting EMIF to the Nios V processor as instruction and data memory, or both. Switching between multiple sub-windows while Nios V processor is executing from EMIF is hazardous.
Enable Slave Control Port	Disable the slave control port if you are connecting EMIF to the Nios V processor as instruction and/or data memory. Same concerns as Number of sub-windows.
Maximum Pending Reads	Start with 1 and gradually increase this value to improve performance.

Figure 14. Connecting Instruction and Data Manager to Address Span Extender





Figure 15. Address Mapping

Assign Base Addresses				Export
Subordinate	address_span_extender_0/expanded_master	niosv/instruction_manager	niosv/data_manager	
address_span_extender_0/windowed_slave		0x0000_0000 - 0x3FF_FFF	0x0000_0000 - 0x3FF_FFF	
emif_ddr4/s0_axi4	0x0000_0000_0000_0000 - 0x0000_0007_FFF_FFF			
emif_ddr4/s0_axi4lite				
intel_archip_memory_0/s1		0x0000_0000 - 0x0003_FFF	0x0000_0000 - 0x0003_FFF	
niosv/timer_sw_agent			0x0004_0000 - 0x0004_000F	
niosv/dm_agent		0x0004_0000 - 0x0004_FFF	0x0004_0000 - 0x0004_FFF	
jtag_uart_0/avision_tag_slave			0x0005_0040 - 0x0005_0047	
emif_ddr4/s0_axi4 via address_span_extender_0		0x0000_0000 - 0x3FF_FFF	0x0000_0000 - 0x3FF_FFF	

Notice that the Address Span Extender can access the whole 8GB memory space of the EMIF. However, via the Address Span Extender, the Nios V processor can access only the first 1GB memory space of the EMIF.


Figure 16. Simplified Block Diagram



### 2.3.1.4.3. Defining Address Span Extender Linker Memory Device


1. Define the Address Span Extender (EMIF) as the reset vector. Alternatively, you can assign the Nios V processor reset vector to other memories, such as OCRAM or flash devices.

**Figure 17. Multiple Options as Reset Vector**



However, the Board Support Package (BSP) Editor cannot automatically register the Address Span Extender (EMIF) as a valid memory. Depending on the choice you made, you see two different situations as shown in the following figures.

**Figure 18. BSP Error when Defining Address Span Extender (EMIF) as Reset Vector**





### Figure 19. Missing EMIF when Defining Other Memories as Reset Vector

Main	BSP Software Packages	BSP Linker Script	BSP Enable File Generation	BSP Target Direct
<b>Linker Section Mappings</b>				
Linker Section Name	Linker Region Name	Memory Device Name		
.bss	intel_onchip_memory_0	intel_onchip_memory_0		
.copy	reset	intel_onchip_memory_0		
.exceptions	intel_onchip_memory_0	intel_onchip_memory_0		
.heap	intel_onchip_memory_0	intel_onchip_memory_0		
.rodata	intel_onchip_memory_0	intel_onchip_memory_0		
.rwdata	intel_onchip_memory_0	intel_onchip_memory_0		
.stack	intel_onchip_memory_0	intel_onchip_memory_0		
.text	intel_onchip_memory_0	intel_onchip_memory_0		
<b>Linker Memory Regions</b>				
Linker Region Name	Address Range	Memory Device Name	Size (Bytes)	Offset (Bytes)
intel_onchip_memory_0	0x40000020 - 0x4003F44F	intel_onchip_memory_0	262112	32
reset	0x40000000 - 0x4000001F	intel_onchip_memory_0	32	

2. You must manually add the Address Span Extender (EMIF) using **Add Memory Device**, **Add Linker Memory Region**, and **Add Linker Section Mappings** in the **BSP Linker Script** tab.
3. Follow these steps:
  - a. Determine the address span of the Address Span Extender using the **Memory Map** (The example in the following figure uses Address Span Extender range from 0x0 to 0x3fff\_ffff).

### Figure 20. Memory Map

WinBox Memory Map (00000000-00000000)

Device	Address Range	Size (bytes)	Attributes
jtag_uart_0	0x00000000 - 0x00000007	8	peripheral
niosv_timer_sw_agent	0x00000008 - 0x0000000F	64	
niosv_dm_agent	0x00000010 - 0x0000001F	65536	
intel_onchip_memory_0	0x00000020 - 0x000000FF	262144	memory
intel_ahb4	0x00000100 - 0x000001FF	131072	

Tree View:

- jtag\_uart\_0
- niosv\_timer\_sw\_agent
- niosv\_dm\_agent
- intel\_onchip\_memory\_0
- intel\_ahb4

Buttons:

- Add Memory Device
- Remove Memory Device
- Memory Usage
- Memory Map

BSP settings file:

- b. Click **Add Memory Device**, and fill in based on the information in your design's **Memory Map**:
  - i. Device Name: `emif_ddr4`.  
*Note:* Ensure you copy the same name from **Memory Map**.
  - ii. Base Address: 0x0
  - iii. Size: 0x40000000
- c. Click **Add** to add a new linker memory region:

**Table 22. Adding Linker Memory Region**

Steps	Reset Vector	
	emif_ddr4	Other memories
1	Add a new Linker Memory Region called <code>reset</code> . <ul style="list-style-type: none"> <li>Region Name: <code>reset</code></li> <li>Region Size: <code>0x20</code></li> <li>Memory Device: <code>emif_ddr4</code></li> <li>Memory Offset: <code>0x0</code></li> </ul>	Add a new Linker Memory Region for the <code>emif_ddr4</code> . <ul style="list-style-type: none"> <li>Region Name: <code>emif_ddr4</code></li> <li>Region Size: <code>0x40000000</code></li> <li>Memory Device: <code>emif_ddr4</code></li> <li>Memory Offset: <code>0x0</code></li> </ul>
2	Add a new Linker Memory Region for the remaining <code>emif_ddr4</code> . <ul style="list-style-type: none"> <li>Region Name: <code>emif_ddr4</code></li> <li>Region Size: <code>0x3fffffe0</code></li> <li>Memory Device: <code>emif_ddr4</code></li> <li>Memory Offset: <code>0x20</code></li> </ul>	

**Figure 21. Linker Region when Defining Address Span Extender (EMIF) as Reset Vector**

Linker Memory Regions				
Linker Region Name	Address Range	Memory Device Name	Size (bytes)	Offset (bytes)
intel_onchip_memory_0	0x40000000 - 0x4003ffff	intel_onchip_memory_0	262144	0
emif_ddr4	0x00000020 - 0x3fffffff	emif_ddr4	1073741792	32
reset	0x00000000 - 0x0000001f	emif_ddr4	32	0

**Figure 22. Linker Region when Defining Other Memories as Reset Vector**

Linker Memory Regions				
Linker Region Name	Address Range	Memory Device Name	Size (bytes)	Offset (bytes)
intel_onchip_memory_0	0x40000020 - 0x4003ffff	intel_onchip_memory_0	262112	32
reset	0x40000000 - 0x4000001f	intel_onchip_memory_0	32	0
emif_ddr4	0x00000000 - 0x3fffffff	emif_ddr4	1073751824	0

- d. Once the `emif_ddr4` is added to the BSP, you can select it for any **Linker Section**.

**Figure 23. Added Address Span Extender (EMIF) Successfully**

Linker Section Mappings		
Linker Section Name	Linker Region Name	Memory Device Name
.bss	emif_ddr4	emif_ddr4
.entry	reset	emif_ddr4
.exceptions	emif_ddr4	emif_ddr4
.heap	emif_ddr4	emif_ddr4
.rodata	intel_onchip_memory_0	intel_onchip_memory_0
.redata	intel_onchip_memory_0	intel_onchip_memory_0
.stack	emif_ddr4	emif_ddr4
.text	emif_ddr4	emif_ddr4

- e. Ignore the warning about *Memory device emif\_ddr4 is not visible in the SOPC design*.
- f. Proceed to **Generate BSP**.

### Related Information

[Introduction to Nios V Processor Booting Methods](#) on page 51

## 2.3.2. Non-Volatile Memory

Non-volatile memory retains its contents when the power switches off, making it a good choice for storing information that the system must retrieve after a system power cycle. Non-volatile memory commonly stores processor boot-code, persistent application settings, and Altera FPGA configuration data. Although non-volatile memory has the advantage of retaining its data when you remove the power, it is much slower compare to volatile memory, and often has more complex writing and erasing procedures. Non-volatile memory is also usually only guaranteed to be erasable a given number of times, after which it may fail.

Examples of non-volatile memory include all types of flash, EPROM, and EEPROM. Altera recommends you to store Altera FPGA bitstreams and Nios V program images in a non-volatile memory, and use serial flash as the boot device for Nios V processors.

### Related Information

- [Generic Serial Flash Interface Altera FPGA IP User Guide](#)
- [Mailbox Client Altera FPGA IP User Guide](#)
- [MAX® 10 User Flash Memory User Guide: On-Chip Flash Altera FPGA IP Core](#)

## 2.4. Clocks and Resets Best Practices

Understanding how the Nios V processor clock and reset domain interacts with every peripheral it connects to is important. A simple Nios V processor system starts with a single clock domain, and it can get complicated with a multi-clock domain system when a fast clock domain collides with a slow clock domain. You need to take note and understand how these different domains sequence out of reset and make sure there aren't any subtle problems.

For best practice, Altera recommends placing the Nios V processor and boot memory in the same clock domain. Do not release the Nios V processor from reset in a fast clock domain when it boots from a memory that resides in a very slow clock domain, which may cause an instruction fetch error. You may require some manual sequencing beyond what Platform Designer provides by default, and plan out reset release topology accordingly based on your use case. If you want to reset your system after it comes up and runs for a while, apply the same considerations to system reset sequencing and post reset initialization requirement.

### 2.4.1. System JTAG Clock

Specifying the clock constraints in every Nios V processor system is an important system design consideration and is required for correctness and deterministic behavior. The Quartus Prime Timing Analyzer performs static timing analysis to validate the timing performance of all logic in your design using industry-standard constraint, analysis, and reporting methodology.

#### Example 1. Basic 100 MHz Clock with 50/50 Duty Cycle and 16 MHz JTAG Clock

```
#####  
# Create 100MHz Clock  
#####  
create_clock -name {clk} -period 10 [get_ports {clk}]  
#####  
Create 16MHz JTAG Clock  
#####
```

```
create_clock -name {altera_reserved_tck} -period 62.500 [get_ports
{altera_reserved_tck}]
set_clock_groups -asynchronous -group [get_clocks {altera_reserved_tck}]
```

### Related Information

[Quartus Prime Timing Analyzer Cookbook](#)


## 2.4.2. Reset Request Interface

Nios V processor includes an optional reset request facility. The reset request facility consists of `reset_req` and `reset_req_ack` signals.

To enable the reset request in Platform Designer:

1. Launch the **Nios V Processor IP Parameter Editor**.
2. On the **Use Reset Request** setting, turn on the **Add Reset Request Interface** option.

**Figure 24. Enable Nios V Processor Reset Request**



The `reset_req` signal acts like an interrupt. When you assert the `reset_req`, you are requesting to reset to the core. The core waits for any outstanding bus transaction to complete its operation. For example, if there is a pending memory access transaction, the core waits for a complete response. Similarly, the core accepts any pending instruction response but does not issue an instruction request after receiving the `reset_req` signal.

The reset operation consists of the following flow:

1. Complete all pending operations
2. Flush the internal pipeline
3. Set the Program Counter to the reset vector
4. Reset the core

The whole reset operation takes a few clock cycles. The `reset_req` must remain asserted until `reset_req_ack` is asserted indicating core reset operation has successfully completed. Failure to do so results in core's state being non-deterministic.

### 2.4.2.1. Typical Use Cases

- You can assert the `reset_req` signal from power-on to prevent the Nios V processor core from starting program execution from its reset vector until other FPGA hosts in the system initialize the Nios V processor boot memory. In this case, the entire subsystem can experience a clean hardware reset. The Nios V processor is held indefinitely in a reset request state until the other FPGA hosts initialize the processor boot memory.
- In a system where you must reset the Nios V processor core without disrupting the rest of the system, you can assert the `reset_req` signal to cleanly halt the current operation of the core and restart the processor from the reset vector once the system releases the `reset_req_ack` signal.
- An external host can use the reset request interface to ease the implementations of the following tasks:
  - Halt the current Nios V processor program.
  - Load a new program into the Nios V processor boot memory.
  - Allow the processor to begin executing the new program.

Altera recommends you to implement a timeout mechanism to monitor the state of `reset_req_ack` signal. If the Nios V processor core falls into an infinite wait state condition and stalls for an unknown reason, `reset_req_ack` cannot assert indefinitely. The timeout mechanism enables you to:

- Define a recovery timeout period and perform system recovery with system level reset.
- Perform a hardware level reset.

### 2.4.3. Reset Release IP

Altera SDM-based devices use a parallel, sector-based architecture that distributes the core fabric logic across multiple sectors. Altera recommends you to use the Reset Release Altera FPGA IP as one of the initial inputs to the reset circuit. Intel® SDM-based devices includes Stratix® 10, and Agilex™ devices. Control-block based devices are not affected by this requirement.

#### Related Information

[AN 891: Using the Reset Release Altera FPGA IP](#)

## 2.5. Assigning a Default Agent

Platform Designer allows you to specify a default agent which acts as the error response default agent. The default agent you designate provides an error response service for hosts that attempt non-decoded accesses into the address map.

The following scenarios trigger a non decoded event:

- Bus transaction security state violation
- Transaction access to undefined memory region
- Exception event and etc.

A default agent should be assigned to handle such events, where undefined transaction is rerouted to the default agent and subsequently responds to Nios V processor with an error response.

### Related Information

- [Quartus Prime Pro Edition User Guide: Platform Designer. Designating a Default Agent](#)
- [Quartus Prime Pro Edition User Guide: Platform Designer. Error Response Slave Altera FPGA IP](#)
- [Github - Supplemental Reset Components for Qsys](#)

## 2.6. Assigning a UART Agent for Printing

Printing is useful for debugging the software application, as well as for monitoring the status of your system. Altera recommends printing basic information such as a start-up message, error message, and execution progress of the software application.

Avoid using the `printf()` library function under the following circumstances:

- The `printf()` library causes the application to stall if no host is reading output. This is applicable to the JTAG UART only.
- The `printf()` library consumes large amounts of program memory.

### 2.6.1. Preventing Stalls by the JTAG UART

**Table 23. Differences between Traditional UART and JTAG UART**

UART Type	Description
Traditional UART	Transmits serial data regardless of whether an external host is listening. If no host reads the serial data, the data is lost.
JTAG UART	Writes the transmitted data to an output buffer and relies on an external host to read from the buffer to empty it.

The JTAG UART driver waits when the output buffer is full. The JTAG UART driver waits for an external host to read from the output buffer before writing more transmit data. This process prevents the loss of transmit data.

However, when system debugging is not required, such as during production, embedded systems are deployed without a host PC connected to JTAG UART. If the system selected the JTAG UART as the UART agent, it could cause stalling system because no external host is connected.

To prevent stalling by JTAG UART, apply of the following options:

**Table 24. Prevention on Stalling by JTAG UART**

Options	During Hardware Development (in Platform Designer)	During Software Development (in Board Support Package Editor)
No UART interface and driver present	Remove JTAG UART from the system	Configure <code>hal.stdin</code> , <code>hal.stdout</code> and <code>hal.stderr</code> as <b>None</b> .
Use other UART interface and driver	Replace JTAG UART with other soft UART IP	Configure <code>hal.stdin</code> , <code>hal.stdout</code> and <code>hal.stderr</code> with other soft UART IP.
Preserve JTAG UART interface (without driver)	Preserve JTAG UART in the system	<ul style="list-style-type: none"> <li>Configure <code>hal.stdin</code>, <code>hal.stdout</code> and <code>hal.stderr</code> as <b>None</b> in the Board Support Package Editor.</li> <li>Disable JTAG UART driver in <b>BSP Driver</b> tab.</li> </ul>

## 2.7. JTAG Signals

The Nios V processor debug module uses the JTAG interface for software ELF download and software debugging. When you debug your design with the JTAG interface, the JTAG signals TCK, TMS, TDI, and TDO are implemented as part of the design. Specifying the JTAG signal constraints in every Nios V processor system is an important system design consideration and is required for correctness and deterministic behavior.

Altera recommends that any design's system clock frequency be at least four times the JTAG clock frequency to ensure that the on-chip instrumentation (OCI) core functions properly.

### Related Information


- [Quartus® Prime Timing Analyzer Cookbook: JTAG Signals](#)  
For more information about JTAG timing constraints guidelines.
- [KDB: Why does niosv-download fail with a non-pipelined Nios® V/m processor at JTAG frequency 24MHz or 16Mhz?](#)

## 2.8. Optimizing Platform Designer System Performance

Platform Designer provides tools for optimizing the performance of the system interconnect for Altera FPGA designs.



Figure 25. Optimization Examples



The example shown in the figure demonstrates the following steps:

1. Adds Pipeline Bridge to alleviate critical paths by placing it:
  - a. Between the Instruction Manager and its agents
  - b. Between the Data Manager and its agents
2. Apply True Dual port On-Chip RAM, with each port dedicated to the Instruction Manager and the Data Manager respectively





Refer to the following related links below, which present techniques for leveraging the available tools and the trade-offs of each implementation.


#### **Related Information**

- [Quartus® Prime Pro Edition User Guide: Platform Designer](#)  
Refer to the topic Optimizing Platform Designer System Performance for more information.
- [Quartus® Prime Standard Edition User Guide: Platform Designer](#)  
Refer to the topic Optimizing Platform Designer System Performance for more information.

### 3. Nios V Processor Software System Design

This chapter describes the Nios V processor software development flow and the software tools that you can use in developing your embedded design system. The content serves as an overview before developing a Nios V processor software system.

**Figure 26. Software Design Flow**



**Note:** Altera recommends that you use an Altera FPGA development kit or a custom prototype board for software development and debugging. Many peripherals and system-level features are available only when your software runs on an actual board.

## 3.1. Nios V Processor Software Development Flow

### 3.1.1. Board Support Package Project

A Nios V Board Support Package (BSP) project is a specialized library containing system-specific support code. A BSP provides a software runtime environment customized for one processor in a Nios V processor hardware system.

The Quartus Prime software provides **Nios V Board Support Package Editor** and **niosv-bsp** utility tools to modify settings that control the behavior of the BSP.

A BSP contains the following elements:

- Hardware abstraction layer
- Device drivers
- Optional software packages
- Optional real-time operating system

### 3.1.2. Application Project

A Nios V C/C++ application project has the following features:

- Consists of a collection of source code and a `CMakeLists.txt`.
  - The `CMakeLists.txt` compiles the source code and links it with a BSP and one or more optional libraries, to create one `.elf` file
- One of the source files contains function `main()`.
- Includes code that calls functions in libraries and BSPs.

Altera provides **niosv-app** utility tool in the Quartus Prime software utility tools to create the Application `CMakeLists.txt`, and RiscFree IDE for Altera FPGAs to modify the source code in an Eclipse-based environment.

## 3.2. Altera FPGA Embedded Development Tools

The Nios V processor supports the following tools for software development:

- Graphical User Interface (GUI) - Graphical development tools that are available in both Windows\* and Linux\* Operating Systems (OS).
  - Nios V Board Support Package Editor (Nios V BSP Editor)
  - Ashling RiscFree IDE for Altera FPGAs
- Command-Line Tools (CLI) - Development tools that are initiated from the Nios V Command Shell. Each tool provides its own documentation in the form of help accessible from the command line. Open the Nios V Command Shell and type the following command: `<name of tool> --help` to view the **Help** menu.
  - Nios V Utilities Tools
  - File Format Conversion Tools
  - Other Utilities Tools

**Table 25. GUI Tools and Command-line Tools Tasks Summary**

Task	GUI Tool	Command-line Tool
Creating a BSP	Nios V BSP Editor	<ul style="list-style-type: none"> <li>In Quartus Prime Pro Edition software: niosv-bsp -c -s=&lt;.qsys file&gt; -t=&lt;bsp type&gt; [OPTIONS] settings.bsp</li> <li>In Quartus Prime Standard Edition software: niosv-bsp -c -s=&lt;.sopcinfo file&gt; -t=&lt;bsp type&gt; [OPTIONS] settings.bsp</li> </ul>
Generating a BSP using existing .bsp file	Nios V BSP Editor	niosv-bsp -g [OPTIONS] settings.bsp
Updating a BSP	Nios V BSP Editor	niosv-bsp -u [OPTIONS] settings.bsp
Examining a BSP	Nios V BSP Editor	niosv-bsp -q -E=<tcl script> [OPTIONS] settings.bsp
Creating an application	-	niosv-app -a=<application directory> -b=<bsp directory> -s=<source files directory> [OPTIONS]
Creating a user library	-	niosv-app -l=<library directory> -s=<source files directory> -p=<public includes directory> [OPTIONS]
Modifying an application	RiscFree IDE for Altera FPGAs	Any command-line source editor
Modifying a user library	RiscFree IDE for Altera FPGAs	Any command-line source editor
Building an application	RiscFree IDE for Altera FPGAs	<ul style="list-style-type: none"> <li>make</li> <li>cmake</li> </ul>
Building a user library	RiscFree IDE for Altera FPGAs	<ul style="list-style-type: none"> <li>make</li> <li>cmake</li> </ul>
Downloading an application ELF	RiscFree IDE for Altera FPGAs	niosv-download
Converting the .elf file	-	<ul style="list-style-type: none"> <li>elf2flash</li> <li>elf2hex</li> </ul>

### Related Information

[Ashling RiscFree Integrated Development Environment \(IDE\) for Altera FPGAs User Guide](#)

### 3.2.1. Nios V Processor Board Support Package Editor

You can use the Nios V processor BSP Editor to perform the following tasks:

- Create or modify a Nios V processor BSP project
- Edit settings, linker regions, and section mappings
- Select software packages and device drivers.


The capabilities of the BSP Editor include the capabilities of the **niosv-bsp** utilities. Any project created in the BSP Editor can also be created using the command-line utilities.

**Note:** For Quartus Prime Standard Edition software, refer to *AN 980: Nios V Processor Quartus Prime Software Support* for the steps to invoke the BSP Editor GUI.

To launch the **BSP Editor**, follow these steps:

1. Open Platform Designer, and navigate to the **File** menu.
  - a. To open an existing BSP setting file, click **Open...**
  - b. To create a new BSP, click **New BSP...**
2. Select the **BSP Editor** tab and provide the appropriate details.

**Figure 27. Launch BSP Editor**



#### Related Information

[AN 980: Nios V Processor Quartus Prime Software Support](#)

### 3.2.2. RiscFree IDE for Altera FPGAs

The RiscFree IDE for Altera FPGAs is an Eclipse-based IDE for the Nios V processor. Altera recommends that you develop the Nios V processor software in this IDE for the following reasons:

- The features are developed and verified to be compatible with the Nios V processor build flow.
- Equipped with all the necessary toolchains and supporting tools which enables you to easily start Nios V processor development.

#### Related Information

[Ashling RiscFree Integrated Development Environment \(IDE\) for Altera FPGAs User Guide](#)

### 3.2.3. Nios V Utilities Tools

You can create, modify, and build Nios V programs with commands typed at a command line or embedded in a script. The Nios V command-line tools described in this section are in the `<Intel Quartus Prime software installation directory>/niosv/bin` directory.

**Table 26. Nios V Utilities Tools**

Command-Line Tools	Summary
niosv-app	To generate and configure an application project.
niosv-bsp	To create or update a BSP settings file and create the BSP files.
niosv-download	To download the ELF file to a Nios® V processor.
niosv-shell	To open the Nios V Command Shell.
niosv-stack-report	To inform you of the left-over memory space available to your application .elf for stack or heap usage.

### 3.2.4. File Format Conversion Tools

File format conversion is sometimes necessary when passing data from one utility to another. The file format conversion tools are in the <Intel Quartus Prime software installation directory>/niosv/bin directory.

**Table 27. File Format Conversion Tools**

Command-Line Tools	Summary
elf2flash	To translate the .elf file to .srec format for flash memory programming.
elf2hex	To translate the .elf file to .hex format for memory initialization.

### 3.2.5. Other Utilities Tools

You might require the following command-line tools when building a Nios V processor based system. These command-line tools are either provided by Intel in <Intel Quartus Prime installation directory>/quartus/bin or acquired from open-source tools.

**Table 28. Other Command-Line Tools**

Command-Line Tools	Type	Summary
juart-terminal	Intel-provided	To monitor stdout and stderr, and to provide input to a Nios® V processor subsystem through stdin. This tool only applies to the JTAG UART IP when it is connected to the Nios® V processor.
openocd	Intel-provided	To execute OpenOCD.
openocd-cfg-gen	Intel-provided	<ul style="list-style-type: none"> <li>To generate the OpenOCD configuration file.</li> <li>To display JTAG chain device index.</li> </ul>



## 4. Nios V Processor Configuration and Booting Solutions

---

You can configure the Nios V processor to boot and execute software from different memory locations. The boot memory is the Quad Serial Peripheral Interface (QSPI) flash, On-Chip Memory (OCRAM), or Tightly Coupled Memory (TCM).

### Related Information

- [Power-Up Trigger Conditions](#) on page 193
- [Power-Up Triggers](#)  
For more information about power-up triggers.

### 4.1. Introduction

The Nios V processor supports two types of boot processes:

- Execute-in-Place (XIP) using `alt_load()` function
- Program copied to RAM using boot copier.

The Nios V embedded programs development is based on the hardware abstraction layer (HAL). The HAL provides a small boot loader program (also known as boot copier) that copies relevant linker sections from the boot memory to their run time location at boot time. You can specify the program and data memory run time locations by manipulating the Board Support Package (BSP) Editor settings.

This section describes:

- Nios V processor boot copier that boots your Nios V processor system according to the boot memory selection
- Nios V processor booting options and general flow
- Nios V programming solutions for the selected boot memory

### 4.2. Linking Applications

When you generate the Nios V processor project, the **BSP Editor** generates two linker related files:

- `linker.x`: The linker command file that the generated application's makefile uses to create the `.elf` binary file.
- `linker.h`: Contains information about the linker memory layout.

All linker setting modifications you make to the BSP project affect the contents of these two linker files.

Every Nios V processor application contains the following linker sections:

**Table 29. Linker Sections**

Linker Sections	Descriptions
.text	Executable code.
.rodata	Any read-only data used in the execution of the program.
.rwdata	Stores read-write data used in the execution of the program.
.bss	Contains uninitialized static data.
.heap	Contains dynamically allocated memory.
.stack	Stores function-call parameters and other temporary data.

You can add additional linker sections to the `.elf` file to hold custom code and data. These linker sections are placed in named memory regions, defined to correspond with physical memory devices and addresses. By default, **BSP Editor** automatically generates these linker sections. However, you can control the linker sections for a particular application.

### 4.2.1. Linking Behavior

This section describes the **BSP Editor** default linking behavior and how to control the linking behavior.

#### 4.2.1.1. Default BSP Linking

During BSP configuration, the tools perform the following steps automatically:

1. Assign memory region names: Assign a name to each system memory device and add each name to the linker file as a memory region.
2. Find largest memory: Identify the largest read-and-write memory region in the linker file.
3. Assign linker sections: Place the default linker sections (`.text`, `.rodata`, `.rwdata`, `.bss`, `.heap`, and `.stack`) in the memory region identified in the previous step.
4. Write files: Write the `linker.x` and `linker.h` files.

Typically, the linker section allocation scheme works during the software development process because the application is guaranteed to function if the memory is large enough.

The rules for the default linking behavior are contained in the Altera-generated Tcl scripts `bsp-set-defaults.tcl` and `bsp-linker-utils.tcl` found in the `<Intel Quartus Prime installation directory>/niosv/scripts/bsp-defaults` directory. The `niosv-bsp` command invokes these scripts. Do not modify these scripts directly.



#### 4.2.1.2. Configurable BSP Linking

You can manage the default linking behavior in the **Linker Script** tab of the **BSP Editor**. Manipulate the linker script using the following methods:

- Add a memory region: Maps a memory region name to a physical memory device.
- Add a section mapping: Maps a section name to a memory region. The **BSP Editor** allows you to view the memory map before and after making changes.

### 4.3. Nios V Processor Booting Methods

There are a few methods to boot up the Nios V processor in Altera FPGA devices. The methods to boot up Nios V processor vary according to the flash memory selection and device families.

**Table 30. Supported Flash Memories with Respective Boot Options**


Supported Boot Memories	Device	Nios V Processor Booting Methods	Application Runtime Location	Boot Copier
On-Chip Flash (for Internal configuration)	Max 10 devices only (with On-Chip Flash IP)	Nios V processor application execute-in-place from On-Chip Flash	On-Chip Flash (XIP) + OCRAM/ External RAM (for writable data sections)	alt_load() function
		Nios V processor application copied from On-Chip Flash to RAM using boot copier	OCRAM/External RAM	Reusing Bootloader via GSFI
General Purpose QSPI Flash (for user data only)	All supported FPGA devices (with Generic Serial Flash Interface FPGA IP)	Nios V processor application execute-in-place from general purpose QSPI flash	General purpose QSPI flash (XIP) + OCRAM/ External RAM (for writable data sections)	alt_load() function
		Nios V processor application copied from general purpose QSPI flash to RAM using boot copier	OCRAM/External RAM	Bootloader via GSFI
Configuration QSPI Flash (for Active Serial configuration)	Control block-based devices (with Generic Serial Flash Interface Intel FPGA IP) <sup>(2)</sup>	Nios V processor application execute-in-place from configuration QSPI flash	Configuration QSPI flash (XIP) + OCRAM/ External RAM (for writable data sections)	alt_load() function
		Nios V processor application copied from configuration QSPI flash to RAM using boot copier	OCRAM/ External RAM	Bootloader via GSFI

*continued...*

<sup>(2)</sup> Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for the device list.

Supported Boot Memories	Device	Nios V Processor Booting Methods	Application Runtime Location	Boot Copier
	SDM-based devices (with Mailbox Client Intel FPGA IP). <sup>(2)</sup>	Nios V processor application copied from configuration QSPI flash to RAM using boot copier	OCRAM/ External RAM	Bootloader via SDM
On-chip Memory (OCRAM)	All supported Altera FPGA devices <sup>(2)</sup>	Nios V processor application execute-in-place from OCRAM	OCRAM	<code>alt_load()</code> function
Tightly Coupled Memory (TCM)	All supported Altera FPGA devices <sup>(2)</sup>	Nios V processor application execute-in-place from TCM	Instruction TCM (XIP) + Data TCM (for writable data sections)	None

**Figure 28. Nios V Processor Boot Flow**



#### Related Information

- [Generic Serial Flash Interface Altera FPGA IP User Guide](#)

- [Mailbox Client Altera FPGA IP User Guide](#)
- [AN 980: Nios V Processor Quartus Prime Software Support](#)

## 4.4. Introduction to Nios V Processor Booting Methods

Nios V processor systems require the software images to be configured in system memory before the processor can begin executing the application program. Refer to [Linker Sections](#) for the default linker sections.

The **BSP Editor** generates a linker script that performs the following functions:

- Ensures that the processor software is linked in accordance with the linker settings of the BSP editor and determines where the software resides in memory.
- Positions the processor's code region in the memory component according to the assigned memory components.

The following section briefly describes the available Nios V processor booting methods.

### 4.4.1. Nios V Processor Application Execute-In-Place from Boot Flash

Altera designed the flash controllers such that the boot flash address space is immediately accessible to the Nios V processor upon system reset, without the need to initialize the memory controller or memory devices. This enables the Nios V processor to execute application code stored on the boot devices directly without using a boot copier to copy the code to another memory type. The flash controllers are:

- On-Chip Flash with On-Chip Flash IP (only in MAX<sup>®</sup> 10 device)
- General purpose QSPI flash with Generic Serial Flash Interface IP
- Configuration QSPI flash with Generic Serial Flash Interface IP (except MAX 10 devices)

When the Nios V processor application execute-in-place from boot flash, the **BSP Editor** performs the following functions:

- Sets the `.text` linker sections to the boot flash memory region.
- Sets the `.bss`, `.rodata`, `.rwdata`, `.stack` and `.heap` linker sections to the RAM memory region.

You must enable the `alt_load()` function in the **BSP Settings** to copy the data sections (`.rodata`, `.rwdata`, `.exceptions`) to the RAM upon system reset. The code section (`.text`) remains in the boot flash memory region.

#### Related Information

- [Generic Serial Flash Interface Altera FPGA IP User Guide](#)
- [Altera MAX 10 User Flash Memory User Guide](#)

#### 4.4.1.1. `alt_load()`

You can enable the `alt_load()` function in the HAL code using the **BSP Editor**.

When used in the execute-in-place boot flow, the `alt_load()` function performs the following tasks:

- Operates as a mini boot copier that copies the memory sections to RAM based on the BSP settings.
- Copies data sections (`.rodata`, `.rwdata`, `.exceptions`) to RAM but not the code sections (`.text`). The code section (`.text`) is a read-only section and remains in the booting flash memory region. This partitioning helps to minimize the RAM usage but may limit the code execution performance because accesses to flash memory are slower than accesses to the on-chip RAM.

The following table lists the BSP Editor settings and functions:

**Table 31. BSP Editor Settings**

BSP Editor Setting	Function
<code>hal.linker.enable_alt_load</code>	Enables <code>alt_load()</code> function.
<code>hal.linker.enable_alt_load_copy_rodata</code>	<code>alt_load()</code> copies <code>.rodata</code> section to RAM.
<code>hal.linker.enable_alt_load_copy_rwdata</code>	<code>alt_load()</code> copies <code>.rwdata</code> section to RAM.
<code>hal.linker.enable_alt_load_copy_exceptions</code>	<code>alt_load()</code> copies <code>.exceptions</code> section to RAM.

#### 4.4.2. Nios V Processor Application Copied from Boot Flash to RAM Using Boot Copier

The Nios V processor and HAL include a boot copier that provides sufficient functionality for most Nios V processor applications and is convenient to implement with the Nios V software development flow.

When the application uses a boot copier, it sets all linker sections (`.text`, `.heap`, `.rwdata`, `.rodata`, `.bss`, `.stack`) to an internal or external RAM. Using the boot copier to copy a Nios V processor application from the boot flash to the internal or external RAM for execution helps to improve the execution performance.

For this boot option, the Nios V processor starts executing the boot copier software upon system reset. The software copies the application from the boot flash to the internal or external RAM. Once the process is complete, the Nios V processor transfers the program control over to the application.

**Note:** If the boot copier is in flash, then the `alt_load()` function does not need to be called because they both serve the same purpose.

##### 4.4.2.1. Nios V Processor Bootloader via Generic Serial Flash Interface

The Bootloader via GSFI is the Nios V processor boot copier that supports QSPI flash memory in control block-based devices. The Bootloader via GSFI includes the following features:


- Locates the software application in non-volatile memory.
- Unpacks and copies the software application image to RAM.
- Automatically switches processor execution to application code in RAM after copy completes.

The boot image is located right after the boot copier. You need to ensure the Nios V processor reset offset points to the start of the boot copier. The Figure: [Memory Map for QSPI Flash with Bootloader via GSFI](#) memory map for QSPI Flash with Bootloader via GSFI shows the flash memory map for QSPI flash when using a boot copier. This memory map assumes the flash memory stores the FPGA image and the application software.

**Table 32. Bootloader via GSFI for Nios V Processor Core**

Nios V Processor Core	Bootloader via GSFI File Location
Nios V/m processor	<Intel Quartus Installation Directory>/niosv/components/bootloader/niosv_m_bootloader.srec
Nios V/g processor	<Intel Quartus Installation Directory>/niosv/components/bootloader/niosv_g_bootloader.srec

**Figure 29. Memory Map for QSPI Flash with Bootloader via GSFI**



*Note:*

1. At the start of the memory map is the FPGA image followed by your data, which consists of boot copier and application code.
2. You must set the Nios V processor reset offset in Platform Designer and point it to the start of the boot copier.
3. The size of the FPGA image is unknown. You can only know the exact size after the Quartus Prime project compilation. You must determine an upper bound for the size of the Altera FPGA image. For example, if the size of the FPGA image is estimated to be less than 0x01E00000, set the Reset Offset to 0x01E00000 in Platform Designer, which is also the start of the boot copier.
4. A good design practice consists of setting the reset vector offset at a flash sector boundary to ensure no partial erase of the FPGA image occurs in case the software application is updated.

#### 4.4.2.2. Nios V Processor Bootloader via Secure Device Manager

The Bootloader via Secure Device Manager (SDM) is a HAL application code utilizing the Mailbox Client Altera FPGA IP HAL driver for processor booting. Altera recommends this bootloader application when using the configuration QSPI flash in SDM-based devices to boot the Nios V processor.


Upon system reset, the Nios V processor first boots the Bootloader via SDM from a tiny on-chip memory and executes the Bootloader via SDM to communicate with the configuration QSPI flash using the Mailbox Client IP.

The Bootloader via SDM performs the following tasks:

- Locates the Nios V software in the configuration QSPI flash.
- Copies the Nios V software into the on-chip RAM or external RAM.
- Switches the processor execution to the Nios V software within the on-chip RAM or external RAM.

Once the process is complete, the Bootloader via SDM transfers program control over to the user application. Altera recommends the memory organization as outlined in [Memory Organization for Bootloader via SDM](#).

**Figure 30. Bootloader via SDM Process Flow**



1. Nios V processor runs the Bootloader via SDM from the on-chip memory.
2. Bootloader via SDM communicates with the configuration flash and locates the Nios V software.
3. Bootloader via SDM copies the Nios V software from the Configuration Flash into on-chip RAM / external RAM.
4. Bootloader via SDM switches the Nios V processor execution to the Nios V software in the on-chip RAM / external RAM.

#### 4.4.3. Nios V Processor Application Execute-In-Place from OCRAM

In this method, the Nios V processor reset address is set to the base address of the on-chip memory (OCRAM). The application binary (.hex) file is loaded into the OCRAM when the FPGA is configured, after the hardware design is compiled in the Quartus Prime software. Once the Nios V processor resets, the application begins executing and branches to the entry point.

*Note:*

- Execute-In-Place from OCRAM does not require boot copier because Nios V processor application is already in place at system reset.
- Altera recommends enabling `alt_load()` for this booting method so that the embedded software behaves identically when reset without reconfiguring the FPGA device image.
- You must enable the `alt_load()` function in the **BSP Settings** to copy the `.rwd` data section upon system reset. In this method, the initial values for initialized variables are stored separately from the corresponding variables to avoid overwriting on program execution.

#### 4.4.4. Nios V Processor Application Execute-In-Place from TCM

The execute-in-place method sets the Nios V processor reset address to the base address of the tightly coupled memory (TCM). The application binary (`.hex`) file is loaded into the TCM when you configure the FPGA after you compile the hardware design in the Quartus Prime software. Once the Nios V processor resets, the application begins executing and branches to the entry point.

*Note:*

Execute-In-Place from TCM does not require boot copier because Nios V processor application is already in place at system reset.

#### 4.5. Nios V Processor Booting from On-Chip Flash (UFM)


Nios V processor booting and executing software from on-chip flash (UFM) is available in MAX 10 FPGA devices. The Nios V processor supports the following two boot options using On-Chip Flash under Internal Configuration mode:

- Nios V processor application executes in-place from On-Chip Flash.
- Nios V processor application is copied from On-Chip Flash to RAM using boot copier.

**Table 33. Supported Flash Memories with respective Boot Options**

Supported Boot Memories	Nios V Booting Methods	Application Runtime Location	Boot Copier
MAX 10 devices only (with On-Chip Flash IP)	Nios V processor application execute-in-place from On-Chip Flash	On-Chip Flash (XIP) + OCRAM/ External RAM (for writable data sections)	<code>alt_load()</code> function
	Nios V processor application copied from On-Chip Flash to RAM using boot copier	OCRAM/ External RAM	Reusing Bootloader via GSFI

**Figure 31. Design, Configuration, and Booting Flow**



#### 4.5.1. MAX 10 FPGA On-Chip Flash Description

MAX 10 FPGA devices contain on-chip flash that is segmented into two parts:

- Configuration Flash Memory (CFM) — stores the hardware configuration data for MAX 10 FPGAs.
- User Flash Memory (UFM) — stores the user data or software applications.

The UFM architecture of MAX 10 device is a combination of soft and hard IPs. You can only access the UFM using the On-Chip Flash IP Core in the Quartus Prime software.

The On-chip Flash IP core supports the following features:

- Read or write accesses to UFM and CFM (if enabled in Platform Designer) sectors using the Avalon MM data and control slave interface.
- Supports page erase, sector erase and sector write.
- Simulation model for UFM read/write accesses using various EDA simulation tools.



### Table 34. On-chip Flash Regions in MAX 10 FPGA Devices

Flash Regions	Functionality
Configuration Flash Memory (sectors CFM0-2)	FPGA configuration file storage
User Flash Memory (sectors UFM0-1)	Nios V processor application and user data

MAX 10 FPGA devices support several configuration modes and some of these modes allow CFM1 and CFM2 to be used as an additional UFM region. The following table shows the storage location of the FPGA configuration images based on the MAX 10 FPGA's configuration modes.

### Table 35. Storage Location of FPGA Configuration Images

Configuration Mode	CFM2	CFM1	CFM0
Dual compressed images	Compressed Image 2		Compressed Image 1
Single uncompressed image	Virtual UFM	Uncompressed image	
Single uncompressed image with Memory Initialization	Uncompressed image (with pre-initialized on-chip memory content)		
Single compressed image with Memory Initialization	Compressed image (with pre-initialized on-chip memory content)		
Single compressed image	Virtual UFM		Compressed Image

You must use the On-chip Flash IP core to access to the flash memory in MAX 10 FPGAs. You can instantiate and connect the On-chip Flash IP to the Quartus Prime software. The Nios V soft core processor uses the Platform Designer interconnects to communicate with the On-chip Flash IP.

### Figure 32. Connection between On-chip Flash IP and Nios V Processor



**Note:** Ensure the On-chip Flash `csr` port is connected to the Nios V processor `data_manager` to enable the processor to control write and erase operations.

The On-chip Flash IP core can provide access to five flash sectors - UFM0, UFM1, CFM0, CFM1, and CFM2.

Important information about the UFM and CFM sectors.:

- CFM sectors are intended for configuration (bitstream) data (\*.pof) storage.
- User data can be stored in the UFM sectors and may be hidden, if the correct settings are selected in the Platform Designer tool.
- Certain devices do not have a UFM1 sector. You can refer to the table: [UFM and CFM Sector Size](#) for available sectors in each individual MAX 10 FPGA device.

- You can configure CFM2 as a virtual UFM by selecting **Single Uncompressed Image** configuration mode.
- You can configure CFM2 and CFM1 as a virtual UFM by selecting **Single Uncompressed Image** configuration mode.
- The size of each sector varies with the selected MAX 10 FPGA devices.

**Table 36. UFM and CFM Sector Size**

This table lists the dimensions of the UFM and CFM arrays.

Device	Pages per Sector					Page Size (Kbit)	Maximum User Flash Memory Size (Kbit) <sup>(3)</sup>	Total Configuration Memory Size (Kbit)	OCRAM Size (Kbit)
	UFM1	UFM0	CFM2	CFM1	CFM0				
10M02	3	3	0	0	34	16	96	544	108
10M04	0	8	41	29	70	16	1248	2240	189
10M08	8	8	41	29	70	16	1376	2240	378
10M16	4	4	38	28	66	32	2368	4224	549
10M25	4	4	52	40	92	32	3200	5888	675
10M40	4	4	48	36	84	64	5888	10752	1260
10M50	4	4	48	36	84	64	5888	10752	1638

#### Related Information

- [MAX 10 FPGA Configuration User Guide](#)
- [Altera MAX 10 User Flash Memory User Guide](#)

### 4.5.2. Nios V Processor Application Execute-In-Place from UFM


The Execute-In-Place from UFM solution is suitable for Nios V processor applications which require limited on-chip memory usage. The `alt_load()` function operates as a mini boot copier that copies the data sections (`.rodata`, `.rdata`, or `.exceptions`) from boot memory to RAM based on the BSP settings. The code section (`.text`), which is a read only section, remains in the MAX 10 On-chip Flash memory region. This setup minimizes the RAM usage but may limit the code execution performance as access to the flash memory is slower than the on-chip RAM.

The Nios V processor application is programmed into the UFM sector. The Nios V processor's reset vector points to the UFM base address to execute code from the UFM after the system resets.

If you are using the source-level debugger to debug your application, you must use a hardware breakpoint. This is because the UFM does not support random memory access, which is necessary for soft breakpoint debugging.

**Note:** You cannot erase or write UFM while performing execute-in-place in the MAX 10. Switch to boot copier approach if you need to erase or write the UFM.

<sup>(3)</sup> The maximum possible value, which is dependent on the configuration mode you select.


**Figure 33. Nios V Processor Application XIP from UFM****4.5.2.1. Hardware Design Flow**

The following section describes a step-by-step method for building a bootable system for a Nios V processor application from On-Chip Flash. The example below is built using MAX 10 device.

**IP Component Settings**

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Make sure external RAM or On-Chip Memory (OCRAM) is added to your Platform Designer system.

**Figure 34. Example IP Connections in Platform Designer for Booting Nios V from On-Chip Flash (UFM)**




3. In the On-Chip Flash IP parameter editor, set the Configuration Mode to one of the following, according to your design preference:
  - **Single Uncompressed Image**
  - **Single Compressed Image**
  - **Single Uncompressed Image with Memory Initialization**
  - **Single Compressed Image with Memory Initialization**

For more information about **Dual Compressed Images**, refer to the *MAX 10 FPGA Configuration User Guide - Remote System Upgrade*.

**Note:** You must assign **Hidden Access** to every CFM regions in the On-Chip Flash IP.

**Figure 35. Configuration Mode Selection in On-Chip Flash Parameter Editor**




### On-Chip Flash IP Settings - UFM Initialization

You can choose one of the following methods according to your preference:

**Note:** The steps in the subsequent subchapters ([Software Design Flow](#) and [Programming](#)) depend on the selection you make here.

- Method 1: Initialize the UFM data in the SOF during compilation  
Quartus Prime includes the UFM initialization data in the SOF during compilation. SOF recompilation is needed if there are changes in the UFM data.
1. Check **Initialize flash content** and **Enable non-default initialization file**.

**Figure 36. Initialize Flash Contents and Enable Non-default Initialization File**



2. Specify the path of the generated .hex file (from the `elf2hex` command) in the **User created hex or mif file**.

**Figure 37. Adding the .hex File Path**



- Method 2: Combine UFM data with a compiled SOF during POF generation  
UFM data is combined with the compiled SOF when converting programming files. You do not need to recompile the SOF, even if the UFM data changes. During development, you do not have to recompile SOF files for changes in the application. Alterarecommends this method for application developers.
1. Uncheck **Initialize flash content**.


**Figure 38. Initialize Flash Content with Non-default Initialization File**



### Reset Agent Settings for Nios V Processor Execute-In-Place Method

1. In the Nios V processor parameter editor, set the **Reset Agent** to On-Chip Flash.

**Figure 39. Nios V Processor Parameter Editor Settings with Reset Agent Set to On-Chip Flash**



2. Click **Generate HDL** when the **Generation** dialog box appears.
3. Specify output file generation options and click **Generate**.

### Quartus Prime Software Settings

1. In the Quartus Prime software, click **Assignments > Device > Device and Pin Options > Configuration**. Set the **Configuration mode** according to the setting in On-Chip Flash IP.

**Figure 40. Configuration Mode Selection in Quartus Prime Software**



2. Click **OK** to exit the **Device and Pin Options** window,
3. Click **OK** to exit the **Device** window.
4. Click **Processing > Start Compilation** to compile your project and generate the .sof file.

**Note:** If the configuration mode setting in Quartus Prime software and Platform Designer parameter editor is different, the Quartus Prime project fails with the following error message.

**Figure 41. Error Message for Different Configuration Mode Setting**

```
Error (14740): Configuration mode on atom "q_sys:q_sys_inst|
altera_onchip_flash:onchip_flash_1|altera_onchip_flash_block:
altera_onchip_flash_block|ufm_block" does not match the project setting. Update
and regenerate the Qsys system to match
the project setting.
```

### Related Information

[MAX 10 FPGA Configuration User Guide](#)

### 4.5.2.2. Software Design Flow

This section provides the design flow to generate and build the Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `hal_app` and `hal_bsp`.

**Figure 42. Software Project Directory Tree**




### Creating the Application BSP Project

To launch the BSP Editor, follow these steps:

1. Enter the Nios V Command Shell.
2. Invoke the BSP Editor with `niosv-bsp-editor` command.
3. In the BSP Editor, click **File ► New BSP** to start your BSP project.
4. Configure the following settings:
  - **SOPC Information File name:** Provide the SOPCINFO file (`.sopcinfo`).
  - **CPU name:** Select Nios V processor.
  - **Operating system:** Select the operating system of the Nios V processor.
  - **Version:** Leave as default.
  - **BSP target directory:** Select the directory path of the BSP project. You can pre-set it at `<Project directory>/software/hal_bsp` by enabling **Use default locations**.
  - **BSP Settings File name:** Type the name of the BSP Settings File.
  - **Additional Tcl scripts:** Provide a BSP Tcl script by enabling **Enable Additional Tcl script**.
5. Click **OK**.

Figure 43. Configure New BSP



### Configuring the BSP Editor and Generating the BSP Project

You can define the processor's exception vector either in On-Chip Memory (OCRAM) or On-Chip Flash based on your design preference. Setting the exception vector memory to OCRAM/External RAM is recommended to make the interrupt processing faster.

1. Go to **Main ► Settings ► Advanced ► hal.linker**.
2. If you select On-Chip Flash as exception vector,
  - a. Enable the following settings:


- **allow\_code\_at\_reset**
- **enable\_alt\_load**
- **enable\_alt\_load\_copy\_rodata**
- **enable\_alt\_load\_copy\_rwdata**

Figure 44. Advanced.hal.linker Settings



- Click on the **Linker Script** tab in the BSP Editor.
- Set the **.exceptions** and **.text** regions in the **Linker Section Name** to On-Chip Flash.
- Set the rest of the regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.

Figure 45. Linker Region Settings (Exception Vector Memory: On-Chip Flash)



- If you select OCRAM/External RAM as exception vector,
  - Enable the following settings:
    - **allow\_code\_at\_reset**
    - **enable\_alt\_load**
    - **enable\_alt\_load\_copy\_rodata**
    - **enable\_alt\_load\_copy\_rwdata**
    - **enable\_alt\_load\_copy\_exception**

Figure 46. Linker Region Settings (Exception Vector Memory: OCRAM/External RAM)



- Click on the **Linker Script** tab in the BSP Editor.
- Set the **.text** regions in the **Linker Section Name** to On-Chip Flash.
- Set the rest of the regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.



**Figure 47. Linker Region Settings (Exception Vector Memory: OCRAM)**

Linker Region Name	Linker Region Name	Memory Device Name
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0
Exception Vector Memory	onchip_flash_0	onchip_flash_0

4. Click **Generate** to generate the BSP project.

### Generating the User Application Project File

1. Navigate to the `software/hal_app` folder and create your application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application `CMakeLists.txt`.

```
niosv-app --app-dir=software/hal_app --bsp-dir=software/hal_bsp \
--srcs=software/hal_app/<user application>
```

### Building the User Application Project

You can choose to build the user application project using Ashling RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the user application using the following command:

```
cmake -G "Unix Makefiles" -B software/hal_app/build -S software/hal_app
make -C software/hal_app/build
```

The application (`.elf`) file is created in `software/hal_app/build` folder.

### Generating the HEX File

You must generate a `.hex` file from your application `.elf` file, so you can create a `.pof` file suitable for programming the devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from On-Chip Flash, use the following command line to convert the ELF to HEX for your application. This command creates the user application (`onchip_flash.hex`) file.

```
elf2hex software/hal_app/build/<user_application>.elf -o onchip_flash.hex \
-b <base address of On-Chip Flash UFM region> \
-w 8 \
-e <end address of On-Chip Flash UFM region>
```

3. Recompile the hardware design if you check **Initialize memory content** option in On-Chip Flash IP (Method 1). This is to include the software data (`.HEX`) in the SOF file.

### 4.5.2.3. Programming

1. In Quartus Prime, click **File ► Convert Programming Files**.
2. Under Output programming file, choose **Programmer Object File (.pof)** as Programming file type.
3. Set **Mode** to **Internal Configuration**.

Figure 48. Convert Programming File Settings



4. Click **Options/Boot info...**, the MAX 10 Device Options window appears.
5. Based on the **Initialize flash content** settings in the On-chip Flash IP, perform one of the following steps:
  - If **Initialize flash content** is checked (Method 1), the UFM initialization data was included in the SOF during Quartus Prime compilation.
    - Select **Page\_0** for **UFM source**: option. Click **OK** and proceed to the next.

Figure 49. Setting Page\_0 for UFM Source if Initialize Flash Content is Checked



- If **Initialize flash content** is not checked (Method 2), choose **Load memory file** for the **UFM source** option. Browse to the generated On-chip Flash HEX file (onchip\_flash.hex) in the **File path**: and click **OK**. This step adds UFM data separately to the SOF file during the programming file conversion.

**Figure 50. Setting Load Memory File for UFM Source if Initialize Flash Content is Not Checked**



6. In the Convert Programming File dialog box, at the **Input files to convert** section, click **Add File...** and point to the generated Quartus Prime .sof file.

**Figure 51. Input Files to Convert in Convert Programming Files for Single Image Mode**



7. Click Generate to create the .pof file.
8. Program the .pof file into your MAX 10 device.
9. Power cycle your hardware.


### 4.5.3. Nios V Processor Application Copied from UFM to RAM using Boot Copier

Altera recommends this solution for MAX 10 FPGA Nios V processor system designs where multiple iterations of application software development and high system performance are required. The boot copier is located within the UFM at an offset that is the same address as the reset vector. The Nios V application is located next to the boot copier.

For this boot option, the Nios V processor starts executing the boot copier upon system reset to copy the application from the UFM sector to the OCRM or external RAM. Once copying is complete, the Nios V processor transfers the program control over to the application.

**Note:** The applied boot copier is the same as the Bootloader via GSFI.

**Figure 52. Nios V Application Copied from UFM to RAM using Boot Copier**




#### 4.5.3.1. Hardware Design Flow

The following section describes a step-by-step method for building a bootable system for a Nios V processor application copied from On-Chip Flash to RAM using boot copier. The example below is built using MAX 10 device.

##### IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Make sure external RAM or On-Chip Memory (OCRAM) is added to your Platform Designer system.

**Figure 53. Example IP Connections in Platform Designer for Booting Nios V Processor from On-Chip Flash (UFM)**



3. In the On-Chip Flash IP parameter editor, set the Configuration Mode to one of the following, according to your design preference:
  - **Single Uncompressed Image**
  - **Single Compressed Image**
  - **Single Uncompressed Image with Memory Initialization**
  - **Single Compressed Image with Memory Initialization**

For **Dual Compressed Images**, refer to the MAX 10 FPGA Configuration User Guide - Remote System Upgrade for more information.

*Note:* You must assign **Hidden Access** to every CFM regions in the On-Chip Flash IP.

**Figure 54. Configuration Mode Selection in On-Chip Flash Parameter Editor**



### On-Chip Flash IP Settings - UFM Initialization

You can choose one of the following methods according to your preference:

**Note:** The steps in the subsequent subchapters ([Software Design Flow](#) and [Hardware Design Flow](#)) depend on the selection you make here.

- Method 1: Initialize the UFM data in the SOF during compilation  
Quartus Prime includes the UFM initialization data in the SOF during compilation. SOF recompilation is needed if there are changes in the UFM data.  
1. Check **Initialize flash content** and **Enable non-default initialization file**.

**Figure 55. Initialize Flash Contents and Enable Non-default Initialization File**



- Specify the path of the generated .hex file (from the elf2hex command and riscv32-unknown-elf-objcopy) in the **User created hex or mif file**.

**Figure 56. Adding the .hex File Path**



- Method 2: Combine UFM data with a compiled SOF during POE generation  
UFM data is combined with the compiled SOF when converting programming files. You do not need to recompile the SOF, even if the UFM data changes. During development, you do not have to recompile SOF files for changes in the application. Alterarecommends this method for application developers.  
1. Uncheck **Initialize flash content**.


**Figure 57. Initialize Flash Content with Non-default Initialization File**



### Reset Agent Settings for Nios V Processor Boot-copier Method

- In the Nios V processor parameter editor, set the **Reset Agent** to On-Chip Flash.

**Figure 58. Nios V Processor Parameter Editor Settings with Reset Agent Set to On-Chip Flash**



- Click **Generate HDL** when the **Generation** dialog box appears.
- Specify output file generation options and click **Generate**.

### Quartus Prime Software Settings

1. In the Quartus Prime software, click **Assignments > Device > Device and Pin Options > Configuration**. Set the **Configuration mode** according to the setting in On-Chip Flash IP.

**Figure 59. Configuration Mode Selection in Quartus Prime Software**



2. Click **OK** to exit the **Device and Pin Options** window,
3. Click **OK** to exit the **Device** window.
4. Click **Processing > Start Compilation** to compile your project and generate the .sof file.

*Note:* If the configuration mode setting in Quartus Prime software and Platform Designer parameter editor is different, the Quartus Prime project fails with the following error message.

**Figure 60. Error Message for Different Configuration Mode Setting**

```
Error (14740): Configuration mode on atom "q_sys:q_sys_inst|
altera_onchip_flash:onchip_flash_1|
altera_onchip_flash_block:altera_onchip_flash_block|ufm_block" does not match
the project setting.
Update and regenerate the Qsys system to match the project setting.
```

### 4.5.3.2. Software Design Flow

This section provides the design flow to generate and build the Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `hal_app` and `hal_bsp`.

**Figure 61. Software Project Directory Tree**




## Creating the Application BSP Project

To launch the BSP Editor, follow these steps:

1. Enter the Nios V Command Shell.
2. Invoke the BSP Editor with `niosv-bsp-editor` command.
3. In the BSP Editor, click **File** ► **New BSP** to start your BSP project.
4. Configure the following settings:
  - **SOPC Information File name:** Provide the SOPCINFO file (.sopcinfo).
  - **CPU name:** Select Nios V processor.
  - **Operating system:** Select the operating system of the Nios V processor.
  - **Version:** Leave as default.
  - **BSP target directory:** Select the directory path of the BSP project. You can pre-set it at <Project directory>/software/hal\_bsp by enabling **Use default locations**.
  - **BSP Settings File name:** Type the name of the BSP Settings File.
  - **Additional Tcl scripts:** Provide a BSP Tcl script by enabling **Enable Additional Tcl script**.
5. Click **OK**.

**Figure 62. Configure New BSP**



## Configuring the BSP Editor and Generating the BSP Project

1. Go to **Main** ► **Settings** ► **Advanced** ► **hal.linker**
2. Leave all settings unchecked.




Figure 63. Advanced.hal.linker Settings



3. Click on the **Linker Script** tab in the BSP Editor.
4. Set all regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.

Figure 64. Linker Region Settings



5. Click **Generate BSP** to generate the BSP project.

### Generating the User Application Project File

1. Navigate to the `software/hal_app` folder and create your application source code,
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application `CMakeLists.txt`.

```
niosv-app --app-dir=software/hal_app --bsp-dir=software/hal_bsp \
--srcs=software/hal_app/<user application>
```

### Building the User Application Project

You can choose to build the user application project using Ashling RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the user application using the following command:

```
cmake -G "Unix Makefiles" -B software/hal_app/build -S software/hal_app
make -C software/hal_app/build
```

The application (`.elf`) file is created in `software/hal_app/build` folder.

### Generating the HEX File

You must generate a .hex file from your application .elf file, so you can create a .pof file suitable for programming the devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from On-Chip Flash, use the following command line to convert the ELF to HEX for your application. This command creates the user application (onchip\_flash.hex) file.
3. Select the suitable Bootloader via GSFI in the elf2flash command.

```
elf2flash
--boot <Intel Quartus Prime installation directory>/
niosv/components/bootloader/<Bootloader via GSFI>
--input software/hal_app/build/<Nios V application>.elf \
--output flash.srec --reset <reset offset + base address of On-Chip Flash
UFM region> \
--base <base address of On-Chip Flash UFM region> \
--end <end address of On-Chip Flash UFM region>
```

```
riscv32-unknown-elf-objcopy --input-target srec --output-target ihex \
flash.srec <Nios V application>.hex
```

4. Recompile the hardware design if you check **Initialize memory content** option in On-Chip Flash IP (Method 1). This is to include the software data (.HEX) in the SOF file.

### 4.5.3.3. Programming

1. In Quartus Prime, click **File ► Convert Programming Files**.
2. Under Output programming file, choose **Programmer Object File (.pof)** as **Programming file type**.
3. Set **Mode** to **Internal Configuration**.

Figure 65. Convert Programming File Settings



4. Click **Options/Boot info...**, the MAX 10 Device Options window appears.
5. Based on the **Initialize flash content** settings in the On-chip Flash IP, do one of the following:


- If you select **Initialize flash content** (Method 1), the UFM initialization data was included in the SOF during Quartus Prime compilation.
  - For **Single Uncompressed/ Compressed Image** configuration mode, select **Page\_0** for **UFM source**: option. Click **OK** and proceed to the next step.

**Figure 66. Setting Page\_0 for UFM Source if Initialize Flash Content is Checked**



- If you turn off **Initialize flash content** (Method 2), choose **Load memory file** for the **UFM source** option. Browse to the generated On-chip Flash HEX file (onchip\_flash.hex) in the **File path**: and click **OK**. This step adds UFM data separately to the SOF file during the programming file conversion.

**Figure 67. Setting Load Memory File for UFM Source if Initialize Flash Content is Not Checked**



6. In the **Convert Programming File** dialog box, at the **Input files to convert** section, click **Add File...** and point to the generated Quartus Prime .sof file.

**Figure 68. Input Files to Convert in Convert Programming Files for Single Image Mode**



7. Click Generate to create the .po file.
8. Program the .po file into your MAX 10 device.
9. Power cycle your hardware.

## 4.6. Nios V Processor Booting from General Purpose QSPI Flash


The Nios V processor supports the following two boot options using general purpose QSPI flash:

- Nios V processor application executes in-place from general purpose QSPI flash.
- Nios V processor application is copied from general purpose QSPI flash to RAM using boot copier.

**Table 37. Supported Flash Memories with respective Boot Options**

Supported Boot Memories	Nios V Booting Methods	Application Runtime Location	Boot Copier
All FPGA devices (with Generic Serial Flash Interface Altera FPGA IP)	Nios V processor application execute-in-place from general purpose QSPI flash	Configuration QSPI flash (XIP) + OCRAM/ External RAM (for writable data sections)	alt_load() function
	Nios V processor application copied from general purpose QSPI flash to RAM using boot copier	OCRAM/ External RAM	Bootloader via GSFI

**Figure 69. Design, Configuration and Booting Flow**




#### 4.6.1. Nios V Processor Application Executes-In-Place from General Purpose QSPI Flash

The execute-in-place (XIP) option is suitable for Nios V processor application, when only a limited amount of on-chip memory is available to the processor.

The `alt_load()` function operates as a mini boot copier that initializes and copies the writable memory sections only to OCRAM or external RAM. The code section (.text), which is a read-only section, remains in the general purpose QSPI flash memory region. Retaining the read-only section in general purpose QSPI minimizes RAM usage but may limit the code execution performance.

The Nios V processor application is programmed into the general purpose QSPI flash. The Nios V processor reset the agent points to the general purpose QSPI flash to allow code execution after the system resets.

**Figure 70. Nios V Processor Application Executes-In-Place from General Purpose QSPI Flash**





*Note:* The Micron N25Q512A83GSF40F devices (in the Altera MAX 10 FPGA Development Kit) is at 4-byte addressing mode after power cycle.

6. Export the `qspi_pins` conduit.

*Note:* You may configure the **SPI Clock Baud-rate Register** to modify the flash access speed.

For MAX 10 FPGA Development Kit, Altera recommends you to apply 0x1 (/2) when the Generic Serial Flash Interface IP is connected to 50 MHz system clock. The default 0x10 (/32) divisor results in QSPI clock of 1.56 MHz, which causes a racing condition when XIP from the QSPI. Increasing the QSPI clock (by reducing the divisor) alleviates the issue.

#### Reset Agent Settings for Nios V Processor Execute-In-Place from General Purpose QSPI Method

1. In the Nios V processor IP parameter editor, set the **Reset Agent** to QSPI Flash.

**Figure 73. Nios V Parameter Editor Settings**



2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

#### Quartus Prime Software Settings

1. In the Quartus Prime software, click **Assignment > Device > Device and Pin Options > Configuration**.
2. Set the **Configuration scheme** according to your FPGA configuration scheme.
3. Click **OK** to exit the **Device and Pin Options** window.
4. Click **OK** to exit the **Device** window
5. Assign the GSFI pin assignment to the general purpose QSPI flash. Refer to MAX 10 FPGA Development Kit User Guide for more information on the board components and their respective MAX 10 FPGA pin number.
6. Click **Start Compilation** to compile your project.

#### 4.6.1.2. Software Design Flow

This section provides the design flow to generate and build a Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The software design flow is based on this directory tree.

Use the following steps to create the software project directory tree:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `app` and `bsp`.

**Figure 74. Software Project Directory Tree**




### Creating the BSP Project Application

To launch the BSP Editor, perform the following steps:

1. Enter the Nios V Command Shell.
2. Invoke the BSP Editor with `niosv-bsp-editor` command.
3. In the BSP Editor, click **File ► New BSP** to start your BSP project.
4. Configure the following settings:
  - **SOPC Information File name:** Provide the SOPCINFO file (`.sopcinfo`).
  - **CPU name:** Select Nios V processor.
  - **Operating system:** Select the operating system of the Nios V processor.
  - **Version:** Leave as default.
  - **BSP target directory:** Select the directory path of the BSP project. You can pre-set it at `<Project directory>/software/hal_bsp` by enabling **Use default locations**.
  - **BSP Settings File name:** Type the name of the BSP Settings File.
  - **Additional Tcl scripts:** Provide a BSP Tcl script by enabling **Enable Additional Tcl script**.
  - Click **OK**.

**Figure 75. Configure New BSP**





## Configuring BSP Editor and Generating the BSP Project

You can define the processor's exception vector either in On-Chip Memory (OCRAM) or QSPI Flash based on your design preference. Setting the exception vector memory to OCRAM/External RAM is recommended to make the interrupt processing faster.

1. Go to **Main ► Settings ► Advanced ► hal.linker**.
2. If you select QSPI Flash as exception vector, follow these steps:
  - a. Turn on the following settings:
    - **allow\_code\_at\_reset**
    - **enable\_alt\_load**
    - **enable\_alt\_load\_copy\_rodata**
    - **enable\_alt\_load\_copy\_rwdata**

**Figure 76. Advanced.hal.linker Settings**

This setting is available if exception vector memory is set to On-Chip Memory (OCRAM)



- b. Click on the **Linker Script** tab in the BSP Editor.
- c. Set **.exceptions** and **.text** regions in the **Linker Section Name** to QSPI Flash.
- d. Set the rest of the regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.

**Figure 77. Linker Region Settings (Exception Vector Memory: QSPI Flash)**

Linker Section Name	Linker Region Name	Memory Device Name
.bss	onchip_memory2_0	onchip_memory2_0
.copy	onchip_memory2_0	onchip_memory2_0
.exceptions	intel_generic_serial_f...	intel_generic_serial_flash_interface_top_0_avl_000
.heap	onchip_memory2_0	onchip_memory2_0
.rodata	onchip_memory2_0	onchip_memory2_0
.rwdata	onchip_memory2_0	onchip_memory2_0
.stack	onchip_memory2_0	onchip_memory2_0
.text	intel_generic_serial_f...	intel_generic_serial_flash_interface_top_0_avl_000

3. If you select OCRAM/External RAM as exception vector, follow these steps:
  - a. Enable the following settings:
    - **allow\_code\_at\_reset**
    - **enable\_alt\_load**
    - **enable\_alt\_load\_copy\_rodata**
    - **enable\_alt\_load\_copy\_rwdata**
    - **enable\_alt\_load\_copy\_exception**

**Figure 78. Advanced.hal.linker Settings**

This setting is available if exception vector memory is set to On-Chip Memory (OCRAM) or external RAM.



- b. Click on the **Linker Script** tab in the BSP Editor.
- c. Set the **.text** regions in the **Linker Section Name** to QSPI Flash.
- d. Set the rest of the regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.

**Figure 79. Linker Region Settings (Exception Vector Memory: OCRAM)**

Linker Section Name	Linker Region Name	Memory Section Name
.bss	onchip_memory2_0	onchip_memory2_0
.data	onchip_memory2_0	onchip_memory2_0
.rodata	onchip_memory2_0	onchip_memory2_0
.rwdata	onchip_memory2_0	onchip_memory2_0
.stack	onchip_memory2_0	onchip_memory2_0
.heap	onchip_memory2_0	onchip_memory2_0
.text	intel_generic_serial_flash_interface_top_0_0_0_0_0_0	intel_generic_serial_flash_interface_top_0_0_0_0_0_0

4. Navigate to the **BSP Drivers** tab.
5. Turn off the Generic Serial Flash Interface driver (intel\_generic\_serial\_flash\_interface\_top).
6. Click **Generate** to generate the BSP project.

### Generating the User Application Project File

1. Navigate to the software/hal folder and create your application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application CMakeLists.txt.

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/hal app/<user application>
```

### Building the Application Project

You can choose to build the application project using the RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the application using the following command:

```
cmake -G "Unix Makefiles" -B software \
hal_app/build -S software/hal_app
```

```
make -C software/hal app/debug
```

The application (.elf) file is created in software/app/debug folder.

### Generating HEX File

You must generate a .hex file from your application .elf file, so you can create a .pof file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from QSPI flash, use the following commands line to convert the ELF to HEX for your application.

```
elf2flash --input software/hal_app/debug/<Nios V application>.elf \  
--output flash.srec --reset <reset offset + base address of GSFI AVL MEM> \  
--base <base address of GSFI AVL MEM> \  
--end <end address of GSFI AVL MEM>
```

```
riscv32-unknown-elf-objcopy --input-target srec --output-target ihex \  
flash.srec <Nios V application>.hex
```

#### 4.6.1.3. Programming Files Generation

The programming files generation for FPGA configuration is not included. Unlike Max 10 On-Chip Flash or Active Serial configuration flash, the general purpose QSPI flash is not for FPGA configuration.

#### Software Programmer Object File (.pof) Generation

*Note:* The quartus.ini file with PGMIO\_SWAP\_HEX\_BYTE\_DATA=ON content is required to byteswap the software HEX file during the POF generation. Create the quartus.ini file or use the quartus.ini available in the related information. Place the quartus.ini file under Quartus Prime tool directory or project directory before you proceed.

1. In Quartus Prime, click **Convert Programming Files** from the **File** tab.
2. Choose **Programmer Object File (.pof)** as **Programming file type**.
3. Set **Mode** to **1-bit Passive Serial**.
4. Set **Configuration device** to **CFI\_512Mb**.
5. Change the **File name** to the desired path and name.
6. Remove the SOF **Page\_0**.
7. Click on **Add HEX Data**, choose the HEX file generated in **HEX file** section.
8. Select **Absolute Addressing** and **Little endian**, and click **OK**.
9. Click **Generate** to create the software .pof file.

**Figure 80. HEX to POF File Conversion**



#### 4.6.1.4. QSPI Flash Programming

##### Generate Parallel Flash Loader

1. Create a new Max 10 FPGA project.
2. Instantiate a Parallel Flash Loader in the system.
3. Configure the IP as follows:
  - a. What operating mode will be used? **Flash Programming**
  - b. What is the target flash? **Quad SPI Flash**
  - c. How many flash devices will be used? **1**
  - d. What's the Quad SPI flash device manufacturer? **Micron**
  - e. What's the Quad SPI flash device density? **QSPI 512 Mbit**
4. Connect the IP interface as follows:
  - a. flash\_io0 - QSPI data 0
  - b. flash\_io1 - QSPI data 1
  - c. flash\_io2 - QSPI data 2
  - d. flash\_io3 - QSPI data 3
  - e. flash\_ncs - QSPI chip select
  - f. flash\_sck - QSPI clock
  - g. pfl\_flash\_access\_granted - VCC (1'b1)
  - h. pfl\_nreset - VCC (1'b1)

Figure 81. Interface Connection

```

module max10_pfl (
    input wire flash_io0,
    input wire flash_io1,
    input wire flash_io2,
    input wire flash_io3,
    output wire flash_nce,
    output wire flash_sck
)

max10_pfl_00 (
    .flash_io0 (flash_io0),
    .flash_io1 (flash_io1),
    .flash_io2 (flash_io2),
    .flash_io3 (flash_io3),
    .flash_nce (flash_nce),
    .flash_sck (flash_sck),
    .pfl_flash_access_granted (1'b1),
    .pfl_flash_access_request (1'b1),
    .pfl_nreset (1'b1)
)
endmodule

```

## 5. Apply timing constraints.

```

derive_pll_clocks

# JTAG Signal Constraints constrain the TCK port, assuming a 24MHz JTAG
# clock and 5ns delays
create_clock -name {altera_reserved_tck} -period 41.667 [get_ports
{ altera_reserved_tck }]
set_input_delay -clock altera_reserved_tck -clock_fall -max 5 [get_ports
altera_reserved_tdi]
set_input_delay -clock altera_reserved_tck -clock_fall -max 5 [get_ports
altera_reserved_tms]
set_output_delay -clock altera_reserved_tck 5 [get_ports altera_reserved_tdo]

#
#some clock uncertainty is required
#
derive_clock_uncertainty

set_false_path -from [get_ports {flash_io1}]
set_false_path -to [get_ports {flash_*}]

```

## 6. Compile the PFL design.


## 7. Generate the PFL design SOF file.

**Software POF File Programming into General Purpose QSPI**

**Note:** You need to program the parallel flash loader into the Intel MAX 10 device before programming the QSPI flash.

1. Program the PFL design SOF file using **Quartus Programmer**.
2. Click on **Auto-Detect** after the PFL is successfully programmed.
3. Click **Yes** to overwrite the existing JTAG chain.
4. A new QSPI flash device will be shown on the screen, connected to MAX 10 device. It is the targeted general purpose QSPI flash.

Figure 82. General Purpose QSPI Flash in JTAG Chain



5. Click **QSPI\_512Mb** and select **Change File**.
6. Choose the software .pof file, and program it.

Figure 83. Programming Software POF File

File	Device	Checksum	Usercode	Program/Configure
<none>	10M500A	00000000	00000000	<input type="checkbox"/>
output_file.pof	QSPI_512Mb	F824A68B		<input checked="" type="checkbox"/>
app.hex				<input checked="" type="checkbox"/>
<none>	1_BIT_TAP	00000000	<none>	<input type="checkbox"/>
<none>	VTAP10	00000000	<none>	<input type="checkbox"/>

7. Wait for the software .pof file programming to complete.
8. Proceed with the FPGA configuration (JTAG, Active Serial, Passive Serial or AvST) to configure the processor hardware.

#### 4.6.2. Nios V Processor Application Copied from General Purpose QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI)

You can use a boot copier to copy the Nios V processor application from the general purpose QSPI flash to RAM when you require multiple iterations of the application software development and high system performance.

The boot copier is located at the Nios V processor reset address in flash, and is immediately followed by the application. For this boot option, the Nios V processor starts executing the boot copier software upon system reset, which copies the application from the general purpose QSPI to the internal or external RAM. Once copying is complete, the Nios V processor transfers the program control over to the application.

**Note:** The applied boot copier is the same as the Bootloader via GSFI.



**Figure 86. Generic Serial Flash Interface Altera FPGA IP Parameter Settings**




3. Change the **Device Density (Mb)** according to the QSPI flash size.
4. To access general purpose QSPI flash, enable **Disable dedicated Active Serial Interface** and **Enable SPI pins interface**.
5. Change the addressing mode by modifying bit 8 of the **Control Register** value in the **Default Settings** parameter section. Changing bit 8 to 0x0 enables 3-byte addressing, or 0x1 enables 4-byte addressing.  
*Note:* The Micron N25Q512A83GSF40F devices (in the MAX 10 FPGA Development Kit) is at 4-byte addressing mode after power cycle.
6. Export the `qspi_pins` conduit.

#### Reset Agent Settings for Nios V Processor Boot-copier Method

1. In the Nios V processor parameter editor, set the **Reset Agent** to QSPI Flash.

**Figure 87. Nios V Parameter Editor Settings**



2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

#### Quartus Prime Software Settings

1. In the Quartus Prime software, click **Assignment > Device > Device and Pin Options > Configuration**.
2. Set **Configuration scheme** according to your FPGA configuration scheme
3. Click **OK** to exit the **Device and Pin Options** window.
4. Click **OK** to exit the **Device** window.
5. Assign the GSFI pin assignment to the general purpose QSPI flash. Refer to MAX 10 FPGA Development Kit User Guide for more information on the board components and their respective MAX 10 FPGA pin number.
6. Click **Start Compilation** to compile your project.



#### 4.6.2.2. Software Design Flow

This section provides the design flow to generate and build the Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `hal_app` and `hal_bsp`.

**Figure 88. Software Project Directory Tree**



#### Creating the Application BSP Project

To launch the BSP Editor, follow these steps:

1. Enter the Nios V Command Shell.
2. Invoke the BSP Editor with `niosv-bsp-editor` command.
3. In the BSP Editor, click **File** ► **New BSP** to start your BSP project.
4. Configure the following settings:
  - **SOPC Information File name:** Provide the SOPCINFO file (`.sopcinfo`).
  - **CPU name:** Select Nios V processor.
  - **Operating system:** Select the operating system of the Nios V processor.
  - **Version:** Leave as default.
  - **BSP target directory:** Select the directory path of the BSP project. You can pre-set it at `<Project directory>/software/hal_bsp` by enabling **Use default locations**.
  - **BSP Settings File name:** Type the name of the BSP Settings File.
  - **Additional Tcl scripts:** Provide a BSP Tcl script by enabling **Enable Additional Tcl script**.
5. Click **OK**.

Figure 89. Configure New BSP



### Configuring the BSP Editor and Generating the BSP Project

1. Go to **Main ► Settings ► Advanced ► hal.linker**
2. Leave all settings unchecked.

Figure 90. Advanced.hal.linker Settings



3. Click on the **Linker Script** tab in the BSP Editor.
4. Set all regions in the **Linker Section Name** list to the On-Chip Memory (OCRAM) or external RAM.

Figure 91. Linker Region Settings

Linker Section Name	Linker Region Name	Memory Source Name
.text	onchip_memory2_0	onchip_memory2_0
.data	onchip_memory2_0	onchip_memory2_0
.bss	onchip_memory2_0	onchip_memory2_0
.rodata	onchip_memory2_0	onchip_memory2_0
.reloc	onchip_memory2_0	onchip_memory2_0
.stack	onchip_memory2_0	onchip_memory2_0
.heap	onchip_memory2_0	onchip_memory2_0
.uninitialized	onchip_memory2_0	onchip_memory2_0

5. Click **Generate** to generate the BSP project.

### Generating the User Application Project File

1. Navigate to the `software/hal_app` folder and create your application source code,
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application `CMakeLists.txt`.

```
niosv-app --app-dir=software/hal_app --bsp-dir=software/hal_bsp \
--srcs=software/hal_app/<user application>
```

### Building the User Application Project

You can choose to build the user application project using Ashling RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the user application using the following command:

```
cmake -G "Unix Makefiles" -B software/hal_app/build -S software/hal_app
make -C software/hal_app/build
```

The application (.elf) file is created in software/hal\_app/build folder.

### Generating the HEX File

You must generate a .hex file from your application .elf file, so you can create a .pof file suitable for programming the devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from general purpose QSPI flash, use the following command line to convert the ELF to HEX for your application. This command creates the user application (onchip\_flash.hex) file.
3. Select the suitable Bootloader via GSFI in the elf2flash command.

```
elf2flash
--boot <Intel Quartus Prime installation directory>/
niosv/components/bootloader/<Bootloader via GSFI>
--input software/hal_app/build/<Nios V application>.elf \
--output flash.srec --reset <reset offset + base address of GSFI AVL MEM> \
--base <base address of GSFI AVL MEM> \
--end <end address of GSFI AVL MEM>
```

```
riscv32-unknown-elf-objcopy --input-target srec --output-target ihex \
flash.srec <Nios V application>.hex
```

#### 4.6.2.3. Programming Files Generation

The method for processor application copied from General Purpose QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI) does not include the programming files generation for FPGA configuration. Unlike MAX 10 On-Chip Flash or Active Serial configuration flash, the general purpose QSPI flash is not for FPGA configuration.


### Software Programmer Object File (.pof) Generation

**Note:** The quartus.ini file with PGMIO\_SWAP\_HEX\_BYTE\_DATA=ON content is required to byteswap the software HEX file during the POF generation. Create the quartus.ini file or use the quartus.ini available in the related information. Place the quartus.ini file under Quartus Prime tool directory or project directory before you proceed.

1. In Quartus Prime, click **Convert Programming Files** from the **File** tab.
2. Choose **Programmer Object File (.pof)** as **Programming file type**.
3. Set **Mode** to **1-bit Passive Serial**.
4. Set **Configuration device** to **CFI\_512Mb**.
5. Change the **File name** to the desired path and name.

6. Remove the SOF **Page\_0**.
7. Click on **Add HEX Data**, choose the HEX file generated in **HEX file** section.
8. Select **Absolute Addressing** and **Little endian**, and click **OK**.
9. Click **Generate** to create the software .pof file.

**Figure 92. HEX to POF File Conversion**



#### 4.6.2.4. QSPI Flash Programming

##### Generate Parallel Flash Loader

1. Create a new MAX 10 FPGA project.
2. Instantiate a Parallel Flash Loader in the system.
3. Configure the IP as follows:
  - a. What operating mode will be used? **Flash Programming**
  - b. What is the target flash? **Quad SPI Flash**
  - c. How many flash devices will be used? **1**
  - d. What's the Quad SPI flash device manufacturer? **Micron**
  - e. What's the Quad SPI flash device density? **QSPI 512 Mbit**
4. Connect the IP interface as follows:
  - a. flash\_io0 - QSPI data 0
  - b. flash\_io1 - QSPI data 1
  - c. flash\_io2 - QSPI data 2
  - d. flash\_io3 - QSPI data 3
  - e. flash\_ncs - QSPI chip select

- f. flash\_sck - QSPI clock
- g. pfl\_flash\_access\_granted - VCC (1'b1)
- h. pfl\_nreset - VCC (1'b1)

**Figure 93. Interface Connection**

```
module max10_pfl (
    input wire flash_io0,
    input wire flash_io1,
    input wire flash_io2,
    input wire flash_io3,
    output wire flash_nrx,
    output wire flash_sck
)

max10_pfl_id0 (
    .flash_io0 (flash_io0),
    .flash_io1 (flash_io1),
    .flash_io2 (flash_io2),
    .flash_io3 (flash_io3),
    .flash_nrx (flash_nrx),
    .flash_sck (flash_sck),
    .pfl_flash_access_granted (1'b1),
    .pfl_flash_access_request (1),
    .pfl_nreset (1'b1)
)

endmodule
```

- 5. Apply timing constraints.

**Figure 94. Example Timing Constraints**

```
derive_pll_clocks

# JTAG Signal Constraints constrain the TCK port, assuming a 24MHz JTAG
# clock and 5ns delays
create_clock -name {altera_reserved_tck} -period 41.667 [get_ports
{ altera_reserved_tck }]
set_input_delay -clock altera_reserved_tck -clock_fall -max 5 [get_ports
altera_reserved_tdi]
set_input_delay -clock altera_reserved_tck -clock_fall -max 5 [get_ports
altera_reserved_tms]
set_output_delay -clock altera_reserved_tck 5 [get_ports altera_reserved_tdo]

#
#some clock uncertainty is required
#
derive_clock_uncertainty

set_false_path -from [get_ports {flash_io1}]
set_false_path -to [get_ports {flash_*}]
```


- 6. Compile the PFL design.
- 7. Generate the PFL design SOF file.

### Software POF File Programming into General Purpose QSPI

**Note:** You need to program the parallel flash loader into the MAX 10 device before programming the QSPI flash.

1. Program the PFL design SOF file using **Quartus Programmer**.
2. Click on **Auto-Detect** after the PFL is successfully programmed.
3. Click **Yes** to overwrite the existing JTAG chain.
4. A new QSPI flash device will be shown on the screen, connected to Max 10 device. It is the targeted general purpose QSPI flash.

Figure 95. General Purpose QSPI Flash in JTAG Chain



5. Click on **QSPI\_512Mb** and select **Change File**.
6. Choose the software .pof file, and program it.

Figure 96. Programming Software POF file

File	Device	Checksum	Usercode	Program/Configure
<none>	10M50DA	00000000	00000000	
- output_file.pof	QSPI_512Mb	FB24A68B		<input checked="" type="checkbox"/>
app.hex				<input checked="" type="checkbox"/>
<none>	1_BIT_TAP	00000000	<none>	
<none>	VTAP10	00000000	<none>	

7. Wait for the software .pof file programming to complete.
8. Proceed with the FPGA configuration (JTAG, Active Serial, Passive Serial or AvST) to configure the processor hardware.

## 4.7. Nios V Processor Booting from Configuration QSPI Flash

The Nios V processor supports the following two boot options using configuration QSPI flash under Active Serial configuration mode:

- Nios V processor application executes in-place from configuration QSPI flash.
- Nios V processor application is copied from configuration QSPI flash to RAM using boot copier.

Based on the related Altera FPGA devices, refer to the following sections:

- Control block-based devices:
  - [Nios V Processor Application Executes-In-Place from Configuration QSPI Flash](#)
  - [Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier \(Bootloader via GSFI\)](#)
- SDM-based devices:
  - [Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier \(Bootloader via SDM\)](#)

**Table 38. Supported Flash Memories with respective Boot Options**

Supported Boot Memories	Nios V Booting Methods	Application Runtime Location	Boot Copier
Control block-based devices <sup>(4)</sup> (with Generic Serial Flash Interface Altera FPGA IP)	Nios V processor application execute-in-place from configuration QSPI flash	Configuration QSPI flash (XIP) + OCRAM/ External RAM (for writable data sections)	alt_load() function
	Nios V processor application copied from configuration QSPI flash to RAM using boot copier	OCRAM/ External RAM	Bootloader via GSFI
SDM-based devices <sup>(4)</sup> (with Mailbox Client Altera FPGA IP)	Nios V processor application copied from configuration QSPI flash to RAM using boot copier	OCRAM/ External RAM	Bootloader via SDM


#### 4.7.1. Nios V Processor Application Executes-In-Place from Configuration QSPI Flash

The execute-in-place (XIP) option is suitable for Nios V processor application, when only a limited amount of on-chip memory is available to the processor. This boot option is only available for control block-based devices.

The `alt_load()` function operates as a mini boot copier that initializes and copies the writable memory sections only to OCRAM or external RAM. The code section (`.text`), which is a read-only section, remains in the configuration QSPI flash memory region. Retaining the read-only section in configuration QSPI minimizes RAM usage but may limit the code execution performance.

The Nios V processor application is programmed into the configuration QSPI flash. The Nios V processor reset the agent points to the configuration QSPI flash to allow code execution after the system resets.

**Figure 97. Nios V Processor Application Executes-In-Place from Configuration QSPI Flash**



<sup>(4)</sup> Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for the device list.

## Related Information

Bootloader via GSFI Example Design on page 117

### 4.7.1.1. Hardware Design Flow

The following sections describe the steps for building a bootable system for a Nios V processor application, which executes in place from the configuration QSPI flash.

The following example is built using an Intel Arria 10 SoC Development Kit.

## IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Add Generic Serial Flash Interface Intel FPGA IP into your Platform Designer.

**Figure 98. Connections for Nios V Processor Project**

Connectio...	Name	Description	
	clock_in	Clock Bridge Intel FPGA IP	
	in_clk	Clock Input	clk
	out_clk	Clock Output	
	reset_in	Reset Bridge Intel FPGA IP	
	in_reset	Reset Input	reset
	out_reset	Reset Output	
	cpu	Nios V/m Processor Intel FPG...	
	clk	Clock Input	
	reset	Reset Input	
	platform_irq_rx	Interrupt Receiver	
	instruction_manager	AXI4 Manager	
	data_manager	AXI4 Manager	
	timer_sw_agent	Avalon Memory Mapped Agent	
	dm_agent	Avalon Memory Mapped Agent	
	ram	On-Chip Memory (RAM or RO...	
	clk1	Clock Input	
	s1	Avalon Memory Mapped Agent	
	reset1	Reset Input	
	gsfi	Generic Serial Flash Interfac...	
	avl_csr	Avalon Memory Mapped Agent	
	avl_mem	Avalon Memory Mapped Agent	
	clk	Clock Input	
	reset	Reset Input	
	jtag_uart	JTAG UART Intel FPGA IP	
	clk	Clock Input	
	reset	Reset Input	
	avalon_jtag_slave	Avalon Memory Mapped Agent	
	irq	Interrupt Sender	



Figure 99. Generic Serial Flash Interface Intel FPGA IP Parameter Settings

Generic Serial Flash Interface Intel FPGA IP  
intel\_generic\_serial\_flash\_interface\_top

General Simulation

Device Density (Mb): 1024 ▼

☐ Disable dedicated Active Serial interface

☐ Enable SPI pins interface

☐ Use byteenable for CSR

Number of Chip Selects used: 1 ▼

▼ Default Settings

Control Register: 0x00000101

3. Change the **Device Density (Mb)** according to the QSPI flash size.
4. Change the addressing mode by modifying bit 8 of the **Control Register** value in the **Default Settings** parameter section. Changing bit 8 to 0x0 enables 3-byte addressing, or 0x1 enables 4-byte addressing.

Note:

Refer to **Intel Supported Configuration Devices tab ► Intel Supported Third Party Configuration Devices** in the *Device Configuration Support Center* to check the byte addressing mode supported for each flash device in each Altera FPGA device.

For example, Arria® 10 devices support the 4-byte addressing mode when used with Micron flash devices .


#### Reset Agent Settings for Nios V Processor Execute-In-Place Method

1. In the Nios V processor IP parameter editor, set the **Reset Agent** to QSPI Flash.
  - a. Your (.sof) image size influences your reset offset configuration. The reset offset is the start address of the HEX file in QSPI flash and it must point to a location after the (.sof) image. If the (.sof) image space and the reset offset location overlap, Quartus Prime software displays an overlap error. You can determine the minimum reset offset by using the configuration bitstream size from the device datasheet.

Refer to the following example:

- The uncompressed configuration bitstream size for Arria 10 GX 660 is 252,959,072 bits (31,619,884 bytes).
- If the SOF image starts at address 0x0, the SOF image can extend up to address 0x1E27B2C. In this case, the minimum reset offset you can select to avoid overlap errors is 0x1E27B30.
- Altera recommends you to use a flash sector boundary address for the reset offset. Doing so allows you to update the application software image at a later time without interfering with the FPGA image.

**Figure 100. Parameter Editor Settings**



2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

#### Quartus Prime Software Settings

1. In the Quartus Prime software, click **Assignment > Device > Device and Pin Options > Configuration**.
2. Set **Configuration scheme** to **Active Serial x4 (can use Configuration Device)**.
3. Set the **Active serial clock source** to **100 MHz Internal Oscillator**.

Figure 101. Device and Pin Options

The screenshot shows the 'Configuration' dialog box. At the top, it says 'Specify the device configuration scheme and the configuration device.' Below this, there are several fields and checkboxes. 'Configuration scheme' is a dropdown menu set to 'Active Serial x4 (can use Configuration Device)'. 'Configuration mode' is a text field. 'Configuration device' is a text field with a 'Configuration Device Options...' button next to it. 'Configuration device I/O voltage' is a dropdown menu set to 'Auto'. There is a checkbox 'Force VCCIO to be compatible with configuration I/O voltage' which is unchecked. 'VIO mode of operation' is a text field. 'Configuration pin' is a text field with a 'Configuration Pin Options...' button next to it. There is a checked checkbox 'Generate compressed bitstreams'. 'Active serial clock source' is a dropdown menu set to '100 MHz Internal Oscillator'. There is an unchecked checkbox 'Enable input tri-state on active configuration pins in user mode'. Below these are two more text fields: 'JPS/FPGA configuration order' and 'HPS (debug access port, DAP)'. At the bottom right is a 'Reset' button.

4. Click **OK** to exit the **Device and Pin Options** window.
5. Click **OK** to exit the **Device** window.
6. Click **Start Compilation** to compile your project.

#### Related Information

[Arria 10 SoC Development Kit](#)


#### 4.7.1.2. Software Design Flow

This section provides the design flow to generate and build a Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The software design flow is based on this directory tree.

Use the following steps to create the software project directory tree:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `app` and `bsp`.

Figure 102. Software Project Directory Tree



### Creating the BSP Project Application

You must edit the BSP editor settings according to the selected Nios V processor boot options.

To launch the BSP Editor, perform the following steps:

1. In the Platform Designer window, select **File ► New BSP**. The **Create New BSP** windows appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and name the BSP as `settings.bsp`.


BSP path: `<project directory>/software/bsp/settings.bsp`

1. For **System file (qsys or socpinfo)**, select the Nios V processor Platform Designer system (\*.qsys).

*Note:* For Quartus Prime Standard Edition software, generate the BSP file using SOPCINFO file. Refer to *AN 980: Nios V Processor Intel Quartus Prime Software Support* for more information.

2. For **Quartus project**, select the Quartus Prime Project File.
3. For **Revision**, select the correct revision.
4. For **CPU name**, select the Nios V processor.
5. Select the **Operating system** as **Altera HAL**.
6. Click **Create** to create the BSP file.

Figure 103. Create New BSP window



### Configuring BSP Editor and Generating the BSP Project

1. In the **BSP Editor**, click **BSP Linker Script**.
2. In the **Linker Section Name** perform the following settings:
  - a. Set `.text` to the QSPI flash in the **Linker Region Name**.
  - b. Set `.exceptions` to OCRAM/ External RAM or QSPI Flash according to your design preference.
  - c. Set the rest of the items to the OCRAM or external RAM.

**Figure 104. Linker Region Settings When Exceptions is set to OCRAM/ External RAM**


Linker Section Mappings		
Linker Section Name	Linker Region Name	Memory Device Name
bss	ram	ram
entry	reset	qspi_avl_mem
exceptions	ram	ram
heap	ram	ram
rodata	ram	ram
rwdata	ram	ram
stack	ram	ram
text	qspi_avl_mem	qspi_avl_mem

**Figure 105. Linker Region Settings When Exceptions is set to QSPI Flash**

Linker Section Mappings		
Linker Section Name	Linker Region Name	Memory Device Name
bss	ram	ram
entry	reset	qspi_avl_mem
exceptions	qspi_avl_mem	qspi_avl_mem
heap	ram	ram
rodata	ram	ram
rwdata	ram	ram
stack	ram	ram
text	qspi_avl_mem	qspi_avl_mem

3. Go to **Main > Settings > Advanced > hal.linker**.
4. If exception is set to OCRAM or External RAM, enable the following:
  - `allow_code_at_reset`
  - `enable_alt_load`
  - `enable_alt_load_copy_rodata`
  - `enable_alt_load_copy_rwdata`
  - `enable_alt_load_copy_exceptions`

**Figure 106. hal.linker Settings for Exception Agent OCRAM or External RAM**



5. If exception is set to QSPI flash, enable the following:

- allow\_code\_at\_reset
- enable\_alt\_load
- enable\_alt\_load\_copy\_rodata
- enable\_alt\_load\_copy\_rwdata

**Figure 107. hal.linker Settings for QSPI Flash**



6. Navigate to the **BSP Drivers** tab.
7. Disable the Generic Serial Flash Interface driver (intel\_generic\_serial\_flash\_interface\_top).

**Figure 108. BSP Drivers**

Mod.	Module Class Name	Modul.	Driver Name	Driver	Enable
cpu	intel_niosv_m	22.4.3	intel_niosv_m_hal_driver	default	<input checked="" type="checkbox"/>
qspi	intel_generic_serial_flash_interface_top	20.3.3	intel_generic_serial_flash_interface_top	default	<input type="checkbox"/>
itag_uart	altera_avalon_itag_uart	19.2.1	altera_avalon_itag_uart_driver	default	<input checked="" type="checkbox"/>
ram	altera_avalon_qochip_memory2	19.2.7	none	none	<input type="checkbox"/>

8. Return to the **BSP Editor** tab and click **Generate BSP**. Make sure the BSP generation is successful.
9. Close the **BSP Editor**.

### Generating the Application Project File

1. Navigate to the `software/app` folder and create your Nios V application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application `CMakeLists.txt`.

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \  
--srcs=software/app/<Nios V application source code>
```

### Building the Application Project

You can choose to build the application project using the RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the application using the following command:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Debug -B \  
software/app/debug -S software/app
```

```
make -C software/app/debug
```

The application (`.elf`) file is created in `software/app/debug` folder.

### Generating HEX File

You must generate a `.hex` file from your application `.elf` file, so you can create a `.jic` file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application execute-in-place (XIP) from configuration QSPI flash, use the following commands line to convert the ELF to HEX for your application. The commands create the application (`.hex`) file.

```
elf2flash --input software/app/debug/<Nios V application>.elf \  
--output flash.srec --reset <reset offset + base address of GSFI AVL MEM> \  
--base <base address of GSFI AVL MEM> \  
--end <end address of GSFI AVL MEM>
```

```
riscv32-unknown-elf-objcopy --input-target srec --output-target ihex \  
flash.srec <Nios V application>.hex
```

### Related Information


[Summary of Nios V Processor Vector Configuration and BSP Settings](#) on page 154

#### 4.7.1.3. Programming Files Generation

##### JTAG Indirect Configuration File (`.jic`) Generation

1. In the Quartus Prime software, go to **File ► Convert Programming Files**.
2. For **Programming file type**, select **JTAG Indirect Configuration File (.jic)**
3. For **Mode** select **Active Serial x4**.

Figure 109. Convert Programming File Window



4. Click "..."/>


Figure 110. Configuration Device Window



5. If you are using a supported device, make your selection, and click **OK**. Else, proceed with the following steps:
  - a. Select **<<new device>>**.
  - b. Enter the information about **Device name**, **Device ID**, **Device I/O voltage**, **Device density**, **Total device die**, **Dummy clock (Single I/O or Quad I/O mode)** and **Programming flow template**.
  - c. Click **Apply**.



*Note:* The **Programming flow template** helps you define a template for flash operation in Initialization, Program, Erase, Verify/Blank-Check/Examine and Termination. If the device is not available for selection, refer to **Modifying Programming Flows** in *Generic Flash Programmer User Guide* to modify the programming flow. For details about memory parameters like dummy clock cycles, please contact the related vendor.



Device name:	MT25QL256
Device ID:	0x20 0xBA 0x19
Device I/O voltage:	3.0V/3.3V
Device density:	256Mb
Total device die:	1
Single I/O mode dummy clock:	15
Quad I/O mode dummy clock:	15
Programming flow template:	Micron <span>Edit...</span>
<input type="checkbox"/> Save as template	

6. Under the **Input files to convert** tab,
  - a. Choose the Flash Loader for the FPGA used by selecting **Flash Loader** and click **Add Device**.
  - b. Add the .sof file to the SOF Data by selecting **SOF Data** and click **Add File**.
  - c. Click **Add Hex Data** to add Nios V application (.hex) file. Select the **Absolute addressing** and **Big-endian** button. Browse to the .hex file location. Click **OK**.
7. Click **Generate** to generate the JIC file.

**Figure 111. Input files to convert tab**



File/Data area	Properties	Start Address
Boot Info		0x00000000
Flash Loader 10A506803		
SOF Data top.sof	Page_0 10A506803-40	<auto>
Hex Data user_application.hex	Absolute addressing	0x07000000

Buttons: Add Hex Data, Add Sof Page, Generate, Close, Help

#### 4.7.1.4. QSPI Flash Programming


##### Altera FPGA Device QSPI Flash Programming

1. Ensure that the Altera FPGA device's Active Serial (AS) pin is routed to the QSPI flash. This routing allows the flash loader to load into the QSPI flash and configure the board correctly.
2. Ensure the MSEL pin setting on the board is configured for AS programming.
3. Open the Intel Quartus Prime Programmer and make sure JTAG was detected under the **Hardware Setup**.
4. Select **Auto Detect** and choose the FPGA device according to your board.
5. Right-click the selected Altera FPGA device and select **Edit ► Change File**. Next, select the generated JIC file.
6. Select the **Program/ Configure** check boxes for the FPGA and QSPI devices.
7. Click **Start** to start programming.

**Note:** Power cycle the device to begin Active Serial configuration scheme, and reset the Nios V processor system upon entering user mode.

#### 4.7.2. Nios V Processor Design, Configuration and Boot Flow (Control Block-based Device)

**Figure 112. Design, Configuration and Booting Flow (Control Block-based Device)**




##### 4.7.2.1. Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI)

You can use a boot copier to copy the Nios V processor application from the configuration QSPI flash to RAM when you require multiple iterations of the application software development and high system performance.

The boot copier is located at the Nios V processor reset address in flash, and is immediately followed by the application. For this boot option, the Nios V processor starts executing the boot copier software upon system reset, which copies the application from the configuration QSPI to the internal or external RAM. Once copying is complete, the Nios V processor transfers the program control over to the application.

**Figure 113. Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI)**



#### Related Information

[Bootloader via GSFI Example Design](#) on page 117

#### 4.7.2.1.1. Hardware Design Flow

The following sections describe a step-by-step method for building a bootable system for a Nios V processor application copied from configuration QSPI flash to RAM using Bootloader via GSFI. The following example is built using Arria 10 SoC Development Kit.

#### IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Add the Generic Serial Flash Interface Altera FPGA IP is into your Platform Designer system.

Figure 114. Connections for Nios V Processor Project

Connectio...	Name	Description	
	<div> <div>clock_in</div> <div> <div>in_clk</div> <div>out_clk</div> </div> </div>	<b>Clock Bridge Intel FPGA IP</b> Clock Input Clock Output	clk Double
	<div> <div>reset_in</div> <div> <div>in_reset</div> <div>out_reset</div> </div> </div>	<b>Reset Bridge Intel FPGA IP</b> Reset Input Reset Output	reset Double
	<div> <div>cpu</div> <div> <div>clk</div> <div>reset</div> <div>platform_irq_rx</div> <div>instruction_manager</div> <div>data_manager</div> <div>timer_sw_agent</div> <div>dm_agent</div> </div> </div>	<b>Nios V/m Processor Intel FPG...</b> Clock Input Reset Input Interrupt Receiver AXI4 Manager AXI4 Manager Avalon Memory Mapped Agent Avalon Memory Mapped Agent	Double Double Double Double Double Double Double
	<div> <div>ram</div> <div> <div>clk1</div> <div>s1</div> <div>reset1</div> </div> </div>	<b>On-Chip Memory (RAM or RO...</b> Clock Input Avalon Memory Mapped Agent Reset Input	Double Double Double
	<div> <div>gsfi</div> <div> <div>avl_csr</div> <div>avl_mem</div> <div>clk</div> <div>reset</div> </div> </div>	<b>Generic Serial Flash Interfac...</b> Avalon Memory Mapped Agent Avalon Memory Mapped Agent Clock Input Reset Input	Double Double Double Double
	<div> <div>jtag_uart</div> <div> <div>clk</div> <div>reset</div> <div>avalon_jtag_slave</div> <div>irq</div> </div> </div>	<b>JTAG UART Intel FPGA IP</b> Clock Input Reset Input Avalon Memory Mapped Agent Interrupt Sender	Double Double Double Double

Figure 115. Generic Serial Flash Interface Altera FPGA IP Parameter Settings

3. Change the **Device Density (Mb)** according to the QSPI flash size.
4. Change the addressing mode by modifying bit 8 of the **Control Register** value in the **Default Settings** parameter section. Changing bit 8 to 0x0 enables 3-byte addressing, or 0x1 enables 4-byte addressing

*Note:*

Refer to **Intel Supported Configuration Devices tab > Intel Supported Third Party Configuration Devices** in *Device Configuration Support Center* to check the byte addressing mode supported for each flash device in each Altera FPGA device.

For example, Arria 10 devices when used with Micron flash devices support the 4-byte addressing mode.

#### Reset Agent Settings for Nios V Processor Boot-copier Method

1. In the Nios V processor parameter editor, set the **Reset Agent** to QSPI Flash.

*Note:* Your SOF image size influences your reset offset configuration. The reset offset is the start of the address of the HEX file in QSPI flash and it must point to a location after the SOF image. If the SOF image space and the reset offset location overlap, Quartus Prime software displays and overlap error. You can determine the minimum reset offset by using the configuration bitstream size from the device datasheet.

For example, the uncompressed configuration bitstream size for Arria 10 GX 660 is 252,959,072 bits (31,619,884 bytes). If the SOF image starts at address 0x0, the SOF image can extend up to address 0x1E27FFF (0x1E27B2C). In this case, the minimum reset offset you can select is 0x2000000.

Figure 116. Nios V Parameter Editor Settings



2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

#### Quartus Prime Software Settings

1. In the Intel Quartus Prime software, click **Assignment > Device > Device and Pin Options > Configuration**.
2. Set **Configuration scheme** to **Active Serial x4 (can use Configuration Device)**.
3. Set the **Active serial clock source** to **100 MHz Internal Oscillator**.

Figure 117. Device and Pin Options



4. Click **OK** to exit the **Device and Pin Options** window.
5. Click **OK** to exit the **Device** window.
6. Click **Start Compilation** to compile your project.

#### Related Information

- [Arria 10 SoC Development Kit](#)
- [Arria 10 Device Datasheet](#)


#### 4.7.2.1.2. Software Design Flow

This section provides the software design flow to generate and build the Nios V processor software project. To ensure a streamline build flow, you are encouraged to create similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder named `software`.
2. In the `software` folder, create two folders named `app` and `bsp`.

**Figure 118. Software Project Directory Tree**



### Creating the BSP Project Application

You must edit the BSP editor settings according to the selected Nios V processor boot options.

To launch the BSP Editor, perform the following steps:

1. In the Platform Designer window, select **File ► New BSP**. The **Create New BSP** windows appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and name the BSP as `settings.bsp`.


BSP path: `<project directory>/software/bsp/settings.bsp`

3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system (`.qsys`) file.

*Note:* For Quartus Prime Standard Edition software, generate the BSP file using SOPCINFO file. Refer to *AN 980: Nios V Processor Intel Quartus Prime Software Support* for more information.

4. For **Quartus project**, select the Quartus Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.

**Figure 119. Create New BSP window**






### Configuring BSP Editor and Generating the BSP Project

1. Go to **Main ► Settings ► Advanced ► hal.linker**.
2. Leave all settings unchecked.

Figure 120. hal.linker Settings



3. Click the **BSP Linker Script** tab in the **BSP Editor**.
4. Set all the Linker Section Name list to the OCRAM or external RAM.

Figure 121. Linker Region Settings

Linker Section Mappings		
Linker Section Name ▲	Linker Region Name	Memory Device Name
.bss	ram	ram
.entry	reset	qsfi_avl_mem
.exceptions	ram	ram
.heap	ram	ram
.rodata	ram	ram
.rwdata	ram	ram
.stack	ram	ram
.text	ram	ram

5. Click **Generate BSP**. Make sure the BSP generation is successful.
6. Close the **BSP Editor**.

### Generating the Application Project File

1. Navigate to the `software/app` folder and create your Nios V application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the application `CMakeLists.txt`.

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/<Nios V application source code>
```

### Building the Application Project

You can choose to build the application project using the RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

With the CLI, you can build the user project using the following commands:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Debug \
-B software/app/debug -S software/app
```

```
make -C software/app/debug
```

The application (.elf) file is created in software/app/debug folder.

### Generating HEX File

You must generate a .hex file from your application .elf file, so you can create a .jic file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application copied from QSPI flash using boot copier, use the following command line to generate the .hex file for your application.
3. Refer to the table *Bootloader via GSFI for Nios V Processor Core* in the topic *Bootloader via GSFI* for the suitable bootloader via GSFI that you can use in the elf2flash command.

```
elf2flash
--boot <Intel Quartus Prime installation directory>/
  niosv/components/bootloader/<Bootloader via GSFI>
--input software/app/debug/<Nios V application>.elf \
--output flash.srec --reset <reset offset + base address of GSFI AVL MEM> \
--base <base address of GSFI AVL MEM> \
--end <end address of GSFI AVL MEM>
```

```
riscv32-unknown-elf-objcopy --input-target srec --output-target ihex \
flash.srec <Nios V application>.hex
```


### Related Information

- [Summary of Nios V Processor Vector Configuration and BSP Settings](#) on page 154
- [Nios V Processor Bootloader via Generic Serial Flash Interface](#) on page 52  
Refer to the table *Bootloader via GSFI for Nios V Processor Core* for more information about the suitable Bootloader via GSFI that you can use in the elf2flash command.

#### 4.7.2.1.3. Programming Files Generation

1. In the Quartus Prime software, go to **File ► Convert Programming Files**.
2. For **Programming file type**, select **JTAG Indirect Configuration File (.jic)**
3. For **Mode** select **Active Serial x4**.

Figure 122. Convert Programming File Window



4. Click ... to enter the **Configuration Device** tab and select the available options. The **Configuration Device** allows for choosing a specific supported device or alternatively an unsupported device.

Figure 123. Configuration Device Window



5. If you are using a supported device, make your selection, and click **OK**. Else, proceed with the following steps:
  - a. Select **<<new device>>**.
  - b. Enter the information about **Device name**, **Device ID**, **Device I/O voltage**, **Device density**, **Total device die**, **Dummy clock (Single I/O or Quad I/O mode)** and **Programming flow template**.
  - c. Click **Apply**.

**Note:** The **Programming flow template** helps you to define a template for flash operation in Initialization, Program, Erase, Verify/Blank-Check/Examine and Termination. If the device is not available for selection, refer to **Modifying Programming Flows** in *Generic Flash Programmer User Guide* to modify the programming flow. Please contact the related vendor for details about memory parameters, such as dummy clock cycles.

The screenshot shows a configuration window for the programming flow template. It includes the following fields and options:

- Device name: MT25QL256
- Device ID: 0x20 0xBA 0x19
- Device I/O voltage: 3.0V/3.3V
- Device density: 256Mb
- Total device die: 1
- Single I/O mode dummy clock: 15
- Quad I/O mode dummy clock: 15
- Programming flow template: Micron (with an Edit... button)
- ☐ Save as template

6. Under the **Input files to convert** tab,
  - a. Select the **Flash Loader** and click **Add Device**.
  - b. Add the .sof file to the SOF Data by selecting **SOF Data** and click **Add File**.
  - c. Click **Add Hex Data** to add Nios V application (.hex) file. Select the **Absolute addressing** and **Big-endian** button. Browse to the .hex file location. Click **OK**.
7. Click **Generate** to generate the JIC file.

**Figure 124. Input files to convert tab**

The screenshot shows the 'Input files to convert' tab with a table listing the input files and their properties. The table has three columns: File/Data area, Properties, and Start Address.

File/Data area	Properties	Start Address
Boot Info		0x00000000
Flash Loader		
TGA5066AC		
SOF Data	Page_0	<auto>
topsof	TGA5066AC(40)	
Hex Data	Absolute addressing	0x02000000
user_application.hex		

On the right side of the table, there are buttons for 'Add Hex Data', 'Add Sof Page', 'Add JIC', 'Remove', 'Find', 'Generate', 'Close', and 'Help'.

#### 4.7.2.1.4. QSPI Flash Programming

##### Altera FPGA Device QSPI Flash Programming

1. Ensure that the Active Serial (AS) pin of the Altera FPGA device is routed to the QSPI flash. This routing allows the flash loader to load into the QSPI flash and configure the board correctly.
2. Ensure the MSEL pin setting on the board is configured for AS programming.
3. Open the Intel Quartus Prime Programmer and make sure JTAG was detected under the **Hardware Setup**.
4. Select **Auto Detect** and choose the FPGA device according to your board.
5. Right-click the selected FPGA device and select **Edit ► Change File**. Next, select the generated JIC file.
6. Select the **Program/ Configure** check boxes for FPGA and QSPI devices. Click **Start** to start programming.

**Note:** Power cycle the device to begin Active Serial configuration scheme, and reset the Nios V processor system upon entering user mode.

#### 4.7.2.2. Bootloader via GSFI Example Design

**Note:** For Quartus Prime Standard Edition software, refer to the topic [Quartus Prime Software Support](#) to generate the example design.

You can download the Bootloader via GSFI example design from the Altera FPGA Design Store. The example design is based on the IArria 10 SoC Development Kit. Using the provided scripts, the hardware and software design are generated, and programmed respectively as SRAM Object Files (.sof) and JTAG Indirect Configuration Files (.jic) into the device.

Follow the steps below to generate the Bootloader via GSFI example design:

1. Go to Altera FPGA Design Store.
2. Search for *Arria10 - Bootloader GSFI Design* package.
3. Click on the link at the title.
4. Accept the *Software License Agreement*.
5. Download the package according to the Quartus Prime software version of your host machine.
6. Double-click to run the `top.par` file.
7. `top_project` folder is created by default after running the PAR file.
8. Open the `top_project` and refer to the `readme.txt` for how-to guide.

**Table 39. Example Design File Description**

File	Description
hw/	Contains files necessary to run the hardware project.
ready_to_test/	Contains pre-built hardware and software binaries to run the design on the target hardware. For this package, the target hardware is Arria 10 SoC development kit.
continued...	

File	Description
scripts/	Consists of scripts to build the design.
sw/	Contains software application files.
readme.txt	Contains description and steps to apply the pre-built binaries or rebuild the binaries from scratch.

Figure 125. Bootloader via GSFI Example Design




Figure 126. JUART Terminal Output

1. In the beginning, the window displays the following message:

```

quart-terminal: connected to hardware target using JTAG UART on cable
quart-terminal: "USB-BlasterII on 10.219.70.10:44584 [1-4.2.4]" device 1, instance 0
quart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

Hello world, this is Nios-V cpu checking in 0...
Hello world, this is Nios-V cpu checking in 1...

```

2. Reaching the end, the window displays the following message:

```

Hello world, this is Nios-V cpu checking in 998...
Hello world, this is Nios-V cpu checking in 999...
Bye world!


```

### Related Information

- [Nios V Processor Application Executes-In-Place from Configuration QSPI Flash](#) on page 95  
For more information about booting the Nios V processor-based system from control-block based FPGA devices.
- [Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier \(Bootloader via GSFI\)](#) on page 106  
For more information about booting the Nios V processor-based system from control-block based FPGA devices.
- [Altera FPGA Design Store](#)

### 4.7.3. Nios V Processor Design, Configuration and Boot Flow (SDM-based Devices)

Figure 127. Design, Configuration and Booting Flow (SDM-based Devices)




#### 4.7.3.1. Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via SDM)

You can use a boot copier to copy the Nios V application from configuration QSPI flash to RAM when multiple iterations of application software development and high system performance are required. Altera recommends applying the memory organization in [Memory Organization for Bootloader via SDM](#) to use the Bootloader via SDM. The following section covers the description of each memory and the steps required to create them.

The boot copier is memory-initialized in the Bootloader ROM. For this boot option, the Nios V processor starts executing the boot copier upon system reset, which copies the application from the configuration QSPI to the internal or external RAM. Once this completes, the Nios V processor transfers the program control over to the application.

**Note:** In SDM-based FPGA device, Nios V software booting from configuration QSPI Flash is not supported when the FPGA device is configured using Avalon-ST scheme.

**Figure 128. Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via SDM)**



#### Memory Organization for Bootloader via SDM

The Nios V processor system should comprise of the following memory spaces to implement the Bootloader via SDM and Nios V application. The memories are implemented as such:

- Bootloader ROM and RAM (used by Bootloader via SDM only).
- Nios V processor application RAM (used by user application only).

**Table 40. Description of Memory Organization**

Memory	Memory Type	Application Use	Linker Section	Notes
Bootloader ROM (Internal ROM)	Read-Only Memory (ROM)	Bootloader via SDM	.text	Set as the Nios V processor reset agent. Perform memory initialization with Bootloader via SDM (.hex) file.
Bootloader RAM (Internal RAM)	Random Access Memory (RAM)	Bootloader via SDM	.rodata, .rwdata, .bss, .stack, .heap, .exceptions	Initialize Bootloader via SDM using alt_load().
User Application RAM (Internal or External RAM)	Random Access Memory (RAM)	Nios V Application	.text, .rodata, .rwdata, .bss, .stack, .heap, .exceptions	The Nios V processor application is loaded into RAM from flash by the Bootloader via SDM.

#### 4.7.3.1.1. Hardware Design Flow

The following sections describe a step-by-step method for building a bootable system for a Nios V processor application copied from configuration QSPI flash to RAM using Bootloader via SDM. The example below is built using Stratix 10 SX SoC L-Tile.



## IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Add the Mailbox Client Altera FPGA IP into your Platform Designer system.

**Figure 129. Connections for Nios V Processor Project**

Connectio...	Name	Description	
<div> <div>clock_in</div> <div>in_clk</div> <div>out_clk</div> </div>	clock_in	Clock Bridge Intel FPGA IP	
	in_clk	Clock Input	clk
	out_clk	Clock Output	
	reset_in	Reset Bridge Intel FPGA IP	
<div> <div>reset_in</div> <div>in_reset</div> <div>out_reset</div> </div>	reset_in	Reset Input	reset
	in_reset	Reset Input	
	out_reset	Reset Output	
	cpu	Nios V/m Processor Intel FPGA IP	
<div> <div>clk</div> <div>reset</div> <div>platform_irq_rx</div> <div>instruction_manager</div> <div>data_manager</div> <div>timer_sw_agent</div> <div>dm_agent</div> </div>	clk	Clock Input	
	reset	Reset Input	
	platform_irq_rx	Interrupt Receiver	
	instruction_manager	AXI4 Manager	
	data_manager	AXI4 Manager	
	timer_sw_agent	Avalon Memory Mapped Agent	
	dm_agent	Avalon Memory Mapped Agent	
	bootcopier_rom	On-Chip Memory (RAM or ROM) Intel ...	
<div> <div>clk1</div> <div>s1</div> <div>reset1</div> </div>	clk1	Clock Input	
	s1	Avalon Memory Mapped Agent	
	reset1	Reset Input	
	bootcopier_ram	On-Chip Memory (RAM or ROM) Intel ...	
<div> <div>clk1</div> <div>s1</div> <div>reset1</div> </div>	clk1	Clock Input	
	s1	Avalon Memory Mapped Agent	
	reset1	Reset Input	
	user_application_mem	On-Chip Memory (RAM or ROM) Intel ...	
<div> <div>clk1</div> <div>s1</div> <div>reset1</div> </div>	clk1	Clock Input	
	s1	Avalon Memory Mapped Agent	
	reset1	Reset Input	
	mailbox	Mailbox Client Intel FPGA IP	
<div> <div>in_clk</div> <div>in_reset</div> <div>avmm</div> <div>irq</div> </div>	in_clk	Clock Input	
	in_reset	Reset Input	
	avmm	Avalon Memory Mapped Agent	
	irq	Interrupt Sender	
<div> <div>clk</div> <div>reset</div> <div>avalon_jtag_slave</div> <div>irq</div> </div>	uart	JTAG UART Intel FPGA IP	
	clk	Clock Input	
	reset	Reset Input	
	avalon_jtag_slave	Avalon Memory Mapped Agent	
<div> <div>irq</div> </div>	irq	Interrupt Sender	

Figure 130. On-Chip Memory (RAM or ROM) Altera FPGA IP Parameter Settings



3. Change the **On-Chip Memory (RAM or ROM) Altera FPGA IP Parameter Settings** according to the memory function. Ensure that you have the following memories in the system.

Memory	Memory Type	Total Memory Size	Memory initialization
Bootloader ROM	ROM (Read-only)	6144 bytes or more	Enable the following settings: <ul style="list-style-type: none"> <li>• <b>Initialize memory content</b></li> <li>• <b>Enable non-default initialization file</b> with <code>bootcopier_rom.hex</code></li> </ul>
Bootloader RAM	RAM (Writable)	6144 bytes or more	Leave all settings unchecked.
User Application RAM	RAM (Writable)	Depends on your application <sup>(5)</sup>	Leave all settings unchecked.

<sup>(5)</sup> Your application size varies according to the usage. Set the memory size according to your design.

### Reset Agent Settings for Nios V Processor

1. In the Nios V processor parameter editor, set the **Reset Agent** to Bootloader ROM.

Figure 131. Nios V Processor Parameter Editor Settings



2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

### Quartus Prime Software Settings

1. In the Intel Quartus Prime software, click **Assignment ► Device ► Device and Pin Options ► Configuration**.
2. Set **Configuration scheme** to **Active Serial x4 (can use Configuration Device)**.
3. Set **VID mode of operation** according to your board design.
4. Set the **Active serial clock source** to **100 MHz Internal Oscillator**.

Figure 132. Device and Pin Options

**Configuration**

Specify the device configuration scheme and the configuration device.

Configuration scheme: ☒ Active Serial x4 (can use Configuration Device) +

Configuration mode:

Configuration device

Configuration device I/O voltage: ☒ Auto

☐ Force VCCIO to be compatible with configuration I/O voltage ☒

VID mode of operation: ☒ PMBus Master

Configuration pin:

☒ Generate compressed bitstreams ☒

Active serial clock source: ☒ 100 MHz Clock Frequency

☐ Enable input tri-state on active configuration pins in user mode ☒

HPS/FPGA configuration order: ☒ After INIT\_DONE

HPS debug access port (DAP): ☒ Disabled

☐ Allow HPS debug without certificate ☒

☐ Disable Register Power-up Initialization ☒

Remote System Update MAX\_RETRY count ☒ 1

5. Click **OK** to exit the **Device and Pin Options** window.
6. Click **OK** to exit the **Device** window.
7. Click **Start Compilation** to compile your project.


#### 4.7.3.1.2. Software Design Flow

This section provides the software design flow to generate and build the Nios V processor software project for the Bootloader via SDM and Nios V application. To ensure a streamlined build flow, you are encouraged to create a similar directory tree in your design project. The following software design flow is based on the following directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder named `software`.
2. In the `software` folder, create two folders named `mailbox_bootloader` and `user_application`.
3. In the `mailbox_bootloader` folder, create two folders named `app` and `bsp`.
4. In the `user_application` folder, create two folders named `app` and `bsp`.

**Figure 133. Software Project Directory Tree**



#### 4.7.3.1.3. Software Design Flow (Bootloader via SDM Project)


This section provides the design flow to generate and build the Bootloader via SDM project.

##### Creating the Bootloader via SDM BSP Project

To launch the BSP Editor, follow these steps:

1. In the Platform Designer window, select **File ► New BSP**. The **Create New BSP** window appears.
2. For **BSP setting file**, navigate to the `software/mailbox_bootloader/bsp` folder and name the BSP as `settings.bsp`.  
BSP path: `<project_directory>/software/mailbox_bootloader/bsp/settings.bsp`
3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system (`.qsys`) file.
4. For **Quartus project**, select the Quartus Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.

Figure 134. Create New BSP Window



### Configuring BSP Editor and Generating the BSP Project

1. Go to **BSP Editor > Main > Settings**
2. Configure the settings per the following table:

Table 41. Settings for BSP Editor


Settings	Action
hal.max_file_descriptors <sup>(6)</sup>	Input as <b>4</b>
hal.log_port <sup>(6)</sup>	Select as <b>None</b>
hal.enable_exit <sup>(6)</sup> hal.enable_clean_exit <sup>(6)</sup> hal.c_plus_plus <sup>(6)</sup>	<b>Unchecked</b> to disable the feature.
hal.sys_clk_timer <sup>(6)</sup> hal.timestamp_timer <sup>(6)</sup> hal.stdin <sup>(6)</sup> hal.stdout <sup>(6)</sup> hal.stderr <sup>(6)</sup>	Select as <b>None</b>
hal.linker	Enable the following settings: <ul style="list-style-type: none"> <li>• <b>allow_code_at_reset</b></li> <li>• <b>enable_alt_load</b></li> <li>• <b>enable_alt_load_copy_rodata</b></li> <li>• <b>enable_alt_load_copy_rwdata</b></li> <li>• <b>enable_alt_load_copy_exceptions</b></li> </ul>
<i>continued...</i>	

<sup>(6)</sup> Altera recommends you to use these settings to reduce the Bootloader via SDM code footprint.

Settings	Action
hal.make.cflags_user_flags <sup>(6)</sup>	Input as <b>-ffunction-sections -fdata-sections</b>
hal.make.link_flags <sup>(6)</sup>	Input as <b>-Wl,--gc-sections</b>
hal.make.cflags_optimization <sup>(6)</sup>	Input as <b>-Os</b>

:


Figure 135. hal Settings



The screenshot shows the 'hal' configuration window with the following settings:

- max\_file\_descriptors: 4
- ☐ enable\_instruction\_related\_exceptions\_api
- log\_port: none
- ☐ enable\_exit
- ☐ enable\_clean\_exit
- ☐ enable\_runtime\_stack\_checking
- ☐ enable\_c\_plus\_plus
- ☐ enable\_lightweight\_device\_driver\_api
- log\_flags: 0
- sys\_clk\_timer: none
- timestamp\_timer: none
- stdin: none
- stdout: none
- stderr: none

Figure 136. hal.linker Settings



The screenshot shows the 'hal.linker' configuration window with the following settings:

- ☒ allow\_code\_at\_reset
- ☒ enable\_alt\_load
- ☒ enable\_alt\_load\_copy\_rodata
- ☒ enable\_alt\_load\_copy\_rwdata
- ☒ enable\_alt\_load\_copy\_exceptions

Figure 137. hal.toolchain Settings





Figure 138. hal.make Settings



3. Go to **BSP Software Package** and enable altera\_safeclib

Figure 139. BSP Software Package

Main	BSP Software Packages	BSP Linker Script																					
	<table> <tr> <th>Software Package Name</th><th>Version</th><th>Enable</th></tr> <tr> <td>altera_safeclib</td><td>19.1</td><td><input checked="" type="checkbox"/></td></tr> <tr> <td>altera_hostfs</td><td>default</td><td><input type="checkbox"/></td></tr> <tr> <td>altera_quad_seven_seg</td><td>default</td><td><input type="checkbox"/></td></tr> <tr> <td>altera_ro_zips</td><td>default</td><td><input type="checkbox"/></td></tr> <tr> <td>intel_vip_warp_data</td><td>default</td><td><input type="checkbox"/></td></tr> <tr> <td>intel_vip_warp_mesh</td><td>default</td><td><input type="checkbox"/></td></tr> </table>	Software Package Name	Version	Enable	altera_safeclib	19.1	<input checked="" type="checkbox"/>	altera_hostfs	default	<input type="checkbox"/>	altera_quad_seven_seg	default	<input type="checkbox"/>	altera_ro_zips	default	<input type="checkbox"/>	intel_vip_warp_data	default	<input type="checkbox"/>	intel_vip_warp_mesh	default	<input type="checkbox"/>	
Software Package Name	Version	Enable																					
altera_safeclib	19.1	<input checked="" type="checkbox"/>																					
altera_hostfs	default	<input type="checkbox"/>																					
altera_quad_seven_seg	default	<input type="checkbox"/>																					
altera_ro_zips	default	<input type="checkbox"/>																					
intel_vip_warp_data	default	<input type="checkbox"/>																					
intel_vip_warp_mesh	default	<input type="checkbox"/>																					

4. Click the **BSP Linker Script** tab in the BSP Editor.
5. Set the .text item in the **Linker Section Name** to the Bootloader ROM in the **Linker Region Name**. Set the rest of the items in the **Linker Section Name** list to the Bootloader RAM.



Figure 140. Linker Region Settings

Linker Section Mappings		
Linker Section Name	Linker Region Name	Memory Device Name
.bss	bootcopier ram	bootcopier ram
.entry	reset	bootcopier rom
.exceptions	bootcopier ram	bootcopier ram
.heap	bootcopier ram	bootcopier ram
.rodata	bootcopier ram	bootcopier ram
.rwdata	bootcopier ram	bootcopier ram
.stack	bootcopier ram	bootcopier ram
.text	bootcopier rom	bootcopier rom

6. Navigate to the **BSP Driver** tab and disable all drivers (except the Nios V Processor and Mailbox Client Altera FPGA IP).

Figure 141. BSP Driver tab

Module Name	Module Class Name	Module Version	Driver Name	Driver Version	Enable
bootcopier ram	altera_avlon_0000000000000000	19.0.0	none	none	
bootcopier rom	altera_avlon_0000000000000000	19.0.0	none	none	
csd	intel_mbox_0000000000000000	22.0.0	intel_mbox_0000000000000000	default	<input checked="" type="checkbox"/>
mailbox	altera_s10_mailbox_client	20.0.0	altera_s10_mailbox_client	default	<input checked="" type="checkbox"/>
uart	altera_avlon_0000000000000000	19.0.0	altera_avlon_0000000000000000	default	<input checked="" type="checkbox"/>
uart_avlon_0000000000000000	altera_avlon_0000000000000000	19.0.0	none	none	

7. Click **Generate BSP**. Make sure the BSP generation is successful.
8. Close the BSP Editor.

### Create the Bootloader via SDM Application Project

1. In software/mailbox\_bootloader/app folder, create a C source code.
2. Name it as mailbox\_bootloader.c.
3. In mailbox\_bootloader.c, copy and paste the Bootloader via SDM code below.

```
#include "altera_s10_mailbox_client_flash.h"
#include "sys/alt_irq.h"
#include <unistd.h>

// Constants
#define PROGRAM_RECORD_HEADER_SZ 8
#define PROGRAM_RECORD_LEN_IDX 0
#define PROGRAM_RECORD_ADDR_IDX 1
#define ERASED_FLASH_CONTENTS 0xFFFFFFFF
#define MAX_ATTEMPTS 1000

// Design specific (customize here)
#define MBOX_NAME "/dev/mailbox"
#define PAYLOAD_OFFSET 0x200000

// Global header buffer
alt_u32 g_program_header[2];

// *** Assumptions:
// All addresses & lengths are 32-bit word aligned
// aka 0x0, 0x4, 0x8, 0xC, 0x10, etc

__attribute__((noreturn)) void error() {
    while (1);
}

void read_flash(intel_mailbox_client* mbox_client,
```

```
int offset,
void* dest_addr,
int length) {
    if (mailbox_client_flash_read(mbox_client, offset, dest_addr, length) !=
0)
        error();
}

__attribute__((noreturn)) int main(int argc, char **argv) {
    intel_mailbox_client* mbox_client = mailbox_client_open(MBOX_NAME);
    int record_address_ptr = PAYLOAD_OFFSET;

    // Obtain exclusive flash access
    // Applied delay if Mailbox Client IP is busy
    int attempt = 0;
    while((mailbox_client_flash_open(mbox_client) != 0) &&
(++attempt < MAX_ATTEMPTS)){
        usleep(10000);
    }
    if (attempt == MAX_ATTEMPTS)
        error();

    for (;;) {
        read_flash(mbox_client, record_address_ptr,
(void *)g_program_header, PROGRAM_RECORD_HEADER_SZ);
        record_address_ptr += PROGRAM_RECORD_HEADER_SZ;

        // The address in this case is the jump target
        if (g_program_header[PROGRAM_RECORD_LEN_IDX] == 0)
            break;

        // This is not a legal or sane length.
        // It implies the flash we're reading isn't programmed,
        // and the safest thing to do in this case is error out.
        if (g_program_header[PROGRAM_RECORD_LEN_IDX] ==
ERASED_FLASH_CONTENTS)
            error();

        read_flash(mbox_client, record_address_ptr,
(void *) (g_program_header[PROGRAM_RECORD_ADDR_IDX]),
g_program_header[PROGRAM_RECORD_LEN_IDX]);
        record_address_ptr += g_program_header[PROGRAM_RECORD_LEN_IDX];
    }

    // Release exclusive flash access
    if (mailbox_client_flash_close(mbox_client) != 0)
        error();

    // Disable all interrupts before jumping
    alt_irq_disable_all();

    // Jump to user application
    void *jump_target = (void *) (g_program_header[PROGRAM_RECORD_ADDR_IDX]);
    asm volatile ("jr %[reset_vec] : : [reset_vec] "r" (jump_target));

    // Code should never get here -- put here to keep the compiler happy
    while (1);
}
```

4. Redefine the MBOX\_NAME according to the name of Mailbox Client IP in system.h.
5. Redefine the PAYLOAD\_OFFSET in mailbox\_bootloader.c.

**Note:** The SOF image size influences the PAYLOAD\_OFFSET. The PAYLOAD\_OFFSET is the start address of the Nios V application HEX file in QSPI flash and must point to a location after the SOF image. You can determine the minimum PAYLOAD\_OFFSET by using the configuration bitstream size from the device datasheet.

For example, the estimated compressed configuration bitstream size for Intel Stratix 10 SX 2800 is 577 Mbits (72.125 MBytes). The actual size can be equal or smaller than this bitstream size. If the SOF image starts at address 0x0, the SOF image should be reached until address 0x44C8FFF (0x44C8A48). With that, the minimum PAYLOAD\_OFFSET you can select is 0x4500000.

6. Launch the Nios V Command Shell.
7. Execute the command below to generate the Bootloader via SDM application CMakeLists.txt.

```
niosv-app --app-dir=software/mailbox_bootloader/app\  
--bsp-dir=software/mailbox_bootloader/bsp\  
--srcs=software/mailbox_bootloader/app/mailbox_bootloader.c
```

### Building the Bootloader via SDM Project

You can choose to build the Bootloader via SDM project using the RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

With the CLI, you can build the Bootloader via SDM using the following commands:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Release -B \  
software/mailbox_bootloader/app/release -S \  
software/mailbox_bootloader/app
```

```
make -C software/mailbox_bootloader/app/release
```

The Bootloader via SDM (.elf) file is created in

software/mailbox\_bootloader/app/release folder.

### Generating the HEX File and Initializing the Memory

A HEX file must be generated from the ELF file so that the HEX file can be used for memory initialization.

1. Launch the Nios V Command Shell.
2. For Bootloader via SDM, use the following command line to convert the ELF to HEX. This command creates the Bootloader via SDM (bootcopier\_rom.hex) file.

```
elf2hex software/mailbox_bootloader/app/release/app.elf \  
-o bootcopier_rom.hex \  
-b <base address of Bootloader ROM> \  
-w <data width of Bootloader ROM in bits> \  
-e <end address of Bootloader ROM> \  
-r <data width of Bootloader ROM in bytes>
```

Recompile the hardware design to memory-initialize the bootcopier\_rom.hex into the Bootloader ROM.

### Related Information

- [Summary of Nios V Processor Vector Configuration and BSP Settings](#) on page 154
- [Bootloader via SDM Example Design](#) on page 138

#### 4.7.3.1.4. Software Design Flow (User Application Project)


This section provides the design flow to generate and build the Nios V processor user application.

##### Creating the User Application BSP Project

To launch the BSP Editor, follow these steps:

1. In the Platform Designer window, select **File ► New BSP** . The **Create New BSP** windows appears.
2. For **BSP setting file**, navigate to the software/user\_application/bsp folder and name the BSP as settings.bsp.  
BSP path: <project directory>/software/user\_application/bsp/settings.bsp
3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system (.qsys).
4. For **Quartus project**, select the Quartus Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.


**Figure 142. Create New BSP Window**



##### Configure BSP Editor and Generate the BSP Project

1. Go to **Main ► Settings ► Settings ► Advanced ► hal.linker**.
2. Enable the following settings:
  - a. **enable\_alt\_load**
  - b. **enable\_alt\_load\_copy\_exceptions**

Figure 143. hal.linker Settings



3. Click the **BSP Linker Script** tab in the **BSP Editor**.

Figure 144. Linker Region Settings

Linker Section Mappings		
Linker Section Name *	Linker Region Name	Memory Device Name
.bss	user application mem	user application mem
.entry	reset	bootcopier rom
.exceptions	user application mem	user application mem
.heap	user application mem	user application mem
.rodata	user application mem	user application mem
.rwdata	user application mem	user application mem
.stack	user application mem	user application mem
.text	user application mem	user application mem

4. Set all the **Linker Section Name** list to the User Application RAM.
5. Click **Generate BSP**. Make sure the BSP generation is successful.
6. Close the **BSP Editor**.

### Creating the User Application Project

1. Navigate to the software/user\_application/app folder and create your user application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the user application CMakeLists.txt.

```
niosv-app --app-dir=software/user_application/app \
--bsp-dir=software/user_application/bsp \
--srcs=software/user_application/app/<user application>
```

### Building the Application Project

You can choose to build the application project using the RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

With the CLI, you can build the user application using the following commands:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Debug \
-B software/user_application/app/debug -S software/user_application/app
```

```
make -C software/user_application/app/debug
```

The user application (.elf) file is created in software/user\_application/app/debug folder.

### Generating the HEX File

You must generate a .hex file from your application .elf file, so you can create a .jic file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application copied from QSPI flash using bootloader via SDM, use the following commands to convert the ELF to HEX for your application. These commands creates the user application (.hex) file.

```
elf2flash --input software/user_application/app/debug/<user application>.elf \
--output flash.srec -epcs --offset 0x0
```

```
riscv32-unknown-elf-objcopy --input-target srec \
--output-target ihex flash.srec \
<user application>.hex
```


### Related Information

Summary of Nios V Processor Vector Configuration and BSP Settings on page 154

#### 4.7.3.1.5. Programming Files Generation

1. Go to **File ► Programming File Generator**.
2. Select the **Configuration mode** to be **Active Serial x4**.
3. In the **Output Files** tab, select **JTAG Indirect Configuration File (.jic)**.

**Figure 145. Programming File Generator (Output Files)**



4. In the **Input Files** tab, perform the following steps:


- a. Add the SOF file by clicking **Add Bitstream**.
- b. Add the user application (.hex) file by clicking **Add Raw Data**.
- c. Select the HEX file and click **Properties**.
- d. Select **Bit Swap : On**.

**Figure 146. Programming File Generator (Input Files)**



5. In the **Configuration Device** tab,
  - a. Add the flash device by clicking **Add Device**.
    - i. If you are using a supported device, you may make your selection, and click **OK**. Else, proceed to **Apply the Configuration Device window**.
  - b. Add the SOF file by selecting the flash device and click **Add Partition**.
  - c. Add the user application (.hex) file by selecting the flash device and click **Add Partition**. Select the **Address Mode** to **Start** and set the **Start address** to the value set for PAYLOAD\_OFFSET in mailbox\_bootcopier.c.
  - d. Select the **Flash loader** according to the Altera FPGA device.

Figure 147. Programming File Generator (Configuration Device)




6. Click **Generate** to generate the JIC file.

### Applying the Configuration Device Window

The **Configuration Device** allows for choosing a specific supported device or alternatively an unsupported device.



Figure 148. Configuration Device Window



1. If you are using a supported device, make your selection, and click **OK**. Else, proceed with the following steps:
  - a. Select **<<new device>>**.
  - b. Enter the information about **Device name**, **Device ID**, **Device I/O voltage**, **Device density**, **Total device die**, **Dummy clock (Single I/O or Quad I/O mode)** and **Programming flow template**.
  - c. Click **Apply**.

*Note:* The **Programming flow template** helps you to define a template for flash operation in Initialization, Program, Erase, Verify/Blank-Check/Examine and Termination. If the device is not available for selection, refer to **Modifying Programming Flows** in *Generic Flash Programmer User Guide* to modify the programming flow.

Device name:	MT25QL256
Device ID:	0x20 0xBA 0x19
Device I/O voltage:	3.0V/3.3V +
Device density:	256Mb +
Total device die:	1
Single I/O mode dummy clock:	15
Quad I/O mode dummy clock:	15
Programming flow template:	Micron + Edit...
<input type="checkbox"/> Save as template	

#### 4.7.3.1.6. QSPI Flash Programming SDM

##### Altera FPGA Device QSPI Flash Programming

1. Ensure that the Altera FPGA device's Active Serial (AS) pin is routed to the QSPI flash. This routing allows the flash loader to load into the QSPI flash and configure the board correctly.
2. Ensure the MSEL pin setting on the board is configured for AS programming.
3. Open the Quartus Prime Programmer and make sure JTAG is detected under the **Hardware Setup**.
4. Select **Auto Detect** and choose the FPGA device according to your board.
5. Right-click the selected Altera FPGA device and select **Edit ► Change File**. Next, select the generated JIC file.
6. Select the **Program/ Configure** check boxes for FPGA and QSPI devices.
7. Click **Start** to start programming.

#### 4.7.3.2. Bootloader via SDM Example Design

You can download the Bootloader via SDM example design from the *Intel FPGA Design Store*. The example design is based on the Stratix 10 SX SoC L-Tile development kit.

Using the provided scripts, the hardware and software design are generated and programmed respectively as SRAM Object Files (.sof) and JTAG Indirect Configuration Files (.jic) into the device.


Follow the steps below to generate the Bootloader via SDM example design:

1. Go to Altera FPGA Design Store.
2. Search for *Stratix10 - Bootloader SDM Design* package.
3. Click on the link at the title.

4. Accept the *Software License Agreement*.
5. Download the package according to the Quartus Prime software version of your host machine.
6. Refer to the `readme.txt` for how-to guide.

**Table 42. Example Design File Description**

File	Description
hw/	Contains files necessary to run the hardware project.
ready_to_test/	Contains pre-built hardware and software binaries to run the design on the target hardware. For this package, the target hardware is Stratix 10 SX 10 SoC L-tile development kit.
scripts/	Consists of scripts to build the design.
sw/	Contains software application files.
readme.txt	Contains description and steps to apply the pre-built binaries or rebuild the binaries from scratch.

**Figure 149. Bootloader via SDM Example Design**

**Figure 150. JUART Terminal Output**

1. In the beginning, the window displays the following message

```

langage@ppg17085: ~$ boot_V10_211865-@ppg17085-
juart-terminal: connected to hardware target using JTAG UART on cable
juart-terminal: 'Stratix 10L SoC Dev Kit on 10.236.218.201 [USB-3]', device 1, 1
instance 0
juart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

[crt0.S] Setting up stack and global pointers.
[crt0.S] Clearing BSS
[crt0.S] Calling alt_main.
[alt_main.c] Entering alt_main, calling alt_irq_init.
[alt_main.c] Done alt_irq_init, calling alt_os_init.
[alt_main.c] Done OS init, calling alt_sem_create.
[alt_main.c] Calling alt_sys_init.
[alt_main.c] Done alt_sys_init.
[alt_main.c] Redirecting IO,
[alt_main.c] Calling main.
Hello World: 0
Hello World: 1
Hello World: 2
Hello World: 3
Hello World: 4

```

2. Reaching the end, the window displays the following message:

```

langage@ppg17085: ~$ boot_V10_211865-@ppg17085-
Hello World: 94
Hello World: 95
Hello World: 96
Hello World: 97
Hello World: 98
Hello World: 99
[alt_exit.c] Entering _exit() function.
[alt_exit.c] Exit code from main was 0.
[alt_exit.c] Calling ALT_OS_STOP().
[alt_exit.c] Calling ALT_SIM_HALT().
[alt_exit.c] Spinning forever.

```

#### Related Information

- [Software Design Flow \(Bootloader via SDM Project\)](#) on page 125
- [Altera FPGA Design Store](#)


## 4.8. Nios V Processor Booting from On-Chip Memory (OCRAM)

This section describes the Nios V processor booting and executing software from On-Chip Memory (OCRAM) available in all supported Altera FPGA devices.


### 4.8.1. Nios V Processor Application Executes in-place from OCRAM

The on-chip memory is initialized during FPGA configuration with data from a Nios V processor application image. This data is built into the FPGA configuration bitstream. This process eliminates the need for a boot copier, as the Nios V processor application is already in place at system reset.

**Figure 151. Nios V Processor Application Executes In-Place from OCRAM when FPGA Device Configured from QSPI Flash**



**Figure 152. Design, Configuration and Booting Flow**



### 4.8.1.1. Hardware Design Flow

The following sections describe a step-by-step method for building a bootable system for a Nios V processor application from OCRM. The example below is built using Intel Arria 10 SoC development kit.

#### IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.
2. Ensure the On-Chip Memory (RAM or ROM) Altera FPGA is added into your Platform Designer system.
3. Enable **Initialize memory content** and **Enable non-default initialization file** with `ram.hex` in the on-chip memory.

Figure 153. Connections for Nios V Processor Project




Figure 154. On-Chip Memory (RAM or ROM) Intel FPGA IP Parameter Settings

#### Reset Agent Settings for Nios V Processor

1. In the Nios V processor parameter editor, set the **Reset Agent** to OCRM

Figure 155. Nios V Processor Parameter Editor Settings

2. Click **Generate HDL**, the Generation dialog box appears.
3. Specify output file generation options and then click **Generate**.

### Quartus Prime Settings

1. In the Intel Quartus Prime software, click **Assignment** ► **Device** ► **Device and Pin Options** ► **Configuration**.
2. Set **Configuration scheme** according to your FPGA configuration scheme
3. Click **OK** to exit the **Device and Pin Options** window.
4. Click **OK** to exit the **Device** window.
5. Click **Start Compilation** to compile your project.

### Related Information

Arria 10 SoC Development Kit


#### 4.8.1.2. Software Design Flow

This section provides the design flow to generate and build the Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `app` and `bsp`.

**Figure 156. Software Project Directory Tree**



### Creating the Application BSP Project

**Note:** For Quartus Prime Standard Edition software, refer to the topic *AN 980: Nios V Processor Quartus Prime Software Support* for the steps to invoke the BSP Editor GUI.


To launch the BSP Editor, follow these steps:

1. In the Platform Designer window, select **File** ► **New BSP**. The **Create New BSP** windows appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and name the BSP as `settings.bsp`.  
BSP path: `<project directory>/software/bsp/settings.bsp`
3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system (`.qsys`) file.  
**Note:** For Quartus Prime Standard Edition software, generate the BSP file using SOPCINFO file. Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for more information.
4. For **Quartus project**, select the Quartus Project File.
5. For **Revision**, select the correct revision.



6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.

Figure 157. Create New BSP Window



### Configuring the BSP Editor and Generating the BSP Project

1. Go to **Main ► Settings ► Advanced ► hal.linker**.
2. Enable the following settings:
  - **allow\_code\_at\_reset**
  - **enable\_alt\_load**
  - **enable\_alt\_load\_copy\_rwdata**

Figure 158. hal.linker Settings



3. Click the **BSP Linker Script** tab in the **BSP Editor**
4. Set all the **Linker Section Name** list to the OCRAM.
5. Click **Generate BSP**. Make sure the BSP generation is successful.
6. Close the **BSP Editor**

### Generating the Application Project File

1. Navigate to the `software/app` folder and create your user application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the user application `CMakeLists.txt`.

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/<user application>
```

### Building the Application Project

You can choose to build the application project using RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the application using the following command:

```
cmake -G "Unix Makefiles" -B software/app/build -S software/app
```

```
make -C software/app/build
```

The user application (`.elf`) file is created in `software/app/build` folder.

### Generating the HEX File

You must generate a `.hex` file from your application `.elf` file, so you can create a `.jic` file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from OCRAM, use the following command line to convert the ELF to HEX for your application. This command creates the user application (`ram.hex`) file.

```
elf2hex software/app/build/<user_application>.elf -o ram.hex \
-b <base address of OCRAM> \
-w <data width of OCRAM in bits> \
-e <end address of OCRAM> \
-r <data width of OCRAM in bytes>
```

**Note:** If you enable ECC in OCRAM, use the following command line to convert the ELF to HEX for your application. The following command line creates the user application (`ram.hex`) file with ECC parity bits. This feature is supported in 32-bit OCRAM only.

```
elf2hex software/app/build/<user_application>.elf -o ram.hex \
-b <base address of OCRAM> \
-w 39 \
-e <end address of OCRAM> \
-r 4
```

3. Recompile the hardware design to memory-initialize the `ram.hex` into the OCRAM.

### Related Information

- [Summary of Nios V Processor Vector Configuration and BSP Settings](#) on page 154
- [AN 980: Nios V Processor Quartus Prime Software Support](#)

#### 4.8.1.3. Programming

The Nios V processor application file is built into the Altera FPGA configuration bitstream. Based on your Altera FPGA configuration scheme, program your device with the programming file containing .sof file. The Nios V processor application runs once the Nios V processor system is reset upon entering user mode.


### 4.9. Nios V Processor Booting from Tightly Coupled Memory (TCM)

This section describes the Nios V processor booting and executing software from Tightly Coupled Memory (TCM) available in all supported Altera FPGA devices.


#### 4.9.1. Nios V Processor Application Executes in-place from TCM

The tightly coupled memories are initialized during FPGA configuration with data from a Nios V processor application image. This data is built into the FPGA configuration bitstream. This process eliminates the need for a boot copier, as the Nios V processor application is already in place at system reset.

**Figure 159. Nios V Processor Application Executes In-Place from TCM when FPGA Device Configured from QSPI Flash**



**Figure 160. Design, Configuration, and Booting Flow**




#### 4.9.1.1. Hardware Design Flow

The following sections describe a step-by-step method for building a bootable system for a Nios V processor application from TCM. The example below is built using Arria 10 SoC development kit.

##### IP Component Settings

1. Create your Nios V processor project using Quartus Prime and Platform Designer.

Figure 161. Connections for Nios V Processor Project



**Note:** Place all external peripheral IPs (e.g. JTAG UART, MSGDMA, PIO, and others) within a peripheral region. This requirement does not apply to dm\_agent and timer\_sw\_agent.

### TCM Settings for Nios V Processor

1. In the Nios V processor parameter editor, enable the **Instruction TCM1** and **Data TCM1**.
2. Initialize **Instruction TCM1** with itcm.hex.
3. Initialize **Data TCM1** with dtcm.hex.

Figure 162. Instruction TCM1 Settings




Figure 163. Data TCM1 Settings

- Align the base address of **instruction\_tcs1** to be the same as **Instruction ITCM1** (0x40000).

Figure 164. Instruction\_tcs1 Aligned Base Address

### Reset Agent Settings for Nios V Processor

- In the Nios V processor parameter editor, set the **Reset Agent** to Instruction TCM1.

Figure 165. Reset Agent Settings for Nios V Processor

- Click **Generate HDL**, the Generation dialog box appears.
- Specify output file generation options and then click **Generate**.

### Quartus Prime Settings

- In the Intel Quartus Prime software, click **Assignment > Device > Device and Pin Options > Configuration**.
- Set **Configuration scheme** according to your FPGA configuration scheme
- Click **OK** to exit the **Device and Pin Options** window.
- Click **OK** to exit the **Device** window.
- Click **Start Compilation** to compile your project.

### Related Information

[Arria 10 SoC Development Kit](#)


#### 4.9.1.2. Software Design Flow

This section provides the design flow to generate and build the Nios V processor software project. To ensure a streamlined build flow, you are encouraged to create similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `app` and `bsp`.

**Figure 166. Software Project Directory Tree**



#### Creating the Application BSP Project

To launch the BSP Editor, follow these steps:

1. In the Platform Designer window, select **File > New BSP**. The **Create New BSP** windows appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and name the BSP as `settings.bsp`.


BSP path: `<project directory>/software/bsp/settings.bsp`

3. For **System file (qsys or sopcinfo)**, select the Nios V/g processor Platform Designer system (`.qsys`) file.

*Note:* For Quartus Prime Standard Edition software, generate the BSP files using SOPCINFO. Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for more information.

4. For **Quartus project**, select the Quartus Prime Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V/g processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.

Figure 167. Create New BSP Window



### Configuring the BSP Editor and Generating the BSP Project

1. Go to **Main ► Settings ► Advanced ► hal.linker**.
2. Enable **allow\_code\_at\_reset** only.

Figure 168. hal.linker Settings



3. Click the **BSP Linker Script** tab in the **BSP Editor**
4. In the **Linker Section Name** perform the following settings:
  - a. Set **.text** and **.exceptions** to Instruction TCM1.
  - b. Set the remaining Linker Section Name to the Data TCM1.



**Figure 169. Linker Region Settings for TCM**

Linker Section Mappings		
Linker Section Name	Linker Region Name	Memory Device Name
bss	niosvdtcm1	niosvdtcm1
entry	reset	niosvitcm1
exceptions	niosvitcm1	niosvitcm1
heap	niosvdtcm1	niosvdtcm1
rodata	niosvdtcm1	niosvdtcm1
rwdara	niosvdtcm1	niosvdtcm1
stack	niosvdtcm1	niosvdtcm1
text	niosvitcm1	niosvitcm1

5. Click **Generate BSP**. Make sure the BSP generation is successful.
6. Close the **BSP Editor**

### Generating the Application Project File

1. Navigate to the `software/app` folder and create your user application source code.
2. Launch the Nios V Command Shell.
3. Execute the command below to generate the user application `CMakeLists.txt`.

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/<user application>
```

### Building the Application Project

You can choose to build the application project using RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the application using the following command:

```
cmake -G "Unix Makefiles" -B software/app/build -S software/app
```

```
make -C software/app/build
```

The user application (`.elf`) file is created in `software/app/build` folder.

### Generating the HEX File

You must generate a `.hex` file from your application `.elf` file, so you can create a `.jic` file suitable for programming flash devices.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from TCM, use the following command line to convert the ELF to HEX for your application. This command creates the user application (`itcm.hex` and `dtcm.hex`) file.

```
elf2hex software/app/build/<user_application>.elf -o itcm.hex \
-b <base address of ITCM> -w 32 \
-e <end address of ITCM> -r 4

elf2hex software/app/build/<user_application>.elf -o dtcm.hex \
-b <base address of DTCM> -w 32 \
-e <end address of DTCM> -r 4
```

**Note:** If you enable ECC in Nios V processor (thus, enabling ECC in TCM), use the following command line to convert the ELF to HEX for your application. This command line creates the user application (`itcm.hex` and `dtdcm.hex`) files with ECC parity bits.

```
elf2hex software/app/build/<user_application>.elf -o itcm.hex \
-b <base address of ITCM> -w 39 \
-e <end address of ITCM> -r 4
elf2hex software/app/build/<user_application>.elf -o dtdcm.hex \
-b <base address of DTCM> -w 39 \
-e <end address of DTCM> -r 4
```

3. Recompile the hardware design to memory-initialize both the HEX files into the Instruction TCM and Data TCM.

#### Related Information

- [Summary of Nios V Processor Vector Configuration and BSP Settings](#) on page 154
- [AN 980: Nios V Processor Quartus Prime Software Support](#)

#### 4.9.1.3. Programming

The Nios V processor application file is built into the Altera FPGA configuration bitstream. Based on your Altera FPGA configuration scheme, program your device with the programming file containing `.sof` file. The Nios V processor application runs once the Nios V processor system is reset upon entering user mode.

### 4.10. Summary of Nios V Processor Vector Configuration and BSP Settings

The following table shows a summary of Nios V processor reset and exception agent configurations, and BSP settings.

**Table 43. Summary of Nios V Processor Vector Configurations and BSP Settings**

Boot Option	Reset Agent	BSP Editor Setting: Settings	BSP Editor Setting: Linker Script
Nios V processor application executes in-place from boot flash	<ul style="list-style-type: none"> <li>On-Chip Flash</li> <li>General Purpose QSPI flash</li> <li>Configuration QSPI Flash</li> </ul>	<p>If the <code>.exceptionn</code> Linker Section is set to OCRAM/ External RAM, enable the following settings in <b>Advanced.hal.linker</b></p> <ul style="list-style-type: none"> <li><code>allow_code_at_reset</code></li> <li><code>enable_alt_load</code></li> <li><code>enable_alt_load_copy_rodata</code></li> <li><code>enable_alt_load_copy_rwdata</code></li> <li><code>enable_alt_load_copy_exceptions</code></li> </ul> <p>If the <code>.exception</code> Linker Section is set to boot flash, enable the following settings in <b>Advanced.hal.linker</b>:</p>	<ul style="list-style-type: none"> <li>Set <code>.text</code> Linker Section to boot flash</li> <li>Set <code>.exception</code> Linker Section to OCRAM/External RAM or boot flash.</li> <li>Set other Linker Sections (<code>.heap</code>, <code>.rwdata</code>, <code>rodata</code>, <code>.bss</code>, <code>.stack</code>) to OCRAM / External RAM</li> </ul>
continued...			

Boot Option	Reset Agent	BSP Editor Setting: Settings	BSP Editor Setting: Linker Script
		<ul style="list-style-type: none"> <li>allow_code_at_reset</li> <li>enable_alt_load</li> <li>enable_alt_load_copy_rodata</li> <li>enable_alt_load_copy_rwdata</li> </ul>	
Nios V processor application copied from boot flash to RAM using bootloader via GSFI	<ul style="list-style-type: none"> <li>On-Chip Flash</li> <li>General Purpose QSPI flash</li> <li>Configuration QSPI Flash</li> </ul>	Uncheck all settings in <b>Advanced.hal.linker</b> .	Make sure all Linker Sections are set to OCRAM / External RAM.
Nios V processor application copied from configuration QSPI flash to RAM using bootloader via SDM	Bootloader ROM	For bootloader via SDM, enable the following settings in <b>Advanced.hal.linker</b> : <ul style="list-style-type: none"> <li>allow_code_at_reset</li> <li>enable_alt_load</li> <li>enable_alt_load_copy_rodata</li> <li>enable_alt_load_copy_rwdata</li> <li>enable_alt_load_copy_exceptions</li> </ul>	For bootloader via SDM: <ul style="list-style-type: none"> <li>Set <b>.text</b> Linker Section to Bootloader ROM.</li> <li>Set other Linker Sections (<b>.heap</b>, <b>.rwdata</b>, <b>.rodata</b>, <b>.bss</b>, <b>.stack</b>, <b>.exception</b>) to Bootloader RAM.</li> </ul>
		For user application, enable the following settings in <b>Advanced.hal.linker</b> : <ul style="list-style-type: none"> <li>enable_alt_load</li> <li>enable_alt_load_copy_exceptions</li> </ul>	For user application, make sure all Linker Sections are set to User Application RAM.
Nios V processor application execute in-place from On-chip Memory (OCRAM)	OCRAM	Enable <b>allow_code_at_reset</b> in <b>Advanced.hal.linker</b> and uncheck other settings.	Make sure all Linker Sections are set to OCRAM.
Nios V processor application execute in-place from Tightly Coupled Memory (TCM)	TCM	Enable <b>allow_code_at_reset</b> in <b>Advanced.hal.linker</b> and uncheck other settings.	<ul style="list-style-type: none"> <li>Set <b>.text</b> and <b>.exception</b> Linker Section to Instruction TCM.</li> <li>Set other Linker Section (<b>.heap</b>, <b>.rwdata</b>, <b>.rodata</b>, <b>.bss</b>, <b>.stack</b> to Data TCM.</li> </ul>

### Related Information

- [Software Design Flow](#) on page 99  
Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via GSFI).
- [Software Design Flow](#) on page 111  
Nios V Processor Application Executes-In-Place from Configuration QSPI Flash.
- [Software Design Flow \(Bootloader via SDM Project\)](#) on page 125  
Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via SDM) - Bootloader via SDM Project
- [Software Design Flow \(User Application Project\)](#) on page 132  
Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via SDM) - User Application Project
- [Software Design Flow](#) on page 144  
Nios V Processor Application Executes in-place from OCRAM
- [Software Design Flow](#) on page 151

## 4.11. Reducing Nios V Processor Booting Time

### 4.11.1. Boot Methods

The Nios V processor supports two booting methods:

**Table 44. Boot Methods**

Boot Methods	Advantages
Execute-in-place	<ul style="list-style-type: none"> <li>Faster boot time than boot copier. This is because the time taken to copy the code from boot memory to RAM is longer than running directly (execute-in-place) from the boot memory.</li> </ul>
Boot copier	<ul style="list-style-type: none"> <li>Altera recommends this method for systems that require higher performance. Although this configuration has longer boot time, it delivers higher application performance than an execute-in-place configuration.</li> </ul>

### 4.11.2. Boot devices

For Nios V application execute-in-place, different boot devices have different boot times based on their individual memory performance.

**Figure 170. Supported Boot Device Performance**



### 4.11.3. Peripheral Initialization

Nios V processor systems initialize all HAL peripherals before `main()` by default. As a result, the boot time varies based on the peripherals you choose. Peripherals that are slow to initialize or have external dependencies increases the boot time and potentially make it less deterministic. If this occurs, you need to calibrate the external memory, such as DDR3, for it to work properly.

DDR3 is an example of a peripheral where the initialization time is significant in comparison to the boot time. The calibration time is long, particularly when compared to boot times for execute-in-place boot configurations. The calibration time significantly impacts Nios V processor application that execute-in-place.

To avoid this, in execute-in-place boot configurations, remove the external memory from the Nios V processor linker region if it is not in use. If size is not an issue, you can choose to use OCRAM. If you are confident working with Nios V processor software, another option is to remove the DDR3 initialization routine from the boot code and initialize the memory later—once the application code has started running.

### 4.11.4. Caches

You can enhance the boot time of your Nios V processor hardware configuration for both execute-in-place or boot copier boot methods to improve boot time. Caches improve the boot time because the data and instruction caches reduce memory bandwidth limitations during the boot sequence.



#### **4.11.5. System Speed**

Using Nios V processor with higher clock speed can improve the boot time.

## 5. Nios V Processor - Using the MicroC/TCP-IP Stack


### 5.1. Introduction

The Nios V processor tools contains the  $\mu$ C/OS-II RTOS and the  $\mu$ C/TCP-IP software component, providing designers with the ability to quickly build networked embedded systems applications for the Nios V processor.

### 5.2. Software Architecture

The onion diagram shows the architectural layers of a Nios V processor  $\mu$ C/OS-II software application.

**Figure 171. Layered Software Model**



Each layer encapsulates the specific implementation details of that layer, abstracting the data for the next outer layer. The following list describes each layer:

- **Nios V processor system hardware:** The core of the onion diagram represents the Nios V processor and hardware peripherals implemented in the Altera FPGA.
- **Software device drivers:** The software device drivers layer contains the software functions that manipulate the Ethernet and hardware peripherals. These drivers know the physical details of the peripheral devices, abstracting those details from the outer layers.
- **HAL API:** The Hardware Abstraction Layer (HAL) application programming interface (API) provides a standardized interface to the software device drivers, presenting a POSIX-like API to the outer layers.
- **MicroC/OS-II:** The  $\mu$ C/OS-II RTOS layer provides multitasking and inter-task communication services to the  $\mu$ C/TCP-IP Stack and the Nios V processor.
- **MicroC/TCP-IP Stack software component:** The  $\mu$ C/TCP-IP Stack software component layer provides networking services to the application layer and application-specific system initialization layer through the sockets API.
- **Application-specific system initialization:** The application-specific system initialization layer includes the  $\mu$ C/OS-II and  $\mu$ C/TCP-IP Stack software component initialization functions invoked from `main()`, as well as creates all application tasks, and all the semaphores, queue, and event flag RTOS inter-task communication resources.
- **Application:** The outermost application layer contains the Nios V  $\mu$ C/TCP-IP Stack application.

### 5.3. Support and Licensing

Altera distributes  $\mu$ C/OS-II and  $\mu$ C/TCP-IP in the Quartus Prime Design Suite for evaluation purposes only. Commercial version of  $\mu$ C/OS-II and  $\mu$ C/TCP-IP is under Apache 2.0 Open Source Licensing, for more information refer to the Micrium Licensing Website.

#### Related Information

[Micrium Licensing Website](#)

For more information about Commercial version about  $\mu$ C/OS-II and  $\mu$ C/TCP-IP under Apache 2.0 Open Source Licensing.

### 5.4. MicroC/TCP-IP Example Designs

#### 5.4.1. Hardware and Software Requirements

To use a  $\mu$ C/OS-II and  $\mu$ C/TCP-IP program on an Altera FPGA requires the following hardware and software:

- Quartus Prime software
  - Quartus Prime Pro Edition software version 21.3 or later
  - Quartus Prime Standard Edition software version 22.1 or later
- Ashling RiscFree IDE for Altera FPGAs software version 22.2 or later
 

*Note:* Altera recommends you to install the same software version for all softwares.
- One of the supported Intel FPGA devices
  - The example designs are implemented on Arria 10 10 SoC development kit
- Intel FPGA Download Cable II
- RJ-45 connected Ethernet cable on the same network as the PC development host

You must connect your development board to a host PC on the Ethernet and USB/JTAG ports.

### Related Information

[Arria 10 SoC Development Kit](#)

## 5.4.2. Overview

*Note:* For Quartus Prime Standard Edition software, refer to *AN 980: Nios V Processor Quartus Prime Software Support* for the steps to generate the example design.


You can download the  $\mu$ C/TCP-IP Example Designs from the *Altera FPGA Store*. The example designs are based on the Arria 10 10 SoC development kit. Using the scripts, the hardware and software design are generated, and programmed as SRAM Object Files (`.sof`) into the device. Using the memory-initialized `.sof` file, the Nios V processor boots the  $\mu$ C/TCP-IP application from the On-Chip Memory after resetting the processor during User Mode.



The featured  $\mu$ C/TCP-IP Example Designs are :

- **$\mu$ C/TCP-IP IPerf Example Design**
  - This example design incorporated the  $\mu$ C/IPerf, an iPerf 2 server or client developed for the  $\mu$ C/TCP-IP Stack and the  $\mu$ C/OS-II RTOS. iPerf 2 is a benchmarking tool for measuring performance between two systems, and it can be used as a server or a client.
  - An iPerf server receives iPerf request sent over a TCP/IP connection from any iPerf clients, and runs the iPerf test according to the provided arguments. Each test reports the bandwidth, loss and other parameters.


**Figure 172.  $\mu$ C/TCP-IP IPerf Data Flow Diagram**



- **µC/TCP-IP Simple Socket Server Example Design**

- This example design demonstrates communication with a telnet client on a development host PC. The telnet client offers a convenient way of issuing commands over a TCP/IP socket to the Ethernet-connected µC/TCP-IP running on the development board with a simple TCP/IP socket server example.
- The socket server example receives commands sent over a TCP/IP connection and turns LEDs on and off according to the commands. The example consists of a socket server task that listens for commands on a TCP/IP port and dispatches those commands to a set of LED management tasks.

**Figure 173. µC/TCP-IP Simple Socket Server Data Flow Diagram**



*Note:* The Nios V target system does not implement a full telnet server.

**Related Information**

- [µC Product Documentation and Release Notes](#)  
For more information about µC/OS-II, µC/TCP-IP and µC/IPerf.
- [AN 980: Nios V Processor Quartus Prime Software Support](#)
- [AN 980: Nios V Processor Quartus Prime Software Support](#)

### 5.4.3. Acquiring the Example Design Files

**Generating the µC/TCP-IP Example Designs**

To generate the µC/TCP-IP Example Designs , perform the following steps:

1. Go to Altera FPGA Design Store.
2. Search for *Arria10 - Simple Socket Server* or *Arria10 - IPerf* package.
3. Click on the link at the title.

4. Accept the *Software License Agreement*.
5. Download the package according to the Quartus Prime software version of your host machine.
6. Refer to the `readme.txt` for how-to guide.

**Table 45. Example Design File Description**

File	Description
hw/	Contains files necessary to run the hardware project.
ready_to_test/	Contains pre-built hardware and software binaries to run the design on the target hardware. For this package, the target hardware is Arria 10 SoC development kit.
scripts/	Consists of scripts to build the design.
sw/	Contains software application files.
readme.txt	Contains description and steps to apply the pre-built binaries or rebuild the binaries from scratch.

### Running the $\mu$ C/TCP-IP Example Designs

The  $\mu$ C/TCP-IP Example Designs are provided with scripts to facilitate the build flow. The scripts are stored in the scripts folder. You may refer to the readme file (`readme.txt`) to develop the example designs using the provided scripts, or develop the design manually using the Nios V processor tools.

For more information about the hardware and software development follow, refer to [Hardware Development Flow](#) and [Software Development Flow](#).

### Related Information

[Altera FPGA Design Store](#)


## 5.4.4. Hardware Design Files

Despite the example designs functioned differently, they share similar hardware design and BSP settings. The only difference lies in their respective Nios V application source code, one for the Simple Socket Server application, while the other for the iPerf 2 application.

The  $\mu$ C/TCP-IP example designs are developed using the Platform Designer. The hardware files can be generated using the `build_sof.py` Python script. The example design consist of:

- Nios V Processor Altera FPGA IP
- On-Chip Memory II Altera FPGA IP for System Memory and Descriptor Memory
- JTAG UART Altera FPGA IP
- System ID Peripheral Altera FPGA IP
- Parallel I/O Altera FPGA IP (PIO)
- Modular Scatter-Gather DMA Altera FPGA IP (mSGDMA)
- Triple-Speed Ethernet Altera FPGA IP (TSE)

Figure 174. Hardware Block Diagram



Note:

- (1) The first  $n$  bytes are reserved for mSGDMA descriptor buffers, where  $n$  is the number of bytes taken by the configured RX or TX buffers. Applications must not use this memory region.
- (2) For MAC variations without internal FIFO buffers, the transmit and receive FIFOs are external to the MAC function.
- (3) Only one buffer type (RX or TX buffers) can reside in the descriptor memory.

## 5.4.5. Software Design Files

### 5.4.5.1. MicroC/TCP-IP IPerf Example Design

The  $\mu$ C/TCP-IP IPerf example design software files are readily available in the example design zip file. They are stored in the `sw/app` folder.

The following software files constitute the  $\mu$ C/TCP-IP IPerf application:

- **uC-IPerf** folder: Contains  $\mu$ C/IPerf source code.
- **app\_iperf.c**: Contains the iPerf reporter application.
- **app\_iperf.h**: Contains function prototypes for the reporter application.
- **iperf\_cfg.h**: Describe the  $\mu$ C/IPerf module static parameters and run-time configuration structure.
- **log.h**: Contains definitions for logging macros.
- **main.c**: Defines the global structure of type `alt_tse_system_info` which describes the TSE configuration. Defines `main()`, which initializes  $\mu$ C/OS-II,  $\mu$ C/TCP-IP and  $\mu$ C/IPerf, processes the MAC and IP addresses, contains the PHY management tasks, and defines function prototypes.
- **uc\_tcp\_ip\_init.c**: Contains MAC address and IP address routines to manage addressing. Routines are used by  $\mu$ C/TCP-IP during initialization, but are implementation-specific.
- **uc\_tcp\_ip\_init.h**: Contains definitions and function prototypes for  $\mu$ C/TCP-IP initialization.

**Note:** For more information about the original  $\mu$ C/IPerf application, refer to *MicroC-IPerf Github Release*.

#### Related Information

[MicroC-IPerf Github Release](#)

For more information about original  $\mu$ C/IPerf application.

#### 5.4.5.2. MicroC/TCP-IP Simple Socket Server Example Design

The  $\mu$ C/TCP-IP Simple Socket Server example design software files are readily available in the example design zip file. They are stored in the `sw/app` folder.

The following software files constitute the  $\mu$ C/TCP-IP Simple Socket Server application:

- **alt\_error\_handler.c:** Contains three error handlers, one each for the Nios V Simple Socket Server,  $\mu$ C/TCP-IP, and  $\mu$ C/OS-II.
- **alt\_error\_handler.h:** Contains definitions and function prototypes for the three software component-specific error handlers.
- **led.c:** Contains the LED management tasks.
- **led.h :** Contains function prototypes for the LED management tasks.
- **log.h:** Contains definitions for logging macros.
- **main.c:** Defines the global structure of type `alt_tse_system_info` which describes the TSE configuration. Defines `main()`, which initializes  $\mu$ C/OS-II and  $\mu$ C/TCP-IP, processes the MAC and IP addresses, contains the PHY management tasks, and defines function prototypes.
- **simple\_socket\_server.c:** Defines the tasks and functions that use the  $\mu$ C/TCP-IP sockets interface, and creates all the  $\mu$ C/OS-II resources.
- **simple\_socket\_server.h:** Defines the task prototypes, task priorities, and other  $\mu$ C/OS-II resources used.
- **uc\_tcp\_ip\_init.c:** Contains MAC address and IP address routines to manage addressing. Routines are used by  $\mu$ C/TCP-IP during initialization, but are implementation-specific.
- **uc\_tcp\_ip\_init.h:** Contains definitions and function prototypes for  $\mu$ C/TCP-IP initialization.


### 5.5. Development Flow

#### 5.5.1. Hardware Development Flow

You can create the  $\mu$ C/TCP-IP example designs hardware system using the Platform Designer.

1. In the Platform Designer, create a new Platform Designer system (`sys.qsys`).
2. Navigate to **View > System Scripting**.
3. Under the **Project Scripts**, add and run `sys.tcl`.

Figure 175. System Scripting Windows



Alternatively, you can run the `sys.tcl` using CLI:

```
qsys-script --script=<QSYS TCL script>.tcl --quartus-project=<Project name>.qpf
```

4. The generated Platform Designer system consist of the Nios V processor, TSE IP, mSGDMA IP and other peripherals. Refer to [Hardware Design Files](#) for the complete system.
5. Click **Generate HDL** to generate the system HDL.
6. Click **Processing ► Start Compilation** to perform a full hardware compilation and generate the hardware `.sof` file.

*Note:* Currently, the hardware `.sof` file is not memory-initialized with the  $\mu$ C/TCP-IP application. Refer to the following section for more information.

#### Related Information

- [Quartus Prime Pro Edition User Guide: Platform Designer](#)  
More information about Creating a Board Support Package with BSP Editor.
- [Nios V Processor Software Developer Handbook: Board Support Package Editor](#)

## 5.5.2. Software Development Flow

Creating a  $\mu$ C/TCP-IP and  $\mu$ C/OS-II software image for the Simple Socket Server or the iPerf example design consist of the following general steps:


1. Create a board support package (BSP) project, including  $\mu$ C/OS-II and the  $\mu$ C/TCP-IP software component.
2. Creating a Nios V application project with the provided software design files.
3. Building the application project.
4. Running and debugging the application project.

To ensure a streamlined build flow, you are encouraged to create similar directory tree in your design project. The following software design flow is based on this directory tree.

Follow these steps to create the software project directory tree:

1. In your design project folder, create a folder called `software`.
2. In the `software` folder, create two folders called `app` and `bsp`.

**Figure 176. Software Project Directory Tree**



### 5.5.2.1. Creating a BSP project


Follow these steps to create a BSP project:

1. In the Platform Designer window, go to **File > New BSP**. The **Create New BSP** window appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and create a BSP file (`settings.bsp`).
3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system.

*Note:* For Quartus Prime Standard Edition software, generate the BSP files using SOPCINFO file. Refer to *AN 980: Nios V Processor Intel Quartus Prime Software Support* for more information.

4. For **Quartus project**, select the example design Quartus Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Micrium MicroC/OS II**.
8. Click **Create** to create the BSP file.

Figure 177. Create New BSP windows



### 5.5.2.2. Configuring the BSP

Follow these steps to configure the BSP project:

1. In the BSP Editor, navigate to **Main ► Settings** to configure the BSP Settings as shown in the following table.
2. Both example designs apply the same BSP settings.


Table 46. BSP Editor Settings

BSP Editor Settings	Description
hal.enable_instruction_related_exceptions_api	Enable by checking the option box.
hal.log_flags	Set value as 0
hal.log_port	Set value as sys_jtag_uart
hal.make.cflags_defined_symbols	Set value as -DTSE_MY_SYSTEM -DAL_T_DEBUG
hal.make.cflags_user_flags	Set value as -ffunction-sections -fdata-sections -fno-tree-vectorize
hal.make.cflags_warnings	Set value as -Wall -Wextra -Wformat -Wformat-security
hal.make.link_flags	Set value as -Wl,--gc-sections
ucosii.miscellaneous.os_max_events	Set value as 80
ucosii.os_tmr_en	Enable by checking the option box.

3. Go to **BSP Software Package** tab and enable the uc\_tcp\_ip software package.



Figure 178. BSP Software Package



- Go to **BSP Driver** tab and enable enable\_small\_driver.

Figure 179. BSP Driver Tab



### 5.5.2.3. Creating an Application Project

You need to use the niosv-app utility to create the application CMakeLists.txt and source it to the application source code. Due to different application source code between the two example designs, the niosv-app commands are sourced different.

1. Copy the **Software Design Files** to the software/app folder.
2. Launch the Nios V Command Shell.
3. Based on your example design, execute the following command to generate the user application CMakeLists.txt.

- $\mu$ C/TCP-IP Simple Socket Server example design

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/alt_error_handler.c \
--srcs=software/app/led.c \
--srcs=software/app/main.c \
--srcs=software/app/simple_socket_server.c \
--srcs=software/app/uc_tcp_ip_init.c
```

- $\mu$ C/TCP-IP IPerf example design

```
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/app_iperf.c \
--srcs=software/app/main.c \
--srcs=software/app/uC-IPerf/OS/uCOS-II/iperf_os.c \
--srcs=software/app/uC-IPerf/Reporter/terminal/iperf_rep.c \
--srcs=software/app/uC-IPerf/Source/iperf-c.c \
--srcs=software/app/uC-IPerf/Source/iperf-s.c \
--srcs=software/app/uC-IPerf/Source/iperf.c \
--srcs=software/app/uc_tcp_ip_init.c \
--incs=software/app/uC-IPerf \
--incs=software/app
```

#### 5.5.2.4. Building the Application Project

You can choose to build the application project using RiscFree IDE for Altera FPGAs, or through the command line interface (CLI).

You can configure the source files such as enabling DHCP or setting MAC and IP addresses. Refer to [Optional Configuration](#) for more details.

If you prefer CLI, you can build the application using the following commands:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Release \
-B software/app/build -S software/app
```

```
make -j4 -C software/app/build
```

The user application (.elf) file is created in software/app/build folder.

#### 5.5.3. Device Programming

To program Nios V processor based system into the FPGA and to run your application, use Quartus Prime Programmer tool.

1. To create the Nios V processor inside the FPGA device, program the .sof file onto the board with the following command.

**Table 47. Command**

Operating System	Command
Windows	quartus_pgm -c 1 -m JTAG -o p;top.sof@1
continued...	

Operating System	Command
Linux	<code>quartus_pgm -c 1 -m JTAG -o p\;top.sof@1</code>

*Note:*

- -c 1 is referring to cable number connected to the Host Computer.
- @1 is referring to device index on the JTAG Chain and may differ for your board.

2. Download the .elf using the `niosv-download` command.

```
niosv-download -g -r <elf file>
```

3. Use the JTAG UART terminal to print the stdout and stderr of the Nios V processor system.

```
juart-terminal
```

## 5.6. Operating the Example Designs

### 5.6.1. Operating the MicroC/TCP-IP IPerf

To display the  $\mu$ C/TCP-IP IPerf application messages, the example design utilizes the JTAG UART Intel FPGA IP. You can begin the display message by using the following command:

```
juart-terminal
```

The JTAG UART terminal displays the booting message logs, followed by the  $\mu$ C/TCP-IP setup logs from the  $\mu$ C/TCP-IP IPerf example design.

Within the  $\mu$ C/TCP-IP setup logs, there is a message stating the current IP address adopted by the system (as configured in `main.c` source code). If DHCP is enabled, the DHCP server-supplied IP address displays the message that indicates the DHCP client for the Ethernet interface acquires a DHCP IP address.

The message "TEST ID : <test number>" is displayed along with its IP address and other information, when the  $\mu$ C/TCP-IP IPerf server is initialized and ready for connection.

After the iPerf server is ready, you can start an iPerf client on your host computer to interact with the iPerf server. To start the iPerf client, follow these steps:

1. From your operating system, open a command shell or a terminal.  
*Note:* On Windows, you can also use **Run** on the Start menu.
2. Type the following command, specifying either the static IP address or the DHCP server-provided IP address:

```
iperf -c <IP Address>
```

If the connection to the development board is successful, the iPerf test result displays in both the iPerf server and client.

In the following examples, the configured IP address for the iPerf server is 192.168.1.45 at port 5001.

Figure 180. iPerf Server on Intel FPGA device

```

liangyu@ppgy01009: ~$ cd /vagrant; ./iperv1000c iperv1000c
uart-terminal: connected to hardware target using FTDI USB on cable
uart-terminal: "USB-GSLasterII on 10.228.218.235 (USB-2)", device 1, instance 0
uart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

[rt0.0] Calling alt_main.
alt_main.c: Entering alt_main, calling alt_irq_init.
alt_main.c: Done alt_irq_init, calling alt_mn_init.
alt_main.c: Done mn_init, calling alt_ssm_create.
alt_main.c: Calling alt_ssm_init.
alt_main.c: Done alt_ssm_init.
alt_main.c: Redirecting IO.
alt_main.c: Calling C++ constructors.
alt_main.c: Calling atexit.
alt_main.c: Calling main.
main: Main Task T00: 0x040c
[alt_main_task]

[alt_main_task] =====
[alt_main_task] uc/TCP-IP Setup
[alt_main_task] =====
[alt_main_task] TSE MAC base: 0x012000
[alt_main_task] Rx dev name: /dev/vqs,tx,rxq004,rx,txp.
[alt_main_task] Tx dev name: /dev/vqs,tx,rxq004,tx,txp.
[alt_main_task] [INFO] Initializing network stack.
Configuring interface IP address:
* address: 192.168.1.1
* Mask: 255.255.255.0
* Gateway: 192.168.1.1
[alt_main_task] [INFO] Initializing network stack: Success. Using interface 1.

IPerv Terminal.

TEST ID : 1
=====
TCP Server listening on 192.168.1.1 Port 5001
Window size: 6000 bytes
Buffer size: 64K bytes

Local 192.168.1.1 Port 5001 connected with 192.168.1.2 Port 61571
[ 0] [ 0] [ 0] 0.000 - 1.060 sec : 1754352 Bytes, 13214 Kbits/sec
[ 0] [ 0] [ 0] 1.060 - 2.060 sec : 1729152 Bytes, 13179 Kbits/sec
[ 0] [ 0] [ 0] 2.060 - 3.060 sec : 1682528 Bytes, 13419 Kbits/sec
[ 0] [ 0] [ 0] 3.060 - 4.070 sec : 1679912 Bytes, 13390 Kbits/sec
[ 0] [ 0] [ 0] 4.070 - 5.075 sec : 1659368 Bytes, 13405 Kbits/sec
[ 0] [ 0] [ 0] 5.075 - 6.070 sec : 1693032 Bytes, 13513 Kbits/sec
[ 0] [ 0] [ 0] 6.070 - 7.062 sec : 1660912 Bytes, 13234 Kbits/sec
[ 0] [ 0] [ 0] 7.062 - 8.065 sec : 1662528 Bytes, 13419 Kbits/sec
[ 0] [ 0] [ 0] 8.065 - 9.060 sec : 1666752 Bytes, 13090 Kbits/sec
[ 0] [ 0] [ 0] 9.060 - 10.062 sec : 1670648 Bytes, 13335 Kbits/sec
===== RESULT =====
Bytes received : 17076480
Duration (sec) : 10.174
Socket Call count : 8426
Transitory error count : 0
CPU Usage Max : 0 %
CPU Usage Average : 0 %
Average speed : 13308 Kbits/sec
=====

```

Figure 181. iPerf Client on Host Computer

```

Command Prompt

C:\liangyu>iperf-2.1.5-win.exe -c 192.168.1.8

Client connecting to 192.168.1.8, TCP port 5001
TCP window size: 64.0 KByte (default)

[ 1] local 192.168.1.2 port 61571 connected with 192.168.1.8 port 5001
[ ID] Interval      Transfer      Bandwidth
[ 1] 0.00-10.17 sec  16.3 MBytes  13.4 Mbits/sec

```

## Related Information

[IPerv Homepage](#)

## 5.6.2. Operating the MicroC/TCP-IP Simple Socket Server

To display the  $\mu$ C/TCP-IP Simple Socket Server application messages, the example design utilizes the JTAG UART Intel FPGA IP. You can begin the display message by using the following command:

```
juart-terminal
```

The JTAG UART terminal displays the booting message logs, followed by the  $\mu$ C/TCP-IP setup logs from the  $\mu$ C/TCP-IP Simple Socket Server example design.

Within the  $\mu$ C/TCP-IP setup logs, find a message stating the system adopts the current IP address (as configured in `main.c` source code). If DHCP is enabled, the DHCP server-supplied IP address displays the message that indicates the DHCP client for the Ethernet interface acquires a DHCP IP address.

The message "[sss\_task] Simple Socket Server listening on port <port number>" is displayed when the  $\mu$ C/TCP-IP Stack is ready for connection.

After the  $\mu$ C/TCP-IP Stack is ready, you can start a telnet session to interact with the stack. To start a telnet session, follow these steps:

1. From your operating system, open a command shell or a terminal.  
*Note:* On Windows, you can also use **Run** on the Start menu.
2. Type the following command, specifying either the static IP address or the DHCP server-provided IP address:

```
telnet <IP Address> <Port>
```

If the connection to the development board is successful, the menu of available commands display in a command window.

[Telnet Session to Intel FPGA Device](#) Figure shows the Nios V Simple Socket Server Menu, along with the following entered commands:

- **0 to 3:** Toggle board LEDs D0 to D3
- **S:** Board LED Light Show
- **Q:** Terminate Session

When you enter commands at the command prompt, Ethernet sends the commands over the telnet connection to a task waiting on a socket for commands. The task responds to those commands by sending instructions to another task that manipulates the LED.

In the following examples, the configured IP address for the Simple Socket Server is 192.168.1.45 at port 80.

Figure 182. Display Message from Altera FPGA device (Disable DHCP)

```

[aregnyug@pglc00073... tcp_ip/a10soc_sss <@pglc00073>
juart-terminal: connected to hardware target using JTAG UART on cable
juart-terminal: "USB-BlastertII on 10.228.218.201 [USB-3]", device 1, instance 0
juart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

[crt0.S] Calling alt_main.
[alt_main.c] Entering alt_main, calling alt_irq_init.
[alt_main.c] Done alt_irq_init, calling alt_os_init.
[alt_main.c] Done OS Init, calling alt_www_create.
[alt_main.c] Calling alt_sys_init.
[alt_main.c] Done alt_sys_init.
[alt_main.c] Redirecting ID.
[alt_main.c] Calling C++ constructors.
[alt_main.c] Calling atexit.
[alt_main.c] Calling main.
[main] Main Task TOS: 0x4aa84

[uc_main_task]
[uc_main_task] =====
[uc_main_task] uC/TCP-IP Setup
[uc_main_task] =====
[uc_main_task] TSE MAC base: 0x212000.
[uc_main_task] Rx cer name: /dev/sys_tse_wsgdma_rx_cer.
[uc_main_task] Tx cer name: /dev/sys_tse_wsgdma_tx_cer.
[uc_main_task] IHFO: Initializing network stack.
[conf_static] Configuring (static) IP address
[conf_static] * Address: 192.168.1.45
[conf_static] * Mask: 255.255.255.0
[conf_static] * Gateway: 192.168.1.1
[uc_main_task] IHFO: Initializing network stack: Success. Using interface 1.
[sss_task] Simple Socket Server listening on port 80
[sss_handle_accept] accepted connection request from 192.168.1.10
[sss_handle_receive] processing RX data
Value for LED_PIO_BASE set to 14.
Value for LED_PIO_BASE set to 12.
Value for LED_PIO_BASE set to 8.
Value for LED_PIO_BASE set to 15.
[sss_handle_receive] closing connection

```

**Figure 183. Display Message from Altera FPGA device (Enable DHCP)**


```

uart-terminal: connected to hardware target using JTAG UART on cable
uart-terminal: "USB-BlasterII on 10.244.228.156 [3-1.3]", device 1, instance 0
uart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

[crt0.S] Calling alt_main.
[alt_main.c] Entering alt_main, calling alt_irq_init.
[alt_main.c] Done alt_irq_init, calling alt_os_init.
[alt_main.c] Done OS Init, calling alt_sem_create.
[alt_main.c] Calling alt_sys_init.
[alt_main.c] Done alt_sys_init.
[alt_main.c] Redirecting IO.
[alt_main.c] Calling C++ constructors.
[alt_main.c] Calling atexit.
[alt_main.c] Calling main.
[main] Main Task TOS: 0x4d75c
Print the value of System ID
System ID from Peripheral core is 0xFACECAFE
[uc_main_task]
[uc_main_task] =====
[uc_main_task]                        uC/TCP-IP Setup
[uc_main_task] =====
[uc_main_task] TSE MAC base: 0x212000.
[uc_main_task] Rx csr name: /dev/sys_tse_msgdma_rx_csr.
[uc_main_task] Tx csr name: /dev/sys_tse_msgdma_tx_csr.
[uc_main_task] INFO: Initializing network stack.
[AppDHCPc_Init] Configuring DHCPc.
.....
[AppDHCPc_Init] Done configuring DHCPc.
[conf_dhcp] DHCP info
[conf_dhcp] * Address: 10.244.228.54.
[conf_dhcp] * DNS:      0.5.18.152.
[uc_main_task] INFO: Initializing network stack: Success. Using interface 1.
[sss_task] Simple Socket Server listening on port 80
[sss_handle_accept] accepted connection request from 10.244.73.178
[sss_handle_receive] processing RX data
Value for LED_PIO_BASE set to 1.
Value for LED_PIO_BASE set to 12.
Value for LED_PIO_BASE set to 8.
Value for LED_PIO_BASE set to 0.
[sss_handle_receive] closing connection

```

### Figure 184. Telnet Session to Intel FPGA Device





## 5.7. Optional Configuration

The default configuration of the two  $\mu$ C/TCP-IP example designs is open for modifications. The configuration is only meant to fulfill the basic requirements to build a working  $\mu$ C/TCP-IP Simple Socket Server and iPerf design. This section introduces some of the common configuration that you can apply on your own designs.

### 5.7.1. Configuring Hardware Name

The global structure of type "alt\_tse\_system\_info" (named "tse\_mac\_device") reflects the IP names according to the `system.h` file. If you change the default IP names or not using the default hardware project, you must update the following names in `main.c` source code. You can find the source code in the `software/apps` folder.

The latest IP names can be found in the `system.h` file after the hardware compilation in Quartus Prime software. The header file is located in the BSP folder.

The following table lists the example design and the default IP names.

**Table 48. Default IP Names**

Example Design	IP Name
TSE	SYS_TSE
TX MSGDMA	SYS_TSE_MSGDMA_TX
RX MSGDMA	SYS_TSE_MSGDMA_RX
Descriptor Memory	SYS_DESC_MEM

**Figure 185. Example Design Platform Designer System**

Name	Description
sys_clk_bridge	Clock Bridge Intel FPGA IP
sys_125m_clk_bridge	Clock Bridge Intel FPGA IP
sys_rst_bridge	Reset Bridge Intel FPGA IP
sys_ispl	ISPLL Intel FPGA IP
sys_cpu	Nios Vm Processor Intel FPGA IP
sys_cpu_ram	On-Chip Memory [2] (RAM or ROM) Intel FPGA IP
sys_jtag_uart	JTAG UART Intel FPGA IP
sys_sysid	System ID Peripheral Intel FPGA IP
sys_led_pio	PIO (Parallel I/O) Intel FPGA IP
sys_desc_mem	On-Chip Memory [2] (RAM or ROM) Intel FPGA IP
sys_tse_msgdma_rx	Modular Scatter-Gather DMA Intel FPGA IP
sys_tse_msgdma_tx	Modular Scatter-Gather DMA Intel FPGA IP
sys_tse	Triple-Speed Ethernet Intel FPGA IP
sys_sscr_ata_pll	Transceiver ATX PLL Intel Arria 10/Cyclone 10 F...

**Example 2. Default Hardware Names in main.c**

```
alt_tse_system_info tse_mac_device[MAXNETS] = {
    TSE_SYSTEM_EXT_MEM_NO_SHARED_FIFO(
        SYS_TSE,           // tse_name
        0,                 // offset
        SYS_TSE_MSGDMA_TX, // msgdma_tx_name
        SYS_TSE_MSGDMA_RX, // msgdma_rx_name
        TSE_PHY_AUTO_ADDRESS, // phy_addr
        NULL,              // phy_cfg_fp
        SYS_DESC_MEM       // desc_mem_name
    )
};
```



### 5.7.2. Configuring MAC and IP Addresses

You can configure the MAC and IP addresses of the  $\mu$ C/TCP-IP module by editing the `struct network_conf conf` in `software/app/main.c` source code.

If a DHCP server is available on your network, enable the DHCP feature by modifying the `use_dhcp` field to `true` (`DEF_TRUE`). If the DHCP feature is enabled, the provided IP addresses, network mask, and gateway are left unused. It is not required to clear their contents.

If the development board is connected directly to your PC with a crossover Ethernet cable, or no DHCP server is available, disable the DHCP feature (`!DEF_TRUE`) and specify the IP addresses, network mask, and gateway.

#### Example 3. Default "struct network\_conf conf" in main.c

```
struct network_conf conf = {
    .tse_sys_info = tse_sys_info,
    .mac_addr = "00:07:ed:ff:8c:05",
    .use_dhcp = !DEF_TRUE,
    .ipv4_addr_str = "192.168.1.45",
    .ipv4_mask_str = "255.255.255.0",
    .ipv4_gateway_str = "192.168.1.1"
};
```

**Note:**

- Choose your default IP and gateway addresses carefully. Some secure router configurations block DHCP request packets on local subnetworks such as the 192.168.X.X subnetwork. If you encounter problems, try using 0.0.0.0 as your default IP and gateway addresses.
- You can configure the DHCP waiting time (`DHCP_WAIT_MS`) in the `uc_tcp_ip_init.c` source code. The DHCP waiting time is the amount of time delayed before verifying that a valid IP address is acquired by the TSE IP.

### 5.7.3. Configuring MicroC/TCP-IP Initialization

You can configure the  $\mu$ C/TCP-IP application specific settings according to your preference. These settings are configurable in `software/app/uc_tcp_ip_init.c` source code.

#### 5.7.3.1. Network Task Configuration

In this example design, the  $\mu$ C/TCP-IP stack has three configurable tasks, the Receive task, the Transmit De-allocation task and the Timer task. Each task is configured with its own task priority and task stack size.

In order to place a task at higher priority, you have to register it with a lower value, and vice versa. The third-party vendor recommends configuring the task priorities as listed below for optimum performance.

- Network Transmit (TX) De-allocation task (Highest priority)
- Network timer task
- Network Receive (RX) task (Lowest Priority)

As for the task stack size, it is dependent on the processor architecture and compiler used. Configuring the stack size to 4,096 bytes is deemed sufficient for most applications.

**Table 49. Network task configuration**

Settings	Description	Default Value
TX_TASK_PRIO	Network TX De-allocation Task Priority	1u
RX_TASK_PRIO	Network RX Task Priority	3u
TMR_TASK_PRIO	Network Timer Task Priority	5u
TX_TASK_SIZE	Network TX De-allocation Task Stack Size	4096u
RX_TASK_SIZE	Network RX Task Stack Size	4096u
TMR_TASK_SIZE	Network Timer Task Stack Size	4096u

**Example 4. Default network task configuration in uc\_tcp\_ip\_init.c**

```
#define TX_TASK_SIZE (4096u)
#define RX_TASK_SIZE (4096u)
#define TMR_TASK_SIZE (4096u)

static const unsigned TX_TASK_PRIO = 1u;
static const unsigned RX_TASK_PRIO = 3u;
static const unsigned TMR_TASK_PRIO = 5u;
```

### 5.7.3.2. Network Interface Configuration

μC/TCP-IP stores received and transmitted data in network buffers (also referred as receive buffers and transmit buffers). The size of these network buffers should fulfill the minimum and maximum packet frame sizes of the network interfaces.

Based on the μC/TCP-IP application requirements, configure the network buffers to better suit your needs in `software/app/uc_tcp_ip_init.c` source code. The following are the configurable network buffers:

- Receive Large Buffer
- Transmit Large Buffer
- Transmit Small Buffer

While it is best to leave the size of large buffers at maximum frame size, you can lower the size of the small buffers to reduce the system's RAM usage, further improving the system performance. Additionally, you can configure the number of receive and transmit buffers allocated to the device. Keep in mind that you need to have at least one buffer given for each network.

After configuring the network buffers, register them to a valid memory locations, either the main system memory or a dedicated descriptor memory. If you are using a dedicated descriptor memory, define the starting address and memory span of the descriptor memory in the source code.

Refer to [Network Buffers Configuration](#) Table for the μC/TCP-IP example designs default configuration. A dedicated descriptor memory is provided in the hardware system, and registered to the receive buffers. Transmit buffers are routed to the main memory.

**Note:** Altera recommends receive buffers to hold up to the maximum frame size because the size of data received is unknown to the device. Alternatively, the size of data transmitted is known to the device, making it possible to use small transmit buffers when the transmitted data is smaller than the maximum frame size. Thus, allowing receive buffers to use large buffers only, while transmit buffers use both large and small buffers.

**Table 50. Network Buffers Configuration**

Settings	Description	Default Value
.RxBufPoolType	Memory location for the receive data buffers. <sup>(7)(8)</sup>	NET_IF_MEM_TYPE_DEDICATED
.RxBufLargeNbr	Number of receive buffers allocated to the device.	NUM_RX_BUFFERS <sup>(9)</sup>
.TxBufPoolType	Memory location for the transmit data buffers. <sup>(7)(8)</sup>	NET_IF_MEM_TYPE_MAIN
.TxBufLargeNbr	Number of transmit buffers allocated to the device.	5u
.TxBufSmallSize	Size of the small transmit buffers.	60u
.TxBufSmallNbr	Number of small transmit buffers allocated to the device.	5u
.MemAddr	Starting address of the dedicated descriptor memory. <sup>(10)</sup>	SYS_DESC_MEM_BASE
.MemSize	Size of the dedicated descriptor memory (in bytes).	SYS_DESC_MEM_SPAN

**Example 5. Default network interface configuration in uc\_tcp\_ip\_init.c**

```
static const CPU_INT08U NUM_RX_LISTS = 2;
static const NET_BUF_QTY NUM_RX_BUFFERS =
    2 * NUM_RX_LISTS * ALTERA_TSE_MSGDMA_RX_DESC_CHAIN_SIZE;

static NET_DEV_CFG_ETHER NetDev_Cfg_Ether_TSE = {

    .RxBufPoolType      = NET_IF_MEM_TYPE_DEDICATED,
    .RxBufLargeSize     = 1536u,
    .RxBufLargeNbr      = NUM_RX_BUFFERS,
    .RxBufAlignOctets   = 4u,
    .RxBufIxOffset      = 2u,

    .TxBufPoolType      = NET_IF_MEM_TYPE_MAIN,
    .TxBufLargeSize     = 1518u,
    .TxBufLargeNbr      = 5u,
    .TxBufSmallSize     = 60u,
    .TxBufSmallNbr      = 5u,
    .TxBufAlignOctets   = 4u,
    .TxBufIxOffset      = 0u,

    .MemAddr            = SYS_DESC_MEM_BASE,
    .MemSize             = SYS_DESC_MEM_SPAN,

    .Flags              = NET_DEV_CFG_FLAG_NONE,
```

<sup>(7)</sup> This field must be set to either NET\_IF\_MEM\_TYPE\_MAIN for main memory or NET\_IF\_MEM\_TYPE\_DEDICATED for dedicated descriptor memory.

<sup>(8)</sup> Only one buffer type (receive or transmit buffers) can be set to NET\_IF\_MEM\_TYPE\_DEDICATED.

<sup>(9)</sup> This field is derived based on NUM\_RX\_LISTS and ALTERA\_TSE\_MSGDMA\_RX\_DESC\_CHAIN\_SIZE.

<sup>(10)</sup> If there is no dedicated descriptor memory in the system, this field should be set to NULL

```
.RxDescNbr = 8u, // NOTE: Not configurable.
.TxDescNbr = 1u, // NOTE: Not configurable.

.BaseAddr          = 0,
.DataBusSizeNbrBits = 0,

.HW_AddrStr = "",
};
```

### 5.7.4. Configuring iPerf Server Auto-Initialization

**Note:** This configuration is only available for  $\mu$ C/TCP-IP iPerf Example Design.

The example design is capable of initializing the iPerf server using pre-determined arguments upon running the Nios V applications. This is developed for ease of use purpose, and it can be disabled if other iPerf utility is required.

To disable this feature, you need to provide the **0** argument to the `App_IPerf_TaskTerminal()`, and the iPerf terminal begins acquiring the custom `iperf` commands after iPerf is successfully initialized. The `iperf` command must end with an ENTER key to complete the acquisition process.

**Figure 186. iPerf Terminal**

```
llangyug@pgk00472...esigva10soc.iperf<@pgk00472>
Juart-terminal: connected to hardware target using JTAG UART on cable
Juart-terminal: "USB-BlasterII on 10.226.218.201 [USB-2]", device 1, instance 0
Juart-terminal: (Use the IDE stop button or Ctrl-C to terminate)

[crt0.S] Calling alt_main.
[alt_main.c] Entering alt_main, calling alt_irq_init.
[alt_main.c] Done alt_irq_init, calling alt_os_init.
[alt_main.c] Done OS Init, calling alt_ssm_create.
[alt_main.c] Calling alt_sys_init.
[alt_main.c] Done alt_sys_init.
[alt_main.c] Redirecting IO.
[alt_main.c] Calling C++ constructors.
[alt_main.c] Calling atexit.
[alt_main.c] Calling main.
[main] Main Task TGS: 0x5c40c
[uc_main_task]

[uc_main_task] =====
[uc_main_task] uC/TCP-IP Setup
[uc_main_task] =====
[uc_main_task] TSE MAC base: 0x212000.
[uc_main_task] Rx csr name: /dev/sys_tse_magdma_rx_csr.
[uc_main_task] Tx csr name: /dev/sys_tse_magdma_tx_csr.
[uc_main_task] INFO: Initializing network stack.
[uc_main_task] Configuring (static) IP address
* Address: 192.168.1.8
* Mask: 255.255.255.0
* Gateway: 192.168.1.1
[uc_main_task] INFO: Initializing network stack: Success. Using interface 1.

iPerf Terminal:

> iperf -s

=====
TEST ID : 1
=====
TCP Server listening on 192.168.1.8 Port 5001
Window size: 4096 bytes
Buffer size: 8192 bytes
=====
```

#### Example 6. iPerf server auto-initialization feature in main.c

```
//To enable auto-initialization
App_IPerf_TaskTerminal( 1 );

//To disable auto-initialization
App_IPerf_TaskTerminal( 0 );
```

## 5.8. MicroC/TCP-IP Simple Socket Server Concepts

### 5.8.1. MicroC/OS-II Resources

This section describes the tasks, queue, event flag, and semaphores that implement the  $\mu$ C/TCP-IP Simple Socket Server application.

#### Tasks

The following table lists the  $\mu$ C/OS-II tasks that implements the  $\mu$ C/TCP-IP Simple Socket Server application.

**Table 51.  $\mu$ C/OS-II tasks for the  $\mu$ C/TCP-IP Simple Socket Server**

Tasks	Description
SSSCreateOSDataStructs()	Creates an instance of all the $\mu$ C/OS-II resources.
SSSCreateTasks()	Initializes tasks that do not use the networking services.
SSSSimpleSocketServerTask()	Manages the socket server connection, and calls relevant subroutines to manage the socket connection.
LEDManagementTask()	Manages the LEDs, driven by commands received from a $\mu$ C/OS-II queue, named SSSLEDCommandQ.
LEDLightshowTask()	Manages the LED light show, once enabled by the LEDManagementTask().

#### Inter-Task Communication Resources

The following global handles (or pointers) create and manipulate your  $\mu$ C/OS-II inter-task communication resources. All the resources begin with Simple Socket Server, indicating a public resource provided by the Nios V Simple Socket Server that is shared between software modules.

The SSSCreateOSDataStructs() function declares and creates these resources in simple\_socket\_server.c.

- **SSSLEDCommandQ:** A  $\mu$ C/OS-II queue that sends commands from the simple socket server task, SSSSimpleSocketServerTask() to the development board LED control task, LEDManagementTask().
- **SSSLEDLightshowSem:** A  $\mu$ C/OS-II semaphore that is referred by the LEDLightshowTask() before the LEDs update.
- **SSSLEDEventFlag:** A  $\mu$ C/OS-II flag that corresponds to one of the LEDs.

**Note:** The  $\mu$ C/TCP-IP Simple Socket Server uses capitalized acronym prefixes to identify public resources for each software module, and lowercase letters with underscores to indicate a private resource or function used internally to a software module.

The following are the software module acronym identifiers:

- **SSS**:  $\mu$ C/TCP-IP Simple Socket Server software module
- **LED**: LED management software module
- **OS**:  $\mu$ C/OS-II RTOS software component

### 5.8.2. Error Handling

A suite of error-handling functions defined in `alt_error_handler()` check error handling of the  $\mu$ C/TCP-IP Simple Socket Server application,  $\mu$ C/TCP-IP Stack, and  $\mu$ C/OS-II system call error-codes. All system, socket, and application calls check for error conditions whenever an error exist.

### 5.8.3. MicroC/TCP-IP Stack Default Configuration

The  $\mu$ C/TCP-IP Stack creates one or more system level tasks during system initialization, when you call the `network_init()` function. Users have complete control over these system level tasks through a global configuration file named `net_cfg.h`, located in the directory structure for the BSP project, in the **uC-TCP-IP/uC-Conf** folder.

You can edit the `#define` statements in `net_cfg.h` to configure the following options for the  $\mu$ C/TCP-IP Stack:

- **Module Inclusion**: Identifies which built-in  $\mu$ C/TCP-IP modules should be started.
- **Module Configuration**: Configure how built-in  $\mu$ C/TCP-IP modules should be started.

#### Related Information

[uC/TCP-IP Documentation](#)

For more information about the  $\mu$ C/TCP-IP Stack configuration.

## 6. Nios V Processor Debugging, Verifying, and Simulating

Debugging and verifying an embedded system involves hardware and software components. To successfully debug an embedded system requires expertise in both hardware and software. This chapter helps you understand several tools and techniques that are useful in debugging, verifying, and bring up the embedded system.

### 6.1. Debugging Nios V/c Processor

Nios V/c processor implements the compact architecture to achieve a smaller logic size by applying the following trait:

- Non-pipelined datapath
- No debug module
- No processor CSR
- No interrupts and exceptions
- No internal timer module

The Nios V/c processor core is limited to hardware debugging without the debug module. Software debugging is not applicable for the Nios V/c processor core.

#### 6.1.1. Pilot System with Non-pipelined Nios V/m Processor

Altera recommends to use the non-pipelined Nios V/m processor to allow full debugging capabilities. The architecture performance of a non-pipelined Nios V/m processor is similar to the Nios V/c processor, at the expense of bigger logic size.

**Table 52. Nios V/c and Nios V/m Processor Core**

Feature	Nios V/c Processor	Non-pipelined Nios V/m Processor
Debug Module	—	Supported
Processor CSR	—	Supported
Interrupt and Exceptions	—	Supported
Logic Size (ALM) <sup>(11)</sup>	x1	x1.5
DMIPS/Mhz Performance <sup>(11)</sup>	x1	x1
CoreMark/MHz Performance <sup>(11)</sup>	x1	x1
Internal Timer	—	Supported

You can utilize Nios V/m processor as a pilot system to debug Nios V/c processor:


<sup>(11)</sup> Relative to the Nios V/c processor.




1. Start the processor system using non-pipelined Nios V/m processor.
  - a. Turn on **Enable Debug**
  - b. Turn off **Enable Pipelining in CPU**
2. Develop the Nios V processor software application in baremetal (Altera HAL).
3. Ensure there is no interrupt or exception in the Nios V/m processor system. Do not connect to the **Interrupt Receiver** on the processor.

*Note:* To implement a JTAG UART Altera FPGA IP without interrupt, you can enable the **small JTAG UART driver** in the BSP Editor to apply polled operation. Ensure that the compile definition (ALTERA\_AVALON\_JTAG\_UART\_SMALL) is found in the `toolchain.cmake`.

**Figure 187. Nios V/m Processor System with No Interrupt**



**Figure 188. Enable Small JTAG UART Driver in BSP Editor**




4. Develop the Nios V processor software application in baremetal (Altera HAL).



5. Program the design SOF file onto the Altera FPGA device.
6. Download the application ELF file into the Nios V processor system.
7. Perform design verification and debugging with the Nios V/m processor core.
8. Verify that the Nios V/m processor is working successfully, then replace the Nios V/m processor with Nios V/c processor.
  - a. Right-click the Nios V/m processor, click **Replace** ➤ **Nios V/c Processor Intel FPGA IP**.
  - b. Reconfigure the same assignment in the **IP Parameter Editor**.
  - c. Address any possible errors.
  - d. Click **Sync System Infos**.

Figure 189. Nios V/c Processor Replacement



9. Implement booting Nios V/c processor from On-Chip Memory.
10. Recreate the application BSP, APP, and ELF.
11. Program the memory-initialized design SOF file onto the Altera FPGA device.
12. Power cycle the Altera FPGA device.

### Related Information

[Nios® V Processor Software Developer Handbook: Use Small Variant Device Drivers](#)

## 6.1.2. printf() Debugging

An alternative to the debug module is debugging using a `printf()` statement. You can augment the targeted application with extra debug log messages printed through `printf()`.

You can develop the debug log messages up to your preference. The key objective is to print as much information as possible.

Examples of the debug log message:

- What is the running process, its inputs, and outputs?
- When was the exact time the process ran?
- Where is the information stored and acquired?
- How is the software progressing?

You can instantiate a JTAG UART or regular UART in a Nios V/c processor system to output character streams and read in character streams.

## 6.2. Debugging Nios V Processor Hardware Designs

### 6.2.1. JTAG Server

A JTAG Server communicates with the hardware and allows multiple programs to use JTAG resources concurrently. You can display the connected devices' JTAG scan chain to validate the Nios V processor's presence in the Altera FPGA.

From the Nios V Command Shell, the `jtagconfig -d` command identifies available JTAG devices and the number of CPUs in the subsystem connected to each JTAG device. The example below shows the system response to a `jtagconfig -d` command.

#### Example 7. System Response to JTAG Server

```
$ jtagconfig -d
1) AGF FPGA Development Kit on Intel® FPGA Download Cable [USB-0]
   (JTAG Server Version 22.1.0 Build 174 03/30/2022 SC Pro Edition)
C341A0DD  AGFB014R24A(.|R1|R2)/.. (IR=10)
Design hash 74DFB795DF11A555CEDF
+ Node 00486E00 Source/Probe #0
+ Node 08986E00 Nios V #0
+ Node 0C006E00 JTAG UART #0
031830DD  10M16S(A|C|L) (IR=10)

Captured DR after reset = (30D068376063061BB020D10DD) [98]
Captured IR after reset = (006AAD55) [32]
Captured Bypass after reset = (0A) [5]
Captured Bypass chain = (00) [5]
JTAG clock speed auto-adjustment is enabled. To disable, set
JtagClockAutoAdjust parameter to 0
JTAG clock speed 24 MHz
```

The response in the example lists one FPGA connected to the running JTAG server through Altera FPGA Download Cable. The cable attached to the USB-0 port is connected to a JTAG node in a Platform Designer subsystem with a single Nios V processor core.

The node numbers represent JTAG nodes inside the FPGA.

- The appearance of node number 0x08986Exx confirms that the FPGA implementation has a Nios V processor with a JTAG debug module. The CPU instances are identified by the least significant byte of the nodes after 0x08986E.
- The appearance of node number 0x0C006Exx confirms that the FPGA implementation has a JTAG UART component. The JTAG UART instances are identified by the least significant byte of the nodes after 0x0C006E.


All instance IDs begin with 0. Only the CPUs that have debug enabled appear in the listing. Use this listing to confirm that you have debug enabled for the Nios V processors you intended.

### 6.2.2. System Console

You can use the System Console to perform low-level debugging of a Platform Designer system. Use the command line mode to access the System Console functionality. You can either work interactively or run a Tcl script. The System Console prints responses to your commands in the terminal window.

You can include the JTAG to Avalon Host Bridge Core to debug with the System Console. It allows the System Console to send and receive data from the running Platform Designer system through the System Level Debug (SLD) hub. Refer to *Debug Tools - Analyzing and Debugging Designs with System Console* for more information

**Figure 190. Connections to System Console**



#### Related Information

[Quartus® Prime Pro Edition User Guide: Debug Tools](#)

Refer to the topic *Analyzing and Debugging Designs with System Console* for more information.

#### 6.2.2.1. JTAG to Avalon Host Bridge Core

The JTAG to Avalon Host Bridge cores provide a connection between System Console and Platform Designer systems via the JTAG interfaces. System Console can initiate Avalon Memory-Mapped (Avalon-MM) transactions by sending encoded streams of bytes via the core. The core support reads and writes, but not burst transactions.

The debugging process is as follows:

1. Starting System Console
2. Locating available services
3. Opening a service
4. Applying Tcl commands
5. Closing a service

The example below demonstrates a Tcl script to access the device registers of *Generic Serial Flash Interface Altera FPGA IP* using System Console.

### Example 8. Sample .tcl script

```
#set GSFI IP CSR base address according to Platform Designer system
set base 0x8000000

#set GSFI IP register map
set control_register [expr {$base + 0x0}]
set spi_clock_baud_rate_register [expr {$base + 0x4}]
set cs_delay_setting_register [expr {$base + 0x8}]
set read_capturing_register [expr {$base + 0xc}]
set operating_protocols_setting [expr {$base + 0x10}]
set read_instr [expr {$base + 0x14}]
set write_instr [expr {$base + 0x18}]
set flash_cmd_setting [expr {$base + 0x1c}]
set flash_cmd_ctrl [expr {$base + 0x20}]
set flash_cmd_addr_register [expr {$base + 0x24}]
set flash_cmd_write_data_0 [expr {$base + 0x28}]
set flash_cmd_write_data_1 [expr {$base + 0x2c}]
set flash_cmd_read_data_0 [expr {$base + 0x30}]
set flash_cmd_read_data_1 [expr {$base + 0x34}]

#locate and open JTAG to Avalon Master Bridge service
set mp [claim_service master [lindex [get_service_paths master] 0] top]

#print the value of Control Register
set reg [master_read_32 $mp $control_register 0x1]
puts "Control Register : $reg"

#modify the value of Control Register's Enable bit field
#to disable the GSFI IP
set reg2 [expr {$reg & 0xfffffffffe}]
master_write_32 $mp $control_register $reg2

#close JTAG to Avalon Master Bridge service
close_service master $mp
```

### Related Information

- [Debug Tools - Analyzing and Debugging Designs with System Console: Starting System Console](#)
- [Debug Tools - Analyzing and Debugging Designs with System Console: Locating Available Services](#)
- [Debug Tools - Analyzing and Debugging Designs with System Console: Opening and Closing Services](#)
- [System Console and Toolkit Tcl Command Reference Manual](#)
- [Generic Serial Flash Interface Altera FPGA IP User Guide](#)

### 6.2.3. Signal Tap Logic Analyzer

The Signal Tap logic analyzer, available in the Quartus Prime software, captures and displays the real-time signal behaviour in an Altera FPGA design. Use the Signal Tap logic analyzer to probe and debug the behaviour of internal signals during normal device operation, without requiring extra I/O pins or external lab equipment.

The Signal Tap logic analyzer can aid the Nios V processor debugging by catching software-related problems, such as an interrupt service routine that does not clear the interrupt signal properly.

The Signal Tap logic analyzer enables user to trigger on and capture instruction trace data that the Nios V processor core executes. You can specify an instruction-trace trigger, which triggers the Signal Tap logic analyzer when the processor reaches a specific address, specific instruction word, or specify your own Signal Tap trigger conditions.

#### Related Information

- [Design Debugging with the Signal Tap Logic Analyzer](#)  
For more information about the Signal Tap logic analyzer.
- [Design Debugging with the Signal Tap Logic Analyzer](#)

#### 6.2.3.1. Hardware and Software Requirements

Use the following hardware and software to begin debugging the Nios V processor system with Signal Tap logic analyzer:

- Hardware requirements:
  - Any Altera FPGA development kit
  - Power Adaptor
  - Altera FPGA Download Cable II
- Software requirements:
  - Quartus Prime Pro Edition software version 21.3 or later
  - Quartus Prime Standard Edition software version 22.1 or later
  - Ashling RiscFree IDE for Altera FPGAs

You must be familiar with the basic use of Signal Tap logic analyzer, Quartus Prime software, Platform Designer development, and Ashling RiscFree IDE for Altera FPGAs. You can implement this debugging approach on your existing design or acquire an example design from the FPGA Design Store.

#### Related Information

- [Altera FPGA Design Store](#)
- [AN 985: Nios® V Processor Tutorial](#)  
For more information about acquiring a working example design.

### 6.2.3.2. Setting Up Signal Tap Logic Analyzer

#### 6.2.3.2.1. Enabling Signal Tap Logic Analyzer

You must create and configure a Signal Tap File (.stp) in your Nios V processor system.

Follow these steps to add the .stp file to the system:

1. In the Quartus Prime **File** menu, click **New**.
2. In the New dialog box, select **Signal Tap Logic Analyzer File**.
3. Click **OK**.
4. Proceed with the **Default** template.
5. Click **Create**.

**Figure 191. New Dialog Box**



#### Related Information

[Add the Signal Tap Logic Analyzer to the Project](#)


#### 6.2.3.2.2. Adding Signals for Monitoring and Debugging

You can add any signals or interfaces within the processor system for monitoring and debugging. The Nios V processor's interested signals are the nodes within it, allowing the Signal Tap Logic analyzer to capture the opcodes executed by the processor.

Follow these steps to add the signals to the Signal Tap **Node** list for monitoring:

1. Compile the design by clicking **Processing > Start Compilation**.
2. In the Signal Tap logic analyzer, perform **Double-click to add nodes**.
3. The **Node Finder** appears, allowing you to find and add the signals in your design.
4. Select **Post-Compilation** to find signal names present after design compilation.

Figure 192. Node Finder











5. Search for the Nios V processor nodes in the following table. Then click the > button.

Table 53. Nios V Processor Nodes

Nodes	Pipeline Stage	Description	Representation
*D_instr_pc[31..0]	Instruction Decode (D)	Program Counter	Memory address of the instruction being fetched.
*D_instr_word[31..0]		Instruction Word	Fetched 32-bits instruction word.
*D_instr_valid		Instruction Valid	Valid instruction to continue E stage.
*E_instr_pc[31..0]	Instruction Execute (E)	Program Counter	Memory address of the instruction being decoded.
*E_instr_word[6..0]		Instruction Word	7-bits opcode from 32-bits instruction word.
*E_instr_valid		Instruction Valid	Valid instruction to continue M stage.
*M0_instr_pc[31..0]	Memory (M)	Program Counter	Memory address of the instruction being executed.
*M0_instr_valid		Instruction Valid	Valid instruction to continue Write Back stage.

6. Click **Insert**. The nodes are added to the **Setup** tab signal list in the Signal Tap logic analyzer GUI.
7. Specify how the logic analyzer uses the signal by enabling or disabling the **Data Enable** and **Trigger Enable** option for the signal:
  - **Data Enable**—disabling this option stops the capture of data.
  - **Trigger Enable**—disabling this option exclude the signal from the triggering conditions.

Figure 193. Signal Tap Setup tab

Node			
Type	Alias	Tap	Name
		Pre-Syn	osc_clk_div2_global
		Pre-Syn	bsp_reset
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst D_instr_pc[31..0]
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst D_instr_word[31..0]
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst D_instr_valid
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst E_instr_pc[31..0]
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst E_instr_word[31..0]
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst E_instr_valid
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst M0_instr_pc[31..0]
		Post-Fit	u0 intel_niosv_m_0 intel_niosv_m_0 hart m_core.niosv_m_full_inst M0_instr_valid

### 6.2.3.2.3. Specifying Trigger Conditions

Standard Signal Tap logic analyzer trigger conditions are described as hardware or logic events while the Nios V processor system's trigger conditions are described as instruction addresses (Program Counter). The Signal Tap logic analyzer triggers when the Nios V processor reaches the specified instruction address during program execution.

#### Basic Trigger Conditions

In basic triggering mode, the Signal Tap logic analyzer uses a processor-visible system address as the trigger to begin trace capture. To set the trigger, navigate to the **Trigger Conditions** column and select any added signal as the trigger.

You can specify the trigger pattern for a single wire as Don't Care, Low, High, Falling Edge, Rising Edge, or Either Edge.

Examples of single wires are:

- D\_instr\_valid
- E\_instr\_valid
- M0\_instr\_valid

For buses, you can select **Insert Value** to enter the pattern in any preferred number formats. Example of buses are:

- D\_instr\_pc[31..0]
- D\_instr\_word[31..0]
- E\_instr\_pc[6..0]
- E\_instr\_word[31..0]
- M0\_instr\_pc[31..0]

1. Pick any pipeline stage as the trigger stage and leave other stages with disabled **Trigger Enable**.
2. Specify the trigger pattern of its Instruction Valid as **High**.
3. Specify a trigger value on the Program Counter by referring to the application objdump file. Refer to *Correlating Trace Data to Software ELF* on instruction trace and objdump file.



The following example selects the M-stage as the triggering stage.

**Note:** Instructions during the D and E-stages are subject to pipeline flush if a software exception or branching occurs during the M-stage. Altera recommends that the M-stage be applied as the triggering stage.

**Figure 194. M-Stage as Triggering Stage**

Mode	Gate Enable	Trigger Enable	Trigger Conditions
Name	185	33	T ✓ Basic AN -
opc_clk_div2_global	✓		
hwp_reset	✓		
+ u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_pc[31.0]	✓		
+ u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_word[31.0]	✓		
u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_valid	✓		
+ u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_pc[31.0]	✓		
+ u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_word[31.0]	✓		
u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_valid	✓		
+ u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_pc[31.0]	✓	✓	00000314b
u0[instel_niosv_m_0[instel_niosv_m_0[hartm_core_niosv_m_full_inst0_inst_valid	✓	✓	T

### Example 9. Setting Up Triggering Stage based on objdump File

```
<Address>: <Opcode>      <Assembly Mnemonic>
314      : ff010113      addi sp,sp,-16
```

- \*\_instr\_pc[31..0] to 0x314
- \*\_instr\_word[31..0] to 0xff010113

### Power-Up Trigger Conditions

The Signal Tap logic analyzer supports a power-up trigger feature. You can use it for monitoring systems in which the Nios V processor operates in self-booting mode, immediately after configuring the FPGA.

In self-booting mode, the Nios V processor begins software execution immediately from system memory without a debugger to start, stop, and load the processor's run-time memory. Manually starting the Signal Tap logic analyzer can result in a slower reaction speed and potentially miss the specified triggering Program Counter. The Signal Tap logic analyzer can begin data acquisition with the power-up trigger before the processor is out of reset.

Follow these steps to begin capturing processor execution starting from the reset vector:

1. Select the processor system reset as the power-up trigger.
2. The power-up trigger appears as a child instance under the parent Signal Tap instances, and all trigger patterns are repopulated with Don't Care.
3. Specify the same trigger patterns again.

Figure 195. Power-Up Triggers

Type	Alias	Tap	Name	Data Enable	Trigger Enable	Trigger Conditions
Pre-Syn		Pre-Syn	osc_clk_div2_global	✓	✓	
Post-Fit		Post-Fit	inst[D] instr_pc[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[D] instr_word[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[M] instr_pc[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[E] instr_pc[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[E] instr_word[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[M] instr_pc[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[E] instr_word[31:0]	✓	✓	
Post-Fit		Post-Fit	inst[M] instr_pc[31:0]	✓	✓	0000031ab
Post-Fit		Post-Fit	inst[E] instr_word[31:0]	✓	✓	

### Related Information

- [Nios V Processor Configuration and Booting Solutions](#) on page 47
- [Power-Up Triggers](#)  
For more information about power-up triggers.

### Other Trigger Conditions

The Signal Tap logic analyzer allows you to define trigger conditions that range from very simple, such as the rising edge of a single signal, to very complex, involving groups of signals, extra logic, and multiple conditions.

Besides Basic and Power-Up trigger conditions, the Signal Tap logic analyzer also support the following trigger conditions:

- Nested Trigger Conditions
- Comparison Trigger Conditions
- Advanced Trigger Conditions
- Custom Trigger HDL Object
- External Triggers
- Sequential Triggering
- State-based Triggering

### Related Information

[Defining Trigger Conditions](#)

### No Trigger Conditions

When disabling **Trigger Enable** for all signals, the Signal Tap logic analyzer does not configure any trigger conditions. It is synonymous with specifying all trigger conditions as Don't Care.

Upon starting the Signal Tap logic analyzer, data acquisition runs indefinitely until data acquisition is stopped or the buffer is full. This approach is applied to determine the current Program Counter of the processor, such as in the event of a processor hang. While there are multiple causes for processor hang, having the Program Counter value at the event of processor hang is crucial in debugging the issue.

Subsequently, you can apply the same Program Counter value as a basic triggering condition for precise capturing.

#### 6.2.3.2.4. Assigning the Acquisition Clock, Sample Depth, and Memory Type, and Buffer Acquisition Mode

You must specify a clock signal to control the acquisition of samples. Specify the clock signal in the **Signal Configuration** pane of the Signal Tap window. Altera recommends that you select the clock signal that the Nios V processor uses as the Signal Tap acquisition clock. Using the Nios V processor clock ensures that the captured instruction trace data accurately corresponds to the instruction execution of the Nios V processor.

You must configure the capture session's sample depth, memory type, and buffer acquisition mode. These configuration options are accessible through the **Signal Configuration** pane. Exercise care when selecting the **Sample Depth** size. Capturing many signals for every sample taken can quickly deplete available memory resources. Use the Signal Tap built-in resource estimator to understand better how adjusting the sample depth parameter impacts your design.

##### Related Information

- [Specifying the Clock, Sample Depth, and RAM Type](#)
- [Specifying the Buffer Acquisition Mode](#)  
For more information on acquisition clock, sample depth, memory type and buffer acquisition mode.

#### 6.2.3.2.5. Compiling the Design and Programming the Target Device

You must perform a full compilation of the Quartus Prime project after enabling the Signal Tap logic analyzer. After compilation, you can program the FPGA target device with the SRAM Object File (.sof) from the Signal Tap window

##### Related Information

[Compile the Design and Signal Tap Instances](#)

#### 6.2.3.3. Running the Capture Session

You can begin data acquisition with the Signal Tap logic analyzer.

First, program the FPGA with the .sof that the Quartus Prime software generates. Next, run Signal Tap analysis, either manually through the **Signal Tap Instance Manager** or automatically when the FPGA is programmed and power-up triggering is selected. If the system meets the trigger conditions, the Signal Tap logic analyzer displays the acquired data in the Signal Tap results window.

You can use the Signal Tap logic analyzer in two different types of data capture sessions, one with the Ashling RiscFree IDE for Altera FPGAs and the other in stand-alone mode.

##### 6.2.3.3.1. Performing Data Capture with Ashling RiscFree IDE for Altera FPGAs

To use the Signal Tap logic analyzer with the Ashling RiscFree IDE for Altera FPGAs, you must manually download a Nios V processor software image and control the operation of the processor through the debugger. You can perform this type of capture session when you are developing and debugging a Nios V processor software application.

Follow these steps to run a Signal Tap capture session with the Nios V processor controlled by the Ashling RiscFree IDE for Altera FPGAs:

1. In the Signal Tap window, program the FPGA target device with the `.sof` generated:
  - On the **Hardware** menu, select the programming cable that is connected to the FPGA development board.
  - In the **SOF Manager** field, click **browse**.
  - In the **Select Programming File** dialog box, select the `.sof` generated.
  - Click **Open**. The **Program Device** button is now available.
  - Click the **Program Device** button to download the `.sof` to the FPGA.
2. In the Signal Tap window, in the Instance Manager pane, click the **Run Analysis** button to start the logic analyzer capture session.
3. In the Ashling RiscFree IDE for Altera FPGAs, right-click the name of the software project you want to run on the Nios V processor and click **Debug As > Debug Configuration > Ashling RISC-V Hardware Debugging**.
4. Set the necessary debug configuration. This action starts the debugger, downloads the `.elf` into system memory, and halts the processor on the entry point to `main()`.
5. On the **Debug** tab, click the **Resume** button to start the Nios V processor execution

The Signal Tap logic analyzer continues running until the trigger condition specified is reached. While the Signal Tap logic analyzer is running, you can use the Ashling RiscFree IDE for Altera FPGAs debugger at the same time safely (for example, you can set breakpoints and stop the processor).

To change the startup breakpoint, follow these steps in the Ashling RiscFree IDE for Altera FPGAs:

1. On the **Run** menu, click **Debug Configurations**.
2. The **Debug Configurations** window appears.
3. In the **Debug Configurations** window, click the **Startup** tab.
4. Specify a new startup breakpoint at **Set breakpoint at**.
5. Click **Apply**.

Alternatively, instead of using the **Debug As** option, you can use the **Run As** option. Using the **Run As** option causes the Ashling RiscFree IDE for Altera FPGAs to download and run the software image from system memory without starting the debugger feature.

#### 6.2.3.3.2. Performing Data Capture Without Software Download

The Signal Tap logic analyzer begins running automatically when the FPGA is programmed. In this case, the Signal Tap logic analyzer already have captured data available. To retrieve the captured data, click **Run Analysis** in the Signal Tap instance manager.

The Nios V processor system is:

- Configured to be self-booting
- Without the need for an external software download
- Selected the Signal Tap power-up trigger feature

### Related Information

Nios V Processor Configuration and Booting Solutions on page 47

#### 6.2.3.4. Analyzing Results

The Signal Tap logic analyzer allows you to view the captured Nios V processor trace data. This section describes several of the post-capture features. The following figure shows an example of data acquisition of Signal Tap logic analyser with M-stage as the triggering stage.

Figure 196. Data Acquisition



The example shows the pipeline behavior of the processor with M-stage Program Counter and M-stage Instruction Valid as trigger conditions. With every passing clock cycle, the instruction from address 314h enters the D-stage, E-stage, and M-stage.

##### 6.2.3.4.1. Viewing Data

Captured Signal Tap data appears in the **Data** tab of the Signal Tap window. Every sample captured displays the following information:

Table 54. Samples Captured Based on Nodes

Nodes	Pipeline Stage	Description	Representation
*D_instr_pc[31..0]	Instruction Decode (D)	Program Counter	Memory address of the instruction being fetched.
*D_instr_word[31..0]		Instruction Word	Fetched 32-bits instruction word.
*D_instr_valid		Instruction Valid	Valid instruction to continue E stage.
*E_instr_pc[31..0]	Instruction Execute (E)	Program Counter	Memory address of the instruction being decoded.
*E_instr_word[6..0]		Instruction Word	7-bits opcode from 32-bits instruction word.
*E_instr_valid		Instruction Valid	Valid instruction to continue M stage.
*M0_instr_pc[31..0]	Memory (M)	Program Counter	Memory address of the instruction being executed.
*M0_instr_valid		Instruction Valid	Valid instruction to continue Write Back stage.

Using the Signal Tap tab controls, you can scroll through the program execution of the Nios V processor. If the specified acquisition clock corresponds to the Nios V processor clock, every rising clock edge corresponds to a new instruction cycle.

You may notice one or more empty instruction entries in the trace data gathered by the Signal Tap logic analyzer. These entries indicate that no instruction was executed by the Nios V processor during that clock cycle. This behavior is typical, and can occur for the following reasons:

- **Cache Miss** — The requested instruction address location generates a miss in the instruction cache, and additional clock cycles are required to fill the cache line and return the instruction.
- **Memory Contention or Speed** — The instruction address location is in memory that requires multiple clock cycles to access, or in memory that is currently controlled by another peripheral or processor.

You can also view the trace data in the Signal Tap list file format. In this tabular format, the trace samples are displayed chronologically in rows. The list file format is useful because it is like the objdump file, simplifying the analysis process. Click **File > Create/Update > Create Signal Tap List File** to create the Signal Tap list file.

#### 6.2.3.4.2. Correlating Trace Data to Software ELF

By examining the contents of the objdump file, you can compare the captured instruction trace to the software image executed by the Nios V processor. The objdump file is a copy of the processor's `.elf` file in a human-readable format that contains C/C++ code fragments, symbolic function names, assembly instructions, and address locations. It is generated automatically after a successful software compilation.

Although the objdump file contains vast amounts of information decoded from the `.elf`, the Nios V processor's instructions appear one per line in this file, in the following format:

```
<Address>: <Opcode> <Assembly Mnemonic>
```

For example, the instructions from Figure [Analyzing results](#) are:

```
314: ff010113 addi sp,sp,-16
318: 00112623 sw ra,12(sp)
31c: 00812423 sw s0,8(sp)
320: 01010413 addi s0,sp,16
```

#### 6.2.3.4.3. Saving and Converting Captured Data

You can save any data captured using Signal Tap data log feature. To enable data logging, turn on the **Data Log** option in the Signal Tap window. To export captured data, on the **File** menu, click **Export** and specify the **File Name**, the **Export Format**, and the **Clock Period**.

#### 6.2.4. In-System Sources and Probes

Traditional debugging techniques often involve using an external pattern generator to exercise the logic and a logic analyzer to study the output waveforms during run time. The Signal Tap Logic Analyzer and In-System Sources and Probes allow you to read or tap internal logic signals during run time to debug your logic design.

You can make the debugging cycle more efficient when you can drive any internal signal manually within your design, which allows you to perform the following actions:

- Force the occurrence of trigger conditions set up in the Signal Tap Logic Analyzer.
- Create simple test vectors to exercise your design without using external test equipment.
- Dynamically control run time control signals(e.g. system reset) with the JTAG chain.

#### Related Information

[Quartus Prime Pro Edition User Guide: Debug Tools](#)

Refer to the topic Design Debugging Using In-System Sources and Probes for more information.

## 6.3. Debugging Nios V Processor Software Designs

### 6.3.1. Ashling RiscFree IDE for Altera FPGAs

The Ashling RiscFree IDE for Altera FPGAs is Ashling's Eclipse\* C/C++ Development Toolkit (CDT) based integrated development environment (IDE) for Altera FPGAs Arm\*-based HPS and RISC-V based Nios V processors. The Ashling RiscFree IDE for Altera FPGAs is free of charge, and it provides a complete, seamless environment for C and C++ software development and has the following features:

- Eclipse\* CDT-based IDE with full source and project creation, editing, build, and debug support using the RISC-V GNU compiler collection (GCC) toolchain.
- Project Manager and Build Manager, including Make and CMake support with rapid import, build, and debug of application frameworks created using the Quartus Prime software.
- RISC-V GNU GCC toolchain with support for newlib or picolibc run-time libraries using the Nios V Hardware Abstraction Layer (HAL) API for hardware access.
- Integrated support for Altera FPGA Download Cable II JTAG debug probe.
- ROM or RAM based debugging support, for example, hardware breakpoints for flash-based support.
- High-level Register Viewer based on industry-standard System View Description (SVD) files.
- Integrated serial terminal

#### Related Information

[Ashling RiscFree Integrated Development Environment \(IDE\) for Altera FPGAs User Guide](#)



### 6.3.2. Ashling Visual Studio Code Extension for Altera FPGAs

Ashling Visual Studio Code Extension is a set of code that runs in Visual Studio Code and provides new or improved features for Altera FPGAs Arm\*-based HPS and RISC-V based Nios V processors. Ashling Visual Studio Code Extension provides a complete, seamless Visual Studio Code based C and C++ software development and has the following features:

- GUI-based debug configurations for Altera FPGA Arm HPS and Nios V soft cores such as probe selection, device selection, core selection etc.
- Auto-detect feature displaying all the devices and cores in the FPGA, allowing user to select the required core for the debug session.
- CMake based project management support, allowing for the direct import and build of Nios V HAL and BSP projects.
- FreeRTOS and Zephyr RTOS aware debug support including tasks and event views.
- Nios V GCC compiler toolchain fully integrated with support for newlib or picolibc run-time libraries using the Nios V Hardware Abstraction Layer (HAL) API for hardware access.
- Integrated support for Intel USB Blaster II JTAG debug probe.
- Custom instruction support and extensions for the Nios V processor.
- Assembly level instruction stepping support.
- ROM or RAM based debugging support (e.g., hardware breakpoints for flash-based support).

### 6.3.3. OpenOCD

The Open On-Chip Debugger (OpenOCD) is an open-source gdb server that provides debugging, in-system programming, and boundary-scan testing for embedded target devices accessible via a hardware debugger's JTAG connection.

#### Related Information

##### [Open On-Chip Debugger](#)

For more information about how to use OpenOCD to debug Nios V processor application.

### 6.3.4. Objdump File

The Nios V processor build process always generate an object dump text file (.objdump) from your application .elf file. The .objdump file contains information about the memory sections and their layout, the addresses of functions, and the original C source code interleaved with the assembly code. The .objdump file generates in the <project\_directory>/software/app/build folder .

### 6.3.5. Show Make Commands

The individual Makefile commands appear in the display as they run. To enable a verbose mode for the make command, execute the following build command in the Nios V Command Shell when building the application:

```
make VERBOSE=1
```



## 6.4. Debugging Tools

The Quartus Prime software allows you to use the debugging tools to exercise and analyze the logic under test and maximize closure. Below are the list of debugging tools in the Quartus Prime software:

- Signal Tap Logic Analyzer
- Logic Analyzer Interface
- Signal Probe
- In-system Sources and Probes
- Virtual JTAG Interface
- System Console
- In-System Memory Content Editor

### Related Information

[Quartus Prime Pro Edition User Guide: Debug Tools](#)

## 6.5. Additional Embedded Design Considerations

Consider the following topics as you design your system:

- JTAG signal integrity
- Additional memory space for prototyping

### 6.5.1. JTAG Signal Integrity

The JTAG signal integrity on your system is very important. Poor signal integrity on the JTAG interface can prevent you from debugging over the JTAG connection or cause inconsistent debugger behavior.

### Related Information

[Quartus Prime Timing Analyzer Cookbook](#)

For more information about JTAG Signals.

### 6.5.2. Additional Memory Space for System Prototyping

Even if your final product includes no off-chip memory, Altera recommends that your prototype board include a connection to some region of off-chip memory. This component in your system provides additional memory capacity that enables you to focus on refining code functionality without worrying about code size. Later in the design process, you can substitute a smaller memory device to store your software.

## 6.6. Simulating Nios V Processor Designs

This section describes the following tasks:

- Generating an RTL simulation environment with Nios V processor example designs and Platform Designer.
- Running the RTL simulation in the Questa\* Intel® FPGA Edition simulator.

The increasing pressure to deliver robust products to market timely has amplified the importance of comprehensively verifying embedded processor designs. Therefore, consider the verification solution supplied with the processor when choosing an embedded processor. Nios V embedded processor designs support a broad range of verification solutions, including the following:

- **Board Level Verification**—Intel offers several development boards that provide a versatile platform for verifying both the hardware and software of a Nios V embedded processor system. You can further debug the hardware components that interact with the processor with the Signal Tap embedded logic analyzer.
- **Register Transfer Level (RTL) Simulation**—RTL simulation is a powerful means of debugging the interaction between a processor and its peripheral set. When debugging a target board, it is often difficult to view signals buried deep in the system. RTL simulation alleviates this problem by enabling you to probe every register and signal in the design. You can easily simulate Nios V based systems in the Questa Intel FPGA Edition simulator with an automatically generated simulation environment, that is Platform Designer.

**Note:** Due to a limitation with embedded memory blocks, the simulation model of Nios V processor does not support ECC on Arria 10 devices.

#### Related Information

[Embedded Memory \(RAM: 1-PORT, RAM: 2-PORT, ROM: 1-PORT, and ROM: 2-PORT\) User Guide](#)

### 6.6.1. Prerequisites

You must have experience using Platform Designer and are familiar with the QuestaSim simulator. To simulate the Nios V processor design using the instructions in this handbook, you must install the following softwares:

- Quartus Prime
- QuestaSim Simulator


### 6.6.2. Setting Up and Generating Your Simulation Environment in Platform Designer

To generate simulation files, perform the following steps:

1. Start the **Intel Quartus Prime software** and open the **Platform Designer** from the **Tools** menu.
2. Open the `<your project design>.qsys` file.  
*Note:* Ensure that you have completed building your Platform Designer system before generating the simulation models
3. In **Platform Designer**, navigate to **Generate ► Generate Testbench System**.
4. On the **Generation** window, set the following parameters to these values:
  - a. Create testbench Platform Designer system— **Standard, BFM for standard Platform Designer interfaces**.

- Note: If your system has exported ports other than the clock and reset, choose Standard, BFM's for standard Avalon interfaces.
- b. Create testbench simulation model—**Verilog**
  - c. Select **Use multiple processors for faster IP generation (when available)**.
5. Click **Generate**, and **Save**, if prompted.

Figure 197. Testbench Generation



#### 6.6.2.1. Using IP and Platform Designer Simulation Setup Scripts

Intel IP cores and Platform Designer systems generate simulation setup scripts. Modify these scripts to set up supported simulators. The script, `msim_setup.tcl` is located in the path: `<project_directory>/sys_tb/sim/mentor`.

### 6.6.3. Creating Nios V Processor Software

#### 6.6.3.1. Generating the Board Support Package

Generate the BSP file using the following steps:

1. Launch the Nios V Command Shell
2. Based on your Quartus Prime version, execute the following command to generate the BSP file. Select the **type** as **hal** or **ucosii**.

- The command for Quartus Prime Pro Edition:

```
niosv-bsp -c --quartus-project=top.qpf --qsys=sys.qsys \  
--type=<hal, ucosii, or freertos> software/bsp/settings.bsp
```

- The command for Quartus Prime Standard Edition:

```
niosv-bsp -c --quartus-project=hw/top.qpf --sopcinfo=hw/sys.sopcinfo \  
--type=<hal, ucosii, or freertos> software/bsp/settings.bsp
```

#### 6.6.3.2. Generating the Application Project File

Generate the application file using the following steps:

1. Launch the Nios V Command Shell.
2. Execute the command below to generate an application CMakeLists.txt.

```
niosv-app --bsp-dir=software/bsp --app-dir=software/app \
--srcs=software/app/<source code 1> \
--srcs=software/app/<source code 2>
```

### 6.6.3.3. Building the Application Project

You can choose to build the application project using the RiscFree IDE for Altera FPGAs, or through the command line interface (CLI).

If you prefer using CLI, you can build the application using the following command:

```
cmake -G "Unix Makefiles" -DCMAKE_BUILD_TYPE=Debug -B \
software/app/build -S software/app
```

```
make -C software/app/build
```

The application (.elf) file is created in software/app/build folder.

### 6.6.4. Generating Memory Initialization File

To generate application image .hex file using the elf2hex command:

```
elf2hex <elf input file> -b <On-chip memory start address> -w <On-chip memory
data width in bits> -e < On-chip memory end address> -r 4 <hex output file>
```

```
e.g. elf2hex software/app/build/hello.elf -b 0x0 -w 32 -e 0x4FFFF -r 4 -o
ram.hex
```

### 6.6.5. Generating System Simulation Files

At this point in the design flow, you have generated your system and created all the files necessary for simulation listed in the table below. These are the necessary files required to run the simulation.

**Table 55. Files Generated for Nios V Processor Simulation**

File	Description
<Project directory>/sys_tb/	Platform Designer generates a testbench system when you enable the <b>Create testbench Platform Designer</b> system option. Platform Designer connects the corresponding Avalon Bus Functional Models to all exported interfaces of your system. For more information about Platform Designer, refer to the <i>Intel Quartus Prime Pro Edition User Guide: Platform Designer</i> .
<Project directory>/sys_tb/sys_tb/sim/mentor/msim_setup.tcl	Sets up a QuestaSim simulation environment and creates alias commands to compile the required device libraries and system design files in the correct order and loads the toplevel design for simulation.
<Project directory>/<Memory Initialization Files>.hex	Memory Initialization Files (.hex) is required to initialize memory components in your system. Use elf2hex utility to create Nios V processor program to populate the .hex file.

## Related Information

Quartus Prime Pro Edition User Guide: Platform Designer

### 6.6.6. Running Simulation in the QuestaSim Simulator Using Command Line

You can launch the QuestaSim simulator using command `vsim`, in the Nios V Command Shell. The `msim_setup.tcl` script in the package generated creates alias commands for each step. For the list of commands, refer to the following table:

Macros	Description
dev_com	Compile device library files.
com	Compiles the design files in correct order.
elab	Elaborates the top-level design.
elab_debug	Elaborates the top-level design with the <code>novopt</code> option.
ld	Compiles all the design files and elaborates the top-level design.
ld_debug	Compiles all the design files and elaborates the top-level design with the <b>vopt</b> option.

**Note:** The **vopt** option is to run optimization before elaborating the top-level design in the simulator.

You can run the simulation in the QuestaSim simulator by performing the following steps.

1. In the transcript window, change your working directory to mentor by using the following command.

```
cd <Project directory>/sys_tb/sys_tb/sim/mentor
```

2. Copy the memory initialization file generated into the current path (Mentor folder)  
`file copy -force <Project directory>/ram.hex ./`

3. Run the `msim_setup.tcl` by using the following command.

```
do msim_setup.tcl
```

4. Compiles all the design files and elaborates the top-level design with **vopt** option by using the following command

```
ld_debug
```

5. Type `run 2ms` to start the simulation for 2 milliseconds.

At the end of the simulation, "Hello world, this is the Nios V/m cpu checking in ..." message prints in the Transcript window. You can observe the simulation results from the waveform viewer as well. The following figure shows the simulation result.

**Figure 198. Simulation Result**



## 7. Nios V Processor — Remote System Update

### 7.1. Overview


Altera FPGA devices support Remote System Update (RSU) feature to allow you to update the FPGA image and reconfigure the device remotely. RSU has the following advantages:

- Provides a mechanism to deliver feature enhancements and bug fixes without recalling your products
- Reduces time-to-market
- Extends product life

In control block-based devices<sup>(12)</sup>, you need the Remote Update Altera FPGA IP to implement the RSU. Refer to *Remote Update Altera FPGA IP User Guide* for more information.

In SDM-based devices<sup>(12)</sup>, you can write configuration bitstreams to the configuration flash device using RSU and Mailbox Client Altera FPGA IP. A single configuration device can store multiple application images and a single factory image. After that, you can perform FPGA reconfiguration from the RSU image through a host. The RSU can implement JTAG-to-Avalon Master Bridge IP, Nios V processor, or Hard Processor System (HPS) as the RSU host.

**Figure 199. Typical Remote System Update Process**



<sup>(12)</sup> Refer to *AN 980: Nios V Processor Quartus Prime Software Support* for the device list.

### Related Information

- [Stratix 10 Configuration User Guide: Remote System Update](#)  
Functional description on RSU and implementing RSU feature with JTAG-to-Avalon Master Bridge IP in Stratix 10 devices
- [Agilex 7 Configuration User Guide: Remote System Update](#)  
Functional description on RSU and implementing RSU feature with JTAG-to-Avalon Master Bridge IP in Agilex 7 devices.
- [Mailbox Client Altera FPGA IP User Guide](#)  
More information about the LibRSU HAL API that performs RSU operations in SDM-based devices (Stratix 10 and Agilex 7 devices).
- [Stratix 10 Hard Processor System Remote System Update User Guide](#)  
More information about using the HPS to drive RSU in Stratix 10 SoC devices.
- [Agilex 7 Hard Processor System Remote System Update User Guide](#)  
More information on using the HPS to drive RSU in Agilex 7 SoC devices.
- [Remote Update Altera FPGA IP User Guide](#)  
Functional description on implementing Remote Update Altera FPGA IP in control block-based devices (Cyclone® 10 GX and Arria 10 devices).
- [AN 980: Nios V Processor Quartus Prime Software Support](#)

## 7.2. Quartus Prime Pro Edition Software and Tool Support

### 7.2.1. Quartus Prime Pro Edition Software

You must use the Quartus Prime Pro Edition software to compile the hardware projects for remote system update in SDM-based devices.

#### 7.2.1.1. Setting Max Retry Parameter

The `max_retry` parameter specifies how many times the application and factory images are tried when configuration failures occur.

- The default value is one, which means each image is tried only once.
- The maximum possible value is three, which means each image can be tried up to three times.

The `max_retry` parameter is stored in the decision firmware data area. The decision firmware data can also be updated by a decision firmware update image, or by a combined application image.

The `max_retry` parameter is specified for the hardware project used to create the factory image, from the Quartus Prime GUI by navigating to **Assignments > Device > Device and Pin Options > Configuration** and selecting the value for the **Remote System Update MAX\_RETRY count** field.



Figure 200. Configuration Window

Configuration

Specify the device configuration scheme and the configuration device.

Configuration scheme: Active Serial x4 (can use Configuration Device)

Configuration device:

Configuration device I/O voltage: Auto

☐ Force VCCIO to be compatible with configuration I/O voltage

VID mode of operation: PMBus Master

Configuration pin:

☒ Generate compressed bitstream

Active serial clock source: 100 MHz Clock Frequency

☐ Disable input tri-state on active configuration pin at user route

HPS/FPGA configuration order: After INIT\_DONE

HPS debug access port (DAP): Disabled

☐ Allow HPS debug without certificate

☐ Disable Register Power-up Initialization

Remote System Update MAX\_RETRY count: 3

You can also specify the parameter directly by editing the project Quartus Prime settings file (.qsf) and adding the following line or changing the value if it is already there:

```
set_global_assignment -name RSU_MAX_RETRY_COUNT 3
```

#### 7.2.1.2. Selecting Factory Load Pin

Quartus Prime software offers the option to select the pin to use to force the factory application to load on a reset.

1. Navigate to **Assignments > Device > Device and Pin Options > Configuration > Configuration Pin Options**.
2. Check the **Direct to Factory Image** check box.
3. Select the desired pin from the drop box.

Figure 201. Configuration PIN GUI



### 7.2.2. Programming File Generator

Quartus Prime Programming File Generator, is part of Quartus Prime Pro Edition software. The tool creates programming files for all RSU scenarios as follows:

- Initial flash images
- Application images
- Factory update images
- Decision firmware update images
- Combined application images

#### Related Information

- [Quartus Prime Pro Edition User Guide: Programmer](#)
- [Quartus Prime Standard Edition User Guide: Platform Designer](#)

### 7.2.2.1. Programming File Generator File Types

The following table lists the most important file types created by the Programming File Generator for RSU:

**Table 56. File Extension**

File Extension	File Type	Description
.jic	JTAG Indirect Configuration File	These files are intended to be written to the flash by using the Quartus Prime Programmer tool. They contain the actual flash data, and also a flash loader, which is a small FPGA design used by the Quartus Prime Programmer to write the data.
.rpd	Raw Programming Data File	These files contain actual binary content for the flash and no additional metadata. They can contain the full content of the flash, similar with the .jic file—this is typically used in the case where an external tool is used to program the initial flash image. They can also contain an application image, or a factory update image.
.map	Memory Map File	These files contain details about where the input data was placed in the output file. This file is human readable.
.rbf	Raw Binary File	These files are binary files which can be used typically to configure the FPGA fabric for HPS first use cases. They can also be used for passively configuring the FPGA device through Avalon streaming interface, but that is not supported with RSU.

### 7.2.2.2. Bitswap Option

The Quartus Prime Programmer assumes by default that the binary files have the bits in the reversed order for each byte. Because of this, you need to enable the **bitswap=on** option as follows:

- For each input binary file (.bin and .hex files are supported).
- For each output RPD file:
  - Full flash images
  - Application images
  - Factory update images
  - Decision firmware update images
  - Combined application images

You can use the **bitswap** option following the examples presented in this document.

### 7.2.2.3. Quartus Prime Programmer

Use the Quartus Prime Programmer to program the initial flash image.

### 7.2.2.4. Supported QSPI Flash Devices

For a list of supported QSPI Flash Devices, refer to the *Intel® Supported Configuration Devices*.

#### Related Information

[Device Configuration - Support Center](#)

### 7.3. Nios V Processor RSU Quick Start Guide in SDM-based Devices


You can perform the remote system update in the SDM-based devices using the Nios V processor system. The example demonstrates the following operations:

**Table 57. Remote System Update Example using Nios V Processor System**

Operation	Supported Image
Creating the flash images	<ul style="list-style-type: none"> <li>Initial RSU image (containing bitstreams for factory and application image)</li> <li>Application update image</li> <li>Factory update image</li> </ul>
Reconfiguring the FPGA device	<ul style="list-style-type: none"> <li>Factory image</li> <li>Application image</li> </ul>
Updating the RSU flash image	<ul style="list-style-type: none"> <li>Factory update image</li> <li>Application update image</li> </ul>

The block diagram below shows the processor system along with the configuration QSPI flash layout. Altera builds the system using the Stratix 10 SX SoC L-Tile development kit. The Nios V processor boots the processor software from the memory-initialized on-chip memory.

**Figure 202. Remote System Update Example Design**



In a normal RSU use case, each image can be unique and performs different functions. The initial RSU JIC image contains the factory image and application image, while the update images are generated as .rpd file.

The Nios V processor system is incapable of performing the device reconfiguration directly with both update images because they are not registered within the initial RSU image. To perform the RSU image update, the processor reads and writes the update images into the initial RSU image and then initiates the device reconfiguration.

**Note:** Besides storing the updated images in a non-volatile flash, they can be transferred to the processor system through a network.

### 7.3.1. Individual Factory, Application, and Update Images

The example requires four images to demonstrate the RSU feature. You can modify a Nios V processor project and create four different systems with distinctive functions. However, you need to perform multiple compilation to achieve that.

To simplify the build flow, this example implements two processor systems (factory and application system) and makes three copies of the latter .SOF file and named them respectively as below:

- `factory.sof` (Factory Image .SOF)
- `application-0.sof` (App Image .SOF)
- `application-1.sof` (App Update Image .SOF)
- `application-2.sof` (Factory Update Image .SOF)

Even if the application images contain the same bitstreams, you can identify the images using the RSU status log.

**Table 58. Nios V Processor System Details**

System	Factory	Application
Platform Designer System	To create a Platform Designer system, follow the steps in section <i>Hardware Design Flow</i> with OCRAM size of 6 Mbytes.	To create a Platform Designer system, follow the steps in section <i>Hardware Design Flow</i> with OCRAM size of 1 Mbytes.
Board Support Package	Apply the BSP settings using the steps in section <i>Software Design Flow</i> .	
Nios V Processor Source Code	Uses <code>factory.c</code> that features basic RSU operations from <i>Example source code for Nios V Processor LibRSU application</i> . Refer to the link in Related Information.	Uses <code>application.c</code> that features a simplified RSU operations from <i>Example source code for Nios V Processor LibRSU application</i> . Refer to the link in Related Information.
Processor Boot Method	Software boots from OCRAM.	
Image	<ul style="list-style-type: none"> <li>• Factory Image .SOF</li> </ul>	<ul style="list-style-type: none"> <li>• App Image .SOF</li> <li>• App Update Image .SOF</li> <li>• Factory Update Image .SOF</li> </ul>

#### Related Information

- [Example source code for Nios V Processor LibRSU application](#)
- [Hardware Design Flow](#) on page 213
- [Software Design Flow](#) on page 216








### 7.3.2. Hardware Design Flow

#### 7.3.2.1. Create a Platform Designer System

1. Add the Nios V processor and the following peripherals into the Platform Designer system:

- Nios V/m Processor Altera FPGA IP
- On-Chip Memory (RAM) Altera FPGA IP
- JTAG UART Altera FPGA IP
- Mailbox Client Altera FPGA IP
- JTAG to Avalon Master Bridge Altera FPGA IP

Figure 203. Connections in Platform Designer System

Connections	Name	Description
	clock_in	Clock Bridge Intel FPGA IP
	in_clk	Clock Input
	reset_in	Reset Bridge Intel FPGA IP
	in_reset	Reset Input
	intel_niosv_m_0	Nios V/m Processor Intel FPGA IP
	clk	Clock Input
	onchip_memory2_0	On-Chip Memory (RAM or ROM) Intel FPGA
	clk1	Clock Input
	jtag_uart_0	JTAG UART Intel FPGA IP
	clk	Clock Input
	s10_mailbox_client_0	Mailbox Client Intel FPGA IP
	in_clk	Clock Input
	master_0	JTAG to Avalon Master Bridge Intel FPGA IP
	clk	Clock Input

- In the Nios V processor **Parameters** tab
  - Enable the **Enable Debug** feature.
  - Set the **Reset Agent** to OCRAM.

Figure 204. Nios V Processor Altera FPGA IP Parameter Editor



3. In the On-Chip Memory (RAM or ROM) Intel FPGA Parameters tab **Total memory size** box, specify the memory size as below:
  - 1 Mbytes for application system
  - 6 Mbytes for factory system.
4. Enable **Initialize memory content** and **Enable non-default initialization file** with `app.hex` in the OCRAM.

Figure 205. On-Chip Memory Intel FPGA IP Parameter Editor



5. Click **Generate HDL**, the Generation dialog box appears.
6. Specify output file generation options and then click **Generate**.

### 7.3.2.2. Quartus Prime Software Settings

1. In the Intel Quartus Prime software, click **Assignment ► Device ► Device and Pin Options ► Configuration**.
2. Set **Configuration scheme** to **Active Serial x4 (can use Configuration Device)**.
3. Set **VID mode of operation** according to your board design.
4. Set the **Active serial clock source** to **100 MHz Internal Oscillator**

Figure 206. Device and Pin Options



5. Click **OK** to exit the **Device and Pin Options** window.
6. Click **OK** to exit the **Device** window.
7. Click **Start Compilation** to compile your project.

### 7.3.3. Software Design Flow

Creating a Nios V processor software image for RSU consists of the following general steps:

1. Generate the ZLIB libraries.
2. Create a board support package (BSP) project.
3. Creating a Nios V processor application project.
4. Building the application project using the provided source codes.
5. Running and debugging the application project.

To ensure a streamline build flow, Altera encourages you to create a similar directory tree in your design project. The following software design flow is based on this directory tree.

To create the software project directory tree, follow these steps:

1. In your design project folder, create a new folder named `software`.
2. In the `software` folder, create another two folders named `app` and `bsp`.



### 7.3.3.1. Generating the ZLIB libraries

The LibRSU HAL API requires the ZLIB libraries. Follow these steps to generate the ZLIB libraries:


1. Acquire the latest version number of ZLIB libraries from the ZLIB home page.
2. Navigate to the design project folder.
3. Copy the following code and replace <version> with the latest version number:

```
wget http://zlib.net/zlib-<version>.tar.gz
tar xf zlib-<version>.tar.gz
mv zlib-<version> zlib
```

4. Run the command.
5. The `zlib` folder is ready with the ZLIB libraries.

*Note:* One of the LibRSU software component, `librsu_ll_qspi.c` includes the ZLIB libraries under a specific path. If the project directory tree is different than the following figure, modify the ZLIB libraries path in `librsu_ll_qspi.c`.

Figure 207. Software Project Directory Tree




### 7.3.3.2. Creating a Board Support Package Project

Follow these steps to create a BSP project:

1. In the Platform Designer window,, go to **File ► New BSP** . The **Create New BSP** window appears.
2. For **BSP setting file**, navigate to the `software/bsp` folder and create a BSP file (`settings.bsp`).
3. For **System file (qsys or sopcinfo)**, select the Nios V processor Platform Designer system.
4. For **Quartus project**, select the example design Quartus Project File.
5. For **Revision**, select the correct revision.
6. For **CPU name**, select the Nios V processor.
7. Select the **Operating system** as **Altera HAL**.
8. Click **Create** to create the BSP file.

Figure 208. Create New BSP Window



### 7.3.3.3. Configuring and Generating the BSP Project

1. In the **BSP Editor**, go to **Main > Settings > Advanced > hal.linker**.
2. Enable the following settings:
  - **allow\_code\_at\_reset**
  - **enable\_alt\_load**
  - **enable\_alt\_load\_copy\_rwdata**

Figure 209. hal.linker Settings



3. Navigate to the **BSP Linker Script** tab in the **BSP Editor**.
4. Set all the **Linker Section Name** list to the OCRAM.
5. In the **BSP Drivers**, enable the device driver for Mailbox Client Altera FPGA IP.
6. Go to **Settings > altera\_s10\_mailbox\_client**. You may set **rsu\_log\_level** as 0 for minimum logging information.
7. Apply **rsu\_protected\_slot** as -1 for no slot protection.
8. Enable the following settings:

- **rsu.enable\_spt\_checksum**
- **rsu.enable\_rsu**
- **fpga\_device.Stratix10**

*Note:* Select other options for **fpga\_device** when you are not using the Stratix 10 device.

**Figure 210. BSP Drivers Tab**



9. Click **Generate BSP**. Make sure the BSP generation is successful.
10. Close the **BSP Editor**.

#### 7.3.3.4. Creating Multiple Application Projects

1. Download the example source code using the link below.
2. Navigate to the `software/app` folder and copy the example source codes.
3. Change the default name of Mailbox Client Intel FPGA IP (`MAILBOX_NAME`) based on the `system.h` file, in the following locations:

- a. The example source codes

- Example Source Codes (`application.c` and `factory.c`)

```
int main(void)
{
    ...
    fd = mailbox_client_open(MAILBOX_NAME);
    ...
}
```

- b. `bsp/drivers/src/altera_s10_mailbox_client_flash_rsu.c`

- ```
int plat_qspi_init(struct qspi_ll_intf **qspi_intf)
{
    ...
    #ifdef MAILBOX_NAME
        /* retrieve data from flash */
        fd = mailbox_client_open(MAILBOX_NAME);
    #endif
    ...
}
```

- c. `bsp/drivers/src/altera_s10_mailbox_client_rsu.c`

- ```
int plat_mbox_init(struct mbox_ll_intf **mbox_intf)
{
    ...
}
```

```
#ifdef MAILBOX_NAME
    fd = mailbox_client_open(MAILBOX_NAME);
#endif
...
}
```

4. Launch the Nios V Command Shell.
5. Execute the command below to generate the user application CMakeLists.txt.

```
//For Application Image
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/application.c,zlib/crc32.c \
--incs=zlib

//For Factory Image
niosv-app --app-dir=software/app --bsp-dir=software/bsp \
--srcs=software/app/factory.c,zlib/crc32.c \
--incs=zlib
```

### Related Information

[Example source code for Nios V Processor LibRSU application](#)

#### 7.3.3.5. Building the Application Projects

You can choose to build the application project using Ashling RiscFree IDE for Altera FPGAs or through the command line interface (CLI).

If you prefer using CLI, you can build the applications using the following command:

```
cmake -G "Unix Makefiles" -B software/app/build \
-S software/app
make -C software/app/build
```

The user application .elf files (app.elf) is created in the build folder.

#### 7.3.3.6. Generating HEX Files

You must generate a .hex file from the user application .elf files, to memory-initialize the OCRAM in the Nios V processor system.

1. Launch the Nios V Command Shell.
2. For Nios V processor application boot from OCRAM, use the following command line to convert the ELF to HEX for your application.

```
elf2hex software/app/build/app.elf -o app.hex \
-b <base address of OCRAM> -w <data width of OCRAM> \
-e <end address of OCRAM>
```

3. Recompile the Nios V processor hardware system to memory-initialize the on-chip memory.

### 7.3.4. Individual Images Generation

Refer to the following steps to generate the four individual images:

1. Repeat the steps in the topics *Hardware Design Flow* and *Software Design Flow* to generate the factory system.
2. Rename the factory image as `factory.sof`.
3. Create three copies of application image and renamed them as
  - `application-0.sof`
  - `application-1.sof`
  - `application-2.sof`

#### Related Information

- [Hardware Design Flow](#) on page 213
- [Software Design Flow](#) on page 216

### 7.3.5. Remote System Update Image Files Generation

To generate the RSU image files in SDM-based devices, you need the Quartus Prime Programming File Generator tool. For generic applications, you can generate the initial image using the `.sof` file. For security application, you need to generate the initial RSU image from the signed or encrypted `.rbf` file.

The next topic describes an example of applying the initial RSU image generation using `.sof` file. For more information on security application, refer to the following collaterals.

#### Related Information

- [Stratix 10 Configuration User Guide: Generating the Initial RSU Image](#)
- [Agilex 7 Configuration User Guide: Generating the Initial RSU Image](#)


#### 7.3.5.1. Generating Initial RSU Image Using SOF file

1. On the **File** menu, click **Programming File Generator**.
2. Select **Active Serial x4** from the **Configuration mode** drop-down list. The current Quartus Prime software only supports remote system update feature in **Active Serial x4**.
3. On the **Output Files** tab, assign the output directory and file name.
4. Select the output file type as **JTAG Indirect Configuration File (.jic)** with
  - a. **Memory Map File (.map)**
  - b. **Raw Programming File (.rpd)**

By default, the `.rpd` file type is little-endian. Set the **Bit swap** to **On** to generate the `.rpd` file in big endian format.


*Note:* If you are using a third-party programmer that does not support the little-endian format, set the **Bit swap** to **On**.

Figure 211. Programming File Generator (Output Files)



- On the **Input Files** tab, click **Add Bitstream**, select the factory.sof file and click **Open**. Repeat this step for the application-0.sof.

Figure 212. Programming File Generator (Input Files)



6. On the **Configuration Device** tab, click **Add Device**, select your flash memory and click **OK**. The Programming File Generator tool automatically populates the flash partitions.
7. Select the `FACTORY_IMAGE` partition and click **Edit**.
8. In the **Edit Partition** dialog box, select the `factory.sof` file in the **Input Files** drop-down list and click **OK**.


*Note:* You must assign **Page 0** to Factory Image. Altera recommends that you let the Quartus Prime software assign the Start address of the `FACTORY_IMAGE` automatically by retaining the default value for **Address Mode** which is **Auto**.

**Figure 213. Programming File Generator (Edit Partition)**



9. Select the flash memory and click **Add Partition**.
10. In the **Add Partition** dialog box, perform the following steps:
  - Define **Name** as **App-0**
  - Select the `application-0.sof` file from the **Input file** drop-down list
  - Assign **Page 1**
  - Assign **Address Mode** as **Start** with starting address at **0x01000000**.
11. If you are generating `.jic` files, click **Select** at the Flash loader, select your device family and device name, and click **OK**.

Figure 214. Programming File Generator (Configuration Device)




- Click **Generate** to generate the remote system update programming files. After generating the programming file, proceed to program the flash memory with the initial RSU image.

### 7.3.5.2. Generating an Application Update Image

- On the **File** menu, click **Programming File Generator**.
- Select **Active Serial x4** from the **Configuration mode** drop-down list. The current Quartus Prime software only supports remote system update feature in **Active Serial x4**.
- On the **Output Files** tab, assign the output directory and file name.
- Select the output file type as **Raw Programming File (.rpd)**.
- By default, the .rpd file type is little-endian. Set the **Bit swap** to **On**.  
*Note:* If you are using a third-party programmer that does not support the little-endian format, set the **Bit swap** to **On** to generate the .rpd file in big endian format.
- On the **Input Files** tab, click **Add Bitstream**. Then, select application update image .sof file (application-1.sof) file and click **Open**.



Figure 215. Programming File Generator (Input Files)



7. Click **Generate** to generate the remote system update programming files. You can now add or update the application image into the initial RSU image.

#### Example 10. Command to generate application image


```
quartus_pfg -c application-1.sof app_image.rpd -o mode=ASX4 -o bitswap=ON
```

#### 7.3.5.3. Generating a Factory Update Flash Image

1. On the **File** menu, click **Programming File Generator**.
2. Select **Active Serial x4** from the **Configuration mode** drop-down list. The current Quartus Prime software only supports remote system update feature in **Active Serial x4**.
3. On the **Output Files** tab, assign the output directory and file name.
4. Select the output file type as **Raw Programming File (.rpd)**.
5. By default, the .rpd file type is little-endian. Set the **Bit swap** to **On**.


*Note:* If you are using a third-party programmer that does not support the little-endian format, set the **Bit swap** to **On** to generate the .rpd file in big endian format.

Figure 216. Programming File Generator (Output Files)



- On the **Input Files** tab, click **Add Bitstream**. Change the **Files of type** to SRAM Object File (\*.sof). Then, select factory update image .sof file (application-2.sof) and click **Open**.

Figure 217. Programming File Generator (Input Files)



7. Select the application-2.sof and then click **Properties**. Turn on **Generate RSU factory update image**.

**Figure 218. Generate RSU Factory Update Image**



8. Click **Generate** to generate the RSU programming files. You can now update the decision firmware, decision firmware data, and the factory image into the initial RSU image.

**Example 11. Command to generate factory update image**

```
quartus_pfg -c application-2.sof factory_update.rpd -o mode=ASX4 -o bitswap=ON -o rsu_upgrade=ON
```

## 7.3.6. QSPI Flash Programming

### 7.3.6.1. Programming the Initial RSU Image

1. Ensure that the Altera FPGA device's Active Serial (AS) pin is routed to the QSPI flash. This routing allows the flash loader to load into the QSPI flash and configure the board correctly.
2. Ensure the MSEL pin setting on the board is configured for AS programming.
3. Open the **Intel Quartus Prime Programmer** and make sure JTAG is detected under the **Hardware Setup**.
4. Select **Auto Detect** and choose the FPGA device according to your board.

5. Right-click the selected Altera FPGA device and select **Edit ► Change File**. Next, select the initial RSU image JIC file.
6. Select the **Program/ Configure** check boxes for FPGA and QSPI devices.
7. Click **Start** to start programming.


### 7.3.6.2. Programming the Update Images

1. Ensure that the Altera FPGA device's Active Serial (AS) pin is routed to the QSPI flash. This routing allows the flash loader to load into the QSPI flash and configure the board correctly.
2. Ensure the MSEL pin setting on the board is configured for AS programming.
3. Open the **Intel Quartus Prime Configuration Debugger** and make sure JTAG is detected under the **Hardware Setup**.
4. Click **Load Device** and select the Altera FPGA device.
5. Navigate to the **Flash** tab.
6. Click **Auto-detect** to auto-detect the QSPI Flash that is attached to the device.
7. Navigate to the **Program** function. Assign **Image Start Address** and **RPD file path**.
  - For `app_image.rpd`, the **Image Start Address** is `0x3000000`.
  - For `factory_update.rpd`, the **Image Start Address** is `0x3800000`.
8. Click **Program RPD** to begin.

**Figure 219. Configuration Debugger - Flash**



Figure 220. Quad SPI Flash Address Map



Example 12. Memory Map File of Initial RSU JIC Image

BLOCK	START ADDRESS	END ADDRESS
BOOT_INFO	0x00000000	0x0010FFFF
FACTORY_IMAGE	0x00110000	0x0084FFFF (0x0080CFFF)
SPT0	0x00850000	0x00857FFF
SPT1	0x00858000	0x0085FFFF
CPB0	0x00860000	0x00867FFF
CPB1	0x00868000	0x0086FFFF
App-0	0x01000000	0x01432FFF

Configuration device: 1SX280LU2  
Configuration mode: Active Serial x4

### Related Information

AN 955: Programmer's Configuration Debugger Tool

## 7.3.7. Operating the RSU Client API

The RSU Client API performs the following operations:

- Trigger Intel FPGA device reconfiguration with selected image
- Update the application image
- Update the factory image

To display the Nios V processor application messages, the example design utilizes the JTAG UART Intel FPGA IP. You can begin the display message by using the following command:

```
juart-terminal
```

The JTAG UART terminal displays the RSU message logs, followed by the RSU Menu. While the factory image provides the full list of operations, the application images can support status log acquisition and reconfiguration operations only. The RSU Menu offers the following options:

1. Acquire RSU status log
2. Acquire Decision Firmware Status Log
3. Trigger reconfiguration with Factory Image
4. Trigger reconfiguration with Application Images
  - a. Application-0 Image
  - b. Application-1 Image
5. Add Application-1 Image
6. Update the Factory Image
7. Erase Decision Firmware

**Note:** For application image, the Menu options are only Options 1 to 4.

### 7.3.7.1. Trigger Reconfiguration Menu with Selected Image

The Trigger reconfiguration menu, Option 3 and 4 performs device reconfiguration with the factory and application images respectively. The following table shows the RSU status log after the device reconfiguration is successful.

**Table 59. Trigger Device Reconfiguration**

Options	RSU Status Log
Trigger reconfiguration with Factory Image	<b>Current Image : 0x00110000</b> Last Fail Image : 0x00000000 State : 0x00000000 Version : 0x00000202 Error location : 0x00000000 Error details : 0x00000000 Retry counter : 0x00000000 Running factory image: yes
Trigger reconfiguration with Application-0 Image	Current Image : 0x01000000 Last Fail Image : 0x00000000 State : 0x00000000 Version : 0x00000202 Error location : 0x00000000 Error details : 0x00000000 Retry counter : 0x00000000 Running factory image: no
Trigger reconfiguration with Application-1 Image (After performing Option 5.)	Current Image : 0x01800000 Last Fail Image : 0x00000000 State : 0x00000000 Version : 0x00000202 Error location : 0x00000000 Error details : 0x00000000 Retry counter : 0x00000000 Running factory image: no

### 7.3.7.2. Updating an Application Image

The Add Application-1 Image, Option 5 performs RSU Image update by adding Application-1 image into RSU slot 1, called **App-1**. It reads the Application-1 RPD image from the QSPI flash, starting from address 0x3000000. After the RPD image is

read successfully, the software proceeds to add and verify the configuration bitstream into **App-1** slot. Once the verification completes, you can proceed to trigger reconfiguration with Application-1 Image in the table *Trigger Device Reconfiguration*.

### Example 13. Application Image Update Log

```
Reading the Application-1 image based on RPD memory map....
Read Successfully.
Slot App-1 created at 0x1800000 with size = 0x460000 bytes.
Slot 1 is erased.
  NAME: App-1
  OFFSET: 0x0000000001800000
  SIZE: 0x00460000
  PRIORITY: [disabled]
Slot 1 was programmed with size=4587520.
Slot 1 was verified with size=4587520.
Add and Verify the image successfully in Slot 1

Please proceed with Option 4 - Trigger reconfiguration to Application Images.
And select Application-1 Image.
```

### 7.3.7.3. Updating the Factory Image

The Update the Factory Image menu, Option 6 performs RSU Image update by updating to a new factory image and decision firmware version. Before initiating Option 6, you are recommended to run Option 7 to erase the current decision firmware to show that a new decision firmware is updated along with the factory image.

The operation begin by reading the Factory Update RPD image from the QSPI flash, starting from address 0x3800000. After the RPD image is read successfully, the software proceeds to add and verify the configuration bitstream into a temporary **FactoryUpdate** slot. Once it is completed, power cycle the device.

**Note:** After the factory image is updated completely, the device automatically reconfigure to the application image with the highest priority.

**Table 60. Decision Firmware Status Log**

Erase Decision Firmware		Power Cycle	
Before	After	Before	After
DCMF0: OK	DCMF0: OK	DCMF0: OK	DCMF0: OK
<b>DCMF1: OK</b>	<b>DCMF1: Corrupted</b>	<b>DCMF1: Corrupted</b>	<b>DCMF1: OK</b>
<b>DCMF2: OK</b>	<b>DCMF2: Corrupted</b>	<b>DCMF2: Corrupted</b>	<b>DCMF2: OK</b>
<b>DCMF3: OK</b>	<b>DCMF3: Corrupted</b>	<b>DCMF3: Corrupted</b>	<b>DCMF3: OK</b>

### Example 14. Factory Image Update Log

```
Reading the Factory Update image based on RPD memory map....
Read Successfully.
Slot FactoryUpdate created at 0x2000000 with size = 0x460000 bytes.
Slot 2 is erased.
  NAME: FactoryUpdate
  OFFSET: 0x0000000002000000
  SIZE: 0x00460000
  PRIORITY: [disabled]
Slot 2 was programmed with size=4587520.
Slot 2 was verified with size=4587520.
Add and Verify the image successfully in Slot 2
```





Please power cycle the device to update the factory image.



## 8. Nios V Processor — Using Custom Instruction

---

### 8.1. Introduction

The Nios V/g processor supports custom instruction feature. This feature allows you to connect the processor to a custom processing engine (custom logic blocks). You can develop the processing engine to support the following functions:

- Enable unimplemented instruction in the Nios V Processor Instruction Set Architecture (ISA).
- Perform hardware acceleration on software algorithms.

Altera recommends you to understand custom instruction feature in Nios V processor by reading *AN 977: Nios V Processor Custom Instruction* before proceeding with the example design.

#### Related Information

[AN 977: Nios V Processor Custom Instruction](#)

For more information about custom instructions that allow you to customize the Nios® V processor to meet the needs of a particular application.

### 8.2. Unimplemented Instruction Example Design

You can refer to *Custom Instruction Design on Nios V/g Processor* in the Altera FPGA Design Store as a reference.

#### Related Information

[Agilex 7 FPGA - Custom Instruction Design on Nios® V/g Processor](#)

#### 8.2.1. Hardware and Software Requirements

You need the following hardware and software in order to apply a custom instruction on a Nios V/g processor.

- Quartus Prime Pro Edition software version 23.1 or later
- Ashling RiscFree for Altera FPGAs software version 23.1 or later  
*Note:* Altera recommends you install the same software version for all softwares.
- One of the supported Intel FPGA devices
  - The example design implemented on Agilex 7 F-Series FPGA development kit (DK-DEV-AGF014EA).
- Altera FPGA Download Cable II

You must connect your development board to a host PC on the USB/JTAG ports.

### Related Information

[Agilex 7 FPGA F-Series Development Kits](#)

## 8.2.2. Overview

You can download the Agilex 7 FPGA -Custom Instruction Design on Nios V/g Processor in the Altera FPGA Design Store. The example designs are based on the Agilex 7 F-Series FPGA Development Kit. Using the scripts, the hardware and software design are generated, and programmed as SRAM Object Files (.sof) and Executable and Linking Format (.elf) into the device. The example design connects two similar processing engines to a Nios V processor system. The processing engines contain custom bit manipulation operations. These operations are not natively supported in the Nios V processor ISA.

## 8.2.3. Acquiring the Example Design File

To generate the example design, perform the following steps:

1. Go to Altera FPGA Design Store.
2. Search for *Agilex 7 FPGA - Custom Instruction Design on Nios® V/g Processor*.
3. Click on the link at the title.
4. Accept the *Software License Agreement*.
5. Download the package according to the Quartus Prime software version of your host PC.
6. Refer to the `readme.txt` for the how-to guide.

**Table 61. Example Design File Description**

File	Description
custom_logic/	Contains the custom logic processing engines, which holds eight different operations.
hw/	Contains file necessary to run the hardware project.
ready_to_test/	Contains pre-built hardware and software binaries to run the design on the target hardware. This design is targeted on Agilex 7 F-Series FPGA Development Kit DK-DEV-AGF014EA.
scripts/	Consists of scripts to build the design.
sw/	Contains software application files.
readme.txt	Contains description and steps to apply the pre-built binaries or rebuild the binaries from scratch.

### Related Information

[Altera FPGA Design Store](#)

## 8.2.4. Hardware Design Files

The Agilex 7 FPGA -Custom Instruction Design on Nios V/g Processor is developed using the Platform Designer. You can generate the hardware files using the `build_sof.py` Python script.


The example design consists of:

- Nios V Processor Altera FPGA IP
- On-Chip Memory II Altera FPGA IP
- JTAG UART Altera FPGA IP
- Processing Engine 1 (PE1) – Declares `funct3` as user-defined intermediate (3'bxxx). All custom operations share a single software C-macro. You can select them using `funct3` input argument.
- Processing Engine 2 (PE2) – Defines `funct3` as extension index (3'b000 to 3'b111). Each operations have its own C-macros. You can call their respective C-macros.

The processing engine comprises of the following operations, which are selected based on the 3-bits `funct3` field.

- Operation 0: 1's complement of `Data0`
- Operation 1: 2's complement of `Data0`
- Operation 2: Multiply `Data0` with `Data1`
- Operation 3: Bit reversal of `Data0`
- Operation 4: Byte reversal of `Data0`
- Operation 5: Word reversal of `Data0`
- Operation 6: Lower word merge of `Data0` and `Data1`
- Operation 7: Higher word merge of `Data0` and `Data1`

**Figure 221. Example Design Block Diagram**



## 8.2.5. Software Design Files

You can find the application file(`custom_instr_app.c`) in the example design zip file. The software file is available in the `sw/app` folder. The source code begins the application by interfacing with PE1, followed by PE2. Within each processing engine, the source code calls all operations, and display the result through the JTAG UART IP into the host PC. The source code provides the same inputs (`data0` and `data1`) into the processing engines. Thus, both PE1 and PE2 return the same responses.

### Related Information

[Overview](#) on page 235

For more information about the example design.

## 8.2.6. Development Flow

### 8.2.6.1. Hardware Development Flow

You can create the example designs hardware system using the `build_sof.py` Python script. The scripts are stored in the `scripts` folder. You can refer to the `readme.txt` file to develop the example designs using the provided scripts, or develop the design manually using the Platform Designer and Nios V processor tools.

After launching the Nios V Command Shell, run the script using the following command :

```
$ quartus_py scripts/build_sof.py
```

### 8.2.6.2. Software Development Flow

Creating the example design software image for the custom instruction example design consist of the following general steps:

1. Creating a board support package (BSP) project with `niosv-bsp`.
2. Creating a Nios V processor application project with the provided software design files with `niosv-app`.
3. Building the application project with CMake and Make.

After launching the Nios V Command Shell, run the following commands.

```
$ niosv-bsp -c --quartus-project=hw/<Project Name>.qpf \  
--qsys=hw/<System Name>.qsys --type=hal sw/bsp/settings.bsp  
$ niosv-app --bsp-dir=sw/bsp --app-dir=sw/app \  
--srcs=sw/app/custom_instr_app.c  
$ cmake -S ./sw/app -G "Unix Makefiles" -B sw/app/build  
$ make -C sw/app/build
```

### 8.2.6.3. Device Programming

To program Nios V processor based system into the FPGA and to run your application, use Quartus Prime Programmer tool.

1. To create the Nios V processor inside the FPGA device, program the `.sof` file onto the board with the following command.

**Table 62. Command**

Operating System	Command
Windows	<code>quartus_pgm -c 1 -m JTAG -o p;&lt;SOF File&gt;@1</code>
Linux	<code>quartus_pgm -c 1 -m JTAG -o p\;&lt;SOF File&gt;@1</code>

*Note:*

- -c 1 is referring to cable number connected to the Host Computer.
- @1 is referring to device index on the JTAG Chain and may differ for your board.

2. Download the .elf using the niosv-download command.

```
niosv-download -g <elf file>
```

3. Use the JTAG UART terminal to print the stdout and stderr of the Nios V processor system.

```
juart-terminal
```

### 8.2.7. Operating the Example Design

To display the application messages, the example design utilizes the JTAG UART Intel FPGA IP. You can begin the display message by using the following command:

```
juart-terminal
```

Figure 222. Output Result from PE1

```
*****
PE1 operations
*****
1's complement of DATA1:0xff
Expected Output:ffffff00
Actual Output:ffffff00
*****
2's complement of DATA1:0xff
Expected Output:ffffff01
Actual Output:ffffff01
*****
Multiplication of DATA1:0x1f and DATA2:0x80
Expected Output:f80
Actual Output:f80
*****
Bit Reversal of DATA1:0x1f
Expected Output:f8000000
Actual Output:f8000000
*****
Byte Reversal of DATA1:0x1f
Expected Output:1f000000
Actual Output:1f000000
*****
Word Reversal of DATA1:0x1f
Expected Output:1f0000
Actual Output:1f0000
*****
Merge Lower-dword DATA1:0x74009078 and DATA2:0x82007083
Expected Output:90787083
Actual Output:90787083
*****
Merge Higher-dword of DATA1:0x74009078 and DATA2:0x82007083
Expected Output:74008200
Actual Output:74008200
End of PE1 operations
*****
*****
```

**Figure 223. Output Result from PE2**

```

*****
PE2 operations
*****
1's complement of DATA1:0xff
Expected Output:ffffff00
Actual Output:ffffff00
*****
2's complement of DATA1:0xff
Expected Output:ffffff01
Actual Output:ffffff01
*****
Multiplication of DATA1:0x1f and DATA2:0x80
Expected Output:f80
Actual Output:f80
*****
Bit Reversal of DATA1:0x111fff
Expected Output:fff88800
Actual Output:fff88800
*****
Byte Reversal of DATA1:0x111fff
Expected Output:ff1f1100
Actual Output:ff1f1100
*****
Word Reversal of DATA1:0x111fff
Expected Output:1fff0011
Actual Output:1fff0011
*****
Merge Lower-dword of DATA1:0x74009078 and DATA2:0x82007083
Expected Output:90787083
Actual Output:90787083
*****
Merge Higher-dword of DATA1:0x74009078 and DATA2:0x82007083
Expected Output:74008200
Actual Output:74008200
End of PE2 operations
*****

```

### 8.3. Hardware Acceleration Example Design

You can refer to *CRC Custom Instruction Design on Nios V/g processor* in *Altera FPGA Design Store* as a reference.

#### Related Information

[Agilex 7 FPGA - CRC Custom Instruction Design on Nios® V/g processor](#)



### 8.3.1. Hardware and Software Requirements

You need the following hardware and software to apply a custom instruction on a Nios V/g processor.

- Quartus Prime Pro Edition software version 23.1 or later.
- Ashling RiscFree for Altera FPGAs software version 23.1 or later.  
*Note:* Altera recommends you install the same software version for all softwares.
- One of the supported Altera FPGA devices:
  - The example design implemented on Agilex 7 F-Series FPGA development kit (DK-DEV-AGF014EA).
  - Altera FPGA Download Cable II

You must connect your development board to a host PC on the USB/JTAG ports.

#### Related Information

[Agilex 7 FPGA F-Series Development Kits](#)

### 8.3.2. Overview

You can download the *CRC Custom Instruction Design on Nios V/g processor* in the Altera FPGA Design Store. The example designs are based on the Agilex 7 F-Series FPGA Development Kit. Use the scripts to generate and program the hardware and software design as SRAM Object Files (`.sof`) and Executable and Linking Format (`.elf`) into the device.

The example design connects a custom logic CRC processing engine to a Nios V processor system. In the Nios V software application, the processor feeds the same checksum data into three CRC decoders (custom logic CRC processing engine, CRC software algorithm, and optimized CRC software algorithm). All three CRC decoders return the same CRC results, and the latency is compared among themselves.

### 8.3.3. Acquiring the Example Design File

To generate the example design, perform the following steps:

1. Go to Intel® FPGA Design Store.
2. Search for *CRC Custom Instruction Design on Nios® V/g processor*.
3. Click on the link at the title.
4. Accept the *Software License Agreement*.
5. Download the package according to the Quartus Prime software version of your host PC.
6. Refer to the `readme.txt` for the how-to guide.

**Table 63. Example Design File Description**

File	Description
custom_logic/	Contains the custom logic CRC processing engine.
hw/	Contains file necessary to run the hardware project.
continued...	

File	Description
ready_to_test/	Contains pre-built hardware and software binaries to run the design on the target hardware. For this package, the target hardware is Intel Agilex® 7 F-Series FPGA Development Kit DK-DEV-AGF014EA.
scripts/	Consists of scripts to build the design.
sw/	Contains software application files.
readme.txt	Contains description and steps to apply the pre-built binaries or rebuild the binaries from scratch.


### 8.3.4. Hardware Design Files

The *CRC Custom Instruction Design on Nios® V/g processor* is developed using the Platform Designer. You can generate the hardware files using the `build_sof.py` Python script.

The example design consists of:

- Nios V Processor Altera FPGA IP
- On-Chip Memory II Altera FPGA IP
- JTAG UART Altera FPGA IP
- CRC Processing Engine

**Figure 224. Example Design Block Diagram**



### 8.3.5. Software Design Files

You can find the following application files in the example design zip file. These software files are available in the `sw/app_crc/srcs` folder.

**Table 64. Software Design Files**

File	Description
ci_crc.c	Defines a macro to access the CRC processing engine.
ci_crc.h	Contains the function prototype for the macro.
crc.c	Defines macros for both software CRC and optimized software CRC algorithms.
crc.h	Contains the function prototypes for the software CRC application.
crc_main.c	Compute the checksum value using all CRC decoder.

The source code begins the application by computing the checksum value using all three CRC decoder and validating the CRC results. Once the CRC results are matched, the application reports the processing performance of the CRC decoder respectively.

## 8.3.6. Development Flow

### 8.3.6.1. Hardware Development Flow

You can create the example designs hardware system using the `build_sof.py` Python script. The scripts are stored in the `scripts` folder. You can refer to the `readme.txt` file to develop the example designs using the provided scripts, or develop the design manually using the Platform Designer and Nios V processor tools.

After launching the Nios V Command Shell, run the script using the following command :

```
$ quartus_py scripts/build_sof.py
```

### 8.3.6.2. Software Development Flow

Creating the example design software image for the custom instruction example design consist of the following general steps:

1. Creating a board support package (BSP) project with `niosv-bsp`.
2. Creating a Nios V processor application project with the provided software design files with `niosv-app`.
3. Building the application project with CMake and Make.

After launching the Nios V Command Shell, run the following commands.

```
$ niosv-bsp -c --quartus-project=hw/<Project Name>.qpf \
--qsys=hw/<System Name>.qsys --type=hal sw/bsp/settings.bsp
$ niosv-app --bsp-dir=sw/bsp_crc --app-dir=sw/app_crc \
--srcs=sw/app_crc/srcs/
$ cmake -S ./sw/app_crc -G "Unix Makefiles" -B sw/app_crc/build
$ make -C sw/app_crc/build
```

### 8.3.6.3. Device Programming

To program Nios V processor based system into the FPGA and to run your application, use Quartus Prime Programmer tool.

1. To create the Nios V processor inside the FPGA device, program the .sof file onto the board with the following command.

**Table 65. Command**

Operating System	Command
Windows	<code>quartus_pgm -c 1 -m JTAG -o p;&lt;SOF File&gt;@1</code>
Linux	<code>quartus_pgm -c 1 -m JTAG -o p\;&lt;SOF File&gt;@1</code>

**Note:**

- -c 1 is referring to cable number connected to the Host Computer.
- @1 is referring to device index on the JTAG Chain and may differ for your board.

2. Download the .elf using the niosv-download command.

```
niosv-download -g <elf file>
```

3. Use the JTAG UART terminal to print the stdout and stderr of the Nios V processor system.

```
juart-terminal
```

### 8.3.7. Operating the Example Design

To display the application messages, the example design utilizes the JTAG UART Altera FPGA IP. You can begin the display message by using the following command:

```
juart-terminal
```

Figure 225. Output Result from CRC Decoders

```

-----
Custom Instruction Name: Software and custom instruction "CRC"
-----

Sys PE specification
-----
Sys PE clock speed = 50 MHz
Number of buffer locations = 10
Size of buffer location = 256 bytes

Initializing all of the buffers with pseudo-random data
Initialization completed

Running the x f func "R"
-----
Completed

Running the optimized software JLL
Completed

Running the custom instruction "R"
-----
Completed

Validating the JLL results when all implementations
All CPU implementations produced the same results

Processing the following implementation
-----
Software "R" = 32 ns
Optimized software JLL = 35 ns
Custom instruction "R" = 33 ns

Processing throughput for each implementation
Software JLL = 49% Kbps
Optimized x f func "R" = 37% Kbps
Custom instruction JLL = 250% Kbps

Speedup ratio
-----
Custom instruction "R" vs x f func "R" = 77
Custom instruction JLL vs optimized software JLL = 25
Optimized x f func "R" vs x f func "R" =

```



## 9. Nios V Embedded Processor Design Handbook Archives

---

For the latest and previous versions of this user guide, refer to [Nios® V Embedded Processor Design Handbook](#). If an IP or software version is not listed, the user guide for the previous IP or software version applies.

IP versions are the same as the Quartus Prime Design Suite software versions up to v19.1. From Quartus Prime Design Suite software version 19.2 or later, IP cores have a new IP versioning scheme.

## 10. Document Revision History for the Nios V Embedded Processor Design Handbook

Document Version	Quartus Prime Version	Changes
2025.07.16	25.1	Corrected a typo in <i>Hardware Design Files</i> topic.
2025.05.22	25.1	<ul style="list-style-type: none"> <li>Updated the Nios V/m processor and Nios V/g processor figures to the latest version.</li> <li>Updated topic <i>Traps, Exceptions, and Interrupts Tab</i> to reflect the <b>Enable Core Level Interrupt Controller</b> feature.</li> <li>Reorganized and added the following topics to <i>Volatile Memory</i>: <ul style="list-style-type: none"> <li>On-Chip Memory Configuration – RAM or ROM</li> <li>Caches</li> <li>Peripheral Regions</li> <li>Tightly Coupled Memory</li> <li>External Memory Interface</li> </ul> </li> <li>Added the following topics: <ul style="list-style-type: none"> <li>Optimizing Platform Designer System Performance</li> <li>Ashling Visual Studio Code Extension for Altera FPGAs</li> </ul> </li> <li>Revised the steps in <i>Create the Bootloader via SDM Application Project</i> in topic <i>Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (Bootloader via SDM)</i>.</li> <li>Updated the following topics: <ul style="list-style-type: none"> <li>Debugging Nios V/c Processor</li> <li>Pilot System with Non-pipelined Nios V/m Processor</li> </ul> </li> <li><code>printf()</code> Debugging</li> </ul>
2025.01.27	24.3.1	<ul style="list-style-type: none"> <li>Updated table <i>Configuration Options Across Core Variants</i> to add Traps, Exceptions, and Interrupts for Nios V/m and Nios V/g processors.</li> <li>Updated the following topics for Nios V/g processor parameters: <ul style="list-style-type: none"> <li>Renamed topic <i>Vector Tab</i> to <i>Traps, Exceptions, and Interrupts Tab</i>.</li> <li><i>Memory Configurations Tab</i></li> <li><i>Custom Instruction Tab</i></li> <li><i>CPU Architecture</i></li> </ul> </li> <li>Updated the following figures to the latest user interface: <ul style="list-style-type: none"> <li>Nios V/m General Purpose Processor Intel FPGA IP - Part 1</li> <li>Nios V/g General Purpose Processor Intel FPGA IP - Part 1</li> </ul> </li> <li>Added new Supported Boot Memories to the table <i>Supported Flash Memories with Respective Boot Options</i>.</li> <li>Added flash controllers to the topic <i>Nios V Processor Application Execute-In-Place from Boot Flash</i>.</li> <li>Added the following new topics: <ul style="list-style-type: none"> <li>Nios V Processor Booting from On-Chip Flash (UFM).</li> <li>Nios V Processor Booting from General Purpose QSPI Flash.</li> <li>Reducing Nios V Processor Booting Time.</li> </ul> </li> </ul>
continued...		

Document Version	Quartus Prime Version	Changes
2024.11.25	24.3	<ul style="list-style-type: none"> <li>Updated table <i>Configuration Options Across Core Variants</i> to show CPU Architecture enabled for Nios V/c processor and Lockstep feature for Nios V/g processor</li> <li>Update the following figures with latest screenshot <ul style="list-style-type: none"> <li>Nios V/c Compact Microcontroller Intel FPGA IP</li> <li>Nios V/g General Purpose Processor Intel FPGA IP - Part 1</li> <li>Nios V/g General Purpose Processor Intel FPGA IP - Part 2</li> <li>Nios V/g General Purpose Processor Intel FPGA IP - Part 3</li> </ul> </li> <li>Added CPU Architecture to the topic <i>Instantiating Nios V/c Compact Microcontroller</i>.</li> <li>Updated table <i>CPU Architecture Tab Parameters</i> with Avalon Interface feature for Nios V/m and Nios V/g processors.</li> <li>Updated table <i>ECC Tab</i> for Nios V/g processor.</li> <li>Added new topic: <i>Lockstep Tab</i> for Nios V/g processor</li> </ul>
2024.07.08	24.2	<ul style="list-style-type: none"> <li>Removed the mention of <i>Eclipse CDT for Embedded C/C++ Developers</i> throughout the document.</li> <li>Replaced the mention of <i>SDM Bootloader</i> to <i>Bootloader via SDM</i>.</li> <li>Replaced the mention of <i>GSFI Bootloader</i> to <i>Bootloader via GSFI</i>.</li> <li>Added subtopics to the topic <i>Signal Tap Logic Analyzer</i>.</li> </ul>
2024.05.13	24.1	<ul style="list-style-type: none"> <li>Removed the topic <i>Nios V Processor Quick Start Guide</i>. Added a link to <i>AN 985: Nios V Processor Tutorial</i>.</li> <li>Updated the topics in <i>Instantiating Nios V/m Microcontroller</i> <ul style="list-style-type: none"> <li>Updated the figures in <i>Instantiating Nios V/m Microcontroller Intel FPGA IP</i>.</li> <li>Updated the table <i>CPU Architecture</i> with mhartid CSR value.</li> </ul> </li> <li>Updated the topics in <i>Instantiating Nios V/g Microcontroller</i> <ul style="list-style-type: none"> <li>Updated the figures in <i>Instantiating Nios V/g Microcontroller Intel FPGA IP</i>.</li> <li>Updated the table <i>CPU Architecture</i> with mhartid CSR value.</li> <li>Added new topics: <ul style="list-style-type: none"> <li>Caches</li> <li>Tightly Coupled Memory</li> <li>System Clock</li> <li>Reset Release IP</li> <li>Assigning a UART Agent for Printing</li> <li>Preventing Stalls by the JTAG UART</li> <li>JTAG Signals</li> </ul> </li> </ul> </li> <li>Updated the section <i>Nios V Processor Application Executes-in-place from TCM</i> <ul style="list-style-type: none"> <li>Updated the figures and steps in <i>Hardware Design Flow</i></li> <li>Added new steps in <i>Software Design Flow</i>.</li> </ul> </li> <li>Updated the topics in <i>Debugging Nios V/c Processor</i>: <ul style="list-style-type: none"> <li><i>Pilot System with Non-pipelined Nios V/m Processor</i></li> <li><i>printf() Debugging</i></li> <li>Added <ul style="list-style-type: none"> <li><i>Debugging Nios® V Processor Hardware Designs</i></li> <li><i>JTAG Server</i></li> <li><i>System Console</i></li> <li><i>JTAG to Avalon Host Bridge Core</i></li> <li><i>Signal Tap Logic Analyzer</i></li> <li><i>In-System Sources and Probes</i></li> <li><i>Ashling* RiscFree* IDE for Intel FPGA</i></li> </ul> </li> </ul> </li> <li>Updated the topics in <i>Nios V Processor — Remote System Update</i> <ul style="list-style-type: none"> <li>Updated the steps in <i>Configuring and Generating the BSP Project</i>.</li> <li>Updated the steps in <i>Creating Multiple Applications</i>.</li> </ul> </li> </ul>
continued...		



Document Version	Quartus Prime Version	Changes
2023.12.04	23.4	<ul style="list-style-type: none"> <li>Updated the note to refer to <i>AN 980: Nios V Processor Intel Quartus Prime Software Support</i> throughout the document.</li> <li>Updated the titles and figures in <i>Instantiating Nios V Processor Intel FPGA IP</i> for the following Nios V processor cores: <ul style="list-style-type: none"> <li>Nios V/c Compact Microcontroller Processor Altera FPGA IP</li> <li>Nios V/m Microcontroller Altera FPGA IP</li> <li>Nios V/g General Purpose Processor Altera FPGA IP</li> </ul> </li> <li>Updated the table: <i>CPU Architecture</i> to remove atomic extensions.</li> <li>Added the command for Quartus Prime Standard Edition version in the following topics: <ul style="list-style-type: none"> <li>Table: <i>GUI Tools and Command-line Tools Tasks Summary</i>.</li> <li>Topic: <i>Generating the Board Support Package in Creating Nios V Processor Software</i>.</li> </ul> </li> <li>Edited the title for <i>Example Design on Unimplemented Instruction (Custom Instruction Design on Nios® V/g processor)</i> to <i>Unimplemented Instruction Example Design</i>.</li> <li>Added topic <i>Hardware Acceleration Example Designs</i>.</li> </ul>
2023.10.02	23.3	<ul style="list-style-type: none"> <li>Added new topics based on new addition Nios V/c processor: <ul style="list-style-type: none"> <li><i>Nios V Processor Licensing</i></li> <li><i>Instantiating Nios V Processor IP Core</i></li> <li><i>Instantiating Nios V/c Processor Altera FPGA IP</i></li> <li><i>Instantiating Nios V/m Processor Altera FPGA IP</i></li> <li><i>Instantiating Nios V/g Processor Altera FPGA IP</i></li> <li><i>Debugging Nios V/c Processor</i></li> <li><i>Steps to Debug Nios V/c Processor</i></li> </ul> </li> <li>Updated <i>Nios V Processor Configuration and Booting Solutions</i> with TCM related in the following topics: <ul style="list-style-type: none"> <li><i>Nios V Processor Booting Methods</i></li> <li>Added <i>Nios V Processor Application Execute-In-Place from TCM</i></li> <li>Added <i>Nios V Processor Booting from Tightly Coupled Memory (TCM)</i></li> <li><i>Summary of Nios V Processor Vector Configuration and BSP Settings</i></li> </ul> </li> <li>Updated the mention of Nios V/m to Nios V in related topics with the release of Nios V/g and Nios V/c processors.</li> </ul>
continued...		

Document Version	Quartus Prime Version	Changes
2023.09.01	23.2	<ul style="list-style-type: none"> <li>Updated <i>Software Design Flow in Processor Application Executes-In-Place from Configuration QSPI Flash</i>: <ul style="list-style-type: none"> <li>Updated figures: <ul style="list-style-type: none"> <li><i>Linker Region Settings When Exceptions is set to OCRAM / External RAM</i>.</li> <li><i>Linker Region Settings When Exceptions is set to QSPI Flash</i>.</li> </ul> </li> <li>Added steps to disable gsfi driver.</li> </ul> </li> <li>Added new section: <i>Nios V Processor RSU Quick Start Guide in SDM-based Devices</i>.</li> <li>Updated figure <i>Nios V Processor System Design Flow</i> in the topic <i>Embedded System Design</i>.</li> </ul>
2023.05.26	23.1	<ul style="list-style-type: none"> <li>Added links to <i>AN 980: Nios V Processor Quartus Prime Software Support</i>.</li> <li>Added a new section: <i>Nios V Processor — Using Custom Instruction</i>.</li> </ul>
2023.04.10	23.1	<ul style="list-style-type: none"> <li>Added new topics: <ul style="list-style-type: none"> <li><i>Caches and Peripheral Regions Tab</i></li> <li><i>Custom Instruction Tab</i></li> </ul> </li> <li>Added table <i>GSFI Bootloader for Nios V Processor Core</i> in the topic <i>GSFI Bootloader</i>.</li> <li>Added a new step in the topic <i>Generating HEX File</i> from the section <i>Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (GSFI Bootloader)</i>.</li> <li>Updated product family name to "Intel Agilex® 7".</li> </ul>

Document Version	Quartus Prime Version	IP Version	Changes
2023.02.14	22.4	22.4.0	<ul style="list-style-type: none"> <li>Edited topic <i>Intel Quartus Prime Software Support</i>.</li> <li>Edited topic <i>Nios V/m Processor Example Design</i>.</li> <li>Added a note in the following topics to refer to the topic <i>Intel Quartus Prime Software Support</i> <ul style="list-style-type: none"> <li><i>Generating the Board Support Package using the BSP Editor GUI</i></li> <li><i>Nios V Board Support Package Editor</i></li> <li><i>Software Design Flow</i></li> <li><i>Creating a BSP project</i></li> </ul> </li> <li>Updated the following topics to align with the design store migration steps: <ul style="list-style-type: none"> <li><i>Generating the Application Project File</i></li> <li><i>GSFI Bootloader Example Design</i></li> <li><i>SDM Bootloader Example Design</i></li> <li><i>MicroC/TCP-IP Example Designs: Overview</i></li> <li><i>Acquiring the Example Design Files</i></li> <li><i>Creating an Application Project</i></li> <li><i>Device Programming</i></li> <li><i>Optional Configuration</i></li> </ul> </li> <li>Removed the following topics: <ul style="list-style-type: none"> <li><i>Generating the Example Design Through Graphical User Interface</i></li> <li><i>Generating the Nios V/m Processor Example Design Using the Command Line Interface</i></li> <li><i>Generate Nios V processor example design from Platform Designer</i></li> <li><i>HEX File Generation</i></li> </ul> </li> </ul>
2022.10.31	22.1std	1.0.0	<ul style="list-style-type: none"> <li>Updated references from <i>Intel Quartus Prime Pro Edition</i> to <i>Intel Quartus Prime</i> to indicate support for both Pro and Standard Edition.</li> <li>Added new topic: <i>Intel Quartus Prime Software Support</i>.</li> </ul>
2022.10.25	22.3	22.3.0	<ul style="list-style-type: none"> <li>Added new section: <i>Nios V Processor — Remote System Update</i>.</li> </ul>
2022.09.26	22.3	22.3.0	<ul style="list-style-type: none"> <li>Updated <i>Configure Nios V Processor Parameters</i> <ul style="list-style-type: none"> <li>Edited <i>Debug Tab</i></li> <li>Added <i>Use Reset Request Tab</i></li> <li>Edited <i>Vectors Tab</i>. Removed <i>Exception Agent</i> and <i>Exception Offset</i></li> </ul> </li> <li>Updated the following figures: <ul style="list-style-type: none"> <li><i>Nios V/m Processor IP instance in Platform Designer</i></li> <li><i>Example connection of Nios V processor with other peripherals in Platform Designer</i></li> <li><i>hal.linker Settings for QSPI Flash</i></li> <li><i>Connections for Nios V Processor Project</i></li> <li><i>hal.linker Settings</i></li> <li><i>Linker Region Settings</i></li> <li><i>hal.make Settings</i></li> <li><i>BSP Driver tab</i></li> </ul> </li> <li>Added <i>Enable Reset from Debug Module</i> to the following figures: <ul style="list-style-type: none"> <li><i>Parameter Editor Settings</i></li> <li><i>Nios V Parameter Editor Settings</i></li> </ul> </li> </ul>

continued...

Document Version	Quartus Prime Version	IP Version	Changes
			<ul style="list-style-type: none"> <li>Removed the mention of <i>exception vector</i>, <i>exception RAM</i>, <i>exception agent</i>, and <i>.exception</i> in the following topics: <ul style="list-style-type: none"> <li>— <i>Defining System Component Design</i></li> <li>— <i>Nios V Processor Design, Configuration and Boot Flow (Control Block-based Device)</i></li> <li>— <i>Reset Agent Settings for Nios V Processor Execute-In-Place Method</i></li> <li>— <i>Reset Agent Settings for Nios V Processor Boot-copier Method</i></li> <li>— <i>Nios V Processor Design, Configuration and Boot Flow (SDM-based Devices)</i></li> <li>— <i>Nios V Processor Application Copied from Configuration QSPI Flash to RAM Using Boot Copier (SDM Bootloader)</i></li> <li>— <i>Table: Description of Memory Organization</i></li> <li>— <i>Design, Configuration and Booting Flow in Nios V Processor Application Executes in-place from OCRAM</i></li> <li>— <i>Table: Summary of Nios V Processor Vector Configurations and BSP Settings</i></li> </ul> </li> <li>Edited <i>Configuring BSP Editor and Generating the BSP Project</i> in <i>Nios V Processor Design, Configuration and Boot Flow (Control Block-based Device)</i>.</li> <li>Added <i>Table: Settings for BSP Editor in Software Design Flow (SDM Bootloader Project)</i>.</li> </ul>
2022.08.12	22.2	21.3.0	<ul style="list-style-type: none"> <li>Edited the steps in <i>Programming Nios V/m into the FPGA Device</i>.</li> <li>Edited <i>Table: Debug Tab Parameter</i> to add the description for <i>dbg_reset</i>.</li> <li>Edited topic <i>On-Chip Memory Configuration - RAM or ROM</i> topic. Added a link to <i>Nios V Processor Application Execute-In-Place from OCRAM</i>.</li> </ul>
continued...			

Document Version	Quartus Prime Version	IP Version	Changes
			<ul style="list-style-type: none"> <li>Changed the topic title from <i>Clocks and Resets</i> to <i>Clocks and Resets Best Practices</i>.</li> <li>Added the following new topics: <ul style="list-style-type: none"> <li><i>Reset Request Interface</i></li> <li><i>Typical Use Cases</i></li> <li><i>Assigning a Default Agent</i></li> </ul> </li> <li>Added a note about configuring the RISC-V toolchain prefix in the topic <i>Eclipse CDT for Embedded C/C++ Developer</i>.</li> </ul>
2022.06.21	22.2	21.3.0	<ul style="list-style-type: none"> <li>Added the support for RiscFree IDE for Intel FPGAs.</li> <li>Removed the following topics: <ul style="list-style-type: none"> <li><i>Setting Up Open-Source Tools</i></li> <li><i>Building the Application Project using Eclipse Embedded CDT</i></li> <li><i>Building the Application Project using the Command-Line Interface</i></li> <li><i>Creating a Software Project using Platform Designer &amp; Eclipse Embedded CDT</i></li> <li><i>Creating a Software Project Using Command Line</i></li> </ul> </li> <li>Edited the Figure : <i>Software Design Flow</i> to include RiscFree IDE for Intel FPGAs</li> <li>Added the following topics: <ul style="list-style-type: none"> <li><i>Nios V Software Development Flow</i></li> <li><i>Board Support Package Project</i></li> <li><i>Application Project</i></li> <li><i>Intel FPGA Embedded Development Tools</i></li> <li><i>Nios V Board Support Package Editor</i></li> <li><i>RiscFree* IDE for Intel FPGA</i></li> <li><i>Eclipse* CDT for Embedded C/C++ Developer</i></li> <li><i>Nios V Utilities Tools</i></li> <li><i>File Format Conversion Tools</i></li> <li><i>Other Utilities Tools</i></li> <li><i>Generating the Board Support Package</i></li> <li><i>Generating the Application Project File</i></li> <li><i>Building the Application Project</i></li> </ul> </li> </ul>
2022.04.04	22.1	21.2.0	Initial release.