

Maintenance Manual

Parking Barrier

Date: June 2023

Doc Version: 1.0

English

Copyright © 2023 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTeco is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKTeco.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/equipment that personnel read, and followed the safety instructions contained in the manual.

In case of any conflict between the terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/documents shall apply in priority.

ZKTeco offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design or fitness for a particular purpose.

ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or

relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkteco.com>.

If there is any issue related to the product, please contact us.

ZKTeco Headquarters

Address ZKTeco Industrial Park, No. 32, Industrial Road,
Tangxia Town, Dongguan, China.

Phone +86 769 - 82109991

Fax +86 755 - 89602394

For business related queries, please write to us at: sales@zkteco.com.

To know more about our global branches, visit www.zkteco.com.

About the Company

ZKTeco is one of the world's largest manufacturers of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/Floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader door locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the maintenance of **Parking Barrier**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Table of Contents

1. MECHANICAL MOVEMENT PART MAINTENANCE	1
2. BALANCE BETWEEN BOOM ARM AND SPRINGS	2
3. CONNECTION BETWEEN MAIN BOARD AND MOTOR.....	3
4. SELF-CHECKING OF THE MACHINE.....	4
5. REMOTE CONTROL	4
6. MAIN BOARD OF THE PARKING BARRIER	5
7. WIND-RESISTANT INTENSITY CHECKING	6
8. SURFACE CLEANING	6
9. EQUIPMENT MAINTENANCE SCHEDULE	7

1. Mechanical Movement Part Maintenance

Inspect the mechanical movement of the parking barrier to ensure that the boom arm moves up and down smoothly and is in the correct position.




First, remove all the springs that balance the weight of the boom arm.

Using a straight screwdriver, twist here to unlock the motor movement, and then manually push the boom arm up to the vertical position.



If the boom arm can move up smoothly to the desired position, it indicates that both the mechanical moving part and the motor movement are functioning properly.

2. Balance Between Boom Arm and Springs




The spring is used to balance the weight of the boom arm when it moves down to the horizontal position. The quantity of springs required depends on the length and diameter of the boom arm.

Check if there is any cracking on the spring, try to replace it if so.

Check the balance between the boom arm and the spring. If the balance is appropriate, the boom arm should come to a stop at the 45-degree position.

If the boom arm shakes when it rises, you can adjust the spring loosely, and if the boom arm shakes when it falls, you can adjust the spring tightly.



- 1) When the barrier boom is at 45°, it is the best balance.
- 2) The spring wire diameter is adjusted according to different boom lengths:
 - A 3m boom requires a $\phi 4.5\text{mm}$ wire,
 - A 4.5m boom requires a $\phi 5.5\text{mm}$ wire, and
 - A 6m boom requires a $\phi 6.5\text{mm}$ wire.

Note: If the boom length is shorter than 2m, please do not install the spring.

3. Connection between Main Board and Motor


The motor is controlled by the DC 24V main board, and the connection is illustrated in the diagram shown below.



The wire connection should be firmly and well, if there is any loose on the wire connection, we need to reconnect it.

4. Self-checking of the Machine

When initially powering on the parking barrier, press the up button to raise the boom arm to the vertical position. Then, press the down button to lower it to the horizontal position. This process, known as 'self-checking,' enables the main board to track the entire movement process and determine the position of the boom arm.



Menu/Save: Menu options/Confirm and Save.

Stop/▼: Stop the boom arm /Flip down the parameter

Open/+: Increase parameter/value


Close/-: Decrease parameter/value

Once the self-checking process is complete, we can use the remote to control the movement of the boom arm.

5. Remote Control


After completing the self-check process, check if the remote control is functioning. If the remote is not working, maybe it ran out of power, we can observe if there is red light on when pressing the remote.

Also the remote receiver may be not connected to the main board, or it was broken, anyway, we can try to double check them.



6. Main Board of the Parking Barrier


The main board is supplied with 24V power. However, when we power it on, the main board does not work at all. To troubleshoot, we can measure the power input. If there is no power input or it measures below 20V, it indicates a potential issue with the power supply. In such a situation, it is advisable to replace the power supply.



If there is power input to the main board, it could indicate that the board has been burned. In such cases, we should check for any signs of burning on the electronic components of the main board. If any burned signs are found, we should investigate the cause and consider replacing the main board.

7. Wind-resistant Intensity Checking

When installing the parking barrier in an area where the wind is consistently strong and poses a risk of damaging the boom arm, consider two possible solutions: adding a boom bracket for additional support or opting for a round boom arm, which gives better resistance against such conditions.



8. Surface Cleaning

The parking barrier machine body should be cleaned monthly or weekly with a soft and wet cloth if water or dust remains on it, making the barrier not good-looking.

9. Equipment Maintenance Schedule

Number	Item	Schedule
1	Overall Cleaning: Rust	Half a year
2	Mechanical movement part	Half a year
3	Balance between boom arm and springs	Half a year
4	Connection between Mainboard and motor	Half a year
5	Mainboard	Half a year
6	Wind-resistant intensity checking	Half a year

ZKTeco Industrial Park, No. 32, Industrial Road,
Tangxia Town, Dongguan, China.

Phone : +86 769 - 82109991

Fax : +86 755 - 89602394

www.zkteco.com

