

SINGER^{*}

INSTRUCTIONS

Genie

Lightweight Portable Zig-Zag Sewing Machine Model 353

The **Cenre*** Portable Zig-Zag Sewing Machine by SINGER

Congratulations...

You are about to discover a wonderful world of sewing pleasure with your **Cenre** sewing machine. You will enjoy its lightweight portability and its many features —

- Plain zig-zag stitching for buttonholes, buttons, and stretch fabrics, as well as decorative needle work.
- Multi-stitch zig-zag stitching for mending, joining, and reinforcing without bulk.
- Blindstitching for overedged seams and almost invisible hems.
- Singer exclusive drop-in, front bobbin for quick, convenient bobbin removal and replacement.
- *Plus* the most-wanted accessories, including a zipper foot for corded seams and zippers, and ball-point needles for synthetic and stretch fabrics... all neatly stored in a handy pouch packed with the machine.

As you go through this book, you will discover how these and many other features enable you to sew beautifully and easily.

Enjoy sewing!

Form B 214

*A Trademark of THE SINGER COMPANY
Copyright 1972 by The Singer Company


Printed in France
S. N. Imp. Paul Dupont - CLICHY

CONTENTS


1. Getting to Know Your Sewing Machine	2	6. Sewing the Professional Way	30
Principal Parts	2	Hints on Sewing Special Fabrics	31
2. Getting Ready to Sew	4	Buttons and Buttonholes.....	35
Preliminary Steps	4	Darning.....	38
Choosing Needle and Thread	6	Zippers	39
Threading the Bobbin Case and Needle..	10, 11	Using the Plain Zig-Zag Stitch.....	41
3. Straight Stitching	13	Using the Multi-Stitch Zig-Zag	43
Adjusting Selectors	14	Using the Blindstitch	44
Sewing a Seam	16	7. Caring for Your Sewing Machine	45
4. Zig-Zag Stitching	20	Cleaning the Machine	45
Basic Zig-Zag Patterns	20	Removing Face Plate and Bobbin Case..	46
Adjusting Selectors	21	Changing Light Bulb	48
Satin Stitching	23	Replacing Slide Plate and End Cover.....	49
5. Accessories and When to Use Them	24	Performance Checklist	50
		<i>Fashion*</i> Aids	51
		Index	52

1 GETTING TO KNOW YOUR SEWING MACHINE


principal parts



- | | |
|-----------------------------------|-----------------------------------|
| 1. Bobbin-Winder
Tension Disc | 11. Reverse-Stitch
Push Button |
| 2. Take-up Lever | 12. Bobbin Winder |
| 3. Needle-Thread
Tension Discs | 13. Spool Pin |
| 4. Needle-Thread
Tension Dial | 14. Presser-Foot
Lifter |
| 5. Slide Plate | 15. Thread Cutter |
| 6. Stitch Width
Selector | 16. Presser Foot |
| 7. Needle Position
Selector | 17. Feed |
| 8. Stitch Pattern
Selector | 18. Bobbin |
| 9. Power & Light
Switch | 19. Needle Plate |
| 10. Stitch Length
Control | 20. Needle Clamp |
| | 21. Hand Wheel |
| | 22. Hand Wheel Disc |
| | 23. Pouch |
| | 24. End Cover |
| | 25. Threading
Chart |



2 GETTING READY TO SEW



preliminary steps

1. **CONNECTING THE MACHINE**

Before plugging in your machine, be sure that the electrical information indicated on the bottom of your machine conforms to your electrical power supply.

Push the machine plug into the receptacle at the right end of the machine. Then connect the power-line plug to your electrical outlet.


2. OPERATING MACHINE AND CONTROLLER

To turn on both machine and sewing light, press right side of power and light switch to ON position (red bar on switch will be visible). To turn off machine and light, press left side of switch to OFF position.

CAUTION: Turn off the power and light switch before changing needles, presser feet and needle plates and when leaving the machine unattended. This eliminates the possibility of starting the machine by accidentally pressing the speed controller.

To run the machine, press the speed controller. The harder you press, the faster the machine will sew.

To stop the machine from sewing, remove pressure from speed controller.



choosing needle and thread

The needle and thread you choose will depend upon the fabric being stitched. The table below is a practical guide to needle and thread


selection. Refer to it before starting a sewing project. Be sure to use the same size and type of thread in both needle and bobbin.

FABRIC, THREAD AND NEEDLE TABLE

FABRIC	THREAD	NEEDLES	
		TYPE	SIZE
DELICATE — tulle, chiffon, fine lace, organza	Fine mercerized cotton Fine synthetic thread	Style 2020 (15 × 1)	9
LIGHTWEIGHT — batiste, organdy, jersey, voile, taffeta, crepe, chiffon velvet, plastic film	50 mercerized cotton "A" silk Synthetic thread Cotton wrapped synthetic	Style 2020 (15 × 1)	11
MEDIUM WEIGHT — gingham, percale, pique, linen, chintz, faille, satin, fine corduroy, velvet, suitings, knits, deep-pile fabrics, vinyl	50 mercerized cotton 60 cotton "A" silk Synthetic thread Cotton wrapped synthetic	Style 2020 (15 × 1)	14


FABRIC	THREAD	NEEDLES	
		TYPE	SIZE
MEDIUM HEAVY — gabardine, tweed, sailcloth, denim, coatings, drapery fabrics, vinyl, deep-pile fabrics	Heavy-duty mercerized cotton 40 to 60 cotton Synthetic thread	Style 2020 (15 × 1)	16
HEAVY — overcoatings, dungaree, upholstery fabrics, canvas	Heavy-duty mercerized cotton 24 to 40 cotton Synthetic thread	Style 2020 (15 × 1)	18
ALL WEIGHTS — decorative straight stitch topstitching	"D" silk † (Buttonhole twist)	Style 2020 (15 × 1)	18
SYNTHETIC KNITS AND STRETCH FABRICS — polyester, doubleknit, spandex, nylon tricot, ciré tricot, jersey, panne velvet	"A" nylon 50 mercerized cotton "A" silk Cotton wrapped synthetic	Style 2045 Ball Point (Yellow Band)	14
LEATHER — suede, kidskin, capeskin, lambskin, lined leathers	50 mercerized cotton Synthetic thread "A" silk Cotton wrapped synthetic	Style 2032 (15 × 2)	11 14 16

† Use with 50 mercerized cotton or "A" silk in bobbin.




WINDING THE BOBBIN

- Press hand wheel disc at 
- Open slide plate just enough to make bobbin accessible, and lift out bobbin.
- Close slide plate.




Winding Steps

- Raise spool pin, break paper at end of spool if necessary, and place thread spool on pin. Lead thread around tension disc and through small hole in bobbin (from the inside).
- Place bobbin on holder and push bobbin to right (to engage bobbin winder).
- Hold thread as shown and start machine. Cut off thread end when winding is well under way.
- When required amount of thread has been wound (winding will stop by itself when bobbin is full), stop machine and cut connecting thread.
- Push bobbin toward left to disengage bobbin winder.
- Press hand wheel disc for sewing (see page 8).






THREADING THE BOBBIN CASE




- Hold bobbin so that thread unwinds as shown. Place bobbin in bobbin case.
- Pull thread into the notch, draw it under tension spring and back into slot.
- Draw about three inches of thread diagonally across the bobbin.
- Close slide plate, allowing thread to enter slot between slide and needle plate.

THREADING THE NEEDLE




Threading the Needle



- Turn hand wheel toward you to raise needle to its highest point and raise presser foot.
- Place thread spool on spool pin and lead thread through all threading points. Thread needle from *front* to *back*.
- Draw about three inches of thread through eye of needle.

RAISING THE BOBBIN THREAD

Now that you have threaded the machine, you will need to raise the bobbin thread through the needle hole in the needle plate. To do this :



- Hold needle thread lightly with left hand and turn hand wheel slowly toward you so that needle enters hole in needle plate.
- Continue turning hand wheel and holding needle thread until needle rises. Tighten your hold on the needle thread and bring up bobbin thread in a loop.
- Open the loop with your fingers.
- Place both needle and bobbin threads under presser foot and draw to back of machine.

... You are now ready to sew

3 STRAIGHT STITCHING

Pattern Selector: Any setting

Needle Position:  Center

Stitch Width: | Straight Stitch

Stitch Length: To suit fabric


General Purpose Needle Plate and Foot

Before you move the selectors to set your sewing machine for straight stitching, turn hand wheel toward you until needle is above the needle plate.


STARTING TO SEW

- Raise presser foot.
- Position needle in fabric where stitching is to start.
- Lower presser foot and start machine.

To sew perfectly on a wide variety of fabrics, adjust stitch length, and thread tension as instructed on the following pages.



adjusting selectors



ADJUSTING STITCH LENGTH

The stitch control lets you select the length of stitches. Numbers to left of the control represent the number of *straight* stitches per inch; the higher the number, the shorter the stitch. Generally, shorter stitches are

best for lightweight fabric; longer ones for heavy fabric. The FINE ▲ area is used for the adjustment of zig-zag satin stitching (see page 23).

SETTING STITCH LENGTH

- Position control so that indicator is aligned with stitch length number.
- To *shorten* the stitch, move control upward to a higher number.
- To *lengthen* the stitch, move control downward to a lower number.

For reverse stitching, press the reverse-stitch push button downward as far as it will go and hold in place (the button can be pushed in while the machine is sewing). Release pressure on the push button to return to forward stitching.

REGULATING NEEDLE-THREAD TENSION

Correct thread tension is important because too much or too little will weaken your seams or cause your fabric to pucker. Make a test sample with the fabric and thread you plan to use and examine it. A perfect stitch will have the needle and bobbin threads locked between the layers of fabric with no loops on top or bottom and no puckers.


The tension dial regulates the degree of tension on your needle thread. Set it according to type of thread and fabric you use. Numbers on dial eliminate guesswork in duplicating settings.

If stitches in your test sample look too loose, increase needle-thread tension. If the fabric puckers, decrease tension.


- To *increase* tension, turn dial to higher number.
- To *decrease* tension, turn dial to lower number.

PRESSER-FOOT PRESSURE

Presser-foot pressure has been preset for all your sewing.



sewing a seam




PIN BASTING

Pin basting is a time-saver and can be used when you sew easy-to-handle fabric. Use fine pins and place them:

- On top of the fabric (never on underside in contact with feed).
- At right angles to the stitching line.
- Just nipping into the fabric at stitching line.


STARTING A SEAM

- Set stitch length selector for desired number of stitches per inch.
- Align fabric with appropriate seam guideline (see page 17).
- Position needle in fabric about 1/2 inch from back edge.



- Backstitch to edge for reinforcement by pushing in reverse-stitch push button. Hold button until stitches reach edge of fabric, then release for forward stitching.

KEEPING THE SEAM STRAIGHT




The numbered lines on the needle plate are guides for keeping

seams straight. Numbers indicate distance, in 8ths of an inch, from the needle. If you want a $5/8$ -inch seam, for example, keep right-hand edge of fabric on number 5 guideline.


TURNING SQUARE CORNERS

To turn a square corner $5/8$ -inch from fabric edge, use the crosslines on the slide plate.

- Line up fabric with right or left guideline 5 on needle plate.
- Stitch seam, slowing speed as you approach corner.



- Stop stitching, *with needle down*, when bottom edge of fabric reaches cornering crosslines on slide plate.
- Raise presser foot and turn fabric on needle, bringing bottom edge of fabric in line with guideline 5.
- Lower foot and stitch in new direction.



GUIDING AND SUPPORTING FABRIC


Most fabrics need only to be *guided* in front of the presser foot. Some fabrics, however, require *support* while being stitched (see page 31).

CURVED SEAMS

Use a short stitch length for elasticity and strength. For example, if you use 12 stitches per inch for straight seams, select 15 to 20 per inch to stitch curved seams in the same fabric.

REINFORCING END OF SEAM

- Stitch to the fabric edge. Backstitch 1/2 inch to reinforce the end of the seam by pushing in the reverse-stitch push button and then releasing it.
- Turn hand wheel toward you to bring needle to its highest point.
- Raise presser foot and remove fabric by drawing it to the back and left.
- Cut threads on thread cutter at rear of presser bar.



4 ZIG-ZAG STITCHING

The basic zig-zag stitches built into your sewing machine, and the selector settings for obtaining these patterns are shown below.

basic zig-zag patterns



Plain Zig-Zag Stitch — Used for buttonholes, button sewing, bar tacks, and applique. It is especially useful for flexible seams in knit and stretch fabrics.




Blindstitch — Indispensable for finishing hems and seam edges, and for zipper insertion.



Multi-Stitch Zig-Zag Stitch—Lets you mend, join and reinforce without bulk.


TO SEW A ZIG-ZAG STITCH PATTERN

- Set pattern selector for stitch desired.
- Adjust stitch length, stitch placement, stitch width and needle-thread tension as instructed on following pages.




adjusting selectors


ADJUSTING WIDTH OF DESIGN



ADJUSTING STITCH PLACEMENT



ADJUSTING NEEDLE-THREAD TENSION




Before adjusting stitch width or needle position selectors, make sure needle is above fabric.

To produce a zig-zag stitch pattern, move selector to any setting to right of straight stitch setting.

Most zig-zag stitching will be done in center (L) needle position. Left (L) and right (L) settings are for special stitch placements, as shown above.

Zig-zag stitching requires less needle-thread tension than straight stitching. If stitches do not lie flat and fabric is puckered, lower tension by turning dial to a lower number.

ZIZ-ZAG STITCHING (Continued)



ADJUSTING STITCH LENGTH


Any stitch length setting from 6 to just below the "FINE" ▲ area will give you an open zig-zag stitch of the zig-zag pattern you select. The lower the number, the more open your stitches will be. The "FINE" stitch area is used for adjusting zig-zag satin stitching (see page 23).

PRESSER-FOOT PRESSURE

Presser-foot pressure has been preset for all your sewing (see page 15).

CHOOSING ACCESSORIES

Refer to pages 26 and 27, and to detailed instructions included in the section called "Sewing the Professional Way", beginning on page 30.



satin stitching

Satin stitching, a series of closely spaced zig-zag stitches, is useful for both utility and decorative work; for example, buttonholes, applique and bar tacks.

Make a test sample first so you can adjust stitch length and thread tension properly. Soft fabrics require a backing to ensure a firm stitch. Crisp organdy or lawn is suitable for this purpose.

SELECTOR SETTINGS AND ACCESSORIES


- Pattern Selector:  Plain Zig-Zag
- Needle Position:  Center
- Stitch Width:  to 
- Stitch Length:  (Fine Area)
- General Purpose Needle Plate and Special Purpose Foot

Adjusting Stitch Length


Gradually move stitch control upwards until stitches are closely spaced and form a smooth surface.

Adjusting Thread Tension


If fabric is puckered, lower needle-thread tension by turning tension dial to a lower number. The tension should be decreased as the stitch width is increased.




Adjusting Stitch Length
for Satin Stitching



5 ACCESSORIES




Transparent Bobbin
172336



Regular Needle
(Style # 2020)



Ball-Point Needle
(Style # 2045)



Changing the Needle

... and when to use them

The accessories that come with your *Genie* sewing machine are designed to help you do many kinds of sewing easily and perfectly. Additional accessories, listed on page 51 at the back of this instruction book, are available at your local Singer Sewing Center.

BOBBINS

Transparent, drop-in bobbin, # 172336, shows thread supply at a glance.

NEEDLES

Your machine is fitted with a style # 2020, size 14 needle for all-purpose sewing.

The needle pack supplied with your accessories contains:


- Style # 2020 needles, for all-purpose sewing.
- Style # 2045 ball-point (yellow band) needles, for sewing synthetic knits and stretch fabrics.

CHANGING THE NEEDLE


The needle clamp is designed so that the needle cannot be inserted backwards. To change the needle:

1. Raise needle bar to its highest position, loosen needle-clamp screw, and remove needle.
2. Insert new needle in clamp, *with the flat side of the needle to the back*; push it up as far as it will go.
3. Tighten needle-clamp screw.


ACCESSORIES (Continued)



General Purpose Foot and Needle Plate



Special Purpose Foot



Zipper Foot

GENERAL PURPOSE FOOT AND NEEDLE PLATE are in place on the machine. Use them for all utility sewing, with either straight or zig-zag stitching.

SPECIAL PURPOSE FOOT is used for all kinds of decorative zig-zag stitching. Use this foot for:

- Zig-zag satin stitching
- Applique
- Buttonholes


ZIPPER FOOT is used to place stitching close to a raised edge. It can be fitted to the presser-foot shank for use on either right or left side of the needle. Use it for:

- Corded seams
- Tubular cording
- Zipper insertion


CHANGING PRESSER FEET

The presser feet that are supplied with your machine snap on and off a common shank. To change the foot:

1. Raise needle to its highest position and raise the presser-foot lifter.
2. Press toe of presser foot upward (as far as it will go) and then snap down to remove the foot.
3. Center the new presser foot under the shank and lower the presser-foot lifter so that shank fits over the presser-foot pin.
4. Press down on presser-foot screw until foot snaps into place.



ACCESSORIES (Continued)




BLINDSTITCH HEM GUIDE is used with the general purpose foot to position the hem fold for blindstitch hemming (page 44). To attach, simply loosen presser-foot screw and slip guide between screw and presser-foot shank. Position guide so that it clears both slide plate and presser-foot toe. Tighten screw.

FEED-COVER NEEDLE PLATE replaces the general purpose needle plate when fabric feeding is *not* desired. Use it for button sewing (page 35) and free-motion darning (page 38).

CHANGING NEEDLE PLATES

1. Raise presser foot (you do not need to remove it).
2. Turn hand wheel toward you until needle is in its highest position.
3. Open slide plate with downward finger pressure. Draw plate toward you, opening it *all the way* to raise the locking pin that holds the needle plate in place.
4. Place thumb under right side of needle plate ; lift and withdraw plate to right.
5. Insert new needle plate under locking pin and over position pin.
6. Close slide plate to lower locking pin and secure the needle plate.



6 SEWING THE PROFESSIONAL WAY

sewing knit and stretch fabrics

When you sew stretch fabrics, doubleknit, tricot and jersey, choose one of the stitch patterns that sew stretch into the seam. The table below will help you make the right selection.

Remember to use a ball-point needle (Style # 2045) in the machine when you attach elastic or sew a synthetic knit or stretch fabric.

STRETCH STITCH CHART	
Stitch	Where to Use
 Plain Zig-Zag	All-purpose stretch sewing—Lingerie seams— Plain seams—Attaching stay tapes—Seam finishing— Edge finishing—Attaching stretch lace.
 Multi-Stitch Zig-Zag	Attaching elastic and stretch lace—Lingerie and swimsuit construction—Girdle seams— Seam finishes—Casings and waistband finishes.
 Blindstitch	Overedged stretch seams—Flexible blindstitch hemming—Overcast seam finishing—Shell hems in lingerie—Ladder seams.

hints on sewing special fabrics

GUIDING AND SUPPORTING FABRIC

Most fabrics of stretch and knit construction need only to be guided in *front* of the presser foot. Some fabrics, however, require support while being stitched.


- For nylon tricot, ciré, panné velvet, and similar synthetic knits, apply *gentle* tension by holding fabric taut in front *and* back of the presser foot as you sew.
- For elasticized fabric, stretch lace, and knits with an unusual amount of elasticity, apply *firm* tension in front *and* back of the foot to stretch the seam as the stitches are being placed.

LEATHER-LOOK VINYL

- Use masking tape or zipper adhesive tape instead of pins or basting to hold seams, zippers, and hems in place for stitching.
- Stitch with a long stitch (8 to 10 stitches per inch). A short stitch may cut the fabric.
- Sew with a steady, even pace and stitch accurately. Seams cannot be ripped out without leaving needle marks in the fabric.
- The shiny side of some vinyls tends to stick to metal surfaces. Use a strip of tissue paper between the fabric and metal machine surfaces to prevent this. Other remedies include dusting fabric with talcum powder or wiping it with a damp sponge.
- Reinforce button and buttonhole areas with interfacing. Bound buttonholes are the best choice for vinyls with knit backing.

LEATHER-LOOK VINYL (Continued)

- Topstitching holds seams and garment edges smooth and flat and adds a decorative note.



- For sharp points on collars and lapels, take one or two stitches diagonally across the point to allow enough space to smoothly enclose the seam edge.

CIRÉ (Wet-Look Taffeta and Tricot)

- Do not use pins in any area of the garment that will be visible when completed.
- Use masking tape or zipper adhesive tape instead of pins or basting to hold seams, zippers, and hems in place for stitching.
- Stitch accurately; seams cannot be ripped out because needle marks remain in fabric.
- Sew seams under gentle tension by holding fabric slightly taut at front and back of needle.
- Stitch ciré taffeta with a fairly long stitch (8 to 10 straight stitches per inch) and use an enclosed edge finish for seams and hems.
- Stitch ciré knits with a medium-length stitch (12 straight stitches per inch) and use a fine ball-point needle.

- Machine-worked buttonholes (as well as bound buttonholes) can be made in ciré fabric. Always use an interfacing and make sure the closed plain zig-zag stitches do not cut the fabric.

VELVET AND VELVETEEN

- Mark and baste with silk thread.
- Use a Style # 2020, size 11 needle, and a fine thread for seaming. "A" silk or nylon thread is recommended for velvet.
- Always stitch in the direction of the nap.
- Pin or hand-baste seams and sew under gentle tension by holding fabric slightly taut in front and back of needle. Extra-long

straight seams may be machine-basted with a long, wide, plain zig-zag stitch.

- To sew panné velvet, use a ball-point needle and a shorter-than-normal stitch length (12 to 15 straight stitches per inch).


DEEP-PILE FABRICS (Fake Fur)

- Pin, rather than baste, seams. Place pins at short intervals at right angles to the seam-line. Pins with colored heads are easier to see and remove.
- Sew in direction of nap.
- Stitch with a fairly long machine stitch (8 to 10 straight stitches per inch) and use cotton wrapped synthetic thread in a size 14 or 16, Style # 2020 needle.

DEEP-PILE FABRICS (Fake Fur) (Continued)

- As seam is stitched, smooth pile away from seam allowance with a darning needle or embroidery pin.
- After stitching seams with a 5/8-inch seam allowance, use small hand scissors to shear pile from entire seam allowance to reduce bulk.
- Stitch 1/4-inch pre-shrunk tape into neckline and shoulder seams for stability and reinforcement.
- Leather and leather-look fabrics complement fur fabrics. Use them for bound buttonholes and easy button loops.
- Coat hems are less bulky if narrow and finished with a three-inch fabric facing or grosgrain ribbon.
- Slash through the center fold of darts and

finger-press open, or stitch with a narrow, plain zig-zag stitch and trim away excess fabric after stitching.



buttons and buttonholes


BUTTONS

- Pattern Selector:  Plain Zig-Zag
 - Needle Position:  Left
 - Stitch Width: See below
 - Feed-Cover Needle Plate
 - Special Purpose or General Purpose Foot
-

Flat buttons can be sewn on by machine using the plain zig-zag stitch. Attach feed-cover plate and special purpose or general purpose foot. Set stitch width selector at  for straight stitching and needle position at  (left).

Place button under presser foot and lower needle into left hole. Lower foot. Turn hand wheel toward you until needle is above foot. Move stitch width selector to a medium-wide

zig-zag setting and continue to turn hand wheel until needle is above right hole in button. Increase or decrease stitch width setting to suit hole-spacing of button. Take six or more zig-zag stitches to attach button and end with needle on left side. Move stitch width selector to  and take a few stitches in left hole of button to fasten threads.



Button Sewing

For best results, Button Sewing Foot No. 161613 is recommended (see page 51).

BUTTONHOLES

- Pattern Selector:  Plain Zig-Zag
 - Needle Position:  Left
 - Stitch Width: See illustrations
 - Stitch Length: Above  (Fine Area)
 - General Purpose Needle Plate
 - Special Purpose Foot
-

Make a test buttonhole on a sample of your fabric. Be sure to duplicate the thickness of the garment and include interfacing if appropriate.

Stitch Width Settings

Use two stitch width settings: one for side stitching and one for bar tacks.

Buttonhole Length

The length of the opening depends on the diameter and thickness of the button. To find the right length, cut a small slit in a scrap of your fabric and gradually enlarge it until the button slips through easily. Add at least 1/8 inch (1/16 inch for each bar tack), and mark the fabric.

Procedure:

Place work under needle, aligning center marking of buttonhole with slot in the presser foot.


Side Stitching: Position needle in fabric at point **A**. Lower foot and stitch to end of marking. Leave needle in fabric at point **B**. Raise foot and pivot work on needle. Lower foot. Take one stitch without changing width setting, bringing work to point **C**.

Bar Tack: Adjust stitch width selector for bar tacks and take at least six stitches. Stop at point **D**.

Side Stitching: Readjust stitch width selector for side stitching. Complete work to point **E**. Leave needle in fabric.

Final Bar Tack: Adjust stitch width selector for bar tacks, and take at least six stitches ending at point **F**.


Fastening Stitch: To secure stitching, move stitch width selector to | and take three stitches. Remove work, draw threads to underside, fasten and trim. Cut opening for button with sharp scissors.



darning

Worn or torn spots on children's clothes, knits, and household linens can be darned quickly and easily with little practice.

-
- Stitch Width: | Straight Stitch
 - Needle Position: ⊥ Center
 - Stitch Length: ▲ (Fine Area)
 - Feed-Cover Needle Plate
 - No Presser Foot, Presser Bar Lowered
 - Moderate Machine Speed
-




1. Trim ragged edges from area to be darned, and center worn section in embroidery hoop.
2. Position work under needle over feed-cover plate; *lower presser bar to engage tension.*
3. Hold needle thread loosely with left hand, turn hand wheel over, and draw bobbin thread up through fabric. Hold both thread ends and lower needle into fabric.
4. Outline area to be darned with running stitches for reinforcement.
5. Stitch across opening, moving hoop under needle at slight angle from lower left to upper right. When opening is filled, cover area with crosswise lines of stitching.

This method of controlling fabric movement with an embroidery hoop may be used to do embroidery or monogramming with the zig-zag stitch.

NOTE: For extra control or darning *without* an embroidery hoop, the use of the Darning and Embroidery Foot is recommended. (See page 51).

zippers


At the notions counter in your Singer Sewing Center, you will find many different kinds of zippers, one of which will be just right for whatever you want to sew. The zipper package will contain easy-to-follow instructions for inserting the zipper. And, with the zipper foot, you will find it easy to form an even line of stitching close to the zipper. See instructions for attaching the zipper foot on the following page.




Zipper Insertion

CORDED SEAMS

The corded seam is a professional treatment for slipcovers, children's clothes, blouses and lingerie. To make a corded seam, make the welting first (or buy it ready-made at a notions counter), then stitch it into the seam. For both steps, use the zipper foot to place the stitching close to the cord.



Making the Welting



Attaching the Zipper Foot:

- Adjust stitch width selector to straight stitch position.

When the zipper is to the *right* of the needle:

- Move spacer on zipper foot to *left*, to allow shank to enter *right* side of foot, so that needle will enter *right* notch in foot.

When the zipper is to the *left* of the needle:

- Move spacer on zipper foot to *right*, to allow shank to enter *left* side of foot, so that needle will enter *left* notch in foot.

(The zipper foot is snapped on to shank as instructed on page 27).

using the plain zig-zag stitch


- Plain Stretch Seam

Stitch Width 

Needle Position 

Stitch Length 15-20

General Purpose Foot





- Lingerie Seam

Stitch Width : and 

Needle Position 

Stitch Length 20

General Purpose Foot



- Repairing Stretch Garments

Stitch Width  

Needle Position 

Stitch Length 15-20

General Purpose Foot



- Bar Tacks

Stitch Width 

Needle Position 

Stitch Length  FINE

General Purpose Foot



using the plain zig-zag stitch


- Blanket Binding

Stitch Width 

Needle Position 

Stitch Length 6-12

General Purpose Foot





- Applique

Stitch Width  and 

Needle Position 

Stitch Length  FINE

Special Purpose Foot



- Seam Finish

Stitch Width  

Needle Position 

Stitch Length 8-15

General Purpose Foot


- Monograms

Stitch Width   

Needle Position 

Stitch Length  FINE

Special Purpose Foot



using the multi-stitch zig-zag


- Attaching Elastic

Stitch Width  

Needle Position 

Stitch Length 20

General Purpose Foot




- Applying Facing Finish

Stitch Width 

Needle Position 

Stitch Length 8-20

General Purpose Foot




- Mending a Tear

Stitch Width  

Needle Position 

Stitch Length 20

General Purpose Foot




- Darts in Interfacing

Stitch Width 

Needle Position 

Stitch Length 20

General Purpose Foot



using the blindstitch


- Blindstitch Hem

Stitch Width   

Needle Position  or 

Stitch Length 10-15

General Purpose Foot





- Ladder Seam

Stitch Width   

Needle Position 

Stitch Length 10-15

General Purpose Foot




- Overedged Stretch Hem

Stitch Width 

Needle Position 

Stitch Length 8-20

General Purpose Foot



- Shell Edging

Stitch Width   

Needle Position 

Stitch Length 12-20

General Purpose Foot



7 CARING FOR YOUR SEWING MACHINE


cleaning the machine

Your machine will serve you perfectly for many years if you take a few moments of your time to keep it clean. How often you will need to clean the machine will depend on how often you use it.

CAUTION: *Before cleaning the machine, disconnect power-line plug from your electrical outlet.*

Remove lint or fluff from exposed parts. With a soft cloth, clean areas indicated in illustration at right.

- If there is excessive lint in the bobbin case area, remove bobbin case for cleaning. See page 47.
- To clean the machine surface, use a *mild* liquid dishwashing detergent in the same strength as used for dishes. Dry with damp cloth so that a thin film is left on the surfaces. *Do not use abrasive or solvent cleaners.*



Cleaning and Oiling the Machine

CLEANING THE MACHINE (Continued)

Remove face plate as instructed below and use a small brush to clean area behind face plate.

Remove needle plate (see page 29) and, using a small brush, clean area under needle plate and slide plate.


After cleaning, apply SINGER* oil at points indicated. SINGER oil is specially prepared and does not contain harmful deposits that can interfere with the smooth action of precision parts.

removing and replacing face plate


CAUTION: Before removing face plate, disconnect power-line plug from electrical outlet.

1. Loosen and remove screw **A**; remove face plate by sliding it downward.

2. Replace face plate by sliding top edge up under edge of top cover; replace and tighten screw **A**.




removing and replacing bobbin case



CAUTION: Before removing bobbin case disconnect power-line plug from electrical outlet.


1. Raise needle to its highest position.
2. Open slide plate all the way and remove needle plate as instructed on page 29.
3. Remove bobbin.
4. To remove bobbin case:
Turn bobbin case holder to back as far as it




will go. Lift out bobbin case.

5. To replace bobbin case:
Insert bobbin case with a back-and-forth motion so that the front of the case is under the position plate as illustrated. Turn holder all the way forward to lock bobbin case in position.
6. Replace needle plate and close slide plate.

changing light bulb



Unlock



Lock


This machine is designed to use a 15 watt light bulb.

Make sure you have disconnected power-line plug from electrical outlet.

Removing Bulb. With thumb of right hand push in and down on tab of light lens and lower the light bracket. *Do not attempt to unscrew the bulb.* Press it up into the socket

and at the same time turn bulb over in direction shown to unlock the bulb pins.


Replacing Bulb. Press new bulb into socket, with bulb pins entering slots of socket, and turn it over in direction shown to lock bulb in position. Push entire assembly up until it snaps in position.



replacing slide plate

Should the slide plate accidentally become disengaged, replace it as follows:

- Raise presser foot and make sure needle is in its highest position.
- With a small screwdriver, lift each end of spring into each of side grooves on underside of the plate. Draw plate gently toward you and fully engage the spring. Close plate.



replacing end cover

- Make sure presser-foot lifter is lowered.
- Slide end cover on machine with bottom edge of cover located on grooves of machine bed.
- Gently push cover toward right until both cover tabs enter slots provided in machine. Close hinged flap.

performance checklist

REMEMBER TO...

- Turn on power and light switch.
- Turn hand wheel toward you to position needle and take-up lever.
- Start and finish sewing with the take-up in its highest position.
- Test stitch on a fabric sample before starting a sewing job.
- Replace bent or burred needles.
- Use a Style # 2045 Ball-Point (yellow band) needle when sewing synthetic knits, spandex, or elastics.
- Make sure needle is out of fabric or above needle plate before adjusting selectors.

IF THREAD BREAKS...

- Is the machine properly threaded?
- Is the bobbin case properly inserted and threaded?
- Is the bobbin-case area free of lint and loose thread ends?
- Is the bobbin or bobbin case damaged?
- Is the needle straight and securely tightened in clamp?
- Is the thread suitable for size of needle?
- Is the thread free of uneven places and knots?
- Is the thread unwinding freely from spool?
- Is the needle-thread tension light enough?
- Is the needle plate, needle hole, or presser foot damaged?

Enjoy Sewing!

If you have any questions, please write to:
Department of Sewing Education
The Singer Company
30 Rockefeller Plaza, New York, N.Y. 10020

FASHION AIDS

special accessories for special jobs

The *Fashion Aids* listed below are designed to increase the versatility of your sewing machine. They are part of the complete

selection of accessories that is available at your local Singer Sewing Center.

- *Professional** Buttonholer No. 102878
- Deluxe Monogrammer..... No. 171278
- Even Feed Foot..... No. 507806
- Button Sewing Foot No. 161613
- Seam Guide No. 161172
- Straight Stitch Foot..... No. 153267
- Straight Stitch Needle Plate ... No. 171391
- Ruffler No. 86742
- Binder Foot..... No. 81245
- Hemmer Foot No. 161671
- Darning & Embroidery Foot No. 161876
- Gathering Foot No. 161659
- Edge Stitcher No. 36865

INDEX

	Page
Accessories.....	24
Applique	42
Blindstitch Hems	44
Bobbin	24
Raising Bobbin Thread	12
Winding	8, 9
Bobbin Case	
Removing and Replacing	47
Threading	10
Buttonholes	36
Buttons	35
Checklist.....	50
Cleaning	45
Darning	38
Elastic, Attaching	43
Electrical Speed Controller	4
Fabric, Thread and Needle Table.....	6
<i>Fashion Aids</i>	51
Guiding and Supporting Fabric	18, 31
Knit Fabrics Sewing.....	30
Light Bulb, Changing	48
Mending	43
Needle	24
Changing.....	24
Threading	11

	Page
Needle Plates	26, 28
Changing.....	29
Needle Position Selector	21
Oiling	45
Pin Basting	16
Power and Light Switch.....	5
Presser Foot Changing.....	27
Principal Parts	2
Reverse-Stitch Push Button	14
Satin Stitching	23
Seams, Sewing	16
Special Fabrics, Sewing.....	31
Special Purpose Foot	26
Stitch Length	14
Stitch Pattern Selector.....	20
Stitch Width Selector.....	21
Straight Stitching.....	13
Thread Tension, Adjusting	15, 23
Threading the Bobbin Case and Needle.....	10, 11
Zig-Zag Stitching.....	20
Needle Position	21
Satin Stitching	23
Stitch Pattern Selector	20
Stitch Length.....	22
Stitch Width	21
Zipper Foot	26, 40
Zippers	39

SINGER

GUARANTEE

WE GUARANTEE that each SINGER* sewing machine has been carefully manufactured and is in perfect operating condition on delivery. When subject to normal family use and care, any parts requiring replacement at any time owing to defects in material or workmanship will be replaced without charge.

THIS GUARANTEE does not apply to parts requiring replacement owing to natural wear or to abuse or negligence of the user or in the event the machine is serviced by other than a SINGER representative or Approved Dealer or with parts other than those supplied by The Singer Company.


IN ADDITION to the above guarantee of parts, each machine will be inspected and adjusted whenever necessary without charge for labor for a period of one year from date of purchase.

THIS GUARANTEE is effective only with respect to the person making the purchase from The Singer Company or one of its Approved Dealers. The original Sales Agreement, or Cash Receipt, must be presented to obtain the benefits of the guarantee.

AGREEMENTS inconsistent with the foregoing shall be void and of no effect.

THE SINGER COMPANY

A Trademark of THE SINGER COMPANY



For the
finest in
floor-care
products,
see the wide
selection
at your Singer
Sewing Center

Like all Singer products,
Singer vacuum cleaners
are built to high standards
of quality and will give you
long, dependable service.

