




# **HG-003 USER MANUAL**

**HYGGER Variable Frequency Quartz Aquarium Heater**





E-mail: [Mago@hygger-online.com](mailto:Mago@hygger-online.com)

HYGGER heater is the perfect aquarium heater for your freshwater or saltwater aquariums.

## ! **Attentions :**

1. Place the hygger heater fully submersible when it's working, and the maximum submersed depth is 80CM/31.5inch.
2. Unplug the heater and wait for 15 minutes before changing water or removing the heater.
3. Please make sure there is enough water flow and water circulation in your fish tank when using the heater .



4. **Reminder: The controller is not waterproof, please do not allow it to get wet.**

# 1. PRODUCT FEATURES

**Fully submersible and make sure enough water flow use:** The heater must be fully submerged to work properly and make sure fish tank has enough water flow or water recycle system in your fish tank.

**Rapid thermal accumulation:** The heating rod is made of explosion-proof quartz glass material and a high-temperature resistant nickel-chromium heating wire with silicon carbide heat conduction; this results in faster water heating and safer, more durable, long lasting heater. Double heating rod makes more powerful.

**LED digital temperature display:** LED digital display flash shows default setting is Fahrenheit for the current water temperature and long press 2 seconds to adjust the set temperature. Every accuracy changes the set temperature by 0.5°F.

The heater rod temperatures ranges from 54°F to 90°F.

**Precise temperature control and variable frequency energy saving:** Indicator light turns red and starts heating after the desired temperature is set. It turns to the green when the water temperature reaches the set temperature and stop heating. When the water temperature is 1°F lower than the desired temperature , the heater will automatically change to the blue indicator light for the variable frequency mode and enter to 50% power heating to save energy.

**Easy operation:** The external adjustable controller is easy to be set and operation. Connect to the socket and use directly. The clear LED display is easy to read and set.

**Auto power off and warning signals:** When the heating rod is exposed to air, the heater will shut off automatically and emit a warning signal. When the heating rod is completely immersed in water, it will start working again. It will abnormal alarm when it's over temperature.

## 2. PRODUCT PARAMETERS:

|                     |                              |                      |                        |
|---------------------|------------------------------|----------------------|------------------------|
| <b>Model No:</b>    | <b>HG-003</b>                |                      |                        |
| <b>Power:</b>       | 200W                         | 300W                 | 500W                   |
| <b>Voltage</b>      | 110V/60Hz    220V-240V /50Hz |                      |                        |
| <b>Cord length:</b> | 4.9 ft+4.9 ft/1.5 M +1.5 M   |                      |                        |
| <b>Application:</b> | 20-40Gal/<br>90~180L         | 30-60Gal<br>135~270L | 50-100Gal/<br>225~450L |

|                                   |                                                                             |                                      |
|-----------------------------------|-----------------------------------------------------------------------------|--------------------------------------|
| <b>Temp Accuracy:</b>             | $\pm 0.1^{\circ}\text{F} / \pm 0.1^{\circ}\text{C}$                         |                                      |
| <b>Control Range:</b>             | $54^{\circ}\text{F} \sim 90^{\circ}\text{F} / 12\text{-}32^{\circ}\text{C}$ |                                      |
| <b>Heating Rod Dimension:</b>     | 9.21x2.48x1.34 inch/<br>23.4x6.3x3.4 cm                                     | 12.36x2.87x1.5 inch/31.4x7.3x3.81 cm |
| <b>Temp Controller Dimension:</b> | 6.22x2.87x1.18 inch/15.8x7.3x3 cm                                           |                                      |


### 3.USE INSTRUCTION:

- Before plugging the appliance into the power, please install the appliance safely.
- Refer to the recommended tank and heater size chart to choose the most suitable heater for the desired temperature.
- Place the heater rod into the tank then plug into the power and the IC temperature controller will display the water temperature.

- Long press the “SET” button and the green light on the controller will be on, the digital temperature on the screen is flashing then you can set the desired temperature.
- Press the “SET” button or rotate the “SET” button until it reaches your desired temperature and the digital temperature will flash 3 times on the display. You can press the “SET” button to set between 54~90°F. Press one time can change 1°F and rotate one time can change 0.5°F. For example if you want to set to 82°F, press the "SET" button until the digital temperature on the screen is 82°F, the heater will heat the water to 81°F by 100% power. Then the heater transform to variable frequency mode, slow down to 50% power until reach 82°F.


**ATTENTION:** When digital temperature on controller is inconsistent with the fish tank water temperature. You can calibrate the controller as follow:

Long press the “SET” button and plug into the power together, hold down the “SET” button and don’t loose it meanwhile use the other hand to rotate the “SET” button until the digital temperature on controller reaches the same temperature in the tank.



Red Light: Fast Heat  
Blue Light: ECO  
Green Light: Standby

1. Long press the “SET” button 2 seconds, it can set temperature and recheck the setting.
2. Rotate the “SET” button turn left or right to change the temperature  $\pm 0.5^{\circ}\text{F}$ .



## 4.Trouble shooting

| Error Code                                                                                           | Failure cause                                                                                                                                          | Solution                                                                                                                                                                     |
|------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>LL</b>                                                                                            | Temperature sensor No.1is failure                                                                                                                      | Re-plug in. if it can' t restore<br>discard the heater                                                                                                                       |
| <b>HH</b>                                                                                            | Temperature sensorNo. 2 failure                                                                                                                        | Re-plug in. if it can' t restore<br>discard the heater                                                                                                                       |
| The heater rod display<br>E1 in the water                                                            | Out of water or sensor is error                                                                                                                        | Re-plug in. if it can't restore<br>discard the heater                                                                                                                        |
| <b>E2</b>                                                                                            | 1.Water recycle is not very well<br>or put the heater rod on wrong<br>position<br>2.Components failureod                                               | 1.Place the heating rod on a position<br>where the water circulation is well<br>2.Check the tank temperature is over<br>95°F or not. If is over 95°F ,discard<br>the heater. |
| E3 (Fish tank water<br>temperature is several<br>degree differences with<br>the desired temperature) | 1.Water recycle is not very well or put<br>the heater rod on wrong position.<br>2.Components failure<br>3. Default water temperature is<br>calibrated. | 1.Place the heating rod in a position<br>where the water circulation is well<br>2.Re-calibrate the water temperature.                                                        |
| <b>E4</b>                                                                                            | Flat power grid interference                                                                                                                           | Restart or return                                                                                                                                                            |

| Phenomenon                                                                    | Explanation                                                        | Solutions                                                                                                                                          |
|-------------------------------------------------------------------------------|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| The heater rod is not display E1, when it out of water                        | No warning sound when its out of water                             | Remove the cover and clean the heater.<br>If it still don't work ,please return.                                                                   |
| No display on LED screen                                                      | PCB failure                                                        | Re-plug in. if it can't restore<br>discard the heater                                                                                              |
| ED display shown<br>temperature tolerance<br>$\pm 1^{\circ}\text{F}$ or above | 1.Water recycle is not very well<br>2.Aquarium thermometer failure | 1.Place the heating rod in a position<br>where the water circulation is well<br>2.Use another thermometer<br>3.Re-calibrate the water temperature. |
| White or yellow dirt<br>adheres                                               | Incrustation scale                                                 | Wash the heater in clean water                                                                                                                     |

## 5.PACKAGE INCLUDED

1×Double quartz heater with LED digital controller

4× Suction cup



1× User manual

## 6. APPLICATION

A. Place the heater as shown in the following diagram:

B. Digital display models

1. Out of water: The heating rod is out of water (at least 8mm/ 0.03inches) and displays the fault code “E01”; the heater will make the warning sound.



**7.WARNING:** To guard against injury, basic safety precautions should be observed including the following:

1.Read and follow this user manual strictly.

2.DANGER-To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, do not attempt to repair yourself; return the heater to an authorized service facility for service or discard the heater.

- A.If the heater shows any sign of abnormal operation, unplug the power and remove the heater from water after 15 minutes.
- B.Carefully examine the heater after installation. It should not be plugged in if there is water on parts not intended to be wet.
- C.Do not operate the heater if it has a damaged cord or plug, if it is malfunctioning, or if it is dropped or damaged in any manner. The power cord of this heater cannot be replaced; if the cord is damaged, the heater should be discarded.

- D. To avoid the possibility of the heater plug getting wet, position aquarium stand and tank to one side of a wall mounted outlet to prevent water from dripping onto the outlet or plug. A “drip loop”, shown in the figure below, should be arranged by the user for each cord connecting the heater to the outlet. The “drip loop” is the part of the cord below the level of the outlet, or the connector. If an extension cord is used, to prevent water traveling along the cord and coming in contact with the outlet. If the plug or outlet does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the heater. Then unplug and examine for the presence of water in the outlet.
3. Close supervision is necessary when the heater is used near children. Daily supervision is necessary when the heater is being used.
4. This heater is not allowed to use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the heater by a person responsible for their safety.
5. To avoid injury, do not contact moving parts or hot parts.

6. Always unplug the heater from the outlet when not in use, before putting on or taking off parts, before maintenance, or placing hands in the water. Never yank the cord to pull plug from outlet. Grasp the plug and pull gently to disconnect.
7. Do not use the heater for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition and will void the warranty.
8. Do not install or store the heater where it will be exposed to the weather or to temperatures below freezing.
9. Only use in freshwater or saltwater aquariums; do not use the heater in other liquids.
10. Make sure the heater is securely installed before operating it.
11. Read and observe all the important notices on the heater.
12. If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the heater rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
13. The heater is intended FOR HOUSEHOLD USE ONLY.
14. SAVE THIS USER MANUAL.

## 8.ATTENTIONS

- ✓ Please check all the items to inspect condition when unboxing the package.
- ✓ Please read the instructions carefully. Use and follow the instructions strictly.
- ✓ Please choose a heater rated for your aquarium.
- ✓ Please place the heating rod in water flow and don't bury it in substrate.
- ✓ Please place the heating rod fully submersed in water when it's on duty.  
Unplug the heater and wait for 15 minutes before changing water or removing the heater.
- ✓ Please keep in mind that the heater can be turned off automatically when exposed to air, but it is a last resort and should be avoided.
- ✓ After using of the heater, calcium carbonate contained in algae or moss may clump and adhere to the heating rod.
- ✓ If dirt adheres to the heating rod, use a sponge or cloth and water to wipe it.  
Do not use alcohol or other chemicals as this may damage the heater harm fish or livestock.
- ✓ When used for a prolonged period with dirt adhered to the heating element, be aware that it may cause failure due to the inability to control the temperature correctly.

## 9.DISPOSAL

Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary. This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for recycling of electrical and electronic appliances. By collecting and recycling waste, you help save natural resources, and make sure the product is disposed in an environmentally friendly way.



## 10.WARRANTY:

1. 1-year free warranty.
2. 1-month free return.
3. Free replacement for 3 months.
4. Contact information:

Website: [www.hygger-online.com](http://www.hygger-online.com)

E-mail: [Mago@hygger-online.com](mailto:Mago@hygger-online.com)





Puhui Import und Export GmbH  
Birnbauismühle 65 Frankfurt(Oder) 15234  
Briefkasten: admin@puhui-jk.de  
Telefonnummer: +03381-2697990



CET PRODUCT SERVICE LTD.  
Chase Business Centre, 39-41 Chase Side,  
London N14 5BP United Kingdom  
info.cetservice@gmail.com  
TEL:+447419325266