

MULTILINGUAL DIAGNOSTIC SCANNER

Item Number W2976

OWNER'S MANUAL



⚠WARNING

It is the owner and/or operators' responsibility to study all WARNINGS, operating, and maintenance instructions contained on the product label and instruction manual prior to operation of this product. The owner/operator shall retain product instructions for future reference.

The owner and/or operator are responsible for maintenance, maintaining all decals or warning labels and while in use, maintaining the unit in good working order. If the owner and/or operator are not fluent in English, the product warnings and instructions shall be read and discussed with the operators' native language by the purchaser/owner or his designee. Make sure that the operator comprehends its contents. Safety information shall be emphasized and understood prior to usage. The product shall be inspected per the operating instructions.

Users of this product must fully understand these instructions. Each person operating this product must also be of sound mind and body and must not be under the influence of any substance that might impair their vision, dexterity or judgment.

Protect yourself and others by observing all safety information.

Failure to comply with instructions could result in personal injury and/or property damage!

If you encounter any problems or difficulties, please contact our customer service department at: 1-800-426-1262 between 6:30 a.m. and 4:30 p.m. Pacific time.

PT
Performance Tool

Please read these instructions carefully and retain them for future use.

Performance Tool®

TABLE OF CONTENTS

Product Specifications.....	2
Safety Precautions and Warnings.....	3
Product Features	3
General Information	4
On-Board-Diagnostics (OBD) II	4
Diagnostic Trouble Codes (DTCs)	4
Location of the Data Link Connector (DLC).....	5
OBD II Readiness Monitors	5
OBD II Monitor Readiness Status	6
OBD II Terminology	7
Product Information	8
Tool Description.....	8
Vehicle Coverage	10
Operating Instructions.....	11
Reading Codes	11
Erasing Codes	14
Retrieving I/M Readiness Status.....	15
Viewing VIN Number.....	17
Rescanning Data	18
Diagnostic Trouble Code (DTC) Definitions.....	19
Limited One Year Warranty.....	48

Product Specifications

- Display: Backlit, 128 x 64 pixel display
- Operating Temperature: 32 to 140 F° (0 to 60°C)
- Storage Temperature: -4 to 158 F°(-20 to 70°C)
- Power: 8 to 18 Volts provided via vehicle battery
- Dimensions: Length/Width/Height 4.34"(110.3 mm) 2.74" (69.5 mm) 0.80"(20.2 mm)
- Weight: 0.46lb (0.21Kg)

SAFETY PRECAUTIONS AND WARNINGS

To prevent personal injury or damage to vehicles and/or the Scan Tool, read this instruction manual first and observe the following safety precautions at a minimum whenever working on a vehicle:

- Always perform automotive testing in a safe environment.
- Wear safety eye protection that meets ANSI standards.
- Keep clothing, hair, hands, tools, test equipment, etc., away from all moving or hot engine parts.
- Operate the vehicle in a well-ventilated work area; Exhaust gases are poisonous.
- Put blocks on drive wheels and never leave vehicle unattended while running tests.
- Use extreme caution when working around the ignition coil, distributor cap, ignition wires and spark plugs. These components create hazardous voltages when the engine is running.
- Put transmission in PARK (for automatic transmission) or NEUTRAL (for manual transmission) and make sure the parking brake is engaged.
- Keep a fire extinguisher suitable for gasoline/chemical/electrical fires nearby.
- Don't connect or disconnect any test equipment with ignition on or engine running.
- Keep the Scan Tool dry, clean and free from oil, water and grease. Use a mild detergent on a clean cloth to clean the outside of the Scan Tool, when necessary.

Product Features

- Works with most 1996 and newer cars & light trucks that are OBD II compliant (including the CAN, VPW, PWM, ISO and KWP 2000 protocols).
- Reads and clears generic and manufacturer specific Diagnostic Trouble Codes (DTCs) and turns off check engine light
- Supports multiple trouble code requests: generic codes, pending codes and manufacturer's specific codes
- Reviews the emission readiness status of OBD monitors
- Retrieves VIN (Vehicle Identification No.) on 2002 and newer vehicles that support Mode 9
- Determines the malfunction indicator lamp (MIL) status
- Easy to use with one plug-in; Highly reliable and accurate
- Easy-to-read crystal-clear backlit 2-line LCD display
- Stand-alone unit with no need for an additional laptop computer to operate
- Small in size and conveniently fits in your palm
- Safely communicates with the on-board computer
- No batteries needed--powered via detachable OBD II cable

GENERAL INFORMATION

On-Board-Diagnostics (OBD) II

The OBD II system is designed to monitor emission control systems and key engine components by performing either continuous or periodic tests of specific components and vehicle conditions. When a problem is detected, the OBD II system turns on a warning lamp (MIL) on the vehicle instrument panel to alert the driver typically by the phrase of “Check Engine” or “Service Engine Soon”. The system will also store important information about the detected malfunction so that a technician can accurately find and fix the problem. Here below follow three pieces of such valuable information:

- Whether the Malfunction Indicator Light (MIL) is commanded ‘on’ or ‘off’;
- Which, if any, Diagnostic Trouble Codes (DTCs) are stored;
- Readiness Monitor Status.

Diagnostic Trouble Codes (DTCs)

OBD II Diagnostic Trouble Codes are codes that are stored by the on-board computer diagnostic system in response to a problem found in the vehicle. These codes identify a particular problem area and are intended to provide you with a guide as to where a fault might be occurring within a vehicle. OBD II Diagnostic Trouble Codes consist of a five-digit alphanumeric code. The first character, a letter, identifies the control system which sets the code. The other four characters, all numbers, provide additional information on where the DTC originated and the operating conditions that caused it to set. On the next page is an example to illustrate the structure of the digits.

Location of the Data Link Connector (DLC)

The DLC (Data Link Connector or Diagnostic Link Connector) is the standardized 16-cavity connector where diagnostic scan tools interface with the vehicle’s on-board computer. The DLC is usually located 12 inches from the center of the instrument panel (dash), under or around the driver’s side for most vehicles. For some Asian and European vehicles, the DLC is located behind the ashtray and the ashtray must be removed to access the connector. Refer to the vehicle’s service manual for the location if the DLC cannot be found.

**DTC EXAMPLE
P0202**

Systems

B = Body
C = Chassis
P = Powertrain
U = Network

Code Type

0 = Generic
1 = Manufacturer
Specific

Sub-Systems

1 = Fuel & Air Metering
2 = Fuel & Air Metering
3 = Ignition System or
Engine Misfire
4 = Auxiliary Emissions Controls
5 = Vehicle Speed Control
& Idle Controls
6 = Computer Output Circuits
7 = Transmission Controls
8 = Transmission Controls

Identifying
specific
malfunctioning
section of the
systems

OBD II Readiness Monitors

An important part of a vehicle's OBDII system is the Readiness monitors, which are indicators used to find out if all of the emissions components have been evaluated by the OBD II system. They are running periodic tests on specific systems and components to ensure that they are performing within allowable limits.

Currently, there are eleven OBD II Readiness Monitors (or I/M Monitors) defined by the U.S. Environmental Protection Agency (EPA). Not all monitors are supported by all vehicles and the exact number of monitors in any vehicle depends on the motor vehicle manufacturer's emissions control strategy.

Continuous Monitors - Some of the vehicle components or systems are continuously tested by the vehicle's OBDII system, while others are tested only under specific vehicle operating conditions. The continuously monitored components listed below are always ready:

1. Misfire
2. Fuel System
3. Comprehensive Components (CCM)

Once the vehicle is running, the OBDII system is continuously checking the above components, monitoring key engine sensors, watching for engine misfire, and monitoring fuel demands. Non--Continuous Monitors -- Unlike the continuous monitors, many emissions and engine system components require the vehicle to be operated under specific conditions before the monitor is ready. These monitors are termed non-continuous monitors and are listed below:

- | | |
|-----------------------|---------------------|
| 1. EGR System | 5. O2 Sensor Heater |
| 2. O2 Sensors | 6. Secondary air |
| 3. Catalyst | 7. Heated Catalyst |
| 4. Evaporative System | 8. A/C system |

OBD II Monitor Readiness Status

OBDII systems must indicate whether or not the vehicle's PCM's monitor system has completed testing on each component. Components that have been tested will be reported as "Ready", or "Complete", meaning they have been tested by the OBDII system. The purpose of recording readiness status is to allow inspectors to determine if the vehicle's OBDII system has tested all the components and/or systems.

The powertrain control module (PCM) sets a monitor to "Ready" or "Complete" after an appropriate drive cycle has been performed. The drive cycle that enables a monitor and sets readiness codes to "ready" varies for each individual monitor. Once a monitor is set as "Ready" or "Complete", it will remain in this state. A number of factors, including erasing of diagnostic trouble codes (DTCs) with a scan tool or a disconnected battery, can result in Readiness Monitors being set to "not ready". Since the three continuous monitors are constantly evaluating, they will be reported as "Ready" all of the time. If testing of a particular supported non-continuous monitor has not been completed, the monitor status will be reported as "Not Complete" or "Not Ready."

In order for the OBD monitor system to become ready, the vehicle should be driven under a variety of normal operating conditions. These operating conditions may include a mix of highway driving and stop and go, city type driving, and at least one overnight-off period. For specific information on getting your vehicle's OBD monitor system ready, please consult your vehicle owner's manual.

OBD II Terminology

Powertrain Control Module (PCM) - OBDII terminology for the on-board computer that controls engine and drive train.

Malfunction Indicator Light (MIL) - Malfunction Indicator Light (Service Engine Soon, Check Engine) is a term used for the light on the instrument panel. It is to alert the driver and/or the repair technician that there is a problem with one or more of vehicle's systems and may cause emissions to exceed federal standards. If the MIL illuminates with a steady light, it indicates that a problem has been detected and the vehicle should be serviced as soon as possible. Under certain conditions, the dashboard light will blink or flash. This indicates a severe problem and flashing is intended to discourage vehicle operation. The vehicle onboard diagnostic system can not turn the MIL off until the necessary repairs are completed or the condition no longer exists.

DTC - Diagnostic Trouble Codes (DTC) that identifies which section of the emission control system has malfunctioned.

Enabling Criteria - Also termed Enabling Conditions. They are the vehicle-specific events or conditions that must occur within the engine before the various monitors will set, or run. Some monitors require the vehicle to follow a prescribed "drive cycle" routine as part of the enabling criteria. Drive cycles vary among vehicles and for each monitor in any particular vehicle.

OBDII Drive Cycle-- A specific mode of vehicle operation that provides conditions required to set all the readiness monitors applicable to the vehicle to the "Ready" condition. The purpose of completing an OBD II drive cycle is to force the vehicle to run its onboard diagnostics. Some form of a drive cycle needs to be performed after DTCs have been erased from the PCM's memory or after the battery has been disconnected. Running through a vehicle's complete drive cycle will "set" the readiness monitors so that future faults can be detected. Drive cycles vary depending on the vehicle and the monitor that needs to be reset. For vehicle specific drive cycle, consult the vehicle's Owner's Manual.

Freeze Frame Data - When an emissions related fault occurs, the OBD II system not only sets a code but also records a snapshot of the vehicle operating parameters to help in identifying the problem. This set of values is referred to as Freeze Frame Data and may include important engine parameters such as engine RPM, vehicle speed, air flow, engine load, fuel pressure, fuel trim value, engine coolant temperature, ignition timing advance, or closed loop status

PRODUCT INFORMATION

Tool Description



1. LCD DISPLAY - Indicates test results. It is a backlit 2-line display with 8 characters on each line.

2. ENTER/EXIT BUTTON - Confirms a selection (or action) from a menu list, or returns to the main menu.

3. SCROLL BUTTON - Scrolls through menu items or It is also used to enter system setup menu when pressed.

4. OBD II CONNECTOR - Connects the Code Scanner to the vehicle's Data Link Connector (DLC).

Navigation

Characters used to help navigate the code reader are:

- 1) "►" -- Indicates current selection.
- 2) "Pd" -- Identifies a pending DTC when viewing DTCs.
- 3) "\$" -- Identifies the control module number from which the data is retrieved.

Power

The power of the code reader is provided via the vehicle Data Link Connector (DLC). Follow the steps below to turn on the code reader:

1) Find DLC on vehicle. (A plastic DLC cover may be found for some vehicles and you need to remove it before plugging the OBD2 cable.)

2) Plug OBD II cable to the vehicle's DLC.

Setup

The code reader allows you to make the following adjustments and settings:

- 1) Language: Selects desired language.
 - 2) Unit of measure: Sets the unit of measure to English or Metric.
 - 3) Contrast adjustment: Adjusts the contrast of the LCD display.
- The Settings of the unit will remain until change to the existing settings is made.

To enter the setup menu

From the second startup screen, press **SCROLL** button to enter **System Setup** menu.

Follow the instructions to make adjustments and settings as described in the following setup options.

- The number in the upper right corner of the screen indicates total number of items under the menu and sequence of currently selected item.

Language Setup

- English is the default language.

1) From **System Setup** menu, use **SCROLL** button to select **Language**, and press **ENTER/EXIT** button.

2) Use **SCROLL** button to select the desired language and press **ENTER/EXIT** button to save your selection and return to previous menu.






Unit of Measurement

- Metric is the default measurement unit.

1) From **System Setup** menu, use **SCROLL** button to select **Unit of Measure** and press **ENTER/EXIT** button.

2) From **Unit of Measure** menu, use **SCROLL** button to select the desired unit of measurement.

3) Press **ENTER/EXIT** button to save your selection and return to previous menu.



Contrast Adjustment

1) From **System Setup** menu, use **SCROLL** button to select **Contrast**, and press **ENTER/EXIT** button.

2) From **Contrast** menu, use **SCROLL** button to adjust contrast.

3) Press **ENTER/EXIT** button to save your settings and return to previous menu.

Exiting System Setup

1) Use **SCROLL** button to select **Exit** and press **ENTER/EXIT** button to return to startup menu.

Vehicle Coverage

The Multilingual Digital Scanner is specially designed to work with all OBD II compliant vehicles, including those equipped with the next-generation protocol-Control Area Network (CAN). It is required by EPA that All 1996 and newer vehicles (cars and light trucks) sold in the United States must be OBD II compliant and this includes all Domestic, Asian and European vehicles.




A small number of 1994 and 1995 model year gasoline vehicles are OBD II compliant. To verify if a 1994 or 1995 vehicle is OBD II compliant, check the Vehicle Emissions Control Information (VECI) Label which is located under the hood or by the radiator of most vehicles. If the vehicle is OBD II compliant, the label will designate "OBD II Certified". Additionally, Government regulations mandate that all OBD II compliant vehicles must have a "common" sixteen-pin Data Link Connector (DLC).

For your vehicle to be OBD II compliant it must have a 16-pin DLC (Data Link Connector) under the dash and the Vehicle Emission Control Information Label must state that the vehicle is OBD II compliant.

OBD II Diagnostics

When more than one vehicle control module is detected by the scan tool, you will be prompted to select the module where the data may be retrieved. The most often to be selected are the Powertrain Control Module [PCM] and Transmission Control Module [TCM].

CAUTION: Don't connect or disconnect any test equipment with ignition on or engine running.



OPERATING INSTRUCTIONS

- 1) Turn the ignition off.
- 2) Locate the vehicle's 16-pin Data Link Connector (DLC).
- 3) Plug into the OBDII cable to the vehicle's DLC.
- 4) Turn the ignition on. Engine can be off or running.
- 5) Press **ENTER/EXIT** button to enter **Diagnostic Menu**. A sequence of messages displaying the OBD2 protocols will be observed on the display until the vehicle protocol is detected.
 - ◆ If the code reader fails to communicate with the vehicle's ECU (Engine Control Unit), a "**LINKING ERROR!**" message shows up on the display.
 - ✓ Verify that the ignition is ON;
 - ✓ Check if the code reader's OBD II connector is securely connected to the vehicle's DLC;
 - ✓ Verify that the vehicle is OBD2 compliant;
 - ✓ Turn the ignition off and wait for about 10 seconds. Turn the ignition back to on and repeat the procedure from step 5.
 - ◆ If the "**LINKING ERROR**" message does not go away, then there might be problems for the code reader to communicate with the vehicle. Contact your local distributor or the manufacturer's customer service department for assistance.
- 6) After the system status is displayed (MIL status, DTC counts, Monitor status), wait a few seconds or press any key for **Diagnostic Menu** to come up.

Reading Codes

- 1) Use **SCROLL** button to select Read Codes from **Diagnostic Menu** and press **ENTER/EXIT** button.
 - If more than one module is detected, you will be prompted to select a module before test.
 - Use **SCROLL** button to select a module, and press **ENTER/EXIT** button.

- 2) View DTCs and their definitions on screen.

System Status

Codes Found	1
Monitors N/A	4
Monitors OK	3
Monitors INC	3

Diagnostic Menu

=====1/6	
▶ 1) Read Codes	
2) Erase Codes	
3) View Freeze Frame	
4) I/M Readiness	

Control Module

=====1/3	
▶ Engine	
Module \$A4	
Exit	

\$11	Pd	1/6
P0115		
=====Generic=====		
Engine Coolant Temperature		
Sensor 1 Circuit		


- The control module number, sequence of the DTCs, total number of codes detected and type of codes (Generic or Manufacturer specific, Stored or Pending codes) will be observed on the upper right hand corner of the display.

3) If more than one DTC is found, use **SCROLL** button, as necessary, until all the codes have been shown up.

- If no codes are detected, a “No codes are stored in the module!” message displays on the screen.

- If retrieved DTCs contain any manufacturer specific or enhanced codes, the display indicates “Manufacturer Control”.

4) Press **ENTER/EXIT** button to return to previous menu.




Erasing Codes


CAUTION: Erasing the Diagnostic Trouble Codes may allow the code reader to delete not only the codes from the vehicle's on-board computer, but also “Freeze Frame” data and manufacturer enhanced data. Further, the I/M Readiness Monitor Status for all vehicle monitors is reset to Not Ready or Not Complete status. Do not erase the codes before the system has been checked completely by a technician.

- This function is performed with key on engine off (KOEO). Do not start the engine.

1) If you decide to erase the DTCs, use **SCROLL** button to select Erase Codes from Diagnostics Menu and press **ENTER/EXIT** button.



2) A warning message comes up asking for your confirmation.



3) If you want to proceed with erasing the codes, press **ENTER/EXIT** button to erase.

- If the codes are cleared successfully, an “Erase Done!” message shows up.

- If the codes are not cleared, then an “Erase Failure. Turn Key on with Engine off!” message displays.

4) Wait a few seconds or press any key to return to **Diagnostic Menu**.

- If you do wish to proceed to erase the codes, then press **SCROLL** button to select **NO** and press **ENTER/EXIT**. A “Command Canceled” message shows up. Press any key or wait a few seconds to return to **Diagnostic Menu**.

Viewing Freeze frame Data

1) To view freeze frame, use **SCROLL** button to select **View Freeze Frame** from **Diagnostic Menu** and press **ENTER/EXIT** button.

- If more than one module is detected, you will be prompted to select a module before test.
- Use **SCROLL** button to select a module and press **ENTER/EXIT** button.

2) Wait a few seconds while the code reader validates the PID MAP.

3) If the retrieved information covers more than one screen, use **SCROLL** button, as necessary, until all data have been shown up.

- The number in the upper right corner of the screen indicates total number of screens the retrieved freeze frame covers and sequence of currently displayed data.

- If there is no freeze frame data available, an advisory message **"No Freeze Frame Data Stored!"** shows on the display.

4) Press **ENTER/EXIT** to return to **Diagnostic Menu**.

Diagnostic Menu

=====3/6

- 1) Read Codes
- 2) Erase Codes
- ▶ 3) View Freeze Frame
- 4) I/M Readiness

Control Module

=====1/3

- ▶ Engine
- Module \$A4
- Exit

View Freeze Frame

=====

Reading PID.01!

- Please Wait -

View Freeze Frame

=====1/4

DTCFRZF	P2770
FUELSYS1	OL
FUELSYS2	N/A
LOAD_PCT (%)	0.0

Retrieving I/M Readiness Status

I/M Readiness function is used to check the operations of the Emission System on OBD2 compliant vehicles. It is an excellent function to use prior to having a vehicle inspected for compliance to a state emissions program.

Some latest vehicle models may support two types of I/M Readiness tests:

- A. Since DTCs Cleared - indicates status of the monitors since the DTCs are erased.
- B. This Drive Cycle - indicates status of monitors since the beginning of the current drive cycle.

An I/M Readiness Status result of "NO" does not necessarily indicate that the vehicle being tested will fail the state I/M inspection. For some states, one or more such monitors may be allowed to be "Not Ready" to pass the emissions inspection.

- **"OK"** - Indicates that a particular monitor being checked has completed its diagnostic testing.
- **"INC"** - Indicates that a particular monitor being checked has not completed its diagnostic testing.
- **"N/A"** - The monitor is not supported on that vehicle.

1) Use **SCROLL** button to select I/M Readiness from Diagnostic Menu and press **ENTER/EXIT**.

- If more than one module is detected, you will be prompted to select a module before test.
- Use the **SCROLL** button to select a module, and press **ENTER/EXIT** button.

2) Wait a few seconds while the code reader validates the PID MAP.

3) If the vehicle supports both types of tests, then both types shows on the screen for selection.

4) Use **SCROLL** button to view the status of the MIL light (“ON” or “OFF”) and the following monitors:

- Misfire monitor - Misfire monitor
- Fuel System Mon - Fuel System Monitor
- Comp. Component - Comprehensive Components Monitor
- EGR - EGR System Monitor
- Oxygen Sens Mon - O2 Sensors Monitor
- Catalyst Mon - Catalyst Monitor
- EVAP System Mon - Evaporative System Monitor
- Oxygen Sens htr - O2 Sensor Heater Monitor
- Sec Air System - Secondary Air Monitor
- Htd Catalyst - Heated Catalyst Monitor
- A/C Refrig Mon - A/C system Monitor

5) If the vehicle supports readiness test of “This Drive Cycle”, a screen of the following will be displayed:

- The number in the upper right corner of the screen indicates total number of screens the retrieved data cover and sequence of currently displayed data.

6) Press **ENTER/EXIT** button to return to previous menu.

Diagnostic Menu

=====4/6

- 1) Read Codes
- 2) Erase Codes
- 3) View Freeze Frame
- ▶ 4) I/M Readiness

Control Module

=====1/3

▶ Engine
Module \$A4
Exit

I/M Readiness

=====

Reading PID...
- Please Wait -

I/M Readiness

=====1/3

▶ Since DTCs Cleared
This Drive Cycle
Exit

Since DTCs Cleared

=====1/3

MIL Status	OFF
Misfire Monitor	OK
Fuel System Mon	OK
Comp. Component	OK

This Drive Cycle

=====1/3

MIL Status	ON
Misfire Monitor	OK
Fuel System Mon	OK
Comp. Component	OK

Viewing Vehicle Information

The Vehicle Info. function enables retrieval of the Vehicle Identification No. (VIN), Calibration ID(s), Calibration Verification Nos. (CVNs) and In-use Performance Tracking on 2000 and newer vehicles that support Mode 9.

1) Use **SCROLL** button to select **Vehicle Info.** from **Diagnostic Menu** and press **ENTER/EXIT** button.

2) Wait a few seconds or press **ENTER/EXIT** button to continue.

- If the vehicle does not support this mode, a “The selected mode is not supported!” message shows on the display.
- If more than one module is detected, you will be prompted to select a module before test.
- Use **SCROLL** button to select a module, and press **ENTER/EXIT** button.

3) Wait a few seconds while the code reader reads vehicle information.

4) From **Vehicle Info.** menu, use **SCROLL** button to select an available items to view and press **ENTER/EXIT** button.

5) View retrieved vehicle information on the screen.

6) Press **ENTER/EXIT** to return to previous menu.

Exiting OBDII Test

1) To exit OBDII test, use **SCROLL** button to select **Exit** from **Diagnostic Menu** and press **ENTER/EXIT** button.

2) A warning message comes up asking your confirmation.

3) If you do want to exit OBDII test, press **ENTER/EXIT** button.

- If you do not want to exit, use **SCROLL** button then select **NO** and press **ENTER/EXIT** button to return.

Diagnostic Menu

=====5/6
▶ 5) I/M Readiness
6) Exit

Vehicle Info.

=====5/6
Turn key on
with engine off!

Press [ENTER] to con.

Control Module

=====1/3
▶ Engine
Module \$A4
Exit

Vehicle Info.

=====1/4
▶ Vehicle ID Number
Calibration ID
Cal. Verif. Number
Exit

Vehicle ID Number

=====5/6
VIN:

2HJ198406H6539415

Diagnostic Menu

=====6/6
5) I/M Readiness
▶ 6) Exit

Exit Test

=====5/6
Exit OBDII Test!
Are you sure?

YES NO

DIAGNOSTIC TROUBLE CODE (DTC) DEFINITIONS

The following Diagnostic Trouble Code Definitions lists provide only Generic Diagnostic Trouble Codes. For Manufacturer Specific Diagnostic Trouble Code Definitions, consult the vehicle's service manual.

CAUTION: Parts or components should not be replaced based on only a DTC without first consulting the vehicle service manual for more information on possible causes of the fault as well as required testing procedures.

OBDII Generic DTC Definitions

P0001	Fuel Volume Regulator Control Circuit Open
P0002	Fuel Volume Regulator Control Circuit Range/Performance
P0003	Fuel Volume Regulator Control Circuit Low
P0004	Fuel Volume Regulator Control Circuit High
P0005	Fuel Shutoff Valve. A Control Circuit Open
P0006	Fuel Shutoff Valve. A Control Circuit Low
P0007	Fuel Shutoff Valve. A Control Circuit High
P0008	Engine Position System Performance (Bank 1)
P0009	Engine Position System Performance (Bank 2)
P0010	Camshaft Position Actuator A -Bank 1 Circuit Malfunction
P0011	Camshaft Position Actuator A -Bank 1 Timing Over-Advanced
P0012	Camshaft Position Actuator A - Bank 1 Timing Over-Retarded
P0013	Camshaft Position Actuator B - Bank 1 Circuit Malfunction
P0014	Camshaft Position Actuator B - Bank 1 Timing Over-Advanced
P0015	Camshaft Position Actuator B - Bank 1 Timing Over-Retarded
P0016	Cam/Crankshaft Pos. Correlation Sensor A - Bank 1
P0017	Cam/Crankshaft Pos. Correlation Sensor B - Bank 1
P0018	Cam/Crankshaft Pos. Correlation Sensor A - Bank 2
P0019	Cam/Crankshaft Pos. Correlation Sensor B - Bank 2
P0020	Camshaft Position Actuator A - Bank 2 Circuit Malfunction
P0021	Camshaft Position Actuator A - Bank 2 Timing Over-Advanced
P0022	Camshaft Position Actuator A -Bank 2 Timing Over-Retarded

OBDII Generic DTC Definitions

P0023	Camshaft Position Actuator B - Bank 2 Circuit Malfunction
P0024	Camshaft Position Actuator B - Bank 2 Timing Over-Advanced
P0025	Camshaft Position Actuator B - Bank 2 Timing Over-Retarded
P0026	Intake Valve-Bank 1 Control Solenoid CKT Range/Performance
P0027	Exhaust Valve-Bank 1 Control Solenoid CKT Range/Performance
P0028	Intake Valve-Bank 2 Control Solenoid CKT Range/Performance
P0029	Exhaust Valve-Bank 2 Control Solenoid CKT Range/Performance
P0030	HO2S Bank 1 Sensor 1 Heater Circuit
P0031	HO2S Bank 1 Sensor 1 Heater Circuit Low
P0032	HO2S Bank 1 Sensor 1 Heater Circuit High
P0033	Turbo/Sup Wastegate Control Circuit
P0034	Turbo/Sup Wastegate Control Circuit Low
P0035	Turbo/Sup Wastegate Control Circuit High
P0036	HO2S Bank 1 Sensor 2 Heater Circuit
P0037	HO2S Bank 1 Sensor 2 Heater Circuit Low
P0038	HO2S Bank 1 Sensor 2 Heater Circuit High
P0039	Turbo/Super Charger Bypass Control CKT Performance
P0040	O2 Bank 1 Sensor 1 Signals Swapped w/ O2 Bank 2 Sensor 1
P0041	O2 Bank 1 Sensor 2 Signals Swapped w/ O2 Bank 2 Sensor 2
P0042	HO2S Bank 1 Sensor 3 Heater Circuit
P0043	HO2S Bank 1 Sensor 3 Heater Circuit Low
P0044	HO2S Bank 1 Sensor 3 Heater Circuit High
P0045	Turbo/Super Charger Boost Control Solenoid A Circuit Open
P0046	Turbo/Super Charger Boost Control Solenoid A Circuit Range/ Perform
P0047	Turbo/Super Charger Boost Control Solenoid A Circuit Low
P0048	Turbo/Super Charger Boost Control Solenoid A Circuit High
P0049	Turbo/Super Charger Boost Input/Turbine Speed Overspeed
P0050	HO2S Bank 2 Sensor 1 Heater Circuit
P0051	HO2S Bank 2 Sensor 1 Heater Circuit Low
P0052	HO2S Bank 2 Sensor 1 Heater Circuit High
P0053	HO2S Bank 1 Sensor 1 Heater Resistance
P0054	HO2S Bank 1 Sensor 2 Heater Resistance
P0055	HO2S Bank 1 Sensor 3 Heater Resistance
P0056	HO2S Bank 2 Sensor 2 Heater Circuit
P0057	HO2S Bank 2 Sensor 2 Heater Circuit Low
P0058	HO2S Bank 2 Sensor 2 Heater Circuit High

OBDII Generic DTC Definitions

P0059	HO2S Bank 2 Sensor 1 Heater Resistance
P0060	HO2S Bank 2 Sensor 2 Heater Resistance
P0061	HO2S Bank 2 Sensor 3 Heater Resistance
P0062	HO2S Bank 2 Sensor 3 Heater Circuit
P0063	HO2S Bank 2 Sensor 3 Heater Circuit Low
P0064	HO2S Bank 2 Sensor 3 Heater Circuit High
P0065	Air Assisted Injector. Control Range/Performance
P0066	Air Assisted Injector. Control Circuit Low
P0067	Air Assisted Injector. Control Circuit High
P0068	MAF/MAP Sensor Throttle Position Correlation
P0069	MAP/BARO Correlation
P0070	Ambient Air Temp. Sensor Circuit
P0071	Ambient Air Temp. Sensor Range/Performance
P0072	Ambient Air Temp. Sensor Circuit Low
P0073	Ambient Air Temp. Sensor Circuit High
P0074	Ambient Air Temp. Sensor CKT Intermittent
P0075	Intake Valve-Bank 1 Control Circuit
P0076	Intake Valve-Bank 1 Control Circuit Low
P0077	Intake Valve-Bank 1 Control Circuit High
P0078	Exhaust Valve-Bank1 Control Circuit
P0079	Exhaust Valve-Bank1 Control Circuit Low
P0080	Exhaust Valve-Bank1 Control Circuit High
P0081	Intake Valve-Bank 2 Control Circuit
P0082	Intake Valve-Bank 2 Control Circuit Low
P0083	Intake Valve-Bank 2 Control Circuit High
P0084	Exhaust Valve-Bank2 Control Circuit
P0085	Exhaust Valve-Bank2 Control Circuit Low
P0086	Exhaust Valve-Bank2 Control Circuit High
P0087	Fuel Rail Pressure Too Low
P0088	Fuel Rail Pressure Too High
P0089	Fuel Pressure Regulator 1 Performance
P0090	Fuel Pressure Regulator 1 Control Circuit
P0091	Fuel Pressure Regulator 1 Control Circuit Low
P0092	Fuel Pressure Regulator 1 Control Circuit High
P0093	Fuel System Leak (Large)
P0094	Fuel System Leak (Small)

OBDII Generic DTC Definitions

P0095	IAT Sensor 2 Circuit
P0096	IAT Sensor 2 CKT Range/Performance
P0097	IAT Sensor 2 Circuit Low
P0098	IAT Sensor 2 Circuit High
P0099	IAT Sensor 2 CKT Intermittent
P0100	MAF or VAF A Circuit Malfunction
P0101	MAF or VAF A Circuit Range/Performance
P0102	MAF or VAF A Circuit Low Input
P0103	MAF or VAF A Circuit High Input
P0104	MAF or VAF A Circuit Intermittent
P0105	MAP/BARO Circuit Malfunction
P0106	MAP/BARO CKT Range/Performance
P0107	MAP/BARO Circuit Low Input
P0108	MAP/BARO Circuit High Input
P0109	MAP/BARO CKT Intermittent
P0110	IAT Sensor Circuit Malfunction
P0111	IAT Sensor 1 CKT Range/Performance
P0112	IAT Sensor 1 Circuit Low Input
P0113	IAT Sensor 1 Circuit High Input
P0114	IAT Sensor 1 CKT Intermittent
P0115	Engine Coolant Temp Circuit Malfunction
P0116	Engine Coolant Temp CKT Range/Performance
P0117	Engine Coolant Temp Circuit Low Input
P0118	Engine Coolant Temp Circuit High Input
P0119	Engine Coolant Temp CKT Intermittent
P0120	TPS/Pedal Position Sensor A Circuit Malfunction
P0121	TPS/Pedal Position Sensor A CKT Range/Performance
P0122	TPS/Pedal Position Sensor A Circuit Low Input
P0123	TPS/Pedal Position Sensor A Circuit High Input
P0124	TPS/Pedal Position Sensor A CKT Intermittent
P0125	Closed Loop Fuel Ctrl Insufficient Coolant Temp
P0126	Coolant Temp Insufficient Stable Operation
P0127	IAT Sensor Too High
P0128	Coolant Temp Below Thermostat Regulating Temp
P0129	Barometric Pressure Too Low
P0130	O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)

OBDII Generic DTC Definitions

P0131	O2 Sensor Circuit Low Volts (Bank 1 Sensor 1)
P0132	O2 Sensor Circuit High Volts (Bank 1 Sensor 1)
P0133	O2 Sensor CKT Slow Response (Bank 1 Sensor 1)
P0134	O2 Sensor CKT No Activity (Bank 1 Sensor 1)
P0135	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)
P0136	O2 Sensor Circuit Malfunction (Bank 1 Sensor 2)
P0137	O2 Sensor Circuit Low Volts (Bank 1 Sensor 2)
P0138	O2 Sensor Circuit High Volts (Bank 1 Sensor 2)
P0139	O2 Sensor CKT Slow Response (Bank 1 Sensor 2)
P0140	O2 Sensor CKT No Activity (Bank 1 Sensor 2)
P0141	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)
P0142	O2 Sensor Circuit Malfunction (Bank 1 Sensor 3)
P0143	O2 Sensor Circuit Low Volts (Bank 1 Sensor 3)
P0144	O2 Sensor Circuit High Volts (Bank 1 Sensor 3)
P0145	O2 Sensor CKT Slow Response (Bank 1 Sensor 3)
P0146	O2 Sensor CKT No Activity (Bank 1 Sensor 3)
P0147	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 3)
P0148	Fuel Delivery Malfunction
P0149	Fuel Timing Malfunction
P0150	O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)
P0151	O2 Sensor Circuit Low Volts (Bank 2 Sensor 1)
P0152	O2 Sensor Circuit High Volts (Bank 2 Sensor 1)
P0153	O2 Sensor CKT Slow Response (Bank 2 Sensor 1)
P0154	O2 Sensor CKT No Activity (Bank 2 Sensor 1)
P0155	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)
P0156	O2 Sensor Circuit Malfunction (Bank 2 Sensor 2)
P0157	O2 Sensor Circuit Low Volts (Bank 2 Sensor 2)
P0158	O2 Sensor Circuit High Volts (Bank 2 Sensor 2)
P0159	O2 Sensor CKT Slow Response (Bank 2 Sensor 2)
P0160	O2 Sensor CKT No Activity (Bank 2 Sensor 2)
P0161	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)
P0162	O2 Sensor Circuit Malfunction (Bank 2 Sensor 3)
P0163	O2 Sensor Circuit Low Volts (Bank 2 Sensor 3)
P0164	O2 Sensor Circuit High Volts (Bank 2 Sensor 3)
P0165	O2 Sensor CKT Slow Response (Bank 2 Sensor 3)
P0166	O2 Sensor CKT No Activity (Bank 2 Sensor 3)

OBDII Generic DTC Definitions

P0167	O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 3)
P0168	Engine Fuel Temperature Too High
P0169	Fuel Composition Incorrect
P0170	Fuel Trim Malfunction (Bank 1)
P0171	System Too Lean (Bank 1)
P0172	System Too Rich (Bank 1)
P0173	Fuel Trim Malfunction (Bank 2)
P0174	System Too Lean (Bank 2)
P0175	System Too Rich (Bank 2)
P0176	Fuel Compensation Sensor Circuit Malfunction
P0177	Fuel Compensation Sensor CKT Range/Performance
P0178	Fuel Compensation Sensor Circuit Low Input
P0179	Fuel Compensation Sensor Circuit High Input
P0180	Fuel Temperature Sensor A Circuit Malfunction
P0181	Fuel Temperature Sensor A CKT Range/Performance
P0182	Fuel Temperature Sensor A Circuit Low Input
P0183	Fuel Temperature Sensor A Circuit High Input
P0184	Fuel Temperature Sensor A CKT Intermittent
P0185	Fuel Temperature Sensor B Circuit Malfunction
P0186	Fuel Temperature Sensor B CKT Range/Performance
P0187	Fuel Temperature Sensor B Circuit Low Input
P0188	Fuel Temperature Sensor B Circuit High Input
P0189	Fuel Temperature Sensor B CKT Intermittent
P0190	Fuel Rail Pressure Sensor Circuit Malfunction
P0191	Fuel Rail Pressure Sensor CKT Range/Performance
P0192	Fuel Rail Pressure Sensor Circuit Low Input
P0193	Fuel Rail Pressure Sensor Circuit High Input
P0194	Fuel Rail Pressure Sensor CKT Intermittent
P0195	Engine Oil Temp Sensor Circuit Malfunction
P0196	Engine Oil Temp Sensor CKT Range/Performance
P0197	Engine Oil Temp Sensor Circuit Low Input
P0198	Engine Oil Temp Sensor Circuit High Input
P0199	Engine Oil Temp Sensor CKT Intermittent
P0200	Injector Circuit Open
P0201	Injector Circuit Open Cylinder 1
P0202	Injector Circuit Open Cylinder 2

OBDII Generic DTC Definitions

P0203	Injector Circuit Open Cylinder 3
P0204	Injector Circuit Open Cylinder 4
P0205	Injector Circuit Open Cylinder 5
P0206	Injector Circuit Open Cylinder 6
P0207	Injector Circuit Open Cylinder 7
P0208	Injector Circuit Open Cylinder 8
P0209	Injector Circuit Open Cylinder 9
P0210	Injector Circuit Open Cylinder 10
P0211	Injector Circuit Open Cylinder 11
P0212	Injector Circuit Open Cylinder 12
P0213	Cold Start Injector 1 Malfunction
P0214	Cold Start Injector 2 Malfunction
P0215	Engine Shutoff Solenoid Malfunction
P0216	Injection Timing Control Circuit Malfunction
P0217	Engine Overtemp Condition
P0218	Transmission Overtemp Condition
P0219	Engine Overspeed Condition
P0220	TPS/Pedal Position Sensor/Switch B Circuit Malfunction
P0221	TPS/Pedal Position Sensor/Switch B CKT Range/Performance
P0222	TPS/Pedal Position Sensor/Switch B Circuit Low Input
P0223	TPS/Pedal Position Sensor/Switch B Circuit High Input
P0224	TPS/Pedal Position Sensor/Switch B CKT Intermittent
P0225	TPS/Pedal Position Sensor/Switch C Circuit Malfunction
P0226	TPS/Pedal Position Sensor/Switch C CKT Range/Performance
P0227	TPS/Pedal Position Sensor/Switch C Circuit Low Input
P0228	TPS/Pedal Position Sensor/Switch C Circuit High Input
P0229	TPS/Pedal Position Sensor/Switch C CKT Intermittent
P0230	Fuel Pump Primary Circuit Malfunction
P0231	Fuel Pump Secondary Circuit Low
P0232	Fuel Pump Secondary Circuit High
P0233	Fuel Pump Secondary Circuit Intermittent Ckt
P0234	Engine Overboost Condition
P0235	Turbo/Super Boost Sensor A Circuit Malfunction
P0236	Turbo/Super Boost Sensor A CKT Range/Performance
P0237	Turbo/Super Boost Sensor A Circuit Low Input
P0238	Turbo/Super Boost Sensor A Circuit High Input

OBDII Generic DTC Definitions

P0239	Turbo/Super Boost Sensor B Circuit Malfunction
P0240	Turbo/Super Boost Sensor B CKT Range/Performance
P0241	Turbo/Super Boost Sensor B Circuit Low Input
P0242	Turbo/Super Boost Sensor B Circuit High Input
P0243	Turbo/Sup Wastegate Solenoid A Malfunction
P0244	Turbo/Sup Wastegate Solenoid A Range/Performance
P0245	Turbo/Sup Wastegate Solenoid A Low
P0246	Turbo/Sup Wastegate Solenoid A High
P0247	Turbo/Sup Wastegate Solenoid B Malfunction
P0248	Turbo /Sup Wastegate Solenoid B Range/Performance
P0249	Turbo/Sup Wastegate Solenoid B Low
P0250	Turbo/Sup Wastegate Solenoid B High
P0251	Injection Pump Metering Control A
P0252	Injection Pump Metering Control A Range/Performance
P0253	Injection Pump Metering Control A Low
P0254	Injection Pump Metering Control A High
P0255	Injection Pump Metering Control A Intermittent (Cam/Rotor/Injector)
P0256	Injection Pump Metering Control B Malfunction (Cam/Rotor/Injector)
P0257	Injection Pump Metering Control B Range/Performance (Cam/Rotor/Injector)
P0258	Injection Pump Metering Control B Low (Cam/Rotor/Injector)
P0259	Injection Pump Metering Control B High (Cam/Rotor/Injector)
P0260	Injection Pump Metering Control B Intermittent (Cam/Rotor/Injector)
P0261	Cylinder 1 Injector Control Circuit Low
P0262	Cylinder 1 Injector Control Circuit High
P0263	Cylinder 1 Contribution Balance Fault
P0264	Cylinder 2 Injector Control Circuit Low
P0265	Cylinder 2 Injector Control Circuit High
P0266	Cylinder 2 Contribution Balance Fault
P0267	Cylinder 3 Injector Control Circuit Low
P0268	Cylinder 3 Injector Control Circuit High
P0269	Cylinder 3 Contribution Balance Fault
P0270	Cylinder 4 Injector Control Circuit Low
P0271	Cylinder 4 Injector Control Circuit High
P0272	Cylinder 4 Contribution Balance Fault

OBDII Generic DTC Definitions

P0273	Cylinder 5 Injector Control Circuit Low
P0274	Cylinder 5 Injector Control Circuit High
P0275	Cylinder 5 Contribution Balance Fault
P0276	Cylinder 6 Injector Control Circuit Low
P0277	Cylinder 6 Injector Control Circuit High
P0278	Cylinder 6 Contribution Balance Fault
P0279	Cylinder 7 Injector Control Circuit Low
P0280	Cylinder 7 Injector Control Circuit High
P0281	Cylinder 7 Contribution Balance Fault
P0282	Cylinder 8 Injector Control Circuit Low
P0283	Cylinder 8 Injector Control Circuit High
P0284	Cylinder 8 Contribution Balance Fault
P0285	Cylinder 9 Injector Control Circuit Low
P0286	Cylinder 9 Injector Control Circuit High
P0287	Cylinder 9 Contribution Balance Fault
P0288	Cylinder 10 Injector Control Circuit Low
P0289	Cylinder 10 Injector Control Circuit High
P0290	Cylinder 10 Contribution Balance Fault
P0291	Cylinder 11 Injector Control Circuit Low
P0292	Cylinder 11 Injector Control Circuit High
P0293	Cylinder 11 Contribution Balance Fault
P0294	Cylinder 12 Injector Control Circuit Low
P0295	Cylinder 12 Injector Control Circuit High
P0296	Cylinder 12 Contribution Balance Fault
P0297	Vehicle Overspeed Error
P0298	Engine Oil Temperature Too High
P0299	Turbo/Super Charger UnderBoost
P0300	Random/Multiple Cylinder Misfire Detected
P0301	Cylinder 1 Misfire Detected
P0302	Cylinder 2 Misfire Detected
P0303	Cylinder 3 Misfire Detected
P0304	Cylinder 4 Misfire Detected
P0305	Cylinder 5 Misfire Detected
P0306	Cylinder 6 Misfire Detected
P0307	Cylinder 7 Misfire Detected
P0308	Cylinder 8 Misfire Detected

OBDII Generic DTC Definitions

P0309	Cylinder 9 Misfire Detected
P0310	Cylinder 10 Misfire Detected
P0311	Cylinder 11 Misfire Detected
P0312	Cylinder 12 Misfire Detected
P0313	Misfire Detected Low Fuel Level
P0314	Misfire Detected Cyl. not Specific
P0315	Crankshaft Position System Variation Not Learned
P0316	Misfire Detected 1st 1000 Revs.
P0317	Rough Road Hardware Not Present
P0318	Rough Road Sensor A Signal Circuit
P0319	Rough Road Sensor B
P0320	Ignition/Dist Engine Speed Input Circuit Malfunction
P0321	Ignition/Dist Engine Speed Input CKT Range/Performance
P0322	Ignition/Dist Engine Speed Input Circuit No Signal
P0323	Ignition/Dist Engine Speed Input CKT Intermittent
P0324	Knock Control System Malfunction
P0325	Knock Sensor 1 Circuit Malfunction Bank 1 or 1 Sensor
P0326	Knock Sensor 1 CKT Range/Performance Bank 1 or 1 Sensor
P0327	Knock Sensor 1 Circuit Low Input Bank 1 or 1 Sensor
P0328	Knock Sensor 1 Circuit High Input Bank 1 or 1 Sensor
P0329	Knock Sensor 1 CKT Intermittent Bank 1 or 1 Sensor
P0330	Knock Sensor 2 Circuit Malfunction (Bank 2)
P0331	Knock Sensor 2 CKT Range/Performance (Bank 2)
P0332	Knock Sensor 2 Circuit Low Input (Bank 2)
P0333	Knock Sensor 2 Circuit High Input (Bank 2)
P0334	Knock Sensor 2 CKT Intermittent (Bank 2)
P0335	Crankshaft Position Sensor A Circuit Malfunction
P0336	Crankshaft Position Sensor A CKT Range/Performance
P0337	Crankshaft Position Sensor A Circuit Low Input
P0338	Crankshaft Position Sensor A Circuit High Input
P0339	Crankshaft Position Sensor A CKT Intermittent
P0340	Camshaft Position Sensor A - Bank 1 Circuit Malfunction
P0341	Camshaft Position Sensor A - Bank 1 CKT Range/Performance
P0342	Camshaft Position Sensor A - Bank 1 Circuit Low Input
P0343	Camshaft Position Sensor A - Bank 1 Circuit High Input
P0344	Camshaft Position Sensor A - Bank 1 CKT Intermittent

OBDII Generic DTC Definitions

P0345	Camshaft Position Sensor A - Bank 2 Circuit Malfunction
P0346	Camshaft Position Sensor A - Bank 2 CKT Range/Performance
P0347	Camshaft Position Sensor A - Bank 2 Circuit Low Input
P0348	Camshaft Position Sensor A - Bank 2 Circuit High Input
P0349	Camshaft Position Sensor A - Bank 2 CKT Intermittent
P0350	Ignition Coil Primary/Secondary Circuit Malfunction
P0351	Ignition Coil A Primary/Secondary Circuit Malfunction
P0352	Ignition Coil B Primary/Secondary Circuit Malfunction
P0353	Ignition Coil C Primary/Secondary Circuit Malfunction
P0354	Ignition Coil D Primary/Secondary Circuit Malfunction
P0355	Ignition Coil E Primary/Secondary Circuit Malfunction
P0356	Ignition Coil F Primary/Secondary Circuit Malfunction
P0357	Ignition Coil G Primary/Secondary Circuit Malfunction
P0358	Ignition Coil H Primary/Secondary Circuit Malfunction
P0359	Ignition Coil I Primary/Secondary Circuit Malfunction
P0360	Ignition Coil J Primary/Secondary Circuit Malfunction
P0361	Ignition Coil K Primary/Secondary Circuit Malfunction
P0362	Ignition Coil L Primary/Secondary Circuit Malfunction
P0363	Misfire Detected Fueling Disabled
P0365	Camshaft Position Sensor B - Bank 1 Circuit Malfunction
P0366	Camshaft Position Sensor B - Bank 1 CKT Range/Performance
P0367	Camshaft Position Sensor B - Bank 1 Circuit Low Input
P0368	Camshaft Position Sensor B - Bank 1 Circuit High Input
P0369	Camshaft Position Sensor B - Bank 1 CKT Intermittent
P0370	Timing Reference High Resolution Signal A Malfunction
P0371	Timing Reference High Resolution Signal A Too Many Pulses
P0372	Timing Reference High Resolution Signal A Too Few Pulses
P0373	Timing Reference High Resolution Signal A Erratic Pulses
P0374	Timing Reference High Resolution Signal A No Pulses
P0375	Timing Reference High Resolution Signal B Malfunction
P0376	Timing Reference High Resolution Signal B Too Many Pulses
P0377	Timing Reference High Resolution Signal B Too Few Pulses
P0378	Timing Reference High Resolution Signal B Erratic Pulses
P0379	Timing Reference High Resolution Signal B No Pulses
P0380	Glow Plug/Heater CKT A Malfunction
P0381	Glow Plug/Heater Indicator Circuit Malfunction

OBDII Generic DTC Definitions

P0382	Glow Plug/Heater CKT B Malfunction
P0383	Glow Plug Module Control Circuit Low
P0384	Glow Plug Module Control Circuit High
P0385	Crankshaft Position Sensor B Circuit Malfunction
P0386	Crankshaft Position Sensor B CKT Range/Performance
P0387	Crankshaft Position Sensor B Circuit Low Input
P0388	Crankshaft Position Sensor B Circuit High Input
P0389	Crankshaft Position Sensor B CKT Intermittent
P0390	Camshaft Position Sensor B - Bank 2 Circuit Malfunction
P0391	Camshaft Position Sensor B - Bank 2 CKT Range/Performance
P0392	Camshaft Position Sensor B - Bank 2 Circuit Low Input
P0393	Camshaft Position Sensor B - Bank 2 Circuit High Input
P0394	Camshaft Position Sensor B - Bank 2 CKT Intermittent
P0400	EGR Flow Malfunction
P0401	EGR Flow Insufficient
P0402	EGR Flow Excessive
P0403	EGR Flow Circuit Malfunction
P0404	EGR Flow CKT Range/Performance
P0405	EGR Flow Sensor A Circuit Low Input
P0406	EGR Flow Sensor A Circuit High Input
P0407	EGR Flow Sensor B Circuit Low Input
P0408	EGR Flow Sensor B Circuit High Input
P0409	EGR Flow Sensor A Circuit
P0410	Secondary Air Injection System Malfunction
P0411	Secondary Air Injection System Incorrect Flow
P0412	Secondary Air Injection System Valve A Malfunction
P0413	Secondary Air Injection System Valve A CKT Open
P0414	Secondary Air Injection System Valve A CKT Short
P0415	Secondary Air Injection System Valve B Malfunction
P0416	Secondary Air Injection System Valve B CKT Open
P0417	Secondary Air Injection System Valve B CKT Short
P0418	Secondary Air Injection System Relay A Malfunction
P0419	Secondary Air Injection System Relay B Malfunction
P0420	Catalyst Efficiency Below Threshold (Bank 1)
P0421	Warm Up Catalyst Below Threshold (Bank 1)
P0422	Main Catalyst Below Threshold (Bank 1)

OBDII Generic DTC Definitions

P0423	Heated Catalyst Below Threshold (Bank 1)
P0424	Heated Catalyst Temp Below Threshold (Bank 1)
P0425	Catalyst Temp. Sensor (Bank 1 Sensor 1)
P0426	Catalyst Temp. Sensor Performance (Bank 1 Sensor 1)
P0427	Catalyst Temp. Sensor Circuit Low (Bank 1 Sensor 1)
P0428	Catalyst Temp. Sensor Circuit High (Bank 1 Sensor 1)
P0429	Catalyst Heater Control (Bank 1)
P0430	Catalyst Efficiency Below Threshold (Bank 2)
P0431	Warm Up Catalyst Below Threshold (Bank 2)
P0432	Main Catalyst Below Threshold (Bank 2)
P0433	Heated Catalyst Below Threshold (Bank 2)
P0434	Heated Catalyst Temp Below Threshold (Bank 2)
P0435	Catalyst Temp. Sensor (Bank 2 Sensor 1)
P0436	Catalyst Temp. Sensor Performance (Bank 2 Sensor 1)
P0437	Catalyst Temp. Sensor Circuit Low (Bank 2 Sensor 1)
P0438	Catalyst Temp. Sensor Circuit High (Bank 2 Sensor 1)
P0439	Catalyst Heater Control (Bank 2)
P0440	EVAP Emission Control System Malfunction
P0441	EVAP Emission Control System Purge Flow Fault
P0442	EVAP Emission Control System Leak (Small)
P0443	EVAP Emission Control System Purge Valve C Fault
P0444	EVAP Emission Control System Purge Valve C Open
P0445	EVAP Emission Control System Purge Valve C Short
P0446	EVAP Emission Control System Vent Circuit Malf
P0447	EVAP Emission Control System Vent Circuit Open
P0448	EVAP Emission Control System Vent Circuit Short
P0449	EVAP Emission Control System Vent Vlv/Sol Malf
P0450	EVAP Emission Control System Pres Sensor Fault
P0451	EVAP Emission Control System Pres Sensor Range
P0452	EVAP Emission Control System Pres Sensor Low
P0453	EVAP Emission Control System Pres Sensor High
P0454	EVAP Emission Control System Pres Sensor Erratic
P0455	EVAP Emission Control System Leak (Large)
P0456	EVAP Emission Control System Leak Very Small
P0457	EVAP Emission Control System Leak Cap Loose/Off
P0458	EVAP System Canister Purge Sol Circuit Low

OBDII Generic DTC Definitions

P0459	EVAP System Canister Purge Sol Circuit High
P0460	Fuel Level Sensor A Circuit Malfunction
P0461	Fuel Level Sensor A CKT Range/Performance
P0462	Fuel Level Sensor A Circuit Low Input
P0463	Fuel Level Sensor A Circuit High Input
P0464	Fuel Level Sensor A CKT Intermittent
P0465	EVAP Emission Purge Flow Sensor Circuit Malfunction
P0466	EVAP Emission Purge Flow Sensor CKT Range/Performance
P0467	EVAP Emission Purge Flow Sensor Circuit Low Input
P0468	EVAP Emission Purge Flow Sensor Circuit High Input
P0469	EVAP Emission Purge Flow Sensor CKT Intermittent
P0470	Exhaust Pressure Sensor Circuit Malfunction
P0471	Exhaust Pressure Sensor CKT Range/Performance
P0472	Exhaust Pressure Sensor Circuit Low Input
P0473	Exhaust Pressure Sensor Circuit High Input
P0474	Exhaust Pressure Sensor CKT Intermittent
P0475	Exhaust Pressure Control Valve Circuit Malfunction
P0476	Exhaust Pressure Control Valve CKT Range/Performance
P0477	Exhaust Pressure Control Valve Circuit Low Input
P0478	Exhaust Pressure Control Valve Circuit High Input
P0479	Exhaust Pressure Control Valve CKT Intermittent
P0480	Cooling Fan 1 Control Circuit
P0481	Cooling Fan 2 Control Circuit
P0482	Cooling Fan 3 Control Circuit
P0483	Control Fan Rationality Check Malfunction
P0484	Control Fan CKT Over Current
P0485	Control Fan Power/Ground Circuit Malfunction
P0486	EGR System Sensor B Circuit
P0487	EGR TPS Control Circuit
P0488	EGR TPS Control CKT Range/Performance
P0489	EGR Control Circuit Low
P0490	EGR Control Circuit High
P0491	Secondary Air System (Bank 1)
P0492	Secondary Air System (Bank 2)
P0493	Fan Speed Overspeed
P0494	Fan Speed Low

OBDII Generic DTC Definitions

P0495	Fan Speed High
P0496	EVAP Emission High Purge Flow Fault
P0497	EVAP Emission Low Purge Flow Fault
P0498	EVAP Emission Vent Vlv/Sol Malf Circuit Low
P0499	EVAP Emission Vent Vlv/Sol Malf Circuit High
P0500	Vehicle Speed Sensor A Malfunction
P0501	Vehicle Speed Sensor A Range/Performance
P0502	Vehicle Speed Sensor A Circuit Low Input
P0503	Vehicle Speed Sensor A Erratic/High
P0504	Brake Switch A Brake Switch B Correlation
P0505	Idle Control System Malfunction
P0506	Idle Control System RPM Low
P0507	Idle Control System RPM High
P0508	Idle Control System Circuit Low
P0509	Idle Control System Circuit High
P0510	Closed Throttle Position Switch
P0511	Idle Air Control Circuit
P0512	Starter Signal Circuit
P0513	Immobilizer Incorrect
P0514	Battery Temperature Sensor CKT Range/Performance
P0515	Battery Temperature Sensor Circuit
P0516	Battery Temperature Circuit Low
P0517	Battery Temperature Circuit High
P0518	Idle Air Control CKT Intermittent
P0519	Idle Air Control System Performance
P0520	Engine Oil Pressure Sensor/Switch Circuit Malfunction
P0521	Engine Oil Pressure Sensor/Switch Range/Performance
P0522	Engine Oil Pressure Sensor/Switch Low Voltage
P0523	Engine Oil Pressure Sensor/Switch High Voltage
P0524	Engine Oil Pressure Too Low
P0525	Cruise Servo CKT Range/Performance
P0526	Fan Speed Sensor Circuit
P0527	Fan Speed Sensor CKT Range/Performance
P0528	Fan Speed Sensor Circuit No Signal
P0529	Fan Speed Sensor CKT Intermittent
P0530	A/C Refrigerant Pressure Sensor A Circuit Malfunction

OBDII Generic DTC Definitions

P0531	A/C Refrigerant Pressure Sensor A CKT Range/Performance
P0532	A/C Refrigerant Pressure Sensor A Circuit Low Input
P0533	A/C Refrigerant Pressure Sensor A Circuit High Input
P0534	A/C Refrigerant Charge Loss
P0535	A/C Evaporator Temperature Sensor Circuit
P0536	A/C Evaporator Temperature Sensor CKT Range/Performance
P0537	A/C Evaporator Temperature Sensor Circuit Low
P0538	A/C Evaporator Temperature Sensor Circuit High
P0539	A/C Evaporator Temperature Sensor CKT Intermittent
P0540	Intake Air Heater A Circuit
P0541	Intake Air Heater A Circuit Low
P0542	Intake Air Heater A Circuit High
P0543	Intake Air Heater A Circuit Open
P0544	Exhaust Gas Temp. Sensor Circuit (Bank 1 Sensor 1)
P0545	Exhaust Gas Temp. Sensor Circuit Low (Bank 1 Sensor 1)
P0546	Exhaust Gas Temp. Sensor Circuit High (Bank 1 Sensor 1)
P0547	Exhaust Gas Temp. Sensor Circuit (Bank 2 Sensor 1)
P0548	Exhaust Gas Temp. Sensor Circuit Low (Bank 2 Sensor 1)
P0549	Exhaust Gas Temp. Sensor Circuit High (Bank 2 Sensor 1)
P0550	Power Steering Pres Sensor Circuit Malfunction
P0551	Power Steering Pres Sensor CKT Range/Performance
P0552	Power Steering Pres Sensor Circuit Low Input
P0553	Power Steering Pres Sensor Circuit High Input
P0554	Power Steering Pres Sensor CKT Intermittent
P0555	Brake Booster Pressure Sensor Circuit
P0556	Brake Booster Pressure Sensor CKT Range/Performance
P0557	Brake Booster Pressure Sensor Circuit Low Input
P0558	Brake Booster Pressure Sensor Circuit High Input
P0559	Brake Booster Pressure Sensor CKT Intermittent
P0560	System Voltage Malfunction
P0561	System Voltage Unstable
P0562	System Voltage Low
P0563	System Voltage High
P0564	Cruise Control Multi-Function. Input A Signal Error
P0565	Cruise Control On Signal Malfunction
P0566	Cruise Control Off Signal Malfunction

OBDII Generic DTC Definitions

P0567	Cruise Control Resume Signal Malfunction
P0568	Cruise Control Set Signal Malfunction
P0569	Cruise Control Coast Signal Malfunction
P0570	Cruise Control Acceleration Signal Error
P0571	Brake Switch A Circuit Malfunction
P0572	Brake Switch A Circuit Low Input
P0573	Brake Switch A Circuit High Input
P0574	Cruise Control Vehicle Speed Too High
P0575	Cruise Control Circuit Malfunction
P0576	Cruise Control Circuit Low Input
P0577	Cruise Control Circuit High Input
P0578	Cruise Control Multi-Function Input A Circuit Stuck
P0579	Cruise Control Multi-Function Input A CKT Range/Performance
P0580	Cruise Control Multi-Function Input A Circuit Low
P0581	Cruise Control Multi-Function Input A Circuit High
P0582	Cruise Control Vacuum Control Circuit Open
P0583	Cruise Control Vacuum Control Circuit Low
P0584	Cruise Control Vacuum Control Circuit High
P0585	Cruise Control Multi-Function Input Correlation
P0586	Cruise Control Vent Control Circuit Open
P0587	Cruise Control Vent Control Circuit Low
P0588	Cruise Control Vent Control Circuit High
P0589	Cruise Control Multi-Function Input B Circuit
P0590	Cruise Control Multi-Function Input B Circuit Stuck
P0591	Cruise Control Multi-Function Input B CKT Range/Performance
P0592	Cruise Control Multi-Function Input B Circuit Low
P0593	Cruise Control Multi-Function Input B Circuit High
P0594	Cruise Control Servo Control Circuit Open
P0595	Cruise Control Servo Control Circuit Low
P0596	Cruise Control Servo Control Circuit High
P0597	Cruise Control Circuit Open
P0598	Cruise Control Circuit Low
P0599	Cruise Control Circuit High
P0600	Serial Communication Link Malfunction
P0601	Internal Control Module Memory Check Sum Error
P0602	Control Module Programming Error

OBDII Generic DTC Definitions

P0603	PCM Keep Alive Memory (KAM) Error
P0604	PCM Random Access Memory (RAM) Error
P0605	PCM Read Only Memory (ROM) Error
P0606	PCM Processor Fault
P0607	Control Module Performance
P0608	Control Module VSS Output A Malfunction
P0609	Control Module VSS Output B Malfunction
P0610	Control Module Vehicle Options Malfunction
P0611	Injector Control Module Performance
P0612	Injector Control Module Relay Control
P0613	TCM Processor Fault
P0614	ECM/TCM Incompatible
P0615	Starter Relay Circuit
P0616	Starter Relay Circuit Low
P0617	Starter Relay Circuit High
P0618	Alternative Fuel Module (KAM) Error
P0619	Alternative Fuel Module Memory
P0620	Generator Control Malfunction
P0621	Generator L-Term. Lamp Control
P0622	Generator F-Term. Field F Control
P0623	Generator Lamp Control Circuit
P0624	Fuel Cap Lamp Circuit
P0625	Generator F-Term. Circuit Low
P0626	Generator F-Term. Circuit High
P0627	Fuel Pump A Control Circuit Open
P0628	Fuel Pump A Control Circuit Low
P0629	Fuel Pump A Control Circuit High
P0630	PCM VIN Not Program. Or Mismatch
P0631	TCM VIN Not Program. Or Mismatch
P0632	Odometer Code Not Programmed ECM/PCM
P0633	Immobilizer Code Not Programmed ECM/PCM
P0634	PCM/ECM/TCM Internal Temp. Too High
P0635	Power Steering Control Circuit
P0636	Power Steering Control Circuit Low
P0637	Power Steering Control Circuit High
P0638	Throttle Actuator Range/Performance (Bank 1)

OBDII Generic DTC Definitions

P0639	Throttle Actuator Range/Performance (Bank 2)
P0640	Intake Air Heater Control Circuit
P0641	Sensor A Reference Voltage Circuit Open
P0642	Sensor A Reference Voltage Circuit Low
P0643	Sensor A Reference Voltage Circuit High
P0644	Driver Display Serial Communication Link
P0645	A/C Clutch Relay Control Circuit
P0646	A/C Clutch Relay Control Circuit Low
P0647	A/C Clutch Relay Control Circuit High
P0648	Immobilizer Lamp Circuit
P0649	Cruise Control Lamp Circuit
P0650	MIL Control Circuit Malfunction
P0651	Sensor B Reference Voltage Circuit Open
P0652	Sensor B Reference Voltage Circuit Low
P0653	Sensor B Reference Voltage Circuit High
P0654	Engine RPM Circuit Malfunction
P0655	Engine Hot Lamp Output Circuit Malfunction
P0656	Fuel Level Output Circuit Malfunction
P0657	Actuator Supply Voltage A Circuit Open
P0658	Actuator Supply Voltage A Circuit Low
P0659	Actuator Supply Voltage A Circuit High
P0660	Intake Man Tuning Control CKT Open (Bank 1)
P0661	Intake Man Tuning Control CKT Low (Bank 1)
P0662	Intake Man Tuning Control CKT High (Bank 1)
P0663	Intake Man Tuning Control CKT Open (Bank 2)
P0664	Intake Man Tuning Control CKT Low (Bank 2)
P0665	Intake Man Tuning Control CKT High (Bank 2)
P0666	PCM/ECM/TCM Internal Temp. Sensor Circuit
P0667	PCM/ECM/TCM Internal Temp. Sensor Range/Performance
P0668	PCM/ECM/TCM Internal Temp. Sensor Circuit Low
P0669	PCM/ECM/TCM Internal Temp. Sensor Circuit High
P0670	Glow Plug/Heater Module Control
P0671	Glow Plug/Heater Cylinder 1
P0672	Glow Plug/Heater Cylinder 2
P0673	Glow Plug/Heater Cylinder 3
P0674	Glow Plug/Heater Cylinder 4

OBDII Generic DTC Definitions

P0675	Glow Plug/Heater Cylinder 5
P0676	Glow Plug/Heater Cylinder 6
P0677	Glow Plug/Heater Cylinder 7
P0678	Glow Plug/Heater Cylinder 8
P0679	Glow Plug/Heater Cylinder 9
P0680	Glow Plug/Heater Cylinder 10
P0681	Glow Plug/Heater Cylinder 11
P0682	Glow Plug/Heater Cylinder 12
P0683	Glow Plug/Heater Module Communication Problem
P0684	Glow Plug/Heater Communication Problem CKT Range/Performance
P0685	ECM/PCM Power Relay Control Circuit Open
P0686	ECM/PCM Power Relay Control Circuit Low
P0687	ECM/PCM Power Relay Control Circuit High
P0688	ECM/PCM Power Relay Sense Circuit Open
P0689	ECM/PCM Power Relay Sense Circuit Low
P0690	ECM/PCM Power Relay Sense Circuit High
P0691	Fan 1 Control Circuit Low
P0692	Fan 1 Control Circuit High
P0693	Fan 2 Control Circuit Low
P0694	Fan 2 Control Circuit High
P0695	Fan 3 Control Circuit Low
P0696	Fan 3 Control Circuit High
P0697	Sensor C Reference Voltage Circuit Open
P0698	Sensor C Reference Voltage Circuit Low
P0699	Sensor C Reference Voltage Circuit High
P0700	Trans Control Sys Malfunction
P0701	Trans Control Sys Range/Performance
P0702	Trans Control Sys Electrical
P0703	Brake Switch B Circuit Malfunction
P0704	Clutch Switch Input Circuit Malfunction
P0705	Trans Range Sensor Circuit Malfunction (PRNDL Input)
P0706	Trans Range Sensor CKT Range/Performance
P0707	Trans Range Sensor Circuit Low Input
P0708	Trans Range Sensor Circuit High Input
P0709	Trans Range Sensor CKT Intermittent
P0710	Transmission Fluid Temperature Sensor Circuit Malfunction

OBDII Generic DTC Definitions

P0711	Trans Fluid Temp Sensor A CKT Range/Performance
P0712	Trans Fluid Temp Sensor A Circuit Low Input
P0713	Trans Fluid Temp Sensor A Circuit High Input
P0714	Trans Fluid Temp Sensor A CKT Intermittent
P0715	Input/Turbine Speed Sensor A Circuit Malfunction
P0716	Input/Turbine Speed Sensor A CKT Range/Performance
P0717	Input/Turbine Speed Sensor A Circuit No Signal
P0718	Input/Turbine Speed Sensor A CKT Intermittent
P0719	Brake Switch B Circuit Low Input
P0720	Output Speed Sensor Circuit Malfunction
P0721	Output Speed Sensor Circuit Range/Performance
P0722	Output Speed Sensor Circuit No Signal
P0723	Output Speed Sensor CKT Intermittent
P0724	Brake Switch B Circuit High Input
P0725	Engine Speed Sensor Circuit Malfunction
P0726	Engine Speed Sensor CKT Range/Performance
P0727	Engine Speed Sensor Circuit No Signal
P0728	Engine Speed Sensor CKT Intermittent
P0729	Gear 6 Ratio Incorrect
P0730	Gear Ratio Incorrect
P0731	Gear 1 Ratio Incorrect
P0732	Gear 2 Ratio Incorrect
P0733	Gear 3 Ratio Incorrect
P0734	Gear 4 Ratio Incorrect
P0735	Gear 5 Ratio Incorrect
P0736	Reverse Ratio Incorrect
P0737	TCM Engine Speed Output Circuit
P0738	TCM Engine Speed Output Circuit Low
P0739	TCM Engine Speed Output Circuit High
P0740	TCC Circuit Malfunction
P0741	Torque Converter CKT Performance Or Stuck Off
P0742	Torque Converter Circuit Stuck On
P0743	Torque Converter Circuit Electrical
P0744	Torque Converter CKT Intermittent
P0745	Pres Control Sol. A Circuit Malfunction
P0746	Pres Control Sol. A CKT Performance Or Stuck Off

OBDII Generic DTC Definitions

P0747	Pres Control Sol. A Circuit Stuck On
P0748	Pres Control Sol. A Circuit Electrical
P0749	Pres Control Sol. A CKT Intermittent
P0750	Shift Solenoid A Malfunction
P0751	Shift Solenoid A CKT Performance Or Stuck Off
P0752	Shift Solenoid A Circuit Stuck On
P0753	Shift Solenoid A Circuit Electrical
P0754	Shift Solenoid A CKT Intermittent
P0755	Shift Solenoid B Malfunction
P0756	Shift Solenoid B CKT Performance Or Stuck Off
P0757	Shift Solenoid B Circuit Stuck On
P0758	Shift Solenoid B Circuit Electrical
P0759	Shift Solenoid B CKT Intermittent
P0760	Shift Solenoid C Malfunction
P0761	Shift Solenoid C CKT Performance Or Stuck Off
P0762	Shift Solenoid C Circuit Stuck On
P0763	Shift Solenoid C Circuit Electrical
P0764	Shift Solenoid C CKT Intermittent
P0765	Shift Solenoid D Malfunction
P0766	Shift Solenoid D CKT Performance Or Stuck Off
P0767	Shift Solenoid D Circuit Stuck On
P0768	Shift Solenoid D Circuit Electrical
P0769	Shift Solenoid D CKT Intermittent
P0770	Shift Solenoid E Malfunction
P0771	Shift Solenoid E CKT Performance Or Stuck Off
P0772	Shift Solenoid E Circuit Stuck On
P0773	Shift Solenoid E Circuit Electrical
P0774	Shift Solenoid E CKT Intermittent
P0775	Pres Ctrl Sol. B Circuit Malfunction
P0776	Pres Ctrl Sol. B CKT Performance Or Stuck Off
P0777	Pres Ctrl Sol. B Circuit Stuck On
P0778	Pres Ctrl Sol. B Circuit Electrical
P0779	Pres Ctrl Sol. B CKT Intermittent
P0780	Shift Malfunction
P0781	1-2 Shift Malfunction
P0782	2-3 Shift Malfunction

OBDII Generic DTC Definitions

P0783	3-4 Shift Malfunction
P0784	4-5 Shift Malfunction
P0785	Shift/Timing Solenoid Malfunction
P0786	Shift/Timing Solenoid Range/Performance
P0787	Shift/Timing Solenoid Low
P0788	Shift/Timing Solenoid High
P0789	Shift/Timing Solenoid Intermittent Ckt
P0790	Normal/Performance Switch Circuit Malfunction
P0791	Intermediate Shaft Speed Sensor A Circuit
P0792	Intermediate Shaft Speed Sensor A Circuit Range/Performance
P0793	Intermediate Shaft Speed Sensor A Circuit No Signal
P0794	Intermediate Shaft Speed Sensor A CKT Intermittent
P0795	Pres Ctrl Sol. C Malfunction
P0796	Pres Ctrl Sol. C CKT Performance Or Stuck Off
P0797	Pres Ctrl Sol. C Circuit Stuck On
P0798	Pres Ctrl Sol. C Circuit Electrical
P0799	Pres Ctrl Sol. C CKT Intermittent
P0800	Transfer Case Control System MIL Request
P0801	Reverse Inhibit Control Circuit Malfunction
P0802	Trans Control Sys MIL Request Circuit Open
P0803	1-4 Upshift (Skip Shift) Solenoid Circuit Malfunction
P0804	1-4 Upshift (Skip Shift) Lamp Circuit Malfunction
P0805	Clutch Position Sensor Circuit Malfunction
P0806	Clutch Position Sensor Circuit Range/Performance
P0807	Clutch Position Sensor Circuit Low
P0808	Clutch Position Sensor Circuit High
P0809	Clutch Position Sensor Circuit Intermittent Ckt
P0810	Clutch Position Control Malfunction
P0811	Clutch Slippage Excessive
P0812	Reverse Input Circuit Malfunction
P0813	Reverse Output Circuit Malfunction
P0814	Trans Range Display Circuit Malfunction
P0815	Upshift Switch Circuit Malfunction
P0816	Downshift Switch Circuit Malfunction
P0817	Starter Disable Circuit
P0818	Driveline Disconnect Switch Input

OBDII Generic DTC Definitions

P0819	Up/Down Shift SW Transmission Range Correlation
P0820	Gear Lever X-Y Sensor Circuit
P0821	Gear Lever X Sensor Circuit
P0822	Gear Lever Y Sensor Circuit
P0823	Gear Lever X Sensor Circuit Intermittent Ckt
P0824	Gear Lever Y Sensor Circuit Intermittent Ckt
P0825	Gear Lever Push/Pull Switch (Shift Anticipate)
P0826	Upshift Switch Downshift Switch Circuit
P0827	Upshift Switch Downshift Switch Circuit Low
P0828	Upshift Switch Downshift Switch Circuit High
P0829	5-6 Shift
P0830	Clutch Position Switch A Circuit Malfunction
P0831	Clutch Position Switch A Circuit Low
P0832	Clutch Position Switch A Circuit High
P0833	Clutch Position Switch B Circuit Malfunction
P0834	Clutch Position Switch B Circuit Low
P0835	Clutch Position Switch B Circuit High
P0836	4 Wheel Drive Switch Circuit Malfunction
P0837	4 Wheel Drive Switch CKT Range/Performance
P0838	4 Wheel Drive Switch Circuit Low
P0839	4 Wheel Drive Switch Circuit High
P0840	Trans Fluid Press Sensor/Switch A Circuit Malfunction
P0841	Trans Fluid Press Sensor/Switch A CKT Range/Performance
P0842	Trans Fluid Press Sensor/Switch A Circuit Low
P0843	Trans Fluid Press Sensor/Switch A Circuit High
P0844	Trans Fluid Press Sensor/Switch A CKT Intermittent
P0845	Trans Fluid Press Sensor/Switch B Circuit Malfunction
P0846	Trans Fluid Press Sensor/Switch B CKT Range/Performance
P0847	Trans Fluid Press Sensor/Switch B Circuit Low
P0848	Trans Fluid Press Sensor/Switch B Circuit High
P0849	Trans Fluid Press Sensor/Switch B CKT Intermittent
P0850	Park/Neutral Switch Input Circuit
P0851	Park/Neutral Switch Circuit Low Input
P0852	Park/Neutral Switch Circuit High Input
P0853	Drive Switch Input Circuit
P0854	Drive Switch Circuit Low Input

OBDII Generic DTC Definitions

P0855	Drive Switch Circuit High Input
P0856	Traction Control Input Signal
P0857	Traction Control Input Signal Range/Performance
P0858	Traction Control Input Signal Low
P0859	Traction Control Input Signal High
P0860	Gear Shift Module Communications Circuit
P0861	Gear Shift Module Communications Circuit Low
P0862	Gear Shift Module Communications Circuit High
P0863	TCM Communications Circuit
P0864	TCM Communications CKT Range/Performance
P0865	TCM Communications Circuit Low
P0866	TCM Communications Circuit High
P0867	Trans Fluid Press
P0868	Trans Fluid Press Low
P0869	Trans Fluid Press High
P0870	Trans Fluid Press Sensor/Switch C Circuit
P0871	Trans Fluid Press Sensor/Switch C CKT Range/Performance
P0872	Trans Fluid Press Sensor/Switch C Circuit Low
P0873	Trans Fluid Press Sensor/Switch C Circuit High
P0874	Trans Fluid Press Sensor/Switch C CKT Intermittent
P0875	Trans Fluid Press Sensor/Switch D Circuit
P0876	Trans Fluid Press Sensor/Switch D CKT Range/Performance
P0877	Trans Fluid Press Sensor/Switch D Circuit Low
P0878	Trans Fluid Press Sensor/Switch D Circuit High
P0879	Trans Fluid Press Sensor/Switch D CKT Intermittent
P0880	TCM Power Input Signal
P0881	TCM Power Input Signal Range/Performance
P0882	TCM Power Input Signal Low
P0883	TCM Power Input Signal High
P0884	TCM Power Input Signal CKT Intermittent
P0885	TCM Power Relay Control Circuit Open
P0886	TCM Power Relay Control Circuit Low
P0887	TCM Power Relay Control Circuit High
P0888	TCM Power Relay Sense Circuit
P0889	TCM Power Relay Sense CKT Range/Performance
P0890	TCM Power Relay Sense Circuit Low

OBDII Generic DTC Definitions

P0891	TCM Power Relay Sense Circuit High
P0892	TCM Power Relay Sense CKT Intermittent
P0893	Multiple Gears Engaged
P0894	Transmission Comp. Slipping
P0895	Shift Time Too Short
P0896	Shift Time Too Long
P0897	Transmission Fluid Deteriorated
P0898	Transmission Ctrl. MIL Request Circuit Low
P0899	Transmission Ctrl. MIL Request Circuit High
P0900	Clutch Actuator Circuit Open
P0901	Clutch Actuator CKT Range/Performance
P0902	Clutch Actuator Circuit Low
P0903	Clutch Actuator Circuit High
P0904	Gate Select Position Circuit
P0905	Gate Select Position CKT Range/Performance
P0906	Gate Select Position Circuit Low
P0907	Gate Select Position Circuit High
P0908	Gate Select Position CKT Intermittent
P0909	Gate Select Control Error
P0910	Gate Select Actuator Circuit Open
P0911	Gate Select Actuator CKT Range/Performance
P0912	Gate Select Actuator Circuit Low
P0913	Gate Select Actuator Circuit High
P0914	Gear Shift Position Circuit
P0915	Gear Shift Position CKT Range/Performance
P0916	Gear Shift Position Circuit Low
P0917	Gear Shift Position Circuit High
P0918	Gear Shift Position CKT Intermittent
P0919	Gear Shift Position Control Error
P0920	Gear Shift Forward Actuator Circuit Open
P0921	Gear Shift Forward Actuator CKT Range/Performance
P0922	Gear Shift Forward Actuator Circuit Low
P0923	Gear Shift Forward Actuator Circuit High
P0924	Gear Shift Reverse Actuator Circuit Open
P0925	Gear Shift Reverse Actuator CKT Range/Performance
P0926	Gear Shift Reverse Actuator Circuit Low

OBDII Generic DTC Definitions

P0927	Gear Shift Reverse Actuator Circuit High
P0928	Gear Shift Lock Solenoid Ctrl Circuit Open
P0929	Gear Shift Lock Solenoid Ctrl CKT Range/Performance
P0930	Gear Shift Lock Solenoid Ctrl Circuit Low
P0931	Gear Shift Lock Solenoid Ctrl Circuit High
P0932	Hydraulic Pressure Sensor Circuit
P0933	Hydraulic Pressure Sensor CKT Range/Performance
P0934	Hydraulic Pressure Sensor Circuit Low
P0935	Hydraulic Pressure Sensor Circuit High
P0936	Hydraulic Pressure Sensor CKT Intermittent
P0937	Hydraulic Oil Temp Sensor Circuit
P0938	Hydraulic Oil Temp Sensor CKT Range/Performance
P0939	Hydraulic Oil Temp Sensor Circuit Low
P0940	Hydraulic Oil Temp Sensor Circuit High
P0941	Hydraulic Oil Temp Sensor CKT Intermittent
P0942	Hyd. Pressure Unit
P0943	Hyd. Pressure Unit Cycling Too Short
P0944	Hyd. Pressure Unit Loss of Pressure
P0945	Hyd. Pump Relay Circuit Open
P0946	Hyd. Pump Relay CKT Range/Performance
P0947	Hyd. Pump Relay Circuit Low
P0948	Hyd. Pump Relay Circuit High
P0949	Auto Shift Adaptive Learning Not Complete
P0950	Auto Shift Manual Control Circuit
P0951	Auto Shift Manual Control CKT Range/Performance
P0952	Auto Shift Manual Control Circuit Low
P0953	Auto Shift Manual Control Circuit High
P0954	Auto Shift Manual Control CKT Intermittent
P0955	Auto Shift Manual Mode Circuit
P0956	Auto Shift Manual Mode CKT Range/Performance
P0957	Auto Shift Manual Mode Circuit Low
P0958	Auto Shift Manual Mode Circuit High
P0959	Auto Shift Manual Mode CKT Intermittent
P0960	Pressure Control Solenoid A Control Circuit Open
P0961	Pressure Control Solenoid A Control CKT Range/Performance
P0962	Pressure Control Solenoid A Control Circuit Low

OBDII Generic DTC Definitions

P0963	Pressure Control Solenoid A Control Circuit High
P0964	Pressure Control Solenoid B Control Circuit Open
P0965	Pressure Control Solenoid B Control CKT Range/Performance
P0966	Pressure Control Solenoid B Control Circuit Low
P0967	Pressure Control Solenoid B Control Circuit High
P0968	Pressure Control Solenoid C Control Circuit Open
P0969	Pressure Control Solenoid C Control CKT Range/Performance
P0970	Pressure Control Solenoid C Control Circuit Low
P0971	Pressure Control Solenoid C Control Circuit High
P0972	Shift Solenoid A Control CKT Range/Performance
P0973	Shift Solenoid A Control Circuit Low
P0974	Shift Solenoid A Control Circuit High
P0975	Shift Solenoid B Control CKT Range/Performance
P0976	Shift Solenoid B Control Circuit Low
P0977	Shift Solenoid B Control Circuit High
P0978	Shift Solenoid C Control CKT Range/Performance
P0979	Shift Solenoid C Control Circuit Low
P0980	Shift Solenoid C Control Circuit High
P0981	Shift Solenoid D Control CKT Range/Performance
P0982	Shift Solenoid D Control Circuit Low
P0983	Shift Solenoid D Control Circuit High
P0984	Shift Solenoid E Control CKT Range/Performance
P0985	Shift Solenoid E Control Circuit Low
P0986	Shift Solenoid E Control Circuit High
P0987	Trans Fluid Press Sensor/Switch E Circuit
P0988	Trans Fluid Press Sensor/Switch E CKT Range/Performance
P0989	Trans Fluid Press Sensor/Switch E Circuit Low
P0990	Trans Fluid Press Sensor/Switch E Circuit High
P0991	Trans Fluid Press Sensor/Switch E CKT Intermittent
P0992	Trans Fluid Press Sensor/Switch F Circuit
P0993	Trans Fluid Press Sensor/Switch F CKT Range/Performance
P0994	Trans Fluid Press Sensor/Switch F Circuit Low
P0995	Trans Fluid Press Sensor/Switch F Circuit High
P0996	Trans Fluid Press Sensor/Switch F CKT Intermittent
P0997	Shift Solenoid F Control CKT Range/Performance
P0998	Shift Solenoid F Control Circuit Low
P0999	Shift Solenoid F Control Circuit High

1 YEAR LIMITED WARRANTY

PERFORMANCE TOOL® extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL® warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to one year from date of purchase, PERFORMANCE TOOL® will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part(s) being returned. For part(s) after 90 days, please remit your request, postage prepaid to:

PERFORMANCE TOOL, P.O. Box 88259 Tukwila, WA 98138

These warranties exclude blades, bits, punches, dies, bulbs, fuses, hoses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL® does not authorize any other person to make any warranty or to assume any liability in connection with its products. Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL® makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL® makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL® makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above. The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL® shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.