# ECO Lines™ F80/F150 RGY Color Change Guide

This is a supplemental user manual for F-Series Line Projectors that have color switching. Line colors and sequences can be manually set and remain in memory, or they can automatically switch via switches or a 0-10V control signal.

#### Description

Each RGY line projector incorporates a control board for color changing functions. The control board is configured with two buttons: M (mode) and S (speed). There are two inputs to the control board: switching and variable voltage. Both inputs are wired to the control panel, switch contact in the front, along with the M and S buttons, and variable 0-10V contact in the rear.


 $\Delta$  WARNING: Applying voltage to the switch contact input will damage the control module. Only the 0-10VDC input is configured for variable voltage.


### Color mode configuration

Switch voltage is designed to be configured with a switch such as a motion sensor and will alternate between selected modes based on the switch state. Variable voltage enables the projector to change between color presets based on the input voltage.

## Switch voltage

# Variable voltage





### Input 1 – Switch voltage

### Input 2 – Variable voltage

Green Flashing: 4-5V

Off: 0-1V Green: 1-2V Red: 2-3V Yellow: 3-4V

Mode 1: open contact	Į.
Mode 2: closed contact (dead short)  Cycle mode 1 color: single press M button	
Start: Off	7: Red/Green
1: Green	Altornating
	Alternating

Alternating

Red Flashing: 5-6V Yellow Flashing: 6-7V Red/Green Alternating: 7-8V Green/Yellow Alternating: 8-9V Red/Yellow Alternating: 9-10V

4: Green Flashing 5: Red Flashing

6: Yellow Flashing

3: Yellow

9: Red/YellowAlternatingOrder repeats

See following flowchart for additional details on controller



### **Controller logic flowchart**

