

Kodak EasyShare printer dock plus series 3



User's Guide

www.kodak.com

For interactive tutorials, www.kodak.com/go/howto



Eastman Kodak Company
Rochester, New York 14650
© Eastman Kodak Company, 2005

All screen images are simulated.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license.


Wi-Fi® is a registered trademark of the Wi-Fi Alliance.

Eastman Kodak Company is an authorized licensee of the SD trademark.

Kodak, EasyShare, Perfect Touch, ImageLink, and XtraLife are trademarks of Eastman Kodak Company.


P/N 4J3802_en

Front/top/side view



- | | |
|---|---|
| 1 Paper light  | 11 Paper tray door |
| 2 Battery charging lights/ Refresh button  | 12 Bluetooth wireless technology button/light  |
| 3 Color Cartridge light  | 13 Cancel button  |
| 4 Transfer button/light  | 14 Picture Size button |
| 5 Slide Show button/light  | 15 Picture Size lights  |
| 6 Red Eye Reduction button/light  | 16 Accessory door |
| 7 Print button/light  | 17 Card slot light |
| 8 4-way control  | 18 SDIO/SD/MMC card slot |
| 9 IR sensor | 19 USB device connector light |
| 10 Paper tray | 20 USB device connector |
| | 21 Audio/Video (A/V) out connector |

Back/top/side view



- | | | | |
|---|-----------------------------|---|--------------------------------------|
| 1 | Camera connector | 4 | Cooling vent |
| 2 | Power connector (DC-in) | 5 | Slot for paper path |
| 3 | USB connector (to computer) | 6 | Color cartridge (installed as shown) |
| | | 7 | Cartridge door |

Table of contents

1 Getting started	1
Finding a location for your printer dock.....	1
Installing the custom camera insert.....	2
Connecting the power	3
Handling and storing the color cartridge	3
Installing and removing the color cartridge	4
Handling and storing the paper	5
Loading paper	6
Installing and removing the paper tray.....	7
2 Setting up your digital camera	8
Docking and charging your digital camera	8
Setting the picture quality.....	10
Tagging pictures for printing.....	11
3 Printing without a computer	12
Printing from your digital camera.....	12
Printing from the internal card reader	13
Printing from a Kodak card reader	14
Printing tagged pictures	15
Printing from a PictBridge compatible camera or device	15
Changing the printed picture size	16
Reducing red eye in your prints.....	20
Canceling printing.....	20
Removing the perforated tabs from the paper	21

4 Using your printer dock with a computer	22
Installing the software.....	22
Connecting to a computer	24
Transferring pictures from your digital camera.....	26
Transferring pictures from the internal card reader	28
Transferring pictures from a Kodak card reader	29
Printing from a computer.....	30
Canceling printing.....	33
Uninstalling the software	34
5 Using the wireless features of your printer dock	35
Printing from a Bluetooth® wireless technology enabled device	35
Printing and transferring over a Wi-Fi wireless network	37
Printing from an infrared device.....	42
Using the Kodak remote control	42
6 Reviewing pictures	43
Reviewing pictures on the camera screen.....	43
Displaying pictures on a television	43
Running a slide show	44
7 Care and maintenance	45
General care	45
Cleaning the paper feed roller	46
Traveling with your printer dock	47
8 Troubleshooting	48
Printing problems.....	48
Transfer/communication problems	56
Wireless network connection	57
Status lights	58
Helpful links	66
Telephone customer support	67

9 Appendix	68
Printer dock specifications	68
Wireless channels.....	69
Important safety instructions	70
Extending battery life	71
Upgrading your software and firmware.....	72
Additional care and maintenance	72
Warranty.....	73
Regulatory compliance	75


1

Getting started

Finding a location for your printer dock

- Place the printer dock on a flat, clean, dust-free surface, in a dry location, and out of direct sunlight.


5 in. (12.7 cm)



- **Allow at least 5 in. (12.7 cm) clearance** from the back of the printer dock for paper travel.
- For proper ventilation, make sure the top and back of the printer dock are not blocked.
- When connecting power or USB cables, keep the cables clear of the paper path to the front and rear of the printer dock.
- Avoid areas where ventilation ducts, open doors, or frequent passersby might expose the printer dock and paper to high levels of dust and debris. Airborne dirt particles can affect picture quality.
- Allow enough space on all sides of the printer dock to let you connect and disconnect cables, change the color cartridge, and add paper.

Installing the custom camera insert

IMPORTANT: Use the custom insert that came with your digital camera to dock the camera, otherwise the camera may not fit on the printer dock.



- Locate and install the custom insert included with your camera.

IMPORTANT: Depending on your camera connector, you may also need to use the optional Kodak dock adapter kit D-26.*

- a Remove any packing material covering the connector.
- b Place the rear tabs of the insert in the slots toward the back of the printer dock.
- c Press the front of the insert down and snap into place.

* Contact customer support for a dock adapter if it is not included with your product. Visit www.kodak.com/go/dfiswwcontacts.

For Kodak EasyShare camera and dock compatibility, visit www.kodak.com/go/adapterkitchart.

Connecting the power




RISK OF ELECTRIC SHOCK:

Use only the AC power adapter included with your printer dock. Other adapters or cords can damage your camera, printer dock, or computer.

- 1 If a digital camera is docked, remove it.
- 2 Connect the AC power cord to the AC power adapter, then to the back of the printer dock.

NOTE: Depending on your country, the AC power cord plug may be different from the one shown.

- 3 Plug the AC power cord into a power outlet.




Handling and storing the color cartridge

- For best quality prints, store the color cartridge in a location where the temperature does not exceed 85 °F (30 °C).
- To avoid getting fingerprints on the ribbon, handle the color cartridge by the spool ends.
- Keep the color cartridge away from direct sunlight and out of high-temperature environments (such as a vehicle parked in the sun).

Installing and removing the color cartridge


- 1 Open the cartridge door on the side of the printer dock.



- 2 Check to make sure there is no slack in the color cartridge ribbon.


To remove slack, push in on the cartridge spool, then rotate the spool clockwise.

IMPORTANT: *Be careful not to rotate the spool more than that necessary to remove slack. Doing so could reduce the number of prints you are able to make.*




- 3 Slide the color cartridge in, label side up, with the arrow pointing toward the printer dock. Push the cartridge until it "clicks" into place.

- 4 Close the cartridge door.




- To remove the color cartridge, open the cartridge door, then push up on the green lever and slide the cartridge out.

IMPORTANT: *The color cartridge may lock in place if there is a paper error. Do not attempt to remove the cartridge without first clearing the paper error. Make sure the Paper light is off before attempting to remove the cartridge (see Paper light under [Status lights](#), page 58).*



- During printing, or upon connecting the power, the Color cartridge light glows amber for 10 seconds if there are five or fewer prints remaining.
- When the cartridge is depleted, the Color cartridge light glows red. Install a new cartridge (see [page 4](#)). After installing a new color cartridge, press the Print button, , to clear the cartridge error and resume printing.


Handling and storing the paper




- To avoid fingerprints, handle the paper by the edges or by the perforated tabs. Do not touch the glossy side of the paper.
 - When storing, remove the paper tray, then close the paper tray cover and paper tray door to keep out dust and debris. Store paper flat.
- Keep the paper away from direct sunlight and out of high-temperature environments (such as a vehicle parked in the sun).

Loading paper

1 Remove the paper tray from the printer dock if installed (see [page 7](#)).




2 From the closed position, slide the paper tray cover back, about 3 in. (8 cm) to the second "click". This is the fully open, or paper loading position.





3 Carefully "fan" the paper to keep the sheets from sticking together.

IMPORTANT: *Do not load more than 25 sheets of paper. Use the upper limit line inside the paper tray as a guide to prevent overloading. Do not load paper that is missing perforated tabs.*



4 Load the paper into the paper tray, with the Kodak logo side facing down.

Installing and removing the paper tray



- 1 From the closed position, slide the paper tray cover partway back, about 1.2 in. (3 cm) to the first "click". This is the semi-open, or installation position.
- 2 Open the paper tray door on the printer dock.
- 3 Slide the paper tray in the printer tray slot until the tray locks into place.

IMPORTANT: *To ensure the paper tray fits squarely on the printer dock, make sure to keep the paper tray cover in the installation position while installing.*

- Pull the paper tray out to remove it.
- Close the paper tray cover and paper tray door to keep out dust and debris.
- When the paper tray is empty, the Paper light glows red. Load paper (see [page 6](#)). After refilling and installing the paper tray, press the Print button, , to clear the paper error and resume printing.

2

Setting up your digital camera

Docking and charging your digital camera

Docking your digital camera lets you make prints directly from the camera and transfer pictures from the camera to the computer. Docking your camera also charges an installed Kodak Ni-MH rechargeable digital camera battery or Kodak Li-Ion rechargeable digital camera battery. See your camera user's guide for details.


Plus, the Kodak EasyShare printer dock plus series 3 is ImageLink print system compatible. This allows you to dock not only Kodak EasyShare digital cameras, but other brands of ImageLink system compatible digital cameras as well.


1 Make sure a custom camera insert is installed on the printer dock (see [page 2](#)). If your camera uses a Kodak Ni-MH rechargeable digital camera battery or Kodak Li-Ion rechargeable digital camera battery, insert in your camera for charging.

2 Place the camera on the printer dock. Push down to seat the connector.

IMPORTANT: *Keep the camera wrist or neck strap clear of the paper path to the front and rear of the printer dock.*

■ The Kodak Ni-MH rechargeable digital camera battery and the Kodak Li-Ion rechargeable digital camera battery charge up to 3 hours.





- The Battery charging lights turn on as charging progresses. Charging is complete when all three lights are lit.
- You may leave the camera on the printer dock to maintain the charge.


For Kodak EasyShare camera and dock compatibility, visit

www.kodak.com/go/adaptkitchart.

For battery information for other brands of ImageLink system compatible cameras, see the camera user's guide.

Refreshing the Kodak Ni-MH rechargeable digital camera battery


IMPORTANT: *The battery refresh feature is intended for use with the Kodak Ni-MH rechargeable digital camera battery only. Li-Ion batteries do not require refreshing.*



If you are getting fewer than 20 pictures per charge with your Kodak Ni-MH rechargeable digital camera battery, follow the tips under [Extending battery life, page 71](#). If these tips don't help, the battery may need to be refreshed. The refresh cycle completely discharges the battery, then fully recharges it.



NOTE: A full refresh cycle takes up to 8 hours, depending on how much charge is left in the battery. For best results, refresh the battery overnight; do not interrupt the discharge/recharge cycle.

- 1 Make sure the Ni-MH rechargeable battery is in the camera.
- 2 Place your EasyShare camera on the printer dock (see [page 8](#)).



- Press and hold the Battery charging lights/Refresh button, , until the Battery charging lights begin flashing green (approximately 5 seconds).

The charging lights monitor the refresh status:

	Descending blinking green lights	Discharging battery (lights turn off as discharging progresses).
	Ascending steady green lights	Charging battery (lights turn on as charging progresses). Charging is complete when all three lights are lit.

To purchase a Kodak Ni-MH rechargeable digital camera battery for your digital camera visit www.kodak.com/go/accessories. See your camera user's guide for battery compatibility.

Setting the picture quality



Before taking pictures, change the picture quality setting (or resolution) on your digital camera to **3:2 ★★★**. This ensures that the pictures you take are proportional to the printer dock paper, preventing unwanted cropping of your pictures. See your camera user's guide for more information.

Tagging pictures for printing

NOTE: The following procedure pertains to Kodak EasyShare digital cameras. For information on tagging pictures on other brands of ImageLink system compatible cameras, see the camera user's guide.

- 1 Press the Share button on your camera,  share.
- 2 Press   to locate a picture.
- 3 Press   to highlight Print  then press the OK button.*
- 4 Optional: You can apply a print quantity to other pictures. Press   to locate a picture. Keep the print quantity as is, or press   to change it. Repeat this step until the desired print quantity is applied to the pictures.
- 5 Press the OK button, then press the Share button to exit.

* To tag all pictures in the storage location, highlight Print All , press the OK button, then indicate the number of copies as described above.

To remove print tagging from all pictures in the storage location, highlight Cancel Prints , then press the OK button.

See your camera user's guide for details.

To print tagged pictures from your Kodak EasyShare digital camera, see [page 15](#). To print tagged pictures from your computer, see [page 30](#).

3

Printing without a computer

Printing from your digital camera


- 1 Take a picture with your camera (see your camera user's guide).
- 2 Place the camera on the printer dock (see [page 8](#)).

The current or most recent picture appears on the camera screen.

- To print the current picture, press the Print button, .

NOTE: If the camera or installed memory card contains pictures tagged for printing, instead of printing the current picture, all tagged pictures are printed (see [page 15](#)).

- To review and choose pictures to print, press the Left/Right control on the printer dock, . For each picture you want to print, press  to select the number of copies. When finished with your selections, press the Print button, .



The Print light blinks, and printing starts. The paper cycles four times before it is ejected. The first three passes apply layers of yellow, magenta, and cyan colors to the print, and the fourth pass applies the Kodak XtraLife™ coating that protects and preserves the image.

IMPORTANT: *To avoid paper misfeeds or jams, wait until printing is complete before removing paper, the paper tray, the color cartridge, or the camera.*


- To exit without printing, press the Cancel button, **X**.

Printing from the internal card reader

Use the built-in card slot to print pictures directly from your SDIO, SD, or MMC memory card.

1 Open the accessory door on the printer dock.

IMPORTANT: Insert the card only as shown. Do not force the card into the card slot. Do not insert or remove a card when the printer dock is transferring pictures (see [page 26](#)) or if the card slot light is blinking.



2 Orient the SDIO, SD, or MMC card as shown, then push the card into the card slot to seat the connector.

- To print the current picture, press the Print button, .

NOTE: If the memory card contains pictures tagged for printing, instead of printing the current picture, all tagged pictures are printed (see [page 15](#)).


IMPORTANT: To avoid paper misfeeds or jams, wait until printing is complete before removing paper, the paper tray, the color cartridge, or the camera.

- To exit without printing, press the Cancel button, **X**.
- To remove the card, push it in, then release it. When the card is partially ejected, pull it out.

Purchase an SD or MMC card and other accessories at a retailer of Kodak products, or visit www.kodak.com/go/accessories.

Printing from a Kodak card reader

Your printer dock is compatible with the Kodak 8-in-1 card reader (sold separately). Other Kodak USB card readers may work with your printer dock; however, other manufacturers' card readers are not supported.



- 1 Open the accessory door on the printer dock.
- 2 Plug the USB connector from the card reader into the USB device connector located on the side of the printer dock.

- 3 Insert the memory card into the card reader (see your card reader user's guide for details). Do not insert more than one card at a time.

- To print the current picture, press the Print button, .

NOTE: If the memory card contains pictures tagged for printing, instead of printing the current picture, all tagged pictures are printed (see [page 15](#)).

IMPORTANT: *To avoid paper misfeeds or jams, wait until printing is complete before removing paper, the paper tray, the color cartridge, or the camera.*

- To exit without printing, press the Cancel button, **X**.

Purchase a Kodak card reader and other accessories at a retailer of Kodak products, or visit www.kodak.com/go/accessories.

Printing tagged pictures

If your camera or memory card contains pictures tagged for printing (see [page 11](#) or your camera user's guide), the printer dock gives you the option to print tagged pictures first. If your camera is docked, a message appears on the camera screen indicating that tagged pictures have been found:

- **To print tagged pictures**—press the Print button, .

The Print light blinks, printing starts, and tagged pictures are printed. Print tags are removed from tagged pictures on your camera or card as they are printed.


IMPORTANT: *To avoid paper misfeeds or jams, wait until printing is complete before removing paper, the paper tray, the color cartridge, or the camera.*

- **To bypass printing of tagged pictures**—press the Cancel button, **X**.

Printing from a PictBridge compatible camera or device

The Kodak EasyShare printer dock plus offers PictBridge compatibility, which lets you communicate with any PictBridge compatible camera or device.

- 1 Open the accessory door on the printer dock.



- 2 Plug the USB connector from the PictBridge compatible camera or device into the USB device connector located on the side of the printer dock.
- 3 Use your PictBridge compatible camera or device to review pictures, choose printing options, and print. See your device user's guide for details.

IMPORTANT: *To avoid paper misfeeds or jams, wait until printing is complete before removing paper, the paper tray, the color cartridge, or the camera.*

Changing the printed picture size

- Before printing, press the Picture Size button repeatedly to scroll through and select a picture size.

Picture Size setting		Number and size of prints per sheet
	1 up (full photo)	One 4 x 6 in. (10.2 x 15.2 cm) picture
	2 up (card size)	Up to two 2.1 x 3.3 in. (5.4 x 8.5 cm) pictures
	4 up (wallet size)	Up to four 2 x 3 in. (5.1 x 7.6 cm) pictures
	9 up (mini photo)	Up to nine 1.3 x 2 in. (3.4 x 5.1 cm) pictures

To change the default picture size:

- Select a picture size (see above), then press and hold the Picture Size button for 4 seconds.

The selected Picture Size light blinks, then glows steady.

Effect of picture size on number of copies

In most cases, the picture size setting also determines the number of copies that are printed. For example, if you choose to print a picture with 2 up selected, 2 copies are printed on one sheet of paper.

When printing tagged pictures (see [page 15](#)), the number of copies that are printed is determined by the setting on your camera or device. For example, if three pictures on your camera are each tagged for printing one copy, and the 4 up option on the printer dock is selected, three 2 x 3 in. (5.1 x 7.6 cm) pictures are printed on one sheet of paper.

For best results, choose a picture size or number of copies (on your camera or device) that optimizes the use of white space on the paper.

NOTE: When printing from a PictBridge compatible camera or device (see [page 15](#)), picture size and number of copies are determined by the device's multi-up and copies settings. Change these settings on your device before printing. If the picture size option selected on your device does not match any of the picture size options on the printer dock, the closest available picture size option on the printer dock is automatically selected.

Printing different pictures on the same sheet



- 1 Tag the pictures you want to print on your digital camera (see [page 11](#)).
- 2 Place the camera on the printer dock, or insert the memory card into the internal card reader or a connected Kodak 8-in-1 card reader (sold separately).
- 3 Press the Picture Size button repeatedly to select either 2 up , 4 up , or 9 up , depending on the picture size you wish to print (see [page 16](#)).
- 4 Press the Print button, , to begin printing.

NOTE: If you select more than one copy of a picture when tagging them on your camera, duplicate pictures are printed on the same sheet (see [page 19](#)).

Printing duplicate pictures on the same sheet

Method 1: by setting it up on your digital camera



- 1 Tag the pictures you want to print on your digital camera (see [page 11](#)). **For each picture**, choose the number of copies you would like to print.
- 2 Place the camera on the printer dock, or insert the memory card into the internal card reader or a connected Kodak 8-in-1 card reader (sold separately).
- 3 Press the Picture Size button repeatedly to select either 2 up , 4 up , or 9 up , depending on the picture size you wish to print (see [page 16](#)).
- 4 Press the Print button, , to begin printing.

Method 2: using the printer dock

- 1 Place the camera on the printer dock.

The current or most recent picture appears on the camera screen.

- 2 Press the Left/Right control on the printer dock, , to review and choose a picture to print.
- 3 Press the Print button, .

The copy screen appears.

- Press  to select the number of copies, then press the Print button, .

Reducing red eye in your prints

The Kodak EasyShare printer dock plus series 3 incorporates technology that automatically detects red eye in your subjects, and lets you correct your prints with push of a button.

To reduce red eye in your printed pictures:

- When setting up a print job, press the Red Eye Reduction button, , before pressing the Print button.

Red eye reduction is applied to any images that were captured using the flash on your digital camera.

To turn red eye reduction default to always on:

- Press and hold the Red Eye Reduction button for 5 seconds.

The Red Eye Reduction light blinks, then glows steady.

Repeat to turn the default to always off.

NOTE: The Red Eye Reduction button is disabled when printing from a computer. If printing from a computer (see [page 30](#)), use the Kodak EasyShare software on your computer.

Printing time may slightly increase when using red eye reduction.


Canceling printing

- Press the Cancel button, **X**.

The print job is canceled and ejected from the printer dock. If you cancel printing during the fourth pass (clear coat), the paper is ejected upon completion.

Removing the perforated tabs from the paper

IMPORTANT: *Remove perforated tabs only after printing. Paper missing perforated tabs will not feed properly.*




- 1 Fold the tabs up, then down.
- 2 Remove each tab and discard.

4

Using your printer dock with a computer

Install Kodak EasyShare software from the included CD to do more with your printer dock, including transferring pictures and printing from your computer.

Installing the software



IMPORTANT: *Install Kodak EasyShare software before connecting the printer dock to the computer.*

- 1 Close all software applications that are open on your computer (including anti-virus software).
- 2 Place the Kodak EasyShare software CD into the CD-ROM drive.

- 3 Load the software:

Windows OS-based computer—if the install window does not appear, choose Run from the Start menu and type **d:\setup.exe** where **d** is the drive letter that contains the CD.

Mac OS X—double-click the CD icon on the desktop, then click the Install icon.

- 4 Follow the on-screen instructions to install the software.

Windows OS-based computer—Select Complete to automatically install the most commonly used applications, or Custom to choose the ones you wish to install.

Mac OS X—follow the on-screen instructions.


IMPORTANT: *To use your printer dock with a computer, you must install the printer driver. If you choose Custom, make sure the printer dock is selected. The printer driver is automatically installed if you choose Complete.*

- 5 If prompted, restart the computer. If you turned off anti-virus software, turn it back on. See the anti-virus software manual for details.

For information on the software applications included on the Kodak EasyShare software CD, click the Help button in the EasyShare software.

Connecting to a computer

IMPORTANT: Make sure your camera is *NOT* docked when you connect the printer dock to the computer.



- 1 Make sure Kodak EasyShare software is installed on the computer (see [page 22](#)).
- 2 Plug the labeled  end of the included USB cable into the labeled USB port on your computer.
See your computer documentation for details.
- 3 Plug the other end of the USB cable into the USB connector on the back of the printer dock.

On Windows operating systems, the first time the printer dock is connected, the new hardware wizard runs. If prompted, follow the instructions on the screen.

See your computer documentation for details.

NOTE: If a Kodak Wi-Fi[®] card (sold separately) is inserted the first time the printer dock is connected, the Add Wireless Printer Assistant may appear. Follow the instructions on the screen.

4 Mac OS X—add the printer dock to your computer:

Add the printer dock to your computer (Mac OS 10.2.8 - 10.3.9):

- a** Open the finder window then click the Applications button. Or, open the Applications folder on your operating drive.
- b** Open the Utilities folder, then double-click Printer Setup Utility.
- c** Click Add.
- d** From the menu, select Kodak printer.
- e** Select the printer dock, then click Add.

The printer dock is added to your computer.

Add the printer dock to your computer (Mac OS 10.4):

- a** Open the finder window then click the Applications button. Or, open the Applications folder on your operating drive.
- b** Open the Utilities folder, then double-click Printer Setup Utility.
- c** Click Add.
- d** From the list of printers, select the printer dock, then click More Printers.
- e** From the pull-down menu at the top of the screen, select Kodak printer.
- f** Select the printer dock, then click Add.

The printer dock is added to your computer.

Transferring pictures from your digital camera

- 1 Make sure Kodak EasyShare software is installed (see [page 22](#)) and the printer dock is connected to your computer (see [page 24](#)).
- 2 If you have an optional USB card reader, disconnect it from the printer dock.
- 3 Place the camera on the printer dock (see [page 8](#)).
- 4 Press the Transfer button, , on the printer dock.

Kodak EasyShare software opens on your computer (if it is installed).

- If prompted to choose a Sync and Transfer Manager option, pick an option that best suits your situation:

Yes, synchronize with my software (recommended if installing on a single or "primary" computer)—each time your camera connects to EasyShare software, pictures and videos are transferred to your computer. In addition, the images on your camera and in EasyShare software on your computer are updated according to the synchronization options you set in EasyShare software (see [page 27](#)).

No, only transfer my pictures (recommended if installing on an additional, or "secondary" computer)—each time your camera connects to EasyShare software, pictures and videos are transferred to your computer. Synchronization is disabled.

NOTE: You can change Sync and Transfer Manager settings in EasyShare software after EasyShare software is installed. Click the Help button in the Kodak EasyShare software for details.

IMPORTANT: *Do not remove the camera when the printer dock is transferring pictures.*

The printer dock Transfer light blinks while the pictures are being transferred. The Transfer light continues to blink until the Transfer or Print button is pressed or the camera is removed from the printer dock.

- To stop transfer, or to return the printer dock to ready status after transferring pictures, press the Cancel button, **X**.

See the Kodak EasyShare software Help for details.

Synchronizing with Kodak EasyShare software (Kodak EasyShare cameras only)

Synchronizing with Kodak EasyShare software is an easy way to organize the images on your Kodak EasyShare camera without making these same changes to your images in the software (and vice versa). More than just transferring pictures and videos from your camera to your computer, synchronizing lets you:

- Automatically update the date and time on your camera with the date and time on your computer
- Exchange address book information between the camera and EasyShare software
- Update albums
- Move favorites and selected pictures from your EasyShare software collection to your EasyShare camera

NOTE: The synchronization options described above are available only to Kodak EasyShare digital cameras that support them. See your camera user's guide, or click the Help button in the Kodak EasyShare software for details.

Each time your EasyShare camera connects to EasyShare software, the updates you selected in your synchronization settings are made. To change synchronization settings, use the EasyShare software Sync and Transfer Manager. Click the Help button in the Kodak EasyShare software for details.

To synchronize your Kodak EasyShare camera with EasyShare software:

Configure the synchronization options in EasyShare software according to the capabilities of your EasyShare digital camera. Then connect your printer dock to the computer, using either the USB cable, or an optional Wi-Fi card to connect to an available Wi-Fi wireless network (see [page 37](#)).


Refer to the instructions under [Transferring pictures from your digital camera, page 26](#). Pressing the Transfer button initiates the synchronization and transfer process. Follow the prompts on the screen.

See your camera user's guide, or click the Help button in the Kodak EasyShare software for details.

Transferring pictures from the internal card reader

- 1 Make sure Kodak EasyShare software is installed (see [page 22](#)) and the printer dock is connected to your computer (see [page 24](#)).
- 2 Open the accessory door on the printer dock.
- 3 If a digital camera is docked, remove it.

IMPORTANT: *Insert the card only as shown. Do not force the card into the card slot.*



- 4 Orient the SD/MMC card as shown, then push the card into the card slot to seat the connector.

- 5 Press the Transfer button, , on the printer dock. Kodak EasyShare software opens on your computer (if it is installed).

The printer dock Transfer light blinks while the pictures are being transferred. The Transfer light continues to blink until the Transfer or Print button is pressed, or until the connection is no longer available.


IMPORTANT: *Do not insert or remove a card when the printer dock is transferring pictures or if the card slot light is blinking.*

- To stop transfer, or to return the printer dock to ready status after transferring pictures, press the Cancel button, **X**.
- To remove the card, push it in, then release it. When the card is partially ejected, pull it out.

Transferring pictures from a Kodak card reader

Your printer dock plus is compatible with the Kodak 8-in-1 card reader (sold separately). Other Kodak USB card readers may work with the printer dock plus; however, other manufacturers' card readers are not supported.

- 1 Make sure Kodak EasyShare software is installed (see [page 22](#)) and the printer dock is connected to your computer (see [page 24](#)).
- 2 Open the accessory door on the printer dock.
- 3 If a digital camera is docked, remove it. If there is a memory card in the card slot, remove it as well.



- 4 Plug the USB connector from the card reader into the USB connector located on the side of the printer dock.

- 5 Insert the memory card into the card reader (see your card reader user's guide for details). Do not insert more than one card at a time.
- 6 Press the Transfer button, , on the printer dock.

Kodak EasyShare software opens on your computer (if it is installed).

The printer dock Transfer light blinks while the pictures are being transferred. The Transfer light continues to blink until the Transfer or Print button is pressed, or until the connection is no longer available.

IMPORTANT: *Do not insert or remove a card when the printer dock is transferring pictures or if the USB device connector light is blinking.*

- To stop transfer, or to return the printer dock to ready status after transferring pictures, press the Cancel button, **X**.

Printing from a computer

We recommend using Kodak EasyShare software (included) for printing. This software lets you take advantage of a wide range of features, including full color enhancement, red eye reduction, picture organization, and much more.

If there are no pictures on your computer, use the printer dock to transfer pictures from your camera or memory card before printing (see [page 26](#)).

IMPORTANT: *Wait until printing is complete before removing paper or the paper tray. Failure to do so can cause paper misfeeds or jams.*

Printing with Kodak EasyShare software

- 1 Make sure Kodak EasyShare software is installed (see [page 22](#)) and the printer dock is connected to your computer (see [page 24](#)).
- 2 Click the My Collection tab.
- 3 Select the pictures you wish to print.
- 4 Click the Print at Home tab.
- 5 Make sure the printer dock is selected as the current printer.
- 6 Change any other settings, such as paper size and print layout, then click Print.

Printing tagged pictures from your computer

- 1 Make sure Kodak EasyShare software is installed (see [page 22](#)) and the printer dock is connected to your computer (see [page 24](#)).
- 2 Transfer the tagged pictures to your computer (see [page 26](#)).
- 3 Click the Print at Home tab.
- 4 Make sure the printer dock is selected as the current printer.
- 5 Change any other settings, such as paper size and print layout, then click Print.

NOTE: The Picture Size and Red Eye Reduction buttons on the printer dock are disabled when printing from a computer. Set printing options using EasyShare software.

See the EasyShare software Help for details.

Printing using other applications

- 1** Make sure the printer driver is installed (see [page 22](#)), and the printer dock is connected to your computer (see [page 24](#)).
- 2** Open the pictures you wish to print in the application from which you want to print.
- 3** Access printer settings by selecting Print or Page Setup from the File menu (depending on your application and operating system).
- 4** Make sure the printer dock is selected as the current printer.
- 5** Change any other settings as needed, then click OK or Print. (Depending on your application and operating system, you may first need to return to the main menu and select Print from the File menu.)

NOTE: The Picture Size and Red Eye Reduction buttons on the printer dock are disabled when printing from a computer. Set printing options using EasyShare software.

Choosing a color mode

Kodak's color mode feature uses automatic color correction to help you make great-looking prints in no time. Your printer dock features three color mode options:

Enhanced—to get richer, more vivid colors.

Natural—to get great, natural color for everyday picture-making.

None—to disable automatic color correction.

To change the color mode:

Windows 2000/XP OS:

- 1 From the Start menu, select Settings, then select Printers.
NOTE: Depending on your Start Menu configuration, you may need to select Printers and Faxes from the Control Panel.
- 2 Right-click the printer dock icon, then select Printing Preferences.
- 3 Click the Color Correction tab.
- 4 Select a color correction option, then click OK.

Windows 98/ME OS:

- 1 From the Start menu, select Settings, then select Printers.
- 2 Right-click the printer dock icon, then select Properties.
- 3 Click the Color Correction tab.
- 4 Under Color Correction, select a color mode option.
- 5 Click OK when complete.

Mac OS X:

- 1 Make sure the printer dock is selected as the current printer.
- 2 From the application File menu, select Print.
- 3 Select Color Control from the Copies & Pages pop-up menu.
- 4 Select Kodak color.
- 5 Select a color mode option.

Canceling printing

Windows OS-based computer:

- 1 Double-click the printer icon in the system tray.
- 2 Click the print job you want to cancel.
- 3 Select Document, then select Cancel.

Mac OS X:

- 1 In Print Center, double-click the printer icon.
- 2 Click the job you want to cancel, then select Delete.

Canceling printing from the printer dock

- Press the Cancel button, **X**, on the printer dock.

The print job is canceled and ejected from the printer dock. If you cancel a print during the fourth pass (clear coat), the paper is ejected upon completion.

Uninstalling the software

If you wish to remove the printer driver or EasyShare software from your computer, use the following procedure:

Windows OS-based computer:

- 1 Open the Control Panel:

From the Start menu, select Settings, then select Control Panel. (On Windows XP operating systems, depending on your configuration, Control Panel may be found in the Start menu.)

- 2 Double-click Add/Remove Programs.
- 3 Select Kodak EasyShare software, then click Remove.
- 4 Select Modify to uninstall single components, such as the printer driver, or select Remove to uninstall all components.
- 5 Follow the on-screen instructions. Restart the computer if prompted.

Mac OS X:

- 1 Double-click the operating drive for your system.
- 2 Select Library, then select Printers.
- 3 Open the Kodak folder, then open the printer dock folder.
- 4 Double-click the printer dock uninstaller program.
- 5 Follow the on-screen instructions.

Using the wireless features of your printer dock

Printing from a Bluetooth® wireless technology enabled device

The on-board Bluetooth radio uses Bluetooth 1.1 technology, allowing you to print from compatible Bluetooth wireless technology enabled devices, including many personal digital assistants (PDAs) and wireless mobile telephones. Use your wireless device to review pictures, choose printing options, and print.

NOTE: The Kodak EasyShare printer dock plus series 3 supports OPP (Object Push) and FTP (File Transfer) profiles only.


By default, the on-board Bluetooth radio is on and ready to receive signals from a compatible Bluetooth technology enabled device.

To turn the Bluetooth radio off:

- Press the Bluetooth button, . Press again to turn it on.

To turn the Bluetooth radio *default* to always off:

- Press and hold the Bluetooth button for 5 seconds. Repeat to turn the default to always on.



NOTE: You must be within 30 ft (10 m) or less of the printer dock for the wireless signal to be received.

To print from your Bluetooth wireless technology enabled device:

- 1 Set wireless technology on your device to On, then select pictures to print.

The discovery process starts, then available Bluetooth wireless technology devices are displayed on your device.

- 2 Select your printer dock on your device.

NOTE: If your device requires you to set authentication, enter pin number 1111 (default).

- 3 Select Send or Beam on your device.

The selected images are sent to the printer dock for printing.

See your device user's guide for details.

To configure Bluetooth wireless technology settings for your printer dock:

- 1 Make sure the printer driver from the included Kodak EasyShare software CD is installed on your computer (see [page 22](#)), then connect the printer dock to your computer with the USB cable (see [page 24](#)).
- 2 Open the Kodak wireless printer configuration utility:

Windows OS-based computer—

- a From the Start menu, select Programs (or All Programs).
- b Open the Kodak folder, then open the Kodak EasyShare printer dock folder.
- c Select Kodak wireless printer configuration utility.

Mac OS X—

- a Open the finder window then click the Applications button. Or, open the Applications folder on your operating drive.
- b Open the Utilities folder, then double-click Printer Setup Utility.
- c Double-click the printer dock from the list, then click Utility.

The configuration utility opens on your computer.

3 Next to Show, select Bluetooth.


4 Change settings as necessary.

See the configuration utility Help for details.


Printing and transferring over a Wi-Fi wireless network

Insert a Kodak Wi-Fi® card (sold separately) into the card slot. Then, print and transfer pictures using your printer dock on an existing Wi-Fi wireless (Infrastructure) network, or print pictures directly to your printer dock over a Wi-Fi wireless device-to-device (Ad-Hoc) network.

Example of a wireless Infrastructure network:




Example of an Ad-Hoc network:



Adding your printer dock to a Wi-Fi wireless network

- 1 Open the accessory door on the printer dock.

IMPORTANT: Insert card only as shown. Do not force the card into the card slot.



- 2 Orient the Kodak Wi-Fi® card as shown, then push the card into the card slot to seat the connector.

The card slot light blinks as the printer dock scans for available networks. Once connected, the card slot light glows steady.

NOTE: When properly inserted, the card sticks out slightly, serving as an antenna for receiving Wi-Fi signals.

- To remove the card, push it in, then release it. When the card is partially ejected, pull it out.

- 3 Make sure the printer driver from the included Kodak EasyShare software CD is installed on your computer (see [page 22](#)), then connect the printer dock to your computer with the USB cable (see [page 24](#)).

- 4** Configure the printer dock Wi-Fi settings (such as SSID and security) and add the printer dock as a wireless printer on your Wi-Fi wireless network:

Windows OS-based computer—

Configure the printer dock Wi-Fi settings:

- a** From the Start menu, select Programs (or All Programs).
- b** Open the Kodak folder, then open the Kodak EasyShare printer dock folder.
- c** Select Kodak wireless printer configuration utility.
The configuration utility opens on your computer.
- d** Next to Show, select WiFi Primary.
- e** Change settings as necessary to match the settings of your Wi-Fi wireless network. Click Wizard to help guide you through the wireless setup process.
See the configuration utility Help for details.

Add the printer dock as a wireless printer to your computer:

- a** From the Start menu, select Programs (or All Programs).
- b** Open the Kodak folder, then open the Kodak EasyShare printer dock folder.
- c** Select Kodak wireless printer computer setup assistant.
- d** Click Next.
- e** Select the printer dock, then click Next.

The wireless printer dock is added to your computer (represented as a wireless "copy" of your printer dock in the Windows OS list of printers).

Mac OS X—

Add the printer dock to your computer:

See [Connecting to a computer, page 24](#).

Configure the printer dock Wi-Fi settings:

- a** Open the finder window then click the Applications button. Or, open the Applications folder on your operating drive.
 - b** Open the Utilities folder, then double-click Printer Setup Utility.
 - c** Select the printer dock from the list, then click Utility.
 - d** Change Wi-Fi settings as necessary to match the settings of your Wi-Fi wireless network. See the wireless configuration utility Help for details.
- 5** Close all programs on your computer, then disconnect the USB cable between the computer and the printer dock.
- 6** (Optional) To print a copy of the current Wi-Fi settings for your printer dock:
 - At the same time, press and hold the Print button, , and the Transfer button, , for 5 seconds.

Print pictures over your Wi-Fi wireless network

- 1 Add the printer dock to your Wi-Fi wireless network (see [page 38](#)).

IMPORTANT: *Add the printer dock to the same network as the computer or device you want to print from. If printing from EasyShare software, in Preferences, make sure Enable wireless connections is selected (click the Help button in the EasyShare software for details).*

- 2 On your computer or on your Wi-Fi enabled device, select and print pictures. See your computer or device user's guide for details.

Transfer pictures over your Wi-Fi wireless network (EasyShare digital cameras only)

- 1 Add the printer dock to your Wi-Fi wireless network (see [page 38](#)).

IMPORTANT: *Add the printer dock to the same network as the computer you want to transfer from. If you have two or more computers on the same network, use the Kodak wireless printer configuration utility on your computer to choose which computer to transfer to (see the wireless configuration utility Help for details).*


- 2 Dock your EasyShare digital camera (see [page 8](#)), then press the Transfer button, , to transfer pictures to EasyShare software on your computer (see [page 26](#)).

NOTE: If the printer dock is connected to the computer with the USB cable, pictures are transferred using the cable connection instead of the wireless connection.

See your computer or device user's guide, or visit www.kodak.com/go/wifisupport and www.wi-fi.org for more information.

Printing from an infrared device

With the on-board infrared sensor, you can print from devices that use IrDA® wireless technology. As with Bluetooth technology, IrDA wireless technology is used in many handheld devices such as PDAs and wireless mobile telephones. Use your infrared device to review pictures, choose printing options, and print. See your device user's guide for details.



NOTE: When using the remote control or a wireless infrared device with your printer dock, make sure the IR sensor on the printer dock is not obstructed.

For more information, visit www.irda.org.

Purchase a Kodak remote control, a Kodak wireless USB adapter, and other accessories at a retailer of Kodak products, or visit www.kodak.com/go/accessories. Also, be sure to visit periodically for new wireless printing accessories.

Using the Kodak remote control

The Kodak remote control (sold separately) lets you view and print pictures and control your printer dock remotely. The remote control is especially helpful when using your television as a display (see [page 43](#)). See the remote control user's guide for details.


Reviewing pictures on the camera screen

- 1 Dock your digital camera (see [page 8](#)).
- 2 Press  on the printer dock to scroll through the pictures, or press the Slide Show button,  (see [page 44](#)).

Displaying pictures on a television

With a docked camera, you can view pictures on a television, monitor, or any device equipped with a video input. (Image quality on a television screen may not be as good as on a monitor or when printed.)

- 1 Open the accessory door on the printer dock.



- 2 Connect the A/V cable (included) from the printer dock A/V out connector to the television or monitor video-in port (yellow) and audio-in port (white).
- 3 Set Video Out (NTSC or PAL) on your camera to the format used in the region you live in. See your camera user's guide for details.
- 4 Dock the camera (see [page 8](#)).

A message appears on the camera screen asking you to select a video display.

Press  on the printer dock to choose either the camera or the TV, then press the Print button, .

- 5 Turn on your television, and select a video channel (see your television user's guide for details). Follow the instructions on the screen. Use the printer dock as usual.

Running a slide show

The Slide Show feature lets you automatically review pictures and videos stored on your EasyShare digital camera.

- 1 Place the Kodak EasyShare digital camera on the printer dock.
 - To view the slide show on a television, connect the printer dock to a TV (see [page 43](#)) before docking your camera.

- 2 Press the Slide Show button, .

The pictures and videos are displayed in the order in which you took them. The slide show is finished when "The End" appears on the screen.

- To manually navigate through pictures and videos during the slide show, press   on the printer dock.
- During the slide show, you can select pictures to print by pressing the Print button, . Press / to choose the number of copies for that picture.

IMPORTANT: *If, after you press the Print button, you decide not to print the picture, select 0 on the copies screen before resuming the slide show, or press the Cancel button to exit the print screen altogether.*

To resume the slide show, press the Slide Show button, . If no button is pressed, after a short time the slide show resumes automatically.

- To cancel the slide show in progress, press the Cancel button, .

When the slide show ends, all pictures you selected for printing are printed.



Changing the slide show settings

See your Kodak EasyShare digital camera user's guide for information on changing the slide show interval and setting the slide show loop.

General care

IMPORTANT: *Disconnect the power before cleaning. Do not use harsh or abrasive cleaners or organic solvents on the printer dock or any of its parts.*

- To clean, wipe the outside of the printer dock with a clean, dry cloth.



- Support the printer dock and tray by placing it on a flat, level surface. Do not block the cooling vents.
 - Avoid blocking the back of the printer dock and paper tray exit.
 - Keep power and USB cables away from the paper path.
 - Keep the surrounding area vacuumed and litter-free.
 - Protect the printer dock from tobacco smoke, dust, sand, and liquid spills.
-
- Avoid placing objects on the printer dock.
 - Keep the printer dock, accessories, and supplies away from direct sunlight and out of high-temperature environments (such as a vehicle parked in the sun).
 - When storing, remove the paper tray, then close the paper tray cover and paper tray door to keep out dust and debris. Store paper flat.


Cleaning the paper feed roller

To prevent misfeeds and to make sure your pictures look their best, we recommend that you keep the paper feed roller clean. Inspect the roller weekly for debris particles, and clean if necessary.

IMPORTANT: *Disconnect the power before cleaning.*

- 1 Remove the paper tray from the printer dock, and leave the paper tray door open.
- 2 **Lightly** moisten a lint-free cloth with water.

IMPORTANT: *Do not use cotton or cotton swabs to clean the paper feed roller.*



- 3 Use the moistened cloth to gently wipe clean the surface of the paper feed roller. Advance the feed roller with your thumb as necessary, and continue cleaning.
- 4 Allow the paper feed roller to fully dry before reconnecting the power.

Traveling with your printer dock

IMPORTANT: *When traveling, keep the printer dock, accessories, and supplies away from direct sunlight and out of high-temperature environments (such as a vehicle parked in the sun).*

Consider purchasing the AC power cord for the region to which you are traveling.

- 1 Disconnect the power and remove all cables.
- 2 Remove the paper tray from the printer dock; close the paper tray cover and the paper tray door on the printer dock.
- 3 Repack the printer dock in the original packing box, or use the optional printer dock travel bag.

Purchase an AC power cord, printer dock travel bag, and other accessories at a retailer of Kodak products, or visit www.kodak.com/go/accessories.


8

Troubleshooting

For step-by-step product support, visit www.kodak.com/go/printerdocksupport. Find the page for your model of printer dock, then select Interactive Troubleshooting & Repairs.

Printing problems

Problem	Cause and/or solution
Paper does not feed (Paper light may glow steady red)	IMPORTANT: Use only Kodak color cartridge & paper kits for your printer dock. Do not use inkjet paper. ■ The paper tray may be empty. Load paper (page 6), re-install the paper tray, then press . ■ Check the paper: 1 Remove the paper tray (page 7). 2 Inspect the paper supply; make sure paper is not damaged in any way, or removable tabs have not been detached. Reload with new paper if necessary. 3 Carefully "fan" the paper to keep the sheets from sticking together. 4 Reload the paper tray. Do not exceed the fill line. 5 Re-install the paper tray, then press  to resume printing. ■ Clean the paper feed roller (page 46).
Multiple sheets of paper are pulled through printer	1 Remove the paper tray (page 7). 2 Remove the paper supply from the paper tray. Carefully "fan" the paper to keep the sheets from sticking together. 3 Reload the paper tray. Do not exceed the fill line. 4 Re-install the paper tray, then press  to resume printing.

Problem	Cause and/or solution
Printer is jammed (Paper and/or cartridge lights may blink quickly)	IMPORTANT: Use only Kodak color cartridge & paper kits for your printer dock. Do not use inkjet paper. ■ If the Paper light is blinking quickly: 1 Remove the paper tray (page 7). 2 Disconnect the power from the printer dock for 5 seconds, then reconnect the power. Carefully remove the paper if it does not automatically eject. IMPORTANT: Check the paper slot on the back of the printer dock for jammed paper:  3 Remove the paper supply from the paper tray. Carefully "fan" the paper to keep the sheets from sticking together. 4 Reload the paper tray. Do not exceed the fill line. 5 Re-install the paper tray, then press  to resume printing. ■ If the Color Cartridge light is blinking quickly, check the color cartridge: IMPORTANT: The color cartridge may lock in place if there is a paper error. Do not attempt to remove the cartridge without first clearing the paper error. Make sure the Paper light is off before attempting to remove the cartridge (see Paper light under Status lights, page 58). Remove the color cartridge, remove any slack from the ribbon, then re-install the cartridge (page 4). Press  to resume printing.

Problem	Cause and/or solution
Printing stops during mid-print (paper stops feeding, and Paper light may blink)	IMPORTANT: <i>Use only Kodak color cartridge & paper kits for your printer dock. Do not use inkjet paper.</i> ■ Check the paper: 1 Remove the paper tray (page 7). 2 Check the paper slot on the back of the printer dock. 3 Remove loose paper from the printer dock. If paper is jammed, see page 49. 4 Inspect the paper supply: make sure removable tabs have not been detached from the paper. Reload with new paper if necessary. 5 Carefully "fan" the paper to keep the sheets from sticking together. 6 Reload the paper tray. Do not exceed the fill line. 7 Re-install the paper tray, then press  to resume printing. ■ Clean the paper feed roller (page 46).
Print is smudged	■ Fingerprints may be on glossy side of paper. Handle paper by the edges or by the removable tabs (page 5).
Print is spotted	■ Check to see if the paper is dirty, and use a dry, lint-free cloth to wipe clean. For excessive dirt or debris, thoroughly clean the paper tray, and load new paper (page 6). Check and clean the paper feed roller if necessary (page 46). NOTE: When storing paper, remove and close the paper tray and paper tray door to keep dust and debris from collecting on the paper or inside the printer dock (page 5).

Problem	Cause and/or solution
Print is too light	IMPORTANT: Use only Kodak color cartridge & paper kits for your printer dock. Do not use inkjet paper. ■ Make sure the paper is loaded with the Kodak logo facing down. Reload if necessary (page 6). ■ Try re-taking the picture with the flash off. See your camera user's guide for details. ■ Adjust the exposure compensation on your camera, and try re-taking the picture. See your camera user's guide for details. ■ Edit the picture using Kodak EasyShare software on your computer. See the EasyShare software Help for details.
Print is too dark or is discolored	■ Try re-taking the picture with the flash on, or move within the flash range of the camera. See your camera user's guide for details. ■ Adjust the exposure compensation on your camera, and try re-taking the picture. See your camera user's guide for details. ■ Edit the picture using Kodak EasyShare software on your computer. See the EasyShare software Help for details. ■ Make sure the printer dock is not placed in direct sunlight or is not operating in a high-temperature environment. ■ Make sure the cooling vents are not blocked or dirty (page 1).
Pictures are cropped	■ Change the picture quality setting (or resolution) on your digital camera to 3:2. See your camera user's guide for details. ■ Adjust cropped pictures using Kodak EasyShare software on your computer. ■ If you are printing from an application on your computer, select the proper paper size in print options. NOTE: Cropping may vary depending on the selected picture size (page 16).
A selected picture does not print.	■ The image file may be corrupt. Review the picture on the camera or computer and delete if necessary. ■ The image file may not be JPEG format. The printer dock can only print JPEG files in standalone mode. Connect to a computer (page 24) and use EasyShare software to print BMP and TIFF formats (page 30).

Problem	Cause and/or solution
Nothing happens when you try to print	■ Check the power connections (page 3). ■ Remove the paper tray, check that paper is properly loaded, and re-install (page 7). ■ If the Paper light glows steady amber, load paper (page 6). ■ Make sure the color cartridge is properly installed (page 4). If the Color Cartridge light is on, install a new cartridge. ■ The image file is not in JPEG format. The printer dock can only print JPEG file in standalone mode. Connect to a computer and use EasyShare software to print BMP and TIFF format files.
Nothing happens when you try to print (from a docked camera)	■ The camera is not properly seated on the connector. Reseat the camera on the printer dock (page 8). ■ Re-establish the connection: remove, then reseat the camera on the printer dock. ■ Make sure there is at least one picture in the camera's internal memory or memory card.
Nothing happens when you try to print (from a Kodak card reader)	NOTE: The Kodak EasyShare printer dock is compatible with the Kodak 8-in-1 card reader (sold separately). Other Kodak USB card readers may work with the printer dock; however, other manufacturers' card readers are not supported. ■ Check the USB connections from the card reader to the printer dock (page 14). ■ Re-establish the connection: disconnect, then reconnect the USB cable from the card reader to the printer dock. ■ Make sure a memory card is inserted and that there is at least one picture on the memory card.
Nothing happens when you try to print (from a PictBridge compatible camera or device)	■ Check the USB connections from the PictBridge compatible camera or device to the printer dock (page 15). ■ Re-establish the connection: disconnect, then reconnect the USB cable from the PictBridge compatible camera or device to the printer dock. ■ Make sure there is at least one picture in the PictBridge compatible camera or device's internal memory or memory card. ■ Make sure the connected camera or device is PictBridge compatible. See your camera or device user's guide for details.

Problem	Cause and/or solution
Nothing happens when you try to print (from computer)	■ Check the USB connections from the printer dock to the computer (page 24). ■ The computer may be transferring pictures. Wait a few seconds, then try again. ■ Access the printer menu for your system. Remove check marks next to Pause Printing and Offline, if checked. ■ Close unnecessary software applications. Disconnect then reconnect the USB cable from the printer dock to the computer (page 24). ■ Make sure you are using the a model U-5A USB cable included with your printer dock. Other USB cables are not supported. ■ Make sure Kodak EasyShare software is installed (page 22). Install if necessary. If you choose Custom installation, make sure to install the printer driver. ■ Uninstall, then reinstall Kodak EasyShare software (page 22). ■ Make sure your computer meets the minimum system requirements. Upgrade your system if necessary.
Nothing happens when you try to print (from a Bluetooth technology enabled device)	■ The internal Bluetooth radio is off. Turn it on by pressing the Bluetooth button, , then try again. ■ Move within range of the Bluetooth radio signal (30 ft., or 10 m). ■ The Bluetooth technology enabled device does not find the printer dock. On the device, turn wireless technology to On, then repeat the discovery process. ■ The Bluetooth technology enabled device does not use an OPP or FTP profile.

Problem	Cause and/or solution
Nothing happens when you try to print (over a Wi-Fi wireless network)	■ Make sure you are using a Kodak Wi-Fi® card. Other brands of Wi-Fi cards are not supported. ■ Inspect the Wi-Fi card to make sure it is not damaged. Do not attempt to use if it appears damaged. ■ Make sure the Wi-Fi card is properly inserted and the card slot light is lit (page 37). ■ Make sure the wireless device you are trying to print from is Wi-Fi compatible and is working properly. See your device user's guide for details.
Nothing happens when you try to print (from an infrared device)	■ There is an obstruction blocking the infrared sensor. Remove the obstruction. Point the infrared device at the infrared sensor, then try again. ■ Move within range of the infrared device. See your device user's guide for details.
Printing is slow	NOTE: When printing a large number of prints, printing may slow down to prevent the print head from overheating. ■ Make sure the printer dock is not placed in direct sunlight or is not operating in a high-temperature environment (higher than 95 °F, or 35 °C). ■ Make sure the cooling vents are not blocked or dirty (page 1). ■ Close unnecessary software applications. ■ Make sure your computer meets the minimum system requirements. Upgrade your system if necessary.

Problem	Cause and/or solution
Unable to remove color cartridge (Paper light may glow steady red or blink)	IMPORTANT: <i>The color cartridge may lock in place if there is a paper error. Do not attempt to remove the cartridge without first clearing the paper error. Make sure the Paper light is off before attempting to remove the cartridge (see Paper light under Status lights, page 58).</i> ■ Check to see if the paper tray is empty or if paper is missing perforated tabs. Reload paper if necessary (page 6), then try again. ■ Make sure paper is not jammed. Clear the jam if necessary (page 49), then try again. ■ Disconnect then reconnect the power and try again. IMPORTANT: <i>Upon reconnecting the power, the color cartridge may advance to the next picture slot on the ribbon, resulting in a supply mismatch (see below).</i>
Paper runs out before the color cartridge (or vice versa)	■ Supply mismatch can result from several different situations, including: —Scrapping of paper as a result of jams or other errors —Gradual advancement of the color cartridge ribbon due to removing ribbon slack or clearing jams —Advancement of the color cartridge ribbon upon reconnecting power to unlock the color cartridge Supply mismatch is likely to occur as you continue to use your printer dock. To keep your cartridge and paper supply synchronized, discard unused cartridge or paper when one or the other is fully depleted.

Transfer/communication problems

Problem	Cause and/or solution
Nothing happens when you try to transfer pictures to the computer	■ Press the Transfer button, , on the printer dock. ■ Check the power and USB connections from the printer dock to the computer (page 24). ■ If you are trying to transfer pictures from a docked camera, make sure to disconnect the optional USB card reader first (page 26). ■ The camera is not properly seated on connector. Reseat the camera on the printer dock (page 8). ■ If you are trying to transfer pictures from a compatible Kodak card reader (page 29) and a camera is docked, remove it. Check the USB connections between the printer dock and the card reader. NOTE: The Kodak EasyShare printer dock is compatible with the Kodak 8-in-1 card reader (sold separately). Other Kodak USB card readers may work with the printer dock; however, other manufacturers' card readers are not supported. ■ Close unnecessary software applications, and minimize remaining application windows. Follow any messages on the screen that may have been hidden by other windows. ■ Disconnect then reconnect the USB cable from the printer dock to the computer (page 24). ■ Make sure you are using the USB cable included with your printer dock (model U-5A USB cable, catalog number 8650988). ■ Make sure Kodak EasyShare software is installed (page 22). Install if necessary. If you choose Custom installation, make sure to install the printer driver. ■ Uninstall, then reinstall Kodak EasyShare software (page 22). ■ Make sure your computer meets the minimum system requirements. Upgrade your system if necessary.

Wireless network connection

Problem	Cause and/or solution
Printer dock cannot connect to the Wi-Fi wireless network	■ A Kodak Wi-Fi® card is not inserted or is not fully inserted. Reinsert the Wi-Fi card (page 37). ■ Check the power connections (page 3). ■ Make sure the wireless router and network are running before the printer dock begins scanning for a network. ■ Out of range of the Wi-Fi signal. Make sure the printer dock is located within the operating range of the Wi-Fi wireless network. ■ The printer dock network settings are incorrect. Using the Wi-Fi wireless configuration utility on your computer, change the settings to match those of the network. See the Wi-Fi wireless configuration utility help for details. ■ There is interference in the wireless signal (such as a microwave oven). Wait until there is no interference, then try again.

Status lights

Color Cartridge light		
Light status	Cause	Action/solution
IMPORTANT: <i>The color cartridge may lock in place if there is a paper error. Do not attempt to remove the cartridge without first clearing the paper error. Make sure the Paper light is off before attempting to remove the cartridge (see Paper light).</i>		
Light is off	The color cartridge is properly installed and is working normally.	None required.
Light glows steady amber	The color cartridge has five or fewer prints remaining.	None required.
Light blinks red	There is a color cartridge jam.	Clear the jam (page 49), then press  .
Light glows steady red	The color cartridge is depleted.	Install a new color cartridge (page 4), then press  .
	The color cartridge is not installed or is not fully seated.	Remove and re-install the color cartridge (page 4), then press  .

Paper light		
Light status	Cause	Action/solution
IMPORTANT: <i>The color cartridge may lock in place if there is a paper error. Do not attempt to remove the cartridge without first clearing the paper error. Make sure the Paper light is off before attempting to remove the cartridge.</i>		
Light is off	The paper tray is properly installed and has an ample supply of paper.	None required.
Light blinks red	There is a paper jam.	Clear the jam (page 49), then press  .
	Printing stopped during mid-print; the paper may be damaged or is missing removable tabs (page 50).	Remove loose paper. Check the paper supply. Reload with new paper if necessary, then press  .
Light glows steady red	The paper tray is empty.	Load paper (page 6), then press  .
	The paper tray is not installed or is improperly installed.	Remove the paper tray, check that paper is properly loaded, and re-install (page 7). Press  to resume printing.
	Paper did not feed; removable tabs may be missing or sheets may be stuck together (page 48).	Check the paper supply. Reload with new paper if necessary, then press  .
	The paper feed roller may be dirty.	Clean the paper feed roller (page 46).

Battery charging lights		
Light status	Cause	Action/solution
All lights are off	The camera is not properly seated on connector.	Reseat the camera on the printer dock (page 8).
	The camera is turned on.	Turn off the camera.
	An unrecognized battery type is installed, or camera does not support charging.	Install a Kodak Ni-MH rechargeable digital camera battery or Kodak Li-Ion rechargeable digital camera battery. See your camera user's guide for battery compatibility and other charging options.
One steady green light 	The camera was just placed in camera dock.	None; dock is checking the charge status of the battery.
Ascending steady green lights   	The battery is charging. Charging is complete when all three lights are lit.	Leave the camera on the dock to continue charging or maintain charge.
One blinking red light 	The battery is not properly installed.	Re-install the battery.
	The battery or connector pin is damaged.	Check for damage.
	The camera and battery have been exposed to extreme temperatures.	Slowly return the camera and battery to room temperature.
Descending blinking green lights   	The Ni-MH rechargeable battery refresh cycle is in progress: discharging (lights turn off as discharging progresses).	Leave the camera on the dock to continue refresh cycle (page 9).

USB device connector light		
Light status	Cause	Action/solution
Light blinks green	Slow blink: the device is initializing or communicating with the printer dock.	None required.
	Fast blink: there is a device or communication error.	Check the USB connections from the device to the printer dock (page 15). Disconnect then reconnect USB cable from printer dock to device.
Light is off	There is no device connected to the USB device connector on the printer dock.	None required.
	The connection between the printer dock and device is loose.	Check the USB connections from the device to the printer dock (page 15).
	A device other than a compatible Kodak card reader or PictBridge compatible camera or device is connected.	Disconnect the device. Connect a Kodak 8-in-1 card reader, or a PictBridge compatible camera or device.

Card slot light (SDIO/SD/MMC card behavior)		
Light status	Cause	Action/solution
Light blinks green	Slow blink: the internal card reader is initializing or communicating with the printer dock.	None required.
	Fast blink: there is a card or communication error.	Remove the card and make sure the card is not write protected or damaged. Replace with a new card if necessary. Reinsert the card.
Light is off	An SDIO/SD/MMC card is not inserted or is improperly inserted in the card slot.	None required.

Transfer button/light		
Light status	Cause	Action/solution
Light glows steady green	The printer dock is ready for transferring pictures.	None required.
Light blinks green	Pictures are being transferred to the computer.	None required. After transferring pictures, the Transfer light continues to blink green until either the Transfer button is pressed again or the connection is no longer available.
Light is off	There are no pictures in the camera or on the memory card.	None required. To enable Transfer: 1 Connect printer dock to computer (page 24). 2 Take pictures. 3 Dock the camera or connect a compatible Kodak card reader (page 14). If using a card reader, make sure a memory card is inserted.
	The camera is not docked, a compatible Kodak card reader is not connected, or a memory card is not inserted.	
	The printer dock is not connected to the computer.	
	The printer dock is running a slide show.	
	The camera is not properly seated on the connector.	Reseat the camera on the printer dock (page 8).
	The printer dock is printing in standalone mode.	The Transfer button is disabled.
	The computer is off.	Turn on the computer.

Slide Show button/light		
Light status	Cause	Action/solution
Light glows steady green	The Slide Show feature is available.	None required. Press the Slide Show button,  , to start.
Light blinks green	The Slide Show is running.	None required. To cancel the Slide Show, press X .
Light is off	The Slide Show feature is not available. NOTE: The Slide Show feature is only available if a camera is docked.	None required. To run a Slide Show, see page 44 .

Red Eye Reduction button/light		
Light status	Cause	Action/solution
Light glows steady green	Red eye reduction has been applied to pictures for the current print job.	None required.
Light is off	Red eye reduction has not been selected. NOTE: Red eye reduction is only available when printing from a docked camera, the internal card reader, or a connected Kodak 8-in-1 card reader.	To turn red eye reduction on or off, press the Red Eye Reduction button,  .

Print button/light		
Light status	Cause	Action/solution
Light glows steady green	The printer dock is ready for printing.	None required.
Light blinks green	The printer dock is printing.	
Light is off	There are no pictures in the camera or on the memory card.	None required. To enable Print:
	The camera is not docked or a compatible Kodak card reader is not connected.	1 Take pictures. 2 Dock the camera or connect a compatible Kodak card reader (page 14). If using a card reader, make sure a memory card is inserted.
	The camera is not properly seated on the connector.	Reseat the camera on the printer dock (page 8).
	The camera or card reader is transferring pictures to the computer, or has established an active connection to the computer.	None required. When transfer is complete, press the blinking Transfer button,  .
	A PictBridge compatible camera or device is connected.	None required. The Print button is disabled; print command is controlled from the PictBridge compatible camera or device. To print from another source, unplug the PictBridge compatible camera or device.

Bluetooth button/light		
Light status	Cause	Action/solution
Light glows steady blue	The Bluetooth radio is on; the printer dock is ready to receive Bluetooth signals.	None required. To turn the Bluetooth radio on or off, press the Bluetooth button,  .
Light is off	The Bluetooth radio is off; the printer dock is unable to receive Bluetooth signals.	

Picture Size lights		
Light status	Cause	Action/solution
One light glows steady green	The indicated picture size is available and selected.	None required. To change picture size, press the Picture Size button repeatedly.
All lights are off	There are no pictures in the camera, on the memory card, or on the PictBridge compatible camera or device.	To enable the picture size option: 1 Take pictures. 2 Dock the camera or connect a compatible Kodak card reader (page 14) or PictBridge compatible camera or device (page 12). If using a card reader, make sure a memory card is inserted.
	The camera is not docked, a compatible Kodak card reader or PictBridge compatible camera or device is not connected, or a memory card is not inserted.	
	The camera is not properly seated on the connector.	Reseat the camera on the printer dock (page 8).
	The camera, card reader, or PictBridge compatible camera or device is transferring pictures to the computer, or has established an active connection to the computer.	None required.

Helpful links

Printer dock	Get support for your product (FAQs, troubleshooting information, etc.)	www.kodak.com/go/printerdocks
	Purchase full range of digital camera and dock accessories.	www.kodak.com/go/accessories
	Download latest printer dock software, firmware and drivers	www.kodak.com/go/printerdockdownloads
	See online tutorials	www.kodak.com/go/howto
Software	Get information on EasyShare software	www.kodak.com/go/easysharesw (or click the Help button in the EasyShare software)
	Get help with the Windows operating system and working with digital pictures	www.kodak.com/go/pcbasics
Other	Get support for Kodak docks, cameras, software, accessories, more	www.kodak.com/go/support
	Get information on the Kodak Wi-Fi® card and wireless	www.kodak.com/go/wifisupport
	Optimize your printer for truer, more vibrant colors	www.kodak.com/go/onetouch
	Register your printer dock	www.kodak.com/go/register

Telephone customer support

If you have questions concerning the operation of the software or printer dock, you may speak with a customer support representative. Before you call, have the printer dock connected to your computer. Be at your computer, and have the following information available:

- Computer model, Operating system
- Processor type and speed (MHz)
- Amount of memory (MB) and free hard disk space
- Printer dock serial number
- Version of Kodak EasyShare software
- Exact error message you received

Australia	1800 147 701	Greece	00800 441 40775	Singapore	800 6363 036
Austria	0179 567 357	Hong Kong	800 901 514	Spain	91 749 76 53
Belgium	02 713 14 45	India	91 22 617 5823	Sweden	08 587 704 21
Brazil	0800 150000	Italy	02 696 33452	Switzerland	01 838 53 51
Canada	1 800 465 6325	Japan	03 5540 9002	Taiwan	0800 096 868
China	800 820 6027	Korea	00798 631 0024	Thailand	001 800 631 0017
Denmark	3 848 71 30	Netherlands	020 346 9372	Turkey	00800 448 827073
Indonesia	001 803 631 0010	New Zealand	0800 440 786	UK	0870 243 0270
Ireland	01 407 3054	Norway	23 16 21 33	US (toll-free) / (toll)	1 800 235 6325 / 585 781 6231
Finland	0800 1 17056	Philippines / Metro Manila	1 800 1 888 9600 / 632 6369600	International Toll Line	+44 131 458 6714
France	01 55 1740 77	Poland	00800 441 1625	International Toll Fax	+44 131 458 6962
Germany	069 5007 0035	Portugal	021 415 4125		

Visit www.kodak.com/go/dfswwcontacts.

Printer dock specifications

For more specifications, visit www.kodak.com/go/printerdocks.

Printer dock specifications	
Printing process	Thermal dye transfer
Operating environment (for optimum picture quality)	Temperature: 50 to 95 °F (10 to 35 °C) Humidity: 10% to 86% RH
Power (via AC power adapter)	Output: 24 V DC Input: 100 V to 240V AC @ 50/60 Hz Consumption while printing: 60 watts maximum
Print speed	Via computer: 60 seconds Standalone: 65 seconds NOTE: First print may take an additional 25 seconds when printing from camera. Print speed is dependent on picture size, number of continuous prints, and environmental conditions.
Size	Without paper tray: 5.28 x 7.40 x 3.27 in. (13.4 x 18.8 x 8.3 cm)
	With paper tray: 12.17 x 7.40 x 3.27 in. (30.9 x 18.8 x 8.3 cm)
Weight	Without paper tray: 33.5 oz (950 g)
	With paper tray: 38.4 oz (1090 g)
Print size	4 x 6 in. (10.2 x 15.2 cm)
Paper size with perforated tabs	4 x 7.25 in. (10.2 x 18.4 cm)
Picture resolution	300 ppi, continuous tone

Printer dock specifications	
Communication with computer	USB 2.0 full speed (PIMA 15740 protocol), via model U-5A USB cable (catalog number 8650988) IEEE802.11b (Wi-Fi), via Kodak Wi-Fi® card
Wireless capability	Format: IEEE802.11b (Wi-Fi), RCR STD-33, ARIB STD-T66 Speed: 1/2/5.5/11Mbps (auto-detect) Frequency range: 2412-2462 MHz (1 - 11 channel ISM band) Access modes: Infrastructure, Ad Hoc Security: 128 (104), 64 (40) bit WEP
Video output	Via Kodak audio/video cable (catalog number 1983881)

Wireless channels

This product operates on the legal channel for your region. You are not able to manually select the channel. Wi-Fi networks operate in the ISM (Industrial, Scientific, and Medical) radio frequency band. The ISM band is divided into channels, each occupying 5 MHz of frequency band. To join a wireless network, a node must set its channel to that of the wireless router (or - in a device-to-device network - to that of the first node).

Nearby networks that operate on the same channel will interfere with one another, resulting in lower network speed or connection loss.



CAUTION:

The Wi-Fi card for this device transmits at 15 dBm. In France, the power level is limited to 10 dBm in outdoor environments, per regulations. When in France, use the wireless functions of this product indoors only.

Important safety instructions

Using this product

- Read and follow these instructions before using Kodak products. Always follow basic safety procedures.
- Use only a USB compliant computer equipped with a current-limiting motherboard. Contact your computer manufacturer if you have questions.
- The use of an accessory attachment that is not recommended by Kodak, such as an AC adapter, may cause fire, electric shock, or injury.



CAUTION:

Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel. Do not expose this product to liquid, moisture, or extreme temperatures. Kodak AC adapters and battery chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards.

Battery safety and handling



CAUTION:

When removing batteries, allow them to cool first; batteries may be hot.

- Use only batteries approved for this product to avoid risk of explosion.
- Keep batteries out of the reach of children.
- Do not allow batteries to touch metal objects, including coins. Otherwise, a battery may short circuit, discharge energy, become hot, or leak.

- Do not disassemble, install backward, or expose batteries to liquid, moisture, fire, or extreme temperature.
- Replace all batteries of a set at the same time. Do not mix new batteries with used ones. Do not mix rechargeable and non-rechargeable batteries. Do not mix lithium, Ni-MH, and Ni-Cd batteries together. Do not mix batteries of different chemistry types, grades, or brands. Failure to observe this precaution may cause leakage.
- Remove batteries when the product is stored for an extended period of time. In the unlikely event that battery fluid leaks inside the product, contact your local Kodak Customer Service representative.
- In the unlikely event that battery fluid leaks onto your skin, wash immediately with water and contact your local health provider. For additional health-related information, contact your local Kodak Customer Service representative.
- Dispose of batteries according to local and national regulations.
- If the battery contacts touch metal objects, the battery may short-circuit, discharge energy, become hot, or leak.
- Do not charge non-rechargeable batteries.

For more information on batteries, see

www.kodak.com/global/en/service/batteries/batteryUsage.jhtml

Extending battery life

- Limit the following activities that quickly deplete battery power:
 - Reviewing your pictures on the camera screen
 - Using the camera screen as a viewfinder
 - Excessive use of the flash
- Dirt on the battery contacts can affect battery life. Wipe the contacts with a clean, dry cloth before loading batteries in the camera.

- Battery performance is reduced at temperatures below 5° C (41° F). When using your camera in cold weather, carry spare batteries and keep them warm. Do not discard cold batteries that do not work; when they return to room temperature, they may be usable.
- If you are getting fewer than 20 pictures per charge with your Kodak Ni-MH rechargeable digital camera battery, (and if none of the tips above seem to help), consider refreshing the battery (see [page 9](#)) or replacing it.

For more information on batteries, see your camera user's guide, or visit www.kodak.com/global/en/service/batteries/batteryUsage.jhtml.

Upgrading your software and firmware

Download the latest versions of the software included on the Kodak EasyShare software CD and the printer dock firmware (the software that runs on the printer dock). Visit www.kodak.com/go/printerdockdownloads.

Additional care and maintenance

- Do not allow chemicals, such as suntan lotion, to come into contact with the painted surface of the printer dock.
- If the printer dock has been subjected to inclement weather or you suspect water has gotten inside the printer dock, turn off the printer dock and remove the paper tray and color cartridge. Allow all components to air-dry for at least 24 hours before using the printer dock again. If this does not resolve the problem, contact customer support (see [page 67](#)).
- Connect a tripod directly to the camera; do not connect a tripod to the camera dock or printer dock.
- Service agreements are available in some countries. Contact a dealer of Kodak products for more information.

- The printer dock and the AC power adapter contain a small amount of lead in the circuit board. Disposal of this material may be regulated due to environmental considerations.

Disposal of the color cartridge is not regulated and should not be subject to state or local landfill, incineration, or recycling requirements.

For more disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at www.eiae.org.

Warranty

Limited warranty

Kodak warrants the Kodak EasyShare printer dock plus series 3 to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase.

Kodak warrants Kodak EasyShare printer dock plus series 3 accessories (excluding batteries) to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase.

Retain the original dated sales receipt. Proof of the date of purchase will be required with any request for warranty repair.

Limited warranty coverage

This limited warranty will be honored only within the geographical location that Kodak EasyShare digital cameras and accessories were purchased.

Kodak will REPAIR or REPLACE Kodak EasyShare digital cameras and accessories if they fail to function properly during the warranty period, subject to any conditions and/or limitations stated herein. Such repair service will include all labor as well as any necessary adjustments and/or replacement parts. Such repair or replacement is the sole remedy under this warranty.

If replacement parts are used in making repairs, these parts may be remanufactured, or may contain remanufactured materials. If it is necessary to replace the entire product, it may be replaced with a remanufactured product.

Limitations

Request for Warranty service will not be accepted without proof of date of purchase, such as a copy of the original dated Kodak EasyShare digital camera or accessory sales receipt. (Always keep the original for your records.)

This warranty does not apply to the battery(s) used in digital cameras or accessories. This warranty does not cover circumstances beyond Kodak's control, nor problems caused by failure to follow the operating instructions in the Kodak EasyShare digital cameras and accessories user's guides.

This warranty does not apply when failure is due to shipping damage, accident, alteration, modification, unauthorized service, misuse, abuse, use with incompatible accessories or attachments, failure to follow Kodak's operation, maintenance or repacking instructions, failure to use items supplied by Kodak (such as adapters and cables), or claims made after the duration of this warranty.

Kodak makes no other express or implied warranty for this product. In the event that the exclusion of any implied warranty is ineffective under the law, the duration of the implied warranty will be one year from the purchase date.

The option of replacement is Kodak's only obligation. Kodak will not be responsible for any special, consequential or incidental damages resulting from the sale, purchase, or use of this product, regardless of the cause. Liability for any special, consequential or incidental damages (including but not limited to loss of revenue or profit, downtime costs, loss of the use of the equipment, cost of substitute equipment, facilities or services, or claims of your customers for such damages resulting from the purchase, use or failure of the product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed and excluded herefrom.

Your rights

Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction.

Outside the United States and Canada

In countries other than the United States and Canada, the terms and conditions of this warranty may be different. Unless specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act.

Regulatory compliance

FCC compliance and advisory



Kodak EasyShare printer dock plus series 3

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

**CAUTION:**

When using the Wi-Fi card with a printer dock: This equipment should be installed and operated with a minimum distance of 7.9 in. (20 cm) for 2.4 GHz operations between the radiator and your body. This transmitter must not be collocated or operate in conjunction with any other antenna or transmitter.

SAR statement (when using with Wi-Fi card)

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. Kodak Wi-Fi[®] card (3F8508) has been tested and found to comply with FCC radiation exposure limits set forth for an uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. The maximum SAR levels tested for Kodak Wi-Fi[®] card (3F8508) have been shown to be 0.616 W/kg at Body.

FCC and Industry Canada

This device complies with Industry Canada RSS-210 and FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian DOC statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Class B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

CE

Hereby, Eastman Kodak Company declares that this Kodak Wi-Fi® card is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Waste Electrical and Electronic Equipment labeling



In the European Union, do not discard the product as unsorted municipal waste. Contact your local authorities or go to www.kodak.com/go/recycle for recycling program information.

Class B ITE

이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역에서는 물론 모든 지역에서 사용할 수 있습니다.

Index

Numerics

4-way control, i, 12, 19, 43, 44

A

AC power adapter & cord, connecting, 3
accessories & supplies, ordering, 66
accessory door, i, 13, 14, 15, 28, 29, 43
audio/video (A/V) out connector, i, 43

B

battery

charging/lights, i, 8, 9, 60
extending life, 9, 71
refreshing Ni-MH rechargeable
 battery, 9
safety, 70

Bluetooth button/light, i, 35, 65

button

4-way control, i, 12, 19, 43, 44
Bluetooth, i, 35
cancel, i, 13, 14, 15, 20, 26, 28, 29,
 33, 44
picture size, i, 16
print, i, 12, 13, 14, 18, 19, 43, 44
red eye reduction, i, 20
refresh, i, 9
slide show, i, 44
transfer, i, 26, 28, 29, 37

C

cable

AC power adapter & cord, 3
audio/video (A/V), 43
USB, 14, 15, 24, 29

camera

connector, ii
docking and charging, 8
insert for dock, 2
preparing for printer dock, 8
printing from, 12
setting picture quality, 10
tagging pictures for printing, 11
transferring pictures from, 26

Canadian DOC statement, 77

cancel button, i, 13, 14, 15, 20, 26,
 28, 29, 33, 44

canceled

printing, 13, 14, 15, 20, 33
slide show, 44
transfer, 26, 28, 29

card reader

external (Kodak), 14, 29
internal, 13, 28

card slot/light, i, 13, 28, 61

care & maintenance

color cartridge, 3
general, 45, 72
paper, 5
paper feed roller, 46
traveling with printer dock, 47

cartridge. See color cartridge
CE, 78
channels, wireless regulations, 69
charging
 camera battery, 8
 lights, i, 8, 9, 60
Class B ITE, 78
color cartridge
 door, ii, 4
 handling, storing, 3
 installing, removing, 4
 light, i, 58
color, automatic correction, 32
computer
 connecting to, 24
 installing software, 22
 printing from, 30, 31
 transferring pictures to, 26, 28, 29
 uninstalling software, 34
connecting
 Kodak card reader, 14, 29
 PictBridge compatible
 camera/device, 15
 power, 3
 to computer, 24
 to television, 43
connector
 A/V out, i, 43
 camera, ii
 power (DC-in), ii, 3
 USB (from device), i, 14, 15, 29
 USB (to computer), ii, 24

cooling vent, ii, 45
copies, printing multiple, 11, 12, 13,
 14, 16, 44
custom camera insert, installing, 2
customer support, 67

D

DC-in, power connector, ii, 3
display, using TV as, 43
disposal and recycling
 batteries, 71
 printer dock, 73
docking and charging camera, 8
door
 accessory, i, 13, 14, 15, 28, 29, 43
 cartridge, ii, 4
 paper tray, i, 7

F

FCC
 and Industry Canada, 77
 compliance and advisory, 75
firmware, upgrading, 66, 72
four-way control, i

H

help
 software, 66
 telephone support, 67
 troubleshooting, 48
 Web links, 66

I

- ImageLink print system, 8
- infrared device
 - IR sensor, i, 42
 - printing from, 42
- insert, custom camera, 2
- installing
 - custom camera insert, 2
 - paper tray, 7
 - software, 22
- IR sensor, for remote/infrared device,
 - i, 42
- IrDA wireless technology, 42

K

- Kodak card reader, 14
 - printing from, 14
 - transferring pictures from, 29
- Kodak EasyShare software
 - help, 66
 - installing, 22
 - printing with, 30
 - uninstalling, 34
- Kodak Web sites, 66
- Kodak Wi-Fi card. *See* wireless

L

- layout. *See* picture size
- light
 - battery charging, i, 9, 60
 - Bluetooth, i, 35, 65
 - card slot, i, 13, 28, 61
 - color cartridge, i, 58
 - paper, i, 59

- picture size, i, 16, 65
- print, i, 12, 64
- red eye reduction, i, 20, 63
- slide show, i, 44, 63
- transfer, i, 26, 28, 29, 37, 62
- USB device connector, i, 14, 15, 29, 61

M

- Macintosh OS
 - installing software on, 22
 - uninstalling software, 34
- maintenance
 - color cartridge, 3
 - general, 45, 72
 - paper, 5
 - paper feed roller, 46
- MMC card slot. *See* card slot/light
- multi-up. *See* picture size

N

- network. *See* wireless

P

- paper
 - feed roller, cleaning, 46
 - handling, storing, 5
 - light, i, 59
 - loading, 6
 - removing perforated tabs, 21
 - slot, ii
- paper tray, i
 - door, i
 - installing, removing, 7

- PictBridge compatible camera/device
 - printing from, 15
- picture size
 - and number of copies, 17
 - button, i, 16
 - changing default, 16
 - lights, i, 16, 65
 - printing different pictures on same sheet, 18
 - printing different sizes/layouts, 16
 - printing duplicate pictures on same sheet, 19
- pictures
 - automatic color correction of, 32
 - printing. *See* printing
 - reducing red eye, 20
 - reviewing on camera, 43
 - selecting number of copies, 11, 12, 13, 14, 16, 44
 - setting quality, 10
 - tagging for automatic printing, 11
 - transferring. *See* transferring pictures
 - viewing on TV, 43
 - viewing slide show, 44
- power
 - AC adapter & cord, 3
 - connecting, 3
 - connector (DC-in), ii, 3
- print button/light, i, 12, 13, 14, 18, 19, 43, 44, 64
- print order
 - bypassing, 15
 - creating on camera (tagging pictures), 10
 - printing, 15
- printer driver
 - installing, 22
 - updating, 66, 72
- printing
 - canceled, 13, 14, 20, 33
 - different pictures on same sheet, 18
 - duplicate pictures on same sheet, 19
 - from Bluetooth technology enabled device, 35
 - from computer, 30, 31
 - from docked camera, 12
 - from external (Kodak) card reader, 14
 - from internal card reader, 13
 - from PictBridge compatible camera/device, 15
 - from wireless infrared device, 42
 - over Wi-Fi network, 37
 - print order, 15
 - problems, 48
 - reducing red eye, 20
 - tagged pictures from computer, 30
 - tagging pictures for, 11
 - with Kodak EasyShare software, 30
 - with remote control, 42
- prints. *See* pictures

Q

quality

- reducing red eye, 20
- setting on camera, 10

R

recharging. *See* charging

recycling and disposal

- batteries, 71
- printer dock, 73

red eye

- automatic reduction of, 20
- button/light, i, 20, 63

refresh

- button, i, 9
- of Ni-MH rechargeable battery, 9

regulatory information

- Canadian DOC statement, 77
- CE, 78
- Class B ITE, 78
- FCC and Industry Canada, 77
- FCC compliance and advisory, 75
- SAR statement, 77
- Waste Electrical and Electronic
Equipment labeling, 78
- wireless channels, 69

remote control, 42

reviewing pictures, 43

- as slide show, 44
- on TV, 43

S

safety, 70

SAR statement, 77

SD card slot. *See* card slot/light

SDIO card slot. *See* card slot/light

sensor. *See* IR sensor

service and support, 67

setup

- camera, 8
- printer dock, 1
- slide show, 44
- software, 22
- slide show, 44
- button/light, i, 44, 63

slot

- card, i, 13, 28
- cooling vent, ii
- paper path, ii

software

- help, 66
- installing, 22
- printing from, 30, 31
- uninstalling, 34
- upgrading, 66, 72

specifications, 68

supplies & accessories, ordering, 66

support, technical, 67

synchronization & transfer, 26, 27

T

- tagging pictures for printing, 11
- telephone support, 67
- television, using as display, 43
- transfer button/light, i, 26, 28, 29, 37, 62
- transferring pictures
 - from camera to computer, 26, 37
 - from external (Kodak) card reader, 29
 - from internal card reader, 28
 - over Wi-Fi network, 37
 - problems, 56
 - synchronizing with
 - EasyShare software, 26, 27
- traveling with printer dock, 47
- tray, paper. *See* paper tray
- troubleshooting
 - lights/LED behavior, 58
 - printing, 48
 - transferring/communication, 56
 - wireless network connection, 57

U

- uninstalling software, 34
- upgrading software & firmware, 66, 72
- URLs, Kodak Web sites, 66
- USB
 - cable, 14, 15, 24, 29
 - connector (to computer), ii, 24
 - device connector, i, 14, 15, 29
 - device connector light, i, 14, 15, 29, 61
 - external (Kodak) card reader, 14, 29
 - wireless adapter, 35

V

- vent, cooling, ii, 45
- viewing pictures. *See* reviewing pictures

W

- warranty, 73
- Waste Electrical and Electronic Equipment labeling, 78
- Wi-Fi *See* wireless
- Windows OS
 - installing software on, 22
 - uninstalling software, 34
- wireless
 - network, troubleshooting, 57
 - printing and transferring via
 - Wi-Fi, 37
 - Wi-Fi card, 37
 - Wi-Fi configuration, 38

X

- Xtralife laminate coating, 12