

ER-4 Quick Start Guide

Click for
Table of Contents

✕

tents



EdgeRouter ER-4



Wall Mount Screws (Qty. 2)



Wall Mount Anchors (Qty. 2)



Power Cord

Installation Requirements

- Drill with a 6 mm drill bit (for wall-mounting)
- Phillips screwdriver
- For indoor applications, use Category 5 (or above) UTP cabling approved for indoor use.
- For outdoor applications, shielded Category 5 (or above) cabling should be used for all wired Ethernet connections and should be grounded through the AC ground of the power supply.

We recommend that you protect your networks from harmful outdoor environments and destructive ESD events with industrial-grade, shielded Ethernet cable from Ubiquiti. For more details, visit: ui.com/toughcable



WARNING: To reduce the risk of fire or electric shock, do not expose the EdgeRouter to rain or moisture.


Note: Although the cabling can be located outdoors, the EdgeRouter itself should be housed inside a protective enclosure.


Click for
Table of Contents

×

Review

ER-4 Quick Start Guide




 **Note:** The System LED functionality has been updated with firmware v1.10.7. We recommend that you update the EdgeRouter to the latest firmware.

1 System LED	
Flashing White	Bootup in progress.
White	Ready for use, not connected to Ubiquiti® Network Management System (UNMS™).
Blue	Ready for use, connected to UNMS.
Steady Blue with Occasional Flashing	Ready for use, unable to connect to UNMS, check connection to UNMS server.
Quickly Flashing Blue	Used to locate a device in UNMS.
Alternating Blue/White	Firmware upgrade in progress.
2 RJ45 Speed/Link/Act LED (0 - 2)	
Off	No Link
Amber	Link Established at 10/100 Mbps
Amber Flashing	Link Activity at 10/100 Mbps
Green	Link Established at 1000 Mbps (1 Gbps)
Green Flashing	Link Activity at 1000 Mbps (1 Gbps)



ER-4 Quick Start Guide

 Off	No Link
Click for Table of Contents	Link Established at 1 Gbps
Green Flashing	Link Activity at 1 Gbps
4 Console	
RJ45 serial console port for Command Line Interface (CLI) management.	
5 USB	
Reserved for future use.	
6 RJ45 Ports (eth0 - eth2)	
RJ45 ports support 10/100/1000 Ethernet connections.	
7 SFP Port (eth3)	
SFP port is hot-swappable and supports Gigabit fiber SFP modules.	
8 Reset Button	
Click here to learn how to reset an EdgeRouter to factory defaults.	

Hardware Installation



WARNING: FAILURE TO PROVIDE PROPER VENTILATION MAY CAUSE FIRE HAZARD. KEEP AT LEAST 20 MM OF CLEARANCE NEXT TO THE VENTILATION HOLES FOR ADEQUATE AIRFLOW.

Wall Mounting


1.

ER-4 Quick Start Guide



Click for
Table of Contents

✕




2.

ER-4 Quick Start Guide



Click for
Table of Contents




3.



Click for
Table of Contents

×

ER-4 Quick Start Guide




4.



Click for
Table of Contents




ER-4 Quick Start Guide



Grounding the EdgeRouter (Recommended)

The Power Cord grounds the device; however, you can add optional ESD grounding for enhanced ESD protection.

1. Attach a screw (not included) to secure a ground wire (not included) to the Grounding Point.




2. Secure the other end of the ground wire to a grounding block.



ER-4 Quick Start Guide

Connect the Power Cord to the Power port and a power outlet.

Click for
Table of Contents



Using SFP Ports

1.



2.

ER-4 Quick Start Guide

Click for
Table of Contents



3.



For information about compatible fiber SFP modules, visit:
ubnt.link/SFP_DAC_Compatibility

Accessing the EdgeOS Configuration Interface

The EdgeOS® configuration interface can be accessed via DHCP or static IP address assignment. By default, eth1 is set up as a DHCP client, while eth0 is assigned a static IP

ER-4 Quick Start Guide

Click for
Table of Contents




net cable from eth1 on the EdgeRouter to a LAN segment that has an existing DHCP server.



2. To check the IP address of the EdgeRouter, use one of the following methods:
 - Set up the DHCP server to provide a specific IP address to the EdgeRouter based on its MAC address (on the label).
 - Let the EdgeRouter obtain an IP address and then check the DHCP server to see which IP address was assigned.
3. Launch your web browser. Enter the appropriate IP address in the address field. Press enter (PC) or return (Mac).
4. Enter ubnt in the Username and Password fields. Read the Ubiquiti License Agreement, and check the box next to I agree to the terms of this License Agreement to accept it. Click Login.

ER-4 Quick Start Guide

Click for
Table of Contents



The EdgeOS Configuration Interface will appear, allowing you to customize your settings as needed. For more information, refer to the EdgeOS User Guide, which is available at ui.com/download/edgemax

Static IP Address


1. Connect an Ethernet cable from the Ethernet port on your computer to the port labeled eth0 on the EdgeRouter.



2. Configure the Ethernet adapter on your host system with a static IP address on the 192.168.1.x subnet.

ER-4 Quick Start Guide

- 4 Enter ubnt in the Username and Password fields. Read the Ubiquiti License Agreement, Click for Table of Contents × ⌵ next to I agree to the terms of this License Agreement to accept it.



The EdgeOS Configuration Interface will appear, allowing you to customize your settings as needed. For more information, refer to the EdgeOS User Guide, which is available at ui.com/download/edgemax

UNMS Management

You can manage your device using UNMS, which lets you configure, monitor, upgrade, and back up your devices using a single application. Get started at www.unms.com

Specifications

ER-4	
Dimensions	229 x 136.5 x 31.1 mm (9.02 x 5.37 x 1.22")
Weight	795 g (1.75 lb)
Max. Power Consumption	13W
Power Method	Universal AC Power Cord (C13)
Power Supply	Internal AC/DC Power Adapter, 30W DC
Supported Voltage Range	100-240VAC, 50/60 Hz Universal Adapter
Button	Reset
LEDs	

ER-4 Quick Start Guide

SFP Data Port
Click for
Table of Contents

x

	Link/Activity
	4-Core 1 GHz MIPS64
	1 GB DDR3 RAM
On-Board Flash Storage	4 GB eMMC, 8 MB SPI NOR
ESD/EMP Protection	Air: ± 24 kV, Contact: ± 24 kV
Interfaces Management Networking	(1) RJ45 Serial Port (4) Ethernet Ports (Default eth0) (3) 10/100/1000 RJ45 Ports (1) 1 Gbps SFP Port
Operating Temperature	-10 to 50° C (14 to 122° F)
Operating Humidity	10 - 90% Noncondensing
Certifications	CE, FCC, IC

Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



WARNING: Failure to provide proper ventilation may cause fire hazard. Keep at least 20 mm of clearance next to the ventilation holes for adequate airflow.



WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.

ER-4 Quick Start Guide

3. This equipment is provided with a detachable power cord which has an integral safety ground wire connection to a grounded safety outlet. Do not replace the power cord with one that is not the provided approved type. Never use an extension cord or connect to a 2-wire outlet as this will defeat the continuity of the grounding system.

Click for
Table of Contents

- a. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
- b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
- c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
- d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
- e. Protective bonding must be installed in accordance with local national wiring rules and regulations.

Limited Warranty

ui.com/support/warranty

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

ISED Canada

CAN ICES-3(A)/NMB-3(A)

Australia and New Zealand



ER-4 Quick Start Guide

Click for
Table of Contents



Product represents the product is in compliance with all directives that are applicable to it.



[WEEE Compliance Statement](#)

[Declaration of Conformity](#)

Online Resources



© 2022 Ubiquiti Inc. All rights reserved.