

KDC-BT370U KDC-BT282U KDC-MP382BT

KMR-D382BT

CD-RECEIVER

INSTRUCTION MANUAL

AUTORADIO CD

MODE D'EMPLOI

RECEPTOR CD

MANUAL DE INSTRUCCIONES

JVCKENWOOD Corporation

For your records

Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your Kenwood dealer for information or service on the product.

Model KDC-BT370U/KDC-BT282U/KDC-MP382BT/KMR-D382BT

Serial number _____

US Residents Only

Register Online

Register your Kenwood product at <https://www.kenwood.com/usa/>

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
In compliance with Federal Regulations, following are reproductions of labels on, or inside the product relating to laser product safety.

JVCKENWOOD Corporation
2967-3, ISHIKAWA-MACHI,
HACHIOJI-SHI, TOKYO, JAPAN

THIS PRODUCT COMPLIES WITH DHHS RULES 21CFR
SUBCHAPTER J IN EFFECT AT DATE OF MANUFACTURE.

Location : Top Plate

Información acerca de la eliminación de equipos eléctricos y electrónicos al final de la vida útil (aplicable a los países que hayan adoptado sistemas independientes de recogida de residuos)



Los productos con el símbolo de un contenedor con ruedas tachado no podrán ser desechados como residuos domésticos. Los equipos eléctricos y electrónicos al final de la vida útil, deberán ser reciclados en instalaciones que puedan dar el tratamiento adecuado a estos productos y a sus subproductos residuales correspondientes. Póngase en contacto con su administración local para obtener información sobre el punto de recogida más cercano. Un tratamiento correcto del reciclaje y la eliminación de residuos ayuda a conservar los recursos y evita al mismo tiempo efectos perjudiciales en la salud y el medio ambiente.

Informação sobre a eliminação de pilhas

Este produto não deve ser eliminado como lixo doméstico geral. Devolva a pilha usada ao revendedor ou entidade autorizada para que a mesma seja devolvida ao fabricante ou importador. A reciclagem e a eliminação de lixo de maneira apropriada ajudarão a conservar os recursos naturais ao mesmo tempo que prevenirão os efeitos prejudiciais à nossa saúde e ao meio ambiente.

CALIFORNIA, USA ONLY

This product contains a CR Coin Cell Lithium Battery which contains Perchlorate Material—special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

Trade Name: KENWOOD
Products: CD-RECEIVER
Model Name: KDC-BT370U/KDC-BT282U/KDC-MP382BT/KMR-D382BT
Responsible Party: JVCKENWOOD USA CORPORATION
2201 East Dominguez Street, Long Beach, CA 90810, U.S.A.
PHONE: 310 639-9000

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

ISED Caution

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Attention de l'ISED

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage.
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Contains Bluetooth Module FCC ID: ZWY88112
IC ID: 12033A-88112

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

CAUTION

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

ATTENTION

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles des radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISED. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

Para cumplimiento de la IFT:

"La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada"

SOFTWARE LICENSE AGREEMENT

The software embedded in the Product (hereinafter the "Licensed Software") provided by Licensor is copyrighted to or sublicensable by the Licensor, and this Agreement provides for the terms and conditions which Users shall follow in order to use the Licensed Software.

The User shall use the Licensed Software by agreeing with the terms of this Software License Agreement. This Agreement shall be deemed completed at the time the User (hereinafter the "User") initially used the Product in which the "Licensed Software" is embedded.

The Licensed Software may include the software which has been licensed to the Licensor directly or indirectly from any third party. In such case, some third parties require the Users to follow their conditions for use separately from this Software License Agreement. Such software shall not be subject to this Agreement, and the Users are urged to read the "Important Notice concerning the Software" to be provided separately below.

Article 1 General Provision

The Licensor shall grant to the User a non-exclusive and non-transferable (other than the exceptional case referred to in Article 3, Paragraph 1) licensed to use the Licensed Software within the country of the User. (the country where the User bought the Product (hereinafter the "Country"))

Article 2 License

1. The license granted under this Agreement shall be the right to use the Licensed Software in the Product.
2. The User shall not duplicate, copy, modify, add, translate or otherwise alter, or lease the Licensed Software and any related documents, whether in whole or in part.
3. The use of the Licensed Software shall be limited to personal purpose, and the Licensed Software shall not be distributed, licensed or sub-licensed whether it is for commercial purpose or not.
4. The User shall use the Licensed Software according to the directions described in the operation manual or help file, and is prohibited to use or duplicate any data in a manner violating the Copyright Law or any other laws and regulations by applying whole or a part of the Licensed Software.

Article 3 Conditions for Grant of License

1. When the User transfers the Product, it may also transfer the license to use the Licensed Software embedded in the Product (including any related materials, updates and upgrades) on condition that no original, copies or related materials continue in the possession of the User, and that the User shall cause the transferee to comply with this Software License Agreement.
2. The User shall not carry out reverse engineering, disassembling, decompiling or any other code analysis works in connection with the Licensed Software.

Article 4 Right pertaining to the Licensed Software

Any and all copyrights and other rights pertaining to the Licensed Software and related documents shall belong to the Licensor or the original holder of the right who granted to the Licensor the license or sublicense for the Licensed Software (hereinafter the "Original Rightholder"), and the User shall not be entitled to any right other than the license granted hereunder, in respect of the Licensed Software and any related documents.

Article 5 Indemnification of Licensor

1. Neither the Licensor nor the Original Rightholder shall be liable for any damage incurred by the User or any third party due to the exercise of the license granted to the User under this Agreement, unless otherwise restricted by law.
2. The Licensor will offer no guarantee for the merchantability, convertibility and consistency with certain objective of the Licensed Software.

Article 6 Liability to Third Party

If any dispute has arisen with any third party due to an infringement upon a copyright, patent or any other intellectual property right that was caused by the User's use of the Licensed Software, the User shall settle such dispute at its own cost and hold the Licensor and the Original Rightholder harmless from any inconvenience it may cause.

Article 7 Confidentiality

The User shall keep the confidentiality of such portion of the Licensed Software, related documents thereof or any other information to be granted under this Agreement, as well as the conditions of this Agreement as has not yet entered the public domain, and shall not disclose or divulge the same to any third party without approval of the Licensor.

Article 8 Termination

In case the User falls under any of the events described in the following items, the Licensor may immediately terminate this Agreement or claim that the User compensates for the damage incurred by the Licensor due to such event:

- (1) when the User violated any provision of this Agreement; or
- (2) when a petition has been filed against the User for an attachment, provisional attachment, provisional disposition or any other compulsory execution.

Article 9 Destruction of the Licensed Software

If this Agreement is terminated pursuant to the provision of Article 8, the User shall destroy the Licensed Software, any related documents and copies thereof within two (2) weeks from such date of termination.

Article 10 Protection of Copyright

1. The copyright and all the other intellectual property rights relating to the Licensed Software shall belong to the Licensor and the Original Rightholder, and in no event shall they be under the ownership of the User.
2. The User shall, whenever it uses the Licensed Software, comply with any laws relating to the copyright and other intellectual property rights.

Article 11 Export Restriction

1. It is prohibited to export the Licensed Software and any related documents outside the country of the User (including transmission thereof outside the country of the User via Internet of other communication tools).
2. The User shall understand that the Licensed Software shall be subject to the export restrictions adopted by the country of User and any other countries.
3. The User shall agree that the software will be subject to any and all applicable international and domestic laws (including the export control regulation of the country of User and any other countries, and any restrictions concerning the end-users, the use by end-users and importing countries to be provided by the country of User and any other countries, and any other governmental authorities).

Article 12 Miscellaneous

1. In the event any part of this Agreement is invalidated by operation of law, the residual provisions shall continue in force.
2. Matters not stipulated in this Agreement or any ambiguity or question raised in the construction of this Agreement shall be provided or settled upon good-faith consultation between the Licensor and the User.
3. The Licensor and the User hereby agree that this Agreement is governed by the laws of Japan, and any dispute arising from, and relating to the rights and obligations under, this Agreement shall be submitted to the exclusive jurisdiction of the Tokyo District Court for its first instance.

Important Notice concerning the Software

-jansson

Copyright (c) 2009-2012 Petri Lehtinen <petri@digip.org>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

-cJSON

Copyright (c) 2009 Dave Gamble

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

-CMP

The MIT License (MIT)

Copyright (c) 2014 Charles Gunyon

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

nanopb

Copyright (c) 2011 Petteri Aimonen <jpa at nanopb.mail.kapsi.fi>

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
 3. This notice may not be removed or altered from any source distribution.
-

sha2

AUTHOR: Aaron D. Gifford - <http://www.aarongifford.com/>

Copyright (c) 2000-2001, Aaron D. Gifford

All rights reserved.

You may obtain a copy of the license at

<https://opensource.org/licenses/BSD-3-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Posix

Copyright (c) 1990, 1993

The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:
This product includes software developed by the University of California, Berkeley and its contributors.
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.

Developed at SunPro, a Sun Microsystems, Inc. business.

Permission to use, copy, modify, and distribute this software is freely granted, provided that this notice is preserved.

Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

Copyright (c) 1995, 1996 Carnegie-Mellon University. All rights reserved.

Author: Chris G. Demetriou

Permission to use, copy, modify and distribute this software and its documentation is hereby granted, provided that both the copyright notice and this permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS "AS IS" CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Carnegie Mellon requests users of this software to return to

Software Distribution Coordinator or Software.Distribution@CS.CMU.EDU

School of Computer Science

Carnegie Mellon University

Pittsburgh PA 15213-3890

any improvements or extensions that they make and grant Carnegie the rights to redistribute these changes.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

Copyright (c) 1993 Martin Birgmeier

All rights reserved.

You may redistribute unmodified or modified versions of this source code provided that the above copyright notice and this and the following conditions are retained.

This software is provided "as is", and comes with no warranties of any kind. I shall in no event be liable for anything that happens to anyone/anything when using this software.

These notices must be retained in any copies of any part of this documentation and/or software.

T-Kernel 2.0

This product uses the source code of T-Kernel 2.0 under T-License 2.0 granted by T-Engine Forum (www.tron.org)

BSD-3-Clause

Copyright (c) 2000-2001, Aaron D. Gifford

All rights reserved.

You may obtain a copy of the license at

<https://opensource.org/licenses/BSD-3-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

LFS Subsystem

Copyright The Regents of the University of California. All rights reserved.

You may obtain a copy of the license at

<https://directory.fsf.org/wiki/License:BSD-4-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Accordo2 Player

Apache License

Licensed under the Apache License,

Version 2.0, January 2004(the "License");

You may obtain a copy of the license at

<http://www.apache.org/licenses/LICENSE-2.0>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Contents

Before Use.....	3
Basics	4
Getting Started	5
1 Select the display language and cancel the demonstration	
2 Set the clock and date	
3 Set the other optional settings	
Radio.....	8
CD/USB/iPod.....	9
SiriusXM® Radio	12
AUX.....	15
KENWOOD Remote Application	15
Bluetooth®	17
Bluetooth – Connection	
Bluetooth – Mobile phone	
Bluetooth – Audio	
Audio Settings.....	23
Display Settings	26
Learning Steering Remote Control	28
Installation/Connection	29

References	33
Maintenance	
More information	
Change the display information	
Troubleshooting.....	35
Specifications	38

How to read this manual

- The displays and faceplates shown in this manual are examples used to provide clear explanations of the operations. For this reason, they may be different from the actual displays or faceplates.
- Operations are explained mainly using buttons on the faceplate of **KDC-BT370U**.
- English indications are used for the purpose of explanation. You can select the display language from the [FUNCTION] menu. (Page 7)
- [XX] indicates the selected items.
- (Page XX) indicates references are available on the stated page.



This symbol on the product means there are important operating and maintenance instructions in this manual. Be sure to carefully read instructions in this manual.

Before Use

IMPORTANT

- To ensure proper use, please read through this manual before using this product. It is especially important that you read and observe Warnings and Cautions in this manual.
- Please keep the manual in a safe and accessible place for future reference.

▲ WARNING

- **Do not operate any function that takes your attention away from safe driving.**
- **Do not ingest the battery, Chemical Burn Hazard.**

The remote control supplied with this product contains a coin/button cell battery.

If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

▲ CAUTION

Volume setting:

- Adjust the volume so that you can hear sounds outside the car to prevent accidents.
- Lower the volume before playing digital sources to avoid damaging the speakers by the sudden increase of the output level.

General:

- Avoid using the external device if it might hinder safe driving.
- Make sure all important data has been backed up. We shall bear no responsibility for any loss of recorded data.
- Never put or leave any metallic objects (such as coins or metal tools) inside the unit to prevent a short circuit.


- If a disc error occurs due to condensation on the laser lens, eject the disc and wait for the moisture to evaporate.
- USB rating is indicated on the main unit. To view, detach the faceplate. (Page 4)
- Depending on the types of cars, the antenna will automatically extend when you turn on the unit with the antenna control wire connected (page 31). Turn off the unit or change the source to STANDBY when parking at a low ceiling area.

Remote control (RC-406):

- Do not leave the remote control in hot places such as on the dashboard.
- Risk of fire or explosion if the battery is replaced by an incorrect type. Ensure to replace only with the same type.
- Risk of fire, explosion or the leakage of flammable liquid or gas if the battery is left in an extremely high temperature surrounding environment and/or subjected extremely low air pressure. The battery pack or batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
- Risk of fire, explosion or the leakage of flammable liquid or gas if the battery is disposed into fire or a hot oven, recharged, shorted, mechanically crushed or cut of the battery.
- If spilled fluid comes in contact with your eyes or on clothing, immediately rinse with water and consult a physician.

Basics


Faceplate




Attach



Detach



How to reset



Reset the unit within 5 seconds after detaching the faceplate.

To

On the faceplate

Turn on the power

Press **SRC**.
• Press and hold to turn off the power.*2

Adjust the volume

Turn the volume knob.

Select a source

• Press **SRC** repeatedly.
• Press **SRC**, then turn the volume knob within 2 seconds.

Change the display information*3

Press **DISP** repeatedly. (Page 34, 35)

*1 Only for illustration purpose.

*2 **KMR-D382BT**: The power will automatically turn off after 20 minutes when in standby mode (Auto Power Off).


*3 **KDC-MP382BT**: You can also turn off the display information by pressing **DISP** repeatedly. (Page 34)

Basics


Remote control (RC-406)

KDC-MP382BT : Can be remotely controlled with an optionally purchased remote control.

KDC-BT370U / **KDC-BT282U** / **KMR-D382BT** : Remote control functions are not available.




How to replace the battery



To	On the remote control
Adjust the volume	Press VOL $\wedge$ or VOL $\vee$. - Press and hold VOL $\wedge$ to continuously increase the volume to 15. Press ATT during playback to attenuate the sound. - Press again to cancel.
Select a source	Press SRC repeatedly.
Turn off the power	Press and hold SRC to turn off the power. (Pressing SRC does not turn on the power.)

Getting Started



1 Select the display language and cancel the demonstration

When you turn on the power for the first time (or [FACTORY RESET] is set to [YES], see page 7), the display shows: "SEL LANGUAGE" $\rightarrow$ "PRESS" $\rightarrow$ "VOLUME KNOB"

- Turn the volume knob to select [ENG] (English) / [SPA] (Spanish) / [FRE] (French), then press the knob.
[ENG] is selected for the initial setup.
Then, (except for **KMR-D382BT**) the display shows: "CANCEL DEMO" $\rightarrow$ "PRESS" $\rightarrow$ "VOLUME KNOB".
- Press the volume knob again.
[YES] is selected for the initial setup.
- Press the volume knob again.
"DEMO OFF" appears.

2 Set the clock and date

- Press the volume knob to enter [FUNCTION].
- Turn the volume knob to select [CLOCK], then press the knob.

To adjust the clock

- Turn the volume knob to select [CLOCK ADJUST], then press the knob.
- Turn the volume knob to make the settings, then press the knob.
Set the time in the order of "Hour" $\rightarrow$ "Minute".
- Turn the volume knob to select [CLOCK FORMAT], then press the knob.
- Turn the volume knob to select [12H] or [24H], then press the knob.

Getting Started

To set the date

- Turn the volume knob to select [DATE FORMAT], then press the knob.
- Turn the volume knob to select [DD/MM/YY] or [MM/DD/YY], then press the knob.
- Turn the volume knob to select [DATE SET], then press the knob.
- Turn the volume knob to make the settings, then press the knob.
Set the date in the order of "Day" → "Month" → "Year" or "Month" → "Day" → "Year".

11 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

3

Set the other optional settings

You can only set the following items while the unit is in STANDBY source.

- Press **⏻SRC** repeatedly to enter STANDBY.
- Press the volume knob to enter [FUNCTION].
- Turn the volume knob to select an item (see the following table), then press the knob.
- Repeat step 3 until the desired item is selected or activated.
- Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

Default: **[XX]**

[AUDIO CONTROL]

- [SWITCH PREOUT] (For **[KDC-BT370U]** / **[KDC-BT282U]** / **[KDC-MP382BT]**)
[REAR]/[SUB-W]: Selects whether rear speakers or a subwoofer are connected to the line out terminals on the rear (through an external amplifier). (Page 32)

[DISPLAY]

[EASY MENU]

(For **[KMR-D382BT]**)

When entering [FUNCTION]...

[ON]: [ZONE 1] illumination changes to white color. ;

[OFF]: [ZONE 1] illumination remains as **[COLOR SELECT]** color.
(Page 27)

- [ZONE 2]** illumination changes to light blue color when you enter [FUNCTION], irregardless of the [EASY MENU] setting.
- Refer to the illustration on page 26 for zone identification.

[TUNER SETTING]

[PRESET TYPE]

[NORMAL]: Memorizes one station for each preset button in each band (FM1/FM2/FM3/AM). ; **[MIX]**: Memorizes one station or SiriusXM channel for each preset button, regardless of the selected band or SiriusXM channel.

[SYSTEM]

[KEY BEEP]

[ON]: Activates the keypress tone. ; **[OFF]**: Deactivates.

[SOURCE SELECT]

[BT AUDIO SRC]

[ON]: Enables BT AUDIO in source selection. ;
[OFF]: Disables. (Page 22)

[BUILT-IN AUX]

[ON]: Enables AUX in source selection. ; **[OFF]**: Disables. (Page 15)

[CD READ]

[1]: Automatically distinguishes between audio file disc and music CD. ;
[2]: Forces to play as a music CD. No sound can be heard if an audio file disc is played.

[USER S.REMO]

(For **[KDC-MP382BT]**)
See page 28 for details.

Getting Started

[F/W UPDATE]

[UPDATE SYSTEM]

- [F/W UP xxxx] [YES]: Starts upgrading the firmware. ; [NO]: Cancels (upgrading is not activated).
For details on how to update the firmware, visit
<<https://www.kenwood.com/cs/ce/>>.
- Once you have upgraded the firmware, you are unable to downgrade the firmware.

- [FACTORY RESET] [YES]: Resets the settings to default (except the stored station). ;
[NO]: Cancels.

- [ENGLISH] Select the display language for [FUNCTION] menu and music information if applicable.

[ESPANOL]

[FRANCAIS] By default, [ENGLISH] is selected.

Register the marine remote ID (for KMR-D382BT)

Applicable only when you connect KENWOOD Marine Remote Control unit (KCA-RC55MR, optional accessory) to this unit.

- For connection, see "Connect external components" on page 32.
- Refer also to the supplied instruction manual of the KENWOOD Marine Remote Control unit for more information.

Preparation:

Press  SRC repeatedly to enter STANDBY, then press the volume knob to enter [FUNCTION].

- 1 Turn the volume knob to select an item, then press the knob.
[SYSTEM] ➡ [REM SETTING] ➡ [REMOTE ID SET]

Remote control ID list is displayed.

- [YES] indicates that this ID is already registered.
- [NO] indicates that this ID is available.

- 2 Turn the volume knob to select an available ID [REM ID1]/[REM ID2]/[REM ID3], then press the knob.

"REGISTERING" appears on the display window.

To register, on the KENWOOD Marine Remote Control unit:

- Press ENTER to register as [REM ID1].
- Press SRC to register as [REM ID2].
- Press DISP to register as [REM ID3].

Once the ID is registered, "COMPLETED" appears.

To delete the registered ID

- 1 Turn the volume knob to select an item, then press the knob.
[SYSTEM] ➡ [REM SETTING] ➡ [REMOTE ID DEL]
- 2 Turn the volume knob to select the ID to delete [ID1 DELETE]/[ID2 DELETE]/[ID3 DELETE], then press the knob.
- 3 Turn the volume knob to select [YES] to delete the selected ID, and select [NO] to cancel.

- To exit, press and hold .
- To return to the previous setting item, press .

Radio



- "ST" indicator lights up when receiving an FM stereo broadcast with sufficient signal strength.
- The unit switches to FM alarm automatically when receiving an alarm signal from FM broadcast.

Search for a station

- 1 Press **SRC** repeatedly to select RADIO.
- 2 Press **BAND** repeatedly (or press **#FM+/*AM-** on the remote control) to select FM1/FM2/FM3/AM.
- 3 Press **◀◀ / ▶▶** (or press **◀◀ / ▶▶** (+) on the remote control) to search for a station.

You can store up to 18 stations for FM and 6 stations for AM.

- **To store a station:** Press and hold one of the number buttons (1 to 6).
- **To select a stored station:** Press one of the number buttons (1 to 6) (or press one of the number buttons (1 to 6) on the remote control).

Direct Access Tuning (using the remote control)

- 1 Press **DIRECT** to enter Direct Access Tuning.
 - 2 Press the number buttons to enter a station frequency.
 - 3 Press **ENT ▶▶** to search for a station.
- To cancel, press **↶** or **DIRECT**.
 - If no operation is done for 10 seconds after step 2, Direct Access Tuning is automatically canceled.

Other settings

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated or follow the instructions stated on the selected item.
- 4 Press and hold **Q/↶** to exit.

To return to the previous setting item, press **Q/↶**.

Default: **[XX]**

[TUNER SETTING]	
[SEEK MODE]	Selects the searching method for ◀◀ / ▶▶ buttons when pressed. [AUTO1]: Automatically search for a station. ; [AUTO2]: Search for a preset station. ; [MANUAL]: Manually search for a station.
[AUTO MEMORY]	[YES]: Automatically starts memorizing 6 stations with good reception. ; [NO]: Cancels. • Selectable only if [NORMAL] is selected for [PRESET TYPE]. (Page 6)
[MONO SET]	[ON]: Improves the FM reception, but the stereo effect will be lost. ; [OFF]: Cancels.
[NEWS SET]	(For KDC-MP382BT) [ON]: The unit will temporarily switch to News Programme if available. ; [OFF]: Cancels.
[REGIONAL]	(For KDC-MP382BT) [ON]: Switches to another station only in the specific region using the "AF" control. ; [OFF]: Cancels.
[AF SET]	(For KDC-MP382BT) [ON]: Automatically searches for another station broadcasting the same program in the same Radio Data System network with better reception when the current reception is poor. ; [OFF]: Cancels.


Radio

[TI]	[ON]: Allows the unit to temporarily switch to Traffic Information if available ("TI" indicator lights up) while listening to all sources except in AM.; [OFF]: Cancels.
[PTY SEARCH]	(For KDC-BT370U / KDC-BT282U / KMR-D382BT) Select the available Program Type (for Radio Broadcast Data System, see page 34), then press ◀▶ to start. (For KDC-MP382BT) 1 Turn the volume knob to select the available Program Type (for Radio Data System, see page 34), then press the knob. 2 Turn the volume knob to select the PTY language ([ENGLISH]/[FRENCH]/[GERMAN]), then press the knob. 3 Press ◀▶ to start searching.
[CLOCK]	
[TIME SYNC]	[ON]: Synchronizes the unit's time to the Radio Broadcast Data System/Radio Data System station time.; [OFF]: Cancels.

- [MONO SET]/[NEWS SET]/[REGIONAL]/[AF SET]/[TI]/[PTY SEARCH] is selectable only when the band is FM1/FM2/FM3.
- If the volume is adjusted during reception of traffic information, alarm or news bulletin, the adjusted volume is memorized automatically. It will be applied the next time traffic information, alarm or news bulletin is turned on.


CD/USB/iPod

Insert a disc




The source changes to CD automatically and playback starts.

Connect a USB device



The source changes to USB automatically and playback starts.

Connect an iPod/iPhone



The source changes to iPod USB automatically and playback starts.

- You can also connect iPod/iPhone via Bluetooth. (Page 17)

*1 Do not leave the cable inside the car when not in use.

*2 KCA-iP103: Lightning type

Basic operations



Selectable sources: CD/USB/iPod USB or iPod BT

For playable audio file, see "Playable files" on page 33.

To	On the faceplate	On the remote control
Play back/pause	Press 6 ▶▶ .	Press ENT ▶▶ .
Reverse/Fast-forward	Press and hold ◀◀ / ▶▶ .	Press and hold ◀◀ / ▶▶ (+).
Select a track/file	Press ◀◀ / ▶▶ .	Press ◀◀ / ▶▶ (+).
Select a folder*	Press 2 ^ / 1 ∇ .	Press #FM+/*AM-.
Repeat play	Press 4 ↺ repeatedly. [TRACK REPEAT]/[ALL REPEAT]: Audio CD [FILE REPEAT]/[FOLDER REPEAT]/[ALL REPEAT]: MP3/ WMA/AAC/WAV/FLAC file [REPEAT ONE]/[REPEAT ALL]/[REPEAT OFF]: iPod	
Random play	Press 3 ✂ repeatedly. [DISC RANDOM]/[RANDOM OFF]: Audio CD [FOLDER RANDOM]/[RANDOM OFF]: MP3/WMA/AAC/ WAV/FLAC file [SHUFFLE ON]/[SHUFFLE OFF]: iPod	
	Press and hold 3 ✂ to select [ALL RANDOM].*	

* For CD: Only for MP3/WMA/AAC files. This does not work for iPod.

Select music drive

While in USB source, press 5 repeatedly.

Stored songs in the following drive will be played back.

- Selected internal or external memory of a smartphone (Mass Storage Class).
- Selected drive of a multiple drive device. (This unit can support multiple drive device of up to 4 drives. However, this unit may take some time to read if three or more cards are connected.)

You can also select the music drive from the [FUNCTION] menu.

- Press the volume knob to enter [FUNCTION].
- Turn the volume knob to select [USB], then press the knob.
- Turn the volume knob to select [MUSIC DRIVE], then press the knob.
- Turn the volume knob to select [DRIVE CHANGE], then press the knob.
The next drive ([DRIVE 1] to [DRIVE 4]) is selected automatically and playback starts.
- Repeat step 1 to step 4 to select the following drives.
- Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

Direct Music Search (using the remote control)

- Press DIRECT.
- Press the number buttons to enter a track/file number.
- Press ENT **▶▶** to search for music.

- To cancel, press **↵** or DIRECT.
- Not available if Random Play is selected.
- Not applicable for iPod USB source.

Select a file to play

■ From a folder or list

- 1 Press **Q/↵**.
- 2 Turn the volume knob to select a folder/list, then press the knob.
- 3 Turn the volume knob to select a file, then press the knob.
Selected file starts playing.

■ Quick search (applicable only for CD source and USB source)

If you have many files, you can search through them quickly.

- 1 Press **Q/↵**.
- 2 Turn the volume knob to select a folder/list, then press the knob.
- 3 Turn the volume knob quickly to browse through the list quickly.
- 4 Turn the volume knob to select a file, then press the knob.
Selected file starts playing.

■ Skip search (applicable only for iPod USB source and iPod BT source)

If you have many files in the selected list, you can perform the following to search for a file by skipping through the list at a rate selected in [SKIP SEARCH].

- 1 Press **Q/↵**.
- 2 Turn the volume knob to select a list, then press the knob.
- 3 Press **◀◀/▶▶** to search at a preset skip search ratio.
 - Pressing and holding **◀◀/▶▶** searches at a 10% ratio regardless of the [SKIP SEARCH] settings.
- 4 Turn the volume knob to select a file, then press the knob.
Selected file starts playing.

[SKIP SEARCH] setting

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select [USB], then press the knob.
- 3 Turn the volume knob to select [SKIP SEARCH], then press the knob.
- 4 Turn the volume knob to select the skip search ratio, then press the knob.
[0.5%] (default)/[1%]/[5%]/[10%]
The skip search ratio is shown as a percentage of the total files.
- 5 Press and hold **Q/↵** to exit.

■ Alphabet search (applicable only for iPod USB source and iPod BT source)

You can search for a file according to the first character.


- 1 Press **Q/↵**.
- 2 Turn the volume knob to select a list, then press the knob.
- 3 Turn the volume knob quickly to enter character search.
- 4 Turn the volume knob to select the character.
 - Select "*" to search for a character other than A to Z, 0 to 9.
- 5 Press **◀◀/▶▶** to move to the entry position.
 - You can enter up to 3 characters.
- 6 Press the volume knob to start searching.
- 7 Turn the volume knob to select a file, then press the knob.
Selected file starts playing.
 - To return to the root folder/first file/top menu, press 5. (Not applicable for BT AUDIO source.)
 - To return to the previous setting item, press **Q/↵**.
 - To cancel, press and hold **Q/↵**.

SiriusXM® Radio (for KMR-D382BT)

Only SiriusXM® brings you more of what you love to listen to, all in one place. Get over 140 channels, including commercial-free music plus the best sports, news, talk, comedy and entertainment. Welcome to the world of satellite radio. A SiriusXM Vehicle Tuner and Subscription are required. For more information, visit <www.siriusxm.com>.

Preparation:

- 1 Connect the optional SiriusXM Vehicle Tuner (commercially available).



- 2 Check your Radio ID for activation.

The SiriusXM Radio ID is required for activation and can be found by tuning to Channel 0 as well as on the label found on the SiriusXM Vehicle Tuner and its packaging.

The Radio ID does not include the letters I, O, S or F.

- 3 Activate the subscription.

For users in the U.S.A.:

Online: Go to <www.siriusxm.com/activatenow>

Phone: Call 1-866-635-2349

For users in Canada:

Online: Go to <www.siriusxm.ca/activate>

Phone: Call 1-888-539-7474

- 4 Press **SRC** repeatedly to select SIRIUS XM to start updating.

Start listening

- 1 Press **SRC** repeatedly to select SIRIUS XM.
- 2 Press **BAND** repeatedly to select a band.
- 3 Press **Q/**.
"Q" indicator lights up.
- 4 Turn the volume knob to select a category, then press the knob.
If "ALL CHANNELS" is selected, all the available channels will be shown.
- 5 Turn the volume knob to select a channel, then press the knob.
 - Pressing and holding 1/2 changes the channel rapidly.
 - If no operation is done for 10 seconds, a channel will be selected automatically.(or)
Press **◀/▶** to search for a channel manually.
 - Pressing and holding **◀/▶** changes the channel rapidly.

If a locked channel or a mature channel is selected, a pass code input screen appears. Enter the pass code to receive the channel. (Page 14)

Parental Control

The Parental Control feature allows you to limit access to any SiriusXM channels, including those with mature content. When enabled, the Parental Control feature requires you to enter a pass code to tune to the locked channels.

- Information on setting up the pass code and locking channels can be found on page 14.

SiriusXM Keymode

Press and hold the volume knob to change the keymode (channel or replay). (Default: Channel keymode)

“GO” indicator lights up when replay keymode is selected.

When channel keymode is selected...

To	On the faceplate
Select a channel	Press ◀◀ / ▶▶ .
Change a channel rapidly	Press and hold ◀◀ / ▶▶ .
Store a channel of the current band	Press and hold one of the number buttons (1 to 6).
Select a stored channel of the current band	Press one of the number buttons (1 to 6).

When replay keymode is selected...

To	On the faceplate
Play back/pause	Press 6 ▶ .
Skip backward/forward	Press ◀◀ / ▶▶ .*
Rewind/Fast-forward	Press and hold ◀◀ / ▶▶ .*
Go to Live	Press 1 .*

* When Live is reached or selected, keymode is automatically changed to channel keymode.

SmartFavorites and TuneStart™

User stored channels are recognized as SmartFavorite channels*. The SiriusXM Vehicle Tuner automatically buffers the broadcast content in the background.

- SmartFavorites feature is available with SXV200 or later SiriusXM Vehicle Tuner.

* SXV300 (and later) SiriusXM Vehicle Tuner can use all 18 stored channels as SmartFavorites. The SXV200 SiriusXM Vehicle Tuner can use 6 stored channels from the current band as SmartFavorites.

When you select a SmartFavorite channel, you can rewind and replay up to 30 minutes of any of the missed news, talk, sports or music content.

- Playback starts from the beginning of the song if **[TUNE START]** is set to **[ON]** (page 14) for most music channels stored as a SmartFavorite.

Press one of the number buttons (1 to 6) to select a stored channel.

TuneScan™

You can get a short preview of the songs that you have missed on each of your SmartFavorites music channels or a music channel currently tuned into.

Press and hold BAND to start scanning the first 6 seconds of the recorded music contents.

- To listen to the current song, press the volume knob to stop scanning. The unit continues playing the current song.
- To select the previous/next song, press **◀◀** / **▶▶**.
- To cancel scanning, press and hold the volume knob. Playback returns to the channel before you entered TuneScan.
- Pressing any button other than volume knob or **◀◀** / **▶▶** will interrupt scanning and eventually stop scanning.

SiriusXM settings

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated or follow the instructions stated on the selected item.
- 4 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

Default: **[XX]**

[SIRIUS XM]	
[SEEK MODE]	Selects the tuning method for ◀◀ / ▶▶ buttons when pressed. [CHANNEL]: Manually search for a channel. ; [PRESET]: Search for a preset channel of the selected band. (Automatically search for preset 1 channel if the current channel is not a preset channel.)
[CHANNEL LOCK]	To unlock settings: 1 Turn the volume knob to select a number. 2 Press ◀◀ / ▶▶ to move to the entry position. 3 Repeat step 1 and step 2 to enter the current pass code. (Initial pass code is 0000.) 4 Press the volume knob to confirm.
[CODE SET]	1 Turn the volume knob to select a number. 2 Press ◀◀ / ▶▶ to move to the entry position. 3 Repeat step 1 and step 2 to enter a new 4-digit pass code. 4 Press the volume knob to confirm. 5 Repeat step 1 to step 4 to reconfirm the pass code. • Make a note of the new pass code to enter channel lock settings for next time.

[LOCK SETTING]	[MATURE CH]: Selects the SiriusXM-defined lock setting. ; [USER DEFINED]: Selects the individual channels the user wants to lock. ; [OFF]: Cancels.
[CHANNEL EDIT]*1	1 Turn the volume knob to select a category, then press the knob. 2 Turn the volume knob to select a channel you want to lock, then press the knob. “L” appears in front of the channel number. 3 Press and hold Q/↵ to exit.
[CHANNEL CLEAR]*1	[YES]: Clears all the locked channels. ; [NO]: Cancels.
[TUNE START]*2	[ON]: All qualified music channels in the SmartFavorites will start playback from the beginning of the song. ; [OFF]: Cancels.
[SIGNAL LEVEL]	Shows the strength ([NO SIGNAL]/[WEAK]/[GOOD]/[STRONG]) of the current received signal.
[BUFFER USAGE]	Shows the memory usage ([0%] to [100%]) for Replay buffer.
[SXM RESET]	[YES]: Resets all SiriusXM settings to default. ; [NO]: Cancels.

*1 Displayed only when [LOCK SETTING] is set to [USER DEFINED].

*2 Available only if the connected SiriusXM Vehicle Tuner is SXV200 or later which supports SmartFavorites.

AUX


You can listen to music from a portable audio player via the auxiliary input jack.

Preparation:

Select [ON] for [BUILT-IN AUX] in [SOURCE SELECT]. (Page 6)

Start listening

- 1 Connect a portable audio player (commercially available).



- 2 Press $\odot$ SRC repeatedly to select AUX.
- 3 Turn on the portable audio player and start playback.

Set the name of the external device

While listening to a portable audio player connected to the unit...

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select [SYSTEM], then press the knob.
- 3 Turn the volume knob to select [AUX NAME SET], then press the knob.
- 4 Turn the volume knob to select an item, then press the knob.
[AUX] (default)/[DVD]/[PORTABLE]/[GAME]/[VIDEO]/[TV]
- 5 Press and hold $\mathbf{Q}/\mathbf{S}$ to exit.

To return to the previous setting item, press $\mathbf{Q}/\mathbf{S}$.

KENWOOD Remote Application

You can control the KENWOOD car receiver from iPhone/iPod touch (via Bluetooth or via USB input terminal) or Android device (via Bluetooth) using KENWOOD Remote application.

- For more information, visit <<https://www.kenwood.com/cs/ce/>>.

Preparation:

Install the latest version of KENWOOD Remote application on your device before connecting.

Start using KENWOOD Remote application

- 1 Start up the KENWOOD Remote application on your device.
- 2 Connect your device.
 - For Android device:
Pair the Android device with this unit via Bluetooth. (Page 17)
 - For iPhone/iPod touch:
Connect iPhone/iPod touch to the USB input terminal. (Page 9)
(or)
Pair the iPhone/iPod touch with this unit via Bluetooth. (Page 17)
(Make sure the USB input terminal is not connected to any device.)
- 3 Select the device to use from the [FUNCTION] menu.
See "Settings to use KENWOOD Remote application" on page 16.
By default, [ANDROID] is selected. To use iPhone/iPod touch, select [YES] for [IOS].
 - **KMR-D382BT**: "R,APP" indicator lights up when KENWOOD Remote application is connected.

KENWOOD Remote Application

Settings to use KENWOOD Remote application

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated.
- 4 Press and hold **Q**/**↵** to exit.

To return to the previous setting item, press **Q**/**↵**.

Default: **[XX]**

[REMOTE APP]

[SELECT] Selects the device ([IOS] or [ANDROID]) to use the application.

[IOS] **[YES]**: Selects iPhone/iPod touch to use the application via Bluetooth or connected via USB input terminal. ; **[NO]**: Cancels.
If [IOS] is selected, select iPod BT source (or iPod USB source if your iPhone/iPod touch is connected via USB input terminal) to activate the application.

- The connectivity of the application will be interrupted or disconnected if:
 - You change from iPod BT source to any playback source connected via the USB input terminal.
 - You change from iPod USB source to iPod BT source.

[ANDROID] **[YES]**: Selects Android device to use the application via Bluetooth. ; **[NO]**: Cancels.

[ANDROID LIST] Selects the Android device to use from the list.

- Displayed only when [ANDROID] of [SELECT] is set to [YES].

[STATUS]

Shows the status of the selected device.

[IOS CONNECTED]: You are able to use the application using the iPhone/iPod touch connected via Bluetooth or USB input terminal.

[IOS NOT CONNECTED]: No iOS device is connected to use the application.

[ANDROID CONNECTED]: You are able to use the application using the Android device connected via Bluetooth.

[ANDROID NOT CONNECTED]: No Android device is connected to use the application.

Bluetooth®

- Depending on the Bluetooth version, operating system and the firmware version of your mobile phone, Bluetooth features may not work with this unit.
- Be sure to turn on the Bluetooth function of the device to make the following operations.
- Signal conditions vary depending on the surroundings.

Bluetooth — Connection


Supported Bluetooth profiles

- Hands-Free Profile (HFP)
- Advanced Audio Distribution Profile (A2DP)
- Audio/Video Remote Control Profile (AVRCP)
- Serial Port Profile (SPP)
- Phonebook Access Profile (PBAP)

Supported Bluetooth codecs

- Sub Band Codec (SBC)
- Advanced Audio Coding (AAC)

Connect the microphone



Pair and connect a Bluetooth device for the first time

- 1 Press **⏻ SRC** to turn on the unit.
- 2 Search and select the name of your receiver ("**KDC-BT370U**" / "**KDC-BT282U**" / "**KDC-MP382BT**" / "**KMR-D382BT**") on the Bluetooth device.
"PAIRING" → "PASS XXXXXX" → "Device name" → "PRESS" → "VOLUME KNOB" appears on the display.
 - For some Bluetooth devices, you may need to enter the Personal Identification Number (PIN) code immediately after searching.
- 3 Press the volume knob to start pairing.
"PAIRING OK" appears when pairing is completed.

Once pairing is completed, Bluetooth connection is established automatically.

- **KDC-BT370U** / **KDC-BT282U** / **KDC-MP382BT**: "BT1" and/or "BT2" indicator on the display window lights up.
- **KMR-D382BT**: "BT1 CONNECTED" and/or "BT2 CONNECTED" appears on the display window for 2 seconds.
" " indicator lights up to show the strength of the battery and signal of the connected device.
- This unit supports Secure Simple Pairing (SSP).
- Up to five devices can be registered (paired) in total.
- Once the pairing is completed, the Bluetooth device will remain registered in the unit even if you reset the unit. To delete the paired device, see **[DEVICE DELETE]** on page 21.
- A maximum of two Bluetooth phones and one Bluetooth audio device can be connected at any time. To connect or disconnect the registered device, see **[PHONE SELECT]** or **[AUDIO SELECT]** in **[BT MODE]**. (Page 21)
However, while in BT AUDIO source, you can connect to five Bluetooth audio devices and switch between these five devices. (Page 22)
- Some Bluetooth devices may not automatically connect to the unit after pairing. Connect the device to the unit manually.
- Refer to the instruction manual of the Bluetooth device for more information.


Bluetooth®

Auto Pairing

When you connect iPhone/iPod touch to the USB input terminal, pairing request (via Bluetooth) is automatically activated if [AUTO PAIRING] is set to [ON]. (Page 21)

Press the volume knob to pair once you have confirmed the device name.

Bluetooth — Mobile phone



Receive a call

When there is an incoming call:

- **KMR-D382BT**: [ZONE 2] illuminates in green color and flashes.
- The unit answers the call automatically if [AUTO ANSWER] is set to a selected time. (Page 19)

During a call:

- **KMR-D382BT**: [ZONE 1] illuminates according to the settings made for [DISPLAY] (page 27) and [ZONE 2] illuminates in green color.
- If you turn off the unit or detach the faceplate, Bluetooth is disconnected.

The following operations may differ or be unavailable depending on the connected phone.

To	On the faceplate	On the remote control
First incoming call...		
Answer a call	Press or the volume knob or one of the number buttons (1 to 6).	Press .
Reject a call	Press .	Press .
End a call	Press .	Press .
While talking on the first incoming call...		
Answer another incoming call and hold the current call	Press .	Press .
Reject another incoming call	Press .	Press .
While having two active calls...		
End current call and activate held call	Press .	Press .
Swap between the current call and held call	Press .	Press .
Adjust the phone volume*1 [00] to [35] (Default: [15])	Turn the volume knob during a call.	Press VOL or VOL during a call. (Press and hold VOL to continuously increase the volume to 15.)

Bluetooth®

To	On the faceplate	On the remote control
Switch between hands-free and private talk modes*2	Press 6 ► during a call.	(Not available)

*1 This adjustment will not affect the volume of the other sources.

*2 Operations may vary according to the connected Bluetooth device.

■ Improve the voice quality

While talking on the phone...

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected or activated.
- 4 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

Default: **[XX]**

[MIC GAIN]	[−10] to [+10] ([−4]): The sensitivity of the microphone increases as the number increases.
[NR LEVEL]	[LEVEL −5] to [LEVEL +5] ([LEVEL 0]): Adjust the noise reduction level until the least noise is being heard during a phone conversation.
[ECHO CANCEL]	[LEVEL −5] to [LEVEL +5] ([LEVEL 0]): Adjust the echo cancellation delay time until the least echo is being heard during a phone conversation.

- Call quality may depend on mobile phone.

■ Make the setting for answering a call

- 1 Press **📞** to enter Bluetooth mode.
- 2 Turn the volume knob to select [SETTINGS], then press the knob.
- 3 Turn the volume knob to select [AUTO ANSWER], then press the knob.
- 4 Turn the volume knob to select the time (in seconds) for the unit to answer the call automatically, then press the knob.
[01] to [30], or select [OFF] to cancels. (Default: [OFF])
- 5 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

■ Make a call

You can make a call from the call history, phonebook, or dialing the number. Call by voice is also possible if your mobile phone has the feature.

- 1 Press **📞** to enter Bluetooth mode.
“(First device name)” appears.
 - If two Bluetooth phones are connected, press **📞** again to switch to the other phone.
“(Second device name)” appears.
- 2 Turn the volume knob to select an item (page 20), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated or follow the instructions stated on the selected item.
- 4 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

[CALL HISTORY]

(Applicable only if the phone supports PBAP.)

- Press the volume knob to select a name or a phone number.
 - "I" indicates call received, "O" indicates call made, "M" indicates call missed.
 - Press DISP to change the display category (NUMBER or NAME).
 - "NO DATA" appears if there is no recorded call history or call number.
- Press the volume knob to call.

[PHONE BOOK]

(Applicable only if the phone supports PBAP.)

- Turn the volume knob quickly to enter alphabet search mode (if the phonebook contains many contacts). The first menu (ABCDEFGHIJK) appears.
 - To go to the other menu (LMNOPQRSTUVWXYZ), press 2 / 1 .
 - To select the desired first letter, turn the volume knob or press / , then press the knob. Select "1" to search with numbers and select "✖" to search with symbols.
- Turn the volume knob to select a name, then press the knob.
- Turn the volume knob to select a phone number, then press the knob to call.
 - For using phonebook with this unit, make sure to allow access to or transfer from your smartphone. Depending on the connected phone, the process may be different.
 - Contacts are categorized as: HM (home), OF (office), MO (mobile), OT (other), GE (general)
 - This unit can display only non-accent letters. (Accent letters such as "Ů" are shown as "U".)

[NUMBER DIAL]

- Turn the volume knob to select a number (0 to 9) or character (✖, #, +).
- Press / to move the entry position. Repeat step 1 and step 2 until you finish entering the phone number.
- Press the volume knob to call.

(or using the remote control)

 - Press the number buttons (0 to 9) to enter the phone number.
 - Press to call.

[VOICE]

Speak the name of the contact you want to call or the voice command to control the phone functions. (See also the following "Make a call using voice recognition".)

[LOW]/[MID]/[FULL]: Shows the strength of the battery.*

[NO SIGNAL]/[LOW]/[MID]/[MAX]: Shows the strength of the current received signal.*

* Functionality depends on the type of the phone used.

Make a call using voice recognition

- Press and hold to activate the voice recognition of the connected phone.
 - Speak the name of the contact you want to call or the voice command to control the phone functions.
- Supported Voice Recognition features vary for each phone. Refer to the instruction manual of the connected phone for details.

Store a contact in memory

You can store up to 6 contacts into the number buttons (1 to 6).

- Press to enter Bluetooth mode.
- Turn the volume knob to select [CALL HISTORY], [PHONE BOOK] or [NUMBER DIAL], then press the knob.
- Turn the volume knob to select a contact or enter a phone number. If a contact is selected, press the volume knob to show the phone number.
- Press and hold one of the number buttons (1 to 6). "STORED" appears when the contact is stored.

To erase a contact from the preset memory, select [NUMBER DIAL] in step 2, store a blank number in step 3 and proceed to step 4.

Bluetooth®

Make a call to a registered number

- 1 Press  to enter Bluetooth mode.
- 2 Press one of the number buttons (1 to 6).
- 3 Press the volume knob to call.
"NO MEMORY" appears if there is no contact stored.

Bluetooth mode settings

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated or follow the instructions stated on the selected item.
- 4 Press and hold  to exit.

To return to the previous setting item, press .

Default: **[XX]**

[BT MODE]	
[PHONE SELECT]	Selects the phone or audio device to connect or disconnect. "✕" appears in front of the device name when connected.
[AUDIO SELECT]	"▷" appears in front of the current playback audio device. • You can connect a maximum of two Bluetooth phones and one Bluetooth audio device at a time.
[DEVICE DELETE]	1 Turn the volume knob to select a device to delete, then press the knob. 2 Turn the volume knob to select [YES] or [NO], then press the knob.
[PIN CODE EDIT] (0000)	Changes the PIN code (up to 6 digits). 1 Turn the volume knob to select a number. 2 Press   to move the entry position. Repeat step 1 and step 2 until you finish entering the PIN code. 3 Press the volume knob to confirm.

[RECONNECT]	[ON]: The unit is automatically reconnect when the last connected Bluetooth device is within the connectable range. ; [OFF]: Cancels.
[AUTO PAIRING]	[ON]: The unit is automatically paired with the supported Bluetooth device (iPhone/iPod touch) when it is connected through USB input terminal. Depending on the operating system of the connected device, this function may not work. ; [OFF]: Cancels.
[INITIALIZE]	[YES]: Initializes all the Bluetooth settings (including stored pairing, phonebook, and etc.). ; [NO]: Cancels.

Bluetooth test mode

You can check the connectivity of the supported profile between the Bluetooth device and the unit.

- Make sure there is no Bluetooth device paired.

- 1 Press and hold .
"PLEASE PAIR YOUR PHONE PIN 0000" appears on the display.
- 2 Search and select the name of your receiver ("KDC-BT370U"/
"KDC-BT282U"/"KDC-MP382BT"/"KMR-D382BT") on the Bluetooth device.
- 3 Operate the Bluetooth device to confirm pairing.
"TESTING" flashes on the display.

The connectivity result (OK or NG) appears after the test.

PAIRING: Pairing status

HF CNT: Hands-Free Profile (HFP) compatibility

AUD CNT: Advanced Audio Distribution Profile (A2DP) compatibility


PB DL: Phonebook Access profile (PBAP) compatibility

To cancel test mode, press and hold  SRC to turn off the unit.

Bluetooth®

Bluetooth — Audio

- Operations and display indications may differ according to their availability on the connected device.
- Depending on the connected device, some features may not work with your device.



While in BT AUDIO source, you can connect to five Bluetooth audio devices and switch between these five devices.

Listen to the audio player via Bluetooth

- 1 Press SRC repeatedly (or press SRC on the remote control) to select BT AUDIO.
 - Pressing enters BT AUDIO directly.
- 2 Operate the audio player via Bluetooth to start playback.

To	On the faceplate	On the remote control
Play back/pause	Press 6	Press ENT
Select group or folder	Press 2 / 1	Press #FM+/*AM-
Reverse skip/ Forward skip	Press /	Press / (+).
Reverse/Fast-forward	Press and hold /	Press and hold / (+).

To	On the faceplate
Repeat play	Press 4 repeatedly. [ALL REPEAT], [FILE REPEAT], [GROUP REPEAT], [REPEAT OFF]
Random play	Press and hold 3 to select [ALL RANDOM] or [GROUP RANDOM]. • Press 3 to select [RANDOM OFF].
Select a file from a folder/list	Refer to "Select a file to play" on page 11.
Switch between connected Bluetooth audio devices	Press 5. (Pressing the "Play" key on the connected device itself also causes switching of sound output from the device.)


Listen to iPod/iPhone via Bluetooth

You can listen to the songs on the iPod/iPhone via Bluetooth on this unit.

Press SRC repeatedly to select iPod BT.

- You can operate the iPod/iPhone in the same way as iPod/iPhone via USB input terminal. (Page 9)
- If you plug in an iPod/iPhone to the USB input terminal while listening to iPod BT source, the source automatically changes to iPod USB source. Press SRC to select iPod BT source if the device is still connected via Bluetooth.

Audio Settings



- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected or activated.
- 4 Press and hold **Q/⏏** to exit.

(or using the remote control)

- 1 Press AUD to enter [AUDIO CONTROL].
- 2 Press **▲/▼** to select an item, then press ENT **▶||**.

To return to the previous setting item, press **Q/⏏**.

Default: **[XX]**

[AUDIO CONTROL]	
[SUB-W LEVEL]	[LEVEL -50] to [LEVEL +10] ([LEVEL 0]): Adjusts the subwoofer output level.
[EASY EQ]	Adjusts your own sound settings. • The settings are stored to [USER] in [PRESET EQ]. • The settings made may affect the current settings of [MANUAL EQ].
[SW]:	[LEVEL -50] to [LEVEL +10] (Default: [LEVEL 0])
[BASS]:	[LEVEL -9] to [LEVEL +9] [LEVEL 0]
[MID]:	[LEVEL -9] to [LEVEL +9] [LEVEL 0]
[TRE]:	[LEVEL -9] to [LEVEL +9] [LEVEL 0]

[MANUAL EQ]	Adjusts your own sound settings for each source. • The settings are stored to [USER] in [PRESET EQ]. • The settings made may affect the current settings of [EASY EQ].	
[62.5HZ]	[LEVEL]	[LEVEL -9] to [LEVEL +9] ([LEVEL 0]): Adjusts the level to memorize for each source. (Before making an adjustment, select the source you want to adjust.)
	[BASS EXTEND]	[ON]: Turns on the extended bass. ; [OFF]: Cancels.
[100HZ]/[160HZ]/ [250HZ]/[400HZ]/ [630HZ]/[1KHZ]/ [1.6KHZ]/[2.5KHZ]/ [4KHZ]/[6.3KHZ]/ [10KHZ]/[16KHZ]	[LEVEL]	[LEVEL -9] to [LEVEL +9] ([LEVEL 0]): Adjusts the level to memorize for each source. (Before making an adjustment, select the source you want to adjust.)
[Q FACTOR]		[1.35]/[1.50]/[2.00]: Adjusts the quality factor.
[PRESET EQ]	[NATURAL]/[ROCK]/[POPS]/[EASY]/[TOP40]/[JAZZ]/[POWERFUL]/[USER]: Selects a preset equalizer suitable to the music genre. (Select [USER] to use the settings made in [EASY EQ] or [MANUAL EQ].)	
[BASS BOOST]	[LV1] to [LV5]: Selects your preferred bass boost level. ; [OFF]: Cancels.	
[LOUDNESS]	[LV1]/[LV2]: Selects your preferred low or high frequencies boost to produce a well-balanced sound at low volume. ; [OFF]: Cancels.	
[SUBWOOFER SET]	[ON]: Turns on the subwoofer output. ; [OFF]: Cancels.	

Audio Settings

[FADER]	[R15] to [F15] ([0]): Adjusts the front and rear speaker output balance.
[BALANCE]	[L15] to [R15] ([0]): Adjusts the left and right speaker output balance.
[VOLUME OFFSET]	[−15] to [+6] ([0]): Presets the initial volume level of each source by comparing to the FM volume level. (Before adjustment, select the source you want to adjust.)
[SOUND EFFECT]	
[SOUND RECNSTR] (Sound reconstruction)	(Not applicable for RADIO source, AUX source and SIRIUS XM source.) [ON]: Creates realistic sound by compensating the high-frequency components and restoring the rise-time of the waveform that are lost in audio data compression. ; [OFF]: Cancels.
[SPACE ENHANCE]	(Not applicable for RADIO source.) [SML]/[MED]/[LRG]: Virtually enhances the sound space. ; [OFF]: Cancels.
[SND REALIZER]	[LV1]/[LV2]/[LV3]: Virtually makes the sound more realistic. ; [OFF]: Cancels.
[STAGE EQ]	[LOW]/[MID]/[HI]: Virtually adjusts the sound position heard from the speakers. ; [OFF]: Cancels.
[DRIVE EQ]	[ON]: Boosts the frequency to reduce the noise heard from outside the car or running noise of the tyres. ; [OFF]: Cancels.
[SPEAKER SIZE]	The frequency and slope settings are automatically set for the crossover of the selected speaker.
[FRONT]	[SIZE] [3.5"/[4"]/[4.75"/[5"]/[6.5"/[6.75"/[7"/[4×6]/[5×7]/[6×8]/[6×9]/[7×10]: Selects according to the connected speaker size for optimum performance.
	[TWEETER] [SMALL]/[MIDDLE]/[LARGE]: Selects according to the size range of the connected tweeter for optimum performance. ; [NONE]: Not connected.

[REAR]	[3.5"]/[4"]/[4.75"]/[5"]/[6.5"]/[6.75"]/[7"]/[4×6]/[5×7]/[6×8]/[6×9]/[7×10]: Selects according to the connected speaker size for optimum performance. ; [NONE]: Not connected.	
[SUBWOOFER]	[6.5"]/[8"]/[10"]/[12"]/[15" OVER]: Selects according to the connected speaker size for optimum performance. ; [NONE]: Not connected.	
[X ' OVER]		
[TWEETER]	[FRQ] [1KHZ]/[1.6KHZ]/[2.5KHZ]/[4KHZ]/[5KHZ]/[6.3KHZ]/[8KHZ]/[10KHZ]/[12.5KHZ]: Adjusts the crossover frequency for the tweeter speaker.	
	[GAIN LEFT] [−8] to [0]: Adjusts the output volume of the left tweeter.	
	[GAIN RIGHT] [−8] to [0]: Adjusts the output volume of the right tweeter.	
[FRONT HPF]	[F-HPF FRQ] [30HZ]/[40HZ]/[50HZ]/[60HZ]/[70HZ]/[80HZ]/[90HZ]/[100HZ]/[120HZ]/[150HZ]/[180HZ]/[220HZ]/[250HZ]: Adjusts the crossover frequency for the selected speakers (high pass filter). ; [THROUGH]: All signals are sent to the selected speakers.	
	[F-HPF SLOPE] [−6DB]/[−12DB]/[−18DB]/[−24DB]: Adjusts the crossover slope. (Selectable only if a setting other than [THROUGH] is selected for [F - HPF FRQ].)	
	[F-HPF GAIN] [−8] to [0]: Adjusts the output volume of the selected speaker.	
[REAR HPF]	[R-HPF FRQ]	Configure the settings for the rear speakers similarly to the front speakers.
	[R-HPF SLOPE]	
	[R-HPF GAIN]	

Audio Settings

[SUBWOOFER LPF]	[SW LPF FRQ]	[30HZ]/[40HZ]/[50HZ]/[60HZ]/[70HZ]/[80HZ]/[90HZ]/[100HZ]/[120HZ]/[150HZ]/[180HZ]/[220HZ]/[250HZ]: Adjusts the crossover frequency for the subwoofer (low pass filter).; [THROUGH]: All signals are sent to the subwoofer.
	[SW LPF SLOPE]	[−6DB]/[−12DB]/[−18DB]/[−24DB]: Adjusts the crossover slope. (Selectable only if a setting other than [THROUGH] is selected for [SW LPF FRQ].)
	[SW LPF PHASE]	[REVERSE] (180°)/[NORMAL] (0°): Selects the phase of the subwoofer output to be in line with the speaker output for optimum performance.
	[SW LPF GAIN]	[−8] to [0]: Adjusts the output volume of the subwoofer.
[DTA SETTINGS]		
For settings, see the following “Digital Time Alignment settings”.		
[CAR SETTINGS]		

- (For **[KDC-BT370U]** / **[KDC-BT282U]** / **[KDC-MP382BT]**)
The following item is selectable only if [SWITCH PREOUT] is set to [SUB-W] (page 6):
 - [SUB-W LEVEL]
 - [SUBWOOFER SET]
 - [SW LEVEL] of [EASY EQ]
 - [SUBWOOFER] of [SPEAKER SIZE]
 - [SUBWOOFER LPF] of [X ' OVER]
 - [SUBWOOFER] of [DISTANCE] and [GAIN] in [DTA SETTINGS]
- The following item is selectable only if [SUBWOOFER SET] is set to [ON] (page 23):
 - [SUB-W LEVEL]
 - [SW LEVEL] of [EASY EQ]
 - [SUBWOOFER] of [SPEAKER SIZE]
 - [SUBWOOFER LPF] of [X ' OVER]
 - [SUBWOOFER] of [DISTANCE] and [GAIN] in [DTA SETTINGS]

- The following item is selectable only if a setting other than [NONE] is selected for [TWEETER], [REAR] and [SUBWOOFER] of [SPEAKER SIZE]:
 - [TWEETER], [REAR HPF], [SUBWOOFER LPF] of [X ' OVER]

Digital Time Alignment settings

Digital Time Alignment sets the delay time of the speaker output to create a more suitable environment for your vehicle.


- For more information, see “Determining the delay time automatically” on page 26.

[DTA SETTINGS]	
[POSITION]	Selects your listening position (reference point). [ALL]: Not compensating; [FRONT RIGHT]: Front right seat; [FRONT LEFT]: Front left seat; [FRONT ALL]: Front seats
[DISTANCE]	[0FT] to [20.01FT]: Fine adjust the distance to compensate. (Before making an adjustment, select the speaker you want to adjust.)
[GAIN]	[−8DB] to [0DB]: Fine adjust the output volume of the selected speaker. (Before making an adjustment, select the speaker you want to adjust.)
[DTA RESET]	[YES]: Resets the settings ([DISTANCE] and [GAIN]) of the selected [POSITION] to default.; [NO]: Cancels.
[CAR SETTINGS]	
Identify your car type and rear speaker location in order to make the adjustment for [DTA SETTINGS].	
[CAR TYPE]	[COMPACT]/[FULL SIZE CAR]/[WAGON]/[MINIVAN]/[SUV]/[MINIVAN(LONG)]: Selects the type of vehicle.; [OFF]: Not compensating.
[R-SP LOCATION]	Selects the location of the rear speakers in your vehicle to calculate the furthest distance from the listening position selected (reference point). • [DOOR]/[REAR DECK]: Selectable only when [CAR TYPE] is selected as [OFF], [COMPACT], [FULL SIZE CAR], [WAGON] or [SUV]. • [2ND ROW]/[3RD ROW]: Selectable only when [CAR TYPE] is selected as [MINIVAN] or [MINIVAN(LONG)].

Audio Settings

- Before making an adjustment for [DISTANCE] and [GAIN] of [DTA SETTINGS], select the speaker you want to adjust:
[FRONT LEFT]/[FRONT RIGHT]/[REAR LEFT]/[REAR RIGHT]/[SUBWOOFER]
 - You can only select [REAR LEFT], [REAR RIGHT] and [SUBWOOFER] if a setting other than [NONE] is selected for [REAR] and [SUBWOOFER] of [SPEAKER SIZE].
- [R-SP LOCATION] of [CAR SETTING] is selectable only if a setting other than [NONE] is selected for [REAR] of [SPEAKER SIZE].

Determining the delay time automatically



If you specify the distance from the currently set listening position to every speaker, the delay time will be automatically calculated.

- Set [POSITION] and determine the listening position as the reference point (the reference point for [FRONT ALL] will be the center between the right and left in the front seats).
- Measure the distances from the reference point to the speakers.
- Calculate the distance between the furthest speaker (subwoofer on the illustration) and other speakers.
- Sets the [DISTANCE] calculated in step 3 for individual speakers.
- Adjusts [GAIN] for individual speakers.

Example: When [FRONT ALL] is selected as the listening position.


Display Settings

Zone identification for brightness setting

KDC-BT370U

KDC-BT282U


KDC-MP382BT



ALL ZONE

Zone identification for color settings and brightness settings

KMR-D382BT



ALL ZONE

Set the dimmer

Press and hold DISP (DIM) to turn on or off the dimmer.

- Once you press and hold this button, [DIMMER] setting (page 27) will be overwritten.

Display Settings

Change the display settings

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item (see the following table), then press the knob.
- 3 Repeat step 2 until the desired item is selected/activated or follow the instructions stated on the selected item.
- 4 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

Default: **[XX]**

[DISPLAY]

[COLOR SELECT] (For **[KMR-D382BT]**)

Selects illumination colors for **[ALL ZONE]**, **[ZONE 1]** and **[ZONE 2]** separately.

- 1 Select a zone. (See the illustration on page 26.)
- 2 Select a preset color for the selected zone.

Default: **[INITIAL COLOR]**

To make your own color, select **[CUSTOM R/G/B]**. The color you have made will be stored in **[CUSTOM R/G/B]**.

- 1 Press the volume knob to enter the detailed color adjustment.
- 2 Press **◀/▶** to select the color (**[R]**/**[G]**/**[B]**) to adjust.
- 3 Turn the volume knob to adjust the level (**[0]** to **[9]**), then press the knob.

[DIMMER]

Dims the illumination.

[ON]: Dimmer is turned on.

[OFF]: Dimmer is turned off.

[DIMMER TIME]: Set the time to turn on dimmer and to turn off dimmer.

- 1 Turn the volume knob to adjust the **[ON]** time, then press the knob.
- 2 Turn the volume knob to adjust the **[OFF]** time, then press the knob.

Default: **[ON]**: **[6:00PM]**; **[OFF]**: **[6:00AM]**

[BRIGHTNESS]

Sets the brightness for day and night separately.

- 1 **[DAY]/[NIGHT]**: Select day or night.
- 2 Select a zone. (See the illustration on page 26.)
- 3 **[LVL00]** to **[LVL31]**: Set the brightness level.

[TEXT SCROLL]

[ONCE]: Scrolls the display information once.; **[AUTO]**: Repeats scrolling at 5-second intervals.; **[OFF]**: Cancels.

[LEVEL METER]

(For **[KMR-D382BT]**)

[ON]: Shows the level meter on the display window (as shown below).; **[OFF]**: Cancels.



Level meter

[CLOCK]

[CLOCK DISPLAY] (Except for **[KMR-D382BT]**)

[ON]: The clock time is shown on the display even when the unit is turned off.; **[OFF]**: Cancels.

[DEMO MODE]

(Except for **[KMR-D382BT]**)

[ON]: Activates the display demonstration automatically if no operation is done for about 15 seconds.; **[OFF]**: Deactivates.

Preset color:


[INITIAL COLOR]/[VARIABLE SCAN]/[CUSTOM R/G/B]/[RED1]/[RED2]/[RED3]/[PURPLE1]/[PURPLE2]/[PURPLE3]/[PURPLE4]/[BLUE1]/[BLUE2]/[BLUE3]/[SKYBLUE1]/[SKYBLUE2]/[LIGHTBLUE]/[AQUA1]/[AQUA2]/[GREEN1]/[GREEN2]/[GREEN3]/[YELLOWGREEN1]/[YELLOWGREEN2]/[YELLOW]/[ORANGE1]/[ORANGE2]/[ORANGERED]

Learning Steering Remote Control (for KDC-MP382BT)

You can control the unit with the steering remote control keys on your vehicle. After connection, you can configure the control keys according to your preference.

- You can only make this configuration if your vehicle is equipped with the electrical steering remote control.
- If the steering remote control in your car is not compatible, configuration may not be completed and an error message may appear. (Page 35)

Make the connection



Configure the control keys

- 1 Press **⏻**SRC repeatedly to enter **STANDBY**.
- 2 Press the volume knob to enter **[FUNCTION]**.
- 3 Turn the volume knob to select **[SYSTEM]**, then press the knob.
- 4 Turn the volume knob to select **[USER S.REMO]**, then press the knob.
- 5 Turn the volume knob to select **[SET KEY]**, then press the knob.
A key list of 16 assignable keys appears.
 - **[K## NONE]**: No function has been assigned.
- 6 Turn the volume knob to select any key from the key list to assign the function, then press the knob.
"PRESS KEY TO ASSIGN K##" appears.

- 7 Press and hold any control keys on your steering remote control which you want to assign.

A list of key functions will appear on the display.

[NONE] (default)/**[ATT]**/**[SEEK UP]**/**[SEEK DOWN]**/**[VOL UP]**/**[VOL DOWN]**/**[MODE]**/**[ON HOOK]**/**[OFF HOOK]**/**[VOICE]**/**[ENTER]**

- 8 Turn the volume knob to select a function to assign, then press the knob.

The selected key function is assigned to the steering remote control key you have selected in step 7.

The display returns to the key list as on step 5.

- **[K## (Function)]**: When certain function has been assigned to a key.

- 9 Repeat step 6 to step 8 to assign other control keys.
- 10 Press and hold **Q/↵** to exit.

Reassign the control keys

- 1 Press **⏻**SRC repeatedly to enter **STANDBY**.
- 2 Press the volume knob to enter **[FUNCTION]**.
- 3 Turn the volume knob to select **[SYSTEM]**, then press the knob.
- 4 Turn the volume knob to select **[USER S.REMO]**, then press the knob.
- 5 Turn the volume knob to select **[RESET KEY]**, then press the knob.
- 6 Turn the volume knob to select **[YES]**, then press the knob.
All the control keys will be reset.
Selecting **[NO]** will cancel the operation.

When **[FACTORY RESET]** is set to **[YES]** (page 7), it will also reset the learning steering remote control.

To return to the previous setting item, press **Q/↵**.

Installation/Connection

This section is for the professional installer.
For safety's sake, leave wiring and mounting to professionals. Consult the car audio dealer.

▲ WARNING

- The unit can only be used with a 12 V DC power supply, negative ground.
- Disconnect the battery's negative terminal before wiring and mounting.
- Do not connect Battery wire (yellow) and Ignition wire (red) to the car chassis or Ground wire (black) to prevent a short circuit.
- To prevent short circuit:
 - Insulate unconnected wires with vinyl tape.
 - Be sure to ground this unit to the car's chassis again after installation.
 - Secure the wires with cable clamps and wrap vinyl tape around the wires that comes into contact with metal parts to protect the wires.

▲ CAUTION

- Install this unit in the console of your vehicle. Do not touch the metal parts of this unit during and shortly after use of the unit. Metal parts such as the heat sink and enclosure become hot.
- Do not connect the $\ominus$ wires of speakers to the car chassis or Ground wire (black), or connect them in parallel.
- Mount the unit at an angle of less than 30°.
- If your vehicle wiring harness does not have the ignition terminal, connect Ignition wire (red) to the terminal on the vehicle's fuse box which provides 12 V DC power supply and is turned on and off by the ignition key.
- Keep all cables away from heat dissipate metal parts.
- After the unit is installed, check whether the brake lamps, blinkers, wipers, etc. on the car are working properly.
- If the fuse blows, first make sure the wires are not touching car's chassis, then replace the old fuse with one that has the same rating.

Part list for installation


(A) Faceplate (×1)




(B) Trim plate (×1)



(C) Mounting sleeve (×1)



(D) Wiring harness (×1)



(E) Extraction key (×2)



(F) Screws*



M5 × 7 mm (×4)



M5 × 6 mm (×4)



M4 × 8 mm (×1)

* Supplied for **KDC-MP382BT** / **KMR-D382BT**.


Basic procedure

- 1 Remove the key from the ignition switch, then disconnect the $\ominus$ terminal of the car battery.
- 2 Connect the wires properly.
See "Wiring connection" on page 31.
- 3 Install the unit to your car.
See "Installing the unit (in-dash mounting)" on page 30.
- 4 Connect the $\ominus$ terminal of the car battery.
- 5 Press $\odot$ SRC to turn on the power.
- 6 Detach the faceplate and reset the unit within 5 seconds. (Page 4)


Installation/Connection

Installing the unit (in-dash mounting)

1




2



Installing the unit (without mounting sleeve)


- 1 Remove the mounting sleeve and trim plate from the unit.
- 2 Align the holes in the unit (on both sides) with the vehicle mounting bracket and secure the unit with screws (supplied/commercially available).



▲ Use only the specified screws. Using wrong screws might damage the unit.

Removing the unit

- 1 Detach the faceplate.
- 2 Fit the catch pin on the extraction keys into the holes on both sides of the trim plate, then pull it out.
- 3 Insert the extraction keys deeply into the slots on each side, then follow the arrows as shown on the illustration.




Installation/Connection

Wiring connection


IMPORTANT

We recommend installing the unit with a commercially available custom wiring harness specific for your car and leave this job to professionals for your safety. Consult your car audio dealer.



Installation/Connection

Connect external components



No Part

- | | |
|---|--|
| 1 | KDC-MP382BT : Learning steering remote control (Page 28) |
| 2 | KMR-D382BT : To KENWOOD Marine Remote Control unit, KCA-RC55MR (optional accessory) (Page 7) |
| 3 | Output terminals (See the following “Connect external amplifiers via output terminals”). |
| 4 | KMR-D382BT : Expansion port (12 V $\overline{\text{---}}$ 500 mA):
To the optional SiriusXM Vehicle Tuner (commercially available) (Page 12) |
| 5 | Microphone input jack (Page 17) |

Connect external amplifiers via output terminals

When connecting to an external amplifier to the output terminals of this unit, firmly connect the ground wire of the amplifier to the car's chassis to avoid damaging the unit.

Model	Output terminals		
KDC-BT370U KDC-BT282U		REAR/SW:	Rear/subwoofer output
KDC-MP382BT		FRONT:	Front output
		REAR/SW:	Rear/subwoofer output
KMR-D382BT		REAR:	Rear output
		FRONT:	Front output
		SW:	Subwoofer output

References


Maintenance

Cleaning the unit

Wipe off dirt on the faceplate with a dry silicone or soft cloth.

Cleaning the connector

Detach the faceplate and clean the connector gently with a cotton swab. Be careful not to damage the connector.



Connector (on the reverse side of the faceplate)

Handling discs

- Do not touch the recording surface of the disc.
- Do not stick tape etc. on the disc, or use a disc with tape stuck on it.
- Do not use any accessories for the disc.
- Clean from the center of the disc and move outward.
- Clean the disc with a dry silicone or soft cloth. Do not use any solvents.
- When removing a disc from this unit, pull it out horizontally.
- Remove burrs from the center hole and disc edge before inserting a disc.

More information

For: — Latest firmware updates and latest compatible item list
— KENWOOD original application
— Any other latest information

Visit <<https://www.kenwood.com/cs/ce/>>.

General

- This unit can only play the following CDs:



- For detailed information and notes about the playable audio files, visit <<https://www.kenwood.com/cs/ce/audiofile/>>.

Playable files

- Disc:
Playable audio file:
MP3 (.mp3), WMA (.wma), AAC (.aac)
Playable media: CD-R/ CD-RW/ CD-ROM
Playable file format: ISO 9660 Level 1/2, Joliet, Long file name
- USB mass storage class device:
Playable audio file:
MP3 (.mp3), WMA (.wma), AAC (.aac), AAC (.m4a), WAV (.wav), FLAC (.flac)
Playable file system: FAT12, FAT16, FAT32

Even when audio files comply with the standards listed above, playback may be impossible depending on the types or conditions of media or devices.
The AAC (.m4a) file in a CD encoded by iTunes cannot be played on this unit.

Unplayable discs

- Discs that are not round.
- Discs with coloring on the recording surface or discs that are dirty.
- Recordable/ReWritable discs that have not been finalized.
- 8 cm CD. Attempting to insert using an adapter may cause malfunction.

About USB devices

- You cannot connect a USB device via a USB hub.
- Connecting a cable whose total length is longer than 5 m may result in abnormal playback.
- This unit cannot recognize a USB device whose rating is other than 5 V and exceeds 1.5 A.

About iPod/iPhone

- Made for
 - iPod touch (6th generation)
 - iPhone 5S, 6, 6 Plus, 6S, 6S Plus, SE, 7, 7 Plus, 8, 8 Plus, X, XS, XS MAX, XR, 11, 11 Pro, 11 Pro MAX, SE (2nd generation), 12, 12 Mini, 12 Pro, 12 Pro MAX
- The song order displayed on the selection menu of this unit may differ from that of the iPod/iPhone.
- Depending on the version of the operating system of the iPod/iPhone, some functions may not operate on this unit.

References

About Program Type

For Radio Broadcast Data System:

[SPEECH]:

[NEWS], [INFORM] (information), [SPORTS], [TALK], [LANGUAGE], [REL TALK] (religious talk), [PERSONLTY] (personality), [PUBLIC], [COLLEGE], [HABL ESP] (spanish talk), [WEATHER]

[MUSIC]:

[ROCK], [CLS ROCK] (classic rock), [ADLT HIT] (adult hits), [SOFT RCK] (softrock), [TOP 40], [COUNTRY], [OLDIES], [SOFT], [NOSTALGA] (nostalgia), [JAZZ], [CLASSICL] (classical), [R & B] (rhythm and blues), [SOFT R&B] (soft rhythm and blues), [REL MUSC] (religious music), [MUSC ESP] (spanish music), [HIP HOP]

For Radio Data System:

[SPEECH]:

[NEWS], [AFFAIRS], [INFO] (information), [SPORT], [EDUCATE], [DRAMA], [CULTURE], [SCIENCE], [VARIED], [WEATHER], [FINANCE], [CHILDREN], [SOCIAL], [RELIGION], [PHONE IN], [TRAVEL], [LEISURE], [DOCUMENT]

[MUSIC]:

[POP M] (music), [ROCK M] (music), [EASY M] (music), [LIGHT M] (music), [CLASSICS], [OTHER M] (music), [JAZZ], [COUNTRY], [NATION M] (music), [OLDIES], [FOLK M] (music)


The unit will search for the Program Type categorized under [SPEECH] or [MUSIC] if selected.

Change the display information

(For **KDC-BT370U** / **KDC-BT282U** / **KDC-MP382BT**)

Each time you press DISP, the display information changes.

- If the information is unavailable or not recorded, "NO TEXT", "NO INFO", or other information (eg. station name) appears or display will be blank.



Source name	Display information: Main display
STANDBY	Source name/Clock ➡ Clock ➡ Turns off the display* ➡ back to the beginning
RADIO	Source name/Clock ➡ Frequency ➡ Clock ➡ Turns off the display* ➡ back to the beginning For FM Radio Broadcast Data System/FM Radio Data System stations only: Source name/Clock ➡ Station name/Program type ➡ Radio text ➡ Radio text+ ➡ Radio text+ song title/Radio text+ artist ➡ Frequency ➡ Clock ➡ Turns off the display* ➡ back to the beginning
CD or USB	For CD-DA: Source name/Clock ➡ Disc title/Artist ➡ Track title/Artist ➡ Playing time ➡ Clock ➡ Turns off the display* ➡ back to the beginning For MP3/WMA/AAC/WAV/FLAC files: Source name/Clock ➡ Song title/Artist ➡ Album title/Artist ➡ Folder name ➡ File name ➡ Playing time ➡ Clock ➡ Turns off the display* ➡ back to the beginning
iPod USB/iPod BT	Source name/Clock ➡ Song title/Artist ➡ Album title/Artist ➡ Playing time ➡ Clock ➡ Turns off the display* ➡ back to the beginning
BT AUDIO	Source name/Clock ➡ Song title/Artist ➡ Album title/Artist ➡ Playing time ➡ Clock ➡ Turns off the display* ➡ back to the beginning
AUX	Source name/Clock ➡ Clock ➡ Turns off the display* ➡ back to the beginning


* Only for **KDC-MP382BT**.

References

(For **KMR-D382BT**)

Each time you press DISP, the display information changes.

- If the information is unavailable or not recorded, "NO TEXT", "NO INFO", or other information (eg. station name) appears or display will be blank.



Source name	Display information: Main display
STANDBY	Source name ➔ Date ➔ back to the beginning
RADIO	Frequency ➔ Date ➔ back to the beginning For FM Radio Broadcast Data System stations only: Station name/Program type ➔ Radio text ➔ Radio text+ ➔ Radio text+ song title/Radio text+ artist ➔ Frequency ➔ Date ➔ back to the beginning
CD or USB	For CD-DA: Disc title/Artist ➔ Track title/Artist ➔ Playing time ➔ Date ➔ back to the beginning For MP3/WMA/AAC/WAV/FLAC files: Song title/Artist ➔ Album title/Artist ➔ Folder name ➔ File name ➔ Playing time ➔ Date ➔ back to the beginning
iPod USB/iPod BT	Song title/Artist ➔ Album title/Artist ➔ Playing time ➔ Date ➔ back to the beginning
SIRIUS XM	Channel number ➔ Channel name ➔ Artist ➔ Song title ➔ Content information ➔ Category name ➔ Date ➔ back to the beginning
BT AUDIO	Song title/Artist ➔ Album title/Artist ➔ Playing time ➔ Date ➔ back to the beginning
AUX	Source name ➔ Date ➔ back to the beginning

Troubleshooting

Symptom	Remedy
Sound cannot be heard.	- Adjust the volume to the optimum level. - Check the cords and connections.
"MISWIRING CHECK WIRING THEN PWR ON" appears.	Turn the power off, then check to be sure the terminals of the speaker wires are insulated properly. Turn the power on again.
"PROTECTING SEND SERVICE" appears.	Send the unit to the nearest service center.
Source cannot be selected.	Check the [SOURCE SELECT] setting. (Page 6)
- Sound cannot be heard. - The unit does not turn on. - Information shown on the display is incorrect.	Clean the connectors. (Page 33)
The unit does not work at all.	Reset the unit. (Page 4)
Correct characters are not displayed.	- This unit can only display uppercase letters, numbers, and a limited number of symbols. - Depending on the display language you have selected (page 7), some characters may not be displayed correctly.
(For KMR-D382BT) "SET ERROR"/"DEL ERROR"	Setting/deleting the remote control ID is unsuccessful. Turn the power off, then turn on the power and perform the operation again. (Page 7)
(For KDC-MP382BT) "ERROR"/"FAILED"	Your steering remote controller is not compatible, learning may not be completed. Consult your car audio dealer for details.
Radio	- Radio reception is poor. - Static noise while listening to the radio. Connect the antenna firmly.

Troubleshooting

Symptom	Remedy
Disc cannot be ejected.	Press and hold  to forcibly eject the disc. Be careful not to drop the disc when it is ejected. If this does not solve the problem, reset the unit (page 4).
Noise is generated.	Skip to another track or change the disc.
"PLEASE EJECT" appears.	Reset the unit (page 4). If this does not solve the problem, consult your nearest service center.
Playback order is not as intended.	Optical disc, the files are played in the order which they were recorded. USB device, the folders are played in the order of creation (date and time). The files within each folder are played in the order of the file name (alphabet).
Elapsed playing time is not correct.	This depends on the recording process earlier (disc/USB).
"READING" keeps flashing.	- Do not use too many hierarchical levels and folders. - Reload the disc or reattach the device (USB/iPod/iPhone).
"UNSUPPORTED DEVICE" appears.	- Check whether the connected USB device is compatible with this unit and ensure the file systems are in supported formats. (Page 33) - Reattach the USB device.
"UNRESPONSIVE DEVICE" appears.	Make sure the USB device is not malfunction and reattach the USB device.
"USB HUB IS NOT SUPPORTED" appears.	This unit cannot support a USB device connected via a USB hub.

CD/USB/iPod

Symptom	Remedy
- The source does not change to "USB" when you connect a USB device while listening to another source. "USB ERROR" appears.	The USB port is drawing more power than the design limit. Turn the power off and unplug the USB device. Then, turn on the power and reattach the USB device. If this does not solve the problem, turn the power off and on (or reset the unit) before replacing with another USB device.
The iPod/iPhone does not turn on or does not work.	- Check the connection between this unit and iPod/iPhone. - Disconnect and reset the iPod/iPhone using hard reset.
"LOADING" appears when you enter search mode by pressing  .	This unit is still preparing the iPod/iPhone music list. It may take some time to load, try again later.
"NO DISC"	Insert a playable disc into the loading slot.
"TOC ERROR"	Make sure the disc is clean and inserted properly.
"NA FILE"	Make sure the media (disc/USB) contain supported audio files. (Page 33)
"COPY PRO"	A copy-protected file is played (disc/USB).
"NO DEVICE"	Connect a device (USB/iPod/iPhone), and change the source to USB/iPod USB again.
"NO MUSIC"	Connect a device (USB/iPod/iPhone) that contains playable audio files.
"iPod ERROR"	- Reconnect the iPod. - Reset the iPod.
"MEMORY FULL"	You have reached the maximum storage limit of your iPod/iPhone.
"CH LOCKED LOCK CODE?"	The selected channel is locked. Enter the correct pass code to unlock. (Page 14)
"CHAN UNSUB"	The selected channel is unsubscribed. Call 1-866-635-2349 in the U.S.A. or 1-888-539-7474 in Canada to subscribe. (Page 12)

CD/USB/iPod

SiriusXM® Radio

Troubleshooting

Symptom	Remedy
SiriusXM® Radio	"CH UNAVAILABLE" The selected channel is unavailable. For more information about the SiriusXM channel lineup, visit <www.siriusxm.com>.
	"CHECK ANTENNA" Check that the antenna and its connection are in good condition.
	"CHECK TUNER" Make sure the SiriusXM Vehicle Tuner is connected to the unit.
	"NO SIGNAL" Make sure the antenna is mounted outside the vehicle.
	"SUBSCRIPTION UPDATED — PRESS ENTER TO CONTINUE." Your subscription is updated. Press the volume knob to continue.
	"CODE ERROR" Make sure you have entered the correct pass code. (Page 14)
	"NO CONTENT" There is insufficient content to start TuneScan.
	"SCAN CANCEL" TuneScan has been aborted.
Bluetooth®	No Bluetooth device is detected. • Search from the Bluetooth device again. • Reset the unit. (Page 4)
	Bluetooth pairing cannot be made. • Make sure you have entered the same PIN code to both the unit and Bluetooth device. • Delete pairing information from both the unit and the Bluetooth device, then perform pairing again. (Page 17)
	Echo or noise is heard during a phone conversation. • Adjust the microphone unit's position. (Page 17) • Check the [ECHO CANCEL] setting. (Page 19)
	Phone sound quality is poor. • Reduce the distance between the unit and the Bluetooth device. • Move the car to a place where you can get a better signal reception.

Symptom	Remedy
Bluetooth®	Voice calling method is not successful. • Use voice calling method in a more quiet environment. • Reduce the distance from the microphone when you speak the name. • Make sure the same voice as the registered voice tag is used.
	Sound is being interrupted or skipped during playback of a Bluetooth audio player. • Reduce the distance between the unit and the Bluetooth audio player. • Turn off, then turn on the unit and try to connect again. • Other Bluetooth devices might be trying to connect to the unit.
	The connected Bluetooth audio player cannot be controlled. • Check whether the connected Bluetooth audio player supports Audio/Video Remote Control Profile (AVRCP). (Refer to the instructions of your audio player.) • Disconnect and connect the Bluetooth player again.
	"NOT SUPPORT" The connected phone does not support Voice Recognition feature or phonebook transfer.
	"NO ENTRY" There is no registered device connected/found via Bluetooth.
	"ERROR" Try the operation again. If "ERROR" appears again, check if the device supports the function you have tried.
	"NO INFO"/"NO DATA" Bluetooth device cannot get the contact information.
	"HF ERROR XX"/ "BT ERROR" Reset the unit and try the operation again. If this does not solve the problem, consult your nearest service center.
	"SWITCHING NG" The connected phones might not support phone switching feature.
	The Bluetooth connection between the Bluetooth device and the unit is unstable. Delete the unused registered Bluetooth device from the unit. (Page 21)

Specifications

Tuner	FM	Frequency Range	KDC-BT370U / KDC-BT282U / KMR-D382BT : 87.9 MHz — 107.9 MHz (200 kHz step) KDC-MP382BT : 87.5 MHz — 108.0 MHz (50 kHz step)
		Usable Sensitivity (S/N = 30 dB)	8.2 dBf (0.71 μ V/75 Ω)
		Quieting Sensitivity (DIN S/N = 46 dB)	17.2 dBf (2.0 μ V/75 Ω)
		Frequency Response (± 3 dB)	30 Hz — 15 kHz
		Signal-to-Noise Ratio (MONO)	64 dB
		Stereo Separation (1 kHz)	40 dB
	AM	Frequency Range	530 kHz — 1 700 kHz (10 kHz step)
		Usable Sensitivity (S/N = 20 dB)	29 dB μ (28.2 μ V)
CD player	Laser Diode		GaAlAs
	Digital Filter (D/A)		8 times over sampling
	Spindle Speed		500 rpm — 200 rpm (CLV)
	Wow & Flutter		Below measurable limit
	Frequency Response (± 1 dB)		20 Hz — 20 kHz
	Total Harmonic Distortion (1 kHz)		0.02 %
	Signal-to-Noise Ratio (1 kHz)		94 dB
	Dynamic Range		91 dB

CD player	Channel Separation	86 dB
	MP3 Decode	Compliant with MPEG-1/2 Audio Layer-3
	WMA Decode	Compliant with Windows Media Audio
	AAC Decode	AAC-LC “.aac” files
USB	USB Standard	USB 1.1, USB 2.0 (High speed)
	File System	FAT12/16/32
	Maximum Supply Current	DC 5 V  1.5 A
	Frequency Response (± 1 dB)	20 Hz — 20 kHz
	Signal-to-Noise Ratio (1 kHz)	98 dB
	Dynamic Range	94 dB
	Channel Separation	91 dB
	MP3 Decode	Compliant with MPEG-1/2 Audio Layer-3
Auxiliary	WMA Decode	Compliant with Windows Media Audio
	AAC Decode	AAC-LC “.aac”, “.m4a” files
	WAV Decode	Linear-PCM
	FLAC Decode	FLAC file (Up to 96 kHz/24 bit)
	Frequency Response (± 3 dB)	20 Hz — 20 kHz
	Input Maximum Voltage	1 000 mV
	Input Impedance	30 k Ω

Specifications

Bluetooth	Version	Bluetooth 4.2
	Frequency Range	2.402 GHz — 2.480 GHz
	RF Output Power (E.I.R.P.)	+4 dBm (MAX), Power Class 2
	Maximum Communication Range	Line of sight approx. 10 m (32.8 ft)
	Profile	HFP 1.7.1 (Hands-Free Profile) A2DP (Advanced Audio Distribution Profile) AVRCP 1.6.1 (Audio/Video Remote Control Profile) PBAP (Phonebook Access Profile) SPP (Serial Port Profile)
Audio	Maximum Output Power	50 W × 4
	Full Bandwidth Power (at less than 1 % THD)	22 W × 4
	Speaker Impedance	4 Ω — 8 Ω
	Tone Action	Band 1: 62.5 Hz ±9 dB
		Band 2: 100 Hz ±9 dB
		Band 3: 160 Hz ±9 dB
		Band 4: 250 Hz ±9 dB
		Band 5: 400 Hz ±9 dB
		Band 6: 630 Hz ±9 dB
		Band 7: 1 kHz ±9 dB
		Band 8: 1.6 kHz ±9 dB
		Band 9: 2.5 kHz ±9 dB
		Band 10: 4 kHz ±9 dB
		Band 11: 6.3 kHz ±9 dB
		Band 12: 10 kHz ±9 dB
		Band 13: 16 kHz ±9 dB

Audio	Preout Level/Load	KDC-BT370U / KDC-BT282U / KDC-MP382BT : 2 500 mV/10 kΩ KMR-D382BT : 4 000 mV/10 kΩ
	Preout Impedance	≤ 600 Ω
General	Operating Voltage	12 V DC car battery
	Installation Size (W × H × D)	182 mm × 53 mm × 155.5 mm (7-3/16" × 2-1/16" × 6-1/8")
	Net Weight (includes Trimplate, Mounting Sleeve)	1.2 kg (2.7 lbs)

Subject to change without notice.

- Windows Media is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.
- Apple, iPhone, iPod, iPod touch, iTunes, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- Android is a trademark of Google LLC.
- SiriusXM and all related marks and logos are trademarks of Sirius XM Radio, Inc. All rights reserved.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JVCKENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.

Made for



iPhone | iPod



KDC-BT370U KDC-BT282U KDC-MP382BT

KMR-D382BT

CD-RECEIVER

Quick Start Guide

AUTORADIO CD

Guide de démarrage rapide

RECEPTOR CD

Guía de inicio rápido

JVCENWOOD Corporation

For your records

Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your Kenwood dealer for information or service on the product.

Model KDC-BT370U/KDC-BT282U/KDC-MP382BT/KMR-D382BT

Serial number _____

US Residents Only

Register Online

Register your Kenwood product at <https://www.kenwood.com/usa/>

For detailed operations and information, refer to the INSTRUCTION MANUAL on the following website:
Pour les opérations et les informations détaillées, reportez-vous au MODE D'EMPLOI sur le site web suivant:
Para obtener más información y detalles sobre las operaciones, consulte el MANUAL DE INSTRUCCIONES en el siguiente sitio web:



[<https://www.kenwood.com/cs/ce/>](https://www.kenwood.com/cs/ce/)

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
In compliance with Federal Regulations, following are reproductions of labels on, or inside the product relating to laser product safety.

JVCKENWOOD Corporation
2967-3, ISHIKAWA-MACHI,
HACHIOJI-SHI, TOKYO, JAPAN

THIS PRODUCT COMPLIES WITH DHHS RULES 21CFR
SUBCHAPTER J IN EFFECT AT DATE OF MANUFACTURE.

Location : Top Plate

Información acerca de la eliminación de equipos eléctricos y electrónicos al final de la vida útil (aplicable a los países que hayan adoptado sistemas independientes de recogida de residuos)



Los productos con el símbolo de un contenedor con ruedas tachado no podrán ser desechados como residuos domésticos. Los equipos eléctricos y electrónicos al final de la vida útil, deberán ser reciclados en instalaciones que puedan dar el tratamiento adecuado a estos productos y a sus subproductos residuales correspondientes. Póngase en contacto con su administración local para obtener información sobre el punto de recogida más cercano. Un tratamiento correcto del reciclaje y la eliminación de residuos ayuda a conservar los recursos y evita al mismo tiempo efectos perjudiciales en la salud y el medio ambiente.

Informação sobre a eliminação de pilhas

Este produto não deve ser eliminado como lixo doméstico geral. Devolva a pilha usada ao revendedor ou entidade autorizada para que a mesma seja devolvida ao fabricante ou importador. A reciclagem e a eliminação de lixo de maneira apropriada ajudarão a conservar os recursos naturais ao mesmo tempo que prevenirão os efeitos prejudiciais à nossa saúde e ao meio ambiente.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

Trade Name: KENWOOD
Products: CD-RECEIVER
Model Name: KDC-BT370U/KDC-BT282U/KDC-MP382BT/KMR-D382BT
Responsible Party: JVCKENWOOD USA CORPORATION
2201 East Dominguez Street, Long Beach, CA 90810, U.S.A.
PHONE: 310 639-9000

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

ISED Caution

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Attention de l'ISED

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage.
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Contains Bluetooth Module FCC ID: ZWY88112
IC ID: 12033A-88112

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

CAUTION

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

ATTENTION

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles des radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISED. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

Para cumplimiento de la IFT:

"La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada"

SOFTWARE LICENSE AGREEMENT

The software embedded in the Product (hereinafter the "Licensed Software") provided by Licensor is copyrighted to or sublicensable by the Licensor, and this Agreement provides for the terms and conditions which Users shall follow in order to use the Licensed Software.

The User shall use the Licensed Software by agreeing with the terms of this Software License Agreement. This Agreement shall be deemed completed at the time the User (hereinafter the "User") initially used the Product in which the "Licensed Software" is embedded.

The Licensed Software may include the software which has been licensed to the Licensor directly or indirectly from any third party. In such case, some third parties require the Users to follow their conditions for use separately from this Software License Agreement. Such software shall not be subject to this Agreement, and the Users are urged to read the "Important Notice concerning the Software" to be provided separately below.

Article 1 General Provision

The Licensor shall grant to the User a non-exclusive and non-transferable (other than the exceptional case referred to in Article 3, Paragraph 1) licensed to use the Licensed Software within the country of the User. (the country where the User bought the Product (hereinafter the "Country"))

Article 2 License

1. The license granted under this Agreement shall be the right to use the Licensed Software in the Product.
2. The User shall not duplicate, copy, modify, add, translate or otherwise alter, or lease the Licensed Software and any related documents, whether in whole or in part.
3. The use of the Licensed Software shall be limited to personal purpose, and the Licensed Software shall not be distributed, licensed or sub-licensed whether it is for commercial purpose or not.
4. The User shall use the Licensed Software according to the directions described in the operation manual or help file, and is prohibited to use or duplicate any data in a manner violating the Copyright Law or any other laws and regulations by applying whole or a part of the Licensed Software.

Article 3 Conditions for Grant of License

1. When the User transfers the Product, it may also transfer the license to use the Licensed Software embedded in the Product (including any related materials, updates and upgrades) on condition that no original, copies or related materials continue in the possession of the User, and that the User shall cause the transferee to comply with this Software License Agreement.
2. The User shall not carry out reverse engineering, disassembling, decompiling or any other code analysis works in connection with the Licensed Software.

Article 4 Right pertaining to the Licensed Software

Any and all copyrights and other rights pertaining to the Licensed Software and related documents shall belong to the Licensor or the original holder of the right who granted to the Licensor the license or sublicense for the Licensed Software (hereinafter the "Original Rightholder"), and the User shall not be entitled to any right other than the license granted hereunder, in respect of the Licensed Software and any related documents.

Article 5 Indemnification of Licensor

1. Neither the Licensor nor the Original Rightholder shall be liable for any damage incurred by the User or any third party due to the exercise of the license granted to the User under this Agreement, unless otherwise restricted by law.
2. The Licensor will offer no guarantee for the merchantability, convertibility and consistency with certain objective of the Licensed Software.

Article 6 Liability to Third Party

If any dispute has arisen with any third party due to an infringement upon a copyright, patent or any other intellectual property right that was caused by the User's use of the Licensed Software, the User shall settle such dispute at its own cost and hold the Licensor and the Original Rightholder harmless from any inconvenience it may cause.

Article 7 Confidentiality

The User shall keep the confidentiality of such portion of the Licensed Software, related documents thereof or any other information to be granted under this Agreement, as well as the conditions of this Agreement as has not yet entered the public domain, and shall not disclose or divulge the same to any third party without approval of the Licensor.

Article 8 Termination

In case the User falls under any of the events described in the following items, the Licensor may immediately terminate this Agreement or claim that the User compensates for the damage incurred by the Licensor due to such event:

- (1) when the User violated any provision of this Agreement; or
- (2) when a petition has been filed against the User for an attachment, provisional attachment, provisional disposition or any other compulsory execution.

Article 9 Destruction of the Licensed Software

If this Agreement is terminated pursuant to the provision of Article 8, the User shall destroy the Licensed Software, any related documents and copies thereof within two (2) weeks from such date of termination.

Article 10 Protection of Copyright

1. The copyright and all the other intellectual property rights relating to the Licensed Software shall belong to the Licensor and the Original Rightholder, and in no event shall they be under the ownership of the User.
2. The User shall, whenever it uses the Licensed Software, comply with any laws relating to the copyright and other intellectual property rights.

Article 11 Export Restriction

1. It is prohibited to export the Licensed Software and any related documents outside the country of the User (including transmission thereof outside the country of the User via Internet of other communication tools).
2. The User shall understand that the Licensed Software shall be subject to the export restrictions adopted by the country of User and any other countries.
3. The User shall agree that the software will be subject to any and all applicable international and domestic laws (including the export control regulation of the country of User and any other countries, and any restrictions concerning the end-users, the use by end-users and importing countries to be provided by the country of User and any other countries, and any other governmental authorities).

Article 12 Miscellaneous

1. In the event any part of this Agreement is invalidated by operation of law, the residual provisions shall continue in force.
2. Matters not stipulated in this Agreement or any ambiguity or question raised in the construction of this Agreement shall be provided or settled upon good-faith consultation between the Licensor and the User.
3. The Licensor and the User hereby agree that this Agreement is governed by the laws of Japan, and any dispute arising from, and relating to the rights and obligations under, this Agreement shall be submitted to the exclusive jurisdiction of the Tokyo District Court for its first instance.

Important Notice concerning the Software

-jansson

Copyright (c) 2009-2012 Petri Lehtinen <petri@digip.org>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

-cJSON

Copyright (c) 2009 Dave Gamble

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

-CMP

The MIT License (MIT)

Copyright (c) 2014 Charles Gunyon

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

nanopb

Copyright (c) 2011 Petteri Aimonen <jpa at nanopb.mail.kapsi.fi>

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
 2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
 3. This notice may not be removed or altered from any source distribution.
-

sha2

AUTHOR: Aaron D. Gifford - <http://www.aarongifford.com/>

Copyright (c) 2000-2001, Aaron D. Gifford

All rights reserved.

You may obtain a copy of the license at

<https://opensource.org/licenses/BSD-3-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Posix

Copyright (c) 1990, 1993

The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:
This product includes software developed by the University of California, Berkeley and its contributors.
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.

Developed at SunPro, a Sun Microsystems, Inc. business.

Permission to use, copy, modify, and distribute this software is freely granted, provided that this notice is preserved.

Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

Copyright (c) 1995, 1996 Carnegie-Mellon University. All rights reserved.

Author: Chris G. Demetriou

Permission to use, copy, modify and distribute this software and its documentation is hereby granted, provided that both the copyright notice and this permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS "AS IS" CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Carnegie Mellon requests users of this software to return to

Software Distribution Coordinator or Software.Distribution@CS.CMU.EDU

School of Computer Science

Carnegie Mellon University

Pittsburgh PA 15213-3890

any improvements or extensions that they make and grant Carnegie the rights to redistribute these changes.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

Copyright (c) 1993 Martin Birgmeier

All rights reserved.

You may redistribute unmodified or modified versions of this source code provided that the above copyright notice and this and the following conditions are retained.

This software is provided "as is", and comes with no warranties of any kind. I shall in no event be liable for anything that happens to anyone/anything when using this software.

These notices must be retained in any copies of any part of this documentation and/or software.

T-Kernel 2.0

This product uses the source code of T-Kernel 2.0 under T-License 2.0 granted by T-Engine Forum (www.tron.org)

BSD-3-Clause

Copyright (c) 2000-2001, Aaron D. Gifford

All rights reserved.

You may obtain a copy of the license at

<https://opensource.org/licenses/BSD-3-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

LFS Subsystem

Copyright The Regents of the University of California. All rights reserved.

You may obtain a copy of the license at

<https://directory.fsf.org/wiki/License:BSD-4-Clause>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Accordo2 Player

Apache License

Licensed under the Apache License,

Version 2.0, January 2004(the "License");

You may obtain a copy of the license at

<http://www.apache.org/licenses/LICENSE-2.0>

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Installation/Connection

This section is for the professional installer.

For safety's sake, leave wiring and mounting to professionals. Consult the car audio dealer.

▲ WARNING

- The unit can only be used with a 12 V DC power supply, negative ground.
- Disconnect the battery's negative terminal before wiring and mounting.
- Do not connect Battery wire (yellow) and Ignition wire (red) to the car chassis or Ground wire (black) to prevent a short circuit.
- To prevent short circuit:
 - Insulate unconnected wires with vinyl tape.
 - Be sure to ground this unit to the car's chassis again after installation.
 - Secure the wires with cable clamps and wrap vinyl tape around the wires that comes into contact with metal parts to protect the wires.


▲ CAUTION

- Install this unit in the console of your vehicle. Do not touch the metal parts of this unit during and shortly after use of the unit. Metal parts such as the heat sink and enclosure become hot.
- Do not connect the $\ominus$ wires of speakers to the car chassis or Ground wire (black), or connect them in parallel.
- Mount the unit at an angle of less than 30°.
- If your vehicle wiring harness does not have the ignition terminal, connect Ignition wire (red) to the terminal on the vehicle's fuse box which provides 12 V DC power supply and is turned on and off by the ignition key.
- Keep all cables away from heat dissipate metal parts.
- After the unit is installed, check whether the brake lamps, blinkers, wipers, etc. on the car are working properly.
- If the fuse blows, first make sure the wires are not touching car's chassis, then replace the old fuse with one that has the same rating.

■ Basic procedure


- 1 Remove the key from the ignition switch, then disconnect the $\ominus$ terminal of the car battery.
- 2 Connect the wires properly. See "Wiring connection" on page 3.
- 3 Install the unit to your car. See the following "Installing the unit (in-dash mounting)".
- 4 Connect the $\ominus$ terminal of the car battery.
- 5 Press $\odot$ SRC to turn on the power.
- 6 Detach the faceplate and reset the unit within 5 seconds. See "How to reset" on page 4.

Installing the unit (in-dash mounting)




Installing the unit (without mounting sleeve)

- 1 Remove the mounting sleeve and trim plate from the unit.
- 2 Align the holes in the unit (on both sides) with the vehicle mounting bracket and secure the unit with screws (supplied/ commercially available).



▲ Use only the specified screws.
Using wrong screws might damage the unit.


Removing the unit



Part list (supplied)

- | | |
|--------------------------|--|
| (A) Faceplate (x1) | (F) Screw (supplied for
KDC-MP382BT / KMR-D382BT) |
| (B) Trimplate (x1) | ⌚ M5 x 7 mm (x4) |
| (C) Mounting sleeve (x1) | ⌚ M5 x 6 mm (x4) |
| (D) Wiring harness (x1) | ⌚ M4 x 8 mm (x1) |
| (E) Extraction key (x2) | |

Wiring connection



- | | |
|---|--|
| a Brown: Connect to the device equipped with muting feature to mute this unit | d Red: Ignition 12 V |
| b Blue/white: To the power control terminal when using the optional power amplifier or to the antenna control terminal in the vehicle | e Yellow: Battery 12 V |
| c Light blue/yellow: To the steering wheel remote control adapter or to KENWOOD Marine Remote Control unit (optional accessory) for KMR-D382BT | f Black: Ground |
| | g White ⊕, White/black ⊖: Front speaker (left) |
| | h Gray ⊕, Gray/black ⊖: Front speaker (right) |
| | i Green ⊕, Green/black ⊖: Rear speaker (left) |
| | j Purple ⊕, Purple/black ⊖: Rear speaker (right) |

Before Use

IMPORTANT

- To ensure proper use, please read through this Guide before using this product. It is especially important that you read and observe Warnings and Cautions in this Guide.
- Please keep the Guide in a safe and accessible place for future reference.

▲ WARNING

Do not operate any function that takes your attention away from safe driving.

▲ CAUTION

Volume setting:


- Adjust the volume so that you can hear sounds outside the car to prevent accidents.
- Lower the volume before playing digital sources to avoid damaging the speakers by the sudden increase of the output level.

General:


- Avoid using the external device if it might hinder safe driving.
- Make sure all important data has been backed up. We shall bear no responsibility for any loss of recorded data.
- Never put or leave any metallic objects (such as coins or metal tools) inside the unit to prevent a short circuit.
- If a disc error occurs due to condensation on the laser lens, eject the disc and wait for the moisture to evaporate.
- USB rating is indicated on the main unit. To view, detach the faceplate.
- Depending on the types of cars, the antenna will automatically extend when you turn on the unit with the antenna control wire connected. Turn off the unit or change the source to STANDBY when parking at a low ceiling area.

Basics

Faceplate



* Only for illustration purpose.

Attach	Detach	How to reset
		
Reset the unit within 5 seconds after detaching the faceplate.		
To		
Turn on the power	On the faceplate	
Adjust the volume	Press SRC .	
Select a source	• Press and hold to turn off the power.	
Change the display information	Turn the volume knob.	
	Press SRC repeatedly.	
	Press DISP repeatedly.	

Getting Started

1 Select the display language and cancel the demonstration

When you turn on the power for the first time (or [FACTORY RESET] is set to [YES]), the display shows: "SEL LANGUAGE" → "PRESS" → "VOLUME KNOB"

- 1 Turn the volume knob to select [ENG] (English) / [SPA] (Spanish) / [FRE] (French), then press the knob.
[ENG] is selected for the initial setup.
Then, (except for [KMR-D382BT]) the display shows: "CANCEL DEMO" → "PRESS" → "VOLUME KNOB".
- 2 Press the volume knob again.
[YES] is selected for the initial setup.
- 3 Press the volume knob again.
"DEMO OFF" appears.

2 Set the clock and date

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select [CLOCK], then press the knob.

To adjust the clock

- 3 Turn the volume knob to select [CLOCK ADJUST], then press the knob.
- 4 Turn the volume knob to make the settings, then press the knob.
Set the time in the order of "Hour" → "Minute".
- 5 Turn the volume knob to select [CLOCK FORMAT], then press the knob.
- 6 Turn the volume knob to select [12H] or [24H], then press the knob.

To set the date

- 7 Turn the volume knob to select [DATE FORMAT], then press the knob.
- 8 Turn the volume knob to select [DD/MM/YY] or [MM/DD/YY], then press the knob.
- 9 Turn the volume knob to select [DATE SET], then press the knob.

- 10 Turn the volume knob to make the settings, then press the knob.
Set the date in the order of "Day" → "Month" → "Year" or "Month" → "Day" → "Year".
- 11 Press and hold Q/↵ to exit.

To return to the previous setting item, press Q/↵.

3 Set the other optional settings

You can only set the following items while the unit is in STANDBY source.

- 1 Press ⏻SRC repeatedly to enter STANDBY.
- 2 Press the volume knob to enter [FUNCTION].
- 3 Turn the volume knob to select an item (see the following table), then press the knob.
- 4 Repeat step 3 until the desired item is selected or activated.
- 5 Press and hold Q/↵ to exit.

To return to the previous setting item, press Q/↵.

Default: [XX]

[SYSTEM]	
[KEY BEEP]	[ON]: Activates the keypress tone. ; [OFF]: Deactivates.
[FACTORY RESET]	[YES]: Resets the settings to default (except the stored station). ; [NO]: Cancels.
[ENGLISH]	Select the display language for [FUNCTION] menu and music information if applicable. By default, [ENGLISH] is selected.
[ESPAÑOL]	
[FRANCAIS]	

Radio

■ Search for a station

- 1 Press  SRC repeatedly to select RADIO.
- 2 Press BAND repeatedly to select FM1/FM2/FM3/AM.
- 3 Press   to search for a station.

■ Settings in memory

You can store up to 18 stations for FM and 6 stations for AM.

Store a station

While listening to a station....

Press and hold one of the number buttons (1 to 6).

Select a stored station

Press one of the number buttons (1 to 6).

CD/USB/iPod

Selectable sources:

CD/USB/iPod USB or iPod BT

■ Start playback

The source changes automatically and playback starts when you load a disc or attach a device (USB device/ iPod/iPhone) to the USB input terminal.

To	On the faceplate
Play back/pause	Press 6  .
Reverse/Fast-forward	Press and hold   .
Select a track/file	Press   .
Select a folder	Press 2  / 1  .
Repeat play	Press 4  repeatedly.
Random play	Press 3  repeatedly.

Functions Settings

- 1 Press the volume knob to enter [FUNCTION].
- 2 Turn the volume knob to select an item, then press the knob.
- 3 Repeat step 2 until the desired item is selected or activated.
- 4 Press and hold **Q/↵** to exit.

To return to the previous setting item, press **Q/↵**.

- Refer to the INSTRUCTION MANUAL on the following website for the detailed explanation of each item: <<https://www.kenwood.com/cs/ce/>>
- The availability of each item vary depending on the model.

[FUNCTION] menu items

- [AUDIO CONTROL] : Sets your preferred audio settings.
[DISPLAY] : Sets your preferred control for the display window.
[TUNER SETTING] : Settings for radio source.
[SIRIUS XM] : Settings for Sirius XM tuner.
[USB] : Settings for using a USB device.
[BT MODE] : Settings for using a Bluetooth device.
[REMOTE APP] : Settings for using smartphone to control this unit.
[MIC GAIN]* : Sets the sensitivity of the microphone.
[NR LEVEL]* : Adjusts the noise reduction level.
[ECHO CANCEL]* : Adjusts the echo cancellation delay time.
[SYSTEM] : Settings for this unit.
[CLOCK] : Adjusts the clock.
[ENGLISH] : Selects language for the menu and music information.
[ESPAÑOL] : Selects language for the menu and music information.
[FRANCAIS] : Selects language for the menu and music information.
[DEMO MODE] : Activates or deactivates the display demonstration.

* Applicable only while talking on the phone.

Examples of some well-used settings

■ Subwoofer Level Setting


- 1 Press the volume knob to enter [FUNCTION].
 FUNCTION
- 2 Turn the volume knob to select [AUDIO CONTROL], then press the knob.
 AUDIO CONTROL → 
- 3 Turn the volume knob to select [SUBWOOFER SET], then press the knob.
 SUBWOOFER SET → 
- 4 Turn the volume knob to select [SW SET ON], then press the knob.
 SW SET ON → 
- 5 Turn the volume knob to select [SUB-W LEVEL], then press the knob.
 SUB-W LEVEL → 
- 6 Turn the volume knob to adjust the subwoofer level, then press the knob.
 SW LEVEL +7 → 
- 7 Press and hold **Q/↵** to exit.


Note:

For **KDC-BT370U** / **KDC-BT282U** / **KDC-MP382BT**, you need to set [SWITCH PREOUT] to [SUB-W] in standby mode before you can make the above settings.

Illumination Color Setting


For **KMR-D382BT**, you can set your preferred illumination color for each zone.




- 1 Press the volume knob to enter [FUNCTION].



- 2 Turn the volume knob to select [DISPLAY], then press the knob.



- 3 Turn the volume knob to select [COLOR SELECT], then press the knob.



- 4 Turn the volume knob to select a zone ([ALL ZONE], [ZONE 1], [ZONE 2]), then press the knob.



- 5 Turn the volume knob to select a color for the selected zone, then press the knob.



- 6 Repeat step 4 and step 5 to set color for other zones.

- 7 Press and hold **Q/⏮** to exit.



Other Information

For playback operations of **AUX** and **SiriusXM® Radio** sources, refer to the INSTRUCTION MANUAL on the following website:

<https://www.kenwood.com/cs/ce/>

- The availability of each source vary depending on the model.

Note for specifications

Bluetooth Frequency Range:

2.402 GHz — 2.480 GHz

Bluetooth RF Output Power (E.I.R.P.):

+4 dBm (MAX), Power Class 2

Speaker Impedance:

4 Ω — 8 Ω

Operating Voltage:

12 V DC car battery

Bluetooth®

- Depending on the Bluetooth version, operating system and the firmware version of your mobile phone, Bluetooth features may not work with this unit.
- Be sure to turn on the Bluetooth function of the device to make the following operations.
- Signal conditions vary depending on the surroundings.

Connect the microphone

Connect the supplied microphone to the microphone input jack on the rear panel.



Pair and connect a Bluetooth device for the first time

- Press **⏻** SRC to turn on the unit.
- Search and select the name of your receiver ("KDC-BT370U"/"KDC-BT282U"/"KDC-MP382BT"/"KMR-D382BT") on the Bluetooth device.
"PAIRING" → "PASS XXXXXX" → "Device name" → "PRESS" → "VOLUME KNOB" appears on the display.
 - For some Bluetooth devices, you may need to enter the Personal Identification Number (PIN) code immediately after searching.
- Press the volume knob to start pairing.
"PAIRING OK" appears when pairing is completed.

Once pairing is completed, Bluetooth connection is established automatically.

- KDC-BT370U** / **KDC-BT282U** / **KDC-MP382BT**: "BT1" and/or "BT2" indicator on the display window lights up.
- KMR-D382BT**: "BT1 CONNECTED" and/or "BT2 CONNECTED" appears on the display window for 2 seconds.
"🔋" indicator lights up to show the strength of the battery and signal of the connected device.

Answer a call

Press **📞** or the volume knob or one of the number buttons (1 to 6).

- To adjust the phone volume [00] to [35], turn the volume knob.
- To end a call, press **📞**.

Audio player via Bluetooth

- Press **⏻** SRC repeatedly to select BT AUDIO.
 - Pressing **📶** enters BT AUDIO directly.
- Operate the audio player via Bluetooth to start playback.

To	On the faceplate
Play back/pause	Press 6 ▶ .
Select group or folder	Press 2 ^ / 1 ∇ .
Reverse skip/Forward skip	Press ◀◀ / ▶▶ .
Reverse/Fast-forward	Press and hold ◀◀ / ▶▶ .
Repeat play	Press 4 ↺ repeatedly.
Random play	Press and hold 3 ∞ to select [ALL RANDOM] or [GROUP RANDOM].

- Windows Media is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.
- Apple, iPhone, iPod, iPod touch, iTunes, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- Android is a trademark of Google LLC.
- SiriusXM and all related marks and logos are trademarks of Sirius XM Radio, Inc. All rights reserved.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JVCKENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.

Made for



iPhone | iPod



MILITARY

Units purchased through the U.S.A. military exchange service overseas may be serviced under warranty in the continental U.S.A., subject to the following conditions:

- 1) The original warranty is in effect.
- 2) Proof of purchase is provided to the service.

WARRANTY FOR MILITARY MARKET

JVC KENWOOD Corporation is proud of the quality and outstanding performance of its products. The products are designed, tested and inspected before being shipped to you. If properly installed and operated in accordance with instructions furnished, it should give you optimum reliable performance.

WARRANTY PERIOD

Our product is warranted for a period of (1) year from the date of the original purchase.

SCOPE OF WARRANTY

Except as specified below, this warranty covers all defects in materials and workmanship of the Kenwood brand products.

During the warranty period, any authorized Kenwood Service Center in the military market listed in the back of this warranty card will provide you free-of-charge both parts and labor required to correct any defect in materials or workmanship.

The following are not covered by this warranty:

1. Voltage conversion.
2. Products checked upon which do not discover any defect covered by the warranty.
3. Cabinets, grilles, other exterior finishes, belts, tape heads, and other non-wearable parts and accessories.
4. Units which have been subjected to tampering, modification or removal.
5. Installation, repair, removal charges.
6. Damaged magnetic tapes.
7. House call charges for any repairs.
8. Shipping or delivery charges in or from an authorized Kenwood Service Center.
9. This warranty will not cover any behavior that is contrary to the following conditions in accordance with the visual inspection of the authorized Kenwood Service Center:

* Unproper maintenance or repair, including the installation of parts or accessories that do not conform to the quality and specifications of the original parts.

* Misuse, abuse, neglect, unauthorized product modification or failure to follow instructions contained in the Owner's Manual.

* Accidents or intentional damage.

* Repairs or attempted repairs by an unauthorized agency (All repairs must be performed at an authorized Kenwood Service Center.)

* Damage or deterioration caused during shipment (Claims must be presented to the carrier).

* Damage or deterioration resulting from removal and reinstallation.

PURCHASER'S RESPONSIBILITIES

As the purchaser of a new Kenwood brand product, you are expected to do the following in order to obtain Kenwood warranty service:

1. Retain your sales slip or other evidence of purchase for proving your eligibility for requesting Kenwood warranty service.
2. Make your unit available to an authorized Kenwood Service Center in the military market for inspection and approved warranty service, or ship your unit in its original carton box or equivalent, fully insured and shipping charges prepaid, to the authorized Kenwood Service Center.

LIMITATION OF IMPLIED WARRANTIES

Any and all implied warranties, including warranties of merchantability and fitness for a particular service, shall be limited to duration to the length of the warranty.

EXCLUSION OF CERTAIN DAMAGES

KENWOOD's liability for any defective product is limited to the repair or replacement of said product, at our option, and shall not include damages of any kind, whether incidental, consequential or otherwise, except to the extent provided by applicable law.

KENWOOD AUTHORIZED SERVICE CENTERS IN MILITARY MARKET

JAPAN:

Yokota
Kenwood Rep.; c/o
Yokota BX, JAAAX AAFES-PAC,
APO San Francisco 96328

Zama

Kenwood Rep.; c/o
Zama PX, JAAAX AAFES-PAC,
APO San Francisco 96342

Misawa

Kenwood Rep.; c/o
Misawa BX, JAAAX AAFES-PAC,
APO San Francisco 96515

Yokosuka

Kenwood Rep.; c/o
A-33, Yokosuka NEX No. 280-010
FPO Seattle 96760

Atsugi

Kenwood Rep.; c/o
Atsugi NEX No. 280-020 FPO Seattle
96767

Iwakuni

Kenwood Rep.; c/o
Marine Corps Exchange, Marine Corps
Air Station,
FPO Seattle 96784

Sasebo

Sasebo NEX;
Navy Exchange 280-040
F.A. Box 116 FPO Seattle 96788

Okinawa

Kenwood Rep.; c/o
OWAX, AAFES-PAC, APO San Francisco
96230

KOREA:

Kenwood Rep.; c/o
KOAX Repair Shop, AAFES-PAC,
DD-Camp Market, APO San Francisco
96488

GUAM:

Kenwood Rep.; c/o
Guam NEX No. 230-010,
FPO San Francisco 96830
Kenwood Rep.; c/o
GUAX, AAFES-PAC, APO San Francisco
96234

U.S.A.:

In The Continental U.S.A.
For Nearest Authorized Service Center:
Tel. 1-800-536-9652
www.us.jvckenwood.com

EUROPE:

Please inquire at the military resale
outlets where you bought your
Kenwood products, or
JVCKENWOOD DEUTSCHLAND GMBH:
Konrad Adenauer Allee 5-11, 61118 Bad
Nauheim, Germany

KENWOOD

Warranty Card

Identificação do produto
Modelo do aparelho e número de série
Model number & serial number

Revendedor & cachet
Nome da loja e carimbo
Dealer & stamp

Data da compra
Data de compra
Purchase date

Nome & endereço do cliente
Nome e endereço do cliente
Name & address of customer

Attention:

This card and receipt (or invoice) are necessary to purchase a new panel in case of theft or damage.

Attention:

Vous aurez besoin de cette carte et du reçu (ou de la facture) pour acheter un nouveau panneau en cas de vol ou d'endommagement.

Atenção:

Em caso de furto ou perda do painel frontal, este Certificado de Garantia e a Nota Fiscal de compra serão requisitados para a aquisição de um novo painel.

© 046-0624-00/04 (K) (15/11)

Dear Customer,

Thank you for purchasing this Kenwood product. As mentioned in the pages of this booklet, our warranty is only valid in the countries listed. If your country is not listed please contact your retailer for information on warranty procedure, or write to:

JVC KENWOOD Customer Information Center

3-12, Moriyacho, Kanagawa-ku, Yokohama-shi, Kanagawa 221-0022, Japan


KENWOOD

KFC-1633MRW


HAUTE PARLER INSTALLATION INSTRUCTIONS Haut Parleur Marine PROCÉDURES D'INSTALLATION ALTA VOZ MARINERO PROCEDIMIENTOS DE INSTALACIÓN

Kenwood Corporation
4001 342-636-916-636


Speaker locations Emplacement des haut-parleurs Ubicación de los altavoces



Connections Raccordements Conexiones




Dimensions Dimensions Dimensiones



Connect the amplifier's output terminal to each terminal.
Relier la prise de sortie de l'amplificateur à chaque borne.
Conecte el terminal de salida del amplificador a cada terminal.

Parts included Parts comprises Partes incluidas



Specifications / Caractéristiques / Especificaciones

Note: The KFC-1633MRW is a high power speaker. It is recommended that the amplifier be used with a power supply of 12V or more.

Model	Power (W)	Frequency Response (Hz)	Impedance (Ω)
KFC-1633MRW	100	20-20,000	4
Peak Power	200		
Rated Power	100		
Frequency Response	20-20,000		
Impedance	4		
Dimensions (mm)	140 x 120 x 120		
Weight (kg)	0.2		

Remarque: Le KFC-1633MRW est un haut-parleur à haute puissance. Il est recommandé d'utiliser un amplificateur avec une alimentation de 12V ou plus.

Modèle	Puissance (W)	Fréquence de Réponse (Hz)	Impédance (Ω)
KFC-1633MRW	100	20-20,000	4
Puissance de Crête	200		
Puissance Nominale	100		
Fréquence de Réponse	20-20,000		
Impédance	4		
Dimensions (mm)	140 x 120 x 120		
Poids (kg)	0.2		


Note: The KFC-1633MRW is a high power speaker. It is recommended that the amplifier be used with a power supply of 12V or more.

Modelo	Potencia (W)	Respuesta de Frecuencia (Hz)	Impedancia (Ω)
KFC-1633MRW	100	20-20,000	4
Potencia de Pico	200		
Potencia Nominal	100		
Respuesta de Frecuencia	20-20,000		
Impedancia	4		
Dimensiones (mm)	140 x 120 x 120		
Peso (kg)	0.2		

TEMPLATE

GABARIT

PLANTILLA



IMPORTANT SAFEGUARDS AVERTISSEMENTS IMPORTANTS

KENWOOD

KENWOOD CORPORATION

- ⚠ **Caution : Read this page carefully to keep your safety.**
⚠ **Lire attentivement cette page pour votre sécurité.**

PRINTED IN TAIWAN TEL: 81-3-6709-0000

Please read all of the safety and operating instructions before operating this unit. For best results, follow all warnings placed on the unit and adhere to the operating and use instructions. These safety and operating instructions should be retained for future reference.

Prenez connaissance des instructions de sécurité et d'emploi de l'appareil avant de faire fonctionner cet appareil. Tous les avertissements et toutes les mises en garde inscrites sur l'appareil doivent être gardés dans le manuel d'emploi. Ces instructions de sécurité et d'emploi doivent être conservées pour référence future.

1. Suffocation After taking the unit out of the polyethylene bag, be sure to dispose of the polyethylene bag out of the reach of children. Otherwise, they may play with the bag which could cause hazard of suffocation.

1. Bouffement Après avoir retiré l'appareil du sac de polyéthylène, bien placer le déchet, hors de la portée des enfants. S'ils jouent avec le sac, ils risquent d'être étouffés.

2. Power supply voltage Connect the illumination lamp equipped speakers to DC 12 V, negative ground.

2. Tension d'alimentation Brancher les haut-parleurs équipés d'une lampe à incandescence sur 12 V CC, terre négative.

3. Water and moisture - Do not install the speakers in locations which may be subject to water or moisture.

3. Eau et humidité - Ne pas installer les haut-parleurs dans des endroits où ils pourraient être exposés à de l'eau ou à l'humidité.

4. Dust and unstable locations - Do not install the speakers in unstable locations or locations subject to dust.

4. Poussière et endroits instables - Ne pas installer les haut-parleurs dans des endroits instables ou exposés à de la poussière.

5. Modification - Do not attempt to open or modify the unit, for this could cause fire hazard or malfunction.

5. Modification - Ne pas essayer de démonter ou de modifier l'appareil, car cela risque de provoquer un incendie ou un fonctionnement incorrect.

6. Cleaning Do not use gasoline, naphtha, or any type of solvent to clean the speakers. Clean by wiping with a soft, dry cloth.

6. Nettoyage - Ne pas utiliser d'essence, de naphte ou d'autres solvants pour nettoyer les haut-parleurs. Se nettoyer à l'aide d'un chiffon doux et sec.

7. Abnormal smell In the event the unit generates smoke or abnormal smell, immediately switch the power OFF. After this, please contact your dealer or nearest service station as soon as possible.

7. Odeur anormale Dans le cas où l'appareil produit de la fumée ou une odeur anormale, arrêter immédiatement l'alimentation. Ensuite, contactez votre concessionnaire ou centre de service le plus proche le plus rapidement possible.

KEENWOOD

Warranty Card

Geräte-Typ und Seriennummer
Identification du produit
Produkt navn og serie nummer
Modelo y Número de serie
Mall ja sarjanumero
Μοντέλο και αριθμός σειράς
Modello e numero di matricola
Modell og serienummer
Modelo e numero de série
Apparat typ & serienummer
Identificatie van het produkt
Módel heiti og raðnumber
H-Módeli u s-seríal number
Model number & serial number

Stempel und Unterschrift des Händlers
Revendeur & cachet
Forhandler
Distribuidor y sello
Jälleenmyyjä & leima
Συμπληρώ σφραγίδα
Timbro del rivenditore
Forhandlerens navn og stempel
Agente e carimbo
Áierfórstjári & stámpel
Dealer & stempel
Undirritun og stimpill sáluaðila
Timbru ta-beijjiegħ
Dealer & stamp

Kaufdatum
Date d'achat
Købsdato
Fecha de compra
Ostapåivä
Ημερομηνία αγοράς
Data di acquisto
Kjøpt dato
Data de compra
Inköpsdatum
Aankoopdatum
Söludagur
Íd-dátá ta' meita nixtare
Purchase date

Name und Anschrift des Käufers
Nom & adresse du client
Købers navn og adresse
Nombre y dirección del cliente
Astakkaun nimi & osoite
Όνομα και διεύθυνση αγοραστή
Nome e indirizzo del cliente
Kundens navn og adresse
Nome e morada do comprador
Kundens namn & adress
Naam & adres van de klant
Nafn og heimilisfang kaupanda
L-ism u l-indirizz tax-xerrej
Name & address of customer

See back cover for table of contents.

Table of Contents

	Page
U.S.A.	2
Australia	3
Canada	4,5
Military	6,7
Belgique et Grand-duché de Luxembourg	8
Danmark	9
Deutschland	9
Nederland	10
Portugal	10
UK & Ireland	11
Österreich	11
Ελλάς	12
España	12
France	13
Italia	13
Suomi	14
Andorra	14
Iceland	14
Malta	14
Norge	15
Schweiz	15
Svizzera	15
Suisse	15
Sverige	15

Dear Customer,

Thank you for purchasing this kenwood product. As mentioned in the pages of this booklet, our warranty is only valid in the countries listed. If your country is not listed please contact your retailer for information on warranty procedure, or write to:

KENWOOD Corporation Customer Information Center
1-16-2, Hakusan, Midori-ku,
Yokohama-shi, Kanagawa, 226-8525 Japan



This warranty will be honored only in the U.S.A.

KENWOOD LIMITED WARRANTY FOR CAR STEREO COMPONENTS

HOW LONG IS THE WARRANTY

Kenwood, Ltd. (hereinafter "Kenwood") warrants this product for a period of one (1) year from the date of original purchase.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as specified below, this warranty shall be void if the following conditions are met:

1. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
2. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
3. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
4. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
5. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
6. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
7. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
8. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
9. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
10. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
11. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
12. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
13. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
14. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
15. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
16. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
17. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
18. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
19. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
20. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
21. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
22. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
23. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
24. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
25. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
26. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
27. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
28. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
29. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
30. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
31. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
32. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
33. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
34. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
35. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
36. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
37. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
38. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
39. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
40. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
41. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
42. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
43. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
44. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
45. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
46. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
47. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
48. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
49. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
50. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
51. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
52. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
53. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
54. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
55. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
56. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
57. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
58. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
59. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
60. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
61. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
62. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
63. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
64. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
65. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
66. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
67. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
68. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
69. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
70. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
71. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
72. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
73. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
74. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
75. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
76. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
77. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
78. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
79. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
80. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
81. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
82. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
83. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
84. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
85. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
86. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
87. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
88. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
89. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
90. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
91. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
92. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
93. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
94. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
95. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
96. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
97. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
98. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
99. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.
100. Any product is not covered by this warranty if it is not used in the U.S.A. by Kenwood's authorized service center.

WHO IS PROTECTED

This warranty is enforceable only by the original purchaser.

WHAT WE WILL PAY FOR

We will pay for all labor and material expenses for original items. Payment of labor and material expenses is limited to the amount of the original purchase price.

HOW TO OBTAIN WARRANTY SERVICE

If you have a problem with your product, please contact:

1. Take your product to any KENWOOD Authorized Service Center in the U.S.A. and ask for a complete description of the problem. If you are unable to do so, please contact Kenwood's Customer Service Center at 1-800-KENWOOD for the nearest Service Center. 1-800-636-8661.
2. Although you must pay for any shipping charges, it is necessary to pay for the cost of the warranty service. We will pay the cost of shipping the product to the nearest Service Center.
3. When you receive your product, please check it for damage. If you find any damage, please contact the nearest Service Center immediately.

LIMITATION OF IMPLIED WARRANTIES

ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS WARRANTY.

EXCLUSION OF DAMAGES

KENWOOD'S LIABILITY FOR ANY DEFECTIVE PRODUCT IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE PRODUCT AT OUR OPTION. KENWOOD SHALL NOT BE LIABLE FOR:

1. INSTALLATION, REMOVAL, OR REPAIRS, DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECTS IN KENWOOD CAR STEREO COMPONENTS, DAMAGES RESULTING FROM NEGLIGENCE, OR DAMAGE TO OTHER PROPERTY.
2. ANY OTHER DAMAGES, INCLUDING CONSEQUENTIAL OR OTHERWISE.
3. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY MAY LAST. KENWOOD DOES NOT ALLOW THE EXCLUSION, LIMITATION, OR DENIAL OF CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

This warranty does not cover the following items and does not affect your rights which may arise from other laws.

If a problem does occur during the term of the Limited Warranty Period, if you have any questions regarding the product, or if the product is not working properly, please contact our Customer Service Center at the address listed below.

KENWOOD USA CORPORATION
PO Box 22745, 2201 East Dominguez Street, Long Beach, CA 90801-2745
Tel: (310) 636-8661

This warranty will only be honored in the country in which the product was originally purchased.

EXPRESS WARRANTY STATEMENT FOR CAR STEREO AND PERSONAL AUDIO COMPONENTS

KENWOOD ELECTRONICS AUSTRALIA PTY LTD. is proud of the quality and workmanship of its audio equipment. This unit has been carefully designed, built and assembled to the highest standards. If properly installed and operated in accordance with instructions furnished, it should give optimum performance.

SCOPE OF EXPRESS WARRANTY

Kenwood's Limited Express Warranty is expressly warranted under a full 12-month and is applicable to all products manufactured by KENWOOD Australia Pty Ltd. Kenwood Australia Pty Ltd. will endeavour to correct any defect in material or workmanship. However, the exclusion of consequential and INCIDENTAL DAMAGES OF THE EXPRESS WARRANTY is not covered by this warranty.

EXPRESS WARRANTY PERIOD

The KENWOOD brand of stereo and personal audio components are expressly warranted for a period of ONE YEAR from the date of original purchase.

CONDITIONS OF THE EXPRESS WARRANTY

When requesting service under KENWOOD's Express Warranty, the following conditions must be presented to an authorized KENWOOD Service Center or your equipment:

1. A full, original receipt showing the date of purchase.
2. A full, original receipt showing the date of purchase.
3. A full, original receipt showing the date of purchase.
4. A full, original receipt showing the date of purchase.
5. A full, original receipt showing the date of purchase.
6. A full, original receipt showing the date of purchase.
7. A full, original receipt showing the date of purchase.
8. A full, original receipt showing the date of purchase.
9. A full, original receipt showing the date of purchase.
10. A full, original receipt showing the date of purchase.
11. A full, original receipt showing the date of purchase.
12. A full, original receipt showing the date of purchase.
13. A full, original receipt showing the date of purchase.
14. A full, original receipt showing the date of purchase.
15. A full, original receipt showing the date of purchase.
16. A full, original receipt showing the date of purchase.
17. A full, original receipt showing the date of purchase.
18. A full, original receipt showing the date of purchase.
19. A full, original receipt showing the date of purchase.
20. A full, original receipt showing the date of purchase.
21. A full, original receipt showing the date of purchase.
22. A full, original receipt showing the date of purchase.
23. A full, original receipt showing the date of purchase.
24. A full, original receipt showing the date of purchase.
25. A full, original receipt showing the date of purchase.
26. A full, original receipt showing the date of purchase.
27. A full, original receipt showing the date of purchase.
28. A full, original receipt showing the date of purchase.
29. A full, original receipt showing the date of purchase.
30. A full, original receipt showing the date of purchase.
31. A full, original receipt showing the date of purchase.
32. A full, original receipt showing the date of purchase.
33. A full, original receipt showing the date of purchase.
34. A full, original receipt showing the date of purchase.
35. A full, original receipt showing the date of purchase.
36. A full, original receipt showing the date of purchase.
37. A full, original receipt showing the date of purchase.
38. A full, original receipt showing the date of purchase.
39. A full, original receipt showing the date of purchase.
40. A full, original receipt showing the date of purchase.
41. A full, original receipt showing the date of purchase.
42. A full, original receipt showing the date of purchase.
43. A full, original receipt showing the date of purchase.
44. A full, original receipt showing the date of purchase.
45. A full, original receipt showing the date of purchase.
46. A full, original receipt showing the date of purchase.
47. A full, original receipt showing the date of purchase.
48. A full, original receipt showing the date of purchase.
49. A full, original receipt showing the date of purchase.
50. A full, original receipt showing the date of purchase.
51. A full, original receipt showing the date of purchase.
52. A full, original receipt showing the date of purchase.
53. A full, original receipt showing the date of purchase.
54. A full, original receipt showing the date of purchase.
55. A full, original receipt showing the date of purchase.
56. A full, original receipt showing the date of purchase.
57. A full, original receipt showing the date of purchase.
58. A full, original receipt showing the date of purchase.
59. A full, original receipt showing the date of purchase.
60. A full, original receipt showing the date of purchase.
61. A full, original receipt showing the date of purchase.
62. A full, original receipt showing the date of purchase.
63. A full, original receipt showing the date of purchase.
64. A full, original receipt showing the date of purchase.
65. A full, original receipt showing the date of purchase.
66. A full, original receipt showing the date of purchase.
67. A full, original receipt showing the date of purchase.
68. A full, original receipt showing the date of purchase.
69. A full, original receipt showing the date of purchase.
70. A full, original receipt showing the date of purchase.
71. A full, original receipt showing the date of purchase.
72. A full, original receipt showing the date of purchase.
73. A full, original receipt showing the date of purchase.
74. A full, original receipt showing the date of purchase.
75. A full, original receipt showing the date of purchase.
76. A full, original receipt showing the date of purchase.
77. A full, original receipt showing the date of purchase.
78. A full, original receipt showing the date of purchase.
79. A full, original receipt showing the date of purchase.
80. A full, original receipt showing the date of purchase.
81. A full, original receipt showing the date of purchase.
82. A full, original receipt showing the date of purchase.
83. A full, original receipt showing the date of purchase.
84. A full, original receipt showing the date of purchase.
85. A full, original receipt showing the date of purchase.
86. A full, original receipt showing the date of purchase.
87. A full, original receipt showing the date of purchase.
88. A full, original receipt showing the date of purchase.
89. A full, original receipt showing the date of purchase.
90. A full, original receipt showing the date of purchase.
91. A full, original receipt showing the date of purchase.
92. A full, original receipt showing the date of purchase.
93. A full, original receipt showing the date of purchase.
94. A full, original receipt showing the date of purchase.
95. A full, original receipt showing the date of purchase.
96. A full, original receipt showing the date of purchase.
97. A full, original receipt showing the date of purchase.
98. A full, original receipt showing the date of purchase.
99. A full, original receipt showing the date of purchase.
100. A full, original receipt showing the date of purchase.

EXCLUSION OF CERTAIN DAMAGES

KENWOOD'S liability for any defect or damage is limited to the repair or replacement of the product at our option, and shall not include damages of any kind, whether incidental, consequential, or otherwise.

PROCEDURE WHEN REQUESTING SERVICE UNDER THE WARRANTY

1. Make your equipment available for service. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.
2. Make your equipment available for service. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.
3. Make your equipment available for service. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.

IMPORTANT NOTICE

1. Proper installation and use are essential to the performance of all KENWOOD products. Therefore, you should read the instructions carefully before using the product.
2. Read the instructions carefully before using the product. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.
3. Read the instructions carefully before using the product. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.
4. Read the instructions carefully before using the product. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.
5. Read the instructions carefully before using the product. If you are unable to do so, please contact our nearest service center, make the product available for service, and pay for the cost of shipping the product to the nearest service center.

KENWOOD ELECTRONICS AUSTRALIA PTY LTD
10 GIFFORDS AVENUE, CENTREPOINT EAST, NORTH RYDE
N.S.W. 2113, AUSTRALIA
TEL: (02) 8691-8222

GARANTIE KENWOOD

KENWOOD ELECTRONICS CANADA INC. (ci-après «KENWOOD») donne par le présent document la garantie suivante pour les produits qu'il fabrique ou fait fabriquer au Canada :

KENWOOD garantit les produits qu'il fabrique ou fait fabriquer au Canada pendant une période déterminée pendant laquelle il s'engage à réparer ou à remplacer gratuitement les produits défectueux. Cette garantie ne s'applique qu'aux produits fabriqués ou fait fabriquer au Canada. Elle ne couvre pas les produits fabriqués ou fait fabriquer ailleurs qu'au Canada. Elle ne couvre pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.

PÉRIODE DE GARANTIE

La période de garantie des produits fabriqués ou fait fabriquer au Canada est de 12 mois à compter de la date de vente au détail. Cette période de garantie ne s'applique qu'aux produits fabriqués ou fait fabriquer au Canada. Elle ne couvre pas les produits fabriqués ou fait fabriquer ailleurs qu'au Canada. Elle ne couvre pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.

EXCLUSIONS DE GARANTIE

Cette garantie ne couvre pas :

- (a) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (b) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (c) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (d) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (e) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (f) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (g) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (h) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (i) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (j) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (k) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (l) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (m) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (n) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (o) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (p) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (q) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (r) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (s) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (t) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (u) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (v) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (w) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (x) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (y) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.
- (z) Les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.

COMMENT OBTENIR DU SERVICE SOUS GARANTIE

Si vous avez un produit qui présente un défaut, vous pouvez obtenir du service sous garantie de la part de KENWOOD. Vous devez d'abord contacter le service à la clientèle de KENWOOD. Si vous ne pouvez pas résoudre le problème, vous pouvez retourner le produit au détaillant où vous l'avez acheté. Le détaillant doit vous fournir un service sous garantie. Si le produit est défectueux, le détaillant doit vous le remplacer ou vous le rembourser. Si le produit est réparé, le détaillant doit vous le remettre. Si le produit est remplacé, le détaillant doit vous le remettre. Si le produit est remboursé, le détaillant doit vous le remettre.

L'ENTRÉE GARANTIE

Cette garantie est en vigueur pendant la période de garantie. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers.

RENOUVELLEMENT

Si le produit est réparé ou remplacé, la période de garantie est renouvelée. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers.

AVIS AUX CONSOMMATEURS

Cette garantie est en vigueur pendant la période de garantie. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers. Elle ne couvre pas les produits qui ont été réparés ou remplacés par un tiers.

IMPORTANT

KENWOOD ne s'engage pas à garantir les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers. Elle ne garantit pas les produits fabriqués ou fait fabriquer au Canada qui ont été réparés ou remplacés par un tiers.

KENWOOD ELECTRONICS CANADA INC.
4000 Central Road, Mississauga, Ontario, Canada L4T 1G6
Téléphone : (905) 876-1211
Télécopieur : (905) 876-1212

KENWOOD WARRANTY

KENWOOD ELECTRONICS CANADA INC. (hereinafter referred to as "KENWOOD") gives the following written warranty to the original purchaser of each new Kenwood product distributed in Canada by KENWOOD and its wholly owned subsidiaries:

KENWOOD warrants that each new Kenwood product, whether manufactured by Kenwood or by any other company, will be free from any defects in materials and workmanship for a period of 12 months from the date of purchase. This warranty is limited to the original purchaser of the product. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party.

WARRANTY PERIOD

This warranty period shall begin on the date of purchase of the product and shall end on the date of the 12th month following the date of purchase. This warranty is limited to the original purchaser of the product. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party.

WARRANTY EXCLUSIONS

This warranty excludes:

- (a) Products purchased from a third party or a company other than Kenwood.
- (b) Products purchased from a third party or a company other than Kenwood.
- (c) Products which have been repaired or replaced by a third party.
- (d) Products which have been repaired or replaced by a third party.
- (e) Products which have been repaired or replaced by a third party.
- (f) Products which have been repaired or replaced by a third party.
- (g) Products which have been repaired or replaced by a third party.
- (h) Products which have been repaired or replaced by a third party.
- (i) Products which have been repaired or replaced by a third party.
- (j) Products which have been repaired or replaced by a third party.
- (k) Products which have been repaired or replaced by a third party.
- (l) Products which have been repaired or replaced by a third party.
- (m) Products which have been repaired or replaced by a third party.
- (n) Products which have been repaired or replaced by a third party.
- (o) Products which have been repaired or replaced by a third party.
- (p) Products which have been repaired or replaced by a third party.
- (q) Products which have been repaired or replaced by a third party.
- (r) Products which have been repaired or replaced by a third party.
- (s) Products which have been repaired or replaced by a third party.
- (t) Products which have been repaired or replaced by a third party.
- (u) Products which have been repaired or replaced by a third party.
- (v) Products which have been repaired or replaced by a third party.
- (w) Products which have been repaired or replaced by a third party.
- (x) Products which have been repaired or replaced by a third party.
- (y) Products which have been repaired or replaced by a third party.
- (z) Products which have been repaired or replaced by a third party.

TO OBTAIN WARRANTY SERVICE

To obtain warranty service, you must first contact the service department of KENWOOD. If you cannot obtain service from KENWOOD, you must return the product to the dealer from whom you purchased it. The dealer must provide you with warranty service. If the product is defective, the dealer must replace it or refund the purchase price. If the product is repaired, the dealer must provide you with the repaired product. If the product is replaced, the dealer must provide you with the replacement product. If the product is refunded, the dealer must provide you with the refund.

ENTIRE WARRANTY

This warranty is the entire warranty for the product. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party.

DISCLAIMER

KENWOOD disclaims any liability for damages, including consequential damages, arising out of the use of the product. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party.

NOTICE TO CONSUMER

This warranty is limited to the original purchaser of the product. It does not cover products which have been repaired or replaced by a third party. It does not cover products which have been repaired or replaced by a third party.

IMPORTANT

KENWOOD does not warrant the performance of the product. It does not warrant the performance of the product. It does not warrant the performance of the product. It does not warrant the performance of the product.

KENWOOD ELECTRONICS CANADA INC.
4000 Central Road, Mississauga, Ontario, Canada L4T 1G6
Tel: (905) 876-1211
Fax: (905) 876-1212

1. The signal $x(t)$ is real valued
2. Period of n samples $\Rightarrow$ period of 2π radians of the radian frequency

KFAC-1000 CORPORATION is proud of the quality and workmanship of its products. However, if there has been some wear or damage, we can replace external components or, if properly installed, we can meet our customer's demands with our in-house service. We stand by our products and our customers.

Information is maintained for a period of ONE YEAR from the date of removal.

Enact an explicit *ethics* in writing course at the university level and encourage all students to take it.

1-800-967-8272

- [illegible]

As the measured change of the GPC band position upon measurement is directly related to the change of the GPC MW_{eff} value,

- ## LIMITATION OF IMPLIED WARRANTIES

EXCLUSION OF CERTAIN DAMAGES

SEN0000033 has been previously published and used in the reporting requirements of this period of work. The use and control of nonconformances was very complex and difficult to use, requiring a lot of time, space, and attention. It is now simpler and easier to use.

JAPAN:

701-221-1111
 701-221-1111
 701-221-1111
 701-221-1111

[illegible]

Enclosed for the
Bureau, BX 100-10753-247,
A-15 San Antonio, Texas.

Kongsberg Byggeselskap
 A/S
 2021 - 2022, by N. A. Hov, 2021-2022
 1775, 5000, 6800

From IF's to 200 (0%) FRC-5 ml. (92%.)

Received 1 April 2004
 Accepted 22 June 2004
 Published online 10 July 2004

5. b. 5 EX
Hire = 2000000/272.240
[2700000 - 2720000] / 272.240 = 997.00

Wash. St. 1998 Pub. (AP) 50 = 1,000,000

Get more features
with the new
Android™ Developer API
on the phone or API on the new Web

Ge. Mead, Boston, MA
 Street: 1155 North 210th St.
 Apartment 5, Phone: 877-80
 Ge. Mead, Boston
 Street: 1155 North 210th St. Phone: 877-80

Hawaii
 6-10-1964
 1-10-1964

121 East 12th Street, New York, NY 10003
 212 677-1212
 121 East 12th Street, New York, NY 10003

2. The following information is required:
 a. The name of the person or persons who
 are the subject of the investigation.
 b. The date of the investigation.
 c. The name of the person or persons who
 are the subject of the investigation.
 d. The date of the investigation.
 e. The name of the person or persons who
 are the subject of the investigation.
 f. The date of the investigation.
 g. The name of the person or persons who
 are the subject of the investigation.
 h. The date of the investigation.
 i. The name of the person or persons who
 are the subject of the investigation.
 j. The date of the investigation.
 k. The name of the person or persons who
 are the subject of the investigation.
 l. The date of the investigation.
 m. The name of the person or persons who
 are the subject of the investigation.
 n. The date of the investigation.
 o. The name of the person or persons who
 are the subject of the investigation.
 p. The date of the investigation.
 q. The name of the person or persons who
 are the subject of the investigation.
 r. The date of the investigation.
 s. The name of the person or persons who
 are the subject of the investigation.
 t. The date of the investigation.
 u. The name of the person or persons who
 are the subject of the investigation.
 v. The date of the investigation.
 w. The name of the person or persons who
 are the subject of the investigation.
 x. The date of the investigation.
 y. The name of the person or persons who
 are the subject of the investigation.
 z. The date of the investigation.

[illegible]

For more information, contact the publisher at (800) 451-7536, ext. 222 or write to the publisher at the address below.

