




PROGRAMMING INSTRUCTIONS




GEM-P816 CONTROL PANEL/COMMUNICATOR


Programming the GEM-P816 Control Panel with the
"Classic" GEM-RP2ASe2, GEM-RP3DGTL, and GEM-RP4RFC/GEM-RP4C Keypads and
the "K Series" GEM-K2AS, GEM-K3DGTL, and GEM-K4/GEM-K4RF Keypads



"K Series" GEM-K4/GEM-K4RF




"K Series" GEM-K2AS



"K Series" GEM-K3DGTL

Quick Start (for GEM-K2AS):

1. Refer to the wiring diagram, connect Siren, Aux. Power, PGM Output, Remote Bus, Earth Ground, Zone and Telephone Wiring. NOTE: See Installation Instructions (WI994).
2. Connect AC power first and then the battery.
3. Configure the keypad (see page 55).
4. Access the Easy Menu Driven (Dealer Program) Mode:




Press NO until "TURN ON PROG Y/N" appears on the keypad display.

Press NEXT/YES to enter Dealer Program Mode. See page 5.

Quick Start (for GEM-K3DGTL):

1. Refer to the wiring diagram, connect Siren, Aux. Power, PGM Output, Remote Bus, Earth Ground, Zone and Telephone Wiring. NOTE: See Installation Instructions (WI994).
2. Connect AC power first and then the battery.
3. Configure the keypad (see page 55).
4. Access the Easy Menu Driven (Dealer Program) Mode:



Press NO until "17" appears on the keypad display.

Press NEXT/YES to enter Dealer Program Mode. See page 5.

**THIS MANUAL INCLUDES FEATURES WHICH ARE ONLY AVAILABLE IN
CONTROL PANEL FIRMWARE VERSION 30G OR LATER.**

CHANGES FROM PREVIOUS EDITION

The following changes have been made to this manual (WI1182C) since the previous edition (WI1182B):









- All "Not for UL installations" footnote references have been made changed to a consistent "double dagger" symbol ("‡").
- Added "Warning" to page 2 (see below).

Warning: The use of non-NAPCO wireless devices with this control panel has not been evaluated by UL and voids the UL listing. In addition, the performance of these devices can not be guaranteed as compatible with NAPCO control panels.

IMPORTANT NOTE

This manual supports the keypad programming of the GEM-P816 control panel with the NAPCO "classic" GEM-RP2ASe2, GEM-RP3DGTL and GEM-RP4RFC series keypads as well as the GEM-K2AS, GEM-K3DGTL and GEM-K4RF "K Series" keypads. The new "K Series" models offer the new STAY and AWAY buttons with simplified functionality, along with the new MENU and ENTER buttons. While the instructions in this manual are depicted using the "K Series" keypads, the manual applies to both the "classic" and the "K Series" keypads.

Program Mode is the same for both keypads--**only the button names have changed**, as follows:

- The  button and the  button operate identically (in Program Mode) for both keypads.
- The  button and the  button operate identically (in Program Mode) for both keypads.
- The  button and the  button operate identically (in Program Mode) for both keypads. The words "NEXT/YES button" are used in this manual.
- The  button and the  button operate identically (in Program Mode) for both keypads. The words "PRIOR/NO button" are used in this manual.

 **For consistency, it is recommended that all keypads either be all "classic" or all "K Series"--both keypad types should not be used in one alarm system.**



NAPCO Security Systems, Inc.
333 Bayview Avenue, Amityville, New York 11701
For Sales and Repairs, call toll free: (800) 645-9445
For direct line to Technical Service, call toll free: (800) 645-9440
Internet: <http://www.napcosecurity.com>

TABLE OF CONTENTS

SYSTEM PROGRAMMING OPTIONS	4	EZM GROUP OPTIONS	36
<i>Introduction</i>	<i>4</i>	AREA BELL CONTROL OPTIONS	37
<i>Downloading From a Computer.....</i>	<i>4</i>	KEYPAD OPTIONS	41
EASY MENU DRIVEN PROGRAM MODE	5	TEMPERATURE DISPLAY AT KEYPAD	42
<i>Dealer Program - Preliminary Information</i>	<i>5</i>	ZONE OPTIONS - ZONES 1 TO 16	43
<i>Accessing Dealer Program Mode</i>	<i>5</i>	RF RECEIVER & SUPERVISORY TIMER OPTIONS	50
<i>Customizing a Default Program.....</i>	<i>5</i>	CLEAR PROGRAM OPTIONS	51
Easy Program Menu:		USER PROGRAM MODE	51
GEM-RP2ASe2/GEM-K2AS KEYPAD	6	Preliminary Information	51
GEM-RP3DGTL/GEM-K3DGTL and		Accessing User Program Mode.....	51
GEM-RP4RFC/GEM-K4RF KEYPAD	13	User Codes.....	52
DIRECT ADDRESS PROGRAM MODE.....	20	KEYPAD CONFIGURATION MODE	53
<i>Keypad Programming Overview.....</i>	<i>20</i>	Keypad Installation.....	53
<i>Accessing Direct Address Program Mode</i>	<i>20</i>	Configuring the Keypads	53
<i>Keypad Address Program Mode Display.....</i>	<i>21</i>	ALPHABETICAL INDEX.....	54
<i>Direct Address Program Mode Keypad Commands</i>	<i>21</i>	ADDRESS NUMBER LOCATION INDEX.....	59
<i>Direct Address Programming Example.....</i>	<i>22</i>	GEM-P816 WIRING DIAGRAM.....	64
<i>Conventions Used in this Manual</i>	<i>23</i>		
SYSTEM DELAYS & TIMEOUTS.....	24		
SYSTEM OUTPUT TIMEOUTS	25		
DOWNLOAD/CALLBACK OPTIONS	25		
PAGER FORMAT OPTIONS.....	25		
SYSTEM OPTIONS	26		
GLOBAL AMBUSH CODE	26		
CS RECEIVER OPTIONS.....	30		
CS SUBSCRIBER ID OPTIONS	31		
CS SYSTEM REPORTING OPTIONS	32		
CS AREA & SYSTEM REPORTING OPTIONS.....	32		
CS ZONE REPORTING OPTIONS	33		
CS USER REPORTING OPTIONS	34		
CS USER REPORTING OPTIONS	35		

Refer to accompanying GEM-P816 Installation Instructions (WI994) for installation information.

NOTE: THESE PROGRAMMING INSTRUCTIONS ARE INTENDED AND WRITTEN FOR THE PROFESSIONAL INSTALLER HAVING SUITABLE EXPERIENCE AND INSTALLATION EQUIPMENT. THE UNIT IS DESIGNED TO BE PROGRAMMED USING AN IBM-COMPATIBLE COMPUTER WITH NAPCO PCD-WINDOWS SOFTWARE. AFTER PROGRAMMING, BE SURE TO RUN THE PCD-WINDOWS ERROR-CHECK UTILITY TO GUARD AGAINST PROGRAMMING CONFLICTS FOR THE TYPE OF SERVICE SELECTED FOR THE INSTALLATION.



SYSTEM PROGRAMMING OPTIONS

INTRODUCTION

The GEM-P816 control panel may be programmed by various means, each of which will be covered in detail in the sections that follow. Keypad displays shown are for a GEM-K2AS, GEM-K3DGTL and GEM-K4RF series keypads. With the GEM-RP2ASe2 and GEM-K2AS keypads, because of their reduced display capabilities, messages are abbreviated and will scroll through two or more screens. Zone descriptions cannot be programmed using GEM-K2AS or GEM-RP2ASe2 keypad, therefore a GEM-RP1CAe2/GEM-K1CA must be used (see WI995).

- ✓ **Downloading From a Computer.** This is the preferred method of programming. The panel may be downloaded from (or uploaded to) an IBM PC-compatible computer, either locally or remotely. Napco's PCD-Windows Quickloader software features context-sensitive help screens as well as an error-checking utility that prevents programming of incompatible or conflicting data to ensure proper panel operation. **Note:** Unattended downloading from a computer is not allowed for Fire Alarm or UL installations.
- ✓ **Easy Menu-Driven Program (Dealer Program) Mode - Keypad Programming.** The Easy Menu-Driven Program Mode allows keypad programming of number of zones in area 1, number of fire zones (both 4-wire and 2-wire), local or Central Station reporting, number of exit/entry zones, number of interior zones, number of 24 hour zones, number of chime zones, Chime 2 zones, Exit/Entry2 zones, 50ms loop response zones (**Note: 750ms is required for Loop Response time in UL installations**), aux output activated on alarm zones, sensor watch zones, keypad sounder on alarm zones, auto bypass re-entry zones, EOLR zones, number of keypads in area 1, Central Station telephone number, Central Station account number, Central Station receiver format, User Codes, RF transmitter points, RF keyfob transmitters, zone descriptions, dealer code, Telco line fault test, Burg output chirp on keyfob, enable CP-01, and clear dealer program/cold start. For new panels, a custom default program may be created at the keypad. A menu-driven utility prompts the installer to configure the system. Further detailed customization is accomplished in the Direct Address Program Mode.
- ✓ **Direct Address (Dealer Program) Program Mode - Keypad Programming.** The Direct Address Program Mode is an extension of the Dealer Program Mode wherein data is entered at the keypad by specific location. This mode is accessed from the Easy Menu Driven Program Mode by pressing the **RESET** button at any time.
- ✓ **User Program Mode - Keypad programming.** The User Program Mode is intended for authorized users and is limited to keypad programming of User Codes.



DOWNLOADING FROM A COMPUTER

The control-panel program may be downloaded from the computer by any of the following methods.

Local Downloading

(**Note:** This procedure should be used after installation, after peripheral devices are connected).

For direct high-speed data transfer to the control panel from a desktop computer, connect the download jack (JP2) on the panel to the LOCAL jack (J3) on the Napco PCI2000/3000 computer interface using the supplied 6-conductor cable. (Refer to PCI2000/3000 Installation Instructions WI443 for wiring diagram and procedures).

Similarly, a high-speed local download may be made in the field using a notebook or laptop computer. Connect JP2 on the control panel to a Napco PCI-MINI computer interface using the 6-conductor cable supplied. (Refer to PCI-MINI Installation Instructions WI767).

Remote Downloading

(Also see PCI2000/3000 Installation Instructions WI443). **Note:** Unattended downloading from a computer is not allowed for Fire Alarm or UL installations.

Function Mode.

Start by establishing a Telco connection between the computer operator and the installer. During this procedure, voice contact will be lost, therefore both the installer and the computer operator should be familiar with the operation. When a steady high-pitched tone is heard at the site phone, access the "ACTIVATE DOWNLOAD" Function (see Keypad Programming Modes), then press the **YES** button or the YES button; the site phone will go dead.
















Hang up the phone and wait for a call from the central station confirming a successful download.

Callback Method.








An installed, unattended panel may be programmed or reprogrammed remotely using the Callback-Method Download feature of the PCD Windows software. Remote downloading requires a modem compatible with the PCI2000/3000. Upon answering the call from the computer, the panel will verify the Download Security Code and, if confirmed, will establish a connection. If a Callback Number is programmed into the panel, the panel will automatically disconnect and call the computer at this number before establishing a connection.

EASY MENU DRIVEN PROGRAM MODE

DEALER PROGRAM - PRELIMINARY INFORMATION

-  The Default Dealer Code is      . Use this code to enter the Dealer Program Mode to program a custom Dealer Code, which replaces the Default Dealer Code. If you clear your Dealer Code, use the Default Dealer Code once again to enter programming.
-  After entering codes or data, press the save  button. **Data will not be stored into memory unless  is pressed.**
-  If the keypad is in the Program Mode and no activity is detected for longer than 4 minutes, a steady tone will sound.
-  Silence the sounder by the  button to continue, or by pressing the  button to exit.
-  When programming a Multiple Area System, Direct Address Programming Mode must be used to complete the program.



ACCESSING DEALER PROGRAM MODE

1. Press       

↙ Dealer Code (Default = 456789) ↘

2. Press "PRIOR/NO" button until "TURNON PROG Y/N" (GEM-RP2ASe2/ GEM-K2AS) or "17" (GEM-RP3DGTL/GEM-K3DGTL or GEM-RP4RFC/GEM-K4RF) appears on the LCD screen.

3. Press "NEXT/YES" button to Enter Dealer Program Mode.



4. Press   **to exit Dealer Program Mode when finished.**

CUSTOMIZING A DEFAULT PROGRAM

For new panels, you can design a default program that will best suit your application. Using this procedure, you will configure the panel for:


- | | | |
|---|---|--|
| <ul style="list-style-type: none"> • Number of Zones in Area 1 • Fire Zones in Area 1 • 2-Wire Fire Zones in Area 1 • Local or Central Station Reporting System • Exit/Entry Zones in Area 1 • Interior Zones in Area 1 • 24 Hour Zones in Area 1 • Chime Zones in Area 1 • Chime 2 Zones in Area 1 • Exit/Entry2 Zones in Area 1 | <ul style="list-style-type: none"> • 50mS Loop Response Zones (Note: 750mS is required for Loop Response time in UL installations) • Aux Output Activated on Alarm Zones • Sensor Watch Zones • Keypad Sounder on Alarm Zones • Auto Bypass re-entry Zones • Enable no EOLR Zones • Enable Telco Line Fault Test • Enable Burg Output Chirp on Keyfob • Enable CP-01 • Number of Keypads in Area 1 | <ul style="list-style-type: none"> • Central Station Receiver 1 Tel. Number • Central Station Receiver 1 Account Number • Central Station Receiver 1 Format • Enter User Codes • RF Transmitter Points <ul style="list-style-type: none"> • <i>Quick Enroll Method</i> • Keyfob Transmitters • Enter Zone Descriptions • Dealer Code • Test Timer |
|---|---|--|

This procedure will automatically set up system keypads, EZMs, wireless transmitters, etc. After your basic default program has been loaded, you may alter it as necessary in the Direct Address Program Mode.

NEW PANELS: The custom default program may be created for new panels only. Once the panel has been programmed by any means, the number zones will be suppressed and cannot be changed. Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press the  button to enter the Direct Address Program Mode; (b) access Location 2285 (Clear Program); (c) press the  button and start over.



GEM-RP2ASe2/GEM-K2AS Keypad Easy Program Menu



Enter the Dealer Security Code (default = 456789) for a new panel or enter your custom Dealer Program Code if programmed. Press the PRIOR/NO button repeatedly until "TURNON/PROG" is displayed. **NOTE:** If you pass "TURNON/PROG", you can scroll back by pressing **[BYPASS]**. Press the NEXT/YES button to enter the Dealer Program Mode. In each of the following steps, press **[MENU]** to jump to the next screen, the NEXT/YES button to go forwards, the PRIOR/NO button to go backwards, **[ENT A1]** to save and **[RESET]** twice to exit at any time.

Ent A1

#ZnXX

(Direct Entry)

Total Number of Zones in Area 1 (Appears for New Panel Only)

Directly enter the total number of zones to be programmed for Area 1. Valid entries are from 01 to 16. Directly enter the total number of zones, including leading zeros. Use number buttons **[1]** through **[9P]**. **NOTE:** Press **[0]** for a zero. The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 18, it will automatically convert this to 20 zones. Press **[ENT A1]** to save. Press the NEXT/YES button to proceed.

Ent Fr

Zn#XX

(Direct Entry)

Fire Zones in Area 1 (Appears for New Panel Only)

Enter the zone number of any zones which are to be used as Fire Zones (both 2-wire, 4-wire or wireless). Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros, and press **[ENT A1]** to save, and then repeat for any additional zone(s). Press NEXT/YES button to proceed.

Ent2WF

Zn#XX

(Direct Entry)

2-Wire Fire Zones in Area 1 (Appears for New Panel Only)

Enter the zone numbers of any Fire Zones (from previous question) which are to be used with 2-wire smoke detectors. The only valid entries are 07 and 08. Directly enter each zone number, including leading zeros. Press **[ENT A1]** to save, and then repeat for any additional zone(s). **NOTE:** Only zones which have been designated as Fire Zones in the prior question may be programmed as 2 Wire Fire zones. Press the NEXT/YES button to proceed. **NOTE:** JP3 must be set to "2-WF" position for 2-wire fire zones (refer to Installation Instructions).

Report

all Zn

Y/N

(Press YES or NO)

Local or Central Station Reporting System (Appears for New Panel Only)

Press the NEXT/YES button for all zones to report; press the PRIOR/NO button for no zones to report (LOCAL SYSTEM).

EntEE1

Zn#XX

(Direct Entry)

Exit/Entry Zones in Area 1 (Appears for New Panel Only)

Directly enter the zone number of any zones which are to be used as Exit/Entry zones. Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros. Use number buttons **[1]** through **[9P]**. **NOTE:** Press the **[0]** button for a zero. Press **[ENT A1]** to save and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.

EntFol1
Zn#XX

(Direct Entry)

Ent24H
Zn#XX

(Direct Entry)

EntCZ1
Zn#XX

(Direct Entry)

EntCZ2
Zn#XX

(Direct Entry)

EntEE2
Zn#XX

(Direct Entry)

Ent50m
Zn#XX

(Direct Entry)

EntAux
Zn#XX

(Direct Entry)




Ent SW
Zn#XX

(Direct Entry)


EntKPS
Zn#XX

(Direct Entry)


Interior (Stay) Bypass Zones in Area 1 *(Appears for New Panel Only)*

Directly enter the zone number of any zones which are to be used as Interior Follower Zones. Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros. Use number buttons  through . **NOTE:** Press  for a zero. Press ENTER to save and then repeat for any additional zone(s). Press the NEXT/YES button to proceed. **NOTE:** All Interior Follower Zones will also be automatically programmed as "Exit/Entry Follower" and "Power Up Delay" zones.

24 Hour Zones in Area 1 *(New Program Only)*


- Enter the zone numbers of zones to be used as 24 Hour zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.

Chime Zones in Area 1 *(New Program Only)*

- Enter the zone numbers which are to be used as Chime Zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.


NOTE: A chime time of 2 seconds will be automatically programmed.

Chime 2 Zones in Area 1 *(New Program Only)*

- Enter the zone numbers which are to be used as Chime 2 Zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.


NOTE: A chime time of 2 seconds will be automatically programmed. Chime 2 zones give a distinct pulsating tone when zone is faulted.

Exit/Entry2 Zones in Area 1 *(New Program Only)*


- Enter the zone numbers of zones to be used as Exit/Entry 2 zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.

NOTE: An Exit/Entry 2 Entry Time of 30 sec. will automatically be programmed.

50mS Loop Response Zones *(New Program Only)*


- Enter the zone numbers of zones to be have a 50mS loop response. **Note:** Time can also be adjusted via address 2280. **Note: 750mS is required for Loop Response time in UL installations.**
- Valid entries are from 01 to 08. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.

AUX Output Activated on Alarm Zones *(New Program Only)*

- Enter the zone numbers of zones to activate the PGM2 output upon alarm.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.


NOTE: An Aux Output Timeout of 15 Minutes will automatically be programmed.

Sensor Watch Zones *(New Program Only)*

- Enter the zone numbers of zones to be Sensor Watch zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.

NOTE: A Sensor Watch Time of 24 hours will automatically be programmed.


Keypad Sounder On Alarm Zones *(New Program Only)*

- Enter the zone numbers of all zones to activate the Keypad Sounder upon alarm.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

EntAUB
Zn#XX

(Direct Entry)

Auto Bypass Re-entry Zones (New Program Only) (Not evaluated by UL)

- Enter the zone numbers of zones to be Auto Bypass Re-entry zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.
- Auto Bypass Re-entry Zones allow the system to be armed with the zone faulted but come back into the system (armed) when the zone is subsequently secured.

EnNEOL
Y/N

(Press YES or NO)

Enable No EOLR Zones (New Program Only)

- Press the NEXT/YES button to program all zones except 24 Hr & fire zones for No End Of Line Resistor. Press the PRIOR/NO button to continue. **NOTE:** Do not program this feature for UL Installations.

Telco
Ln Fit
Y/N

(Press YES or NO)

Enable Telco Line Fault Test? (New Program Only)

- Press the NEXT/YES button to enable Telco Line Fault Test.
 - Press the PRIOR/NO button to continue.
- NOTE:** If enabled, a Telco Line Fault Test Delay of 60 seconds will automatically be programmed.

KF Out
Chirp
Y/N

(Press YES or NO)

Enable Burg Output Chirp on Keyfob? (New Program Only)

- Press the NEXT/YES button to enable Burg Output Chirp on Keyfob Arm / Disarm.
 - Press the PRIOR/NO button to continue.
- NOTE:** The Burg Output will chirp once on Keyfob Arm and twice on Keyfob Disarm.

Enable
CP01?
Y/N

(Press YES or NO)





Enable SIA CP01? (New Program Only)

- Press the NEXT/YES button to enable.
 - Press the PRIOR/NO button to continue.
- The SIA CP-01 Features are designed to reduce the incidence of false alarms. See WI994, "Installer Programming Quick Reference Chart SIA False Alarm Reduction" and "GEM-P816 Factory Default Description" for more information. **NOTE:** Do not enable unless reporting, otherwise system trouble *Fail to Communicate* may occur.

Ent A1
#KP 01

(Direct Entry)











Number of Keypads in Area 1

Directly enter the total number of Keypads to be installed in Area 1. Valid entries are from 01 to 07. Directly enter the number of keypads, including leading zeros. Use number buttons  through . **NOTE:** Press  for a zero. Press  to save. Press the NEXT/YES button to proceed.

Phone#

(Direct Entry)

Central Station Receiver 1 Telephone Number

Using number buttons, enter telephone number of up to 16 digits including prefix letters, if necessary, for receiver 1. Use number buttons  through  for digits 1–9; press the   buttons for a zero and   through   for letters B–F, respectively. **NOTE:** Pre-Dial Delay = "D"; Dial-Tone Detection = "E". Pressing  will produce a blank space (*). Press  to save. Press the NEXT/YES button to proceed.



NOTE: Central Station Receiver 2 and 3 Telephone Numbers can only be entered in Direct Address Programming. See CS Receiver Options.





Acc #

[] [] [] []

(Direct Entry)

Central Station Receiver 1 Account Number

Enter an account number of up to four digits. Use number buttons  through  for digits 1–9.

NOTE: Press the   buttons for a zero and press  for a blank space (•). Press  to save.

Press the NEXT/YES button to proceed.

NOTE: Central Station Receiver 2 and 3 Account Numbers can only be entered in Direct Address Programming. See CS Reporting Options.









RecFmt

() ()

(Direct Entry)

Central Station Receiver 1 Format

From the table below, enter the central station's receiver format. Use number buttons  through .

NOTE: Press the   buttons for a zero and press  for a blank space (•). Press   through   for letters B–E, respectively. Press  to save. Press the NEXT/YES button to proceed.

NOTE: Central Station Receiver 2 and 3 Formats can only be entered in Direct Address Programming. See CS Receiver Options.

DATA ENTRY	CS RECEIVER 1 FORMAT
•(blank)	Ademco Slow, Silent Knight Slow
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow

DATA ENTRY	CS RECEIVER 1 FORMAT
5	Universal High Speed
B	SIA
C	Ademco Point ID
E	Pager

User01

(Direct Entry)

OPT__









(Direct Entry)

ACC __


(Direct Entry)

Enter User Codes (Press the button to set cursor.)

For default program, enter up to 16 User Codes, with Area 1 Options.

Press  once to set the cursor to the User Code. Use the number buttons  through  to enter a code from 3 to 6 digits. Enter up to 6 digits (4 digits is recommended) in the first six boxes from left to right for each user code. Valid entries are: 0-9. **NOTE:** Press  for a zero and press   for a blank space (•). No blank spaces in between; leave blank (•) any trailing boxes. If “Enable Global Ambush Code” (Address 0720) is enabled and “Global Ambush Code” (Address 1054) is **not** left blank(•), *do not* program the first two digits of ANY User Code the same as the “Global Ambush Code”. **Note:** If the programmed code was less than 6 digits, press  to set the cursor to the Area 1 Options Level (OPT). Refer to the table on the next page for the available area options. **Note:** Duplicate User Codes are not allowed; therefore a duplicate Code entered in the LCD Window will erase when  is pressed.

USER OPTIONS									
USER CODE (UP TO 6 DIGITS)								AREA 1 OPTIONS	



USER AREA OPTIONS		
DATA ENTRIES		OPTION ENABLED
L	R	
blank(*)	blank(*)	Disabled
blank(*)	1	Arm/Disarm
blank(*)	2	Arm Only
blank(*)	3	Service
blank(*)	4	Access
blank(*)	5	Ambush
blank(*)	Add 8	* User Program
4	blank(*)	Bypass Enable

AREA OPTIONS: Area 1 Options may be programmed for all 16 users.

Select the desired Area Options (Area 1) from the table shown and enter in the remaining four boxes for each user code.

Example: Program a code of "2222" for User 02, with Area 1 options of "Arm/Disarm" and "User Program". Enter "2222" for a user code, "(blank) 9" for Area 1 options.

AREA OPTIONS	EXPLANATION
Disabled	User Code not active in this area.
Arm/Disarm	Allows User Code to arm/disarm this area.
Arm Only	Prevents User Code from disarming this area.
Service	A Service Code has restricted arm/disarm rights; if an area is armed with a Service Code, a "MONITOR ON" appears on the GEM-RP2ASe2 keypad and the area can be disarmed with any valid User Code, including a Service Code. If the area is armed with OTHER than a Service Code, it CANNOT be disarmed with a Service Code. This is typically used to allow tradesmen access to premises under control of the owner.
Access	This is normally used to activate a door strike while an area is disarmed. Also program "Access Control on PGM2 Output" (Address 0719) and "PGM2 Output Access Control Timeout" (Address 0711).
Ambush	There are two types of Ambush Codes: (1) A 2-digit code (prefix) that is entered immediately prior to (and as part of) the regular User Code and (2) A separate and unique User Code. Disarming with an Ambush Code will cause a silent report to be sent to a central station. Thus, should a user be forced to disarm, he can silently signal an emergency while appearing to be merely disarming the system.
* User Program	User Program Option is enabled for Keypad 1 only. To enable User Program Option for any user add 8 to the data entry for Area 1 Option (see example). Then, User Programming can be performed only at Keypad 1 by a user code with user program enabled.
Bypass Enable	Security Bypass--Bypass is enabled only with a security code.

Press to save. To proceed to the next User Code, press to set the cursor to the User Number and change it using the number buttons.

Program a new User Code as previously described. Remember to record your user codes in the *Easy Menu Programming Worksheet* at the back of this manual.

Related User Options: "Enable Global Ambush Code" (Address 1422), "Global Ambush Code" (Address 2045) & "Enable Manager's Mode" (Address 1421).

CHANGING OR CANCELING A CODE: To change any code, merely program over the existing code as described above and press to save. Similarly, to cancel a code, blank out each number of the code press to save.

Zn# 01

000000

(Direct Entry)

:0 Pt.

(Direct Entry)

RF Transmitter Points (Press the button to set cursor).

(For wireless systems only. Also see Quick Method, which follows).

For each transmitter (keyfob transmitters also), enter the **zone number** (01–16) to which the transmitter will be mapped, the **6-digit RF ID #**: **1-digit checksum number** printed on the transmitter and box, the **point number** (1 or 2); enter "9" for unsupervised (all points). **NOTE:** When programming the ID Code number, "0" through "9" = through ; "A" = ; "B" = ; "C" = ; "D" = ; "E" = and "F" = . Press to save. Press the NEXT/YES button to proceed.

Quick Enroll Method.

If a receiver is already installed in the panel, Napco transmitter wireless points can be programmed automatically ("enrolled") using the following procedure. **NOTE:** The transmitter point will be enrolled only if the signal strength is 3 or greater.

1. Enter the zone number to which the transmitter point will be mapped.
2. Press the button to enter the Enroll Mode. The red and green LEDs on the keypad will flash.
3. Open the loop of the point that is to be programmed (GEM-TRANS2 only).
4. Install the transmitter battery. The keypad will beep to indicate that the point has been successfully enrolled. Multi-point transmitters can be mapped to successive zones simultaneously (see example).

Example. A 2-point transmitter has the RF ID number 287613:1. Map point 1 to Zone 6 and point 2 to Zone 9.

1. Enter the Enroll mode as described above.
2. Enter Zone "06".
3. Open point-1 loop.
4. Install the battery. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 1 will be mapped to Zone 6).
5. Enter Zone "09".
6. Close point-1 loop and open point-2 loop.
7. Remove the transmitter battery, then re-install it. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 2 is mapped to Zone 9).

KEYFOB ZONE ASSIGNMENT: Keyfobs can also be assigned to zones to allow multiple wireless panic buttons on one alarm system, each reporting to a central station, a pager or having a description on the keypad that describes the person holding the keyfob, the location where the person holding the keyfob is stationed, or the special purpose of the keyfob button being depressed. See *Keyfob Transmitters as Zone Input Devices*.

KFob01

Area

(Direct Entry)


000000

(Direct Entry)


: 0 0 0

(Direct Entry)




and 9P, respectively; "A" = * 0; "B" = * 1; "C" = * 2 and "D" = * 3.




If the Keyfob is converted for Two Button "Emergency Use" (by cutting an internal jumper), both top or bottom buttons must be depressed to activate an alarm. In this case, the Aux-1 and Aux-2 cannot be programmed. Press  to save. Press the NEXT/YES button to proceed. **NOTE:** Keyfobs 1-8 report openings and closings as Users 09-16.
















Keyfob Transmitters as Arm/Disarm & Control Devices

(Press  to set cursor).

Keyfobs can be programmed as "Arm/Disarm" devices using their On/Off buttons (refer to WI752). For each Keyfob Transmitter, enter:


 The **Keyfob Transmitter number** (01–08). Press   through   for 01-08.




 **Area number** to which transmitter is assigned ("1" for Area 1 or "0" to disable keyfob). Press  or  for 0 or 1, respectively.

 The **6-digit RF ID #** printed on the transmitter (enter all numbers and/or letters, including leading "0"s, if any): "0" through "9" =  through ; "A" =  ; "B" =  ; "C" =  ; "D" =  ; "E" =   and "F" =  .

 1-digit checksum number printed on the transmitter.

 **Aux 1 Option** (see keyfob aux 1 & aux 2 options).

 **Aux 2 Option** (see keyfob aux 1 & aux 2 options).

For Aux 1/Aux 2 Options: "0", "1", "2" and "9" = , , 

DATA ENTRY	AUX 1/AUX 2 OPTIONS
0	None
1	Relay Group 1 Toggle
2	Relay Group 2 Toggle
9	Keypad Panic
A	Keypad Aux.
B	Instant
C	PGM2 Output Toggle
D	Access on PGM2 Output
E	Arm Stay
F	Interior Button

Keyfob Transmitters as Zone Input Devices

(refer to display as shown above: press the PRIOR/NO button to go backwards).

Each of the 4 keyfob buttons can be assigned to a zone. For example, On button = point 1; Off button = point 2; A1 = point 3; A2 = point 4. Up to 16 keyfobs (using 1 button) or 8 keyfobs (using 2 buttons) or 4 keyfobs (using all 4 buttons) or any combination up to a maximum of 16 controlled zones can be assigned, providing multiple wireless panic buttons on a system, each reporting to a Central Station or a pager and/or annunciating on a keypad the keyfob zone number with description/location. *To assign a keyfob to a zone:* program the keyfob as you would a transmitter, entering the keyfob's ID code, check sum and point number at the appropriate zone. The "Quick Method" is not allowed. The zone may be hardwired to an electrical sensor as well as assigned to a keyfob (either one will activate the zone alarm output). **NOTE:** If assigning a keyfob to a zone, the "ON/OFF" buttons on the keyfob will no longer arm/disarm the system. The keyfob is converted to a "panic only" device.

ZONE DESCRIPTIONS: GEM-RP2ASe2 cannot be used to enter Zone Descriptions. To enter Zone Descriptions, you must use the GEM-RP1CAe2 Keypad / GEM-K1CA Keypad (See WI995) or the Napco PCD-Windows Quickloader Software.

D Code

(Direct Entry)


456789

(Direct Entry)


RE-ENT

(Direct Entry)

Dealer Code

Directly enter the Dealer Code (default = 456789), including leading zeros. Use the  through

 buttons. **NOTE:** Press  for a zero. Press  to save. Re-enter the Dealer Code to verify

the previous code. Press  to save. Press the NEXT/YES button to proceed.



EXIT DEALER PROGRAM MODE: This completes the custom default program. Press the **RESET** button to enter the Direct Address Program Mode for further programming or press **RESET** once again to end all programming and resume normal keypad operation.

CLEAR PROGRAM: Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press **RESET** to enter the Address Program Mode; (b) access Location 2285 (Clear Program) or 2286 (Cold Start); (c) press **ENTER** and then (d) press **RESET** to exit the Dealer Program Mode. A "SYSTEM TROUBLE/E09-00 SERVICE" will occur. Press **RESET** to silence the keypad.

2285 XX

(Direct Entry)

Clear Dealer Program (Erases Dealer Program)

This *erases the dealer program*. Use this feature to start a customized default program. Program Data and System Status Memory is erased where Scheduled Data and Zone Descriptions are maintained.

Access address 2285, then press the **ENTER** button. Data entry is not allowed. **NOTE:** Enter Easy Menu Driven Program Mode to program system again.

2286 XX


(Direct Entry)

Cold Start (Erases Entire Program)

This erases the entire program including Dealer Program by erasing Program Data, Zone Description Data and System Status Data (similar to a new panel).

Access address 2286, then press the **ENTER** button. Data entry is not allowed. **NOTE:** Some features (schedules) can only be programmed again with the Downloading Software.



GEM-RP3DGT/L/GEM-K3DGT/L and GEM-RP4RFC/GEM-K4RF Keypad Easy Program Menu



Enter the Default Dealer Program Code ("456789") for a new panel or enter your custom Dealer Program Code if programmed. Press **[MENU]**, followed by [PRIOR/NO] repeatedly until "17" is displayed (you can scroll back by pressing **[BYPASS]**). Press **[NEXT]** to enter Dealer Program Mode. For the GEM-RP3DGT/L/GEM-K3DGT/L (and GEM-RP4RFC/GEM-K4RF), questions are in the form of a 2-digit number flashing in the display. Press **[MENU]** to set the cursor into the next field to answer the question. Press **[MENU]** again to scroll through each segment. Press **[NEXT]** to go to the next question. To

review your Easy Program Mode responses (before pressing **[ENTER]** to save), press **[MENU]** until the 2-digit question number flashes in the display again. If the data is correct, press **[ENTER]** to save. If the data is incorrect, press **[MENU]** to set the cursor into the next field and again enter your data. **Note:** Review your Easy Program Mode responses after the initial programming of the control, except for questions marked "For New Panel Only". These questions set up the basic structure of the panel program ("Number of Zones in an Area", etc.) and cannot be viewed or altered once set. To exit the Dealer Program Mode, press **[RESET]** twice to resume normal keypad operation. To return the panel

to the factory default, enter the Direct Address Program Mode, go to location 2286 and press **[ENTER]**.





(Direct Entry)

Total Number of Zones *(Appears for New Panel Only)*

Directly enter the total number of zones to be programmed. Valid entries are from 01 to 16. Directly enter the total number of zones, including leading zeros. Use number buttons **[1]** through **[9P]**.



NOTE: Press the **[0]** button for a zero. The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 13, it will automatically convert this to 16 zones. Press **[ENTER]** to save. Press the NEXT/YES button to proceed.



(Direct Entry)

Fire Zones *(Appears for New Panel Only)*


Enter the zone number of any Fire Zones (both 2-wire, 4-wire or wireless). Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros, and press **[ENTER]** to save, and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.



(Direct Entry)

2-Wire Fire Zones *(Appears for New Panel Only)*



Enter the zone number of any Fire Zones (from previous question) which are to be used with 2-wire smoke detectors. The only valid entries are 07 and 08. Directly enter each zone number, including leading zeros. Press **[ENTER]** to save, and then repeat for any additional zone. **NOTE:** Only zones which have been designated as Fire Zones can be programmed as 2 Wire Fire zones. Press the NEXT/YES button to proceed. **NOTE:** JP7 must be set to "2-WF" position for 2-wire fire zones 7 and 8 (refer to Installation Instructions).



(Press YES or NO)

Local System or C.S. Reporting System *(Appears for New Panel Only)*

Press the NEXT/YES button for all zones to report; press the PRIOR/NO button for no zones to report (LOCAL SYSTEM).





(Direct Entry)

Exit/Entry Zones *(Appears for New Panel Only)*

Directly enter the zone numbers which are to be used as Exit/Entry zones. Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros. Use number buttons **[1]** through **[9P]**. **NOTE:** Press the **[0]** button for a zero. Press **[ENTER]** to save and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.

NOTE: Exit/Entry Zones will have an entry delay of 30 seconds and an exit delay of 60 seconds.



(Direct Entry)

Interior Zones (Appears for New Panel Only)

Directly enter the zone numbers which are to be used as Interior Zones. Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros. Use number buttons through . **NOTE:** Press the button for a zero. Press to save and then repeat for any additional zone(s). Press the NEXT/YES button to proceed.



NOTE: All Interior zones will also be automatically programmed as "Exit/Entry Follower" and "Power Up Delay" zones.



(Direct Entry)

24 Hour Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as 24 Hour zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.




(Direct Entry)

Chime Zones in Area 1 (New Program Only)

- Enter the zone numbers which are to be used as Chime Zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

NOTE: A chime time of 2 seconds will be automatically programmed.





(Direct Entry)

Chime 2 Zones in Area 1 (New Program Only)

- Enter the zone numbers which are to be used as Chime 2 Zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

NOTE: A chime time of 2 seconds will be automatically programmed. Chime 2 zones give a distinct pulsating tone when zone is faulted.





(Direct Entry)

Exit/Entry2 Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press to save and repeat for any additional zone(s); press the NEXT/YES button to proceed.



NOTE: An Exit/Entry 2 Entry Time of 30 seconds will automatically be programmed.



(Direct Entry)

50 mS Loop Response Zones (New Program Only)

- Enter the zone numbers of zones to have a 50mS loop response.
- Valid entries are from 01 to 8. Directly enter each zone number, including leading zeros.
- Press to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed. **(Note: 750mS is required for Loop Response time in UL installations).** **Note:** Time can also be adjusted via address 2280.



(Direct Entry)

Aux Output Activated on Alarm Zones (New Program Only)

- Enter the zone numbers of zones to activate the PGM2 Output upon alarm.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press to save and then repeat for any additional zone(s), Press the NEXT/YES button to proceed.


NOTE: A PGM2 Output Timeout of 15 Minutes will automatically be programmed.

15	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

<u>H</u>	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Direct Entry)

Sensor Watch Zones (New Program Only)

- Enter the zone numbers of zones to be Sensor Watch zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.


NOTE: A Sensor Watch Time of 24 hours will automatically be programmed.

16	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

<u>H</u>	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Direct Entry)

Keypad Sounder On Alarm Zones (New Program Only)


- Enter the zone numbers of all zones to activate the Keypad Sounder upon alarm.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

17	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

<u>H</u>	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Direct Entry)

Auto Bypass Re-entry Zones (New Program Only) (Not evaluated by UL)

- Enter the zone numbers of zones to be Auto Bypass Re-entry zones.
- Valid entries are from 01 to 16. Directly enter each zone number, including leading zeros.
- Press  to save and then repeat for any additional zone(s), press the NEXT/YES button to proceed.

- Auto Bypass Re-entry Zones allow the system to be armed with the zone faulted but come back into the system (armed) when the zone is subsequently closed.

18	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Press YES or NO)

Enable No EOLR Zones (New Program Only)

- Press the NEXT/YES button to program all zones except 24 Hr & fire zones for No End Of Line Resistor. Press the PRIOR/NO button to continue. **NOTE:** Do not program this feature for UL Installations.

19	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Press YES or NO)

Enable Telco Line Fault Test?

- Press the NEXT/YES button to enable Telco Line Fault Test.
 - Press the PRIOR/NO button to continue.
- NOTE:** There is a preset 60 second Telco Line Fault Test Delay.

20	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

(Press YES or NO)

Enable Burg Output Chirp on Keyfob?

- Press the NEXT/YES button to enable Burg Output Chirp on Keyfob Arm / Disarm.
 - Press the PRIOR/NO button to continue.
- NOTE:** The Burg Output will chirp once on Keyfob Arm and twice on Keyfob Disarm.

(Press YES or NO)

21	○	○	○	○	○
	INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME

Enable SIA CP-01?

- Press the NEXT/YES button to enable.
- Press the PRIOR/NO button to continue.

The SIA CP-01 Features are designed to reduce the incidence of false alarms. **NOTE:** Do not enable unless reporting, otherwise system trouble *Fail to Communicate* may occur.

22	○	○	○	●	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

24	○	○	○	●	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

25	○	○	○	●	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

26	○	○	○	●	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

Number of Keypads

Directly enter the total number of Keypads to be installed. Valid entries are from 01 to 07. Directly enter the number of keypads, including leading zeros. Use number buttons [1] through [9P]. **NOTE:** Press [0] for a zero. Press [ENTER] to save. Press the NEXT/YES button to proceed.

Central Station Receiver 1 Telephone Number

Using number buttons, enter telephone number of up to 16 digits including prefix letters, if necessary, for receiver 1. Use number buttons [1] through [9P] for digits 1–9; press [*] [0] for a zero and [*] [1] through [*] [5] for letters B–F, respectively. **NOTE:** Pre-Dial Delay = “D”; Dial-Tone Detection = “E”. Pressing [0] will produce a blank space (•). Press [ENTER] to save. Press the NEXT/YES button to proceed. **NOTE:** Central Station Receiver 2 and 3 Telephone Numbers can only be entered in Direct Address Programming. See CS Receiver Options.

Central Station Receiver 1 Account Number

Enter an account number of up to four digits. Use number buttons [1] through [9P] for digits 1–9. **NOTE:** Press the [0] button for a zero and press the [*] [0] buttons for a blank space (•). Press [ENTER] to save. Press the NEXT/YES button to proceed. **NOTE:** Central Station Receiver 2 and 3 Account Numbers can only be entered in Direct Address Programming. See CS Reporting Options.

Central Station Receiver 1 Format

From the table below, enter the central station's receiver format. Use number buttons [1] through [9P]. **NOTE:** Press the [0] button for a zero and press [*] [0] for a blank space (•). Press [*] [1] through [*] [4] for letters B–E, respectively. Press [ENTER] to save. Press the NEXT/YES button to proceed.

DATA ENTRY	CS RECEIVER 1 FORMAT
blank(•)	Ademco Slow, Silent Knight Slow
1	Sescoa, Vertex, DCI, Franklin Fast
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
8	Radionics BFSK

DATA ENTRY	CS RECEIVER 1 FORMAT
9	FBI 4/3/1
0	Radionics Modem 2
B	SIA
C	Ademco Point ID
D	Ademco Express
E	Pager

NOTE: Modem IIe is available only in Direct Address Programming. Central Station Receiver 2 and 3 Formats can only be entered in Direct Address Programming. See CS Receiver Options.

27	○	○	○	●	○
INTERIOR	BYPASS	FIRE/TBL	SYS TBL	CHIME	

(Direct Entry)

Enter User Codes (Press the [MENU] button to set cursor)

Enter up to 16 User Codes with User Options for each code. Refer to the tables below for available data entries for User Options.

Press [MENU] once to set cursor to the User Number and enter the desired User Number. Press [MENU] once again to set the cursor to the User Code. Use the number buttons [1] through [9P] to enter a code from 3 to 6 digits. Enter up to 6 digits (4 digits are recommended) in the first six boxes from left to right for each user code. Valid entries are: 0-9. **Note:** Press [0] for a zero. No blank spaces in between; leave blank (•) any trailing boxes. If an “Ambush Prefix” (Address 0495) is entered, *do not* program the first two digits of ANY User Code as the same digits entered for the “Ambush Prefix”.

If the programmed code is less than 6 digits, press [MENU] to set the cursor to USER OPTIONS.

Refer to the tables on the next page for the available User Option data entries.

USER OPTIONS									
USER CODE (UP TO 6 DIGITS)								AREA 1 OPTIONS	

USER AREA OPTIONS		
DATA ENTRIES		OPTION ENABLED
L	R	
blank(*)	blank(*)	Disabled
blank(*)	1	Arm/Disarm
blank(*)	2	Arm Only
blank(*)	3	Service
blank(*)	4	Access
blank(*)	5	Ambush
blank(*)	Add 8	* User Program
4	blank(*)	Bypass Enable

USER OPTIONS: Area 1 options for 16 Users:

Select the desired options from the table shown and enter in the remaining boxes for each user code.

Example: Program a code of "1234" for user 02, with Area 1 options of "Arm/Disarm" and "User Program":



With "27" displayed in keypad window, press

[MENU], [0] [2] (User 2), [MENU]
[1] [2] [3] [4], [*] [0] [*]
[0] (User Code), [0] [9P] (User Area 1
options) and [ENTER] (save).

Notes: (1) For **User Code**, press [*] [0] for Blank Space; (2) For **User Options**, press [0] for Blank Space.

CODE TYPE	EXPLANATION
Disabled	User Code not active.
Arm/Disarm	Allows User Code to arm/disarm.
Arm Only	Prevents User Code from disarming.
Service	A Service Code has restricted arm/disarm rights; if an area is armed with a Service Code, a "SERVICE ON" appears on the GEM-RP2ASe2 keypad and the area can be disarmed with any valid User Code, including a Service Code. If the area is armed with OTHER than a Service Code, it CANNOT be disarmed with a Service Code. This is typically used to allow tradesmen access to premises under control of the owner.
Access	This is normally used to activate a door strike. Also program "Access Control on PGM2 Output" (Address 0719) and "PGM2 Output Access Control Timeout" (Address 0711).
Ambush	There are two types of Ambush Codes: (1) A 2-digit code (prefix) that is entered immediately prior to (and as part of) the regular User Code and (2) A separate and unique User Code. Disarming with an Ambush Code will cause a silent report to be sent to a central station. Thus, should a user be forced to disarm, he can silently signal an emergency while appearing to be merely disarming the system.
* User Program	User Program Option is enabled for Keypad 1 only, wherever it is connected. To enable User Program Option for any user add 8 to the data entry Option (see example). Then, User Programming can be performed only at Keypad 1 by a user code with user program enabled.
Bypass Enable	Security Bypass--Bypass is enabled only with a security code.

Related User Options: "Enable Global Ambush Code" (Address 1422) & "Global Ambush Code" (Address 2045).



RF Transmitter Points (Press the [MENU] button to set cursor)

(For wireless systems only. Also see Quick Method, which follows).

For each transmitter (keyfob transmitters also), enter the zone number (01–16) to which the transmitter will be mapped, the 6-digit RF ID#: 1-digit checksum number printed on the transmitter and box, the point number (1 or 2); enter "9" for unsupervised (all points). **NOTE:** When programming the ID Code number, "A" = [*] [0]; "B" = [*] [1]; "C" = [*] [2]; "D" = [*] [3]; "E" = [*] [4]; "F" = [*] [5]. Press [ON/OFF] to save. Press NEXT ([INTERIOR]) to proceed.

Quick Enroll Method.

If a receiver is already installed in the panel, Napco transmitter wireless points can be programmed automatically ("enrolled") using the following procedure. **NOTE:** The transmitter point will be enrolled only if the signal strength is 3 or greater.

1. Enter the zone number to which the transmitter point will be mapped.
2. Press the [BYPASS] button to enter the Enroll Mode. The red and green LEDs on the keypad will flash and the window will display as shown at left.
3. Open the loop of the point that is to be programmed (GEM-TRANS2 or GEM-TRANS4 only).
4. Install the transmitter battery. The keypad will beep to indicate that the point has been successfully enrolled. Multi-point transmitters can be mapped to successive zones simultaneously (Example 1) or to selected zones point by point (Example 2).

Example 1. A 4-point transmitter has the RF ID number 410078:1. Map the first three points to Zones 11–13, respectively.

1. Enter the Enroll mode as described in step 2 above.
2. Enter Zone "11".

3. Open the loops of points 1, 2 and 3.
4. Install the transmitter battery. The keypad will beep 3 times to indicate that three points have been programmed.

Transmitter 410078:1, point 1 will be mapped to Zone 11.

Transmitter 410078:1, point 2 will be mapped to Zone 12.

Transmitter 410078:1, point 3 will be mapped to Zone 13.



The keypad will now display Zone 13, the last zone enrolled.

Example 2. A 2-point transmitter has the RF ID number 287613:1. Map point 1 to Zone 6 and point 2 to Zone 9.

1. Enter the Enroll mode as described above.
2. Enter Zone "06".
3. Open point-1 loop.
4. Install the battery. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 1 will be mapped to Zone 6).
5. Enter Zone "09".
6. Close point-1 loop and open point-2 loop.
7. Remove the transmitter battery, then re-install it. The keypad will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 2 is mapped to Zone 9).



KEYFOB ZONE ASSIGNMENT: Keyfobs can also be assigned to zones to allow multiple wireless panic buttons on one alarm system, each reporting to a central station, a pager or having a description on the keypad that describes the person holding the keyfob, the location where the person holding the keyfob is stationed, or the special purpose of the keyfob button being depressed. *See the next page, Keyfob Zone Assignment.*



Keyfob Transmitters (Press **MENU** to set cursor).

Keyfobs can be programmed as “Arm/Disarm” devices (refer to WI752).

For each Keyfob Transmitter, enter:

☞ The Keyfob Transmitter number (01–08).

☞ Area number to which transmitter is assigned (1 only); enter 0 to disable keyfob.

☞ The 6-digit RF ID # printed on the transmitter (enter all numbers and/or letters, including leading “0”s, if any).

☞ 1-digit checksum number printed on the transmitter (enter all numbers and/or letters, including leading “0”s, if any).

☞ Aux-1 Option (see keyfob aux 1 & aux 2 options).

☞ Aux-2 Option (see keyfob aux 1 & aux 2 options).

Press **ENTER** to save. Press the NEXT/YES button to proceed.

DATA ENTRY	AUX 1/AUX 2 OPTIONS
0	None
1	Relay Group 1 Toggle
2	Relay Group 2 Toggle
9	Panic
A	Auxiliary
B	Instant
C	PGM2 Output Toggle
D	Access on PGM2 Output
E	Arm Stay
F	Interior Button

NOTE: Keyfobs 1-8 report openings and closings as Users 09-16.

Note: If the Keyfob is converted for Two Button “Emergency Use” (by cutting an internal jumper), both top or bottom buttons must be depressed to activate an alarm. In this case, the Aux-1 and Aux-2 cannot be programmed.

Keyfob Transmitters as Zone Input Devices (refer to display above: press the PRIOR/NO button to go backwards).


Each of the 4 keyfob buttons can be assigned to a zone. For example, On button = point 1; Off button = point 2; A1 = point 3; A2 = point 4. Up to 16 keyfobs (using 1 button) or 8 keyfobs (using 2 buttons) or 4 keyfobs (using all 4 buttons) or any combination up to a maximum of 16 controlled zones can be assigned, providing multiple wireless panic buttons on a system, each reporting to the Central Station or a pager and/or annunciating on a keypad the keyfob zone

number with description/location. *To assign a keyfob to a zone:* program the keyfob as you would a transmitter, entering the keyfob's ID code, check sum and point number at the appropriate zone. The “Quick Method” is not allowed. The zone may be hardwired to a sensor as well as assigned to a keyfob (either one will activate the zone alarm output). **NOTE:** If assigning a keyfob to a zone, the “ON/OFF” buttons on the keyfob will no longer arm/disarm the system. The keyfob is converted to a “panic only” device.

ZONE DESCRIPTIONS: GEM-K3DGTL cannot be used to enter Zone Descriptions. To enter Zone Descriptions, you must use the *GEM-K1CA Keypad* or the *Napco Quickloader Software*.



DATE ENTRY: GEM-K3DGTL cannot be used to enter the date. To enter Date, you must use the *GEM-K1CA Keypad (Version 5 or later)* or the *Napco Quickloader Software*.



TIME ENTRY: GEM-K3DGTL cannot be used to enter the time. To enter Time, you must use the *GEM-K1CA Keypad (Version 5 or later)* or the *Napco Quickloader Software*.






(Direct Entry)





Dealer Code

Directly enter the Dealer Code, including leading zeros. Use the  through  buttons.


NOTE: Press  for a zero. Press  to save.

Re-enter the Dealer Code to verify the previous code. Press  to save. Press the NEXT/YES button to proceed. **NOTE:** The Dealer Code can be two or more digits (up to 6 digits).

EXIT DEALER PROGRAM MODE: This completes the custom default program. Press  to enter the Direct Address Program Mode for further programming or press  once again to end all programming and resume normal keypad operation.

CLEAR PROGRAM: Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press  to enter the Address Program Mode; (b) access Location 2285 (Clear Program) or 2286 (Cold Start); (c) press  and then (d) press  to exit the Dealer Program Mode. A System Trouble Condition will occur. Press  to silence the keypad.

This is an extension of the Dealer Program Mode. This method of programming is used in conjunction with the Keypad Programming Worksheets that follow. Refer to these worksheets to identify the 4-digit location (address) of the feature to be programmed. An illustrative example is provided on the next page.




KEYPAD PROGRAMMING OVERVIEW


Direct Address Programming allows you to go directly to the address locations and change the data entries to customize your control panel options. Whereas the Easy Menu Program Mode is a simple quick start guide with limited options, the Direct Address Program Mode is more flexible allowing you to change all the options.

It consists of multiple address locations with two data entry locations each (left and right) as shown in the adjacent diagram.


ACCESSING DIRECT ADDRESS PROGRAM MODE



KEYPAD ADDRESS PROGRAM MODE DISPLAY




GEM-RP2ASe2/GEM-K2AS Keypads



GEM-RP3DGTL/GEM-K3DGTL Keypads

Press **MENU** followed by (1) the 4 digit address location, and (2) the corresponding data shown.



GEM-RP4RFC/GEM-K4RF Keypads

Press **MENU** followed by (1) the 4 digit address location, and (2) the corresponding data shown. **Note:** A long beep sounds when in Address Program Mode.

1 = ADDRESS LOCATION **2** = DATA ENTRY LOCATION (Left and Right Digits)

DIRECT ADDRESS PROGRAM MODE KEYPAD COMMANDS

A. GEM-K2AS (and GEM-RP2ASe2) Keypad

To access, press **RESET** in Dealer Program Mode

1. Toggle Cursor to 4-digit address field using the **MENU** button.
2. Enter address Number directly using number buttons (0-9).
3. Enter Data directly using number buttons.*
4. Press the **ENTER** button to save:

To exit, press **RESET**.

NOTE: Press **0** button to clear character at cursor. _____

Select NEXT/PRIOR Address. _____


Press *** STAY** to jump to next programming block.

* Press *** 0** through *** 5** for 10-15, respectively.

B. GEM-K3DGTL/GEM-RP3DGTL Keypads

To access Direct Address Program Mode, press **RESET** in the Easy Menu Mode.

1. Press **MENU**.
 2. Enter the 4 digit Address location directly using number buttons (0-9).
 3. Enter the 2 digit data directly using number buttons (0-9).
 4. Press **ENTER** to save.
- To exit, press **RESET**.



NOTE: "A" = *** 0**; "B" = *** 1**; "C" = *** 2**; "D" = *** 3**; "E" = *** 4**; "F" = *** 5**. Press **0** for a zero or to clear.

Example: Direct Address Programming

Program Zones 6, 7 and 8 as Exit/Entry Follower Zones.

DETERMINE THE DATA ENTRIES

1. Referring to ZONE FEATURES in the Programming Worksheets that follow, Exit/Entry Follower for Zones 5 through 8 are located at address 0916, left digit. Circle the data values for Zones 5–8.
2. Add the data values for Zones 6, 7 and 8: $2+4+8=14$. From Tables 1 and 2, "14" (E) is entered as press *** 4**. The right digit (for Zones 1 through 4, none of which are Exit/Entry Follower Zones) is entered as a blank (•).

ZONE OPTION	ZONES LEFT DATA VALUES SUM = 14 (CIRCLE)				ADDRESS 0916			ZONES RIGHT DATA VALUES			
	ZN08	ZN07	ZN06	ZN05	L	ADDR	R	ZN04	ZN03	ZN02	ZN01
EXIT/ENTRY FOLLOWER	⑧	④	②	1	E	0916	BLANK (•)	8	4	2	1


ENTER DATA


PROGRAM THE DATA ENTRIES


1. Enter the panel's Dealer Security Code, then press **MENU**.
2. Answer NO (**INSTANT**) to all questions until "ACTIVATE PROGRAM Y/N" is displayed; then press the NEXT/YES button.
NOTE: If you pass "ACTIVATE PROGRAM", scroll backward using **BYPASS**.
3. Press **RESET** to enter the Address Program Mode. Address "0000" will display.
4. Press **0 9 P 1 6** to access Address 0916. The data for both digits will display and the cursor will advance to the data field.
5. Press *** 4** to enter an "E" in the left digit and press **0** to enter a blank (•) in the right digit.
6. Press **ENTER** to save. Address 0916 is now programmed with "E •".
7. Enter another 4-digit address to continue programming or press **RESET** to exit and resume normal keypad operation.

The displays shown on the previous pages will appear after a brief delay.

 Use **MENU** to toggle the cursor between the 4-digit address field and the data entry locations.

 Enter the address directly using the number buttons.

 The contents of the address will be read automatically, along with the feature name and programming information. The cursor will advance to the data field. Enter the required data directly using the number buttons.

 Press **ENTER** to save the contents of each address.

EXIT DIRECT ADDRESS PROGRAM MODE: When done, press **RESET** to exit and resume normal keypad operation.


CONVENTIONS USED IN THIS MANUAL



The Keypad Programming Worksheets in the back are provided as an address-programming reference to help the installer modify his custom default program or to make minor field alterations to an existing panel program. It is recommended that the panel be uploaded to NAPCO's PCD-Windows software following any keypad programming and that the PCD-Windows error-check feature be utilized to reduce the possibility of programming omissions or conflicts.


Note: Most of the addresses shown comprise two data entry locations, left and right digits. Program the left digits on the left data-display segment, and the right digit on the right segment. For those addresses having only one programmable nibble, program the right segment only; the left segment should display a blank (•).

Keep the Keypad Programming Worksheets on file for future reference.

General Programming Steps

 1. Contact the central station to ascertain receiver format, data format, event codes, subscriber numbers and telephone number(s).

 2. Select the desired features by circling  the respective "address" boxes. Refer to the Programming Options and Worksheets for guidance in selecting the "data" (1,2,4,8) to be entered into those boxes.

 3. Program the data entered in the boxes on the worksheets into the respective addresses. The display will show the entry numerically, but will display "0" for the number 10, and letters "B", "C", "D", "E", and "F" for the numbers 11 through 15, respectively. To program a 10, press *** 0**. To program 11 through 15, press *** 1** through *** 5**, respectively.

NOTE: See the Direct Address Programming Example on the previous page.



DATA ENTRY SELECTIONS (BINARY VALUE CIRCLED) 				ENTRY TOTAL	PRESS 	KEYPAD DISPLAYS
8	4	2	1	blank	0	•
8	4	2	①	1	1	1
8	4	②	1	2	2	2
8	4	②	①	3	3	3
8	④	2	1	4	4	4
8	④	2	①	5	5	5
8	④	②	1	6	6	6
8	④	②	①	7	7F	7
⑧	4	2	1	8	8A	8
⑧	4	2	①	9	9P	9
⑧	4	②	1	10	* 0	0
⑧	4	②	①	11	* 1	B
⑧	④	2	1	12	* 2	C
⑧	④	2	①	13	* 3	D
⑧	④	②	1	14	* 4	E
⑧	④	②	①	15	* 5	F

Table 1 (above). Determining data entry for a location (each "nibble"). Numbers in parentheses indicate data for selected zones or features. (See Programming Worksheets that follow).

SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 1413, 1417, 2050 & 2055)

EXIT DELAY (sec.)	ADDRESS 0000	
	LEFT	RIGHT

[Default = 3 C]

ENTRY DELAY 1 (sec.)	ADDRESS 0001	
	LEFT	RIGHT

[Default = 1 E]

ENTRY DELAY 2 (sec.)	ADDRESS 0002	
	LEFT	RIGHT

[Default = 1 E]

PGM2 Output Access Cntrl Timeout (sec.)	ADDRESS 1413	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

ABORT DELAY (sec.)	ADDRESS 1417	
	LEFT	RIGHT

[Default = 1 E]

DATA ENTRIES		DELAY/ TIMEOUT
LEFT	RIGHT	
blank (•)	blank (•)	0 sec.
blank (•)	F	15 sec.
1	E	30 sec.
2	D	45 sec.
3	C	60 sec.
5	0	90 sec.
7	8	120 sec.
F	F	255 min.

1. Select delay/timeout (0-255 sec.) from the table shown.
2. Enter in corresponding address locations above (left and right digits).
3. For a desired delay/timeout not listed do the following:
 - A. Choose a desired delay/timeout, ex: 20 sec.
 - B. Divide it by 16

4. Press  to save.

$$\begin{array}{r}
 16 \overline{) 20} \\
 \underline{-16} \\
 4
 \end{array}$$

① Quotient → Left Digit
④ Remainder → Right Digit

EXIT/ENTRY DELAYS: Apply only to zones programmed with the following options "Exit/Entry 1, Exit/Entry 2, Exit/Entry Follower". For UL Installations, the maximum exit delay is 60 seconds and the maximum entry delay is 45 seconds. **NOTE:** Sensor Watch Time Options are similar to above table, except in hours.

Sensor Watch Time (Hrs.)	ADDRESS 2050	
	LEFT	RIGHT

[Default = 24 HRS = 1 8]

Report Cancel Window (min.)	ADDRESS 2055	
	LEFT	RIGHT

[Default = zero minutes = blank (•) blank (•)]

PROGRAMMING TIMEOUTS: Either use the tables provided or calculate your own timeout using the steps indicated. **WARNING:** Timers have uncertainty of +/-1sec, so a "time" of 1 second may actually timeout IMMEDIATELY.

SYSTEM DELAYS & TIMEOUTS (ADDRESS 1418 & 1419)

CHIME TIME (%sec.)	ADDRESS 1418	
	LEFT	RIGHT

[Default = 2 sec. = blank (•) 8]

AC Fail Report Delay (min.)	ADDRESS 1419	
	LEFT	RIGHT

[Default = 60 mins. = 3 C]

DEFAULTS: The defaults shown on this page and on the following pages are automatically set after exiting the Easy Menu Driven Mode.

CHIME TIMEOUT OPTIONS		
DATA ENTRIES		TIMEOUT
LEFT	RIGHT	
blank (•)	blank (•)	(0) ¼sec. = 0 sec.
blank (•)	2	(2) ¼sec. = ½ sec.
blank (•)	3	(3) ¼sec. = ¾ sec.
blank (•)	4	(4) ¼sec. = 1 sec.
blank (•)	5	(5) ¼sec. = 1.25 sec.
blank (•)	6	(6) ¼sec. = 1.5 sec.
blank (•)	7	(7) ¼sec. = 1.75 sec.
blank (•)	8	(8) ¼sec. = 2 sec.
F	F	(255) ¼sec. = 63.25

AC FAIL REPORT DELAY OPTIONS		
DATA ENTRIES		TIMEOUT
LEFT	RIGHT	
blank (•)	blank (•)	blank (•)
blank (•)	1	1
blank (•)	2	2
blank (•)	3	3
blank (•)	4	4
blank (•)	5	5
blank (•)	6	6
blank (•)	7	7
F	F	255 min. = 4 Hr., 30 min.

1. Select delay/timeout from the table shown.
2. Enter in corresponding address locations above (left and right digits).
3. For a desired delay/timeout not listed do the following:
 - A. Choose a desired delay/timeout, ex: 20
 - B. Divide it by 16

4. Press  to save.

$$\begin{array}{r}
 16 \overline{) 20} \\
 \underline{-16} \\
 4
 \end{array}$$

① Quotient → Left Digit
④ Remainder → Right Digit



Program Option	ADDRESS LOC.	
	LEFT	RIGHT

ENTER DATA 

PROGRAMMING STEPS:

1. Lookup desired Programming Option by Address Location (highlighted in black).
2. Select the programming option data entry from the tables shown.
3. Enter the selected data entry in the boxes shown.
4. For more information on a programming option refer to the Glossary at the end of this manual.

SYSTEM OUTPUT TIMEOUTS (ADDRESS 1412 & 1414-1416)

PGM2 Output Timeout (min.)	ADDRESS 1412	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Alarm Output Timeout (min.)	ADDRESS 1414	
	LEFT	RIGHT

[Default = 15 mins. = (blank) F]

Pulse Alarm Output Timeout (min.)	ADDRESS 1415	
	LEFT	RIGHT

[Default = 15 mins. = (blank) F]

PGM1 Output Timeout (min.)	ADDRESS 1416	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

DATA ENTRIES		DELAY/ TIMEOUT
LEFT	RIGHT	
blank (•)	blank (•)	0 min.
blank (•)	1	1 min.
blank (•)	2	2 min.
blank (•)	3	3 min.
blank (•)	4	4 min.
blank (•)	5	5 min.
blank (•)	6	6 min.
1	blank (•)	16 min.
↓	↓	↓
F	F	255 min.

1. Select delay/timeout (0-255 min.) from the table shown.
2. Enter in corresponding address locations above (left and right digits).
3. For a desired delay/timeout not listed do the following:
 - Choose a desired delay/timeout, ex: 20 min.
 - Divide it by 16

4. Press  to save.

$$\begin{array}{r}
 \textcircled{1} \text{ Quotient} \longrightarrow \text{Left Digit} \\
 16 \overline{) 20} \\
 \underline{-16} \\
 \textcircled{4} \text{ Remainder} \longrightarrow \text{Right Digit}
 \end{array}$$

OUTPUT TIMEOUTS: If a timeout of "0 min." is selected, then the output will remain active (ON) until the system is reset or disarmed. For UL Residential Installations, the minimum timeout is 4 minutes. Not UL listed for Commercial Installations.

DOWNLOAD/CALLBACK OPTIONS (ADDRESS 2059 & 0526-0545)

No. Rings Before Pickup	ADDRESS 2059	
	LEFT	RIGHT
	blank (•)	

[Default = blank (•) blank (•)]

NUMBER OF RINGS BEFORE PICKUP: Enter the number of rings before automatic pickup by the control panel when downloading from a computer (see installation instructions WI994 for more information).

1. Enter in right digit only (left digit is not used).
2. Valid entries are: 3-9, 0 = 10, B = 11, C = 12, D = 13, E = 14, F = 15






NOTE: Default is 15 Rings. Dark shaded data shows option not available.

3. Press  to save.

CALLBACK Telephone Number (Digits 1-20)	ADDRESS 0526-0545 (RIGHT DIGITS 1-20)																			
	0526	0527	0528	0529	0530	0531	0532	0533	0534	0535	0536	0537	0538	0539	0540	0541	0542	0543	0544	0545
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

[Default = blank (•) for all digits 1-20]

CALLBACK TELEPHONE NUMBER: Enter telephone number to be used when downloading from a computer (see installation instructions WI994 for more information).

1. Enter in right digit only (left digit is not used).
2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (•). For a zero, press  .
3. Valid entries are: 1-9, B = , C = , D = 3 sec. pause, E = Wait for dial tone, F = ignore location.
4. Press  to save.


PAGER FORMAT OPTIONS (ADDRESS 0546 & 0547)

Leading Digits for Pager Format (1st Digit)	ADDRESS 0546	
	LEFT	RIGHT
	blank (•)	

Leading Digits for Pager Format (2nd Digit)	ADDRESS 0547	
	LEFT	RIGHT
	blank (•)	



[Default = blank (•) blank (•)]

LEADING DIGITS FOR PAGER FORMAT: In Pager Format reporting, the message typically begins with "00". However, for some pager services, this will cause the Pager's Voice Mail feature to activate. This option allows you to program these digits to any number desired. A typical Pager report is "003 22 1234", where 3 is the Event, 22 is the zone, and 1234 is the Subscriber ID number. For example, if the Leading Digits are programmed as "98", the Pager report will now appear as "983 22 1234". **NOTE:** See CS Receiver Options to select Pager Format.



1. Enter in 1st and 2nd Leading Digits in right digit only (left digit is not used) as shown.
2. Valid entries are: 0-9.
3. Press  to save.





SYSTEM OPTIONS (ADDRESS 0836-0863 & 2045)

SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE	GLOBAL SYSTEM EVENT/TROUBLE LEFT DATA VALUES (CIRCLE )				ADDRESS 0836-0843			GLOBAL SYSTEM EVENT/TROUBLE RIGHT DATA VALUES (CIRCLE )			
	Bell Superv.	EZM TAMPER	AC FAIL	LOW BATTERY	LEFT	ADDR	RIGHT	MEMORY FAILURE	RF RCVR. TROUBLE	TELCO FAILURE	TEST TIMER
Alarm Output	8	4	2	1		0836		8	4	2	1
Pulsed Alarm Output	8	4	2	1		0837		8	4	2	1
PGM1 Output	8	4	2	1		0838		8	4	2	1
PGM2 Output	8	4	2	1		0839		8	4	2	1
Report Event Telco 1	8	4	2	1		0840		8	4	2	1
Report Restore Telco 1	8	4	2	1		0841		8	4	2	1
Report Event Telco 3	8	4	2	1		0842		8	4	2	1
Report Restore Telco 3	8	4	2	1		0843		8	4	2	1

[Default = blank (•) blank (•) from address 0836-0843] **Note:** If *Test Timer* is enabled (above), *Digital Dialer Test* is also enabled.

SYSTEM RESPONSE ACTIVATED BY AREA 1 EVENT/TROUBLE	AREA 1 SYSTEM EVENT/TROUBLE LEFT DATA VALUES (CIRCLE )				ADDRESS 0856-0863			AREA 1 SYSTEM EVENT/TROUBLE RIGHT DATA VALUES (CIRCLE )			
	Keyfob Low Batt.	FAIL TO CLOSE	FAIL TO OPEN	KEYPAD TAMPER	LEFT	ADDR	RIGHT	KEYPAD AUX. [‡]	KEYPAD FIRE	KEYPAD PANIC	AMBUSH
Pulsed Alarm Output	8	4	2	1		0856		8	4	2	1
Alarm Output	8	4	2	1		0857		8	4	2	1
PGM1 Output	8	4	2	1		0858		8	4	2	1
PGM2 Output	8	4	2	1		0860		8	4	2	1
Report Event Telco 1	8	4	2	1		0861		8	4	2	1
Report Event Telco 3	8	4	2	1		0863		8	4	2	1


[Default = blank (•) blank (•) from address 0856-0863] [‡]**NOTE:** Keypad Aux. is not to be selected for UL Installations.

1. Select the desired option by circling  the data values for each digit (left and right).
2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.
4. Press  to save.

Global Ambush Code	ADDRESS 2045	
	LEFT	RIGHT

[Default = blank (•) blank (•)]



GLOBAL AMBUSH CODE: It is the 2-digits entered immediately prior to the regular disarm code. If "Enable Global Ambush Code" (Address 1422) is selected and Address 2045 is left blank (•), then the 2-digit Global Ambush Code is "99". If "Enable Global Ambush Code" is selected and Address 2045 is **not** left blank (•), then the 2-digit Global Ambush Code is the two digits entered in address 2045.



 Enter in address location (both left and right digits) ; valid entries are 1-9.



 Press  to save.



THIS PAGE INTENTIONALLY LEFT BLANK



SYSTEM OPTIONS (ADDRESS 1420-1424)



SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE )	ADDRESS 1420		RIGHT DATA VALUES (CIRCLE )	SYSTEM OPTIONS
RESERVED	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Opening Report Only after Alarm Report
Enable AutoArm if not closed at end of Window	2			2	Closing Report Only on Conditional Close
Enable Keypad Time/Date Display	4			4	Incl. Sel./Grp. Bypass in Cond. Close /Status
Disable Zone Fault Scrolling	8			8	Status Report
		[Default = blank (•) blank (•)]			

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE )	ADDRESS 1421		RIGHT DATA VALUES (CIRCLE )	SYSTEM OPTIONS
Access Control on PGM2 Output	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Auto Bell Test on Arming
Maintained Keyswitch Arming	2			2	Auto Reset after Burglary Output Timeout
Enable Manager's Mode	4			4	Suppress Bypass Reminder when Armed
Disable Keypad Instant Mode	8			8	Enable Local Alarm on First Zone AND Trip
		[Default = blank (•) blank (•)]			

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE )	ADDRESS 1422		RIGHT DATA VALUES (CIRCLE )	SYSTEM OPTIONS
Disable Keypad Function Mode Download	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Interior Normally Bypassed
Disable Callback Download	2			2	Enable Global Ambush Code **
Chirp Output on Keyfob Arm/Disarm	4			4	Reset Day Zone with Arm/Disarm Only
Change Pulse Output to Temporal Output [§]	8			8	Enable Residential Fire
		[Default = blank (•) blank (•)]			

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE )	ADDRESS 1423		RIGHT DATA VALUES (CIRCLE )	SYSTEM OPTIONS
Line-Fault Test only when Armed*	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	RESERVED
Enable Line-Fault Test*	2			2	Wireless Trouble Activates Telco 1
Inhibit System Trouble Audible at Keypad [‡]	4			4	Wireless Trouble Activates Telco 3
Select Alarm Output for Keyfob Chirp	8			8	Enable Alarm Output on Telco Fail only when Armed
		[Default = blank (•) blank (•)]			

SYSTEM OPTIONS	LEFT DATA VALUES (CIRCLE )	ADDRESS 1424		RIGHT DATA VALUES (CIRCLE )	SYSTEM OPTIONS
Don't Clear PGM2 Output with Disarm	1	LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)	1	Automatic Interior Bypass/Easy Exit
Disable 2nd Call Ans. Machine Override	2			2	Veri-phone Zones Trip PGM2 Output
RESERVED	4			4	Veri-phone Audio Priority Over Alarms
Disable Code Required for EZ Bypass	8			8	Resound on Wireless Smoke Low Battery
		[Default = blank (•) blank (•)]			

1. Select the desired option by circling  the data values for each digit (left and right).
2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.
4. Press  to save.





***NOTE:** To select "Line-Fault Test only when Armed", you must also select "Enable Line-Fault Test" at address 1423.







****NOTE:** If "Enable Global Ambush Code" in Address 1422 is selected, then program the 2-digit "Global Ambush Code" in Address 2045. If Address 2045 is left blank (•), then, the 2-digit "Global Ambush Code" will be "99".

‡NOTE: Not for UL Installations.

§This feature must be programmed in Fire Alarm applications.

SYSTEM OPTIONS (ADDRESS 2051-2054)



-  1. Select the desired option by circling  the data values for each digit (left and right).
-  2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
-  3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.
-  4. Press  to save.

***Note:** (Address 2052) If this feature is not selected, the E15 Lug will, by default, activate when the system is armed (in either Stay or Away mode).

‡NOTE: Not for UL Installations.

††NOTE: This option is for reference only and cannot be changed.

CS RECEIVER OPTIONS (ADDRESS 0460-0525)

CS Receiver 1 Format	ADDRESS 0460	
	LEFT	RIGHT
	blank (*)	


CS Receiver 2 Format	ADDRESS 0482	
	LEFT	RIGHT
	blank (*)	

CS Receiver 3 Format	ADDRESS 0504	
	LEFT	RIGHT
	blank (*)	







DATA ENTRY	CS RECEIVER 1 FORMAT
blank (*)	Ademco Slow, Silent Knight Slow
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
B	SIA
C	Ademco Point ID
E	Pager *

Default for CS Receiver 1 Format depends on Easy Menu Question "RCVR FORMAT". [Default = (blank) * (blank)] for CS Receivers 2 and 3 Formats.



CS RECEIVER FORMATS: Up to 3 CS Formats may be programmed.

1. Select the desired CS Receiver Format from the table shown.
2. Enter in the corresponding right digit address location (left digit is not used) for each CS Receiver. **NOTE:** Dark shaded data value box shows option not available.
3. Press  to save.

*See Pager Format Options to program Leading Digits for Pager Format.

CS RECEIVER TELCO 1 OPTIONS		LEFT DATA VALUES (CIRCLE 		ADDRESS 0461		RIGHT DATA VALUES (CIRCLE 		CS RECEIVER TELCO 1 OPTIONS	
Sum Check		1		<div><div>LEFT DIGIT (SUM OF DATA VALUES)</div><div>RIGHT DIGIT (SUM OF DATA VALUES)</div></div> <p>[Default = blank (•) blank (•)]</p>		1		1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2				2		2300Hz Handshake/Kissoff *	
Enable TCP/IP AES RPT		4				4		Enable Zone Number on Pulse Alarm	
RESERVED		8				8		Single Digit Only	
CS RECEIVER TELCO 2 OPTIONS		LEFT DATA VALUES (CIRCLE 		ADDRESS 0483		RIGHT DATA VALUES (CIRCLE 		CS RECEIVER TELCO 2 OPTIONS	
Sum Check		1		<div><div>LEFT DIGIT (SUM OF DATA VALUES)</div><div>RIGHT DIGIT (SUM OF DATA VALUES)</div></div> <p>[Default = blank (•) blank (•)]</p>		1		1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2				2		2300Hz Handshake/Kissoff *	
Enable TCP/IP AES RPT		4				4		Enable Zone Number on Pulse Alarm	
RESERVED		8				8		Single Digit Only	
CS RECEIVER TELCO 3 OPTIONS		LEFT DATA VALUES (CIRCLE 		ADDRESS 0505		RIGHT DATA VALUES (CIRCLE 		CS RECEIVER TELCO 3 OPTIONS	
Sum Check		1		<div><div>LEFT DIGIT (SUM OF DATA VALUES)</div><div>RIGHT DIGIT (SUM OF DATA VALUES)</div></div> <p>[Default = blank (•) blank (•)]</p>		1		1400Hz Handshake/Kissoff *	
3/1 with Extended Restores		2				2		2300Hz Handshake/Kissoff *	
Enable TCP/IP AES RPT		4				4		Enable Zone Number on Pulse Alarm	
RESERVED		8				8		Single Digit Only	

CS RECEIVER OPTIONS: Select options for any of the three CS Receivers.

1. Select the desired option by circling  the data values for each digit (left and right).
 2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
 3. Enter in address location (left and right digits).
- NOTE:** Dark shaded data value box shows option not available. Press  to save.






NOTE: * If both are selected, 1400Hz has priority over 2300Hz.

CS Receiver 1 Telephone Number (Digits 1-20)	ADDRESS 0462-0481 (RIGHT DIGITS 1-20)																			
	0462	0463	0464	0465	0466	0467	0468	0469	0470	0471	0472	0473	0474	0475	0476	0477	0478	0479	0480	0481
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
CS Receiver 2 Telephone Number (Digits 1-20)	ADDRESS 0484-0503 (RIGHT DIGITS 1-20)																			
	0484	0485	0486	0487	0488	0489	0490	0491	0492	0493	0494	0495	0496	0497	0498	0499	0500	0501	0502	0503
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
CS Receiver 3 Telephone Number (Digits 1-20)	ADDRESS 0506-0525 (RIGHT DIGITS 1-20)																			
	0506	0507	0508	0509	0510	0511	0512	0513	0514	0515	0516	0517	0518	0519	0520	0521	0522	0523	0524	0525
	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Default for CS Receiver 1 Telephone Number depends on Easy Menu Question "CENTRAL PHONE #".

[Default = blank (*)] across digits 1-20 for CS Receiver Telephone Numbers 2 and 3.

CS RECEIVER TELEPHONE NUMBERS: Enter telephone numbers for any of the three CS Receivers (Telco 1, 2 & 3).

1. Enter in right digit only (left digit is not used).
2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (*). For a zero, press  .
3. Valid entries are: 1-9, B = , C = , D = 3 sec. pause, E = Wait for dial tone, F = ignore location. Press  to save.

CS SUBSCRIBER ID OPTIONS (ADDRESS 0560-0667)

CS Telco 1 Sub- scriber Opening/ Closing ID Number (Area 1)	ADDRESS 0560-0563 (RIGHT DIGITS 1-4)			
	0560	0561	0562	0563

CS Telco 1 Sub- scriber Event ID Number (System)	ADDRESS 0592-0595 (RIGHT DIGITS 1-4)			
	0592	0593	0594	0595

CS Telco 1 Sub- scriber Event ID Number (Area 1)	ADDRESS 0576-0579 (RIGHT DIGITS 1-4)			
	0576	0577	0578	0579

CS Telco 2 Sub- scriber Opening/ Closing ID Number (Area 1)	ADDRESS 0596-0599 (RIGHT DIGITS 1-4)			
	0596	0597	0598	0599

CS Telco 2 Sub- scriber Event ID Number (System)	ADDRESS 0628-0631 (RIGHT DIGITS 1-4)			
	0628	0629	0630	0631

CS Telco 2 Sub- scriber Event ID Number (Area 1)	ADDRESS 0612-0615 (RIGHT DIGITS 1-4)			
	0612	0613	0614	0615

CS Telco 3 Sub- scriber Opening/ Closing ID Number (Area 1)	ADDRESS 0632-0635 (RIGHT DIGITS 1-4)			
	0632	0633	0634	0635




CS Telco 3 Sub- scriber Event ID Number (System)	ADDRESS 0664-0667 (RIGHT DIGITS 1-4)			
	0664	0665	0666	0667

CS Telco 3 Sub- scriber Event ID Number (Area 1)	ADDRESS 0648-0651 (RIGHT DIGITS 1-4)			
	0648	0649	0650	0651

Default for CS Telco 1 Subscriber Event ID Number (Area 1) depends on Easy Menu Question "ACCOUNT #". [Default = blank (•) blank (•) blank (•) blank (•)] for all other ID Numbers.

CS TELCO SUBSCRIBER ID NUMBERS: Enter the Subscriber Opening/Closing and Event ID Numbers for any of the 3 CS Receivers.

 1. Enter in corresponding right digit address location (*left digit is not used*).

 2. Enter 3 or 4 digits (depending on the CS receiver format) for each subscriber number from left to right. **NOTE:** Leave trailing boxes blank (•). For a zero, press  . Valid entries are: 1-9, 0 and B-F. **NOTE:** A is not permitted. Press [Enter] to save.

CS SYSTEM REPORTING OPTIONS (ADDRESS 0670-0705)

CS SYSTEM REPORTING CODES	ADDRESS 0670-0682		
		ADDR	
Alarm Restore	blank (•)	0670	
Trouble	blank (•)	0671	
Trouble Restore	blank (•)	0672	
Xmitter Low Battery	blank (•)	0673	
Xmitter Supervision	blank (•)	0674	
Xmitter Tamper	blank (•)	0675	
RESERVED	blank (•)	0676	blank (•)
Opening	blank (•)	0677	
Closing	blank (•)	0678	
Opening after Alarm	blank (•)	0679	
Conditional Close	blank (•)	0680	
Cancel	blank (•)	0681	
Test Timer		0682	

CS SYSTEM REPORTING CODES	ADDRESS 0683-0708		
		ADDR	
Telco Fail		0683	
RF Rec. Trouble		0684	
Memory Fail		0685	
Low Battery		0686	
Panel AC Fail		0687	
EZM Tamper		0688	
Alarm Output Superv.		0689	
Ambush		0698	
Panic		0699	
Fire		0700	
Auxiliary [‡]		0701	
Tamper		0702	
Fail to Open		0703	
Fail to Close		0704	
Keyfob Low Battery		0705	

CS SYSTEM REPORTING CODES:

1. Enter in corresponding address location (left and right digits).

NOTE: Left digit is the first digit and right digit is the second digit in a two digit CS receiver format.

2. Valid entries are: 1-9, 0 and B-F.

NOTE: A is not permitted.

3. To disable a code leave boxes blank (•).

NOTE: Dark shaded data value box shows option not available.

4. Press  to save.


[‡]**NOTE:** Keypad Aux. is not to be selected for UL Installations.

[Default = blank (•) blank (•) from address 0670-0682]
[Default = blank (•) blank (•) from address 0683-0705]

CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 0785, 0786 & 0788)


DISABLE OPENING REPORTS	
ADDRESS 0785	
LEFT DIGIT	RIGHT DIGIT (SUM OF DATA VALUES)
blank (•)	


[Default = blank (•) blank (•)]

RIGHT DATA VALUES (CIRCLE )	AREA
1	AREA 1
2	RESERVED
4	RESERVED
8	RESERVED

DISABLE CLOSING REPORTS	
ADDRESS 0786	
LEFT DIGIT	RIGHT DIGIT (SUM OF DATA VALUES)
blank (•)	


[Default = blank (•) blank (•)]

RIGHT DATA VALUES (CIRCLE )	AREA
1	AREA 1
2	RESERVED
4	RESERVED
8	RESERVED


CS SYSTEM REPORT OPTIONS	LEFT DATA VALUES (CIRCLE )
Cancel Next Test Timer on any Report	1
Disable Wait for Silence (Pager Format)	2
Disable Wait for Handshake on Transmit	4
Disable Auto Dial Tone Detect	8

ADDRESS 0788	
LEFT DIGIT (SUM)	RIGHT DIGIT (SUM)

[Default = blank (•) blank (•)]

RIGHT DATA VALUES (CIRCLE )	CS SYSTEM REPORT OPTIONS
1	Backup Report on Telco 1 & 2
2	Touch-tone Dialing Only *
4	Touch-tone Dialing w/Rotary Backup *
8	RESERVED

CS AREA & SYSTEM REPORTING OPTIONS:

1. Select the desired option by circling  the data values for each digit (left and right).
2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
3. Enter in address location (left and right digits).

NOTE: Dark shaded data value box shows option not available. Press  to save.

*** NOTE:** If neither Touch-tone Dialing nor Touch-tone w/Rotary Backup is selected, then system defaults automatically to Rotary Dialing. Leave blank (•) to select Rotary Dialing.

CS ZONE REPORTING OPTIONS (ADDRESS 0720-0735)

ADDRESS 0720-0727							
CONTROL PANEL ZONES REPORT CODE							
ZONE 1	ZONE 2	ZONE 3	ZONE 4	ZONE 5	ZONE 6	ZONE 7	ZONE 8
0720	0721	0722	0723	0724	0725	0726	0727
L R	L R	L R	L R	L R	L R	L R	L R

ADDRESS 0728-0731			
ZONES REPORT CODE			
ZONE 9	ZONE 10	ZONE 11	ZONE 12
0728	0729	0730	0731
L R	L R	L R	L R

ADDRESS 0732-0735			
ZONES REPORT CODE			
ZONE 13	ZONE 14	ZONE 15	ZONE 16
0732	0733	0734	0735
L R	L R	L R	L R


Default for Group Zone Report Codes depends on Easy Menu Question "RCVR. FORMAT".

ZONE REPORT CODE OPTIONS	
DATA ENTRIES	
LEFT	RIGHT

DATA ENTRIES LEFT	MODEM CODE
1	Fire
2	Panic
3	Burglary
4	Hold up
7	Gas Alarm
8	Heat Alarm
0	Auxiliary Alarm
B	24 Hour Auxiliary

PULSE EVENT CODE will be the first digit of the 2 digit reporting code. The second digit will be the second digit of the reporting zone. For example, for zone 9 (address 0728), if the right digit is "3", then the reporting code is "39". For example, for zone 15 (address 0734), if the right digit is "4", then the reporting code is "45".

MODEM CODES determine the zone types reported for the following formats: SIA and ADEMCO Point ID.

 1. Select the desired Modem Code for each zone from the table shown.

 2. Press  to save.

CS USER REPORTING OPTIONS (ADDRESS 0800-0813)

User Opening Telco 1	LEFT DATA VALUE				ADDRESS 0800		RIGHT DATA VALUES				LEFT DATA VALUE				ADDRESS 0801		RIGHT DATA VALUES			
	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1

User Opening Telco 1	ADDRESS 0804		RIGHT DATA VALUES			
	LEFT	RIGHT	User 36	User 35	User 34	User 33
			8		2	1

User 33 = Auto Arming/Disarming
 User 34 = Quickloader Remote Arming/Disarming
 User 35 = Easy Arming (Opening not applicable)
 User 36 = Keyswitch Arming

NOTE: These opening events will report as the user number shown. Also, Keyfobs 1-8 (see Easy Menu Program Driven Mode) will report as Users 09-16, respectively.


User Opening Telco 1	LEFT DATA VALUE				ADDRESS 0809		RIGHT DATA VALUES				LEFT DATA VALUE				ADDRESS 0810		RIGHT DATA VALUES			
	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1

User Opening Telco 1	ADDRESS 0813		RIGHT DATA VALUES			
	LEFT	RIGHT	User 36	User 35	User 34	User 33
			8		2	1

User 33 = Auto Arming/Disarming
 User 34 = Quickloader Remote Arming/Disarming
 User 35 = Easy Arming (Opening not applicable)
 User 36 = Keyswitch Arming

NOTE: These opening events will report as the user number shown. Also, Keyfobs 1-8 (see Easy Menu Program Driven Mode) will report as Users 09-16, respectively.

CS USER REPORTING OPTIONS: [Default = blank (•) blank (•) from address 0800-0813]

1. Select the desired option by circling the data values for each digit (left and right).
2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.
4. Press  to save.

CS USER REPORTING OPTIONS (ADDRESS 0818-0831)

User Opening Telco 3	LEFT DATA VALUE				ADDRESS 0818		RIGHT DATA VALUES				LEFT DATA VALUE				ADDRESS 0819		RIGHT DATA VALUES			
	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1

User Opening Telco 3	ADDRESS 0822		RIGHT DATA VALUES			
	LEFT	RIGHT	User 36	User 35	User 34	User 33
			8		2	1

User 33 = Auto Arming/Disarming
 User 34 = Quickloader Remote Arming/Disarming
 User 35 = Easy Arming (Opening not applicable)
 User 36 = Keyswitch Arming

NOTE: These opening events will report as the user number shown. Also, Keyfobs 1-8 (see Easy Menu Program Driven Mode) will report as Users 09-16, respectively.



User Opening Telco 3	LEFT DATA VALUE				ADDRESS 0827		RIGHT DATA VALUES				LEFT DATA VALUE				ADDRESS 0828		RIGHT DATA VALUES			
	User 8	User 7	User 6	User 5	LEFT	RIGHT	User 4	User 3	User 2	User 1	User 16	User 15	User 14	User 13	LEFT	RIGHT	User 12	User 11	User 10	User 9
	8	4	2	1			8	4	2	1	8	4	2	1			8	4	2	1

User Opening Telco 3	ADDRESS 0831		RIGHT DATA VALUES			
	LEFT	RIGHT	User 36	User 35	User 34	User 33
			8		2	1

User 33 = Auto Arming/Disarming
 User 34 = Quickloader Remote Arming/Disarming
 User 35 = Easy Arming (Opening not applicable)
 User 36 = Keyswitch Arming

NOTE: These opening events will report as the user number shown. Also, Keyfobs 1-8 (see Easy Menu Program Driven Mode) will report as Users 09-16, respectively.

CS USER REPORTING OPTIONS: [Default = blank (•) blank (•) from address 0818-0831]

1. Select the desired option by circling  the data values for each digit (left and right).
2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
3. Enter in address location (left and right digits). **NOTE:** Dark shaded data value box shows option not available.
4. Press  to save.

EZM GROUP OPTIONS (ADDRESS 1455-1456)

EZM Group 1	
ADDRESS 1455	
LEFT	RIGHT
blank	

EZM Group 2	
ADDRESS 1456	
LEFT	RIGHT
blank	

EZM TYPE	
DATA ENTRIES	OPTION
blank (•)	Not used (No EZM present)
1	4-Zone EZM

EZM GROUP	ZONES COVERED NORMAL
1	9-12
2	13-16

EZM GROUP OPTIONS: Up to 2 Groups of 4 Zones each may be programmed depending on the number of Zones used and which EZM modules are connected. Each Group represents 4 Zones.


1. Select EZM type from the table shown.
2. Enter either blank (•) or "1" in corresponding address locations above.

NOTE: Dark shaded data value box shows option not available.

3. Press  to save.


AREA BELL CONTROL OPTIONS (ADDRESS 1473, 1477, 1481, 1485)


Output Turns Off upon Disarm

RESERVED	LEFT DATA VALUES (CIRCLE )
RESERVED	1
RESERVED	2
RESERVED	4
RESERVED	8

Burglary Output Turns Off upon Disarm	
ADDRESS 1473	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)
●	(1)


[Default = blank (•) one (1)]

RIGHT DATA VALUES (CIRCLE )	Disarming
1	Burg Output Silenced
2	RESERVED
4	RESERVED
8	RESERVED


RESERVED	LEFT DATA VALUES (CIRCLE )
RESERVED	1
RESERVED	2
RESERVED	4
RESERVED	8

Pulsed Burg Output Turns Off upon Disarm	
ADDRESS 1477	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)
●	(1)

[Default = blank (•) one (1)]


RIGHT DATA VALUES (CIRCLE )	Disarming
1	Pulsed Burg Output Silenced
2	RESERVED
4	RESERVED
8	RESERVED


Silence PGM1 Output / PGM2 Output

RESERVED	LEFT DATA VALUES (CIRCLE )
RESERVED	1
RESERVED	2
RESERVED	4
RESERVED	8

PGM1 Output Turns Off upon Disarm	
ADDRESS 1481	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)
●	(1)


[Default = blank (•) one (1)]

RIGHT DATA VALUES (CIRCLE )	Disarming
1	PGM1 Output Silenced
2	RESERVED
4	RESERVED
8	RESERVED

RESERVED	LEFT DATA VALUES (CIRCLE )
RESERVED	1
RESERVED	2
RESERVED	4
RESERVED	8







PGM2 Output Turns Off upon Disarm	
ADDRESS 1485	
LEFT DIGIT (SUM OF DATA VALUES)	RIGHT DIGIT (SUM OF DATA VALUES)
●	(1)

[Default = blank (•) one (1)]

RIGHT DATA VALUES (CIRCLE )	Disarming
1	PGM2 Burg Output Silenced
2	RESERVED
4	RESERVED
8	RESERVED

OUTPUT TURNS OFF UPON DISARM:

Select options for any of the 4 Outputs. By default, the ability to turn off an output upon disarm is not allowed.

-  1. Select the desired option by circling  the data values for right digit only (left is not used).
-  2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 23).
-  3. Enter in right digit address location. **NOTE:** Dark shaded data value box shows option not available.
-  4. Press  to save.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

KEYPAD OPTIONS (ADDRESS 1425-1431, 1440-1446)

Keypad 1 Type	ADDRESS 1425	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 2 Type	ADDRESS 1426	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 3 Type	ADDRESS 1427	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 4 Type	ADDRESS 1428	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 5 Type	ADDRESS 1429	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 6 Type	ADDRESS 1430	
	LEFT	RIGHT

[Default = blank (•) blank (•)]

Keypad 7 Type	ADDRESS 1431	
	LEFT	RIGHT


[Default = blank (•) blank (•)]



KEYPAD TYPE	
LEFT	OPTION
blank (•)	Burg Keypad
2	Wizard Keypad [‡]

[‡]Not for UL Installations.

KEYPAD ASSIGNMENT	
RIGHT	OPTION
blank (•)	Disabled
1	Active Keypad

KEYPAD TYPE: Up to 7 keypads may be programmed, if they are connected.**NOTE:** See Keypad Configuration Mode.

1. Select keypad type for each keypad from the tables shown.
2. Enter in corresponding right and left digit address locations above.
3. Press  to save.

KEYPAD NO.	KEYPAD OPTIONS				ADDRESS 1440-1446			KEYPAD OPTIONS			
	LEFT DATA VALUES (CIRCLE 							RIGHT DATA VALUES (CIRCLE 			
	RSRVD	PANEL ACCESS	EASY ARMING	AMBUSH	LEFT	ADDR	RIGHT	RSRVD	KEYPAD PANIC	KEYPAD AUX. [‡]	KEYPAD FIRE
1	8	4	2	1		1440		8	4	2	1
2	8	4	2	1		1441		8	4	2	1
3	8	4	2	1		1442		8	4	2	1
4	8	4	2	1		1443		8	4	2	1
5	8	4	2	1		1444		8	4	2	1
6	8	4	2	1		1445		8	4	2	1
7	8	4	2	1		1446		8	4	2	1

[Default = blank (•) blank (•) from address 1440-1446]

[‡]NOTE: Keypad Aux. is not to be selected for UL Installations.**KEYPAD OPTIONS:** Select options for any of the 7 keypads.


1. Select the desired option entering the option number (1-8) for each digit.
2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available.

3. Press  to save.

TEMPERATURE DISPLAY AT KEYPAD (ADDRESS 1666-1668)


--ZONE 6 TEMPERATURE SENSOR--



Temperature Display at the Keypad

The temperature is displayed instead of the date on line 2 of the GEM-RP1CAe2 and GEM-K1CA keypads only. The keypads listed on the cover of this manual are able to program, but not display, this Temperature Display feature.

The GEM-RP1CAe2 / GEM-K1CA keypad will display from -22F to 140F (or -30C to 60C). Fahrenheit is the default setting, select Celsius by enabling address 1668 option 2 (right nibble). When this Temperature Display Option is enabled, Zone 6 becomes the input for the GEM-TEMP64 Temperature Sensor module and Zone 6 of the panel becomes inoperative.

Address 1668 option 3 (right nibble) enables Zone 6 to report a temperature problem. Address 1666 (options 1-7) set the lower limit temperature value and address 1667 (options 1-7) sets the upper limit temperature value (both values are set in binary). If the temperature detected by the panel is above or below these set limits, the panel will report an alarm on Zone 6. To function and report properly, Zone 6 must be selected as a reporting zone, 24hr zone in area 1 and auto-resettable. At both 1666 and 1667 addresses, option 8 sets positive or negative temperature. If the temperature of 0 degrees is required, "negative zero" (-0) degrees must be used (+0 or an empty location is not a valid temperature). To simulate the sensor module, a power supply can be connected to Zone 6 and set from .55v to 3.05v to display the whole temperature range. Temperature values are read and updated every 5 seconds. To report an outer limit temperature, the temperature must be out of limits for 2 seconds. To avoid false alarm reports, the limits have a threshold of 5 degrees in the software. Two new logs have been created for temperature out of limits and restore. If the  key is depressed and held down for 2 seconds, the date will display for 5 seconds.

In addition, three addresses must be enabled (either via Quickloader or via direct address programming) in order for the **Temperature Display at Keypad** feature to operate.

The following features must be enabled In Quickloader (or in direct address programming):

1. **Keypad Assignment, Temperature Settings** tab, **Enable Temperature Display** (Address 1668, option 1)
2. **Keypad Assignment, Keypad Features** tab, **Enable Keypad Time/Date Display** (Address 1420, option 7)
3. **Keypad Assignment, Keypad Features** tab, **Enable Set Time/Date Message** (Address 2051, option 1)

Note: If these three addresses are set and power (AC and battery) are subsequently removed, they keypad will indicate that the time and date are lost and will need to be reset. See WI1425 for more information.

[‡]This feature not evaluated by UL.

ZONE OPTIONS - ZONES 1 TO 16 (ADDRESS 0900-1016)

See steps listed at bottom of page → Step 1 Step 2 Step 4 Step 4 Step 2 Step 2 Step 4 Step 4 Step 2

For notes (A), (B) and (C), see next page.

NOTE: (Address Location 0942 can only be programmed as “blank (•) blank (•)”, “4 blank (•)”, “8 blank (•)” or “C blank (•)”.

- NOTE:** Dark shaded boxes = option not available.
See Direct Address Programming Example page 22.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

RF RECEIVER & SUPERVISORY TIMER OPTIONS (ADDRESS 2029-2044 & 2056)

Number of RF Receivers	ADDRESS 2056		DATA ENTRIES	RF Receiver(s)
	LEFT	RIGHT		
	blank (*)		RIGHT	
			blank (*)	None
			1	1
			2	2

Default for Number of Receivers depends on Easy Menu Question for RF Transmitters.

RF RECEIVERS: Up to 2 RF Receivers may be programmed.

1. Select the number of receivers from the table shown.

2. Enter in corresponding right digit address location shown (left digit is not used).

3. Press  to save.

RF SUPERVISORY TIMER	RF TRANSMITTER	ADDRESS 2029-2036			RF SUPERVISORY TIMER	RF TRANSMITTER	ADDRESS 2037-2044		
		LEFT	ADDR	RIGHT			LEFT	ADDR	RIGHT
Type 0	Window/Door, 2 Pt.	blank (*)	2029		Type 8	Smoke Detector	blank (*)	2037	
Type 1	Window/Door, 2 Pt.	blank (*)	2030		Type 9	RESERVED	blank (*)	2038	
Type 2	Window/Door, 2 Pt.	blank (*)	2031		Type A	Dual Tech.	blank (*)	2039	
Type 3	Window/Door, 2 Pt.	blank (*)	2032		Type B	RESERVED	blank (*)	2040	
Type 4	RESERVED	blank (*)	2033		Type C	Window/Door, 4 Pt.	blank (*)	2041	
Type 5	PIR	blank (*)	2034		Type D	PIR	blank (*)	2042	
Type 6	PIR	blank (*)	2035		Type E	Smoke Detector	blank (*)	2043	
Type 7	Smoke Detector	blank (*)	2036		Type F	Napco Glass Break	blank (*)	2044	

[Default = blank (*) blank (*) from address 2029-2044]

RF SUPERVISORY TIMERS		
DATA ENTRIES		DELAY
LEFT	RIGHT	
blank (*)	3	90 min.
blank (*)	4	120 min.
blank (*)	5	150 min.
blank (*)	6	180 min.
blank (*)	7	210 min.
blank (*)	8	240 min.
blank (*)	9	270 min.
blank (*)	0	300 min.
blank (*)	B	330 min.
blank (*)	C	360 min.
blank (*)	D	390 min.
blank (*)	E	420 min.
blank (*)	F	450 min.

RF SUPERVISORY TIMERS: RF Supervisory Timers may be programmed for each type of transmitter used. A transmitter will send a transmission every time it is tripped, when there is NO activity, the transmitter sends a status transmission about once an hour. If the receiver does NOT receive ANY signal (a trip or a status) from a transmitter in the time specified for transmitter type, a system trouble "WIRELESS TROUBLE/EO4-NN SERVICE" will be displayed at the keypad.

1. Select timer delay from the table shown. Timers are programmed in increments of 30 minutes each. Valid entries are [blank (*)3]-[blank (*)F], 90 minutes-450 minutes.

2. Enter in corresponding address locations above right digit only (left digit is not used).

3. Press  to save.

NOTE: These timers apply only to Supervised RF Transmitters (see RF Transmitters in Easy Menu Driven Mode Programming).

CLEAR PROGRAM OPTIONS (ADDRESS 2285 & 2286)

2285 XX

GEM-RP1CAe2 Keypad


2285 XX

GEM-RP2ASe2 Keypad

Clear Dealer Program (Erases Dealer Program)



This *erases the dealer program*. Use this feature to start a customized default program. Program Data and System Status Memory is erased where Scheduled Data and Zone Descriptions are maintained.

Access address 2285, then press the  button. Data entry is not allowed.

NOTE: Enter Easy Menu Driven Program Mode to program system again.

2286 XX

GEM-RP1CAe2 Keypad


2286 XX

GEM-RP2ASe2 Keypad

Cold Start (Erases Entire Program)



This *erases the entire program* including Dealer Program by erasing Program Data, Zone Description Data and System Status Data (similar to a new panel).


Access address 2286, then press the  button. Data entry is not allowed.

NOTE: Some features (schedules) can only be programmed again with the Downloading Software. **NOTE:** Some features (schedules) can only be programmed again with the Downloading Software. If power fails, time and date restarts at 00:00:00 and a date of 01-01-04 (January 1, 2004).


USER PROGRAM MODE



PRELIMINARY INFORMATION


The User Program Mode is covered in detail in the operating instructions for the keypad in use.

 The Program Mode cannot be accessed while the communicator is transmitting except during the first three minutes after power-up.

 After entering codes or data, press the save  button. *Data will not be stored into memory unless this button is pressed.*

 If the keypad is in the Program Mode and no activity is detected for longer than 4 minutes, a steady tone will sound.


 Press the  button to silence the sounder and exit the User Program Mode.

Use the  button to manually scroll the display at the end of each programming line.

ACCESSING USER PROGRAM MODE

1. Press       

↖ New Panel (Default User Code = 123) ↗
Existing Panel (Any Code with User Program Option Enabled)


2. Press  Until "TURNON PROG Y/N" (GEM-RP2ASe2/GEM-K2AS) or "97" (GEM-RP3DGTL/GEM-K3DGTL or GEM-RP4RFC/GEM-K4RF) appears on the LCD screen.

3. Press  To Enter User Program Mode.

4. Press  To Exit User Program Mode when finished.

USER CODES


GEM-K2AS Keypad



(Direct Entry)

To Program User Codes


1. Enter 2-digit User Number (01-16) directly using number buttons (0-9).
2. Press the **[MENU]** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **[ENTER]** button to save each code.




NOTE: Press **[*]** **[0]** button to clear character at cursor.
To continue press **[STAY]** or **[AWAY]** button.

Programming User Codes with GEM-K2AS Keypad


GEM-K3DGTL Keypad



User Program Mode




User Number



User Code (Direct Entry)

To Program User Codes


1. Enter 2-digit User Number (01-16) directly using number buttons (0-9).
2. Press the **[MENU]** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **[ENTER]** button to save each code.




NOTE: Press **[*]** **[0]** button to clear character at cursor.
To continue press **[STAY]** or **[AWAY]** button.

Programming User Codes with GEM-K3DGTL Keypad


GEM-K4RF Keypad



User Program Mode




User Number



User Code (Direct Entry)

To Program User Codes


1. Enter 2-digit User Number (01-16) directly using number buttons (0-9).
2. Press the **[MENU]** button.
3. Enter Code (1-6 digits) directly using number buttons (0-9).
4. Press the **[ENTER]** button to save each code.



NOTE: Press **[*]** **[0]** button to clear character at cursor.
To continue press **[STAY]** or **[AWAY]** button.

Programming User Codes with GEM-K4RF Keypad

KEYPAD CONFIGURATION MODE



This section will focus on configuring the GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL and GEM-RP4RFC/GEM-K4RF Keypads. For ease of programming, it is recommended that a GEM-RP1CAe2 or a GEM-K1CA be selected (see WI995 for Programming Instructions using the GEM-RP1CAe2 or GEM-K1CA keypads).

KEYPAD INSTALLATION

Each keypad must be assigned an address number (1–7) and each requires its own configuration procedure (see CONFIGURING THE KEYPADS, which follows, and DIRECT ADDRESS KEYPAD AREA OPTIONS). At least 1 keypad must be used; only 1 is required for a single-area Commercial Burglary installation.

GEM-RP2ASe2/GEM-K2AS - are utility LCD keypads combining several preset LCD words with a limited message line. **NOTE:** Due to space constraints, available messages are abbreviated and will scroll automatically.



CONFIGURING THE KEYPADS

Configuring the GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL and GEM-RP4RFC/GEM-K4RF Keypads

Up to 7 GEM-RP2ASe2/GEM-K2AS, GEM-RP3DGTL/GEM-K3DGTL and/or GEM-RP4RFC/GEM-K4RF keypads may be connected to the panel (Keypads 1–7). Each must be configured for a keypad address. In addition, the keypad may be configured to disable (a) touchpad backlight; (b) LCD backlight; and (c) entry sounder. Keypads are configured by the proper selection of jumpers. Refer to the label on the circuit board insulation paper for jumper locations and a summary of settings.

KEYPAD ADDRESS

If more than one keypad is installed:

-  Each must be assigned a unique address (that is, no two keypads may be numbered alike).
-  Keypads must be addressed consecutively (that is, missing numbers are not permitted).

Assign the keypad address number by selecting Jumpers J1–3 in accordance with the table at right.

KEYPAD NUMBER	KEYPAD ADDRESS SETTING			
	1	2	3	PARK
1	OFF or ON	OFF	OFF	STORE SPARE JUMPER AT THIS POSITION
2	OFF	ON	OFF	
3	ON	ON	OFF	
4	OFF	OFF	OFF	
5	ON	OFF	ON	
6	OFF	ON	ON	
7	ON	ON	ON	

TOUCHPAD BACK LIGHT

Cut Jumper A to disable touch pad backlighting to conserve 11mA standby current.

LCD BACKLIGHT

Cut Jumper B to disable LCD backlighting.

DISABLE SOUNDER

Cut Jumper C to disable the sounder. (Do not disable in UL applications).

ALPHABETICAL INDEX

1400HZ HANDSHAKE/KISSOFF, ADDRESS 0461	30	AREA BELL CONTROL OPTIONS (ADDRESS 1477).....	37
1400HZ HANDSHAKE/KISSOFF, ADDRESS 0483	30	AREA BELL CONTROL OPTIONS (ADDRESS 1481).....	37
1400HZ HANDSHAKE/KISSOFF, ADDRESS 0505	30	AREA BELL CONTROL OPTIONS (ADDRESS 1485).....	37
2300HZ HANDSHAKE/KISSOFF, ADDRESS 0461	30	AREA BURG OUTPUT SILENCED	37
2300HZ HANDSHAKE/KISSOFF, ADDRESS 0483	30	AREA OPTIONS	10
2300HZ HANDSHAKE/KISSOFF, ADDRESS 0505	30	AREA PGM1 OUTPUT SILENCED.....	39
24 HOUR AUXILIARY (MODEM CODE).....	33	AREA PGM2 BURG OUTPUT SILENCED	40
24 HOUR ZONES IN AREA 1	7, 14, 15	AREA PULSED BURG OUTPUT SILENCED.....	38
24-HOUR ZONE (ZONE OPTION).....	43	AUTO BELL TEST ON ARMING, ADDRESS 1421	28
2-WIRE FIRE ZONES	13	AUTO BYPASS RE-ENTRY ZONES	8, 14, 15
2-WIRE FIRE ZONES IN AREA 1.....	6	AUTO RESET (ZONE OPTION)	43
2-WIRE SMOKE DETECTORS (ZONE OPTION)	43	AUTO RESET AFTER BURGLARY OUTPUT TIMEOUT, ADDRESS 1421	28
3/1 WITH EXTENDED RESTORES, ADDRESS 0461	30	AUTO-BYPASS (ZONE OPTION).....	43
3/1 WITH EXTENDED RESTORES, ADDRESS 0483	30	AUTO-BYPASS RE-ENTRY (ZONE OPTION).....	43
3/1 WITH EXTENDED RESTORES, ADDRESS 0505	30	AUTOMATIC INTERIOR BYPASS/EASY EXIT, ADDRESS 1424.....	28
50 MS LOOP RESPONSE ZONES	7	AUX 1/AUX 2 OPTIONS	11, 18
50MS LOOP RESPONSE (ZONE OPTION).....	43	AUX OUTPUT ACTIVATED ON ALARM ZONES	14, 15
50MS LOOP RESPONSE ZONES	14, 15	AUX OUTPUT ACTIVATED ON ALARM ZONES	7
ABORT DELAY (ZONE OPTION).....	43	AUXILIARY ALARM (MODEM CODE).....	33
ABORT DELAY, ADDRESS 1417	24	BACKUP REPORT ON TELCO 1 & 2, ADDRESS 0788.....	32
AC FAIL REPORT DELAY, ADDRESS 1419.....	24	BURGLARY (MODEM CODE)	33
ACCESS CONTROL ON PGM2 OUTPUT, ADDRESS 1421.....	28	BURGLARY OUTPUT TURNS OFF UPON DISARM	37
ACCESSING DEALER PROGRAM MODE	5	CALLBACK METHOD.....	4
ACCESSING USER PROGRAM MODE	51	CALLBACK TELEPHONE NUMBER, ADDRESS 0526-0545.....	25
ACTIVATE DOWNLOAD	4	CANCEL NEXT TEST TIMER ON ANY REPORT, ADDRESS 0788.....	32
ADEMCO POINT ID (RECEIVER FORMAT)	30	CENTRAL STATION RECEIVER 1 ACCOUNT NUMBER	9, 16
ADEMCO SLOW, SILENT KNIGHT SLOW (RECEIVER FORMAT).....	30	CENTRAL STATION RECEIVER 1 FORMAT	9, 16
ALARM ON DAY ZONE (ZONE OPTION)	43	CENTRAL STATION RECEIVER 1 TELEPHONE NUMBER	8, 16
ALARM OUTPUT (ZONE OPTION)	43	CHANGE PULSE OUTPUT TO TEMPORAL OUTPUT, ADDRESS 1422	28
ALARM OUTPUT TIMEOUT, ADDRESS 1414.....	25	CHANGING OR CANCELING A CODE.....	10, 17
ALARM RESTORE 1 (ZONE OPTION).....	43	CHIME (ZONE OPTION)	43
ALARM RESTORE 3 (ZONE OPTION).....	43	CHIME 2 (ZONE OPTION)	43
ALARM TELCO 1 (ZONE OPTION)	43	CHIME 2 ZONES IN AREA 1.....	7, 14, 15
ALARM TELCO 3 (ZONE OPTION)	43	CHIME TIME, ADDRESS 1418	24
AREA 1 SYSTEM EVENT/TROUBLE	26	CHIME ZONES IN AREA 1.....	7, 14, 15
AREA BELL CONTROL OPTIONS (ADDRESS 1473).....	37		

ALPHABETICAL INDEX (CONT'D)

CHIRP OUTPUT ON KEYFOB ARM/DISARM, ADDRESS 1422.....	28	1424.....	28
CLEAR DEALER PROGRAM.....	51	DISABLE AUTO DIAL TONE DETECT, ADDRESS 0788.....	32
CLEAR PROGRAM.....	12, 19	DISABLE CALL WAITING ON 1ST ATTEMPT, ADDRESS 2053.....	29
CLEAR PROGRAM OPTIONS (ADDRESS 2285 & 2286).....	51	DISABLE CALLBACK DOWNLOAD, ADDRESS 1422.....	28
CLOSING REPORT ONLY ON CONDITIONAL CLOSE, ADDRESS 1420.....	28	DISABLE CLOSING REPORTS, ADDRESS 0786.....	32
COLD START.....	51	DISABLE CODE REQUIRED FOR EZ BYPASS, ADDRESS 1424.....	28
CONFIGURING THE KEYPADS.....	53	DISABLE KEYPAD FUNCTION MODE DOWNLOAD, ADDRESS 1422.....	28
CONVENTIONS USED IN THIS MANUAL.....	23	DISABLE KEYPAD INSTANT MODE, ADDRESS 1421.....	28
CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 0785, 0786 & 0788).....	32	DISABLE OPENING REPORTS, ADDRESS 0785.....	32
CS RECEIVER 1 FORMAT, ADDRESS 0460.....	30	DISABLE SOUNDER.....	53
CS RECEIVER 2 FORMAT, ADDRESS 0482.....	30	DISABLE SYSTEM TROUBLE AUDIBLE TIMEOUT, ADDRESS 2051.....	29
CS RECEIVER 3 FORMAT, ADDRESS 0504.....	30	DISABLE WAIT FOR HANDSHAKE ON TRANSMIT, ADDRESS 0788.....	32
CS RECEIVER OPTIONS (ADDRESS 0460-0525).....	30	DISABLE WAIT FOR SILENCE (PAGER FORMAT), ADDRESS 0788.....	32
CS RECEIVER TELEPHONE NUMBERS.....	30	DISABLE ZONE FAULT SCROLLING, ADDRESS 1420.....	28
CS SUBSCRIBER ID OPTIONS (ADDRESS 0560-0667).....	31	DON'T CLEAR PGM2 OUTPUT WITH DISARM, ADDRESS 1424.....	28
CS SYSTEM REPORT OPTIONS.....	32	DOWNLOAD/CALLBACK OPTIONS (ADDRESS 2059 & 0526- 0545).....	25
CS SYSTEM REPORTING CODES.....	32	DOWNLOADING FROM A COMPUTER.....	4
CS SYSTEM REPORTING OPTIONS (ADDRESS 0670-0705).....	32	EASY MENU DRIVEN PROGRAM MODE.....	5
CS USER REPORTING OPTIONS (ADDRESS 0800-0813).....	34	EASY MENU-DRIVEN PROGRAM MODE.....	4
CS USER REPORTING OPTIONS (ADDRESS 0818-0831).....	35	EASY PROGRAM MENU.....	13
CS ZONE REPORTING OPTIONS (ADDRESS 0720-0735).....	33	ENABLE "K SERIES" STYLE KEYPADS, ADDRESS 2051.....	29
CUSTOMIZING A DEFAULT PROGRAM.....	5	ENABLE ALARM OUTPUT ON TELCO FAIL ONLY WHEN ARMED, ADDRESS 1423.....	28
DAY ZONE OPEN (ZONE OPTION).....	43	ENABLE AUTOARM IF NOT CLOSED AT END OF WINDOW, ADDRESS 1420.....	28
DAY ZONE SHORT (ZONE OPTION).....	43	ENABLE BURG OUTPUT CHIRP ON KEYFOB.....	8, 14, 15
DEALER CODE.....	11, 19	ENABLE CANCEL REPORT TO TELCO 3, ADDRESS 2051.....	29
DEALER CODE (DEFAULT).....	5	ENABLE CP-01 EGRESS TONES ONLY, ADDRESS 2053.....	29
DEALER PROGRAM.....	5	ENABLE CP-01 LIMITS, ADDRESS 2053.....	29
DEALER PROGRAM MODE.....	4	ENABLE GEM-PRINT MODULE, ADDRESS 2051.....	29
DEFAULT DEALER CODE.....	5	ENABLE GLOBAL AMBUSH CODE, ADDRESS 1422.....	28
DIGITAL DIALER RPT ENTER /EXIT TEST MODE, ADDRESS 2053.....	29	ENABLE KEYPAD 1 ONLY PROGRAMMING, ADDRESS 2053.....	29
DIRECT ADDRESS PROGRAM MODE.....	20	ENABLE KEYPAD SET TIME/DATE MESSAGE, ADDRESS 2051.....	29
DIRECT ADDRESS PROGRAM MODE (ACCESS).....	22	ENABLE KEYPAD TIME/DATE DISPLAY, ADDRESS 1420.....	28
DIRECT ADDRESS PROGRAM MODE KEYPAD COMMANDS.....	21		
DISABLE [ON/OFF] AS EASY EXIT, ADDRESS 2051.....	29		
DISABLE 2ND CALL ANS. MACHINE OVERRIDE, ADDRESS			

ALPHABETICAL INDEX (CONT'D)

ENABLE LINE-FAULT TEST, ADDRESS 1423	28	GAS ALARM (MODEM CODE)	33
ENABLE LOCAL ALARM ON FIRST ZONE AND TRIP, ADDRESS 1421	28	GEM-P816 WIRING DIAGRAM	64
ENABLE MANAGER'S MODE, ADDRESS 1421	28	GEM-RP2ASE2/GEM-K2AS KEYPAD EASY PROGRAM MENU	6
ENABLE NO EOLR ZONES	8, 14, 15	GEM-RP3DGTL/GEM-K3DGTL AND GEM-RP4RFC/GEM- K4RF KEYPAD EASY PROGRAM MENU	13
ENABLE RESIDENTIAL FIRE, ADDRESS 1422	28	GENERAL PROGRAMMING STEPS	23
ENABLE SIA CP-01	8, 14, 15	GLOBAL AMBUSH CODE, ADDRESS 2045	26
ENABLE TCP/IP AES RPT (ADDRESS 0461)	30	GLOBAL SYSTEM EVENT/TROUBLE	26
ENABLE TCP/IP AES RPT (ADDRESS 0483)	30	HEAT ALARM (MODEM CODE)	33
ENABLE TCP/IP AES RPT (ADDRESS 0505)	30	HOLD UP (MODEM CODE)	33
ENABLE TCP/IP COMMUNICATIONS, ADDRESS 2054	29	INCL. SEL./GRP. BYPASS IN COND. CLOSE /STATUS, ADDRESS 1420	28
ENABLE TELCO LINE FAULT TEST	8, 14, 15	INHIBIT SYSTEM TROUBLE AUDIBLE AT KEYPAD, ADDRESS 1423	28
ENABLE ZONE NUMBER ON PULSE ALARM, ADDRESS 0461	30	INTERIOR (STAY) BYPASS (ZONE OPTION)	43
ENABLE ZONE NUMBER ON PULSE ALARM, ADDRESS 0483	30	INTERIOR (STAY) BYPASS ZONES IN AREA 1	7
ENABLE ZONE NUMBER ON PULSE ALARM, ADDRESS 0505	30	INTERIOR NORMALLY BYPASSED, ADDRESS 1422	28
ENTER USER CODES	9, 16	INTERIOR ZONES	14, 15
ENTRY DELAY 2, ADDRESS 0002	24	KEYFOB TRANSMITTERS	18
ENTRY DELAY, ADDRESS 0001	24	KEYFOB TRANSMITTERS AS ARM/DISARM & CONTROL DEVICES	11
ENTRY/EXIT 1 (ZONE OPTION)	43	KEYFOB TRANSMITTERS AS ZONE INPUT DEVICES	11, 18
ENTRY/EXIT 2 (ZONE OPTION)	43	KEYFOB ZONE ASSIGNMENT	11, 18
ERASE DEALER PROGRAM	51	KEYPAD ADDRESS	53
ERASE ENTIRE PROGRAM	51	KEYPAD ADDRESS PROGRAM MODE DISPLAY	21
EXIT DEALER PROGRAM MODE	12, 19	KEYPAD CONFIGURATION MODE	53
EXIT DELAY, ADDRESS 0000	24	KEYPAD EASY PROGRAM MENU	13
EXIT TIME RESTART, ADDRESS 2053	29	KEYPAD INSTALLATION	53
EXIT/ENTRY DELAYS	24	KEYPAD OPTIONS (ADDRESS 1425-1431, 1440-1446)	41
EXIT/ENTRY FOLLOWER (ZONE OPTION)	43	KEYPAD PROGRAMMING	4
EXIT/ENTRY ZONES	13	KEYPAD PROGRAMMING OVERVIEW	20
EXIT/ENTRY ZONES IN AREA 1	6	KEYPAD SOUNDER ON ALARM (ZONE OPTION)	43
EXIT/ENTRY2 ZONES IN AREA 1	7, 15	KEYPAD SOUNDER ON ALARM ZONES	7, 14, 15
EZM GROUP OPTIONS (ADDRESS 1455-1456)	36	KEYPAD TYPE	41
FIRE (ZONE OPTION)	43	KEYSWITCH ARMING (ZONE OPTION)	43
FIRE (MODEM CODE)	33	LCD BACKLIGHT	53
FIRE ALARM VERIFICATION (ZONE OPTION)	43	LEADING DIGITS FOR PAGER FORMAT, ADDRESS 0546- 0547	25
FIRE ZONES	13	LINE-FAULT TEST ONLY WHEN ARMED, ADDRESS 1423	28
FIRE ZONES IN AREA 1	6		
FUNCTION MODE	4		

ALPHABETICAL INDEX (CONT'D)

LOCAL DOWNLOADING.....	4	PULSE ALARM OUTPUT TIMEOUT, ADDRESS 1415.....	25
LOCAL OR CENTRAL STATION REPORTING SYSTEM.....	6	PULSE EVENT CODE.....	33
LOCAL SYSTEM OR C.S. REPORTING SYSTEM.....	13	PULSED ALARM OUTPUT (ZONE OPTION).....	43
LUG E15 AREA 1 ARMED AWAY ONLY, ADDRESS 2052.....	29	PULSED BURG OUTPUT TURNS OFF UPON DISARM.....	38
MAINTAINED KEYSWITCH ARMING, ADDRESS 1421.....	28	QUICK ENROLL METHOD.....	10, 17
MODEM CODES.....	33	RADIONICS FAST (RECEIVER FORMAT).....	30
MULTIPLE AREA SYSTEM.....	6	RADIONICS, DCI, FRANKLIN SLOW (RECEIVER FORMAT).....	30
NEVER ARM (ZONE OPTION).....	43	RECEIVER TELCO OPTIONS.....	30
NO EOL RESISTOR (ZONE OPTION).....	43	REMOTE DOWNLOADING.....	4
NUMBER OF KEYPADS.....	16	REPORT CANCEL WINDOW, ADDRESS 2055.....	24
NUMBER OF KEYPADS IN AREA 1.....	8	RESET DAY ZONE WITH ARM/DISARM ONLY, ADDRESS 1422.....	28
NUMBER OF RF RECEIVERS, ADDRESS 2056.....	50	RESOUND ON WIRELESS SMOKE LOW BATTERY, ADDRESS 1424.....	28
NUMBER OF RINGS BEFORE PICKUP, ADDRESS 2059.....	25	RF RECEIVER & SUPERVISORY TIMER OPTIONS (ADDRESS 2029-2044 & 2056).....	50
OPENING REPORT ONLY AFTER ALARM REPORT, ADDRESS 1420.....	28	RF RECEIVERS (NUMBER OF), ADDRESS 2056.....	50
OUTPUT TIMEOUTS.....	25	RF SUPERVISORY TIMERS.....	50
OUTPUT TURNS OFF UPON DISARM.....	37, 38, 39, 40	RF TRANSMITTER POINTS.....	10, 17
PAGER (RECEIVER FORMAT).....	30	ROTARY DIALING.....	32
PAGER FORMAT OPTIONS (ADDRESS 0546 & 0547).....	25	RPT EXIT ERR/RECENT CLOSE, ADDRESS 2053.....	29
PANIC (MODEM CODE).....	33	SELECT ALARM OUTPUT FOR KEYFOB CHIRP, ADDRESS 1423.....	28
PCI2000/3000.....	4	SELECTIVE BYPASS (ZONE OPTION).....	43
PGM ON RF TRANSMITTER TAMPER, ADDRESS 2052.....	29	SENSOR WATCH (ZONE OPTION).....	43
PGM1 OUTPUT (ZONE OPTION).....	43	SENSOR WATCH TIME, ADDRESS 2050.....	24
PGM1 OUTPUT TIMEOUT, ADDRESS 1416.....	25	SENSOR WATCH ZONES.....	7, 14, 15
PGM1 OUTPUT TURNS OFF UPON DISARM.....	39	SIA (RECEIVER FORMAT).....	30
PGM2 OUTPUT (ZONE OPTION).....	43	SILENT KNIGHT FAST (RECEIVER FORMAT).....	30
PGM2 OUTPUT ACCESS CNTRL TIMEOUT, ADDRESS 1413.....	24	SINGLE DIGIT ONLY, ADDRESS 0461.....	30
PGM2 OUTPUT TIMEOUT, ADDRESS 1412.....	25	SINGLE DIGIT ONLY, ADDRESS 0483.....	30
PGM2 OUTPUT TURNS OFF UPON DISARM.....	40	SINGLE DIGIT ONLY, ADDRESS 0505.....	30
POWER-UP DELAY (ZONE OPTION).....	43	SOUND ALARM ON EXIT ERROR, ADDRESS 2053.....	29
PRE-ALARM WARNING (ZONE OPTION).....	43	STATUS REPORT, ADDRESS 1420.....	28
PRIORITY (ZONE OPTION).....	43	SUM CHECK, ADDRESS 0461.....	30
PRIORITY AREA ARMING.....	36	SUM CHECK, ADDRESS 0483.....	30
PRIORITY WITH BYPASS (ZONE OPTION).....	43	SUM CHECK, ADDRESS 0505.....	30
PROGRAMMING STEPS.....	23	SUPERVISORY TIMERS, RF.....	50
PROGRAMMING TIMEOUTS.....	24		
PROGRAMMING USER CODES.....	52		

ALPHABETICAL INDEX (CONT'D)

SUPPRESS BYPASS REMINDER WHEN ARMED, ADDRESS 1421.....	28	ZONE 6 TEMPERATURE SENSOR.....	42
SWINGER SHUTDOWN (ZONE OPTION).....	43	ZONE ANDING GROUP 1-4 (ZONE OPTION).....	43
SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 1413, 1417, 2050 & 2055).....	24	ZONE AREA 1 (ZONE OPTION).....	43
SYSTEM DELAYS & TIMEOUTS (ADDRESS 1418 & 1419).....	24	ZONE OPTIONS - ZONES 1 TO 16 (ADDRESS 0900-1016).....	43
SYSTEM OPTIONS (ADDRESS 0836-0863 & 2045).....	26		
SYSTEM OPTIONS (ADDRESS 1420-1424).....	28		
SYSTEM OPTIONS (ADDRESS 2051-2054).....	29		
SYSTEM OUTPUT TIMEOUTS (ADDRESS 1412 & 1414-1416).....	25		
SYSTEM PROGRAMMING OPTIONS.....	4		
SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/ TROUBLE.....	26		
TCP/IP PANEL/SITE INITIATED FUNCTIONS (ADDRESS 2054).....	29		
TEMPERATURE DISPLAY AT KEYPAD (ADDRESS 1666- 1668).....	42		
TOTAL NUMBER OF ZONES IN AREA 1.....	6		
TOUCHPAD BACK LIGHT.....	53		
TOUCH-TONE DIALING ONLY, ADDRESS 0788.....	32		
TOUCH-TONE DIALING W/ROTARY BACKUP, ADDRESS 0788.....	32		
TROUBLE ON OPEN (ZONE OPTION).....	43		
TROUBLE ON SHORT (ZONE OPTION).....	43		
TROUBLE RESTORE 1 (ZONE OPTION).....	43		
TROUBLE RESTORE 3 (ZONE OPTION).....	43		
TROUBLE TELCO 1 (ZONE OPTION).....	43		
TROUBLE TELCO 3 (ZONE OPTION).....	43		
TWO-WIRE FIRE ZONES.....	13		
UNIVERSAL HIGH SPEED (RECEIVER FORMAT).....	30		
USER CODES.....	9		
USER CODES, PROGRAMMING.....	52		
USER OPTIONS.....	17		
USER PROGRAM MODE.....	4, 51		
VERI-PHONE AUDIO PRIORITY OVER ALARMS, ADDRESS 1424.....	28		
VERI-PHONE ZONES TRIP PGM2 OUTPUT, ADDRESS 1424.....	28		
WIRELESS TROUBLE ACTIVATES TELCO 1, ADDRESS 1423.....	28		
WIRELESS TROUBLE ACTIVATES TELCO 3, ADDRESS 1423.....	28		
WIRING DIAGRAM.....	64		

ADDRESS NUMBER LOCATION INDEX

ADDRESS 0000	EXIT DELAY	24
ADDRESS 0000-0002	SYSTEM DELAYS & TIMEOUTS	24
ADDRESS 0001	Entry Delay	24
ADDRESS 0002	ENTRY DELAY 2	24
ADDRESS 0460	CS Receiver 1 Format	30
ADDRESS 0460-0525	CS RECEIVER OPTIONS	30
ADDRESS 0461	1400Hz Handshake/Kissoff	30
ADDRESS 0461	2300Hz Handshake/Kissoff	30
ADDRESS 0461	3/1 with Extended Restores	30
ADDRESS 0461	Enable Zone Number on Pulse Alarm	30
ADDRESS 0461	Single Digit Only	30
ADDRESS 0461	Sum Check	30
ADDRESS 0461	Enable TCP/IP AES RPT	30
ADDRESS 0482	CS Receiver 2 Format	30
ADDRESS 0483	1400Hz Handshake/Kissoff	30
ADDRESS 0483	2300Hz Handshake/Kissoff	30
ADDRESS 0483	3/1 with Extended Restores	30
ADDRESS 0483	Enable Zone Number on Pulse Alarm	30
ADDRESS 0483	Single Digit Only	30
ADDRESS 0483	Sum Check	30
ADDRESS 0483	Enable TCP/IP AES RPT	30
ADDRESS 0504	CS Receiver 3 Format	30
ADDRESS 0505	1400Hz Handshake/Kissoff	30
ADDRESS 0505	2300Hz Handshake/Kissoff	30
ADDRESS 0505	3/1 with Extended Restores	30
ADDRESS 0505	Enable Zone Number on Pulse Alarm	30
ADDRESS 0505	Single Digit Only	30
ADDRESS 0505	Sum Check	30
ADDRESS 0505	Enable TCP/IP AES RPT	30
ADDRESS 0526-0545	Callback Telephone Number	25
ADDRESS 0526-0545	DOWNLOAD/CALLBACK OPTIONS	25
ADDRESS 0546-0547	LEADING DIGITS FOR PAGER FORMAT	25
ADDRESS 0546-0547	PAGER FORMAT OPTIONS	25
ADDRESS 0560-0667	CS SUBSCRIBER ID OPTIONS	31
ADDRESS 0670-0705	CS SYSTEM REPORTING OPTIONS	32
ADDRESS 0720-0735	CS ZONE REPORTING OPTIONS	33
ADDRESS 0785	CS AREA & SYSTEM REPORTING OPTIONS	32
ADDRESS 0785	DISABLE OPENING REPORTS	32
ADDRESS 0786	CS AREA & SYSTEM REPORTING OPTIONS	32
ADDRESS 0786	DISABLE CLOSING REPORTS	32
ADDRESS 0788	Backup Report on Telco 1 & 2	32
ADDRESS 0788	Cancel Next Test Timer on any Report	32
ADDRESS 0788	CS AREA & SYSTEM REPORTING OPTIONS	32
ADDRESS 0788	Disable Auto Dial Tone Detect	32
ADDRESS 0788	Disable Wait for Handshake on Transmit	32
ADDRESS 0788	Disable Wait for Silence (Pager Format)	32
ADDRESS 0788	Touch-tone Dialing Only	32
ADDRESS 0788	Touch-tone Dialing w/Rotary Backup	32
ADDRESS 0800-0813	CS USER REPORTING OPTIONS	34
ADDRESS 0818-0831	CS USER REPORTING OPTIONS	35

ADDRESS NUMBER LOCATION INDEX (CONT'D)

ADDRESS 0836-0863.....	SYSTEM OPTIONS.....	26
ADDRESS 0900-1016.....	ZONE OPTIONS - ZONES 1 TO 16.....	43
ADDRESS 1412.....	PGM2 Output Timeout.....	25
ADDRESS 1412.....	SYSTEM OUTPUT TIMEOUTS.....	25
ADDRESS 1413.....	PGM2 Output Access Cntrl Timeout.....	24
ADDRESS 1413.....	SYSTEM DELAYS & TIMEOUTS.....	24
ADDRESS 1414.....	Alarm Output Timeout.....	25
ADDRESS 1414-1416.....	SYSTEM OUTPUT TIMEOUTS.....	25
ADDRESS 1415.....	Pulse Alarm Output Timeout.....	25
ADDRESS 1416.....	PGM1 Output Timeout.....	25
ADDRESS 1417.....	ABORT DELAY.....	24
ADDRESS 1417.....	SYSTEM DELAYS & TIMEOUTS.....	24
ADDRESS 1418.....	CHIME TIME.....	24
ADDRESS 1418-1419.....	SYSTEM DELAYS & TIMEOUTS.....	24
ADDRESS 1419.....	AC Fail Report Delay.....	24
ADDRESS 1420.....	Closing Report Only on Conditional Close.....	28
ADDRESS 1420.....	Disable Zone Fault Scrolling.....	28
ADDRESS 1420.....	Enable AutoArm if not closed at end of Window.....	28
ADDRESS 1420.....	Enable Keypad Time/Date Display.....	28
ADDRESS 1420.....	Incl. Sel./Grp. Bypass in Cond. Close /Status.....	28
ADDRESS 1420.....	Opening Report Only after Alarm Report.....	28
ADDRESS 1420.....	Status Report.....	28
ADDRESS 1420-1424.....	SYSTEM OPTIONS.....	28
ADDRESS 1421.....	Access Control on PGM2 Output.....	28
ADDRESS 1421.....	Auto Bell Test on Arming.....	28
ADDRESS 1421.....	Auto Reset after Burglary Output Timeout.....	28
ADDRESS 1421.....	Disable Keypad Instant Mode.....	28
ADDRESS 1421.....	Enable Local Alarm on First Zone AND Trip.....	28
ADDRESS 1421.....	Enable Manager's Mode.....	28
ADDRESS 1421.....	Maintained Keyswitch Arming.....	28
ADDRESS 1421.....	Suppress Bypass Reminder when Armed.....	28
ADDRESS 1422.....	Change Pulse Output to Temporal Output.....	28
ADDRESS 1422.....	Chirp Output on Keyfob Arm/Disarm.....	28
ADDRESS 1422.....	Disable Callback Download.....	28
ADDRESS 1422.....	Disable Keypad Function Mode Download.....	28
ADDRESS 1422.....	Enable Global Ambush Code.....	28
ADDRESS 1422.....	Enable Residential Fire.....	28
ADDRESS 1422.....	Interior Normally Bypassed.....	28
ADDRESS 1422.....	Reset Day Zone with Arm/Disarm Only.....	28
ADDRESS 1423.....	Enable Alarm Output on Telco Fail only when Armed.....	28
ADDRESS 1423.....	Enable Line-Fault Test.....	28
ADDRESS 1423.....	Inhibit System Trouble Audible at Keypad.....	28
ADDRESS 1423.....	Line-Fault Test only when Armed.....	28
ADDRESS 1423.....	Select Alarm Output for Keyfob Chirp.....	28
ADDRESS 1423.....	Wireless Trouble Activates Telco 1.....	28
ADDRESS 1423.....	Wireless Trouble Activates Telco 3.....	28
ADDRESS 1424.....	Automatic Interior Bypass/Easy Exit.....	28
ADDRESS 1424.....	Disable 2nd Call Ans. Machine Override.....	28
ADDRESS 1424.....	Disable Code Required for EZ Bypass.....	28
ADDRESS 1424.....	Don't Clear PGM2 Output with Disarm.....	28
ADDRESS 1424.....	Resound on Wireless Smoke Low Battery.....	28

ADDRESS NUMBER LOCATION INDEX (CONT'D)


ADDRESS 1424	Veri-phone Audio Priority Over Alarms.....	28
ADDRESS 1424	Veri-phone Zones Trip PGM2 Output.....	28
ADDRESS 1425-1431	KEYPAD OPTIONS	41
ADDRESS 1440-1446	KEYPAD OPTIONS	41
ADDRESS 1455-1456	EZM GROUP OPTIONS	36
ADDRESS 1473	AREA BELL CONTROL OPTIONS	37
ADDRESS 1477	AREA BELL CONTROL OPTIONS	37
ADDRESS 1481	AREA BELL CONTROL OPTIONS	37
ADDRESS 1485	AREA BELL CONTROL OPTIONS	37
ADDRESS 1666-1668	Temperature Display at Keypad	42
ADDRESS 2029-2044	RF RECEIVER & supervisory timer options	50
ADDRESS 2045	GLOBAL AMBUSH CODE	26
ADDRESS 2045	SYSTEM OPTIONS	26
ADDRESS 2050	Sensor Watch Time	24
ADDRESS 2050	SYSTEM DELAYS & TIMEOUTS	24
ADDRESS 2051	Disable [ON/OFF] as Easy Exit	29
ADDRESS 2051	Disable System Trouble Audible Timeout	29
ADDRESS 2051	Enable "K Series" Style Keypads	29
ADDRESS 2051	Enable Cancel Report to Telco 3	29
ADDRESS 2051	Enable GEM-PRINT Module	29
ADDRESS 2051	Enable Keypad Set Time/Date Message.....	29
ADDRESS 2051-2054	SYSTEM OPTIONS	29
ADDRESS 2052	Lug E15 Area 1 Armed Away Only	29
ADDRESS 2052	PGM on RF Transmitter Tamper	29
ADDRESS 2053	Digital Dialer Rpt Enter /Exit Test Mode	29
ADDRESS 2053	Disable Call Waiting on 1st Attempt	29
ADDRESS 2053	Enable CP-01 Egress Tones Only	29
ADDRESS 2053	Enable CP-01 Limits	29
ADDRESS 2053	Enable Keypad 1 Only Programming	29
ADDRESS 2053	Exit Time Restart	29
ADDRESS 2053	Rpt Exit Err/Recent Close	29
ADDRESS 2053	Sound Alarm On Exit Error.....	29
ADDRESS 2054	Enable TCP/IP Communications.....	29
ADDRESS 2054	TCP/IP Panel/Site Initiated Functions	29
ADDRESS 2055	Report Cancel Window	24
ADDRESS 2055	SYSTEM DELAYS & TIMEOUTS	24
ADDRESS 2056	Number of RF Receivers.....	50
ADDRESS 2056	RF RECEIVER & supervisory timer options	50
ADDRESS 2056	RF Receivers (number of).....	50
ADDRESS 2059	DOWNLOAD/CALLBACK OPTIONS	25
ADDRESS 2059	NUMBER OF RINGS BEFORE PICKUP	25
ADDRESS 2285-2286	Clear program OPTIONS	51

NOTES

NOTES



GEM-P816 WIRING DIAGRAM



Smoke Detector Compatibility Identifier GEM-P816